

PHOTOGRAPH THIS SHEET

AD A 129 294

DTIC ACCESSION NUMBER



LEVEL



INVENTORY

"Thermophysical Properties of Selected Materials.
Part I: Properties"

20^b/Y

DOCUMENT IDENTIFICATION

1976


DISTRIBUTION STATEMENT A

Approved for public release;
Distribution Unlimited

DISTRIBUTION STATEMENT

ACCESSION FOR	
NTIS	GRA&I
DTIC	TAB
UNANNOUNCED	
JUSTIFICATION	
BY	
DISTRIBUTION /	
AVAILABILITY CODES	
DIST	AVAIL AND/OR SPECIAL
A	21

DISTRIBUTION STAMP



DATE ACCESSIONED

83 05 18 018

DATE RECEIVED IN DTIC

PHOTOGRAPH THIS SHEET AND RETURN TO DTIC-DDA-2

AD-A292947

**THERMOPHYSICAL PROPERTIES OF
SELECTED AEROSPACE MATERIALS**


PART I: THERMAL RADIATIVE PROPERTIES

S. S. POULAKOS AND C. T. HO, Editors

**THERMOPHYSICAL AND ELECTRONIC PROPERTIES INFORMATION CENTER
CINDAS - Purdue University**

**DISTRIBUTION STATEMENT A
Approved for public release;
Distribution Unlimited**

DISCLAIMER NOTICE



**THIS DOCUMENT IS BEST
QUALITY AVAILABLE. THE COPY
FURNISHED TO DTIC CONTAINED
A SIGNIFICANT NUMBER OF
PAGES WHICH DO NOT
REPRODUCE LEGIBLY.**

Unclassified

SECURITY CLASSIFICATION OF THIS PAGE (When Data Entered)

REPORT DOCUMENTATION PAGE		READ INSTRUCTIONS BEFORE COMPLETING FORM
1. REPORT NUMBER	2. GOVT ACCESSION NO.	3. RECIPIENT'S CATALOG NUMBER
4. TITLE (and Subtitle) "Thermophysical Properties of Selected Materials. Part I: Properties"		5. TYPE OF REPORT & PERIOD COVERED Data Book (See block 18)
		6. PERFORMING ORG. REPORT NUMBER
7. AUTHOR(s) Touloukian, Y. S. and Ho, C. Y.		8. CONTRACT OR GRANT NUMBER(s) DSA 900-76-C-0860
9. PERFORMING ORGANIZATION NAME AND ADDRESS CINDAS/Purdue University 2595 Yeager Road West Lafayette, IN 47906		10. PROGRAM ELEMENT, PROJECT, TASK AREA & WORK UNIT NUMBERS
11. CONTROLLING OFFICE NAME AND ADDRESS Defense Logistics Agency DTIC-AI/Cameron Station Alexandria, VA 22314		12. REPORT DATE 1976
14. MONITORING AGENCY NAME & ADDRESS (if different from Controlling Office) Army Materials & Mechanics Research Center Attn: DRXMR-P/Arsenal Street Watertown, MA 02172		13. NUMBER OF PAGES 1.058
		15. SECURITY CLASS. (of this report) Unclassified
		15a. DECLASSIFICATION/DOWNGRADING SCHEDULE
16. DISTRIBUTION STATEMENT (of this Report) Unlimited		
17. DISTRIBUTION STATEMENT (of the abstract entered in Block 20, if different from Report)		
18. SUPPLEMENTARY NOTES TEPIAC Publication (DTIC Source Code 413571) Limited hard copies on Data Book available from TEPIAC (see address in block 9 above). Discounted price: \$35.00 Microfiche copies also available from DTIC		
19. KEY WORDS (Continue on reverse side if necessary and identify by block number) *Emittance--*Reflectance--*Absorptance--*Transmittance--*Thermal Radiative Properties--*Thermophysical Properties--*Metals--*Dome Materials--*Transparent Materials--*Composites--aluminum alloys--stainless steels--titanium alloys--manganese steel--aluminum oxide--boron nitride--calcium aluminum silicate-- (continued on reverse side)		
20. ABSTRACT (Continue on reverse side if necessary and identify by block number) This volume presents the most comprehensively compiled experimental data and the critically evaluated and recommended values for the thermal radiative properties (hemispherical, normal, angular) spectral emittance, reflectance, absorptance, and transmittance of twenty-seven selected aircraft/spaceship structural materials of technological interest. (continued on reverse side)		

Unclassified

SECURITY CLASSIFICATION OF THIS PAGE(When Data Entered)

magnesium fluoride--pyroceram--silica--silicon carbide--silicon nitride--acrylic resins--lucite--silicone resins--plastics--boron composites--graphite composites--glass composites--epoxy composites--aluminized grafoil

20. ABSTRACT (Cont)

Each subproperty is treated with respect to both wavelength and temperature dependences whenever possible. In the compilation of experimental data, all available data covering from the photographic region of the spectrum up to 100 microns are included. The recommended values resulting from critical evaluation, analysis, and synthesis of the available data and information cover the wavelength range of present interest from visible region to the infrared, if possible. Furthermore, the recommended values as a function of temperature are given for four particularly useful wavelengths.

The experimental data and the recommended values for each dependence of each subproperty of each material are presented in both tabular and graphical forms, together with a discussion text and a specification table. The former reviews and discusses the available data and information, the theoretical guidelines and other factors on which the critical evaluation, analysis, and synthesis of data are based, and the considerations involved in arriving at the final assessment and recommendations, and the latter gives the information on the specimen characterization and measurement method and condition for each set of experimental data.

In order to enable the user to fully utilize and property interpret the data and information presented in this reference work and also to enhance the usefulness of the data themselves, the theoretical background of thermal radiative properties is given at the beginning of the volume. Since most of the selected materials are not well known, a concise description of each of the materials is given at the beginning of each of the subsections.

Unclassified

SECURITY CLASSIFICATION OF THIS PAGE(When Data Entered)

PREFACE

This volume was prepared by the Thermophysical and Electronic Properties Information Analysis Center (TEPIAC), a DOD Information Analysis Center operated by the Center for Information and Numerical Data Analysis and Synthesis (CINDAS), Purdue University, West Lafayette, Indiana.

The overall program is aimed at providing data and information on all the important thermophysical properties of twenty-seven selected aerospace materials. This Part I contains data and information on thermal radiative properties only. Other parts are in preparation to cover other thermophysical properties.

Because of the extensive scope and highly specialized nature of the work, the staff who contributed to this volume were drawn not only from TEPIAC but also from other CINDAS programs. The following key personnel comprised the team responsible for the authorship (including data compilation, evaluation, and generation of recommended values) of the sections on the various selected materials: Mr. M. W. Johnson (Aluminum Alloy 2024), Dr. P. D. Desai (Aluminum Alloy 7075 and Titanium Alloy Ti-6Al-4V), Mr. T. Y. R. Lee (AISI 304 Stainless Steel), Dr. R. A. Matula (Aluminum oxide, boron nitride, calcium aluminum silicate, magnesium fluoride, Pyroceram, and vitreous silica), Mr. T. N. Havill (silicon), Dr. K. Y. Wu (silicon carbide), Dr. T. C. Chi (silicon nitride, acrylic resins, Lucite, polycarbonate plastics, and silicone resins), and Dr. H. H. Li (aluminized grafoil, boron fiber aluminum matrix composite, graphite fiber aluminum matrix composite, boron fiber epoxy composite, glass fiber epoxy composite, and graphite fiber epoxy composite). The Scientific Documentation Division of TEPIAC provided the in-depth search of the literature supplemental to its basic coverage.

We wish to take this opportunity to acknowledge the assistance provided by many of our friends both in governmental laboratories and in industry. In most cases this assistance has taken the form of providing reports or papers not readily available.

It is hoped that the present volume will prove useful to a large technical community as it provides a wealth of knowledge heretofore unknown or inaccessible to many. In particular, it is felt that the critical evaluation, analysis and reference data recommendation, whenever possible, constitute perhaps the most unique aspect of this work.

In putting a volume of this magnitude together it is nearly impossible to avoid some errors and omissions. It is hoped that we were able to keep these to a minimum. The editors and contributors would be most grateful if those who use this volume bring to their attention any additional known data or any possible errors that might have been inadvertently committed.

Y. S. TOULOUKIAN
Director of CINDAS
Distinguished Atkins Professor of
Engineering
Purdue University

SUMMARY

This volume presents the most comprehensively compiled experimental data and the critically evaluated and recommended values for the thermal radiative properties (hemispherical, normal, angular) spectral emittance, reflectance, absorptance, and transmittance of twenty-seven selected aircraft/spacecraft structural materials of technological interest.

Each subproperty is treated with respect to both wavelength and temperature dependences whenever possible. In the compilation of experimental data, all available data covering from the photographic region of the spectrum up to 100 μm are included. The recommended values resulting from critical evaluation, analysis, and synthesis of the available data and information cover the wavelength range of present interest from visible region (below 1 μm) to the infrared of 15 μm , if possible. Furthermore, the recommended values as a function of temperature are given for four particularly useful wavelengths (whenever possible): 2.8 μm , 3.8 μm , 5.0 μm , and 10.6 μm .

The experimental data and the recommended values for each dependence of each subproperty of each material are presented in both tabular and graphical forms, together with a discussion text and a specification table. The former reviews and discusses the available data and information, the theoretical guidelines and other factors on which the critical evaluation, analysis, and synthesis of data are based, and the considerations involved in arriving at the final assessment and recommendations, and the latter gives the information on the specimen characterization and measurement method and condition for each set of experimental data.

In order to enable the user to fully utilize and properly interpret the data and information presented in this reference work and also to enhance the usefulness of the data themselves, the theoretical background of thermal radiative properties is given at the beginning of the volume. Since most of the selected materials are not well known, a concise description of each of the materials is given at the beginning of each of the subsections.

The material and property coverage of this volume is summarized in the table entitled "Page Index to Materials and Properties" which appears on the next page.

PAGE INDEX TO MATERIALS AND PROPERTIES*

Page No. Material	Property				Emissance				Reflectance				Absorptance				Transmittance											
	HSE (λ)	HSE (T)	NSE (λ)	NSE (T)	ASE (T)	ASE (λ)	HSR (λ)	HSR (T)	NSR (λ)	NSR (T)	ASR (λ)	ASR (T)	ASA (λ)	ASA (T)	NSA (λ)	NSA (T)	ASA (λ)	ASA (T)	HST (λ)	HST (T)	NST (λ)	NST (T)	AST (λ)	AST (T)				
Aluminum Alloy 2024		28	38	41			46	61	64		94	102	108		113	113	113	113	113	113	113	113	113	113	113			
Aluminum Alloy 7075		114	120				126	132		135		138		141	141	141	141	141	141	141	141	141	141	141	141	141		
AISI 304 Stainless Steel		142	152			155	161	164		168	174		180	180	180	180	180	180	180	180	180	180	180	180	180	180		
Titanium Alloy Ti-6Al-4V		181	188	192		195	201	205		211	217	221		224	224	224	224	224	224	224	224	224	224	224	224	224	224	
Hadfield Manganese Steel																												
Aluminum Oxide		226	247			253	260		265	269		270		274														
Boron Nitride		279	289			295	307																					
Calcium Aluminum Silicate		320	329			332	342																					
Magnesium Fluoride		363	376			379	387																					
Pyroceram (Corning 9606)		419	423			427																						
Silica (Vitreous)		447	468			477	488	491		500		509																
Silicon		532	551			558																						
Silicon Carbide		593	606			613																						
Silicon Nitride		647				654																						
Acrylic Resins		684				690																						
Lucite		728				731	737																					
Polycarbonate Plastics		766				770	776																					
Polyphenylquinoxaline																												
Silicone Resins		805				813	822																					
Aluminized Gratafol		879	882			885	888																					
Boron Fiber/Aluminum		900	903			906	909																					
Graphite Fiber/Aluminum		921	924			927	930																					
Boron Fiber/Epoxy		941	944			947	953																					
Glass Fiber/Epoxy		963	966			969	975																					
Graphite Fiber/Epoxy		985	989			992	998																					
Silicon Nitride/Graphite Fiber																												
Silicon Nitride/Vitreous Silica																												

* In the column headings, H = Hemispherical, N = Normal, A (in the first position) = Angular, S = Spectral, E = Emissance, R = Reflectance, A (in the third position) = Absorptance, T = Transmittance, (λ) = Wavelength dependence, and (T) = Temperature dependence. Blank space indicates that no information is available.

CONTENTS

	Page
PREFACE	iii
SUMMARY	iv
LIST OF TABLES	viii
LIST OF FIGURFS	xxiii
LIST OF SYMBOLS	xxxv
1. INTRODUCTION	1
2. THEORETICAL BACKGROUND	3
2.1. General Remarks	3
2.2. Terminology	5
2.3. Interrelationships between Thermal Radiative Properties	9
2.4. Fresnel Equations for Specular Reflection	11
2.5. Thermal Radiative Properties of Metals	13
2.6. Thermal Radiative Properties of Nonmetallic Solids	18
3. DATA EVALUATION AND GENERATION OF RECOMMENDED VALUES	24
4. THERMAL RADIATIVE PROPERTIES OF SELECTED MATERIALS	26
4.1. Aluminum Alloy 2024 M. W. Johnson	27
4.2. Aluminum Alloy 7075 P. D. Desai	114
4.3. AISI 304 Stainless Steel T. Y. R. Lee	142
4.4. Titanium Alloy Ti-6Al-4V P. D. Desai	181
4.5. Hadfield Manganese Steel	225
4.6. Aluminum Oxide R. A. Matula	226
4.7. Boron Nitride R. A. Matula	279
4.8. Calcium Aluminum Silicate R. A. Matula	320
4.9. Magnesium Fluoride R. A. Matula	363
4.10. Pyroceram R. A. Matula	418

4.11.	Silica (Vitreous)	447
	R. A. Matula		
4.12.	Silicon	530
	T. N. Havill		
4.13.	Silicon Carbide	593
	K. Y. Wu		
4.14.	Silicon Nitride	647
	T. C. Chi		
4.15.	Acrylic Resins	683
	T. C. Chi		
4.16.	Lucite	727
	T. C. Chi		
4.17.	Polycarbonate Plastics	765
	T. C. Chi		
4.18.	Polyphenylquinoxaline	802
4.19.	Silicone Resins	804
	T. C. Chi		
4.20.	Aluminized Grafoil	847
	H. H. Li		
4.21.	Boron Fiber Aluminum Matrix Composite	898
	H. H. Li		
4.22.	Graphite Fiber Aluminum Matrix Composite	919
	H. H. Li		
4.23.	Boron Fiber Epoxy Composite	940
	H. H. Li		
4.24.	Glass Fiber Epoxy Composite	962
	H. H. Li		
4.25.	Graphite Fiber Epoxy Composite	984
	H. H. Li		
4.26.	Silicon Nitride with Chopped Graphite Fiber	1007
4.27.	Silicon Nitride with Vitreous Silica	1008
5.	REFERENCES	1009

LIST OF TABLES

	PAGE
1. CLASSICAL MODELS FOR THE OPTICAL PROPERTIES OF METALS	15
1- 1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	30
1- 2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	36
1- 3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	37
1- 4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	39
1- 5. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	42
1- 6. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	47
1- 7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	53
1- 8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	57
1- 9. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	62
1-10. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	65
1-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	72
1-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	87
1-13. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (INCIDENT ANGLE DEPENDENCE)	92
1-14. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (INCIDENT ANGLE DEPENDENCE)	93
1-15. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	95
1-16. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	100
1-17. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	101
1-18. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	103
1-19. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	106
1-20. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	107

1-21.	PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	109
2- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	115
2- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	118
2- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	119
2- 4.	RECOMMENDED ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	121
2- 5.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	124
2- 6.	EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	125
2- 7.	RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	127
2- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	130
2- 9.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	131
2-10.	RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	133
2-11.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	136
2-12.	RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	139
3- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	144
3- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	147
3- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	149
3- 4.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	153
3- 5.	RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	156
3- 6.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	159
3- 7.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	160
3- 8.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	162
3- 9.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	166

3-10.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	167
3-11.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	169
3-12.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	172
3-13.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	173
3-14.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	175
3-15.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	178
3-16.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	179
4- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	183
4- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	186
4- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	187
4- 4.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	190
4- 5.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	191
4- 6.	RECOMMENDED ANGULAR SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	193
4- 7.	RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	196
4- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	199
4- 9.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	200
4-10.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	203
4-11.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	204
4-12.	RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	206
4-13.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	209
4-14.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	210
4-15.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	212

4-16.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	215
4-17.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	216
4-18.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	219
4-19.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	220
4-20.	RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	222
6- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE(COORS AD 99) (WAVELENGTH DEPENDENCE)	228
6- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	235
6- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	240
6- 4.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE(COORS AD 99) (TEMPERATURE DEPENDENCE)	248
6- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (TEMPERATURE DEPENDENCE)	251
6- 6.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (TEMPERATURE DEPENDENCE)	252
6- 7.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	255
6- 8.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	257
6- 9.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	262
6-10.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	263
6-11.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	267
6-12.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	268
6-13.	MEASUREMENT INFORMATION ON THE HEMISPHERICAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	272
6-14.	EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	273
6-15.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	276
6-16.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)	277
7- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	281

7- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	284
7- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	286
7- 4.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE)	290
7- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE)	293
7- 6.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE)	294
7- 7.	TYPICAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	296
7- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	299
7- 9.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	301
7-10.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	308
7-11.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	311
7-12.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	312
7-13.	TYPICAL NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	314
7-14.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	317
7-15.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)	318
8- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE(CORNING 9753) (WAVELENGTH DEPENDENCE)	322
8- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	326
8- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	327
8- 4.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE(CORNING 9753) (TEMPERATURE DEPENDENCE)	330
8- 5.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE(CORNING 9753) (WAVELENGTH DEPENDENCE)	333
8- 6.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	336
8- 7.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	337
8- 8.	MEASUREMENT INFORMATION ON THE REFRACTIVE INDEX OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	340

8- 9.	EXPERIMENTAL REFRACTIVE INDEX OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	341
8-10.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE(CORNING 9753) (TEMPERATURE DEPENDENCE)	343
8-11.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF CALCIUM ALUMINUM SILICATE(CORNING 9753) (WAVELENGTH DEPENDENCE)	346
8-12.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE(CORNING 9753) (WAVELENGTH DEPENDENCE)	350
8-13.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	353
8-14.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)	354
8-15.	PROVISIONAL NORMAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE(CORNING 9753) (TEMPERATURE DEPENDENCE)	358
8-16.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE)	361
8-17.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE)	362
9- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE(IRTRAN 1) (WAVELENGTH DEPENDENCE)	365
9- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	368
9- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	369
9- 4.	MEASUREMENT INFORMATION ON THE REFRACTIVE INDEX OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	374
9- 5.	EXPERIMENTAL REFRACTIVE INDEX OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	375
9- 6.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE(IRTRAN 1) (TEMPERATURE DEPENDENCE)	377
9- 7.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE(IRTRAN 1) (WAVELENGTH DEPENDENCE)	380
9- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	383
9- 9.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	384
9-10.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	389
9-11.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	390
9-12.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE(IRTRAN 1) (WAVELENGTH DEPENDENCE)	392
9-13.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	395

9-14.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	396
9-15.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE(IRTRAN 1) (TEMPERATURE DEPENDENCE)	400
9-16.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE(IRTRAN 1) (WAVELENGTH DEPENDENCE)	404
9-17.	MEASUREMENT INFORMATION ON THE NCRMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	407
9-18.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)	409
9-19.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE(IRTRAN 1) (TEMPERATURE DEPENDENCE)	416
10 - 1.	MEASUREMENT INFORMATION ON THE NCRMAL SPECTRAL EMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)	421
10 - 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)	422
10 - 3.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF PYROCERAM (TEMPERATURE DEPENDENCE)	425
10 - 4.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF PYROCERAM (TEMPERATURE DEPENDENCE)	426
10 - 5.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF PYROCERAM(CORNING 9606) (WAVELENGTH DEPENDENCE)	428
10 - 6.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF PYROCERAM (WAVELENGTH DEFENDENCE)	431
10 - 7.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)	432
10 - 8.	MEASUREMENT INFORMATION ON THE HEMISPHERICAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)	435
10 - 9.	EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)	436
10 - 10.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM(CORNING 9606) (WAVELENGTH DEPENDENCE)	438
10 - 11.	MEASUREMENT INFORMATION ON THE NCRMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)	441
10 - 12.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)	443
11 - 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	450
11 - 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	453
11 - 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	454
11 - 4.	MEASUREMENT INFORMATION ON THE REFRACTIVE INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENOENCE)	460

11- 5.	EXPERIMENTAL REFRACTIVE INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	462
11- 6.	MEASUREMENT INFORMATION ON THE ABSORPTION INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	466
11- 7.	EXPERIMENTAL ABSORPTION INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	467
11- 8.	PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	469
11- 9.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	472
11-10.	EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	473
11-11.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	478
11-12.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	481
11-13.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	483
11-14.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (TEMPERATURE DEPENDENCE)	489
11-15.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	492
11-16.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	495
11-17.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	498
11-18.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	501
11-19.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	504
11-20.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	505
11-21.	PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	510
11-22.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	513
11-23.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	518
11-24.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	521
11-25.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (TEMPERATURE DEPENDENCE)	528
12- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	535

12- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE)	539
12- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE)	542
12- 4.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	553
12- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	556
12- 6.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	557
12- 7.	RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	560
12- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE)	563
12- 9.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE)	565
12-10.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	568
12-11.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	571
12-12.	RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	575
12-13.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE)	578
12-14.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE)	580
12-15.	RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	588
12-16.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	591
12-17.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	592
13- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	595
13- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	599
13- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	601
13- 4.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE)	607
13- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE)	611
13- 6.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE)	612

13- 7.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	614
13- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	618
13- 9.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	620
13-10.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	627
13-11.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	631
13-12.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	632
13-13.	RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	634
13-14.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	637
13-15.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)	640
14- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	649
14- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	652
14- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	653
14- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	655
14- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	658
14- 6.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	659
14- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	662
14- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	665
14- 9.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	666
14-10.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	668
14-11.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	672
14-12.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)	674
15- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	685

15- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	688
15- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	689
15- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	691
15- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	694
15- 6.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	695
15- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	700
15- 8.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	703
15- 9.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	704
15-10.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	708
15-11.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	712
15-12.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)	714
16- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	729
16- 2.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	732
16- 3.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	735
16- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	736
16- 5.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	738
16- 6.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	741
16- 7.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	742
16- 8.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	744
16- 9.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	747
16-10.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	748
16-11.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	750

16-12.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	754
16-13.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE)	756
17- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	768
17- 2.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	771
17- 3.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	774
17- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	775
17- 5.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	777
17- 6.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	780
17- 7.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	781
17- 8.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	783
17- 9.	MEASUREMENT INFORMATION ON THE SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	786
17-10.	EXPERIMENTAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	787
17-11.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	789
17-12.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	793
17-13.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)	794
19- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE)	807
19- 2.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	810
19- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	811
19- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	814
19- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	817
19- 6.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	819
19- 7.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	823

19- 8.	MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE)	826
19- 9.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE)	827
19-10.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	829
19-11.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	833
19-12.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)	835
20- 1.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)	849
20- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)	850
20- 3.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM (TEMPERATURE DEFENDENCE)	853
20- 4.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE)	859
20- 5.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)	867
20- 6.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)	869
20- 7.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)	873
20- 8.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)	874
20- 9.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (TEMPERATURE DEFENDENCE)	876
20-10.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE)	877
20-11.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE)	880
20-12.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE)	883
20-13.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE)	886
20-14.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE)	889
20-15.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE)	892
20-16.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEFENDENCE)	895
21- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)	901

21- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	904
21- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)	• • • • • • •	907
21- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	910
21- 5.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)	• • • • • • •	913
21- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEFENDENCE)	• • • • • • •	916
22- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)	• • • • • • •	922
22- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	925
22- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)	• • • • • • •	928
22- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	931
22- 5.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)	• • • • • • •	934
22- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	937
23- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	• • • • • • •	942
23- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	945
23- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	• • • • • • •	948
23- 4.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)	• • • •	951
23- 5.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)	• • • • • • •	952
23- 6.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	954
23- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	• • • • • • •	957
23- 8.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	960
24- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)	• • • • • • •	964
24- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	• • • • • • •	967
24- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	• • • • • • •	970

24- 4.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)	973
24- 5.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	974
24- 6.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	976
24- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	979
24- 8.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	982
25- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	987
25- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	990
25- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	993
25- 4.	MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)	996
25- 5.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE)	997
25- 6.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	999
25- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)	1002
25- 8.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)	1005

LIST OF FIGURES

	PAGE
1. GEOMETRIC PARAMETERS DESCRIPTIVE OF REFLECTION FROM A SURFACE	8
2. TYPICAL BEHAVIOR OF THERMAL RADIATIVE PROPERTIES OF METALS	14
3. TYPICAL BEHAVIOR OF THERMAL RADIATIVE PROPERTIES OF A TRANSPARENT NON-SCATTERING NONMETALLIC SOLID.	19
4. THE REFLECTIVITY AND TRANSMISSIVITY OF A SEMITRANSPARENT SLAB	22
1- 1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	31
1- 2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	32
1- 3. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALCLAD ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	33
1- 4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF OXIDIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	34
1- 5. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	35
1- 6. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALCLAD ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE).	40
1- 7. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	43
1- 8. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	44
1- 9. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	45
1-10. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	48
1-11. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	49
1-12. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALCLAD ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	50
1-13. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALCLAD ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	51
1-14. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF OXIDIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	52
1-15. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALCLAD ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	63
1-16. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	66
1-17. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	67

1-18.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	68
1-19.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	69
1-20.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	70
1-21.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	71
1-22.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (INCIDENT ANGLE DEPENDENCE).	91
1-23.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	96
1-24.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).	97
1-25.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALCLAD ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	98
1-26.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF OXIDIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	99
1-27.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALCLAD ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	104
1-28.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)	105
1-29.	PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	110
1-30.	PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	111
1-31.	PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)	112
2- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	116
2- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	117
2- 3.	RECOMMENDED ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	122
2- 4.	EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	123
2- 5.	RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	128
2- 6.	EXPERIMENTAL NORMAL SPECTRAL FERLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	129
2- 7.	RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	134
2- 8.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	137

2- 9. RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)	140
3- 1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	145
3- 2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	146
3- 3. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	154
3- 4. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	157
3- 5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	158
3- 6. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	163
3- 7. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	165
3- 8. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	170
3- 9. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)	171
3-10. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	176
3-11. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)	177
4- 1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	184
4- 2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	185
4- 3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	189
4- 4. RECOMMENDED ANGULAR SPECTRAL EMITTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	194
4- 5. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	197
4- 6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	198
4- 7. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE)	202
4- 8. RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	207
4- 9. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	208
4-10. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)	213

4-11.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE).	214
4-12.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (TEMPERATURE DEPENDENCE).	218
4-13.	RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE).	223
6- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).	229
6- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELNGTH DEPENDENCE).	230
6- 3.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).	231
6- 4.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).	232
6- 5.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (HAVELENGTH DEPENDENCE).	233
6- 6.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (HAVELENGTH DEPENDENCE).	234
6- 7.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (TEMPERATURE DEPENDENCE).	249
6- 8.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (TEMPERATURE DEPENDENCE).	250
6- 9.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).	254
6-10.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).	261
6-11.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).	266
6-12.	EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE ((AVELENGTH DEPENDENCE).	271
6-13.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).	275
7- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	282
7- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	283
7- 3.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE).	291
7- 4.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE).	292
7- 5.	TYPICAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	297
7- 6.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	298

7- 7.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	309
7- 8.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	310
7- 9.	TYPICAL NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	315
7-10.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).	316
8- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).	324
8- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).	325
8- 3.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEFENDENCE).	331
8- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).	334
8- 5.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM, SILICATE (WAVELENGTH DEPENDENCE).	335
8- 6.	EXPERIMENTAL REFRACTIVE INDEX OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).	339
8- 7.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEFENDENCE).	344
8- 8.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).	348
8- 9.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).	351
8-10.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).	352
8-11.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEFENDENCE).	359
8-12.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE).	360
9- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	366
9- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	367
9- 3.	EXPERIMENTAL REFRACTIVE INDEX OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	373
9- 4.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (TEMPERATURE DEPENDENCE).	378
9- 5.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	381
9- 6.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	382

9- 7.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	388
9- 8.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	393
9- 9.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	394
9-10.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (TEMPERATURE DEPENDENCE).	401
9-11.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	405
9-12.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).	406
9-13.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (TEMPERATURE DEPENDENCE).	417
10- 1.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).	420
10- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF PYROCERAM (TEMPERATURE DEPENDENCE).	424
10- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).	429
10- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).	430
10- 5.	EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).	434
10- 6.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).	439
10- 7.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).	440
11- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).	451
11- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICA(VITRECUS) (WAVELENGTH DEPENDENCE).	452
11- 3.	EXPERIMENTAL REFRACTIVE INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).	459
11- 4.	EXPERIMENTAL ABSORPTION INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).	465
11- 5.	PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITRECUS) (WAVELENGTH DEPENDENCE).	470
11- 6.	EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).	471
11- 7.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).	479
11- 8.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).	480

11- 9.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (TEMPERATURE DEPENDENCE)	490
11-10.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	493
11-11.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	494
11-12.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	502
11-13.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	503
11-14.	PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	511
11-15.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	514
11-16.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	515
11-17.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	516
11-18.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)	517
11-19.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (TEMPERATURE DEPENDENCE)	529
12- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	536
12- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	537
12- 3.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF LOW-RESISTIVITY, DOPED SILICON (WAVELENGTH DEPENDENCE)	538
12- 4.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF HIGH-RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	554
12- 5.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON (TEMPERATURE DEPENDENCE)	555
12- 6.	RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	561
12- 7.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON OF VARIED PURITY (WAVELENGTH DEPENDENCE)	562
12- 8.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	569
12- 9.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF HIGH-RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)	572
12-10.	RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)	576
12-11.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON OF VARIED SILICON (TEMPERATURE DEPENDENCE)	577

12-12.	RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF HIGH-RESISTIVITY PURITY (WAVELENGTH DEPENDENCE).	589
12-13.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON (TEMPERATURE DEPENDENCE)	590
13- 1.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	597
13- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	598
13- 3.	RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE).	609
13- 4.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE).	610
13- 5.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	616
13- 6.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	617
13- 7.	RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	629
13- 8.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	630
13- 9.	RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	635
13-10.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).	636
14- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).	650
14- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).	651
14- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).	656
14- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).	657
14- 5.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).	663
14- 6.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).	664
14- 7.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE COATINGS (WAVELENGTH DEPENDENCE).	669
14- 8.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE COATINGS (WAVELENGTH DEPENDENCE).	670
14- 9.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE POWDERS (WAVELENGTH DEPENDENCE).	671
15- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).	686

15- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).	687
15- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).	692
15- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).	693
15- 5.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).	701
15- 6.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).	702
15- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN COATING (TEMPERATURE DEPENDENCE)	706
15- 8.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE).	709
15- 9.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE).	710
15-10.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC THIN FILMS (WAVELENGTH DEPENDENCE).	711
16- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	730
16- 2.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	733
16- 3.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	734
16- 4.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	739
16- 5.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	740
16- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	745
16- 7.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	746
16- 8.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	751
16- 9.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE).	752
16-10.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE THIN FILMS (WAVELENGTH DEPENDENCE).	753
17- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	769
17- 2.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	772
17- 3.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	773

17- 4.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	778
17- 5.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	779
17- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	784
17- 7.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	785
17- 8.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	790
17- 9.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).	791
17-10.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS THIN FILMS (WAVELENGTH DEPENDENCE).	792
19- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICONE RESIN COATING (WAVELENGTH DEPENDENCE).	808
19- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).	809
19- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICONE RESIN COATING (WAVELENGTH DEPENDENCE).	815
19- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).	816
19- 5.	PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN COATING (WAVELENGTH DEPENDENCE).	824
19- 6.	EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).	825
19- 7.	PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).	830
19- 8.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).	831
19- 9.	EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICONE RESIN COATINGS (WAVELENGTH DEFENDENCE).	832
20- 1.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE).	848
20- 2.	EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE).	852
20- 3.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE).	866
20- 4.	EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE).	872
20- 5.	EXPERIMENTAL NORMAL SPECTPAL ABSORPTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE).	875
20- 6.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE).	881

20- 7.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE).	884
20- 8.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE).	887
20- 9.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE).	890
20-10.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE).	893
20-11.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE).	896
21- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).	902
21- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).	905
21- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).	908
21- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).	911
21- 5.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).	914
21- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).	917
22- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).	923
22- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).	926
22- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).	929
22- 4.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).	932
22- 5.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).	935
22- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).	938
23- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).	943
23- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	946
23- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).	949
23- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).	950
23- 5.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	955

23- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).	958
23- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	961
24- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).	965
24- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	968
24- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE).	971
24- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE).	972
24- 5.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	977
24- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE).	980
24- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	983
25- 1.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).	988
25- 2.	PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	991
25- 3.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIEER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE).	994
25- 4.	EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEFENDENCE).	995
25- 5.	PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	1000
25- 6.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).	1003
25- 7.	PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).	1006

LIST OF SYMBOLS

a	Absorption coefficient
c	Velocity of light in vacuum
CLA	Center line average
d	Specimen thickness
E	Irradiance
I	Radiant intensity
j	Unit imaginary number
k	Absorption index
K*	Complex dielectric constant
L	Radiance
m	Electron mass; RMS slope
M	Exitance
n	Refractive index
n*	Complex refractive index
N	Number density of free electrons
P	A quantity in Fresnel equations
q	Electron charge
Q	Radiant energy; A quantity in Fresnel equations
r	Electrical resistivity
R	Single surface reflectance
RMS	Root mean square
t	Time
T	Internal transmittance; Temperature
V	Volume
W	Radiant density

α	Absorptance
α_p	Absorptance for incident radiation polarized parallel to plane of incidence
α_s	Absorptance for incident radiation polarized normal to plane of incidence
α_∞	Absorptivity
β	Temperature coefficient of electrical resistivity
ϵ	Emittance
ϵ_0	Permittivity of free space
ϵ_p	Emittance for radiation polarized parallel to plane of incidence
ϵ_s	Emittance for radiation polarized normal to plane of incidence
ϵ_∞	Emissivity
θ	Zenith angle for incident conditions
θ'	Zenith angle for viewing conditions
$\Delta\theta$	Half angle of acceptance of optical system
κ	Loss value factor
λ	Wavelength
ρ	Reflectance
ρ_p	Reflectance for incident radiant energy polarized parallel to plane of incidence
ρ_s	Reflectance for incident radiant energy polarized normal to plane of incidence
ρ_∞	Reflectivity
σ	RMS roughness
τ	Transmittance; Relaxation time
ϕ	Azimuthal angle for incident conditions
ϕ'	Azimuthal angle for viewing conditions
Φ	Radiant flux
Φ_a	Absorbed flux
Φ_i	Incident flux
Φ_r	Reflected flux

- Φ_t Transmitted flux
 ω Solid angle for incident conditions
 ω' Solid angle for viewing conditions

1. INTRODUCTION

This reference work presents the most comprehensively compiled experimental data and the critically evaluated and recommended values on the thermal radiative properties of twenty-seven selected aircraft/spacecraft structural materials.

The twenty-seven specific materials and generic groups of materials covered are the following:

	<u>Melting Point (K)</u>
1. Metals	
(1) Aluminum Alloy 2024	775-911
(2) Aluminum Alloy 7075	750-911
(3) AISI 304 Stainless Steel	1670-1727
(4) Titanium Alloy Ti-6Al-4V	1803-1908
(5) Hadfield Manganese Steel	1470-1480
2. Dome Materials	
(6) Aluminum oxide (Wesgo Al-300)	2315-2320
(7) Boron nitride	3273(sublimation)
(8) Calcium aluminum silicate (Corning 9753)	1723-1773
(9) Magnesium fluoride (Kodak IRTRAN 1)	1528
(10) Pyroceram (Corning 9606)	1623(softening)
(11) Silica (vitreous)	1950-2000
(12) Silicon	1687
(13) Silicon carbide	>2400(sublimation)
(14) Silicon nitride	2200(dissociation)
3. Transparent Materials	
(15) Acrylic resins	277-511(softening)
(16) Lucite	397(softening)
(17) Polycarbonate plastics	520(decomposition)
(18) Polyphenylquinoxaline	430(softening)
(19) Silicone resins	580(decomposition)
	780-830(decomposition)
	473-873(thermal degradation)
4. Composites	
(20) Aluminized grafoil	933.52(M. P. o' Al)
(21) Boron fiber aluminum matrix composite	933.52(M. P. of Al)
(22) Graphite fiber aluminum matrix composite	933.52(M. P. of Al)
(23) Boron fiber epoxy composite	590(epoxy decomposition)
(24) Glass fiber epoxy composite	590(epoxy decomposition)
(25) Graphite fiber epoxy composite	590(epoxy decomposition)
(26) Silicon nitride with chopped graphite fiber	
(27) Silicon nitride with vitreous silica	

The thermal radiative properties covered include the four prime properties: emittance, reflectance, absorptance, and transmittance. Additionally, each of the

prime properties are divided into three subproperties: hemispherical spectral, normal spectral, and angular spectral, and each subproperty is treated with respect to both wavelength and temperature dependences, wherever possible.

In the compilation of experimental data, all available data covering from the photographic region of the spectrum up to 100 μm are included. The recommended values resulting from critical evaluation, analysis, and synthesis of the available data and information cover the wavelength range of present interest from visible region (below 1 μm) to the infrared of 15 μm , if possible. Furthermore, the recommended values as a function of temperature are given for four particularly useful wavelengths (whenever possible); namely: 2.8, 3.8, 5.0, and 10.6 μm .

In order to enable the user to fully utilize and properly interpret the data and information presented in this report and also to enhance the usefulness of the data themselves, Section 2 provides the theoretical background of thermal radiative properties, which is believed useful. In Section 3 the procedure for data evaluation and the generation of recommended values is briefly outlined. The original experimental data and the critically evaluated and recommended values in both tabular and graphical forms for the various subproperties of the selected materials are given in Section 4, together with a discussion text and a table on measurement information. The discussion text reviews and discusses the available data and information, the theoretical guidelines and other factors on which the critical evaluation, analysis, and synthesis of data are based, and the considerations involved in arriving at the final assessment and recommendations. In this discussion text the accuracy or uncertainty of the recommended values is also stated. The table on measurement information contains the information on the specimen characterization and measurement method and condition for each set of experimental data. Since most of the selected materials are not well known, a concise description of each of the materials is given at the beginning of each of the subsections in Section 4. The complete bibliographic citations for the 332 references are given in Section 5.

2. THEORETICAL BACKGROUND*

2.1. General Remarks

The purpose of this section is to briefly explain the theoretical background that is helpful in understanding thermal radiative properties and the material presented in this report.

When light or other forms of electromagnetic radiation is incident on a material, three things can happen: the light is reflected, the light is absorbed, or the light is transmitted. Materials in general exhibit selective reflectance, absorptance, and transmittance, which means that the reflectance, absorptance, and transmittance vary with the wavelength of the incident light. For example, if the fraction of the incident light or radiative energy transmitted is plotted against wavelength, it would show peaks and valleys. What is the significance of peaks in a transmittance curve as a function of wavelength? When looking through a piece of blue glass which is illuminated by white light, it would appear blue to an observer. This means that the blue light with its characteristic wavelengths passes through the material and is not absorbed. Red glass which is illuminated by white light will appear red to an observer meaning that the red light with its characteristic wavelengths is not absorbed and passes through the glass with little loss in intensity. Thus, as a generalization, it can be stated that the wavelengths of light that are transmitted by a material are those wavelengths at which the light is not selectively absorbed by the material. This generalization holds not only for visible light but also for thermal radiation. The peaks or high values of transmittance correspond to the thermal radiation which is not absorbed at those particular wavelengths and the valleys or low values of transmittance correspond to the thermal radiation which is absorbed at those particular wavelengths. What physically occurs when light or thermal radiation at certain wavelengths is absorbed? A material is made up of a large number of atoms and/or molecules. These atoms or molecules can undergo various kinds of motion or changes in condition by excitation with light or other electromagnetic radiation of certain wavelengths. When the wavelength of the incident radiation is the same as the wavelength necessary to excite various kinds of motion or changes in condition, the atoms or molecules absorb the radiation of those wavelengths and the remaining radiation with other wavelengths is transmitted through the material.

Radiation is one of the three fundamental means of heat transfer, the others being conduction and convection. Radiation differs from the other means in two important respects: first, no medium is required for the transport of energy by radiation, and second,

* For details, see the text in [T61238 and T66579].

the rate of heat dissipation by radiation varies approximately as the fourth power of the absolute temperature, while that by the other means varies approximately as the first power of temperature. For these reasons, radiation becomes the dominant means of heat transfer at high temperatures and in the absence of an atmosphere.

The thermal radiative properties - emittance, reflectance, absorptance, and transmittance - are the parameters which are descriptive of the energy transported by means of radiation. The properties can be prescribed in greater detail to account for the spectral or wavelength conditions and the geometrical or directional conditions in which the radiant energy interacts with the solid. This interaction can be phenomenologically described by other properties as well, such as the optical constants, complex dielectric constant, or propagation factor, each of which is especially convenient for studying various aspects of the interaction.

There is a marked contrast between the radiative properties of metallic and nonmetallic solids. The magnitude of the radiative properties of the metallic solid is determined to a large extent by the surface condition; due to the high absorption index radiant energy will not travel more than a few hundred angstroms into the metal before being totally absorbed. As a result, surface roughness, oxide layer formations, structural defects due to mechanical stresses, etc. can be predominating influences on the property variations. The nonmetallic or dielectric materials are known to be less sensitive to surface conditions; the absorption and emission processes are "bulk" or "volume" phenomena. This is a consequence of appreciable transparency of the nonmetallic solid to thermal radiation.

The understanding of the basic mechanism of interaction between radiant energy and metallic solids is reasonably well developed. The behavior of the metallic solid is fairly adequately described by the free electron models which indeed are only approximate, but do provide simple and useful tools. The more sophisticated theories, while still not useful as yet for the prediction of numerical values from structural parameters, do provide a means for evaluation of experimental data and a basis for developing empirical relations to meet specific conditions. Our understanding of the theory of nonmetallic behavior is less well developed. The simplest model ascribes the nonmetallic behavior as due to a combination of several types of free electrons and electrons bound to the lattice. The theory is useful for basic understanding of behavior but not tractable for direct computation of property values. The problem is further complicated by transparency, scattering phenomena, and temperature gradients within the solid, which can usually be treated only in a gross or oversimplified manner.

5

In summary, then, pertaining to the principal differences between the metallic and nonmetallic behaviors, it can be stated that there are two: (1) the contributions of the transparency of nonmetallic solids giving rise to "volume" effects rather than "surface" effects which predominate the behavior of metallic solids, and (2) the lack of theoretical tools and simplified models for nonmetallic solids as are available for metallic materials.

2. 2. Terminology

In order to understand the many terms and the notation used to describe thermal radiation, an explanation of relevant processes, things, quantities, properties, and descriptors, etc. is called for.

a. Processes

Radiation. The process by which radiant energy is emitted by a body. This process is also called emission.

Reflection. The process by which radiant energy incident on a surface or medium leaves that surface or medium from the incident side.

Transmission. The process by which radiant energy incident on a surface or medium leaves that surface or medium on a side other than the incident side.

Absorption. The process by which radiant energy is converted into another form of energy.

Propagation. The process or processes by which radiant energy is transferred from one region to another region in space.

b. Things

Radiator. A source of radiant energy.

Thermal Radiator. A radiator that emits thermal radiant energy, as a consequence of its temperature only.

Blackbody. A body or surface that absorbs all of the radiant energy incident upon it, and emits the maximum possible amount of thermal radiant energy at each frequency for a body at its temperature.

Reflector. A body that reflects incident radiant energy.

Transmitter. A body that transmits incident radiant energy.

Transparent Body. A body that transmits radiant energy directly, without diffusion or scattering, and has a relatively high transmittance.

Translucent Body. A body that transmits radiant energy principally by diffuse transmission. Objects are not seen distinctly through such a body.

Absorber. A body that absorbs incident radiant energy.

c. Quantities

Radiant Energy, Q. Energy in the form of electromagnetic waves or photons. Joules, ergs, or kilowatt-hours.

Thermal Radiant Energy, Q. Radiant energy that is emitted by a thermal radiator.

Radiant Density, W. $W = dQ/dV$. Radiant energy per unit volume. Joule per cubic meter, erg per cubic centimeter.

Radiant Flux, Φ . $\Phi = dQ/dt$. Time rate of flow of radiant energy. Erg per second, watt.

Radiant Intensity, I. $I = d\Phi/d\omega$. Flux per unit solid angle from a source. Watt per steradian.

Radiance, L. $L = d^2\Phi/d\omega dA \cos \theta$. Flux propagated in a given direction, per unit solid angle about that direction and per unit area projected normal to the direction.

Exitance, M. $M = d\Phi/dA$. Flux per unit area leaving a surface.

Irradiance, E. $E = d\Phi/dA$. Flux per unit area incident on a surface.

d. Properties

Properties ending in "ance" are properties of real specimens, regardless of thickness or surface condition. Properties ending in "ivity" are intrinsic properties of the material of which the specimen is composed, and can only be approached by values measured on real specimens that have clean optically smooth surfaces and are opaque.

Reflectance, ρ . The ratio of reflected flux to incident flux.

Absorptance, α . The ratio of absorbed flux to incident flux.

Transmittance, τ . The ratio of transmitted flux to incident flux.

Internal Transmittance, T. The ratio of the radiant flux reaching the exit surface to the flux which leaves the entry surface of a transparent body.

Emittance, ϵ . The ratio of the radiant exitance of a body at a given temperature to that of a blackbody radiator at the same temperature.

Reflectivity, ρ, ρ_∞ . The reflectance of a specimen that has an optically smooth surface and is thick enough to be opaque.

Absorptivity, α, α_∞ . The absorptance of a specimen that has an optically smooth surface and is thick enough to be opaque.

Emissivity, $\epsilon, \epsilon_\infty$. The emittance of a specimen that has an optically smooth surface and is thick enough to be opaque.

Reflectance Factor, R. The ratio of the flux reflected by a specimen under specified conditions of irradiation and viewing to that reflected by the ideal completely reflecting, perfectly diffusing surface, identically irradiated and viewed.

For each of the four thermal radiative properties it is necessary to specify the wavelength conditions and the geometrical conditions applicable to the property.

e. Wavelength Descriptor

The only wavelength descriptor that is applicable to this report is the term "spectral". Used as a modifier for a thermal radiative property it means as a function of wavelength. For example, spectral transmittance means transmittance as a function of wavelength and is designated as $\tau(\lambda)$. Used in the context of a condition, the concept spectral means for a very narrow band of wavelength and is also referred to as monochromatic.

f. General Geometrical Descriptors

Figure 1 shows the general case of reflection at a surface and indicates the necessary geometric parameters required to fully describe the incident and reflected fluxes. The beams representing the incident and viewed flux are described by the zenith angles for θ and θ' and by the beam solid angles ω and ω' . The longitudinal angles Φ and Φ' relate the axes of the beams to each other and some reference line on the specimen; as a practical matter very few measurements so specify this angular descriptor. It is the convention in this report to distinguish three sets of general conditions as follows:

Normal - Conditions for incidence and/or viewing through a solid angle ω or ω' , normal to the specimen; that is θ or $\theta' < 15^\circ$.




Figure 1. Geometric parameters descriptive of reflection from a surface. θ is the zenith angle, or colatitude, in degrees; Φ is the azimuthal angle, or longitude, in degrees; ω is the beam solid angle, in steradians; and the symbol ' refers to viewing conditions.

Angular - Conditions for incidence and/or viewing through a solid angle ω or ω' at some direction specified by θ or $\theta' \geq 15^\circ$

Hemispherical - Conditions for incidence and/or viewing of flux over a hemispherical region; that is ω or $\omega' = 2\pi$

The descriptors normal and angular do not fully describe the geometric conditions; ω and/or ω' and θ and θ' must be provided to fully specify the geometry.

g. Present Classification Scheme

In the classification scheme used in the data section of this report, reflectance, absorptance, and transmittance subproperties are grouped geometrically by incidence conditions and emittance is grouped by viewing conditions.

For absorptance, transmittance, and reflectance, hemispherical means the radiation is incident over a hemisphere, i.e., $\omega = 2\pi$, while normal means $\theta < 15^\circ$ and angular means $\theta \geq 15^\circ$. For emittance, hemispherical means $\omega' = 2\pi$, normal $\theta' < 15^\circ$, and angular $\theta' \geq 15^\circ$.

h. Symbolic Representation

The various subproperties are expressed according to the following convention. The symbols for the four primary properties ϵ , ρ , α , and τ have already been presented.

The geometric (incidence and viewing conditions) and wavelength descriptors, in that same order, are symbolically represented within the parentheses being separated by semicolons. The most general case would be (using reflectance as an example):

$$\rho(\theta, \Phi, \omega; \theta', \Phi', \omega'; \lambda)$$

where the wavelength descriptor, λ , used in this report has previously been defined.

As a practical matter not all the designations are always needed and many are omitted for convenience sake; usually Φ and Φ' are not used and, of course, for emittance and absorptance, the incidence and viewing geometry symbols, respectively, are not applicable.

It should be noted that for the subproperties of emittance and absorptance, only one geometric descriptor is required to designate the conditions of viewing and incidence, respectively. For the subproperties of reflectance and transmittance, two geometric descriptors are required since both incidence and viewing conditions need to be specified.

2.3. Interrelations Between Thermal Radiative Properties

All matter is continually emitting radiant energy as a result of the thermal vibration of the particles (electrons, ions, atoms, and molecules) of which it is composed. This process is called thermal radiation, and the radiant energy so emitted is called thermal radiant energy.

Each solid body is not only continually emitting thermal radiant energy, but it is also continually being bombarded by radiant energy from its surroundings, some of which is absorbed. The net rate of heat transfer by radiation to or from the body is equal to the difference in the rates of emission and absorption. Hence, the properties of the body that influence these rates are called thermal radiative properties.

When a body is irradiated, part of the incident radiant energy is reflected, part is absorbed, and the rest is transmitted. Nothing else can happen to it. The incident flux, Φ_i , is equal to the sum of the reflected flux, Φ_r , the absorbed flux, Φ_a , and the transmitted flux, Φ_t :

$$\Phi_i = \Phi_r + \Phi_a + \Phi_t \quad (2.3-1)$$

This is an example of the Law of Conservation of Energy.

The reflectance, ρ , is the ratio of reflected flux to incident flux; the absorptance, α , is the ratio of absorbed flux to incident flux; and the transmittance, τ , is the ratio of transmitted flux to incident flux. Dividing both sides of eq. (2.3-1) by Φ_i gives

$$1 = \rho + \alpha + \tau \quad (2.3-2)$$

For opaque materials, $\tau = 0$, hence for such materials

$$\rho + \alpha = 1 \quad (\tau = 0) \quad (2.3-3)$$

Kirchhoff's law states that the absorptance is equal to the emittance

$$\alpha = \epsilon \quad (2.3-4)$$

Thus, for an opaque material

$$\rho + \epsilon = 1 \quad (2.3-5)$$

and the thermal radiative properties of an opaque body are fully described by either the reflectance or the emittance. However, there are certain restrictions that apply to eqs. (2.3-2) through (2.3-5). They are restricted by the geometric and wavelength distribution of the reflected and emitted radiant energy. Considering the geometric distribution only, for opaque specimens

$$\alpha(\theta, \omega) = 1 - \rho(\theta, \omega; 2\pi) \quad (2.3-6)$$

where θ, ω are the same for α and ρ , and

$$\epsilon(\theta', \omega') = \alpha(\theta, \omega) \quad (2.3-7)$$

where $\theta = \theta'$ and $\omega = \omega'$. Equation (2.3-6) was derived on the basis of conservation of energy. Incident radiant energy that is not reflected must be absorbed and eq. (2.3-7) is a statement of Kirchhoff's law. Equations (2.3-6) and (2.3-7) can be used to convert one type of data (subproperty) to another. If normal emittance data are not available, for instance, normal absorptance or normal hemispherical reflectance can be used to compute the desired values.

The variation of the thermal radiative properties with temperature, wavelength, and geometric conditions (including polarization) of irradiation and viewing poses certain restrictions on eqs. (2.3-2) through (2.3-5). For eqs. (2.3-2) and (2.3-3) to be valid, α , ρ , and τ must be evaluated under the same conditions, which means that the temperature of the specimen must be the same, and the spectral composition, direction, solid angle, and degree and direction of polarization of the incident radiant energy must be identical, and all of the reflected and transmitted radiant energy must be measured.

Kirchhoff's law, eq. (2.3-4), is derived for the condition that the specimen is irradiated in a blackbody cavity with walls at the same temperature as the specimen, which means that the specimen is uniformly irradiated over a hemisphere with unpolarized radiant energy having the spectral distribution of that of a blackbody radiator at

the temperature of the specimen. However, it can be proved that eq. (2.3-4) is also valid for the two conditions: (1) any solid angle less than a hemisphere if the direction and solid angle of the incident beam for the absorption evaluation is identical to the direction and solid angle (but opposite in sense) of the emitted beam for the emittance evaluation, and (2) for plane-polarized radiant energy with the plane of polarization at any given angle to the plane of measurement, provided that it is the same for the incident radiant energy for the absorption evaluation and the emitted radiant energy for the emittance evaluation. Even with these modifications, eq. (2.3-4) applies strictly only provided the spectral composition of the incident radiant energy for the absorptance is that of blackbody radiant energy at the temperature of the specimen. This would appear to impose a severe restriction on the general applicability of eq. (2.3-5). However, it can also be shown that eq. (2.3-4) applies to any small wavelength band, as well as to total blackbody radiant energy. The properties of reflectance, absorptance, and transmittance do not vary with the amount of incident radiant energy until very high flux densities are reached. Within the narrow wavelength band used in measuring spectral thermal radiative properties the spectral distribution of radiant energy from almost any thermal source is approximately the same as that from a blackbody radiator at the temperature of the specimen. Also, polarization effects are completely absent for normally incident radiant energy and are negligible at angles near the normal. Hence eqs. (2.3-4) and (2.3-5) can be considered valid for normal spectral properties and can be used to convert normal hemispherical reflectance to normal emittance with but little error.

2.4. Fresnel Equations for Specular Reflection

When an electromagnetic wave in vacuum is incident on the plane surface of an optically homogeneous specimen, interaction of the wave with the material of the specimen will occur. The electrical and magnetic properties of the specimen will be different from those of the vacuum, and as a result, there may be a change in the direction of propagation of the wave, its velocity, amplitude, wavelength, and phase, and it may be separated into two portions, one reflected and one transmitted. The transmitted portion will be partially or totally absorbed. The only property of the wave that never changes is its frequency.

Similar changes in the wave will occur whenever it is incident on an interface between two media of different properties. The changes can be computed from the properties of the material, or the differences in properties on the two sides of the interface, and from the direction of propagation of the wave relative to the interface and the direction of its plane of polarization relative to the plane containing the direction of incidence and the normal to the interface at the point of incidence.

The optical properties describe the interaction of an electromagnetic wave with matter in terms of phase and amplitude, while the thermal radiative properties describe the energy transfer during the interaction. It is obvious that the two types of properties, optical and thermal radiative, are related. In some cases the relationships are simple.

One situation in which the relation is not simple is that for the general case of a wave incident on an interface. By solving the Maxwell equations for the boundary conditions, the Fresnel relations for specular reflection can be derived. The specular reflectance at the interface (fraction of incident flux reflected in the direction of mirror reflectance) is given as [see pp. 17 and 18 of A00012]

$$\rho_s(\theta) = \frac{Q^2 + P^2 - 2Q \cos \theta + \cos^2 \theta}{Q^2 + P^2 + 2Q \cos \theta + \cos^2 \theta} \quad (2.4-1)$$

$$\rho_p(\theta) = \rho_s(\theta) \frac{Q^2 + P^2 - 2Q \sin \theta \tan \theta + \sin^2 \theta \tan^2 \theta}{Q^2 + P^2 + 2Q \sin \theta \tan \theta + \sin^2 \theta \tan^2 \theta} \quad (2.4-2)$$

where

$$2Q^2 = [(n^2 - k^2 - \sin^2 \theta)^2 + 4n^2k^2]^{1/2} + (n^2 - k^2 - \sin^2 \theta) \quad (2.4-3)$$

$$2P^2 = [(n^2 - k^2 - \sin^2 \theta)^2 + 4n^2k^2]^{1/2} - (n^2 - k^2 - \sin^2 \theta) \quad (2.4-4)$$

The angle θ is the angle between the incident ray and the normal to the interface, ρ_s is the reflectance for plane-polarized incident radiant energy with its plane of polarization normal to the plane of incidence (the plane containing the incident ray and the normal to the interface at the point of incidence), ρ_p is the reflectance for plane-polarized incident radiant energy with its plane of polarization parallel to the plane of incidence, n is the refractive index, and k is the absorption index.

If the incident radiant energy is completely unpolarized

$$\rho(\theta) = \frac{1}{2} [\rho_s(\theta) + \rho_p(\theta)]. \quad (2.4-5)$$

For an opaque material the directional absorptance can be found and using Kirchhoff's law, eq. (2.3-4), the directional emittance can be found for the polarized components

$$\epsilon_s(\theta) = \alpha_s(\theta) = 1 - \rho_s(\theta) \quad (2.4-6)$$

$$\epsilon_p(\theta) = \alpha_p(\theta) = 1 - \rho_p(\theta) \quad (2.4-7)$$

and also for unpolarized light

$$\epsilon(\theta) = \alpha(\theta) = 1 - \rho(\theta) \quad (2.4-8)$$

The Fresnel eqs. (2.4-1) and (2.4-2) have been expressed in terms of n and k , but the relations are found in various forms in the literature. The simplest case occurs for normal incidence ($\theta = 0$), where the equations reduce to

$$\rho_p(0) = \rho_s(0) \quad (2.4-9)$$

and

$$Q = n \quad P = k \quad (2.4-10)$$

Hence, for radiant energy incident from vacuum or a medium of index of refraction of 1,

$$\rho(0) = \frac{(n - 1)^2 + k^2}{(n + 1)^2 + k^2} \quad (2.4-11)$$

2.5. Thermal Radiative Properties of Metals

a. General Behavior

The general behavior of the thermal radiative properties of metals is shown in Figure 2. For thicknesses greater than several hundred angstroms, metals are opaque, that is, they show zero transmittance for all wavelengths. The reflectance rises in the region of $1-2 \mu\text{m}$ to a large value which has a slightly increasing slope. The emittance and absorptance decrease rapidly in the region of $1-2 \mu\text{m}$ reaching a low value with a slight negative slope.

b. Classical Free-Electron Theory

The theoretical models for ideal metallic surfaces leads to help in predicting some thermal radiative properties.

The earliest attempts to predict the optical properties of metals were made by Lorentz, Drude [T20117], Kronig [A00023], and Mott and Zener [A00022], who assumed the metal to contain electrons which were essentially free to move under the influence of the electric field induced by the incident electromagnetic wave. These free electrons are the valence electrons in the outer shell of the atoms constituting the metal. When the wave is incident upon its surface, an oscillating electric field parallel to the surface is induced in the metal and the free electrons will oscillate under the influence of this field at the frequency of the incident wave. There is a phase difference between the




Figure 2. Typical behavior of thermal radiative properties of metals.

oscillation of the electrons and that of the field, caused by a viscous damping force arising from collisions between accelerated electrons and the atomic lattice. To describe the optical behavior of the material requires two parameters: the number density of free electrons, N , being excited by the induced field, and the average time (relaxation time, τ) between collisions of the electron with the atomic lattice. These two parameters can be estimated from the number of valence electrons per unit volume, the electrical conductivity and the assumption of a spherical Fermi surface. This is called the Drude Free Electron model, and is shown in Table 1 expressing the complex dielectric constant, K^* , as a function of the two parameters N and τ . See the List of Symbols for the meaning of other symbols.

If the phase change arising from electronic collisions can be neglected, the model describing the optical behavior of the material is greatly simplified. This situation occurs when the relaxation time is zero or when the time between electronic collisions is much less than the period of the induced electric field. For this condition, the optical behavior can be completely described by one material parameter - the dc electrical resistivity, r . Table 1 presents the resulting model for the complex dielectric constant, labeled the Simplified Drude Free Electron model.

This simplified model for the optical constants serves as the basis for relations used to compute the thermal radiative properties of materials from knowledge of the electrical resistivity (or conductivity) as a function of temperature. If the appropriate relation between the complex dielectric constant, K^* , and $\epsilon(0; \lambda)$ is used with the simplified Drude model, the normal spectral emissivity can be expressed as a function of the electrical resistivity, r , in the series form

$$\epsilon(0; \lambda) = 0.365(r/\lambda)^{1/2} - 0.0464(r/\lambda) + \dots \quad (2.5-1)$$

Table 1. Classical Models for the Optical Properties of Metals (MKS Units)

Drude Free Electron. Assumes the metal contains free electrons which are subjected to an oscillating electric field and a viscous damping force proportional to the velocity of the electrons arising from collisions between accelerated electrons and the atomic lattice.

Simplified Drude Free Electron.
Drude theory valid for long wavelengths where currents in the metal are in phase with electric field.

$$K^* = 1 - \left(\frac{\lambda}{\lambda_0}\right)^2 \frac{1 + j(\lambda/\lambda_1)}{1 + (\lambda/\lambda_1)^2} \quad \lambda_1 = 2\pi c \tau$$

$$\lambda_0 = \left[\frac{\pi m c^2 \epsilon_0}{q^2 N} \right]^{1/2}$$

$$K^* = -j \frac{\lambda}{c \epsilon_0 r}$$

where the units are r (ohm-m) and λ (m). This celebrated relation is frequently referred to as the Hagen-Rubens relation.

From the above discussions, the assumptions used to derive this basic model limit the Hagen-Rubens relation to long wavelengths (usually beyond 10 μm) and high temperatures for metals in which the electronic structure can be approximated by one class of free electrons as the current carriers. This relationship has found extensive use in engineering applications.

An equation that can be used for the short wavelength region is developed by introducing a resonant wavelength into the denominator

$$\epsilon(0; \lambda) = A' \left(\frac{r}{\lambda - \lambda_0} \right)^{1/2} + B' \left(\frac{r}{\lambda - \lambda_0} \right) + \dots \quad (2.5-2)$$

where A' and B' are adjustable parameters. For metals, the resistivity is connected with temperature as

$$r = r_0 [1 + \beta(T - 293)] \quad (2.5-3)$$

where r_0 is the resistivity of the metal at 293 K and β is the temperature coefficient of the resistivity. Alternatively, the resistivity can be connected to the temperature by means of a power series

$$r = A' + B' T + C' T^2 + D' T^3 \quad (2.5-4)$$

Using eq. (2.5-3) in eq. (2.5-2), the Hagen-Rubens equation becomes

$$\epsilon(0, \lambda) = A + B \left[\frac{1 + \beta(T-293)}{\lambda - \lambda_0} \right]^{1/2} + C \left[\frac{1 + \beta(T-293)}{\lambda - \lambda_0} \right] + D \left[\frac{1 + \beta(T-293)}{\lambda - \lambda_0} \right]^{3/2} \quad (2.5-5)$$

where A , B , C , D , and λ_0 are adjustable parameters. By finding the normal spectral emittance, the normal spectral absorptance and reflectance can be computed from Kirchhoff's law, i.e.,

$$\alpha(0, \lambda) = \epsilon(0, \lambda) \quad (2.5-6)$$

and then, since a metal is opaque, the reflectance can be found from

$$\rho(0, 2\pi, \lambda) = 1 - \alpha(0, \lambda) \quad (2.5-7)$$

c. Non-Ideal Surfaces

The preceding discussion of the theoretical models used to predict radiative properties applied to ideal surfaces.

It has been understood for many years that the surface condition of metallic specimens plays a dominant role in the magnitude of the radiative properties. The literature abounds with examples of test surfaces shown to be very sensitive to methods of preparation, thermal history, and environmental conditions. Despite this awareness, descriptions of test surfaces are generally inadequate because of our modest understanding of the important mechanisms of real surface effects and how to properly characterize a surface.

Topographical, chemical, and physical (structural) characteristics all influence the properties of the metallic surface. The topographical characteristics describe the profile or geometry of the surface - the boundary between the material and the surrounding medium. The chemical characteristics describe the composition of the surface layer including such features as inhomogeneities and contaminants. The physical characteristics describe the structure of the surface such as crystal lattice orientation, particle size, strain, and other features which might affect the radiant energy exchange process.

To isolate the individual surface characteristics as outlined is a difficult task. For most materials it is not practical to alter one characteristic without causing an influence on another. The control of the many variables required to study surface characterization in a logical manner is a complex problem. As a result only the simplest of surface profiles or compositional effects have been studied or are understood.

The most important influences on the radiative properties of metals arise from surface roughness and films (oxide growth). The effect is most pronounced on the spectral radiative properties when the characteristic profile variation or film thickness is of the same order as the wavelength of interest. For some situations a thin dielectric film has a more significant influence on emittance properties than does surface roughness of the same dimension. These changes in spectral properties are also apparent as changes in angular distribution of reflected or emitted energy.

The influences of surface characteristics - topographical, chemical, physical - can be considerably dependent upon the energy spectrum of importance to the radiative property of interest. For example, the description of a surface for use as a room temperature absorber ($5 < \lambda < 40 \mu\text{m}$) will be quite different from that for a solar absorber ($0.25 < \lambda < 4 \mu\text{m}$). Also the techniques required to study each will be quite different.

The profiles of real metal surfaces are always shown as irregular patterns of peaks and valleys. Various parameters are in common use to describe the topography of a surface including RMS (root mean square) height, CLA (center line average) height,

lay, average slope, height distribution, etc. [A00021, T36500, A00020]. Such parameters are obtained primarily from stylus-type profilometers and to some extent from interferometry techniques.

The effect of surface roughness on the optical properties of materials was first studied by Lord Rayleigh, but only recently has this problem been of intense interest. If the size of the irregularities is of the order of the wavelength or larger, the interaction can be described by geometrical optics [T33896]. In this case, the facets of the surfaces reflect in various directions, and the properties/orientation of the facets must be described by some statistical process in order to explain the optical behavior of the surface. If, however, the surface irregularities are much smaller than the wavelength, the optical behavior can be explained by diffraction phenomena.

The diffraction problem was originally studied by Rice [A00019] and Davies [A00018] and their work was extended and experimentally verified by Bennett and Porteus [T45929]. Their expression for the relative reflectance ratio of the rough, ρ , to smooth, ρ_0 , surface at normal incidence is given as

$$\frac{\rho}{\rho_0} = \exp [-(4\pi\sigma/\lambda)^2] + 32\pi^4 (\sigma/\lambda)^4 (\Delta\theta)^2/m \quad (2.5-6)$$

where σ is the RMS roughness, m is the RMS slope, and $\Delta\theta$ is the half angle of acceptance of the optical system. The first term represents the coherently or specularly reflected fraction and the second term the incoherent or diffusely reflected term. The second term is shown proportional to $(\sigma/\lambda)^4$, and hence for longer wavelengths and smoother surfaces the first term predominates.

2.6. Thermal Radiative Properties of Nonmetallic Solids

a. General Behavior

The typical behavior for a nonmetallic solid which is transparent with little scattering is shown in Figure 3. The transmittance rises sharply in the region of 1-2 μm to a large constant value and drops sharply towards zero in the 8-9 μm region (the use of the 1-2 μm range and the 8-9 μm range is done only for illustrative purposes). Since the reflectance is of the order of 10% and decreases slowly in the entire range of interest, the emittance and absorptance show a behavior as if the transmittance were rotated 180° about the wavelength axis. The emittance decreases sharply in the 1-2 μm region, stays at a constant but low level and in the 8-9 μm region rises sharply to a level near 1.0.




Figure 3. Typical behavior of thermal radiative properties of a transparent non-scattering nonmetallic solid.

b. Partially Transparent Material - Multiple Reflection Model

The simplest of the models to deal with the partially transparent nonscattering materials was developed by McMahon [T20468]. The theory is limited to only the passage of radiant energy normal to the surface but is useful to the very common problem of interpretation of reflectance or transmittance spectra of a partially reflecting slab sample.

Kirchhoff's law in its simplest form relates the spectral emissivity to spectral reflectivity of an opaque material as

$$\epsilon(\lambda, T) = 1 - \rho(\lambda, T) \quad (2.6-1)$$

For a body which is partially transparent because of its low absorption coefficient and/or thickness, Kirchhoff's law cannot be applied directly. Recall that the law derives from the existence of an energy balance between the emission and absorption of a body in thermal equilibrium within a uniformly heated enclosure. When the body is opaque, the incident flux is absorbed or reflected. If the body is partially transparent, the incident flux is absorbed and a significant fraction appears as reflected and transmitted flux after having undergone many internal reflections. For the general expression of Kirchhoff's law it is necessary to include the influence of transmittance.

McMahon shows the three measurable quantities emittance, reflectance, and transmittance are related to the single surface reflectance, R, and the internal transmittance, T, by the following expressions

$$\epsilon(\lambda) = \frac{[1-R(\lambda)] [1-T(\lambda)]}{[1-R(\lambda) T(\lambda)]} \quad (2.6-2)$$

$$\rho(\lambda) = R(\lambda) \left[1 + \frac{T^2(\lambda) [1-R(\lambda)]^2}{1-R^2(\lambda) T^2(\lambda)} \right] \quad (2.6-3)$$

$$\tau(\lambda) = T(\lambda) \frac{[1-R(\lambda)]^2}{[1-R^2(\lambda) T^2(\lambda)]} \quad (2.6-4)$$

The summation of these three equations is unity:

$$\epsilon(\lambda) + \rho(\lambda) + \tau(\lambda) = 1 \quad (2.6-5)$$

and this expression is the extension of Kirchhoff's law to partially transparent bodies.

Also, the results for ϵ , ρ , and τ can be understood by considering a collimated beam of radiant flux incident normally on a semitransparent slab of thickness d and complex index of refraction n^* . The incident flux upon first striking the interface is partially reflected and the balance passes through the interface. The reflected portion

R is computed from the Fresnel relations for normal incidence conditions

$$R = \left(\frac{n^* - 1}{n^* + 1} \right)^2 \quad (2.6-6)$$

It is important to recognize that this reflectance, R, is based upon a single reflection. The remaining flux that passes through the interface will traverse the thickness of the slab while being absorbed and eventually reach the back side. In the course of traversing the thickness of the slab, the radiant flux is diminished by a factor e^{-ad} , where a is the absorption coefficient and d is the specimen thickness. It is convenient to define the internal transmittance, T, as

$$T = e^{-ad} \quad (2.6-7)$$

which is the transmittance (frequently referred to as the transmissivity) within the material and is not affected by or inclusive of interface influences. Of the original flux striking the slab, the fraction $(1 - R)T$ has reached the near side of the slab upon first traversing the slab thickness. At this near interface, a fraction R is reflected and the balance passes through. This process of multiple reflection at the interfaces and traversing of the thickness must be considered to determine the overall transmittance and reflectance of the slab. Figure 4 represents the multiple processes occurring, giving the results

$$\rho = R \left[1 + \frac{T^2(1 - R)^2}{1 - R^2T^2} \right] \quad (2.6-8)$$

$$\tau = T \left[\frac{(1 - R)^2}{1 - R^2T^2} \right] \quad (2.6-9)$$

In terms of the single surface reflectance, R, absorption coefficient, a, and thickness, d, the relations are

$$\tau = \frac{(1 - R)^2 e^{-ad}}{1 - R^2 e^{-2ad}} \quad (2.6-10)$$

$$\rho = R \left[1 + \frac{e^{-2ad} (1 - R)^2}{1 - R^2 e^{-2ad}} \right] \quad (2.6-11)$$

$$\epsilon = \alpha = \frac{(1 - R) (1 - e^{-ad})}{1 - R e^{-ad}} \quad (2.6-12)$$

The above equations hold for $k \ll n$ where k is the absorption index ($\alpha = 4\pi k/\lambda$).




Figure 4. The reflectivity and transmissivity of a semitransparent slab.

A special case of the eqs. (2.6-10) through (2.6-12) is for the case of zero absorption ($\alpha \rightarrow 0$). In that case

$$\epsilon = \alpha = 0 \quad (2.6-13)$$

$$\tau = \frac{2n}{n^2 + 1} \quad (2.6-14)$$

$$\rho = \frac{(n - 1)^2}{n^2 + 1} \quad (2.6-15)$$

The extension of eq. (2.6-10) that holds for k not being less than n is [p. 14 of A00024]

$$\tau = \frac{(1 - R)^2 e^{-ad} \left(1 + \frac{k^2}{n^2} \right)}{1 - R^2 e^{-2ad}}$$

c. Kodak Scheme

Kodak has a method of calculating absorptance and reflectance from transmittance and refractive index data [E62600]. The energy impinging on a transparent slab is broken up into a reflected and transmitted beam. This is continued for three passes and the components added. The analysis is carried out in terms of the loss value factor, κ , from which reflectance and absorptance are calculated. The value of the loss value factor in terms of the measured transmittance, T , and the single surface reflectance, R , is

$$\kappa = \frac{1 - T - 2R(1 - R + R^2)}{1 - 2R + 4R^2} \quad (2.6-16)$$

and

$$\rho = R [1 + (1 + \kappa)^2 (1 - R)^2] \quad (2.6-17)$$

$$\alpha = \epsilon = \kappa (1 - \kappa R) \quad (2.6-18)$$

d. Polymers

Pregelhof, Franey, and Haas [T77125] use a one-dimensional model for polycarbonate plastics, and assuming uniform properties, the emittance $\epsilon(\lambda)$, absorptance $\alpha(\lambda)$, transmittance $\tau(\lambda)$, and reflectance $\rho(\lambda)$ of a polymer sheet can be derived as follows.

$$\epsilon(\lambda) = \alpha(\lambda) = \frac{(1 - R) [(1 + R) \sinh ad + (1 - R) (\cosh ad - 1)]}{(1 + R^2) \sinh ad + (1 - R^2) \cosh ad} \quad (2.6-19)$$

$$\tau(\lambda) = \frac{(1 - R)^2}{(1 + R^2) \sinh ad + (1 - R^2) \cosh ad} \quad (2.6-20)$$

$$\rho(\lambda) = \frac{2R [R \sinh ad + (1 - R) \cosh ad]}{(1 + R^2) \sinh ad + (1 - R^2) \cosh ad} \quad (2.6-21)$$

where $R = (n - 1)^2 / (n + 1)^2$ and n is the refractive index, d is the thickness of the sample, and a is the absorption coefficient.

For the polycarbonate plastic bulk materials, it can be assumed that

$$e^{ad} \gg R^2 e^{-ad} \quad (2.6-22)$$

which enables eqs. (2.6-19) through (2.6-21) to become the following:

$$\epsilon(\lambda) = \alpha(\lambda) \cong (1 - R) [1 - (1 - R) e^{-ad} - R e^{-2ad}] \quad (2.6-23)$$

$$\tau(\lambda) \cong (1 - R)^2 e^{-ad} \quad (2.6-24)$$

$$\rho(\lambda) \cong R [1 + (1 - 2R) e^{-2ad}] \quad (2.6-25)$$

In a wavelength region when the material becomes opaque, i.e., $\tau = 0$, the absorptance can be obtained from

$$\alpha(\lambda) \cong (1 - R)$$

3. DATA EVALUATION AND GENERATION OF RECOMMENDED VALUES

As a result of comprehensive search of literature, numerous research documents of interest to this program are uncovered. These documents are procured and studied, from which pertinent data are extracted, scrutinized, organized, key-punched, homogeneously tabulated, and plotted in huge working graphs readied for data analysis and synthesis. The information on specimen characterization and measurement methods and conditions is recorded in a table specially designed for recording measurement information, which includes (to the extent provided in the original source document) the following:

- (1) Purity, chemical composition, dopant concentration, carrier concentration, defect concentration.
- (2) Type of crystal, crystal axis orientation.
- (3) Microstructure, grain size, inhomogeneity, additional phases.
- (4) Specimen shape and dimensions.
- (5) Method and procedure of fabrication.
- (6) Manufacturer and supplier, stock number, catalog number.
- (7) Heat, mechanical, irradiative, and other treatments.
- (8) Surface conditions.
- (9) Film thickness and substrate material.
- (10) Test environment, degree of vacuum or pressure.
- (11) Experimental method used in the measurement.
- (12) Reference standard used in data observation or reduction.
- (13) Form in which data are presented in the original source document other than tabular data.
- (14) Other pertinent remarks.

Due to the difficulties in accurate measurement of thermal radiative properties of materials and in exact characterization of test specimens and surface conditions, the available experimental data extracted from various research documents are usually widely divergent and subject to large uncertainty. Data evaluation and analysis is therefore very important. The procedure involves critical evaluation of the validity and reliability of the data and related information, resolution and reconciliation of disagreements in conflicting data, correlation of data in terms of various controlling parameters, curve fitting with theoretical or empirical equations, comparison of results with theoretical predictions or with results derived from theoretical relationships or from generalized empirical correlations, etc. Besides critical evaluation and analysis of existing data,

theoretical methods and semiempirical techniques are employed to fill data gaps and to synthesize fragmentary data so that the resulting recommended values are internally consistent and cover as wide a range of wavelength or temperature as possible.

Depending upon the level of confidence the data analyst has placed on the values and upon the degree of completeness of characterization of the test material and surface conditions for which the values are generated, the values are designated as "recommended values", "provisional values", or "typical values". In this report, all the values generated have been properly designated, and the accuracy or uncertainty of the values clearly stated.

4. THERMAL RADIATIVE PROPERTIES OF SELECTED MATERIALS

In each of the following subsections the thermal radiative property data and information for each dependence of each subproperty of each material are presented in the following order: (1) discussion text, (2) table of recommended values, (3) figure of recommended curves, (4) figure of experimental data, (5) table of measurement information, and (6) table of experimental data.

In the discussion text, a review and discussion of the available data and information for the particular dependence of the particular subproperty of the material is given, together with a discussion of the theoretical guidelines and other factors on which the critical evaluation, analysis, and synthesis are based and of the considerations involved in arriving at the final assessment and recommendations.

In the table of recommended values, the values are tabulated with small increments in temperature or wavelength so that linear interpolation of values is meaningful. The recommended values cover the spectrum from visible region (below 1 μm) up to the infrared of 15 μm , whenever possible. Those values as a function of temperature are, whenever possible, tabulated for four particular gas-laser wavelengths: 2.8 μm (hydrogen fluoride laser), 3.8 μm (deuterium fluoride laser), 5.0 μm (carbon monoxide laser), and 10.6 μm (carbon dioxide laser). The values may be designated as recommended, provisional, or typical values. The accuracy or uncertainty of the values is stated in the discussion text. In this report, the ranges of uncertainties of recommended, provisional, and typical values are less than $\pm 15\%$, between $\pm 15\%$ and $\pm 30\%$, and greater than $\pm 30\%$, respectively.

In the figure of recommended curves, experimental data (sometimes selected) are also shown as background for comparison. The curves and data are plotted only up to 14 μm , even though the recommended values or available experimental data may exist above 14 μm . Those values or data above 14 μm not shown in the figure can always be found in the table.

In the figure of experimental data, similarly, data in the wavelength range above 14 μm are not shown. They are, however, tabulated in the experimental data table. Corresponding to each set of data plotted in the figure and tabulated in the experimental data table, the information on the specimen characterization and measurement method and condition is given in the table of measurement information.

Since most of the selected materials are not well known, a concise description of each of the materials is given at the beginning of each of the subsections.

4.1. Aluminum Alloy 2024

Aluminum Alloy 2024, formerly known as Aluminum Alloy 24S, is a wrought alloy with copper as the principal alloying element. Its nominal composition [A00005] is (by weight) 4.5% Cu, 1.5% Mg, 0.6% Mn, and balance Al.

Some physical [T15906] and mechanical properties [A00006] of this material are as follows: solidus temperature, 775 K; liquidus temperature, 911 K; specific gravity, 2.77; tensile (ultimate) strength, 19.0-51.0 kg/mm²; Brinell hardness number (500 kg load, 10 mm ball), 47-130. These properties vary over a wide range due to differences in applied heat treatments.

In the heat treated condition, the mechanical properties of this alloy are similar to, and sometimes exceed, those of mild steel. This heat treatment is specified by a letter "T" after the 2024 designation. The "T", followed by the numerals 1-10, inclusive, designates one specific combination of basic treatments, thus Aluminum Alloy 2024-T4. Briefly, these heat treatments are broken down as follows [A00006] :

- T1 - cooled from an elevated temperature shaping process and naturally aged to a substantially stable condition.
- T2 - annealed (cast products only)
- T3 - solution heat-treated and then cold worked
- T4 - solution heat-treated and naturally aged to a substantially stable condition
- T5 - cooled from an elevated temperature shaping process and then artificially aged
- T6 - solution heat-treated and then artificially aged
- T7 - solution heat-treated and then stabilized
- T8 - solution heat-treated, cold worked, and then artificially aged
- T9 - solution heat-treated, artificially aged, and then cold worked
- T10 - cooled from an elevated temperature shaping process, artificially aged, and then cold worked.

Each of these thermal treatments [A00005] has a unique effect on the mechanical properties of the alloy. The symbol does not define the time and temperature of the thermal treatments; the details of the practice may be varied as desired or convenient if the end result as expressed by specified mechanical properties is unchanged. Should variation of the same basic operation be applied to the same alloy, resulting in different characteristics, other digits are added to the basic designation (Aluminum Alloy 2024-T81 or Aluminum Alloy 2024-T851). The second and third numbers in the heat treatment designation are arbitrary numbers, generally having no logical significance. With the

older nomenclature the specific heat treatments were not catalogued as above. An alloy may be described as Aluminum 24S-T, where the T only means that the material was tempered to a stable condition.

This alloy does not have as good corrosion resistance properties as most other aluminum alloys and under certain conditions may be subjected to intergranular corrosion. Therefore, it is widely used in the clad, anodized, or alodined states. In the clad [A00006] state the 2024 Aluminum Alloy is protected from corrosion by a thin surface of pure metal or an alloy with a higher solution potential than Aluminum Alloy 2024. In this report the term alclad was assumed to have meant the cladding material was pure aluminum. The anodizing [A00005] process involves forming a conversion coating on the metal surface by anodic oxidation. Alodining is also a conversion coating, with the coating being some other type of material such as a phosphate or chromate. These processes greatly increase Aluminum Alloy 2024's resistance to corrosion.

In this report data is actually reported for four different types of Aluminum Alloy 2024 for different subproperties. These types are as follows: Aluminum Alloy 2024 (either heat-treated or not heat-treated), alclad Aluminum Alloy 2024, alodined Aluminum Alloy 2024, and anodized Aluminum Alloy 2024. The provisional values for alclad Aluminum Alloy 2024 are from theoretical calculations using the relation discussed in subsection 4.20, based on Eq. (2.5-5), to calculate normal spectral reflectance. The data given for this alodined Aluminum Alloy 2024 is for a chromate conversion coating applied to the specimen. So, likewise, the provisional curves for the alodined specimen are for this same chromate coating. For the anodized specimen, the surface is actually a layer of aluminum oxide. Therefore, the provisional curves are for this same type of specimen.

No data was located for the following subproperties of aluminum alloy 2024: HSE(T), NSE(T), ASE(λ), ASE(T), HSR(λ), HSR(T), NSR(T), ASR(T), HSA(λ), HSA(T), ASA(λ), and ASA(T).

Data in the data tables also includes data for grooved surfaces of Aluminum Alloy 2024 for the subproperties ASR(λ) and NSR(λ). These data points are not plotted but are included in the report.

Aluminum Alloy 2024 is perhaps the best known and most widely used aircraft alloy.

a. Normal Spectral Emittance (Wavelength Dependence)

There are seven sets of experimental data available for the wavelength dependence (0.12-27.0 μm) of the normal spectral emittance of Aluminum Alloy 2024 under various

surface conditions. These are listed in Table 1-3 and shown in Figures 1-2 and 1-5.

(1) Highly Polished Aluminum Alloy 2024

The recommended values listed in Table 1-1 and shown in Figure 1-1 for highly polished Aluminum Alloy 2024 were generated from the absorptance data reported by Schriempf and Wieting [A00003] and are believed to be accurate to $\pm 10\%$ over the entire wavelength range at 293 K.

(2) Highly Polished Alclad Aluminum Alloy 2024

The recommended values listed in Table 1-1 and shown in Figure 1-3 for highly polished alclad Aluminum Alloy 2024 were generated with the relation discussed in subsection 4.20, based on Eq. (2.5-5), and are believed accurate to $\pm 10\%$ at the reported wavelength range at 293 K. These values are consistent with the normal spectral reflectance data of Grimm and Fannin [A00001] on a similar material. Provisional values at 450, 600, and 750 K tabulated in Table 1-1 and shown in Figure 1-3 were calculated with the relation discussed in subsection 4.20, based on Eq. (2.5-5), and are believed accurate to $\pm 20\%$ over the entire wavelength region for a highly polished (ideal) surface.

(3) Oxidized Aluminum Alloy 2024

Provisional values at 823 K listed in Table 1-1 and shown in Figure 1-4 were generated from the data of Blau, et al. [T16606] and are believed accurate to $\pm 20\%$ over the entire wavelength range.

TABLE I-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	HIGHLY POLISHED ALCLAD $T = 293$	HIGHLY POLISHED ALCLAD $T = 450$	HIGHLY POLISHED ALCLAD $T = 600$	HIGHLY POLISHED ALCLAD $T = 750$	HIGHLY POLISHED ALCLAD $T = 823$
2.00	0.0980	2.5	0.0677	2.5	0.071A†	2.5
2.60	0.0760	2.8	0.057	2.8	0.063A	2.8
3.00	0.0697	3.0	0.052	3.0	0.059A	3.0
3.50	0.0575	3.5	0.044	3.5	0.052A	3.5
3.80	0.0524	3.8	0.041	3.8	0.048A	3.8
4.00	0.0438	4.0	0.039	4.0	0.046A	4.0
4.50	0.0440	4.5	0.035	4.5	0.043A	4.5
5.00	0.0402	5.0	0.033	5.0	0.040A	5.0
5.50	0.0375	5.5	0.031	5.5	0.037A	5.5
6.00	0.0355	6.0	0.029	6.0	0.035A	6.0
6.50	0.0338	6.5	0.027	6.5	0.034A	6.5
7.00	0.0323	7.0	0.026	7.0	0.032A	7.0
7.50	0.0310	7.5	0.025	7.5	0.031A	7.5
8.00	0.0298	8.0	0.024	8.0	0.030A	8.0
8.50	0.0287	8.5	0.023	8.5	0.029A	8.5
9.00	0.0278	9.0	0.023	9.0	0.028A	9.0
9.50	0.0272	9.5	0.022	9.5	0.027A	9.5
10.00	0.0270	10.0	0.021	10.0	0.026A	10.0
10.60	0.0262	10.5	0.021	10.5	0.026A	10.5
11.00	0.0256	11.0	0.020	11.0	0.025A	11.0
11.50	0.0254	11.5	0.020	11.5	0.025A	11.5
12.00	0.0250	12.0	0.019	12.0	0.024A	12.0
12.50	0.0246	12.5	0.019	12.5	0.024A	12.5
13.00	0.0242	13.0	0.019	13.0	0.023A	13.0
13.50	0.0239	13.5	0.018	13.5	0.023A	13.5
14.00	0.0235	14.0	0.018	14.0	0.022A	14.0
14.50	0.0232	14.5	0.017	14.5	0.022A	14.5
15.00	0.0228	15.0	0.017	15.0	0.021A	15.0

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL.




FIGURE 1-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-3. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALCLAD ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF OXIDIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-5. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024
(WAVELENGTH DEPENDENCE).

TABLE I-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T29202	Research Projects Div., G.C. Marshall Space Flight Center	1963	0.12-2.6	323	Specimen 1	Front surface of sample was initially roughened with a variety of emery papers; sample then brought to a fine polish with grinding wheel and alumina powder; measurements made at equivalent time periods in temperature-humidity controlled room; measurements in 0.25-2.5 μm wavelength region were made with a Beckman 24500 reflectance unit and a Beckman DK-2 monochromator in conjunction with an integrating sphere; reported values of normal spectral emittance calculated from formula $\epsilon = 1 - r$; data extracted from figure.
2 T29202	Research Projects Div., G.C. Marshall Space Flight Center	1963	0.26-27.0	323	Specimen 3	Different sample, the above specimens and conditions; measurements in infrared region of spectrum made with an energy detector.
3 T29202	Research Projects Div., G.C. Marshall Space Flight Center	1963	0.26-2.6	323	Specimen 4	Different sample, the above specimens and conditions.
4 T16606	Blaau, H.H., Charlee, E.E., Marsh, J.B., Martin, W.J., and Jasperse, J.R.	1960	2.0-14.0	823		Unpolished, oxidized in air for 2 hr; specimen heated by silicon carbide furnace, emittance measured by Perkin-Elmer Model 12C energy detector; data extracted from figure; $\theta \approx 0^\circ$, reported error $\pm 4\%$.
5 T20470	Weber, D.	1959	7.15-15.06	383	24ST Aluminum (ANA13-352)	Specimen reported as flat and smooth; Perkin-Elmer Model 112 infrared spectrometer used for measurements; normal emissivity assumed; data extracted from figure; reported error $\pm 5\%$.
6 T20470	Weber, D.	1959	7.15-15.06	303	24ST Aluminum (ANA13-362)	The above specimen and conditions.
7 T21553	Berry, J., Lee, T., and Shaw, C.	1959	1.5-21.0	301		Specimen buffed on wheel with jeweler's rouge for 17 min; data extracted from smooth curve; normal emissivity assumed.

TABLE I-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELLENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	CURVE 1 $T = 323^\circ$		CURVE 2 (CONT.)		CURVE 3 (CONT.)		CURVE 5 (CONT.)		CURVE 6 $T = 303^\circ$		CURVE 7 $T = 301^\circ$	
		λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
0.12	0.291	1.21	0.121	0.53	0.197	1.35	0.068	0.70	0.068	1.15	0.068	1.05	0.058
0.26	0.307	1.40	0.118	0.61	0.175	1.46	0.066	0.78	0.069	1.22	0.062	1.12	0.056
0.32	0.309	1.60	0.117	0.61	0.198	1.50	0.066	0.81	0.069	1.29	0.062	1.19	0.056
0.36	0.240	1.80	0.121	0.91	0.193	1.62	0.066	0.85	0.069	1.33	0.062	1.23	0.056
0.41	0.222	2.00	0.121	1.02	0.166	1.47	0.066	0.90	0.069	1.47	0.062	1.37	0.056
0.53	0.170	2.40	0.126	1.20	0.137	1.39	0.121	0.95	0.121	1.55	0.123	1.45	0.115
0.62	0.155	2.60	0.155	1.61	0.123	1.75	0.060	1.00	0.129	8.12	0.050	8.12	0.050
0.70	0.186	3.00	0.161	2.01	0.129	9.06	0.042	0.99	0.136	10.07	0.025	10.07	0.025
0.81	0.192	3.79	0.089	2.21	0.145	10.07	0.042	1.00	0.145	11.07	0.042	11.07	0.042
1.02	0.146	5.19	0.054	2.40	0.161	12.05	0.042	1.01	0.161	12.05	0.042	12.05	0.042
1.21	0.129	6.16	0.090	2.40	0.145	13.05	0.023	1.02	0.145	13.05	0.023	13.05	0.023
1.48	0.120	7.62	0.036	2.60	0.161	14.06	0.038	1.03	0.161	14.06	0.038	14.06	0.038
1.60	0.131	8.57	0.036	2.60	0.161	15.06	0.047	1.04	0.161	15.06	0.047	15.06	0.047
1.89	0.135	9.54	0.034	2.81	0.161	16.06	0.047	1.05	0.161	16.06	0.047	16.06	0.047
2.01	0.135	10.36	0.034	2.81	0.161	17.06	0.047	1.06	0.161	17.06	0.047	17.06	0.047
2.20	0.143	10.97	0.042	2.93	0.177	18.06	0.047	1.07	0.177	18.06	0.047	18.06	0.047
2.39	0.151	11.73	0.034	3.00	0.197	19.06	0.047	1.08	0.197	19.06	0.047	19.06	0.047
2.68	0.168	12.28	0.042	3.00	0.197	20.06	0.047	1.09	0.197	20.06	0.047	20.06	0.047
2.68	0.168	12.94	0.043	3.07	0.197	21.06	0.047	1.10	0.197	21.06	0.047	21.06	0.047
2.68	0.168	13.62	0.043	5.02	0.369	22.06	0.243	1.11	0.369	22.06	0.243	22.06	0.243
2.68	0.168	14.04	0.057	5.99	0.360	23.06	0.243	1.12	0.360	23.06	0.243	23.06	0.243
2.68	0.168	14.08	0.052	6.98	0.336	24.06	0.243	1.13	0.336	24.06	0.243	24.06	0.243
2.68	0.168	14.12	0.042	7.95	0.326	25.06	0.243	1.14	0.326	25.06	0.243	25.06	0.243
2.68	0.168	14.65	0.060	6.97	0.310	26.06	0.243	1.15	0.310	26.06	0.243	26.06	0.243
2.68	0.168	16.27	0.051	9.98	0.291	27.06	0.243	1.16	0.291	27.06	0.243	27.06	0.243
2.68	0.168	16.27	0.044	10.98	0.277	28.06	0.243	1.17	0.277	28.06	0.243	28.06	0.243
2.68	0.168	18.27	0.039	11.98	0.265	29.06	0.243	1.18	0.265	29.06	0.243	29.06	0.243
2.68	0.168	20.10	0.038	12.95	0.253	30.06	0.243	1.19	0.253	30.06	0.243	30.06	0.243
2.68	0.168	21.78	0.047	14.00	0.252	31.06	0.243	1.20	0.252	31.06	0.243	31.06	0.243
2.68	0.168	24.32	0.064	0.60	0.252	32.06	0.243	1.21	0.252	32.06	0.243	32.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	33.06	0.243	1.22	0.252	33.06	0.243	33.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	34.06	0.243	1.23	0.252	34.06	0.243	34.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	35.06	0.243	1.24	0.252	35.06	0.243	35.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	36.06	0.243	1.25	0.252	36.06	0.243	36.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	37.06	0.243	1.26	0.252	37.06	0.243	37.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	38.06	0.243	1.27	0.252	38.06	0.243	38.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	39.06	0.243	1.28	0.252	39.06	0.243	39.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	40.06	0.243	1.29	0.252	40.06	0.243	40.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	41.06	0.243	1.30	0.252	41.06	0.243	41.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	42.06	0.243	1.31	0.252	42.06	0.243	42.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	43.06	0.243	1.32	0.252	43.06	0.243	43.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	44.06	0.243	1.33	0.252	44.06	0.243	44.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	45.06	0.243	1.34	0.252	45.06	0.243	45.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	46.06	0.243	1.35	0.252	46.06	0.243	46.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	47.06	0.243	1.36	0.252	47.06	0.243	47.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	48.06	0.243	1.37	0.252	48.06	0.243	48.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	49.06	0.243	1.38	0.252	49.06	0.243	49.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	50.06	0.243	1.39	0.252	50.06	0.243	50.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	51.06	0.243	1.40	0.252	51.06	0.243	51.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	52.06	0.243	1.41	0.252	52.06	0.243	52.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	53.06	0.243	1.42	0.252	53.06	0.243	53.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	54.06	0.243	1.43	0.252	54.06	0.243	54.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	55.06	0.243	1.44	0.252	55.06	0.243	55.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	56.06	0.243	1.45	0.252	56.06	0.243	56.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	57.06	0.243	1.46	0.252	57.06	0.243	57.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	58.06	0.243	1.47	0.252	58.06	0.243	58.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	59.06	0.243	1.48	0.252	59.06	0.243	59.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	60.06	0.243	1.49	0.252	60.06	0.243	60.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	61.06	0.243	1.50	0.252	61.06	0.243	61.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	62.06	0.243	1.51	0.252	62.06	0.243	62.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	63.06	0.243	1.52	0.252	63.06	0.243	63.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	64.06	0.243	1.53	0.252	64.06	0.243	64.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	65.06	0.243	1.54	0.252	65.06	0.243	65.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	66.06	0.243	1.55	0.252	66.06	0.243	66.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	67.06	0.243	1.56	0.252	67.06	0.243	67.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	68.06	0.243	1.57	0.252	68.06	0.243	68.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	69.06	0.243	1.58	0.252	69.06	0.243	69.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	70.06	0.243	1.59	0.252	70.06	0.243	70.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	71.06	0.243	1.60	0.252	71.06	0.243	71.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	72.06	0.243	1.61	0.252	72.06	0.243	72.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	73.06	0.243	1.62	0.252	73.06	0.243	73.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	74.06	0.243	1.63	0.252	74.06	0.243	74.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	75.06	0.243	1.64	0.252	75.06	0.243	75.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	76.06	0.243	1.65	0.252	76.06	0.243	76.06	0.243
2.68	0.168	26.98	0.060	0.60	0.252	77.06	0.243	1.66	0.252	77.06	0.243	77.06	0.

b. Normal Spectral Emittance (Temperature Dependence)

There are no experimental data located in the literature. The provisional values tabulated in Table 1-4 and shown in Figure 1-6 were calculated with the relation discussed in subsection 4.20, based on Eq. (2.5-5), for highly polished alclad Aluminum Alloy 2024 for wavelengths of 2.8, 3.8, 5.0, and 10.6 μm . These values are believed accurate to $\pm 20\%$ over the entire wavelength range.

TABLE I-4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T	ϵ	T	ϵ	T	ϵ	T	ϵ
HIGHLY POLISHED ALCLAD $\lambda = 2.8$							
250.0	0.054	250.0	0.038	250.0	0.030	250.0	0.019
293.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021
300.0	0.057	300.0	0.041	300.0	0.033	300.0	0.021
350.0	0.060	350.0	0.044	350.0	0.036	350.0	0.023
400.0	0.062	400.0	0.046	400.0	0.036	400.0	0.024
450.0	0.063	450.0	0.043	450.0	0.040	450.0	0.026
500.0	0.065	500.0	0.050	500.0	0.041	500.0	0.027
550.0	0.066	550.0	0.052	550.0	0.043	550.0	0.028
600.0	0.067	600.0	0.053	600.0	0.044	600.0	0.029
650.0	0.068	650.0	0.055	650.0	0.046	650.0	0.030
700.0	0.068	700.0	0.056	700.0	0.047	700.0	0.031
750.0	0.069	750.0	0.057	750.0	0.048	750.0	0.032
HIGHLY POLISHED ALCLAD $\lambda = 3.0$							
250.0	0.054	250.0	0.038	250.0	0.030	250.0	0.019
293.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021
300.0	0.057	300.0	0.041	300.0	0.033	300.0	0.021
350.0	0.060	350.0	0.044	350.0	0.036	350.0	0.023
400.0	0.062	400.0	0.046	400.0	0.036	400.0	0.024
450.0	0.063	450.0	0.043	450.0	0.040	450.0	0.026
500.0	0.065	500.0	0.050	500.0	0.041	500.0	0.027
550.0	0.066	550.0	0.052	550.0	0.043	550.0	0.028
600.0	0.067	600.0	0.053	600.0	0.044	600.0	0.029
650.0	0.068	650.0	0.055	650.0	0.046	650.0	0.030
700.0	0.068	700.0	0.056	700.0	0.047	700.0	0.031
750.0	0.069	750.0	0.057	750.0	0.048	750.0	0.032
HIGHLY POLISHED ALCLAD $\lambda = 5.0$							
250.0	0.054	250.0	0.038	250.0	0.030	250.0	0.019
293.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021
300.0	0.057	300.0	0.041	300.0	0.033	300.0	0.021
350.0	0.060	350.0	0.044	350.0	0.036	350.0	0.023
400.0	0.062	400.0	0.046	400.0	0.036	400.0	0.024
450.0	0.063	450.0	0.043	450.0	0.040	450.0	0.026
500.0	0.065	500.0	0.050	500.0	0.041	500.0	0.027
550.0	0.066	550.0	0.052	550.0	0.043	550.0	0.028
600.0	0.067	600.0	0.053	600.0	0.044	600.0	0.029
650.0	0.068	650.0	0.055	650.0	0.046	650.0	0.030
700.0	0.068	700.0	0.056	700.0	0.047	700.0	0.031
750.0	0.069	750.0	0.057	750.0	0.048	750.0	0.032
HIGHLY POLISHED ALCLAD $\lambda = 10.6$							
250.0	0.054	250.0	0.038	250.0	0.030	250.0	0.019
293.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021
300.0	0.057	300.0	0.041	300.0	0.033	300.0	0.021
350.0	0.060	350.0	0.044	350.0	0.036	350.0	0.023
400.0	0.062	400.0	0.046	400.0	0.036	400.0	0.024
450.0	0.063	450.0	0.043	450.0	0.040	450.0	0.026
500.0	0.065	500.0	0.050	500.0	0.041	500.0	0.027
550.0	0.066	550.0	0.052	550.0	0.043	550.0	0.028
600.0	0.067	600.0	0.053	600.0	0.044	600.0	0.029
650.0	0.068	650.0	0.055	650.0	0.046	650.0	0.030
700.0	0.068	700.0	0.056	700.0	0.047	700.0	0.031
750.0	0.069	750.0	0.057	750.0	0.048	750.0	0.032




FIGURE 1-6. PROVISIONAL NORMAL SPECTRAL EMMITTANCE OF ALCUAD ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE).

c. Angular Spectral Emittance (Wavelength Dependence)

There are no data available for this subproperty but the provisional values listed in Table 1-5 and shown in Figures 1-7, 1-8, and 1-9 for anodized, alodined ($\theta = 15^\circ$), and alodined ($\theta = 45^\circ$) Aluminum Alloy 2024, respectively, were calculated from the angular spectral reflectance data (see Section 4.1.f). These values are believed accurate to $\pm 15\%$ over the entire wavelength range for the anodized and alodined Aluminum Alloy 2024 ($\theta = 15^\circ$) materials at 293 K. The provisional values for alodined Aluminum Alloy 2024 ($\theta = 45^\circ$) are accurate to $\pm 20\%$.

There are several methods which can be used to produce an anodized surface. The angular spectral emittance can vary widely with the anodizing process, i.e., porous or hard, secondary treatments such as sealing or dying of the surface layer, and thickness. Most of the authors do not clearly specify the nature of the anodizing process or surface conditions. So the provisional values reported in Table 1-5 are applicable only to the sulfuric acid anodized surface. Similarly, there are several alodining processes. Depending on this process the angular spectral emittance may vary. The provisional values apply only to the chromate conversion coating used in the references.

TABLE I-5. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
SULFURIC ACID ANODIZED, $\theta = 15^\circ$ $T = 293$											
0.30	0.743	6.10	0.464	2.34	0.517	12.00	0.142	2.00	0.240		
0.35	0.640	6.20	0.473	2.50	0.531	12.50	0.135	2.20	0.258		
0.40	0.553	6.40	0.410	2.00	0.604	13.06	0.129	2.40	0.288		
0.50	0.482	6.60	0.398	3.00	0.677	13.50	0.123	2.60	0.358		
0.60	0.474	6.80	0.405	3.05	0.685	14.00	0.118	2.80	0.552		
0.70	0.475	7.00	0.426	3.10	0.689	14.50	0.113	3.00	0.620		
0.80	0.461	7.20	0.514	3.15	0.690	15.00	0.109	3.10	0.618		
0.83	0.482	7.40	0.640	3.20	0.682			3.20	0.696		
0.90	0.434	7.60	0.740	3.25	0.673			3.40	0.556		
1.00	0.380	7.80	0.820	3.30	0.655			3.60	0.470		
1.20	0.320	8.00	0.875	3.50	0.589			3.80	0.406		
1.40	0.292	8.20	0.918	3.70	0.528			4.00	0.366		
1.60	0.274	8.40	0.942	3.80	0.502			4.20	0.338		
1.80	0.268	8.60	0.949	4.00	0.480			4.40	0.320		
2.00	0.279	8.80	0.947	4.20	0.458			4.50	0.316		
2.20	0.301	9.00	0.941	4.50	0.431			4.60	0.320		
2.40	0.341	9.20	0.920	4.56	0.426			4.70	0.400		
2.60	0.422	9.40	0.893	4.61	0.427			4.72	0.412		
2.80	0.779	9.60	0.864	4.70	0.461			4.76	0.414		
3.20	0.677	10.60	0.960	4.74	0.470			4.80	0.412		
3.85	0.807	9.80	0.855	4.77	0.481			4.90	0.320		
2.90	0.610	10.00	0.864	4.77	0.481			5.00	0.298		
2.95	0.808	10.20	0.900	4.81	0.472			5.20	0.280		
3.00	0.797	10.40	0.935	4.87	0.440			5.40	0.270		
3.20	0.677	10.60	0.960	4.93	0.405			5.60	0.260		
3.40	0.592	10.80	0.972	4.95	0.397			5.80	0.252		
3.60	0.526	11.00	0.975	5.00	0.394			6.00	0.246		
3.80	0.484	11.20	0.963	5.50	0.362			7.00	0.220		
4.00	0.454	11.40	0.955	6.00	0.334			8.00	0.200		
4.20	0.428	11.60	0.949	6.50	0.308			9.00	0.181		
4.40	0.410	11.80	0.943	7.00	0.285			10.00	0.164		
4.60	0.396	12.00	0.938	7.50	0.263			10.60	0.156		
4.80	0.389	12.50	0.928	8.00	0.244			11.00	0.150		
5.00	0.384	13.00	0.920	8.50	0.227			12.00	0.136		
5.20	0.382	13.50	0.915	9.00	0.210			13.00	0.127		
5.40	0.390	14.00	0.909	9.50	0.195			14.00	0.116		
5.60	0.406	14.50	0.905	10.00	0.182						
5.80	0.442	15.00	0.902	10.60	0.167						
6.00	0.476			11.00	0.150						
	0.484			11.50	0.150						




FIGURE 1-7. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-8. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)




FIGURE 1-9. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF ALCOINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).

d. Normal Spectral Reflectance (Wavelength Dependence)

There are 47 sets of experimental data available for the wavelength dependence ($\lambda = 0.3\text{-}25.0 \mu\text{m}$) of the normal spectral reflectance of Aluminum Alloy 2024 under various surface conditions. These are listed in Table 1-8 and most of them are shown in Figure 1-11. There are four sets of experimental data available for wavelength dependence ($\lambda = 2.0\text{-}15.0 \mu\text{m}$) of the normal spectral reflectance of polished alclad Aluminum Alloy 2024 shown in Figure 1-13. Out of the total 47 data sets, 15 sets are for a polished material. Most of the measurements are for wavelengths between 0.3-3.0 μm .

(1) Highly Polished Aluminum Alloy 2024

The recommended values at 293 K listed in Table 1-6 and plotted in Figure 1-10 are primarily from the investigation of Schriempf and Wieting [A00003] and are believed to be accurate to $\pm 10\%$ over the entire wavelength range. These values are consistent with the normal spectral emittance measurements of the similar material.

(2) Alclad Aluminum Alloy 2024

There are four sets of data for the wavelength dependence (2.0-14.7 μm) of the angular spectral reflectance of alclad Aluminum Alloy 2024. These are shown in Figure 1-13 and listed in Table 1-8. The incident angle reported is 15°. The normal spectral reflectance values for an ideal aluminum surface calculated using the relation discussed in subsection 4.20 and based on Eq. (2.5-5) agree extremely well with experimental results. These recommended values are believed accurate to $\pm 10\%$ over the entire wavelength range. The provisional values for highly polished alclad Aluminum Alloy 2024 reported at 450, 600, and 750 K shown in Figure 1-12 and listed in Table 1-6, were calculated from the relation discussed in subsection 4.20, based on Eq. (2.5-5). These values are believed accurate to $\pm 20\%$.

(3) Oxidized Aluminum Alloy 2024

The provisional values listed in Table 1-6 and shown in Figure 1-14 are for oxidized Aluminum Alloy 2024 at 823 K. These values are consistent with the provisional normal spectral emittance values (see Section 4.1a). These values are believed accurate to $\pm 20\%$.

TABLE 1-6. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	HIGHLY POLISHED ALCLAD $T = 293$	HIGHLY POLISHED ALCLAD $T = 450$	HIGHLY POLISHED ALCLAD $T = 600$	HIGHLY POLISHED ALCLAD $T = 750$	HIGHLY POLISHED ALCLAD $T = 750$	λ	ρ	HIGHLY POLISHED ALCLAD $T = 750$	λ	ρ	OXIDIZED ALLOY $T = 823$
2.20	0.9020	2.5	0.933	2.5	0.929A†	2.5	0.927A†	2.5	0.925A†	2.00	0.974A†	
2.80	0.9240	2.6	0.943	2.6	0.937A	2.6	0.933A	2.6	0.931A	2.20	0.982A	
3.00	0.9303	3.0	0.948	3.0	0.941A	3.0	0.937A	3.0	0.934A	2.50	0.990A	
3.50	0.9425	3.5	0.956	3.5	0.946A	3.5	0.944A	3.5	0.940A	2.80	0.997A	
3.86	0.9476	3.8	0.959	3.8	0.952A	3.8	0.947A	3.8	0.943A	3.00	0.961A	
4.00	0.9502	4.0	0.961	4.0	0.954A	4.0	0.949A	4.0	0.945A	3.20	0.960A	
4.50	0.9560	4.5	0.965	4.5	0.957A	4.5	0.953A	4.5	0.949A	3.50	0.961A	
5.00	0.9538	5.0	0.967	5.0	0.960A	5.0	0.956A	5.0	0.952A	3.80	0.9619A	
5.50	0.9625	5.5	0.969	5.5	0.963A	5.5	0.958A	5.5	0.954A	4.00	0.9624A	
6.00	0.9645	6.0	0.971	6.0	0.965A	6.0	0.960A	6.0	0.957A	4.20	0.9626A	
6.50	0.9662	6.5	0.973	6.5	0.966A	6.5	0.962A	6.5	0.958A	4.50	0.9634A	
7.00	0.9677	7.0	0.974	7.0	0.968A	7.0	0.963A	7.0	0.960A	4.80	0.9638A	
7.50	0.9690	7.5	0.975	7.5	0.969A	7.5	0.965A	7.5	0.961A	5.00	0.9640A	
8.00	0.9702	8.0	0.976	8.0	0.970A	8.0	0.966A	8.0	0.963A	5.20	0.9644A	
8.50	0.9713	8.5	0.977	8.5	0.971A	8.5	0.967A	8.5	0.964A	5.50	0.9649A	
9.00	0.9722	9.0	0.977	9.0	0.972A	9.0	0.968A	9.0	0.965A	5.80	0.9654A	
9.50	0.9728	9.5	0.978	9.5	0.973A	9.5	0.969A	9.5	0.966A	6.00	0.9658A	
10.00	0.9730	10.0	0.979	10.0	0.974A	10.0	0.970A	10.0	0.967A	6.20	0.9660A	
10.60	0.9738	10.5	0.979	10.5	0.974A	10.5	0.971A	10.5	0.968A	6.50	0.9664A	
11.00	0.9742	11.0	0.980	11.0	0.975A	11.0	0.971A	11.0	0.968A	7.00	0.9670A	
11.50	0.9746	11.5	0.980	11.5	0.975A	11.5	0.972A	11.5	0.969A	7.20	0.9672A	
12.00	0.9750	12.0	0.981	12.0	0.976A	12.0	0.972A	12.0	0.970A	7.50	0.9677A	
12.50	0.9754	12.5	0.981	12.5	0.976A	12.5	0.973A	12.5	0.970A	8.00	0.9683A	
13.00	0.9758	13.0	0.981	13.0	0.977A	13.0	0.974A	13.0	0.971A	8.50	0.9690A	
13.50	0.9761	13.5	0.982	13.5	0.977A	13.5	0.974A	13.5	0.971A	9.00	0.9697A	
14.00	0.9765	14.0	0.982	14.0	0.978A	14.0	0.975A	14.0	0.972A	9.50	0.9704A	
14.50	0.9768	14.5	0.983	14.5	0.978A	14.5	0.975A	14.5	0.972A	10.00	0.9710A	
15.00	0.9772	15.0	0.983	15.0	0.975A	15.0	0.973A	15.0	0.971A	10.50	0.9716A	
										11.00	0.9723A	
										11.50	0.9729A	
										12.00	0.9734A	
										12.50	0.9739A	
										13.00	0.9746A	
										13.50	0.9750A	
										14.00	0.9752A	

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL.





FIGURE 1-10. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024
(WAVELENGTH DEPENDENCE).






FIGURE 1-12. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALCLAD ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-13. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALCLAD ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-14. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF OXIDIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).

TABLE I-7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence)

Cur. Ref. No.	Author(s) and Schurin, B.D.	Year 1957	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T06979	Betz, H.T., Morris, J.C., Olson, O.H., and Schurin, B.D.	1957	0.3-2.7	293	Aluminum 24-ST	Surface conditions as received from supplier, may include oily film or plain dirt; a General Electric Recording Spectrophotometer is used in visible range and an integrating sphere reflectometer is used for ultraviolet and infrared regions; magnesium carbonate block used for standard; smooth values extracted from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta=6^\circ$ in visible region, $\theta=90^\circ$ in ultraviolet and infrared regions; reported error $\pm 4\%$.
2 T06979	Betz, H.T., et al.	1957	0.3-2.7	293	Aluminum 24-ST	Similar to the above specimen except sample cleaned with liquid detergent to remove superficial dirt and oil films.
3 T06979	Betz, H.T., et al.	1957	0.3-2.7	293	Aluminum 24-ST	Similar to the above specimen except sample polished with fine polishing compound on buffing wheel.
4 T06979	Betz, H.T., et al.	1957	0.3-2.7	293	Aluminum 24-ST	Similar to the above specimen except sample allowed to oxidize in air at red heat for 30 min.
5 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 7	Specimen was 15/16" x 1" x 1" with symmetric V-grooves cut into one 15/16" x 1" face; grooved surfaces made for this study with ruling machine of type used by Beuschi and Lomb, loc.; profiles and angle so reported by manufacturer, valley to valley distance (w), 53.33 μm, peak to valley height (h), 24.4 μm, and angle between faces, 119°15'; source used is G.E. 30A/T20/4 tungsten ribbon strip lamp enclosed in H ₂ O cooled shield, monochromator used was Perkin-Elmer Model 83, detectors used were RCA 1P28 photomultiplier tube for visible (0.2-0.7 μm) and Perkin-Elmer lead sulfide photocconducting cell for near infrared (0.4-2.8 μ); incident beam and viewing path was perpendicular to groove; angle θ said to be negative if measured in same direction from normal as θ ; θ uncertainty $\pm 1^\circ$; reference was standard mirror; specimen appeared "bright and shining" to eye; measured temperature specified as room temperature, 293 K assigned; $\theta=0^\circ$, $\theta=-58^\circ$.
6 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta'=80^\circ$.
7 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 8	Similar to the above specimen except $\theta'=59^\circ$.
8 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta'=60^\circ$.
9 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 9	Similar to the above specimen except w = 16.67 μm, h = 4.9 μm, the angle of the V-groove = 119°6'; $\theta=58.0^\circ$.
10 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 9	The above specimen except $\theta'=59.5^\circ$.
11 T29563	Eberhart, R.C.	1960	1.0-2.6	293	Aluminum 24ST, Polished	Specimen 2.22 cm discs, 0.16 to 0.32 cm thick; sample surface prepared by standard metallographic techniques, average horizontal peak to peak distance, 30 μm, groove depth is 0.40 μm; integrating sphere used with P&S detector; reference standard MgO; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta=5^\circ$, $\omega=27^\circ$.
12 T29563	Eberhart, R.C.	1960	0.4-1.0	293	Aluminum 24ST, Polished	Similar to the above specimen except a photodiode detector (RCA PM 128 photomultiplier tube) was used with an integrating sphere.

TABLE 1-7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
13 T29563	Eberhart, R.C.	1960	1.0-2.6	293	Aluminum 2AST, Polished	Similar to the above specimen except a Beckman DK-2 spectrophotometer was used for measurement; stated values were uncorrected; reported error 10-15%.
14 T29563	Eberhart, R.C.	1960	1.0-2.6	293	Aluminum 2AST, Polished	Similar to specimen in curve 11.
15 T29563	Eberhart, R.C.	1960	1.0-2.6	293	Aluminum 2AST, Polished	Similar to the above specimen but a Beckman DK-2 spectrophotometer was used for measurement; stated values were corrected.
16 T29563	Eberhart, R.C.	1960	1.2,1.8	293	Aluminum 2AST, Polished	Similar to specimen in curve 11 except $\theta=0^\circ$.
17 T29563	Eberhart, R.C.	1960	1.2,1.8	293	Aluminum 2AST, Polished	Similar to specimen in curve 11 except $\theta=10^\circ$.
18 T29563	Eberhart, R.C.	1960	1-2.6	293	Aluminum 2AST, Polished	Similar to the above specimen except data extracted from smooth curve; $\theta=5^\circ$.
19 T29563	Eberhart, R.C.	1960	1-2.6	293	Aluminum 2AST, Grade 1	Similar to the above specimen except average horizontal peak to peak distance, 7 μm , groove depth (average displacement from mean surface line) is 3.45 μm ; sample surface prepared with sandpaper; data extracted from smooth curve.
20 T29563	Eberhart, R.C.	1960	1-2.6	293	Aluminum 2AST, Grade 2	Similar to the above specimen except average horizontal peak to peak distance, 10 μm , groove depth (average displacement from mean surface line) is 4.32 μm ; sample surface prepared with sandpaper; data extracted from smooth curve.
21 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Polished	Similar to specimen in curve 11 except data extracted from smooth curve; $\theta=0^\circ$.
22 T29562	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Polished	Similar to the above specimen except $\theta=5^\circ$.
23 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Polished	Similar to the above specimen except $\theta=10^\circ$.
24 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Grade 1	Similar to the above specimen except average horizontal peak to peak distance, 7 μm , groove depth (average displacement from mean surface line) is 3.48 μm ; sample surface prepared with sandpaper; data extracted from smooth curve; $\theta=0^\circ$.
25 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Grade 1	Similar to the above specimen except $\theta=5^\circ$.
26 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Grade 1	Similar to the above specimen except $\theta=10^\circ$.
27 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Grade 2	Similar to the above specimen except average horizontal peak to peak distance, 10 μm , groove depth (average displacement from mean surface line) is 4.32 μm ; sample surface prepared with sandpaper; data extracted from smooth curve; $\theta=0^\circ$.
28 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Grade 2	Similar to the above specimen except $\theta=5^\circ$.
29 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 2AST, Grade 2	Similar to the above specimen except $\theta=10^\circ$.

TABLE 1-7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
30 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Polished; Beckman DK-2 spectrometer integrating sphere used for measurement; MgO reference standard; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta=0^\circ$, $\omega=27^\circ$. Similar to the above specimen except $\theta=10^\circ$.
31 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Roughened sample; surface roughened with sandpaper; scratches parallel, coarse structure-peak to peak depth 6.35 μm , spacing ~34 μm ; fine structure-peak to peak depth 1 μm ; Beckman DK-2 spectrometer integrating sphere used for measurement; MgO reference standard; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta=0^\circ$, $\omega=27^\circ$.
32 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=10^\circ$.
33 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Sample anodized; specimen irradiated in vacuum $\leq 1 \times 10^{-5}$ mm Hg at level of 0.75 cal/min for 100 hr; measurements made with Beckman DK-2 Spectrophotometer; data extracted from figure; measurement temperature not explicitly given, 293 K assigned; normal reflectance assumed; $\theta=0^\circ$.
34 T24808	Alexander, A.L., Cowling, J.E., and Noonan, F.M.	1961	0.22-2.7	293	Aluminum Alloy 24S-T	Similar to the above specimen except irradiation applied for 60 hr.
35 T24808	Alexander, A.L., et al.	1961	0.20-2.7	293	Aluminum Alloy 24S-T	Similar to the above specimen except irradiation applied for 20 hr.
36 T24808	Alexander, A.L., et al.	1961	0.22-2.7	293	Aluminum Alloy 24S-T	Similar to the above specimen except irradiation applied for 60 hr.
37 T24808	Alexander, A.L., et al.	1961	0.22-2.7	293	Aluminum Alloy 24S-T	Similar to the above specimen except not exposed to irradiation.
38 T24808	Alexander, A.L., et al.	1961	0.22-2.7	293	Aluminum Alloy 24S-T	Sample clean rolled; specimen irradiated in vacuum $\leq 1 \times 10^{-5}$ mm Hg at level of 0.75 cal/min for 100 hr; measurements made with Beckman DK-2 spectrophotometer; data extracted from figure; measurement temperature not explicitly given, 293 K assigned; normal reflectance assumed; $\theta=0^\circ$.
39 T24808	Alexander, A.L., et al.	1962	0.22-2.7	293	Aluminum Alloy 24S-T	Similar to the above specimen except irradiation applied for 60 hr.
40 T24808	Alexander, A.L., et al.	1961	0.22-2.7	293	Aluminum Alloy 24S-T	Similar to the above specimen except irradiation applied for 20 hr.
41 T24808	Alexander, A.L., et al.	1961	0.22-2.7	293	Aluminum Alloy 24S-T	Similar to the above specimen except not exposed to irradiation.
42 A00003	Schriener, J.T. and Wiering, T.J.	1974	2.53-20.0	293	Aluminum Alloy	Author states specimen was "aluminum alloy very similar to 2024 aluminum"; author describes surface as "high quality"; reflectance measured using grating spectrometer; a gold reference mirror was used as a standard; data extracted from figure; measurement temperature specified as room temperature, 293 K assigned; $\theta=0^\circ$, reported error $\pm 0.1\%$.

TABLE 1-7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
43 A300C:	Grimm, F. C. and Farnin, E.R.	1972	2-14.7	293	2024-T81 Alclad, Sample No. B-1	Polished; sample thickness 99.0×10^{-3} cm; samples prepared by Organic Chemistry Laboratory of Dept. 256; measurements made with a Dunn Associates ellipsoidal mirror reflectometer; measurement temperature specified as ambient temperature 293 K assigned; data extracted from smooth curve; relative reflectance reported, multiplied by 0.95 to convert to absolute (gold reference standard used); $\theta=15^\circ$, $\omega=2\pi$.
44 A03001	Grimm, F. C. and Farnin, E.R.	1972	2.8-10.6	293	2024-T81 Alclad, Sample No. B-1	The above specimen; reported values different from the values of above specimen for unknown reason.
45 A05001	Grimm, F. C. and Farnin, E.R.	1972	2.8-10.6	293	2024-T81 Alclad, Sample No. B-1	The above specimen.
46 A01001	Grimm, F. C. and Farnin, E.R.	1972	2.8-10.6	293	2024-T81 Alclad, Sample No. B-1	The above specimen except sample heat treated by heating to 644 K for 1 hr in air; absolute reflectance reported; data extracted from table.
47 T4074C	Shipley, W. S. and Thosteson, T.O.	1960	0.4-25.0	293	2024-T3 Aluminum Sample S-4	"125" finish; measurement temperature not given explicitly, 293 K assigned; data extracted from smooth curve; normal reflectance assumed; $\theta \sim 0^\circ$, $\omega = 2\pi$.

TABLE I-8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)

[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ]

λ	ρ	CURVE 1 $T = 293.$	λ	ρ	CURVE 1 (CONT.)	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 5* $T = 293.$	λ	ρ	CURVE 6* $T = 293.$	λ	ρ	CURVE 7* $T = 293.$	λ	ρ	CURVE 8* $T = 293.$	
0.300	0.515	2.705	0.987		2.324	1.000		2.299	0.922		1.956	0.026		0.5	0.183												
0.320	0.547			CURVE 2 $T = 293.$	2.377	0.987		2.360	0.917		2.026	0.042															
0.339	0.575				2.458	0.990		2.413	0.910		2.116	0.051															
0.361	0.598				2.516	0.988		2.456	0.917		2.211	0.059															
0.397	0.638	0.300	0.581		2.705	0.987		2.516	0.931		2.281	0.069															
0.427	0.666	0.357	0.638	CURVE 3 $T = 293.$	2.605	0.987		2.552	0.941		2.351	0.080															
0.466	0.685	0.399	0.672		0.300	0.300		2.611	0.950		2.414	0.094		0.5	0.226												
0.506	0.701	0.450	0.700		0.323	0.729		2.653	0.941		2.470	0.912															
0.560	0.719	0.523	0.729		0.379	0.633		2.700	0.922		2.522	0.926															
0.640	0.738	0.596	0.752		0.449	0.648		2.642	0.942		2.562	0.936															
0.724	0.738	0.654	0.758		0.506	0.657		2.700	0.922		2.603	0.943															
0.775	0.726	0.708	0.752		0.576	0.665		0.300	0.072		0.336	0.190															
0.811	0.719	0.766	0.735		0.614	0.672		0.336	0.190		0.353	0.242															
0.851	0.736	0.793	0.727		0.682	0.693		0.672	0.672		0.367	0.254															
0.893	0.756	0.822	0.731		0.742	0.747		0.725	0.688		0.414	0.263		0.5	0.237												
0.926	0.782	0.842	0.742		0.766	0.766		0.772	0.647		0.457	0.279		1.5	0.342												
1.017	0.795	0.866	0.866		0.930	0.803		0.805	0.645		0.569	0.324		0.640	0.360												
1.113	0.822	0.887	0.887		1.013	0.799		0.838	0.659		0.640	0.360		0.705	0.376												
1.228	0.857	1.013	0.887		1.024	0.824		0.873	0.687		0.725	0.414		0.873	0.414												
1.310	0.862	1.017	0.857		1.171	0.857		0.908	0.710		0.792	0.393		1.022	0.556												
1.370	0.867	1.217	0.874		1.330	0.876		1.006	0.736		0.845	0.408		0.5	0.440												
1.445	0.873	1.317	0.874		1.415	0.876		1.134	0.762		0.890	0.429		1.5	0.378												
1.506	0.881	1.415	0.876		1.476	0.883		1.232	0.777		0.941	0.465		1.116	0.606												
1.570	0.893	1.495	0.883		1.538	0.897		1.269	0.777		0.989	0.514		1.022	0.556												
1.621	0.902	1.502	0.902		1.538	0.897		1.362	0.765		1.045	0.562		1.166	0.633												
1.729	0.902	1.517	0.902		1.694	0.917		1.452	0.773		1.161	0.633		1.251	0.649												
1.795	0.893	1.584	0.906		1.626	0.909		1.409	0.767		1.345	0.668		1.430	0.686												
1.838	0.898	1.799	0.910		1.799	0.910		1.452	0.773		1.505	0.717		1.591	0.749												
1.890	0.910	1.846	0.916		1.845	0.917		1.510	0.790		1.611	0.802		1.663	0.773												
1.945	0.930	1.914	0.935		1.914	0.935		1.568	0.812		1.715	0.837		1.814	0.867												
2.003	0.952	1.980	0.953		1.980	0.953		1.629	0.830		1.817	0.867		1.914	0.897												
2.064	0.965	2.015	0.963		2.015	0.963		1.707	0.837		1.905	0.867		2.013	0.907												
2.142	0.979	2.054	0.971		2.054	0.971		1.833	0.844		1.955	0.717		2.116	0.749												
2.214	0.989	2.107	0.981		2.107	0.981		1.961	0.861		2.053	0.797		2.174	0.827												
2.275	1.003	2.166	0.988		2.166	0.988		2.135	0.882		2.215	0.807		2.314	0.734												
2.324	1.003	2.204	0.987		2.204	0.987		2.190	0.889		2.281	0.809		2.380	0.735												
2.377	0.987	2.214	0.989		2.214	0.989		2.170	0.916		2.267	0.797		2.367	0.727												
2.458	0.990	2.275	1.000		2.275	1.000		2.186	0.926		2.283	0.807		2.383	0.735												
2.516	0.992	2.357	1.000		2.357	1.000		2.299	0.922		2.396	0.806		2.495	0.734												

* NOT SHOWN IN FIGURE.

TABLE 1-8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE) (CONTINUED)

* NOT SHOWN IN FIGURE.

TABLE I-8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 1-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ
CURVE 47 (CONT.)			
0.56	0.400	12.63	0.891
0.60	0.400	13.00	0.900
0.70	0.492	14.90	0.900
0.87	0.492	15.19	0.891
0.91	0.511	17.29	0.891
0.93	0.512	17.57	0.900
1.00	0.541	25.00	0.899
1.15	0.616		
1.76	0.715		
2.14	0.752		
2.37	0.761		
2.60	0.752		
2.85	0.726		
3.07	0.771		
3.24	0.786		
3.68	0.801		
3.73	0.817		
3.89	0.832		
4.11	0.832		
4.29	0.839		
4.31	0.851		
4.61	0.851		
5.10	0.870		
5.65	0.853		
5.90	0.822		
6.35	0.822		
6.60	0.852		
6.86	0.846		
7.48	0.861		
7.83	0.862		
8.07	0.871		
8.40	0.871		
8.64	0.864		
8.99	0.871		
9.57	0.871		
9.87	0.882		
10.37	0.882		
10.57	0.892		
12.12	0.892		
12.48	0.900		

e. Normal Spectral Reflectance (Temperature Dependence)

There are no experimental data available. The provisional values listed in Table 1-9 and shown in Figure 1-15 are from the relationship discussed in subsection 4.20 and based on Eq. (2.5-5) for highly polished alclad Aluminum Alloy 2024 assuming that aluminum is the cladding material for wavelengths of 2.8, 3.8, 5.0, and 10.6 μm . These values are believed accurate to $\pm 20\%$.

TABLE 1-9. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : REFLECTANCE, ρ)

T	ρ	T	ρ	T	ρ	T	ρ
HIGHLY POLISHED ALCLAD $\lambda = 2.8$		HIGHLY POLISHED ALCLAD $\lambda = 3.6$		HIGHLY POLISHED ALCLAD $\lambda = 5.0$		HIGHLY POLISHED ALCLAD $\lambda = 10.6$	
250.0	0.946	250.0	0.962	250.0	0.970	250.0	0.981
293.0	0.943	293.0	0.959	293.0	0.967	293.0	0.979
300.0	0.943	300.0	0.959	300.0	0.967	300.0	0.979
350.0	0.940	350.0	0.956	350.0	0.964	350.0	0.977
400.0	0.938	400.0	0.954	400.0	0.962	400.0	0.976
450.0	0.937	450.0	0.952	450.0	0.960	450.0	0.974
500.0	0.935	500.0	0.950	500.0	0.959	500.0	0.973
550.0	0.934	550.0	0.948	550.0	0.957	550.0	0.972
600.0	0.933	600.0	0.947	600.0	0.956	600.0	0.971
650.0	0.932	650.0	0.945	650.0	0.954	650.0	0.970
700.0	0.932	700.0	0.944	700.0	0.953	700.0	0.969
750.0	0.931	750.0	0.943	750.0	0.952	750.0	0.968




FIGURE 1-15. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALCLAD ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE).

f. Angular Spectral Reflectance (Wavelength Dependence)

There are 191 sets of experimental data for various surface conditions of Aluminum Alloy 2024. Of these sets 111 are for grooved surfaces by Zipin [T39074] which are included in the report as additional information. The analysis includes two types of Aluminum Alloy 2024, anodized and alodined.

There are seven sets of experimental data for anodized Aluminum Alloy 2024 and four sets of experimental data for alodined Aluminum Alloy 2024, both with the angle of incidence equal to 15° . For the alodined Aluminum Alloy 2024, there is one set of experimental data available for an incidence angle of 45° .

(1) Anodized Aluminum Alloy 2024

The experimental data sets are shown in Figure 1-17 and listed in Table 1-12. The provisional values for temperature 293 K are given in Table 1-10 and shown in Figure 1-16 and are considered accurate to within $\pm 15\%$ over the entire wavelength range at 293 K. These values show the absorption peaks near wavelengths 0.8, 2.9, 6.0, 9.9, and $11.0 \mu\text{m}$ and these values are considerably lower than those for polished alclad Aluminum Alloy 2024 and alodined Aluminum Alloy 2024 for wavelengths above $5.5 \mu\text{m}$. These provisional values apply only to the surface conditions cited in references, see Section 4.1c.

(2) Alodined Aluminum Alloy 2024

The experimental data sets are shown in Figure 1-19 and listed in Table 1-12 for an incidence angle of 15° . The provisional values at 293 K, shown in Figure 1-18 and listed in Table 1-10 are primarily from the investigations of Grimm and Fannin [A00001]. These are considered accurate to within $\pm 15\%$ over the entire wavelength range. These values show absorption peaks near wavelengths 3.1 and $4.8 \mu\text{m}$. The experimental data set is shown in Figure 1-21 and listed in Table 1-12 for an incidence angle of 45° . The provisional values of angular spectral reflectance from the investigation of Grimm and Fannin [A00001] are accurate to within $\pm 20\%$ over the entire reported wavelength range. These values also show absorption peaks near wavelengths 3.1 and $4.8 \mu\text{m}$. The provisional values apply only to the surface conditions cited in references, see Section 4.1c.

TABLE 1-10. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)




FIGURE 1-16. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)




FIGURE 117. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-18. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-19. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-20. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-21. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).

TABLE 1-11. MEASUREMENT INFORMATION ON THE ANGULAP SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, X	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T36486	Aronson, J.R. and McLinden, H.G.	1964	20.0-39.0	8.5 ± 1	Aluminum Alloy 2024	Samples were 0.02 meter disks of a few mm thickness; measurement made by Perkin-Elmer Model 201-C spectrometer while temperature measured by carbon composition resistor; reflectance measured relative to Aluminum 2024 at room temperature; smooth values extracted from figure; $\theta = 45^\circ$, reported error ± 5%.
2 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 3	Specimen was 15/16" x 1" with symmetric V-grooves cut into one 15/16" x 1" face; grooved surfaces made for this study with ruling machine of type used by Bausch and Lomb, Inc.; specifications of grooved profiles and angle as reported by manufacturer. Valley to valley distance (w), 50 μm ; peak to valley height (h), 25.4 μm , and angle between faces, 89°g; source used is G.E. 30A/T20/4 tungsten ribbon strip lamp enclosed in H ₂ O cooled shield, monochromator used was Perkin-Elmer Model 93, detectors used were RCA 1P28 photomultiplier tube for visible (0.2-0.7 μ) and Perkin-Elmer lead sulfide photoconducting cell for near infrared (0.4-2.8 μ); incident beam and viewing path was perpendicular to groove; angle θ said to be negative if measured in same direction from normal as θ ; θ' uncertainty ± 1°; reference was standard mirror; specimen appeared "bright and shiny" to eye; measured temperature specified as room temperature, 293 K assigned; $\theta = 75^\circ$, $\theta' = -15.25^\circ$, reported error ± 0.05%.
3 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 3	The above specimen except $\theta = 15^\circ$, $\theta' = -74.5^\circ$.
4 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 3	The above specimen except $\theta = 75^\circ$, $\theta' = -15.5^\circ$.
5 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 4	Similar to the above specimen except w = 25 μm , h = 12.7 μm , the angle of the V-groove is 89°g.
6 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 4	The above specimen except $\theta = 15^\circ$, $\theta' = -74.5^\circ$.
7 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	Similar to the above specimen except w = 16.67 μm , h = 2.19 μm , the angle of the V-groove is 150°30', incident and observation angle as specified, different wavelengths; $\theta = 45^\circ$.
8 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta = 38^\circ$.
9 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 7	Similar to the above specimen except w = 83.33 μm , h = 24.4 μm , the angle of the V-groove is 119°15', $\theta = 75^\circ$, $\theta' = 15^\circ$.
10 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta = 60^\circ$, $\theta' = 0^\circ$.
11 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta = 45^\circ$, $\theta' = 13^\circ$.
12 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta = 30^\circ$, $\theta' = 27^\circ$.
13 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta = 15^\circ$, $\theta' = 74.5^\circ$.
14 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta = 42.5^\circ$.

TABLE 1-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K.	Name and Designation	Composition (weight percent), Specifications, and Remarks
15 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta=75^\circ$, $\theta'=14.5^\circ$.	
16 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta=45^\circ$, $\theta'=14^\circ$.	
17 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta=15^\circ$, $\theta'=74^\circ$.	
18 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 7	The above specimen except $\theta=42^\circ$.	
19 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 8	Similar to the above specimen except $w=41.67 \mu\text{m}$, $h=12.2 \mu\text{m}$, the angle of the V-groove is $119^\circ 20'$; $\theta=75^\circ$, $\theta'=15^\circ$.	
20 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=60^\circ$, $\theta'=0^\circ$.	
21 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=45^\circ$, $\theta'=14^\circ$.	
22 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=30^\circ$, $\theta'=28^\circ$.	
23 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=15^\circ$, $\theta'=74.5^\circ$.	
24 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=45^\circ$.	
25 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=75^\circ$, $\theta'=14.5^\circ$.	
26 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=45^\circ$, $\theta'=15.5^\circ$.	
27 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=15^\circ$, $\theta'=73^\circ$.	
28 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 8	The above specimen except $\theta=42^\circ$.	
29 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 9	Similar to the above specimen except $w=16.67 \mu\text{m}$, $h=4.9 \mu\text{m}$, the angle of the V-groove is $119^\circ 56'$; $\theta=60^\circ$, $\theta'=0.5^\circ$.	
30 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 9	The above specimen except $\theta=45^\circ$, $\theta'=16.5^\circ$.	
31 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 9	The above specimen except $\theta=30^\circ$, $\theta'=32.5^\circ$.	
32 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 9	The above specimen except $\theta=15^\circ$, $\theta'=72.5^\circ$.	
33 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 9	The above specimen except $\theta=49.5^\circ$.	
34 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 11	Similar to the above specimen except $w=200 \mu\text{m}$, $h=26.5 \mu\text{m}$, the angle of the V- groove is $150^\circ 16'$; $\theta=75^\circ$, $\theta'=45^\circ$.	

TABLE 1-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
35 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 11	The above specimen except $\theta=60^\circ$, $\theta'=60^\circ$.
36 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 11	The above specimen except $\theta=30^\circ$.
37 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 11	The above specimen except $\theta=45^\circ$, $\theta'=74.5^\circ$.
38 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 11	The above specimen except $\theta=15^\circ$.
39 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 11	The above specimen except $\theta=30^\circ$, $\theta'=60^\circ$.
40 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 11	The above specimen except $\theta=15^\circ$, $\theta'=45^\circ$.
41 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 12	Similar to the above specimen except $w=100 \mu\text{m}$, $h=15.25 \mu\text{m}$, the angle of the V-groove is $150^\circ 17'$; $\theta=75^\circ$, $\theta'=45^\circ$.
42 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 12	The above specimen except $\theta=60^\circ$, $\theta'=60^\circ$.
43 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 12	The above specimen except $\theta=30^\circ$.
44 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 12	The above specimen except $\theta=45^\circ$, $\theta'=74.5^\circ$.
45 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 12	The above specimen except $\theta=15^\circ$.
46 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 12	The above specimen except $\theta=30^\circ$, $\theta'=60^\circ$.
47 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 12	The above specimen except $\theta=15^\circ$, $\theta'=45^\circ$.
48 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	Similar to the above specimen except $w=41.67 \mu\text{m}$, $h=5.48 \mu\text{m}$, the angle of the V-groove is $150^\circ 29'$; $\theta=44^\circ$.
49 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta=75^\circ$, $\theta'=45.75^\circ$.
50 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta=60^\circ$, $\theta'=60^\circ$.
51 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta=31^\circ$.
52 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta=45^\circ$, $\theta'=75^\circ$.
53 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta=16^\circ$.
54 T39074	Zipin, R.B.	1965	0.5,1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta=30^\circ$, $\theta'=60^\circ$.

TABLE I-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
55 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 15^\circ$, $\theta = 45^\circ$.
56 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 75^\circ$, $\theta = 59^\circ$.
57 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 55^\circ$.
58 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 52^\circ$.
59 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 48.5^\circ$.
60 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 45.5^\circ$.
61 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 42.5^\circ$.
62 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 38.5^\circ$.
63 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 37.5^\circ$.
64 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 34.5^\circ$.
65 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 60^\circ$, $\theta = 64.5^\circ$.
66 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 56.5^\circ$.
67 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 53^\circ$.
68 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 50^\circ$.
69 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 46.5^\circ$.
70 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 41^\circ$.
71 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 35.5^\circ$.
72 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 33^\circ$.
73 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 30.5^\circ$.
74 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 13	The above specimen except $\theta = 28.5^\circ$.

TABLE I-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Designation of Specimen	Composition (weight percent), Specifications, and Remarks
75 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	Similar to the above specimen except $w = 16.67 \mu\text{m}$, $h = 2.19 \mu\text{m}$, the angle of the V-groove is $150^\circ 30'$; $\theta' = 23.5^\circ$.
76 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 66.5^\circ$.
77 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 62.5^\circ$.
78 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 58.5^\circ$.
79 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 55.5^\circ$.
80 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 53.5^\circ$.
81 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 50.5^\circ$.
82 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 43^\circ$.
83 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 38.5^\circ$.
84 T39074	Zipin, R.B.	1965	0.5, 1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 36^\circ$.
85 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 32.5^\circ$.
86 T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 30.5^\circ$.
87 T39074	Zipin, P.E.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 28.25^\circ$.
88 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 15^\circ$, $\theta' = 60.5^\circ$.
89 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 51.25^\circ$.
90 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 43.5^\circ$.
91 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 36.5^\circ$.
92 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 30^\circ$, $\theta' = 73.5^\circ$.
93 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 59.5^\circ$.
94 T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 50^\circ$.

TABLE I-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
95	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 30^\circ$.
96	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 24^\circ$.
97	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 45^\circ$, $\theta' = 75^\circ$.
98	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 63^\circ$.
99	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 52.5^\circ$.
100	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 38^\circ$.
101	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 31^\circ$.
102	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 25.8^\circ$.
103	T35074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 20^\circ$.
104	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 14.5^\circ$.
105	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 9^\circ$.
106	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 30^\circ$, $\theta' = 68.5^\circ$.
107	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 59^\circ$.
108	T35074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 51^\circ$.
109	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 42.5^\circ$.
110	T39074	Zipin, R.B.	1965	1.5	293	Aluminum Alloy 2024T-4, Sample 14	The above specimen except $\theta' = 15^\circ$, $\theta' = 52^\circ$.
111	T35074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 5	Similar to the above specimen except $w = 10 \mu\text{m}$, $h = 5 \mu\text{m}$, the angle of the V-groove is 90° ; grooves made by burnishing with weighted diamond; specimen did not appear "bright and shining" to eye; $\theta' = 75^\circ$, $\theta' = -20^\circ$, reported error $\pm 0.5\%$.
112	T39074	Zipin, R.B.	1965	0.5	293	Aluminum Alloy 2024T-4, Sample 5	The above specimen except $\theta' = 15^\circ$, $\theta' = -74.5^\circ$.
113	T43493	Bevans, J.T. Brown, G.L. Luedke, E.E. W.D., Nelson, K.E., and Russell, D.A.	1962	0.25-2.0	303	Sample materials prepared by Anadite Corp., South Gate, Calif.; sample discs were 19 mm in diameter; soft sulfuric acid anodize; 30 μm thick irradiation treatment; source used was GE B-H6 Mercury Arc Lamp at level of 5.5×10^3 Watt/meter ² . spectral reflectances measured with either integrating sphere reflectometer or Beckman DK-2A modified reflectometer; data extracted from smooth curve; temperature not monitored for each sample, range 294-311, average temperature of 303 used; $\theta' = 15^\circ$, $w = 2\mu$.	

TABLE I-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s) Name	Year of Measurement	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
114 T43493	Bevans, J.T., Brown, G.L., Luedke, E.E., Mills, W.D., Nelson, K.F., and Russell, D.A.	1962	0.25-2.0	303		Similar to the above specimen except measurements made after exposure period of 96 hr at pressure of 10^{-6} Torr.
115 T43493	Bevans, J.T., et al.	1962	0.25-2.0	303		Specimen 2, 22 cm discs, 0.16 to 0.32 cm thick; sample surface prepared by standard metallographic techniques, average horizontal peak to peak distance is 30 μm, groove depth (average displacement from mean surface line) is 0.40 μm, integrating sphere used with PbS detector; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta=20^\circ$, $\omega^2=2\pi$.
116 T29563	Eberhart, R.C.	1960	1.2, 1.8	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=30^\circ$.
117 T29563	Eberhart, R.C.	1960	1.2, 1.8	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=40^\circ$.
118 T29563	Eberhart, R.C.	1960	1.2, 1.8	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=50^\circ$.
119 T29563	Eberhart, R.C.	1960	1.2, 1.8	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=60^\circ$.
120 T29563	Eberhart, R.C.	1960	1.2, 1.8	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=70^\circ$.
121 T29563	Eberhart, R.C.	1960	1.2, 1.8	293	Aluminum 24ST, Polished	Similar to the above specimen except data extracted from smooth curve; $\theta=15^\circ$.
122 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=20^\circ$.
123 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=25^\circ$.
124 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=30^\circ$.
125 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=35^\circ$.
126 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=40^\circ$.
127 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=45^\circ$.
128 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=50^\circ$.
129 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=55^\circ$.

TABLE 1-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
131	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=60^\circ$.
132	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=65^\circ$.
133	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Similar to the above specimen except $\theta=70^\circ$.
134	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except average horizontal peak to peak distance, 7 μm , groove depth, 3.28 μm ; sample surface prepared with sandpaper; data extracted from smooth curve; $\theta=15^\circ$.
135	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=20^\circ$.
136	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=25^\circ$.
137	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=30^\circ$.
138	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=35^\circ$.
139	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=40^\circ$.
140	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=45^\circ$.
141	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=50^\circ$.
142	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=55^\circ$.
143	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=60^\circ$.
144	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=65^\circ$.
145	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=70^\circ$.
146	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=75^\circ$.
147	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 1	Similar to the above specimen except $\theta=80^\circ$.
148	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except average horizontal peak to peak distance, 10 μm , groove depth, 4.52 μm ; sample surface prepared with sandpaper; $\theta=15^\circ$.
149	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=20^\circ$.
150	T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=25^\circ$.

TABLE I-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
151 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=30^\circ$.
152 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=35^\circ$.
153 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=40^\circ$.
154 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=45^\circ$.
155 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=50^\circ$.
156 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=55^\circ$.
157 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=60^\circ$.
158 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=65^\circ$.
159 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=70^\circ$.
160 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=75^\circ$.
161 T29563		Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Grade 2	Similar to the above specimen except $\theta=80^\circ$.
162 T19294		Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Polished; Beckman DK2 spectrometer integrating sphere used for measurement; MgO reference standard; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta=20^\circ$, $\omega=35^\circ$.
163 T19294		Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=30^\circ$.
164 T19294		Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=40^\circ$.
165 T19294		Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=50^\circ$.
166 T19294		Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=60^\circ$.
167 T19294		Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=70^\circ$.
168 T19294		Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Roughened sample; surface roughened with sandpaper, scratches parallel; coarse structure - peak to peak depth 6.35 μm , spacing, 34 μm , fine structure - peak to peak depth, 1 μm ; Beckman DK2 spectrometer integrating sphere used for mea- surement; MgO reference standard; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta=20^\circ$, $\omega=2\pi$.

TABLE I-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
159 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=30^\circ$.
170 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=40^\circ$.
171 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=50^\circ$.
172 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=60^\circ$.
173 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=70^\circ$.
174 T19294	Rolling, R.E. and Seban, R.A.	1960	1.2	293	Aluminum 24ST	Similar to the above specimen except $\theta=80^\circ$.
175 A00001	Grimm, F.C. and Fannin, E.R.	1972	2-14.7	293	2024-T61 Alclad, Sample No. A-1	Specimen brush-alodined; sample thickness 101.6×10^{-3} cm; samples prepared by Organic Chemistry Laboratory of Dept. 256; measurements made with a Dunn Associates ellipsoidal mirror reflectometer; measurement temperature specified as ambient temperature, 203 K assigned; data extracted from smooth curve; relative reflectance reported, multiplied by 0.95 to convert to absolute (gold reference standard used); $\theta=15^\circ$, $\omega=2\pi$; chromate conversion coating.
176 A00001	Grimm, F.C. and Fannin, E.R.	1972	2-14.7	293	2024-T781 Alclad, Sample No. A-1	The above specimen; reported values different from the values of above specimen for unknown reason.
177 A00001	Grimm, F.C. and Fannin, E.R.	1972	2-14.7	293	2024-T781 Alclad, Sample No. A-1	The above specimen except $\theta=45^\circ$.
178 A00001	Grimm, F.C. and Fannin, E.R.	1972	2-14.7	293	2024-T781 Alclad, Sample No. A-1	The above specimen; reported values different from the values of above specimen for unknown reason; $\theta=15^\circ$.
179 A00001	Grimm, F.C. and Fannin, E.R.	1972	2-14.7	293	2024-T781 Alclad, Sample No. A-1	The above specimen except sample heat treated by heating to 644 K for 1 hr in air.
180 A00001	Grimm, F.C. and Fannin, E.R.	1972	2-14.7	293	2024-T781 Alclad, Sample No. B-1	Polished; sample thickness 99×10^{-3} cm; samples prepared by Organic Chemistry Laboratory of Dept. 256; measurements made with a Dunn Associates ellipsoidal mirror reflectometer; measurement temperature specified as ambient temperature, 293 K assigned; data extracted from smooth curve; relative reflectance reported, multiplied by 0.95 to convert to absolute (gold reference standard used); $\theta=15^\circ$, $\omega=2\pi$.
181 A00001	Grimm, F.C. and Fannin, E.R.	1972	2.8-10.6	293	2024-T781 Alclad, Sample No. B-1	The above specimen; reported values different from the values of above specimen for unknown reason; data extracted from table.
182 A00001	Grimm, F.C. and Fannin, E.R.	1972	2.8-10.6	293	2024-T781 Alclad, Sample No. B-1	The above specimen except $\theta=45^\circ$.
183 A00001	Grimm, F.C. and Fannin, E.R.	1972	2.8-10.6	293	2024-T781 Alclad, Sample No. B-1	The above specimen; reported values different from the values of above specimen for unknown reason; data extracted from table; $\theta=15^\circ$.
184 A00001	Grimm, F.C. and Fannin, E.R.	1972	2.8-10.6	293	2024-T781 Alclad, Sample No. B-1	The above specimen except sample heat treated by heating to 644 K for 1 hr in air.

TABLE I-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence) (continued)

Cur. Ref. No. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
185 A00001	Clemm, F. C. and Farnin, E. R.	1972	2-14.7	293	2024-T851 Al, Sample No. C-1	Anodized with sulfuric acid; sample thickness = 0.254 cm; samples prepared by Organic Chemistry Laboratory of Dept. 256; measurements made with a Dunn Associat ellipsoidal mirror reflectometer; measurement temperature specified as ambient temperature, 293 K assigned; data extracted from smooth curve; relative reflectance reported multiplied by 0.95 to convert to absolute (gold reference standard used); $\theta=15^\circ$, $\omega=27^\circ$.
186 A00001	Grimm, F. C. and Farnin, E. R.	1972	2.8-10.6	293	2024-T851 Al, Sample No. C-1	The above specimen; reported values different from the values of above specimen for unknown reason.
187 A00001	Grimm, F. C. and Farnin, E. R.	1972	2.8-10.6	293	2024-T851 Al, Sample No. C-1	The above specimen except $\theta=45^\circ$.
188 A00001	Grimm, F. C. and Farnin, E. R.	1972	2.8-10.6	293	2024-T851 Al, Sample No. C-1	The above specimen; reported values different from the values of above specimen for unknown reason; data extracted from table; $\theta=15^\circ$.
189 A00001	Grimm, F. C. and Farnin, E. R.	1972	2.8-10.6	293	2024-T851 Al, Sample No. C-1	The above specimen except sample heat treated by heating to 644 K for 1 hr in air.
190 T73502	Bowman, B. L., Jack, J. H., and Spies, E. W.	1973	0.35-2.0	293	2024 T4 Aluminum	Highly polished surface; measurements made in air with Gier-Dinkle magnesium oxide coated integrating sphere reflectometer; data extracted from smooth curve; measured temperature specified as room temperature, 293 K assigned; $\theta=15^\circ$, $\omega^0=27^\circ$.
191 T73502	Bowman, B. L., et al.	1973	0.35-1.1	293	2024 T4 Aluminum	Similar to the above specimen except surface had diffuse finish provided by glass- bead blasting the surface.

TABLE I-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)

(WAVELENGTH, $\lambda \cdot \mu\text{m}$; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 1* $T = 8.5$		CURVE 6* $T = 293.$		CURVE 14* $T = 293.$		CURVE 22* $T = 293.$		CURVE 30* $T = 293.$		CURVE 37 (CONT.)* $T = 293.$		1.5	0.295		
20.0	0.857	0.5	0.166	0.5	0.061	0.5	0.124	0.5	0.039						
20.9	0.866	CURVE 7* $T = 293.$		CURVE 15* $T = 293.$		1.5	0.088			CURVE 38* $T = 293.$					
22.8	0.908					CURVE 23* $T = 293.$		CURVE 31* $T = 293.$		0.5	0.455				
23.7	0.934					1.5	0.437	0.5	0.0781	1.5	0.53				
24.9	0.962					CURVE 24* $T = 293.$		CURVE 32* $T = 293.$		0.5	0.380				
25.8	0.962	1.5	0.28	1.5	0.437	0.5	0.16	0.5	0.0995	1.5	0.380				
27.4	0.947	CURVE 8* $T = 293.$		CURVE 16* $T = 293.$		CURVE 25* $T = 293.$		CURVE 33* $T = 293.$		0.5	0.405				
29.8	0.967					1.5	0.0676	0.5	0.0449	1.5	0.675				
33.0	0.967	CURVE 9* $T = 293.$		CURVE 17* $T = 293.$		CURVE 26* $T = 293.$		CURVE 34* $T = 293.$		0.5	0.41*				
36.0	0.955					1.5	0.136	1.5	0.254	1.5	0.675				
40.0	0.960	1.5	0.081	1.5	0.0676	1.5	0.054	0.5	0.024	1.5	0.448				
50.8	0.945	CURVE 2* $T = 293.$		CURVE 10* $T = 293.$		CURVE 18* $T = 293.$		CURVE 27* $T = 293.$		0.5	0.576				
62.1	0.965					1.5	0.056	1.5	0.0411	1.5	0.675				
99.0	0.970	CURVE 3* $T = 293.$		0.5	0.915	1.5	0.056	1.5	0.0411	1.5	0.675				
				1.5	0.75	CURVE 19* $T = 293.$		CURVE 28* $T = 293.$		0.5	0.164				
						0.5	0.355	0.5	0.078	1.5	0.13				
						CURVE 11* $T = 293.$		CURVE 29* $T = 293.$		0.5	0.530				
						CURVE 12* $T = 293.$		0.5	0.47	1.5	0.335				
								CURVE 30* $T = 293.$		0.5	0.565				
								1.5	0.46	1.5	0.625				
								CURVE 31* $T = 293.$		0.5	0.485				
										0.5	0.315				

* NOT SHOWN IN FIGURE.

TABLE I-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm : TEMPERATURE, T , $^{\circ}\text{K}$: REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 44* $T = 293.$		CURVE 51* $T = 293.$		CURVE 59* $T = 293.$		CURVE 67* $T = 293.$		CURVE 75* $T = 293.$		CURVE 83* $T = 293.$	
0.5 0.280 1.5 0.211	0.5 0.55	1.5 0.510	1.5 0.035	1.5 0.025	1.5 0.025	1.5 0.025	1.5 0.025	1.5 0.025	1.5 0.025	1.5 0.0271	1.5 0.0271
CURVE 45* $T = 293.$		CURVE 52* $T = 293.$		CURVE 60* $T = 293.$		CURVE 68* $T = 293.$		CURVE 76* $T = 293.$		CURVE 84* $T = 293.$	
0.5 0.615 1.5 0.505	0.5 0.235	1.5 0.648	1.5 0.020	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.043	1.5 0.043
CURVE 46* $T = 293.$		CURVE 53* $T = 293.$		CURVE 61* $T = 293.$		CURVE 69* $T = 293.$		CURVE 77* $T = 293.$		CURVE 85* $T = 293.$	
0.5 0.465 1.5 0.308 1.5 0.312	0.5 0.465	1.5 0.376	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.015	1.5 0.31	1.5 0.31
CURVE 47* $T = 293.$		CURVE 54* $T = 293.$		CURVE 62* $T = 293.$		CURVE 70* $T = 293.$		CURVE 78* $T = 293.$		CURVE 86* $T = 293.$	
0.5 0.325 1.5 0.357	0.5 0.305	1.5 0.0475	1.5 0.020	1.5 0.010	1.5 0.010	1.5 0.010	1.5 0.010	1.5 0.010	1.5 0.010	1.5 0.466	1.5 0.466
CURVE 48* $T = 293.$		CURVE 55* $T = 293.$		CURVE 63* $T = 293.$		CURVE 71* $T = 293.$		CURVE 79* $T = 293.$		CURVE 87* $T = 293.$	
1.5 0.49* $T = 293.$		CURVE 56* $T = 293.$		CURVE 64* $T = 293.$		CURVE 72* $T = 293.$		CURVE 80* $T = 293.$		CURVE 88* $T = 293.$	
0.5 0.738 1.5 0.06	1.5 0.645	1.5 0.0250	1.5 0.054	1.5 0.0303	1.5 0.0303	1.5 0.0303	1.5 0.0303	1.5 0.0303	1.5 0.0303	1.5 0.342	1.5 0.342
CURVE 50* $T = 293.$		CURVE 57* $T = 293.$		CURVE 65* $T = 293.$		CURVE 73* $T = 293.$		CURVE 81* $T = 293.$		CURVE 89* $T = 293.$	
0.5 0.69 1.5 0.06	1.5 0.0782	1.5 0.040	1.5 0.442	1.5 0.1189	1.5 0.1189	1.5 0.1189	1.5 0.1189	1.5 0.1189	1.5 0.1189	1.5 0.567	1.5 0.567
CURVE 51* $T = 293.$		CURVE 58* $T = 293.$		CURVE 66* $T = 293.$		CURVE 74* $T = 293.$		CURVE 82* $T = 293.$		CURVE 90* $T = 293.$	
1.5 0.216 1.5 0.06	1.5 0.050	1.5 0.171	1.5 0.013	1.5 0.045	1.5 0.045	1.5 0.045	1.5 0.045	1.5 0.045	1.5 0.045	1.5 0.569	1.5 0.569

* NOT SHOWN IN FIGURE.

TABLE I-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE) (CONTINUED)

	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 91* $T = 293.$			CURVE 99* $T = 293.$		CURVE 107* $T = 293.$		CURVE 113 (CONT.)		CURVE 114 (CONT.)		CURVE 117* $T = 293.$	
1.5 0.246	1.5 0.0267	1.5 0.179	1.5 0.0267	1.5 0.457	1.5 0.455	1.5 0.455	1.5 0.742	1.5 0.742	1.5 0.742	1.5 0.742	1.5 0.742	1.5 0.742
CURVE 92* $T = 293.$	CURVE 100* $T = 293.$	CURVE 108* $T = 293.$	CURVE 108* $T = 293.$	0.460 0.484	0.460 0.484	0.460 0.484	1.745 1.752	1.745 1.752	1.745 1.752	1.745 1.752	1.745 1.752	1.745 1.752
1.5 0.0875	1.5 0.0223	1.5 0.036	1.5 0.036	0.497 0.505	0.497 0.505	0.497 0.505	1.803 1.810	1.803 1.810	1.803 1.810	1.803 1.810	1.803 1.810	1.803 1.810
CURVE 93* $T = 293.$	CURVE 101* $T = 293.$	CURVE 109* $T = 293.$	CURVE 109* $T = 293.$	0.567 0.514	0.567 0.514	0.567 0.514	1.888 1.895	1.888 1.895	1.888 1.895	1.888 1.895	1.888 1.895	1.888 1.895
1.5 0.0944	1.5 0.032	1.5 0.020	1.5 0.020	0.620 0.517	0.620 0.517	0.620 0.517	1.995 1.998	1.995 1.998	1.995 1.998	1.995 1.998	1.995 1.998	1.995 1.998
CURVE 94* $T = 293.$	CURVE 102* $T = 293.$	CURVE 110* $T = 293.$	CURVE 110* $T = 293.$	0.690 0.513	0.690 0.513	0.690 0.513	2.098 2.101	2.098 2.101	2.098 2.101	2.098 2.101	2.098 2.101	2.098 2.101
1.5 0.0660	1.5 0.0167	1.5 0.030	1.5 0.030	0.751 0.506	0.751 0.506	0.751 0.506	2.183 2.186	2.183 2.186	2.183 2.186	2.183 2.186	2.183 2.186	2.183 2.186
CURVE 95* $T = 293.$	CURVE 103* $T = 293.$	CURVE 111* $T = 293.$	CURVE 111* $T = 293.$	0.816 0.519	0.816 0.519	0.816 0.519	2.278 2.281	2.278 2.281	2.278 2.281	2.278 2.281	2.278 2.281	2.278 2.281
1.5 0.479	1.5 0.217	0.5 0.0346	0.5 0.0346	0.879 0.561	0.879 0.561	0.879 0.561	2.373 2.376	2.373 2.376	2.373 2.376	2.373 2.376	2.373 2.376	2.373 2.376
CURVE 96* $T = 293.$	CURVE 104* $T = 293.$	CURVE 112* $T = 293.$	CURVE 112* $T = 293.$	0.946 0.614	0.946 0.614	0.946 0.614	2.468 2.471	2.468 2.471	2.468 2.471	2.468 2.471	2.468 2.471	2.468 2.471
1.5 0.119	1.5 0.345	0.5 0.0089	0.5 0.0089	0.346 0.454	0.346 0.454	0.346 0.454	2.563 2.566	2.563 2.566	2.563 2.566	2.563 2.566	2.563 2.566	2.563 2.566
CURVE 97* $T = 293.$	CURVE 105* $T = 293.$	CURVE 113 $T = 303.$	CURVE 113 $T = 303.$	0.527 0.539	0.527 0.539	0.527 0.539	2.658 2.661	2.658 2.661	2.658 2.661	2.658 2.661	2.658 2.661	2.658 2.661
1.5 0.097	1.5 0.116	0.249 0.223	0.249 0.223	0.619 0.539	0.619 0.539	0.619 0.539	2.753 2.756	2.753 2.756	2.753 2.756	2.753 2.756	2.753 2.756	2.753 2.756
CURVE 98* $T = 293.$	CURVE 106* $T = 293.$	0.272 0.232	0.272 0.232	0.787 0.520	0.787 0.520	0.787 0.520	2.848 2.851	2.848 2.851	2.848 2.851	2.848 2.851	2.848 2.851	2.848 2.851
1.5 0.053	1.5 0.0203	0.294 0.246	0.294 0.246	0.853 0.543	0.853 0.543	0.853 0.543	2.943 2.946	2.943 2.946	2.943 2.946	2.943 2.946	2.943 2.946	2.943 2.946
		0.307 0.271	0.307 0.271	1.035 0.650	1.035 0.650	1.035 0.650	3.038 3.041	3.038 3.041	3.038 3.041	3.038 3.041	3.038 3.041	3.038 3.041
		0.322 0.313	0.322 0.313	1.091 0.670	1.091 0.670	1.091 0.670	3.133 3.136	3.133 3.136	3.133 3.136	3.133 3.136	3.133 3.136	3.133 3.136
		0.342 0.366	0.342 0.366	1.273 0.705	1.273 0.705	1.273 0.705	3.228 3.231	3.228 3.231	3.228 3.231	3.228 3.231	3.228 3.231	3.228 3.231
		0.349 0.392	0.349 0.392	1.402 0.710	1.402 0.710	1.402 0.710	3.323 3.326	3.323 3.326	3.323 3.326	3.323 3.326	3.323 3.326	3.323 3.326
		0.356 0.419	0.356 0.419	1.492 0.732	1.492 0.732	1.492 0.732	3.418 3.421	3.418 3.421	3.418 3.421	3.418 3.421	3.418 3.421	3.418 3.421
		0.377 0.437	0.377 0.437	1.570 0.742	1.570 0.742	1.570 0.742	3.513 3.516	3.513 3.516	3.513 3.516	3.513 3.516	3.513 3.516	3.513 3.516

* NOT SHOWN IN FIGURE.

TABLE I-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, $\lambda \cdot \mu\text{m}$; TEMPERATURE, T ; K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ								
CURVE 124* $T = 293.$		CURVE 132* $T = 293.$		CURVE 140* $T = 293.$		CURVE 156* $T = 293.$		CURVE 164* $T = 293.$			
1.02 0.871	1.02 0.630	1.02 0.633	1.02 0.612	1.02 0.617	1.02 0.617	1.02 0.515	1.02 0.748	1.02 0.716	1.02 0.699		
CURVE 125* $T = 293.$		CURVE 135* $T = 293.$		CURVE 141* $T = 293.$		CURVE 149* $T = 293.$		CURVE 157* $T = 293.$		CURVE 165* $T = 293.$	
1.02 0.843	1.02 0.591			1.02 0.614		1.02 0.617		1.02 0.515		1.02 0.748	
CURVE 126* $T = 293.$		CURVE 134* $T = 293.$		CURVE 142* $T = 293.$		CURVE 150* $T = 293.$		CURVE 158* $T = 293.$		CURVE 166* $T = 293.$	
1.02 0.753	1.02 0.687	1.02 0.602	1.02 0.617	1.02 0.617	1.02 0.518	1.02 0.518	1.02 0.716	1.02 0.699	1.02 0.699		
CURVE 127* $T = 293.$		CURVE 135* $T = 293.$		CURVE 143* $T = 293.$		CURVE 151* $T = 293.$		CURVE 159* $T = 293.$		CURVE 167* $T = 293.$	
1.02 0.575	1.02 0.693	1.02 0.600	1.02 0.613	1.02 0.613	1.02 0.519	1.02 0.519	1.02 0.699	1.02 0.699	1.02 0.699		
CURVE 128* $T = 293.$		CURVE 136* $T = 293.$		CURVE 144* $T = 293.$		CURVE 152* $T = 293.$		CURVE 160* $T = 293.$		CURVE 168* $T = 293.$	
1.02 0.524	1.02 0.694	1.02 0.604	1.02 0.604	1.02 0.604	1.02 0.520	1.02 0.520	1.02 0.699	1.02 0.699	1.02 0.699		
CURVE 129* $T = 293.$		CURVE 137* $T = 293.$		CURVE 145* $T = 293.$		CURVE 153* $T = 293.$		CURVE 161* $T = 293.$		CURVE 169* $T = 293.$	
1.02 0.526	1.02 0.692	1.02 0.607	1.02 0.584	1.02 0.584	1.02 0.515	1.02 0.515	1.02 0.699	1.02 0.699	1.02 0.699		
CURVE 130* $T = 293.$		CURVE 138* $T = 293.$		CURVE 146* $T = 293.$		CURVE 154* $T = 293.$		CURVE 162* $T = 293.$		CURVE 170* $T = 293.$	
1.02 0.591	1.02 0.681	1.02 0.609	1.02 0.561	1.02 0.561	1.02 0.637	1.02 0.637	1.02 0.698	1.02 0.698	1.02 0.698		
CURVE 131* $T = 293.$		CURVE 139* $T = 293.$		CURVE 147* $T = 293.$		CURVE 155* $T = 293.$		CURVE 163* $T = 293.$		CURVE 171* $T = 293.$	
1.02 0.642	1.02 0.660	1.02 0.600	1.02 0.521	1.02 0.521	1.02 0.619	1.02 0.619					

* NOT SHOWN IN FIGURE.

TABLE I-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE) (CONTINUED)

	λ	ρ		λ	ρ		λ	ρ		λ	ρ		λ	ρ	
CURVE 172* $T = 293.$															
1.2	0.595		3.81	0.521		12.84	0.878		4.49	0.575		4.98	0.689		
3.96	0.532		3.96	0.532		13.09	0.888		4.61	0.582		5.92	0.715		
4.03	0.549		4.03	0.549		13.39	0.886		4.61	0.571		5.12	0.724		
CURVE 173* $T = 293.$															
4.17	0.554		4.17	0.554		13.74	0.892		4.65	0.564		5.53	0.748		
4.29	0.580		4.29	0.580		14.09	0.892		4.70	0.581		5.76	0.756		
4.63	0.592		4.63	0.592		14.72	0.905		4.74	0.469		2.16	0.614		
1.2	0.603		4.49	0.600		4.49	0.600		4.89	0.589		2.16	0.609		
4.61	0.607		4.61	0.607		4.66	0.606		5.04	0.606		2.22	0.691		
4.66	0.608		4.66	0.608		4.71	0.608		5.41	0.642		2.26	0.648		
CURVE 174* $T = 293.$															
4.66	0.565		4.66	0.565		4.67	0.567		5.61	0.657		2.32	0.636		
4.80	0.534		4.80	0.534		4.80	0.534		5.81	0.662		2.37	0.689		
1.2	0.601		4.82	0.558		4.89	0.410		6.03	0.656		2.39	0.635		
4.99	0.629		4.99	0.629		5.15	0.511		6.20	0.668		2.41	0.619		
5.18	0.654		5.18	0.654		5.20	0.436		6.46	0.697		2.44	0.634		
5.31	0.667		5.31	0.667		5.24	0.470		6.58	0.706		2.47	0.610		
5.52	0.675		5.52	0.675		5.28	0.465		6.72	0.707		2.51	0.625		
5.68	0.689		5.68	0.689		5.31	0.441		6.84	0.697		2.54	0.615		
5.95	0.700		5.95	0.700		5.38	0.495		7.00	0.702		2.57	0.633		
6.12	0.700		6.12	0.700		5.40	0.444		7.11	0.710		2.61	0.616		
6.25	0.707		6.25	0.707		5.44	0.460		7.39	0.720		2.64	0.610		
6.31	0.718		6.31	0.718		5.51	0.468		7.62	0.739		2.72	0.593		
6.61	0.739		6.61	0.739		5.55	0.493		7.89	0.765		2.74	0.551		
6.81	0.739		6.81	0.739		5.60	0.468		8.00	0.822		2.81	0.455		
7.08	0.755		7.08	0.755		5.67	0.488		8.51	0.780		2.82	0.362		
7.23	0.755		7.23	0.755		5.74	0.473		9.07	0.803		2.86	0.386		
7.38	0.766		7.38	0.766		5.74	0.405		9.48	0.817		3.09	0.375		
7.51	0.766		7.51	0.766		5.79	0.366		9.80	0.822		3.23	0.398		
8.26	0.815		8.26	0.815		8.83	0.356		9.96	0.820		3.31	0.418		
8.44	0.815		8.44	0.815		8.86	0.317		10.05	0.825		3.61	0.552		
8.75	0.824		8.75	0.824		9.00	0.294		11.17	0.836		3.74	0.585		
9.97	0.824		9.97	0.824		9.11	0.294		11.72	0.847		3.81	0.609		
9.20	0.833		9.20	0.833		9.21	0.311		12.14	0.867		4.05	0.636		
9.43	0.833		9.43	0.833		9.37	0.347		12.48	0.877		4.22	0.662		
10.20	0.852		10.20	0.852		10.37	0.379		13.08	0.879		4.39	0.669		
10.47	0.848		10.47	0.848		10.48	0.395		13.53	0.876		4.49	0.685		
10.72	0.856		10.72	0.856		10.56	0.455		13.81	0.882		4.57	0.698		
11.22	0.858		11.22	0.858		11.76	0.486		14.05	0.896		4.64	0.693		
11.55	0.865		11.55	0.865		12.84	0.501		14.39	0.912		4.78	0.642		
12.07	0.870		12.07	0.870		12.97	0.522		14.67	0.915		4.78	0.578		
12.53	0.875		12.53	0.875		14.03	0.522		14.76	0.563		4.87	0.652		
CURVE 177 $T = 293.$															
4.49	0.575		4.61	0.582		4.61	0.571		5.04	0.606		5.04	0.707		
4.61	0.571		4.61	0.571		4.65	0.567		5.11	0.619		5.12	0.724		
4.65	0.564		4.65	0.564		4.69	0.557		5.19	0.633		5.23	0.748		
4.70	0.581		4.70	0.581		4.74	0.547		5.24	0.645		5.31	0.760		
4.74	0.589		4.74	0.589		4.78	0.537		5.31	0.654		5.41	0.776		
4.89	0.609		4.89	0.609		4.93	0.527		5.37	0.662		5.51	0.790		
5.04	0.606		5.04	0.606		5.08	0.517		5.43	0.671		5.63	0.804		
5.11	0.619		5.11	0.619		5.16	0.507		5.53	0.680		5.73	0.828		
5.19	0.634		5.19	0.634		5.24	0.497		5.63	0.690		5.83	0.852		
5.24	0.645		5.24	0.645		5.29	0.487		5.93	0.700		6.13	0.876		
5.31	0.657		5.31	0.657		5.36	0.477		6.23	0.710		6.43	0.898		
5.37	0.668		5.37	0.668		5.42	0.467		6.53	0.720		6.73	0.922		
5.41	0.678		5.41	0.678		5.46	0.457		6.83	0.730		7.03	0.946		
5.53	0.689		5.53	0.689		5.58	0.447		7.13	0.740		7.33	0.960		
5.63	0.698		5.63	0.698		5.68	0.437		7.43	0.750		7.63	0.974		
5.76	0.706		5.76	0.706		5.81	0.427		7.73	0.760		7.93	0.988		
5.89	0.715		5.89	0.715		5.94	0.417		8.03	0.770		8.23	0.998		
6.01	0.724		6.01	0.724		6.06	0.407		8.33	0.780		8.53	1.012		
6.19	0.734		6.19	0.734		6.24	0.397		8.63	0.790		8.83	1.026		
6.39	0.748		6.39	0.748		6.46	0.387		8.93	0.800		9.13	1.040		
6.59	0.762		6.59	0.762		6.66	0.377		9.23	0.810		9.43	1.054		
6.80	0.776		6.80	0.776		6.87	0.367		9.53	0.820		9.73	1.068		
6.98	0.788		6.98	0.788		7.05	0.357		9.83	0.830		10.03	1.082		
7.16	0.798		7.16	0.798		7.23	0.347		10.13	0.840		10.33	1.096		
7.35	0.812		7.35	0.812		7.42	0.337		10.43	0.850		10.63	1.110		
7.53	0.824		7.53	0.824		7.60	0.327		10.73	0.860		10.93	1.124		
7.70	0.836		7.70	0.836		7.77	0.317		11.03	0.870		11.23	1.138		
7.88	0.847		7.88	0.847		7.95	0.307		11.33	0.880		11.53	1.152		
8.05	0.858		8.05	0.858		8.12	0.297		11.63	0.890		11.83	1.166		
8.23	0.868		8.23	0.868		8.30	0.287		11.93	0.900		12.13	1.180		
8.41	0.878		8.41	0.878		8.48	0.277		12.23	0.910		12.43	1.194		
8.60	0.888		8.60	0.888		8.67	0.267		12.53	0.920		12.73	1.208		
8.80	0.898		8.80	0.898		8.87	0.257		12.83	0.930		13.03	1.222		
9.00	0.908		9.00	0.908		9.07	0.247		13.13	0.940		13.33	1.236		
9.20	0.918		9.20	0.918		9.27	0.237		13.43	0.950		13.63	1.250		
9.40	0.928		9.40	0.928		9.47	0.227		13.73	0.960		13.93	1.264		
9.60	0.938		9.60	0.938		9.67	0.217		14.03	0.970		14.23	1.278		
9.80	0.948		9.80	0.948		9.97	0.207		14.33	0.980		14.53	1.292		
10.00	0.958		10.00	0.958		10.17	0.197		14.63	0.990		14.83	1.306		
10.20	0.968		10.20	0.968		10.37	0.187		14.93	1.000		15.13	1.320		
10.40	0.978		10.40	0.978		10.57	0.177		15.23	1.010		15.43	1.334		
10.60	0.988		10.60	0.988		10.77	0.167		15.53	1.020		15.73	1.348		
10.80	0.998</td														

TABLE 1-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	
CURVE 178 (CONT.)																						
2.28	0.386	6.60	0.629	2.54	0.428	6.32	0.717	3.00	0.940	2.6	0.49	6.67	0.630	2.58	0.443	6.98	0.736	3.08	0.958	2.6	0.49	
2.33	0.374	6.69	0.636	2.58	0.443	6.98	0.736	3.08	0.958	2.6	0.49	6.71	0.631	2.63	0.418	9.23	0.739	3.26	0.947	3.6	0.68	
2.38	0.390	6.67	0.636	2.63	0.418	2.71	0.446	9.34	0.746	3.33	0.964	6.74	0.632	2.68	0.438	9.63	0.747	3.55	0.952	5.8	0.71	
2.40	0.370	7.08	0.631	2.71	0.446	2.83	0.422	9.63	0.747	3.55	0.952	6.77	0.634	2.89	0.422	9.75	0.750	3.63	0.978	10.6	0.84	
2.44	0.405	7.32	0.636	2.83	0.438	7.49	0.664	2.92	0.422	10.02	0.750	3.97	0.962	7.86	0.661	2.92	0.433	10.13	0.750	4.97	0.975	
2.47	0.392	7.49	0.646	2.89	0.422	8.06	0.664	2.92	0.433	10.02	0.750	4.97	0.962	8.15	0.679	2.98	0.433	10.13	0.754	4.975	0.975	
2.52	0.404	7.49	0.646	2.92	0.422	8.54	0.703	3.01	0.440	10.39	0.754	5.19	0.968	8.64	0.703	3.07	0.440	10.61	0.760	5.28	0.979	
2.56	0.369	8.15	0.679	2.98	0.433	9.54	0.703	3.07	0.440	10.61	0.760	5.28	0.979	9.54	0.730	3.25	0.461	11.34	0.771	5.6	0.98	
2.65	0.412	8.54	0.703	3.01	0.440	10.39	0.754	3.08	0.440	10.61	0.760	5.37	0.979	10.39	0.754	3.08	0.440	10.81	0.771	5.8	0.98	
2.72	0.412	8.64	0.703	3.07	0.440	10.61	0.760	3.08	0.440	10.81	0.771	5.37	0.979	10.61	0.760	3.08	0.440	11.34	0.771	5.8	0.98	
2.77	0.351	9.35	0.730	3.25	0.461	9.50	0.730	3.49	0.500	11.98	0.771	4.49	0.968	9.50	0.730	3.49	0.500	11.98	0.771	5.6	0.96	
2.83	0.323	9.50	0.730	3.49	0.500	9.63	0.726	3.62	0.513	12.45	0.779	4.59	0.975	9.63	0.726	3.62	0.513	12.45	0.779	5.6	0.96	
2.87	0.275	9.63	0.726	9.71	0.734	9.76	0.527	12.68	0.789	4.71	0.976	10.6	0.976	9.71	0.734	9.76	0.527	12.68	0.789	5.6	0.96	
2.92	0.266	9.84	0.742	9.84	0.742	9.85	0.527	13.14	0.791	4.87	0.970	10.81	0.970	9.85	0.742	9.85	0.527	13.14	0.791	5.6	0.96	
2.96	0.266	9.84	0.742	10.10	0.746	9.98	0.538	13.76	0.804	5.05	0.980	11.76	0.980	9.98	0.742	10.10	0.746	9.98	0.804	5.05	0.980	
3.04	0.240	10.52	0.746	10.52	0.746	10.54	0.541	14.17	0.808	6.00	0.980	14.17	0.980	10.54	0.746	10.54	0.541	14.17	0.808	6.00	0.980	
3.21	0.262	11.00	0.762	11.00	0.762	11.00	0.558	14.53	0.808	6.99	0.984	14.53	0.984	11.00	0.762	11.00	0.558	14.53	0.808	6.99	0.984	
3.42	0.302	11.29	0.765	11.29	0.765	11.29	0.560	14.63	0.805	7.63	0.984	14.63	0.984	11.29	0.765	11.29	0.560	14.63	0.805	7.63	0.984	
3.50	0.324	11.58	0.764	11.58	0.764	11.58	0.562	14.67	0.808	7.95	0.984	14.67	0.984	11.58	0.764	11.58	0.562	14.67	0.808	7.95	0.984	
3.66	0.375	11.78	0.771	11.78	0.771	11.78	0.564	14.71	0.808	8.24	0.994	14.71	0.994	11.78	0.771	11.78	0.564	14.71	0.808	8.24	0.994	
3.82	0.416	12.43	0.776	12.43	0.776	12.43	0.619	15.13	0.808	8.41	0.997	15.13	0.997	12.43	0.776	12.43	0.619	15.13	0.808	8.41	0.997	
3.99	0.438	12.74	0.795	13.35	0.795	5.73	0.641	2.00	0.920	8.88	0.991	5.73	0.641	2.00	0.920	9.02	0.991	9.02	0.991	8.88	0.991	
4.23	0.455	13.35	0.795	13.84	0.798	6.05	0.650	2.06	0.918	9.62	0.988	6.05	0.650	2.06	0.918	9.81	0.993	9.81	0.993	9.62	0.988	
4.33	0.481	14.58	0.811	14.85	0.811	14.85	0.653	2.10	0.963	10.00	0.989	14.85	0.811	14.85	0.653	2.10	0.963	10.00	0.989	10.00	0.989	
4.42	0.478	14.76	0.811	14.85	0.811	14.85	0.655	2.17	0.974	10.00	0.989	14.85	0.811	14.85	0.655	2.17	0.974	10.00	0.989	10.00	0.989	
4.53	0.496	14.76	0.811	14.76	0.811	14.76	0.655	2.17	0.974	10.00	0.989	14.76	0.811	14.76	0.655	2.17	0.974	10.00	0.989	10.00	0.989	
4.64	0.501	14.58	0.800	14.58	0.800	14.58	0.655	2.17	0.974	10.00	0.989	14.58	0.800	14.58	0.655	2.17	0.974	10.00	0.989	10.00	0.989	
4.70	0.493	14.85	0.807	14.85	0.807	14.85	0.657	2.28	0.882	12.00	0.988	14.85	0.807	14.85	0.657	2.28	0.882	12.00	0.988	12.00	0.988	
4.82	0.407	14.93	0.807	14.93	0.807	14.93	0.660	2.30	0.957	14.67	0.992	14.67	0.957	14.67	0.660	2.30	0.957	14.67	0.992	14.67	0.992	
4.88	0.463	14.93	0.807	14.93	0.807	14.93	0.660	2.34	0.996	14.67	0.992	14.67	0.996	14.67	0.660	2.34	0.996	14.67	0.992	14.67	0.992	
4.93	0.479	14.93	0.807	14.93	0.807	14.93	0.660	2.36	0.915	14.67	0.992	14.67	0.992	14.67	0.660	2.36	0.915	14.67	0.992	14.67	0.992	
4.98	0.516	2.07	0.459	3.0	0.53	5.0	0.62	2.43	0.931	2.09	0.723	2.09	0.931	2.09	0.53	2.43	0.931	2.09	0.723	2.09	0.931	
5.11	0.534	2.15	0.411	2.19	0.387	10.6	0.76	2.47	0.968	2.14	0.619	2.14	0.968	2.14	0.76	2.47	0.968	2.14	0.619	2.14	0.968	
5.42	0.554	2.19	0.427	7.33	0.609	2.28	0.76	2.51	0.952	2.14	0.619	2.14	0.952	2.14	0.76	2.51	0.952	2.14	0.619	2.14	0.952	
5.57	0.571	2.28	0.427	7.33	0.609	2.28	0.76	2.51	0.952	2.14	0.619	2.14	0.952	2.14	0.76	2.51	0.952	2.14	0.619	2.14	0.952	
5.94	0.584	2.36	0.396	7.39	0.695	2.66	0.928	2.6	0.57	5.0	0.671	5.0	0.928	5.0	0.695	2.6	0.57	5.0	0.671	5.0	0.928	
6.88	0.584	2.48	0.413	7.56	0.696	2.70	0.945	2.70	0.704	7.70	0.704	7.70	0.945	7.70	0.696	2.70	0.704	7.70	0.704	7.70	0.945	
6.19	0.595	2.45	0.406	7.70	0.704	2.63	0.707	8.12	0.424	2.63	0.707	8.12	0.707	2.63	0.707	8.12	0.424	2.63	0.707	8.12	0.707	
6.39	0.597	2.49	0.424	7.70	0.707	2.63	0.707	8.12	0.424	2.63	0.707	8.12	0.707	2.63	0.707	8.12	0.424	2.63	0.707	8.12	0.707	

* NOT SHOWN IN FIGURE.

TABLE 1-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE. T, K; REFLECTANCE, P)

λ	ρ	λ	ρ	CURVE 185 (CONT.)			CURVE 186			CURVE 187*			CURVE 190 (CONT.)		
			$T = 293.$			$T = 293.$			$T = 293.$			$T = 293.$			
2.61	0.666	6.25	0.548												
2.75	0.299	6.35	0.577	2.6	0.14		0.974	0.643							
2.85	0.191	6.50	0.602	3.6	0.43		1.043	0.869							
2.90	0.211	6.61	0.607	5.0	0.48		1.097	0.883							
2.97	0.196	6.73	0.594	10.6	0.02		1.183	0.896							
3.03	0.247	6.83	0.598				1.279	0.907							
3.08	0.240	7.03	0.566				1.429	0.919							
3.20	0.268	7.15	0.519				1.547	0.919							
3.24	0.315	7.44	0.332				1.979	0.924							
3.24	0.338	7.91	0.152	2.6	0.22										
3.31	0.340	8.34	0.063	3.6	0.51										
3.31	0.357	8.58	0.056	5.0	0.58										
3.39	0.365	8.71	0.044	10.6	0.03										
3.58	0.509	8.83	0.046												
3.64	0.517	9.07	0.062												
3.67	0.552	9.34	0.098												
3.79	0.563	9.45	0.115												
3.87	0.554	9.69	0.136	2.6	0.14										
3.97	0.554	9.82	0.146	3.6	0.43										
4.07	0.541	10.02	0.135	5.0	0.48										
4.07	0.549	10.44	0.057	16.6	0.02										
4.18	0.554	10.68	0.037												
4.28	0.561	10.87	0.026												
4.28	0.566	11.00	0.026												
4.35	0.585	11.12	0.039												
4.46	0.592	11.28	0.049	2.6	0.26										
4.52	0.603	11.74	0.049	3.6	0.43										
4.71	0.613	12.06	0.069	5.0	0.49										
4.76	0.612	12.53	0.069	10.6	0.02										
4.81	0.616	13.07	0.061												
4.93	0.616	13.35	0.077												
5.08	0.620	13.50	0.077												
5.25	0.607	13.69	0.066												
5.53	0.599	13.86	0.091												
5.59	0.591	14.24	0.091	0.102											
5.71	0.582														
5.78	0.567														
5.86	0.540														
6.03	0.511														
6.22	0.535														

* NOT SHOWN IN FIGURE.

g. Angular Spectral Reflectance (Incident Angle Dependence)

Room temperature values of the angular spectral reflectance for wavelengths $1.2 \mu\text{m}$ and $1.8 \mu\text{m}$ as a function of incidence angle are listed in Table 1-14 and shown in Figure 1-22.




FIGURE 1-22. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024
(INCIDENT ANGLE DEPENDENCE).

TABLE I-13. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 2024 (Incident Angle Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T29563	Eberhart, R.C.	1960	1.2	293	Aluminum 24ST, Polished	Specimen 2.22 cm discs, 0.16 to 0.32 cm thick; sample surface prepared by standard metallographic techniques, average horizontal peak to peak distance is 30 μm , groove depth (average displacement from mean surface line) is 0.40 μm ; integrating sphere used with PHS detector; reference standard MgO; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta = 20^\circ$, $\omega' = 2\pi$.	
2 T29563	Eberhart, R.C.	1960	1.8	293	Aluminum 24ST, Polished	Similar to the above specimen	
3 T19294	Follans, R.E. and Seban, H.A.	1960	1.2	293	Aluminum 24ST	Polished; Beckman DK2 spectrometer integrating sphere used for measurement; MgO reference standard; ω' extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta = 0^\circ$ to 70° , $\omega' = 2\pi$.	
4 T19294	Rolling, R.E. and Seban, H.A.	1960	1.2	293	Aluminum 24ST	Roughened sample; surface roughened with sandpaper, scratches parallel; coarse structure - peak to peak depth 6.35 μm , spacing, 34 μm , fine structure - peak to peak depth, 1 μm ; Beckman DK2 spectrometer integrating sphere used for measurement; MgO reference standard; data extracted from figure; measurement temperature not given explicitly, 293 K assigned; $\theta = 0^\circ$ to 80° , $\omega' = 2\pi$.	

TABLE I-14. EXPERIMENTAL ANGULAR SPECTRAL REFLECTION OF ALUMINUM ALLOY 2024 (INCIDENT ANGLE DEPENDENCE)
ANGLE, θ , DEGREE; TEMPERATURE, T ; κ : REFLECTANCE, ρ)

θ	ρ	θ	ρ	θ	ρ
CURVE 1 $T = 293.$					
0.	0.794	30.	0.699	60.	0.656
10.	0.822	40.	0.699	70.	0.595
20.	0.837	50.	0.699	80.	0.603
30.	0.820	60.	0.699		
40.	0.690				
50.	0.662				
60.	0.719				
70.	0.693				
CURVE 2 $T = 293.$					
0.	0.882				
10.	0.914				
20.	0.929				
30.	0.910				
40.	0.741				
50.	0.731				
60.	0.524				
70.	0.771				
CURVE 3 $T = 293.$					
0.	0.794				
10.	0.824				
20.	0.937				
30.	0.821				
40.	0.782				
50.	0.748				
60.	0.716				
70.	0.691				
CURVE 4 $T = 293.$					
0.	0.661				
10.	0.660				
20.	0.690				

h. Normal Spectral Absorptance (Wavelength Dependence)

There are two sets of experimental data available for the wavelength dependence (2.53–20.0 μm) of the normal spectral absorptance of Aluminum Alloy 2024 for polished surface conditions. These are listed in Table 1-17 and shown in Figure 1-24.

(1) Highly Polished Aluminum Alloy 2024

The recommended values at 293 K listed in Table 1-15 and shown in Figure 1-23 for highly polished Aluminum Alloy 2024 were generated from the measurements of Schriempf and Wieting [A00003] and are believed accurate to $\pm 10\%$ over the entire wavelength range.

(2) Highly Polished Alclad Aluminum Alloy 2024

The recommended values at 293 K are listed in Table 1-15 and shown in Figure 1-25 for highly polished alclad Aluminum Alloy 2024. These values were generated with the relationship discussed in Section 4.20, based on Eq. (2.5-5), and are believed accurate to $\pm 10\%$ over the entire wavelength range. The provisional values for highly polished alclad Aluminum Alloy 2024 were calculated for temperatures of 450, 600, and 750 K by the relationship discussed in Section 4.20, based on Eq. (2.5-5), are listed in Table 1-15 and shown in Figure 1-25 and are believed accurate to $\pm 20\%$ over the entire wavelength range.

(3) Oxidized Aluminum Alloy 2024

The provisional values are listed in Table 1-15 and shown in Figure 1-26 for oxidized Aluminum Alloy 2024 at 823 K. These values are consistent with the normal spectral emittance values of Blau, et al. [T16606] and are believed accurate to $\pm 20\%$ over the entire wavelength range.

TABLE 1-15. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	HIGHLY POLISHED ALCLAD $T = 293$	HIGHLY POLISHED ALCLAD $T = 450$	HIGHLY POLISHED ALCLAD $T = 600$	HIGHLY POLISHED ALCLAD $T = 750$	λ	α	HIGHLY POLISHED ALCLAD $T = 823$
2.00	0.0980	2.5	0.067	2.5	0.071A†	2.5	0.073A†	2.5
2.60	0.0760	2.6	0.057	2.6	0.063A	2.6	0.067A	2.6
3.00	0.0697	3.0	0.052	3.0	0.059A	3.0	0.063A	3.0
3.50	0.0575	3.5	0.044	3.5	0.052A	3.5	0.056A	3.5
3.60	0.0524	3.6	0.041	3.6	0.049A	3.6	0.053A	3.6
4.00	0.0498	4.0	0.039	4.0	0.046A	4.0	0.051A	4.0
4.50	0.0444	4.5	0.035	4.5	0.043A	4.5	0.047A	4.5
5.00	0.0402	5.0	0.033	5.0	0.040A	5.0	0.044A	5.0
5.50	0.0375	5.5	0.031	5.5	0.037A	5.5	0.042A	5.5
6.00	0.0355	6.0	0.029	6.0	0.035A	6.0	0.040A	6.0
6.50	0.0336	6.5	0.027	6.5	0.034A	6.5	0.038A	6.5
7.00	0.0323	7.0	0.026	7.0	0.032A	7.0	0.037A	7.0
7.50	0.0310	7.5	0.025	7.5	0.031A	7.5	0.035A	7.5
8.00	0.0298	8.0	0.024	8.0	0.030A	8.0	0.034A	8.0
8.50	0.0287	8.5	0.023	8.5	0.029A	8.5	0.033A	8.5
9.00	0.0276	9.0	0.023	9.0	0.028A	9.0	0.032A	9.0
9.50	0.0272	9.5	0.022	9.5	0.027A	9.5	0.031A	9.5
10.00	0.0270	10.0	0.021	10.0	0.026A	10.0	0.030A	10.0
10.60	0.0262	10.5	0.021	10.5	0.026A	10.5	0.029A	10.5
11.00	0.0258	11.0	0.020	11.0	0.025A	11.0	0.029A	11.0
11.50	0.0254	11.5	0.020	11.5	0.025A	11.5	0.028A	11.5
12.00	0.0250	12.0	0.019	12.0	0.024A	12.0	0.028A	12.0
12.50	0.0246	12.5	0.019	12.5	0.024A	12.5	0.027A	12.5
13.00	0.0242	13.0	0.019	13.0	0.023A	13.0	0.026A	13.0
13.50	0.0239	13.5	0.018	13.5	0.023A	13.5	0.025A	13.5
14.00	0.0235	14.0	0.018	14.0	0.022A	14.0	0.025A	14.0
14.50	0.0232	14.5	0.017	14.5	0.022A	15.0	0.025A	14.5
15.00	0.0228	15.0	0.017	15.0	0.021A	15.0	0.027A	15.0

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL.




FIGURE 1-23. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-24. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024
(WAVELENGTH DEPENDENCE).




FIGURE 1-25. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALCLALO ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-26. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF OXIDIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).

TABLE I-16. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	A00001	Schriempf, J.T. and Wieling, T.J.	1974	2. 53-20.0	293	Aluminum Alloy	Author states specimen was "aluminum alloy very similar to 2024 aluminum"; author describes surface as "high quality"; reflectance was measured using a grating spectrometer; absorbance then calculated from $\alpha = 1 - \rho$; a gold reference mirror was used as a standard; data extracted from figure; measurement temperature specified as room temperature, 293 K assigned; $\theta=0^\circ$, reported error $\pm 0.1\%$. Polished; measurement temperature specified as room temperature, 293 K assigned; $\theta=0^\circ$.
2	A00016	Neighours, J.R., (Editor)	1974	2. 8,10.6	293		

TABLE I-17. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α
CURVE 1	
$T = 293.$	
2.53	0.0650
2.92	0.0717
3.36	0.0609
3.63	0.0551
4.03	0.0505
4.48	0.0439
5.02	0.0391
7.16	0.0329
8.38	0.0290
9.10	0.0266
9.98	0.0269
11.13	0.0265
12.54	0.0246
14.31	0.0229
16.66	0.0198
19.11	0.0195
20.88	0.0167
CURVE 2	
$T = 293.$	
2.0	0.047
10.6	0.033

i. Normal Spectral Absorptance (Temperature Dependence)

There are two sets of experimental data available for the temperature dependence (325-593 K) of the normal spectral absorptance of Aluminum Alloy 2024. These are listed in Table 1-20 and shown in Figure 1-28. This available data was not sufficient to generate recommended values, but values were calculated by the relation discussed in subsection 4.20, based on equation (2.5-5), for highly polished alclad Aluminum Alloy 2024 for wavelengths of 2.8, 3.8, 5.0, and 10.6 μm . These values are believed accurate to $\pm 20\%$ over the entire wavelength range and are listed in Table 1-18 and shown in Figure 1-27.

TABLE 1-18. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

T	α	T	α	T	α	T	α
HIGHLY POLISHED ALCLAD $\lambda = 2.6$	0.054	HIGHLY POLISHED ALCLAD $\lambda = 3.6$	0.038	HIGHLY POLISHED ALCLAD $\lambda = 5.0$	0.030	HIGHLY POLISHED ALCLAD $\lambda = 10.6$	0.019
250.0	0.057	250.0	0.041	250.0	0.033	250.0	0.021
293.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021
300.0	0.057	300.0	0.041	300.0	0.033	300.0	0.021
350.0	0.060	350.0	0.044	350.0	0.036	350.0	0.023
400.0	0.062	400.0	0.046	400.0	0.038	400.0	0.024
450.0	0.063	450.0	0.047	450.0	0.040	450.0	0.026
500.0	0.065	500.0	0.050	500.0	0.041	500.0	0.027
550.0	0.066	550.0	0.052	550.0	0.043	550.0	0.028
600.0	0.067	600.0	0.053	600.0	0.044	600.0	0.029
650.0	0.068	650.0	0.055	650.0	0.046	650.0	0.030
700.0	0.068	700.0	0.056	700.0	0.047	700.0	0.031
750.0	0.069	750.0	0.057	750.0	0.048	750.0	0.032




FIGURE 1-27. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALCLAD ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE).




FIGURE 1-28. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE).

TABLE 1-19. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (Temperature Dependence)

Car. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	E 66194	Cunningham, S. S. and Laughlin, W. T.	1971-1973	10.6	325-453	2024 Alclad Aluminum	Specimen was circular; sample in as-received condition, then washed with methanol; room atm environment; sample irradiated with a 10C watt CO ₂ laser with intensity from 60-165 watts/cm ² ; samples were uniformly heated by entire laser beam; thermocouples were attached to back of sample, one at center and one along perimeter; NSA calculated from temperature rise; author calls absorptance "coupling coefficient"; $\theta=0^\circ$, reported error $\pm 0.3\%$.
2	E 66194	Cunningham, S. S. and Laughlin, W. T.	1971-1973	10.6	328-593	2024 Alclad Aluminum	Specimen was 12.7 x 12.7 cm flat plate; sample in as-received condition, then washed with methanol; room atm environment; sample irradiated with a 5000 watt CO ₂ laser with intensity from 75-3700 watts/cm ² ; beam size varied depending on intensity, but beam was always in center of plate; three thermocouples were attached to sample back, one at center of plate, another along line between opposing corners of plate, and another along line between two other opposing corners; NSA calculated from temperature rise; author calls absorptance "coupling coefficient"; $\theta=0^\circ$, reported error $\pm 0.4\%$.

TABLE I-20. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2024 (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

T	α
CURVE 1	
$\lambda = 10.6$	
324°	0.024
325°	0.022
453°	0.039
CURVE 2	
$\lambda = 10.6$	
328°	0.022
443°	0.025
593°	0.031

j. Angular Spectral Absorptance (Wavelength Dependence)

There are no experimental data available for this subproperty but provisional values are listed in Table 1-21 and shown in Figures 1-29, 1-30, and 1-31 for anodized, alodined ($\theta = 15^\circ$), and alodined ($\theta = 45^\circ$) Aluminum Alloy 2024, respectively. These were calculated from the provisional angular spectral reflectance data listed in Table 1-10 and shown in Figures 1-16, 1-18, and 1-20. The values are believed accurate to $\pm 15\%$ over the entire range for the anodized and alodined ($\theta = 15^\circ$) Aluminum Alloy 2024 materials at 293 K. The alodined ($\theta = 45^\circ$) Aluminum Alloy 2024 provisional values are accurate to $\pm 20\%$. These values apply only to the surface conditions cited in references, see Section 4.1-c.

TABLE 1-21. PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 2C24 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α)

λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α
SULFURIC ACID ANODIZED, $\theta=15^\circ$ $T = 293$	SULFURIC ACID ANODIZED, $\theta=15^\circ$ $T = 293$ (CONT.)	CHROMATE ALODINED, $\theta=15^\circ$ $T = 293$	CHROMATE ALODINED, $\theta=15^\circ$ $T = 293$ (CONT.)	CHROMATE ALODINED, $\theta=45^\circ$ $T = 293$															
0.30	0.740	6.10	0.484	2.34	0.517	12.00	0.142	2.00	0.240	0.740	0.473	2.50	0.531	12.50	0.135	2.20	0.250	0.740	0.473
0.35	0.640	6.20	0.473	2.00	0.604	13.00	0.129	2.40	0.280	0.640	0.410	2.00	0.604	13.50	0.123	2.60	0.350	0.640	0.410
0.40	0.550	6.40	0.410	3.00	0.677	13.50	0.123	2.00	0.280	0.550	0.393	3.00	0.677	14.00	0.116	2.80	0.552	0.550	0.393
0.50	0.482	6.60	0.393	3.05	0.685	14.00	0.116	2.00	0.280	0.482	0.405	3.10	0.685	14.50	0.113	3.00	0.620	0.482	0.405
0.60	0.474	6.80	0.405	3.15	0.686	14.50	0.113	2.00	0.280	0.474	0.426	3.20	0.682	15.00	0.109	3.10	0.610	0.474	0.426
0.70	0.475	7.00	0.426	3.20	0.673	15.00	0.109	2.00	0.280	0.700	0.740	3.25	0.673	15.50	0.105	3.20	0.606	0.700	0.740
0.80	0.461	7.20	0.514	3.30	0.655	15.50	0.105	2.00	0.280	0.800	0.820	3.50	0.589	16.00	0.101	3.30	0.470	0.800	0.820
0.83	0.482	7.40	0.640	3.40	0.640	16.00	0.101	2.00	0.280	0.830	0.882	3.70	0.528	16.50	0.101	3.40	0.400	0.830	0.882
0.90	0.434	7.60	0.740	3.50	0.673	16.50	0.101	2.00	0.280	0.900	0.942	3.80	0.508	17.00	0.101	3.50	0.330	0.900	0.942
1.00	0.380	7.80	0.820	3.80	0.655	17.00	0.101	2.00	0.280	1.000	0.947	4.00	0.480	17.50	0.101	3.80	0.270	1.000	0.947
1.20	0.320	8.00	0.875	3.90	0.655	17.50	0.101	2.00	0.280	1.200	0.940	4.20	0.458	18.00	0.101	3.90	0.210	1.200	0.940
1.40	0.292	8.20	0.918	4.00	0.655	18.00	0.101	2.00	0.280	1.400	0.920	4.50	0.431	18.50	0.101	4.00	0.160	1.400	0.920
1.60	0.274	8.40	0.942	4.10	0.655	18.50	0.101	2.00	0.280	1.600	0.920	4.56	0.426	19.00	0.101	4.10	0.160	1.600	0.920
1.80	0.266	8.60	0.949	4.20	0.655	19.00	0.101	2.00	0.280	1.800	0.920	4.61	0.427	19.50	0.101	4.20	0.160	1.800	0.920
2.00	0.279	8.80	0.947	4.30	0.655	19.50	0.101	2.00	0.280	2.000	0.920	4.70	0.427	20.00	0.101	4.30	0.160	2.000	0.920
2.20	0.301	9.00	0.940	4.40	0.655	20.00	0.101	2.00	0.280	2.200	0.920	4.80	0.427	20.50	0.101	4.40	0.160	2.200	0.920
2.40	0.341	9.20	0.920	4.50	0.655	20.50	0.101	2.00	0.280	2.400	0.920	4.81	0.427	21.00	0.101	4.50	0.160	2.400	0.920
2.60	0.422	9.40	0.893	4.60	0.655	21.00	0.101	2.00	0.280	2.600	0.920	4.87	0.440	21.50	0.101	4.60	0.160	2.600	0.920
2.80	0.779	9.60	0.864	4.70	0.655	21.50	0.101	2.00	0.280	2.800	0.920	4.93	0.458	22.00	0.101	4.70	0.160	2.800	0.920
2.85	0.807	9.80	0.855	4.74	0.655	22.00	0.101	2.00	0.280	2.850	0.920	4.95	0.470	22.50	0.101	4.80	0.160	2.850	0.920
2.90	0.810	10.00	0.869	4.77	0.655	22.50	0.101	2.00	0.280	2.900	0.920	4.97	0.481	23.00	0.101	4.90	0.160	2.900	0.920
2.95	0.808	10.20	0.900	4.81	0.655	23.00	0.101	2.00	0.280	2.950	0.920	4.98	0.482	23.50	0.101	5.00	0.160	2.950	0.920
3.00	0.797	10.40	0.935	4.87	0.655	23.50	0.101	2.00	0.280	3.000	0.920	5.00	0.440	24.00	0.101	5.20	0.280	3.000	0.920
3.20	0.677	10.60	0.960	4.93	0.655	24.00	0.101	2.00	0.280	3.200	0.920	5.05	0.405	24.50	0.101	5.40	0.270	3.200	0.920
3.40	0.592	10.80	0.972	4.95	0.655	24.50	0.101	2.00	0.280	3.400	0.920	5.07	0.397	25.00	0.101	5.60	0.260	3.400	0.920
3.60	0.526	11.00	0.975	5.00	0.655	25.00	0.101	2.00	0.280	3.600	0.920	5.10	0.394	25.50	0.101	5.80	0.252	3.600	0.920
3.80	0.484	11.20	0.963	5.10	0.655	25.50	0.101	2.00	0.280	3.800	0.920	5.15	0.362	26.00	0.101	6.00	0.246	3.800	0.920
4.00	0.454	11.40	0.955	5.20	0.655	26.00	0.101	2.00	0.280	4.000	0.920	5.20	0.334	26.50	0.101	6.20	0.220	4.000	0.920
4.20	0.428	11.60	0.949	5.30	0.655	26.50	0.101	2.00	0.280	4.200	0.920	5.30	0.308	27.00	0.101	6.40	0.200	4.200	0.920
4.40	0.410	11.80	0.943	5.40	0.655	27.00	0.101	2.00	0.280	4.400	0.920	5.40	0.285	27.50	0.101	6.60	0.181	4.400	0.920
4.60	0.396	12.00	0.938	5.50	0.655	27.50	0.101	2.00	0.280	4.600	0.920	5.50	0.263	28.00	0.101	6.80	0.164	4.600	0.920
4.80	0.389	12.50	0.928	5.60	0.655	28.00	0.101	2.00	0.280	4.800	0.920	5.60	0.244	28.50	0.101	7.00	0.160	4.800	0.920
5.00	0.384	13.00	0.920	5.70	0.655	28.50	0.101	2.00	0.280	5.000	0.920	5.70	0.227	29.00	0.101	7.20	0.156	5.000	0.920
5.20	0.382	13.50	0.915	5.80	0.655	29.00	0.101	2.00	0.280	5.200	0.920	5.80	0.208	29.50	0.101	7.40	0.150	5.200	0.920
5.40	0.390	14.00	0.909	5.90	0.655	29.50	0.101	2.00	0.280	5.400	0.920	5.90	0.195	30.00	0.101	7.60	0.127	5.400	0.920
5.60	0.406	14.50	0.905	6.00	0.655	30.00	0.101	2.00	0.280	5.600	0.920	6.00	0.182	30.50	0.101	7.80	0.116	5.600	0.920
5.80	0.442	15.00	0.902	6.00	0.655	30.50	0.101	2.00	0.280	5.800	0.920	6.00	0.167	31.00	0.101	8.00	0.150	5.800	0.920
5.90	0.476	15.50	0.900	6.10	0.655	31.00	0.101	2.00	0.280	5.900	0.920	6.10	0.158	31.50	0.101	8.20	0.136	5.900	0.920
6.00	0.484	16.00	0.900	6.20	0.655	31.50	0.101	2.00	0.280	6.000	0.920	6.20	0.150	32.00	0.101	8.40	0.127	6.000	0.920




FIGURE 1-29. PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF ANODIZED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).




FIGURE 1-30. PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE)




FIGURE 1-31. PROVISIONAL ANGULAR SPECTRAL ABSORBTANCE OF ALODINED ALUMINUM ALLOY 2024 (WAVELENGTH DEPENDENCE).

k. Transmittance

Although it is true that metals and alloys in the form of extremely thin films may be transparent for a wide wavelength range, they are opaque if the thickness is greater than several hundred angstroms.

As an aircraft/spacecraft structural material, this alloy is not used in the form of extremely thin films and therefore is opaque; that is, its transmittance is zero.

4.2. Aluminum Alloy 7075

Aluminum 7075, formerly known as aluminum alloy 75S is a wrought alloy with zinc as the principal alloying element. Its nominal composition (by weight) is: 5.5% Zn, 2.5% Mg, 1.5% Cu, 0.3% Cr, and Al balance [A00005]. Various properties and usage of this alloy is discussed in [T15906] and [A00005].

In the solution-heat treated condition, this alloy is designated as 7075-T6. It is among the highest strength aluminum alloy which is commonly used in the aircraft structural parts. This alloy is also available in clad state.

Some physical and mechanical properties [A00005] of this alloy are as follows:

Liquidus temperature: 911 K

Solidus temperature: 749 K

Density at 293 K: 2.80 g cm^{-3}

Room-temperature tensile (ultimate) strength: 23 kg mm^{-2} (for annealed alloy)
 58 kg mm^{-2} (for 7075-T6)

Brinell hardness number: 60 (for annealed alloy)

(500 kg load, 10 mm ball) 150 (for 7075-T6)

a. Normal Spectral Emittance (Wavelength Dependence)

There are seven sets of experimental data available for the wavelength dependence ($0.3\text{-}27 \mu\text{m}$) of the normal spectral emittance of Aluminum Alloy 7075 under various surface conditions. These are tabulated in Table 2-3 and shown in Figure 2-2.

(1) Aluminum Alloy 7075

The recommended values tabulated in Table 2-1 and shown in Figure 2-1 for Aluminum Alloy 7075 with surface roughness of about $0.0005\text{-}0.0006 \mu\text{m}$ are primarily from the investigations of Schocken [T29202]. These are considered accurate to within $\pm 15\%$ over the entire wavelength range.

(2) Aluminum Alloy 7075-T6

The recommended values tabulated in Table 2-1 and shown in Figure 2-1 for Aluminum Alloy 7075-T6 rolled sheet were calculated from the normal spectral reflectance data (see Section 4.2.c).

TABLE 2-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ
POLISHED ALLOY $T = 323$	0.3	0.260	0.043
0.4	0.165	2.8	0.040
0.5	0.136	3.0	0.030
0.6	0.131	3.8	0.029
0.7	0.156	4.0	0.024
0.8	0.164	5.0	0.023
0.9	0.166	6.0	0.022
1.0	0.120	7.0	0.022
1.2	0.090	8.0	0.021
1.4	0.076	9.0	0.020
1.6	0.075	10.0	0.019
1.8	0.078	10.6	0.018
2.0	0.083	11.0	0.018
2.4	0.088	12.0	0.016
2.8	0.092	13.0	0.016
3.0	0.092	14.0	0.017
3.4	0.099	15.0	0.017
3.6	0.082		
4.0	0.070		
4.5	0.070		
5.0	0.064		
6.0	0.054		
7.0	0.048		
8.0	0.046		
9.0	0.045		
10.0	0.045		
10.6	0.044		
11.0	0.043		
12.0	0.043		
13.0	0.043		
14.0	0.042		
15.0	0.042		




FIGURE 2-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE).




FIGURE 2-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE).

TABLE 2-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (Wavelength Dependence)

Car. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	T29202	Schocken, K.	1963	0.29-3.65	323	Aluminum Alloy 7075 Specimen 1	Nominal composition: 5.6 Zn, 2.5 Mg, 1.6 Cr, 0.3 Cr, Al balance, surface roughness 3.2-4.4 microinches, measurements in nitrogen.
2	T29202	Schocken, K.	1963	0.24-26.9	323	Aluminum Alloy 7075 Specimen 3	Similar to the above specimen except surface roughness is 1.9-2.5 microinches.
3	T29202	Schocken, K.	1963	0.24-1.4	323	Aluminum Alloy 7075 Specimen 4	Similar to the above specimen except surface roughness is 3.2-4.5 microinches.
4	T20470	Weber, D.	1959	7.15-15.00	383	75 ST Aluminum	Specimen flat and smooth; reported error ± 50%.
5	T20470	Weber, D.	1959	7.15-15.05	323	75 ST Aluminum	Similar to the above specimen.

TABLE 2-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)

	λ	ϵ	CURVE 1 $T = 323.$	λ	ϵ	CURVE 2 (CONT.)	λ	ϵ	CURVE 3 (CONT.)	λ	ϵ								
	0.24	0.310	0.88	0.144	0.34	0.240	0.88	0.113	0.40	0.233	0.29	0.280							
	0.29	0.280	0.99	0.113	0.40	0.210	1.19	0.087	0.44	0.185	0.32	0.242							
	0.32	0.242	1.40	0.077	0.49	0.159	1.59	0.075	0.60	0.159	0.40	0.190							
	0.44	0.184	1.78	0.080	0.70	0.175	1.99	0.081	0.90	0.182	0.49	0.157							
	0.54	0.148	2.18	0.031	1.03	0.155	2.37	0.036	1.20	0.163	0.60	0.145							
	0.70	0.159	2.59	0.091	1.40	0.093	3.66	0.093	1.40	0.093	0.79	0.183							
	0.83	0.160	5.09	0.062	7.15	0.058	CURVE 4 $T = 363.$												
	0.99	0.122	6.06	0.038	8.12	0.052	CURVE 4 $T = 363.$												
	1.19	0.097	7.04	0.041	9.10	0.049	CURVE 4 $T = 363.$												
	1.40	0.085	7.60	0.045	10.07	0.046	CURVE 4 $T = 363.$												
	1.60	0.082	8.54	0.045	11.04	0.047	CURVE 4 $T = 363.$												
	1.77	0.084	9.44	0.039	12.01	0.046	CURVE 4 $T = 363.$												
	1.98	0.084	10.26	0.031	13.05	0.057	CURVE 4 $T = 363.$												
	2.16	0.084	10.95	0.043	14.02	0.053	CURVE 4 $T = 363.$												
	2.37	0.091	11.66	0.036	15.00	0.078	CURVE 4 $T = 363.$												
	2.60	0.099	12.27	0.045	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	3.65	0.084	12.90	0.045	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	CURVE 2 $T = 323.$		14.04	0.043	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.24	0.310	14.65	0.053	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.25	0.286	16.19	0.029	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.30	0.255	18.26	0.035	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.32	0.211	19.95	0.031	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.34	0.194	21.71	0.037	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.38	0.168	24.35	0.037	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.46	0.158	26.88	0.061	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$					
	0.50	0.134	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$				CURVE 5 $T = 323.$			
	0.54	0.129	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$				CURVE 5 $T = 323.$			
	0.59	0.129	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$				CURVE 5 $T = 323.$			
	0.60	0.136	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$				CURVE 5 $T = 323.$			
	0.64	0.132	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$				CURVE 5 $T = 323.$			
	0.71	0.149	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$				CURVE 5 $T = 323.$			
	0.79	0.174	CURVE 5 $T = 323.$									CURVE 5 $T = 323.$				CURVE 5 $T = 323.$			

b. Angular Spectral Emittance (Wavelength Dependence)

There are six sets of experimental data available for the wavelength dependence (0.3-15 μm) of the angular spectral emittance of Aluminum Alloy 7075-T6 for an incidence angle, $\theta = 25^\circ$. These values are tabulated in Table 2-6 and shown in Figure 2-4.

The recommended values tabulated in Table 2-4 and shown in Figure 2-3 for Aluminum Alloy 7075-T6 with surface roughness of about 0.0005-0.001 μm and the incident angle, $\theta = 25^\circ$, are primarily from the investigation of Edwards and Catton [T38391]. These values are considered accurate to within $\pm 15\%$ over the entire wavelength range. The angular spectral reflectance values for the similar material, but sandblasted with silicon carbide, are considerably higher than the values reported in Table 2-4. It is worth noting that Edwards and Catton [T38391] consider their values as the normal spectral emittance rather than the angular spectral emittance. Therefore, tabulated values from Table 2-4 may be applicable for the normal spectral emittance.

TABLE 2-4. RECOMMENDED ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T, K; EMITTANCE, ϵ)

λ	ϵ
POLISHED 7075-T6 ALLOY $T = 300$	
0.4	0.170
0.5	0.160
0.6	0.151
0.7	0.149
0.8	0.143
0.9	0.124
1.0	0.102
1.2	0.074
1.4	0.057
1.6	0.047
1.8	0.041
2.0	0.036
2.4	0.035
3.0	0.035
3.4	0.035
4.0	0.035
5.0	0.035
6.0	0.034
7.0	0.034
8.0	0.033
9.0	0.032
10.0	0.031
10.6	0.030
11.0	0.030
12.0	0.030
13.0	0.030
14.0	0.029
15.0	0.029




FIGURE 2-3. RECOMMENDED ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075
(WAVELENGTH DEPENDENCE).




FIGURE 2-4. EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE).

TABLE 2-5. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T32391	Edwards, D.K. and Cotton, L.	1965	0.32-15.0	306	7075-T6	Polished specimen; Rms rough; 2-4 microinches; $\theta=25^\circ$.	
2 T38391	Edwards, D.K. and Cotton, L.	1965	0.34-15.0	306	7075-T6	Similar to the above specimen except sanded; grit mesh number is 150; grit sieve opening is 104 μ ; Rms roughness: 10-15 micro-inches in line, and 70-90 micro-inches across, $\theta=25^\circ$.	
3 T38391	Edwards, D.K. and Cotton, L.	1965	0.46-15.0	306	7075-T6	Similar to the above specimen except grit mesh number is 80; grit sieve opening is 116 μ ; Rms roughness: 20-60 microinches in line and 150-170 microinches across; $\theta=25^\circ$.	
4 T38391	Edwards, D.K. and Cotton, L.	1965	0.41-15.0	306	7075-T6	Similar to the above specimen except grit mesh number is 40; grit sieve opening 42 μ ; Rms roughness: 50-100 microinches in line and 270-300 microinches across; $\theta=25^\circ$.	
5 T36391	Edwards, D.K. and Cotton, L.	1965	0.32-15.0	306	7075-T6	Similar to the specimen in curve 6 except sandblasted with 250 mesh silicon carbide; Rms roughness 10-15 microinches; $\theta=25^\circ$.	
6 T38391	Edwards, D.K. and Cotton, L.	1965	0.32-15.0	306	7075-T6	Similar to the above specimen except sandblasted with 60 mesh Silicon Carbide; Rms roughness 250-300 microinches.	

TABLE 2-6. EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	CURVE 1 $T = 306.$	CURVE 3 $T = 306.$	CURVE 5 $T = 306.$	CURVE 6 (CONT.)	λ	ϵ	CURVE 6 $T = 306.$
0.32	0.22	0.46	0.19	0.32	0.29	0.32	0.29	0.29
0.41	0.16	0.55	0.18	0.41	0.28	0.41	0.28	0.28
0.46	0.16	0.65	0.19	0.55	0.27	0.55	0.27	0.27
0.55	0.15	0.81	0.20	0.64		0.64		
0.64	0.15	0.88	0.19	0.79		0.79		
0.79	0.15	1.0	0.14	1.0		1.0		
0.86	0.14	1.4	0.10	1.4		1.4		
1.0	0.090	1.6	0.093	1.3		1.3		
1.2	0.075	2.0	0.081	2.0		2.0		
1.4	0.056	2.4	0.071	2.4		2.4		
1.6	0.050	3.1	0.082	3.1		3.1		
1.8	0.045	4.0	0.066	4.0		4.0		
2.0	0.038	6.0	0.061	6.0		6.0		
2.4	0.037	10.0	0.052	10.3		10.3		
3.1	0.039	13.0	0.036	13.1		13.1		
4.0	0.035	15.0	0.036	15.0		15.0		
6.0	0.035					17.1	0.12	
10.3	0.030					19.2	0.11	
15.0	0.030					21.1	0.11	
λ	ϵ	CURVE 2 $T = 306.$	CURVE 4 $T = 306.$	CURVE 5 $T = 306.$	CURVE 6 $T = 306.$	λ	ϵ	CURVE 6 $T = 306.$
0.34	0.24	0.41	0.21	0.32	0.60	0.41	0.56	0.60
0.46	0.21	0.61	0.20	0.41	0.56	0.46	0.56	0.56
0.55	0.20	0.83	0.23	0.64	0.55	0.64	0.55	0.55
0.65	0.29	1.0	0.16	0.79	0.55	0.79	0.55	0.55
0.81	0.21	1.2	0.14	1.0	0.51	1.0	0.51	0.51
0.88	0.21	1.4	0.12	1.4	0.46	1.4	0.46	0.46
1.0	0.17	1.6	0.097	1.6	0.45	1.6	0.45	0.45
1.4	0.13	2.0	0.091	2.0	0.44	2.0	0.44	0.44
1.6	0.11	2.4	0.086	2.4	0.41	2.4	0.41	0.41
2.0	0.099	4.0	0.072	4.0	0.39	4.0	0.39	0.39
2.4	0.093	6.0	0.067	6.0	0.38	6.0	0.38	0.38
3.1	0.093	15.0	0.051	15.0	0.31	15.0	0.31	0.31
4.0	0.081							
6.0	0.076							
10.4	0.057							
15.0	0.051							

c. Normal Spectral Reflectance (Wavelength Dependence)

There are no experimental data sets available for Aluminum Alloy 7075, however only one set of experimental data is available for the wavelength dependence (2.8-15.0 μm) of the normal spectral reflectance of Aluminum Alloy 7075-T6 alloy. This is tabulated in Table 2-9 and shown in Figure 2-6.

(1) Aluminum Alloy 7075

The recommended values tabulated in Table 2-7 and shown in Figure 2-5 are for Aluminum Alloy 7075 with surface roughness of about 0.0005-0.0006 μm . These values calculated from the normal spectral emittance data (see Section 4.2.b) are considered accurate to about $\pm 15\%$ over the entire wavelength range.

(2) Aluminum Alloy 7075-T6

The recommended values tabulated in Table 2-7 and shown in Figure 2-5 for Aluminum Alloy 7075-T6 clad sheet are primarily from the investigation of Cunningham [A00027]. These values are considered accurate to within $\pm 15\%$ over the entire temperature range.

TABLE 2-7. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ
AL ALLOY 7075 POLISHED $T = 323$			
0.3	0.740	2.6	0.957
1.4	0.815	3.0	0.960
0.5	0.864	3.6	0.970
0.6	0.869	4.0	0.971
0.7	0.850	5.0	0.976
0.8	0.836	6.0	0.977
0.9	0.852	7.0	0.978
1.0	0.820	8.0	0.979
1.2	0.910	9.0	0.980
1.4	0.922	10.0	0.981
1.6	0.925	10.6	0.982
1.8	0.922	11.0	0.982
2.0	0.917	12.0	0.982
2.4	0.912	13.0	0.982
2.6	0.908	14.0	0.983
3.0	0.908	15.0	0.983
3.4	0.910		
3.6	0.918		
4.0	0.922		
4.5	0.930		
5.0	0.936		
6.0	0.946		
7.0	0.952		
8.0	0.954		
9.0	0.955		
10.0	0.955		
10.6	0.956		
11.0	0.957		
12.0	0.957		
13.0	0.957		
14.0	0.958		
15.0	0.958		




FIGURE 2-5. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE).




FIGURE 2-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY AL-7075
(WAVELENGTH DEPENDENCE).

TABLE 2-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	A00027	Cumingson, G.R.	1975	3-15	293	7075 T6	Rolled sheet.

404

TABLE 2-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ
CURVE 1	
$T = 293$	
3.	0.961
4.	0.969
5.	0.976
6.	0.976
7.	0.980
8.	0.980
9.	0.981
10.	0.982
11.	0.983
12.	0.983
14.	0.983
15.	0.985
16.	0.986
20.	0.986
22.	0.986
24.	0.986

d. Angular Spectral Reflectance (Wavelength Dependence)

There are no experimental data available for this subproperty. The recommended values for Aluminum Alloy 7075-T6 with surface roughness 0.0005-0.001 μm and incidence angle, $\theta=25^\circ$, are calculated from the recommended values of the angular spectral emittance (see Section 4.2.b). These values tabulated in Table 2-10 and shown in Figure 2-7 are considered accurate to within $\pm 15\%$ over the entire wavelength range. As discussed in Section 4.2.b, these values may be applicable for the normal spectral reflectance.

TABLE 2-10. RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ
POLISHED 7075-T6 ALLOY $T = 300$	0.922
0.4	0.922
0.5	0.940
0.6	0.949
0.7	0.951
0.8	0.957
0.9	0.976
1.0	0.992
1.2	0.926
1.4	0.943
1.6	0.953
1.8	0.959
2.0	0.962
2.8	0.965
3.0	0.965
3.8	0.965
4.0	0.965
5.0	0.965
6.0	0.966
7.0	0.966
8.0	0.967
9.0	0.968
10.0	0.969
10.6	0.970
11.0	0.970
12.0	0.970
13.0	0.970
14.0	0.971
15.0	0.971




FIGURE 2-7. RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

There are no experimental data available for this subproperty.

(1) Aluminum Alloy 7075

The recommended values tabulated in Table 2-11 and shown in Figure 2-8 are for Aluminum Alloy 7075 with surface roughness of about 0.0005-0.0006 μm . These values calculated from the recommended values for the normal spectral emittance tabulated in Table 2-1 are considered accurate to about $\pm 15\%$ over the entire wavelength range.

(2) Aluminum Alloy 7075-T6

The recommended values tabulated in Table 2-11 and shown in Figure 2-8 are for Aluminum Alloy 7075-T6 clad sheet. These values calculated from the normal spectral emittance data tabulated in Table 2-1 are considered accurate to about $\pm 15\%$ over the entire wavelength range.

TABLE 2-11. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α)

λ	α	λ	α
POLISHED ALLOY $T = 323$		ROLLED SHEET $T = 293$	
0.3	0.260	2.0	0.043
0.4	0.185	3.0	0.040
0.5	0.136	3.5	0.030
0.6	0.131	4.0	0.029
0.7	0.150	5.0	0.024
0.8	0.164	6.0	0.023
0.9	0.148	7.0	0.022
1.0	0.120	8.0	0.021
1.2	0.090	9.0	0.020
1.4	0.078	10.0	0.019
1.6	0.075	10.6	0.016
1.8	0.078	11.0	0.016
2.0	0.083	12.0	0.018
2.4	0.088	13.0	0.016
2.8	0.092	14.0	0.017
3.0	0.092	15.0	0.017
3.4	0.090		
3.6	0.082		
4.0	0.078		
4.5	0.070		
5.0	0.064		
6.0	0.054		
7.0	0.048		
8.0	0.046		
9.0	0.045		
10.0	0.045		
10.6	0.044		
11.0	0.043		
12.0	0.043		
13.0	0.043		
14.0	0.042		
15.0	0.042		




FIGURE 2-8. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE).

f. Angular Spectral Absorptance (Wavelength Dependence)

There are no experimental data available for this subproperty. The recommended values tabulated in Table 2-12 and shown in Figure 2-9 are for Aluminum Alloy 7075-T6 with surface roughness of about 0.0005-0.001 μm , and incidence angle, $\theta = 25^\circ$. These values calculated from the recommended values tabulated in Table 2-4 are considered accurate to about $\pm 15\%$ over the entire wavelength range. As discussed in Section 4.2.b these values may be applicable for the normal spectral absorptance.

TABLE 2-12. RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α
POLISHED 7075-T6 ALLOY $T = 300$	
0.4	0.178
0.5	0.160
0.6	0.151
0.7	0.149
0.8	0.143
0.9	0.124
1.0	0.102
1.2	0.074
1.4	0.057
1.6	0.047
1.8	0.041
2.0	0.038
2.5	0.035
3.0	0.035
3.5	0.035
4.0	0.035
5.0	0.035
6.0	0.034
7.0	0.034
8.0	0.033
9.0	0.032
10.0	0.031
10.6	0.030
11.0	0.030
12.0	0.030
13.0	0.030
14.0	0.029
15.0	0.029




FIGURE 2-9. RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF ALUMINUM ALLOY 7075 (WAVELENGTH DEPENDENCE).

/

g. Transmittance

Although it is true that metals and alloys in the form of extremely thin films may be transparent for a wide wavelength range, they are opaque if the thickness is greater than several hundred angstroms.

As an aircraft/spaceship structural material, this alloy is not used in the form of extremely thin films and therefore is opaque that is, its transmittance is zero.

4.3. AISI 304 Stainless Steel

The family of steel known as "stainless steel" covers an exceptionally wide range. About 35-40 different combinations of ingredients have been used by various manufacturers. Primarily all stainless steels have a base alloy of Fe and Cr. The nominal composition of s.s. 304 is (18-20%) Cr, (8-12%) Ni, 2% Mn, 1% Si, 0.08% C, and Fe balance. The composition of s.s. 304-L type is essentially the same except the composition of carbon is lowered to 0.03%.

Chromium, when added in excess of 10%, makes alloy heat and corrosion resistance. Other elements are added to obtain special characteristics. The most important of these in the case of stainless steel is nickel which increases its corrosion resistance and workability of the alloy. This addition causes a structural change which is known as austenitic which makes the alloy nonhardenable and nonmagnetic. It is possible to weld AISI 304 stainless in moderate thickness without subsequent heat treatment to restore corrosion resistance, whereas 304-L variety, due to its low carbon content, has lower hazard of carbide precipitation after welding or annealing.

Various properties and uses of this alloy are discussed in detail in [A00005]. Some of the physical properties can be summarized as follows:

Density:	7.9 g cm^{-3}
Melting range:	1670-1727 K
Electrical resistivity: at room temperature	$72 \mu\Omega \text{ cm}$
Modulus of elasticity in tension:	$28 \times 10^6 \text{ psi}$
Modulus of elasticity in torsion:	$12.5 \times 10^6 \text{ psi}$

a. Normal Spectral Emittance (Wavelength Dependence)

There are 31 sets of experimental data available for the wavelength dependence ($0.20-27 \mu\text{m}$) of the normal spectral emittance of AISI 304 Stainless Steel for oxidized and anodized surfaces covering the temperature range from room temperature to 1273 K. These are tabulated in Table 3-3 and shown in Figure 3-2.

(1) Polished AISI 304 Stainless Steel

The recommended values at 293 K tabulated in Table 3-1 and shown in Figure 3-1 are for polished and unoxidized surfaces are primarily from the investigations of Rolling and Funai [T47998, T29202]. These values are considered accurate to within $\pm 15\%$ over the entire wavelength range.

(2) Oxidized AISI 304 Stainless Steel

The typical values at 1273 K tabulated in Table 3-1 and shown in Figure 3-1 are for polished and oxidized surfaces of a sample heated in air for about six hours at 1273 K. These values, primarily from the investigations of Blau, et al. [T16606] are considered accurate to about $\pm 30\%$ over the entire wavelength range.

TABLE 3-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ ; μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ]

† VALUE FOLLOWED BY A "B" IS TYPICAL.




FIGURE 3-1. RECOMMENDED NORMAL SPECTRAL EMMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE).




FIGURE 3-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL.
(WAVELENGTH DEPENDENCE).

TABLE 3-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T16606	Blau, H.H., March, J.B., Martin, W.S., Jasperse, J.R., and Chaffee, E.	1960	2.0-14.0	873		Nominal composition: 18.00-20.00 Cr, 8.00-12.00 Ni; 2.00 max Mn, 1.00 max Si, 0.08 max C, Fe balance; oxidized in air for 3 hr at 873 K; measured in air; $\theta' \sim 0^\circ$.
2 T16606	Blau, H.H., et al.	1960	2.0-14.0	1273		Different sample, same as above specimen, and conditions except oxidized in air for 6 hr at 1273 K.
3 T29402	NASA Technical Note No. D-1523	1963	0.20-27.00	323		Nominal composition: 18.00-20.00 Cr, 8.00-12.00 Ni; 2.00 max Mn, 1.00 max Si, 0.08 max C, Fe balance; surface roughness 0.75 micro-inches (center line avg); measured in nitrogen; computed from $\epsilon = 1 - R(2\pi, 5^\circ)$; author indicated that slight error in transition region of 2.5μ to 6.5μ , deviation around 6μ can be attributed to water vapor absorption, apparent rise at 24 to 27μ due to scattered light; $\theta' \sim 5^\circ$.
4 T76314	Conradry, W.P.	1963	0.3-21.0	1255		Chemical composition furnished by the supplier, 0.08 C, 1.0 Si, 2.0 Mn, 8-11 Ni, 18-20 Cr and Fe balance; disk specimen machined from rod stock obtained from Ducommun Metals and Supply Company; oxide formed by heating in air at 1255 K for 2 hr; stabilized after 30 days at 922 K.
5 T47555	Rolling, R.E. and Funai, A.I.	1967	0.25-18.9	300	1S	Sample 2 \times 8 \times 0.015 in. obtained with type 2B (bright, annealed) surface finish; 18.37 Cr, 8.89 Ni, 1.80 Mn, 0.50 Si, 0.054 C, 0.25 P, 0.007 S, and Ti balance; electropolished and cleaned using the following procedure: Step 1, soak 5 min. in $\text{Na}_4\text{P}_2\text{O}_7$ solution (60 g/liter) at 130 F. Step 2, electropolish for 20 min in a $\text{H}_3\text{PO}_4/\text{H}_2\text{SO}_4$ solution at 80 F. Step 3, rinse with distilled water, Step 4, dip in solution of nitric acid (100 ml per liter) and sodium dichromate (20 g per liter). Step 5, rinse and dry, rms roughness 0.33 μm ; not oxidized surface.
6 T47933	Rolling, R.E. and Funai, A.I.	1967	1.5-12	811	1S-2	Similar to the above specimen, first temperature cycle, time at this temperature 45 min.
7 T47938	Rolling, R.E. and Funai, A.I.	1967	1.5-12	955	1S-2	Similar to the above specimen, first temperature cycle, time at this temperature 35 min.
8 T47938	Rolling, R.E. and Funai, A.I.	1967	1.5-12	807	1S-2	Similar to the above specimen, second temperature cycle, surface appeared to be unoxidized at start of this cycle, time at this temperature 3 hr 15 min.
9 T47938	Rolling, R.E. and Funai, A.I.	1967	1.5-12	946	1S-2	Similar to the above specimen, time at this temperature 3 hr 15 min.
10 T47938	Rolling, R.E. and Funai, A.I.	1967	1.5-12	948	1S-2	Similar to the above specimen, time at this temperature 3 hr 50 min.
11 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	309	2S	Similar to the above specimen except oxidized for 1/2 hr at 600 C in wet hydrogen furnace, average weight gain $2.1 \mu\text{g}/\text{cm}^2$, approximate film thickness $0.015 \mu\text{m}$ based on weight gain data and assumption of uniform film of Fe_3O_4 with average density of $5.2 \text{ g}/\text{cm}^3$; gold color of interference film, test pressure 4×10^{-6} torr.
12 T47995	Rolling, R.E. and Funai, A.I.	1967	1.5-12	310	2S	Similar to the above specimen, first temperature cycle for 2 hr.
13 T47996	Rolling, R.E. and Funai, A.I.	1967	1.5-12	952	2S	Similar to the above specimen, at this temperature for 3 hr 20 min.
14 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	1061	2S	Similar to the above specimen, at this temperature for 6 hr.

TABLE 3-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (Wavelength Dependence) (continued)

Cur. Ref. No. No.	Author(s) Funai, A.I.	Year 1967	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
15 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	1067	25	Similar to the above specimen.
16 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	803	25	Similar to the above specimen except second temperature cycle, at this temperature for 2 hr 10 min, color of oxide film changed from gold to silver-gray.
17 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	940	25	Similar to the above specimen, at this temperature for 35 min.
18 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	300	35	Similar to the above specimen except oxidation temperature at 800 C for 30 min, average weight gain 24.3 $\mu\text{g/cm}^2$, approximate film thickness 0.170 μm , purple color of oxide film, test pressure 2.5×10^{-6} torr.
19 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	807	35	Similar to the above specimen except at this temperature for 2 hr.
20 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	953	35	Similar to the above specimen except at this temperature for 3 hr 15 min.
21 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	1090	35	Similar to the above specimen except at this temperature for 5 hr 30 min, instability of the oxide film observed.
22 T47998	Rolling, R.E. and Funai, A.I.	1967	0.31-18.9	300	45	Similar to the above specimen except oxidation temperature at 1000 C for 30 min, average weight gain 135.7 $\mu\text{g/cm}^2$, approximate film thickness 0.95 μm , dull gray color of oxide film; test pressure 4.5×10^{-6} torr.
23 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	818	45	Similar to the above specimen except first temperature cycle, at this temperature for 1 hr 40 min.
24 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	957	45	Similar to the above specimen except at this temperature for 5 hr.
25 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	811	45	Similar to the above specimen except second temperature cycle, at this temperature for 40 min.
26 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	949	45	Similar to the above specimen.
27 T47998	Rolling, R.E. and Funai, A.I.	1967	0.31-19	360	55	Similar to the above specimen except oxidation temperature at 1000 C for 90 min, average weight gain 200 $\mu\text{g/cm}^2$, approximate film thickness 1.40 μm , dark brownish gray color of oxide film, test pressure 3.5×10^{-6} torr.
28 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	809	55	Similar to the above specimen except first temperature cycle, at this temperature for 3 hr 15 min.
29 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	950	55	Similar to the above specimen except at this temperature for 3 hr 30 min.
30 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	814	55	Similar to the above specimen except second temperature cycle, at this temperature for 30 min.
31 T47998	Rolling, R.E. and Funai, A.I.	1967	1.5-12	952	55	Similar to the above specimen except at this temperature for 45 min.

TABLE 3-3. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T, K; EMISSANCE, ϵ)

λ	ϵ	CURVE 1 $T = 873.$	CURVE 2 $T = 1273.$	CURVE 3 (CONT.)	CURVE 4 (CONT.)	CURVE 4 (CONT.)	CURVE 5 (CONT.)	CURVE 5 (CONT.)	CURVE 7 (CONT.)	λ	ϵ	
2.0	0.370	0.40	0.40	0.435	0.3	0.925	1.3	0.705	5.0	0.157	10.0	0.110
3.0	0.340	0.45	0.45	0.410	0.4	0.936	13.5	0.701	6.0	0.150	12.0	0.095
4.0	0.320	0.51	0.51	0.372	0.5	0.936	14.0	0.719	6.50	0.139		
5.0	0.300	0.54	0.54	0.362	0.6	0.936	14.5	0.730	7.00	0.140		
6.0	0.280	0.59	0.59	0.337	0.6	0.922	15.0	0.732	7.50	0.137		
7.0	0.260	0.70	0.70	0.317	0.7	0.698	15.5	0.732	8.00	0.131		
8.0	0.260	0.81	0.81	0.311	0.9	0.860	16.0	0.743	8.50	0.121		
9.0	0.250	0.90	0.90	0.303	1.0	0.844	16.5	0.756	9.00	0.118		
10.0	0.243	1.00	1.00	0.293	1.1	0.836	17.0	0.801	10.00	0.108		
11.0	0.230	1.19	0.276	0.276	1.2	0.830	17.5	0.776	12.00	0.102		
12.0	0.220	1.40	0.256	0.256	1.3	0.825	18.0	0.737	14.00	0.095		
13.0	0.210	1.60	0.232	0.232	1.4	0.825	18.5	0.725	14.50	0.094		
14.0	0.200	1.79	0.224	0.224	1.5	0.825	19.0	0.782	15.00	0.089		
		1.99	0.207	0.207	1.6	0.826	19.5	0.815	15.50	0.086		
		2.19	0.202	0.202	1.7	0.827	20.0	0.830	16.00	0.095		
		2.40	0.200	0.200	1.8	0.825	20.5	0.810	17.00	0.093		
		2.59	0.221	0.221	1.9	0.823	21.0	0.766	18.00	0.090		
2.0	0.770	2.70	0.216	0.216	2.0	0.817					1.5	0.353
3.0	0.760	3.70	0.210	0.181	3.0	0.786					2.0	0.289
4.0	0.690	5.00	0.180	0.180	3.5	0.772					3.0	0.230
5.0	0.650	6.11	0.180	0.180	4.0	0.764					4.0	0.195
6.0	0.720	7.07	0.157	0.157	4.5	0.756					6.0	0.157
7.0	0.777	7.54	0.144	0.144	5.0	0.745					6.5	0.135
8.0	0.780	8.48	0.133	0.133	5.5	0.745					10.0	0.111
9.0	0.785	9.50	0.129	0.129	5.5	0.741					12.0	0.096
10.0	0.750	10.22	0.125	0.125	6.0	0.735					4.0	0.177
11.0	0.650	10.99	0.119	0.119	6.5	0.732					6.0	0.255
12.0	0.560	11.73	0.113	0.113	7.0	0.731					6.0	0.251
13.0	0.450	12.31	0.115	0.115	7.5	0.730					6.0	0.146
14.0	0.400	12.90	0.118	0.118	8.0	0.730					6.0	0.121
		13.54	0.121	0.121	8.5	0.775					10.0	0.104
		13.98	0.103	0.103	9.0	0.815					12.0	0.084
		16.23	0.091	0.091	9.5	0.851					4.0	1.5
		18.26	0.091	0.091	10.0	0.839					6.0	0.244
0.22	0.659	21.76	0.093	0.093	10.5	0.808					6.0	0.161
0.26	0.621	24.34	0.097	0.097	11.0	0.784					6.0	0.134
0.31	0.537	26.92	0.095	0.095	11.5	0.757					10.0	0.116
0.34	0.428				12.0	0.735					12.0	0.097
0.40	0.451				12.5	0.718					6.0	0.155
											6.0	0.130

TABLE 3-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	CURVE 11 $T = 300.$	CURVE 12 $T = 310.$	CURVE 13 $T = 321.$	CURVE 14 $T = 332.$	CURVE 15 (CONT.)	CURVE 16 $T = 343.$	CURVE 17 $T = 352.$	CURVE 18 (CONT.)	CURVE 19 (CONT.)	CURVE 20 $T = 353.$	CURVE 21 $T = 360.$	CURVE 22 $T = 360.$
0.31	0.816	1.5	0.322	4.0	0.243	1.75	0.650	10.0	0.161	2.50	0.764		
0.40	0.728	2.0	0.269	6.0	0.190	2.00	0.602	12.0	0.132	3.00	0.731		
0.50	0.471	3.0	0.221	10.0	0.157	2.50	0.723			3.50	0.696		
0.56	0.329	4.0	0.187	12.0	0.132	3.00	0.604			4.00	0.666		
0.62	0.311	6.0	0.153			3.50	0.506			4.50	0.641		
0.75	0.314	8.0	0.129			4.00	0.444			5.00	0.625		
0.87	0.342	10.0	0.119			4.50	0.378			5.50	0.612		
0.95	0.351	12.0	0.086			5.00	0.329			6.00	0.605		
1.00	0.349					5.50	0.293			6.50	0.605		
1.12	0.336					6.00	0.262			7.00	0.627		
1.25	0.321					6.50	0.239			7.50	0.677		
1.50	0.284					7.00	0.215			8.00	0.727		
1.75	0.255					7.50	0.199			9.00	0.724		
2.00	0.279					8.00	0.195			9.50	0.716		
2.25	0.282					8.50	0.163			10.00	0.714		
2.50	0.275					9.00	0.130			11.00	0.713		
3.0	0.243					9.50	0.161			12.00	0.712		
3.50	0.217					10.00	0.152			13.00	0.711		
4.00	0.196					10.50	0.147			14.00	0.710		
4.50	0.184					11.00	0.140			15.00	0.709		
5.00	0.179					11.50	0.138			16.00	0.708		
6.00	0.176					12.00	0.134			17.00	0.707		
7.00	0.167					12.50	0.134			18.00	0.706		
7.50	0.163					13.00	0.134			19.00	0.705		
8.00	0.151					13.50	0.134			20.00	0.704		
8.50	0.139					14.00	0.134			21.00	0.703		
9.00	0.129					14.50	0.134			22.00	0.702		
9.50	0.125					15.00	0.127			23.00	0.701		
10.00	0.115					15.50	0.157			24.00	0.700		
12.00	0.109					16.00	0.164			25.00	0.699		
14.00	0.109					16.50	0.179			26.00	0.698		
16.00	0.109					17.00	0.31			27.00	0.697		
16.50	0.114					17.50	0.31			28.00	0.696		
17.00	0.116					18.00	0.31			29.00	0.695		
17.50	0.115					18.50	0.31			30.00	0.694		
18.00	0.112					19.00	0.31			31.00	0.693		
18.50	0.108					19.50	0.31			32.00	0.692		
19.00	0.106					20.00	0.31			33.00	0.691		
19.50	0.106					20.50	0.31			34.00	0.690		
20.00	0.106					21.00	0.31			35.00	0.689		
20.50	0.106					21.50	0.31			36.00	0.688		
21.00	0.106					22.00	0.31			37.00	0.687		
21.50	0.106					22.50	0.31			38.00	0.686		
22.00	0.106					23.00	0.31			39.00	0.685		
22.50	0.106					23.50	0.31			40.00	0.684		
23.00	0.106					24.00	0.31			41.00	0.683		
23.50	0.106					24.50	0.31			42.00	0.682		
24.00	0.106					25.00	0.31			43.00	0.681		
24.50	0.106					25.50	0.31			44.00	0.680		
25.00	0.106					26.00	0.31			45.00	0.679		
25.50	0.106					26.50	0.31			46.00	0.678		
26.00	0.106					27.00	0.31			47.00	0.677		
26.50	0.106					27.50	0.31			48.00	0.676		
27.00	0.106					28.00	0.31			49.00	0.675		
27.50	0.106					28.50	0.31			50.00	0.674		
28.00	0.106					29.00	0.31			51.00	0.673		
28.50	0.106					29.50	0.31			52.00	0.672		
29.00	0.106					30.00	0.31			53.00	0.671		
29.50	0.106					30.50	0.31			54.00	0.670		
30.00	0.106					31.00	0.31			55.00	0.669		
30.50	0.106					31.50	0.31			56.00	0.668		
31.00	0.106					32.00	0.31			57.00	0.667		
31.50	0.106					32.50	0.31			58.00	0.666		
32.00	0.106					33.00	0.31			59.00	0.665		
32.50	0.106					33.50	0.31			60.00	0.664		
33.00	0.106					34.00	0.31			61.00	0.663		
33.50	0.106					34.50	0.31			62.00	0.662		
34.00	0.106					35.00	0.31			63.00	0.661		
34.50	0.106					35.50	0.31			64.00	0.660		
35.00	0.106					36.00	0.31			65.00	0.659		
35.50	0.106					36.50	0.31			66.00	0.658		
36.00	0.106					37.00	0.31			67.00	0.657		
36.50	0.106					37.50	0.31			68.00	0.656		
37.00	0.106					38.00	0.31			69.00	0.655		
37.50	0.106					38.50	0.31			70.00	0.654		
38.00	0.106					39.00	0.31			71.00	0.653		
38.50	0.106					39.50	0.31			72.00	0.652		
39.00	0.106					40.00	0.31			73.00	0.651		
39.50	0.106					40.50	0.31			74.00	0.650		
40.00	0.106					41.00	0.31			75.00	0.649		
40.50	0.106					41.50	0.31			76.00	0.648		
41.00	0.106					42.00	0.31			77.00	0.647		
41.50	0.106					42.50	0.31			78.00	0.646		
42.00	0.106					43.00	0.31			79.00	0.645		
42.50	0.106					43.50	0.31			80.00	0.644		
43.00	0.106					44.00	0.31			81.00	0.643		
43.50	0.106					44.50	0.31			82.00	0.642		
44.00	0.106					45.00	0.31			83.00	0.641		
44.50	0.106					45.50	0.31			84.00	0.640		
45.00	0.106					46.00	0.31			85.00	0.639		
45.50	0.106					46.50	0.31			86.00	0.638		
46.00	0.106					47.00	0.31			87.00	0.637		
46.50	0.106					47.50	0.31			88.00	0.636		
47.00	0.106					48.00	0.31			89.00	0.635		
47.50	0.106					48.50	0.31			90.00	0.634		
48.00	0.106					49.00	0.31			91.00	0.633		
48.50	0.106					49.50	0.31			92.00	0.632		
49.00	0.106					50.00	0.31			93.00	0.631		
49.50	0.106					50.50	0.31			94.00	0.630		
50.00	0.106					51.00	0.31			95.00	0.629		
50.50	0.106					51.50	0.31			96.00	0.628		
51.00	0.106					52.00	0.31			97.00	0.627		
51.50	0.106					52.50	0.31			98.00	0.626		
52.00	0.106					53.00	0.31			99.00	0.625		
52.50	0.106					53.50	0.31			100.00	0.624		
53.00	0.106					54.00	0.31			101.00	0.623		
53.50	0.106					54.50	0.31			102.00	0.622		
54.00	0.106					55.00	0.31			103.00	0.621		
54.50	0.106					55.50	0.31			104.00	0.620</		

TABLE 3-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	
CURVE 23 $T = 818.$																				
CURVE 24 $T = 957.$																				
1.5	0.979	4.0	0.707	13.50	0.816	1.5	1.000	1.5	1.000	2.0	1.000	3.0	0.955	4.0	0.955	4.0	0.955	4.0	0.955	
2.0	0.933	6.0	0.648	13.75	0.730	2.0	1.000	2.0	1.000	3.0	0.955	3.0	0.955	4.0	0.955	4.0	0.955	4.0	0.955	
3.0	0.809	8.0	0.647	14.00	0.580	3.0	0.955	3.0	0.955	4.0	0.955	4.0	0.955	4.0	0.955	4.0	0.955	4.0	0.955	
4.0	0.665	10.0	0.635	14.25	0.447	4.0	0.955	4.0	0.955	5.0	0.955	5.0	0.955	6.0	0.955	6.0	0.955	6.0	0.955	
6.0	0.623	12.0	0.573	14.50	0.367	4.0	0.955	4.0	0.955	5.0	0.955	5.0	0.955	6.0	0.955	6.0	0.955	6.0	0.955	
8.0	0.615	CURVE 27 $T = 300.$		14.75	0.348	6.0	0.910	6.0	0.910	7.0	0.334	7.0	0.845	8.0	0.845	8.0	0.845	8.0	0.845	
10.0	0.591	10.0	0.591	15.00	0.333	10.0	0.874	10.0	0.874	11.0	0.333	11.0	0.874	12.0	0.874	12.0	0.874	12.0	0.874	
12.0	0.536	CURVE 26 (CONT.)		15.75	0.347	12.0	0.823	12.0	0.823	13.0	0.347	13.0	0.823	14.0	0.823	14.0	0.823	14.0	0.823	
CURVE 25 $T = 811.$																				
1.5	1.000	6.50	0.722	16.00	0.352	1.5	1.000	1.5	1.000	2.0	0.357	2.0	0.357	3.0	0.357	3.0	0.357	3.0	0.357	
2.0	1.000	7.00	0.698	16.25	0.357	2.0	0.992	2.0	0.992	3.0	0.374	3.0	0.947	4.0	0.947	4.0	0.947	4.0	0.947	
3.0	0.672	7.50	0.693	16.50	0.426	3.0	0.955	3.0	0.955	4.0	0.362	4.0	0.955	5.0	0.362	5.0	0.955	5.0	0.955	
4.0	0.605	8.00	0.656	17.00	0.511	4.0	0.955	4.0	0.955	5.0	0.362	5.0	0.955	6.0	0.362	6.0	0.955	6.0	0.955	
6.0	0.669	2.00	0.686	17.50	0.629	6.0	0.901	6.0	0.901	7.0	0.362	7.0	0.901	8.0	0.362	8.0	0.901	8.0	0.901	
8.0	0.624	3.00	0.918	17.69	0.343	8.0	0.830	8.0	0.830	9.0	0.350	9.0	0.830	10.0	0.350	10.0	0.830	10.0	0.830	
10.0	0.609	3.50	0.912	17.79	0.350	10.0	0.830	10.0	0.830	11.0	0.350	11.0	0.830	12.0	0.350	12.0	0.830	12.0	0.830	
12.0	0.553	4.00	0.899	18.00	0.376	12.0	0.810	12.0	0.810	13.0	0.376	13.0	0.810	14.0	0.376	14.0	0.810	14.0	0.810	
CURVE 26 $T = 952.$																				
1.5	1.000	5.50	0.848	18.50	0.421	1.5	1.000	1.5	1.000	2.0	0.424	2.0	0.424	3.0	0.424	3.0	0.424	3.0	0.424	
2.0	1.000	6.00	0.768	19.00	0.424	2.0	0.992	2.0	0.992	3.0	0.424	3.0	0.947	4.0	0.947	4.0	0.947	4.0	0.947	
3.0	0.672	7.50	0.693	19.50	0.424	3.0	0.955	3.0	0.955	4.0	0.424	4.0	0.955	5.0	0.424	5.0	0.955	5.0	0.955	
4.0	0.717	8.00	0.701	20.00	0.424	4.0	0.955	4.0	0.955	5.0	0.424	5.0	0.955	6.0	0.424	6.0	0.955	6.0	0.955	
6.0	0.642	8.50	0.727	20.50	0.424	6.0	0.955	6.0	0.955	7.0	0.424	7.0	0.955	8.0	0.424	8.0	0.955	8.0	0.955	
8.0	0.633	9.00	0.764	21.00	0.424	8.0	0.955	8.0	0.955	9.0	0.424	9.0	0.955	10.0	0.424	10.0	0.955	10.0	0.955	
10.0	0.606	9.50	0.796	21.50	0.424	10.0	0.955	10.0	0.955	11.0	0.424	11.0	0.955	12.0	0.424	12.0	0.955	12.0	0.955	
12.0	0.561	10.00	0.822	22.00	0.424	12.0	0.810	12.0	0.810	13.0	0.424	13.0	0.810	14.0	0.424	14.0	0.810	14.0	0.810	
CURVE 27 (CONT.) $T = 950.$																				
1.5	0.979	6.0	0.648	13.50	0.816	1.5	1.000	1.5	1.000	2.0	0.816	2.0	1.000	3.0	0.816	3.0	1.000	3.0	1.000	
2.0	0.933	8.0	0.647	13.75	0.730	2.0	1.000	2.0	1.000	3.0	0.816	3.0	1.000	4.0	0.816	4.0	1.000	4.0	1.000	
3.0	0.809	10.0	0.635	14.00	0.580	3.0	1.000	3.0	1.000	4.0	0.816	4.0	1.000	5.0	0.816	5.0	1.000	5.0	1.000	
4.0	0.665	12.0	0.573	14.25	0.447	4.0	1.000	4.0	1.000	5.0	0.816	5.0	1.000	6.0	0.816	6.0	1.000	6.0	1.000	
6.0	0.623	CURVE 28 $T = 809.$		14.50	0.367	6.0	0.910	6.0	0.910	7.0	0.334	7.0	0.845	8.0	0.334	8.0	0.845	8.0	0.845	
8.0	0.615	15.00	0.348	15.00	0.334	8.0	0.845	8.0	0.845	9.0	0.334	9.0	0.845	10.0	0.334	10.0	0.845	10.0	0.845	
10.0	0.591	15.50	0.333	15.50	0.333	10.0	0.845	10.0	0.845	11.0	0.334	11.0	0.845	12.0	0.334	12.0	0.845	12.0	0.845	
12.0	0.536	16.00	0.347	16.00	0.352	12.0	0.823	12.0	0.823	13.0	0.352	13.0	0.823	14.0	0.352	14.0	0.823	14.0	0.823	
CURVE 29 $T = 950.$																				
1.5	1.000	6.50	0.722	16.00	0.357	1.5	1.000	1.5	1.000	2.0	0.357	2.0	0.357	3.0	0.357	3.0	0.357	3.0	0.357	
2.0	1.000	7.00	0.698	16.25	0.357	2.0	0.992	2.0	0.992	3.0	0.426	3.0	0.947	4.0	0.947	4.0	0.947	4.0	0.947	
3.0	0.672	7.50	0.693	16.50	0.426	3.0	0.955	3.0	0.955	4.0	0.426	4.0	0.955	5.0	0.426	5.0	0.955	5.0	0.955	
4.0	0.717	8.00	0.701	17.00	0.511	4.0	0.955	4.0	0.955	5.0	0.426	5.0	0.955	6.0	0.426	6.0	0.955	6.0	0.955	
6.0	0.642	8.50	0.727	17.42	0.638	6.0	0.955	6.0	0.955	7.0	0.426	7.0	0.955	8.0	0.426	8.0	0.955	8.0	0.955	
8.0	0.633	9.00	0.764	17.50	0.629	8.0	0.955	8.0	0.955	9.0	0.426	9.0	0.955	10.0	0.426	10.0	0.955	10.0	0.955	
10.0	0.606	9.50	0.796	17.69	0.343	10.0	0.830	10.0	0.830	11.0	0.350	11.0	0.830	12.0	0.350	12.0	0.830	12.0	0.830	
12.0	0.561	10.00	0.822	18.00	0.424	12.0	0.810	12.0	0.810	13.0	0.424	13.0	0.810	14.0	0.424	14.0	0.810	14.0	0.810	
CURVE 26 $T = 949.$																				
1.5	1.000	6.00	0.768	19.00	0.424	1.5	1.000	1.5	1.000	2.0	0.424	2.0	0.424	3.0	0.424	3.0	0.424	3.0	0.424	
2.0	0.998	6.50	0.730	19.50	0.424	2.0	0.992	2.0	0.992	3.0	0.424	3.0	0.947	4.0	0.947	4.0	0.947	4.0	0.947	
3.0	0.672	7.00	0.698	20.00	0.424	3.0	0.955	3.0	0.955	4.0	0.424	4.0	0.955	5.0	0.424	5.0	0.955	5.0	0.955	
4.0	0.717	7.50	0.701	20.50	0.511	4.0	0.955	4.0	0.955	5.0	0.424	5.0	0.955	6.0	0.424	6.0	0.955	6.0	0.955	
6.0	0.642	8.00	0.727	21.00	0.638	6.0	0.955	6.0	0.955	7.0	0.424	7.0	0.955	8.0	0.424	8.0	0.955	8.0	0.955	
8.0	0.633	8.50	0.764	21.50	0.629	8.0	0.955	8.0	0.955	9.0	0.424	9.0	0.955	10.0	0.424	10.0	0.955	10.0	0.955	
10.0	0.606	9.00	0.796	22.00	0.343	10.0	0.830	10.0	0.830	11.0	0.424	11.0	0.830	12.0	0.424	12.0	0.830	12.0	0.830	
12.0	0.561	10.00	0.822	22.50	0.424	12.0	0.810	12.0	0.810	13.0	0.424	13.0	0.810	14.0	0.424	14.0	0.810	14.0	0.810	

b. Normal Spectral Emittance (Temperature Dependence)

There is no experimental data available for this property. The provisional values for the polished surface, tabulated in Table 3-4 and shown in Figure 3-3, for 3.8μ and 10.6μ , covering the temperature range from room temperature to the melting point, were calculated by using the Kirchhoff law, i.e., $\epsilon_\lambda = \alpha_\lambda$. Data for α_λ are available in Section 4.3.g. These are considered accurate to within $\pm 20\%$ over the entire temperature range.

TABLE 3-4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

POLISHED	$\lambda = 3.0$	$\lambda = 10.6$
293.	0.137	293.
300.	0.138	300.
400.	0.143	400.
500.	0.148	500.
600.	0.154	600.
700.	0.158	700.
800.	0.165	800.
900.	0.170	900.
1000.	0.176	1000.
1100.	0.180	1100.
1200.	0.186	1200.
1300.	0.192	1300.
1400.	0.196	1400.
1500.	0.202	1500.
1600.	0.207	1600.
1700.	0.212	1700.
1727.	0.213	1727.




FIGURE 3-3. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

There are seven experimental data sets available for the wavelength dependence (0.97-295.9 μm) of the normal spectral reflectance of AISI 304 Stainless Steel from 77 K to room temperature. These are tabulated in Table 3-7 and shown in Figure 3-5.

The recommended values at 293 K, tabulated in Table 3-5 and shown in Figure 3-4, are for polished and unoxidized surfaces. These values, primarily from the investigations of Leigh [T33512] and Stockham [T45583], and the recommended values for the normal spectral emittance shown in Table 3-1 are considered accurate to within $\pm 15\%$ over the entire wavelength range.

The typical values at 1273 K, tabulated in Table 3-5 and shown in Figure 3-4, are for polished and oxidized surfaces. These values were calculated by using the Kirchhoff law, $\rho_\lambda = 1 - \alpha_\lambda = 1 - \epsilon_\lambda$, where the values for the normal spectral emittance are shown in Table 3-1. These values are considered accurate to about $\pm 30\%$ over the entire wavelength range.

TABLE 3-5. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ
POLISHED		POLISHED		POLISHED	
$T = 293$		$T = 293$ (CONT.)		$T = 1273$	
0.22	0.426	13.50	0.923	2.00	0.2328†
0.25	0.468	14.00	0.924	2.50	0.2318
0.30	0.618			2.80	0.2308
0.32	0.628			3.00	0.2468
0.40	0.608			3.50	0.2718
0.50	0.698			3.80	0.2928
0.60	0.728			4.00	0.3108
1.00	0.748			4.50	0.3368
1.50	0.794			5.00	0.3508
1.88	0.828			5.50	0.3208
2.00	0.833			6.00	0.2638
2.20	0.836			6.50	0.2568
2.40	0.838			7.00	0.2408
2.50	0.828			7.50	0.2308
2.60	0.820			8.00	0.2248
2.80	0.824			8.50	0.2298
3.00	0.828			9.00	0.2198
3.50	0.834			9.50	0.2358
3.80	0.840			10.00	0.2548
4.00	0.846			10.60	0.3118
4.50	0.852			11.00	0.3528
5.00	0.860			11.50	0.4008
5.50	0.866			12.00	0.4468
6.00	0.872			12.50	0.4908
6.50	0.879			13.00	0.5448
7.00	0.884			13.50	0.5768
7.50	0.889			14.00	0.5908
8.00	0.893				
8.50	0.898				
9.00	0.902				
9.50	0.904				
10.00	0.908				
10.50	0.911				
10.60	0.912				
11.00	0.914				
11.50	0.917				
12.00	0.919				
12.50	0.920				
13.00	0.921				

† VALUE FOLLOWED BY A "B" IS TYPICAL.




FIGURE 3-4. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE).




FIGURE 3-5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE).

TABLE 3-6. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	T33512	Leigh, C. H.	1962	1.81-26.01	298		Nominal composition: 18.00-20.00 Cr, 8.00-12.00 Ni, 2.00 max Mn, 1.00 max Si, 0.08 max C. Fe balance; polished; converted from $R(2\pi 0^\circ)$; data extracted from smooth curve; $\theta=0^\circ \cdot \omega^1=2\pi$.
2	T33512	Leigh, C. H.	1962	1.94-26.01	298		Similar to the above specimen and conditions except damaged by particle impact.
3	T33512	Leigh, C. H.	1962	1.90-25.99	77		Similar to the above specimen and conditions.
4	T68366	Stockham, L. W.	1972	0.97-9.95	300		Specimen cut from 1 1/2 in. bar stock, milled to thickness of 1/4 in. and polished using standard techniques; RMS roughness $0.03 \pm 0.005 \mu$.
5	T45583	Jones, M. C. and Palmer, D.C.	1969	2.8-295.8	77		Sample ground in form of a flat disk 11/16 in. diameter and about 1/8 in. thick; relative measurement where energy reflected from a sample compared with that from a calibrated reference surface which is chosen to use films derived from very pure gold (799.999 pure) deposited from vapor on highly polished flat glass substrates under high vacuum or ultrahigh-vacuum conditions; commercial spectrophotometer having nominal wavelength range from 1-700 μm .
6	T45583	Jones, M. C. and Palmer, D.C.	1969	2.8-295.8	105		Similar to the above specimen measured at 105 K.
7	T45583	Jones, M. C. and Palmer, D.C.	1969	2.9-295.9	297		Similar to the above specimen except measured at 297 K.

TABLE 3-7. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ
CURVE 1 $T = 296.$		CURVE 3 (CONT.)		CURVE 6 $T = 105.$	
1.01	0.777	22.01	0.889	2.6	0.641
3.40	0.822	23.96	0.895	3.3	0.649
5.42	0.862	25.99	0.899	3.9	0.652
6.55	0.871	CURVE 4 $T = 300.$		4.6	0.676
8.44	0.881			5.2	0.686
10.77	0.897			6.2	0.703
13.42	0.907	0.97	0.615	7.0	0.911
15.90	0.906	1.95	0.768	9.0	0.925
16.98	0.919	3.94	0.834	12.4	0.937
21.65	0.923	5.95	0.875	14.1	0.942
26.01	0.924	7.93	0.883	21.7	0.954
CURVE 2 $T = 296.$		9.95	0.910	25.5	0.954
				26.4	0.959
		CURVE 5 $T = 77.$		33.1	0.961
1.94	0.739	2.8	0.841	56.1	0.966
3.39	0.798	3.3	0.853	65.3	0.964
5.92	0.852	7.77	0.866	78.5	0.964
10.02	0.867	10.02	0.866		
12.09	0.897	12.09	0.886		
14.02	0.898	14.02	0.898		
16.65	0.902	16.65	0.902		
18.70	0.898	18.70	0.898		
20.67	0.890	20.67	0.890		
22.32	0.895	22.32	0.895		
24.41	0.899	24.41	0.899		
26.01	0.899	26.01	0.899		
CURVE 3 $T = 77.$		25.4	0.949	12.4	0.930
		28.4	0.951	14.3	0.934
		33.1	0.963	21.8	0.942
		39.2	0.962	25.5	0.949
		49.4	0.967	29.0	0.949
		56.1	0.966	33.1	0.952
		65.3	0.963	39.2	0.955
		79.5	0.969	49.3	0.958
				56.1	0.962
				65.3	0.959
				78.5	0.965

d. Normal Spectral Reflectance (Temperature Dependence)

There is no experimental data available for this property. Two provisional values, tabulated in Table 3-8 and shown in Figure 3-6, were generated for 3.8μ and 10.6μ , respectively, covering the temperature range from room temperature to the melting point. The relation $\rho_\lambda + \alpha_\lambda = 1$ was employed for this case. Data for α_λ are available in Section 4.3.g. These values are considered accurate to about $\pm 20\%$ for the entire temperature range.

TABLE 3-6. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

T	ρ	T	ρ
POLISHED			
$\lambda = 3.0$		$\lambda = 10.6$	
293.	0.863	293.	0.912
300.	0.862	300.	0.911
400.	0.857	400.	0.907
500.	0.852	500.	0.903
600.	0.846	600.	0.900
700.	0.842	700.	0.897
800.	0.835	800.	0.894
900.	0.83	900.	0.890
1000.	0.824	1000.	0.867
1100.	0.823	1100.	0.863
1200.	0.814	1200.	0.860
1300.	0.806	1300.	0.877
1400.	0.804	1400.	0.873
1500.	0.798	1500.	0.871
1600.	0.793	1600.	0.868
1700.	0.786	1700.	0.864
1727.	0.787	1727.	0.864




FIGURE 3-6. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE).

e. Angular Spectral Reflectance (Wavelength Dependence)

There are three sets of experimental data available for the wavelength dependence (0.1-0.2 μm) of the angular spectral reflectance of AISI 304 Stainless Steel at temperature 300 K. These are tabulated in Table 3-10 and shown in Figure 3-7.

No recommendations were made because of the lack of information in the wavelength range which we are interested in.




FIGURE 3-7. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE).

TABLE 3-9. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL. (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T77362	Marmo, F. F., Engelmann, A., and Schultz, E. D.	1967	0.1-0.2	300			The top and bottom parts of reflectometer contain a rotary push-pull vacuum cell with an indicating pointer and a fixed 360 degree protractor, angle of incidence of 20 degrees; $\theta=20^\circ$.
2 T77362	Marmo, F. F., et al.	1967	0.1-0.2	300			Similar to the above specimen except angle of incidence of 45 degree; $\theta=45^\circ$.
3 T77362	Marmo, F. F., et al.	1967	0.1-0.2	300			Similar to the above specimen except angle of incidence of 70 degree; $\theta=70^\circ$.

TABLE 3-10. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)

(WAVELENGTH, $\lambda \cdot \mu\text{m}$; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ
CURVE 1 $T = 300.$					
0.1115	0.050	0.1344	0.107	0.1544	0.302
0.1146	0.053	0.1357	0.109	0.1581	0.295
0.1161	0.056	0.1377	0.108	0.1608	0.316
0.1176	0.056	0.1395	0.103	0.1703	0.330
0.1189	0.056	0.1436	0.096	0.1753	0.336
0.1216	0.062	0.1464	0.095	0.1803	0.349
0.1254	0.066	0.1487	0.099	0.1853	0.354
0.1278	0.072	0.1517	0.108	0.1923	0.356
0.1344	0.076	0.1532	0.115	0.1953	0.358
0.1357	0.076	0.1544	0.121	0.2003	0.361
0.1377	0.076	0.1561	0.126		
0.1395	0.074	0.1608	0.146		
0.1436	0.069	0.1703	0.164		
0.1464	0.067	0.1803	0.190		
0.1467	0.069	0.1853	0.197		
0.1517	0.076	0.1903	0.205		
0.1532	0.085	0.1953	0.208		
0.1544	0.090	0.2003	0.212		
0.1581	0.093				
0.1608	0.112				
0.1753	0.152				
0.1803	0.163				
0.1853	0.171				
0.1903	0.176				
0.1953	0.184				
0.2003	0.196				
CURVE 2 $T = 300.$					
0.1115	0.079	0.1115	0.250		
0.1146	0.082	0.1146	0.251		
0.1161	0.085	0.1161	0.255		
0.1176	0.086	0.1176	0.258		
0.1189	0.089	0.1189	0.262		
0.1216	0.091	0.1216	0.276		
0.1254	0.093	0.1254	0.279		
0.1278	0.098	0.1278	0.286		
CURVE 3 $T = 300.$					
0.1115	0.079	0.1357	0.294		
0.1146	0.082	0.1377	0.289		
0.1161	0.085	0.1395	0.282		
0.1176	0.086	0.1436	0.274		
0.1189	0.089	0.1464	0.274		
0.1216	0.091	0.1487	0.273		
0.1254	0.093	0.1517	0.266		
0.1278	0.098	0.1532	0.295		

f. Normal Spectral Absorptance (Wavelength Dependence)

There are five sets of experimental data available for the wavelength dependence (2.8-20 μm) of the normal spectral absorptance of AISI 304 Stainless Steel near room temperature. These values are tabulated in Table 3-13 and shown in Figure 3-9.

The recommended values for polished surfaces at 293 K, tabulated in Table 3-11 and shown in Figure 3-8 are primarily based on the work by Harmon [A00003] and the recommended data for normal spectral emittance of wavelength dependence (see Section 4.3.a).

The accuracy for this recommended data is considered to within $\pm 15\%$ for the entire wavelength range.

The typical values at 1273 K, tabulated in Table 3-11 and shown in Figure 3-8, are for polished and oxidized surfaces. These values were calculated by using the Kirchhoff law, $\alpha_\lambda = \epsilon_\lambda$, where the values for the normal spectral emittance are shown in Table 3-1. These values are considered accurate to about $\pm 30\%$ over the entire wavelength range.

TABLE 3-11. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)[†]

λ	α	λ	α	λ	α
POLISHED		POLISHED		POLISHED	
$T = 293$		$T = 293$ (CONT.)		$T = 1273$	
0.22	0.572	13.50	0.077	2.00	0.7688 [†]
0.25	0.532	14.00	0.076	2.50	0.7658
0.30	0.392			2.80	0.7628
0.32	0.372			3.00	0.7548
0.40	0.392			3.50	0.7298
0.50	0.302			3.80	0.7068
0.80	0.272			4.00	0.6908
1.00	0.252			4.50	0.6648
1.50	0.206			5.00	0.6508
1.68	0.172			5.50	0.6808
2.00	0.167			6.00	0.7178
2.20	0.164			6.50	0.7448
2.40	0.162			7.00	0.7608
2.50	0.172			7.50	0.7708
2.60	0.180			8.00	0.7768
2.80	0.176			8.50	0.7808
3.00	0.172			9.00	0.7818
3.50	0.166			9.50	0.7658
3.80	0.168			10.00	0.7468
4.00	0.156			10.60	0.6998
4.50	0.148			11.00	0.6468
5.00	0.140			11.50	0.6008
5.50	0.134			12.00	0.5548
6.00	0.128			12.50	0.5028
6.50	0.121			13.00	0.4568
7.00	0.116			13.50	0.4248
7.50	0.111			14.00	0.4028
8.00	0.107				
8.50	0.102				
9.00	0.098				
9.50	0.096				
10.00	0.092				
10.50	0.089				
11.00	0.086				
11.50	0.083				
12.00	0.081				
12.50	0.080				
13.00	0.079				

[†] VALUE FOLLOWED BY A "B" IS TYPICAL.




FIGURE 3-8. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE).




FIGURE 3-9. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE).

TABLE 3-12. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (Wavelength Dependence)

Cur. Ref. No. No. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A00016	Neighbours, J.R. (Editor)	1974	2.8	300		Polished surface condition.
2 A00016	Neighbours, J.R. (Editor)	1974	2.8	300		As received surface condition.
3 A00016	Neighbours, J.R. (Editor)	1974	10.6	300		Polished surface condition.
4 A00016	Neighbours, J.R. (Editor)	1974	10.6	300		As received surface condition.
5 A00003	Harmon, N.F. (Editor)	1974	3.42-20.00	293		High quality surface.

TABLE 3-13. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T, K ; ABSORPTANCE, α)

λ	α
CURVE 1 T = 300.	
2.0	0.21
CURVE 2 T = 300.	
2.0	0.4
CURVE 3 T = 300.	
10.6	0.11
CURVE 4 T = 300.	
10.6	0.4
CURVE 5 T = 293.	
3.4	0.175
3.7	0.166
4.1	0.157
4.5	0.147
5.1	0.136
7.2	0.114
8.4	0.104
9.1	0.099
10.0	0.093
11.1	0.086
12.5	0.083
14.3	0.076
16.6	0.071
19.1	0.064
20.0	0.061

g. Normal Spectral Absorptance (Temperature Dependence)

There are eight sets of data available for the temperature dependence (293-1727 K) of the normal spectral absorptance of AISI 304 Stainless Steel covering the wavelength range from 2.8 μm to 10.6 μm . These values are tabulated in Table 3-16 and shown in Figure 3-11.

The provisional values for the polished surface for 3.8 μm and 10.6 μm are tabulated in Table 3-14 and shown in Figure 3-10 covering the temperature range from 293 to 1727 K.

The provisional values for 3.8 μm are primarily based on the work by Neighbours [A00016] who theoretically calculated the normal spectral absorptance from the equation $\alpha_{\lambda} = A_0 + A_2 T$ assuming that this AISI 304 Stainless Steel obeyed the Drude-Lorentz theory.

The provisional values at 10.6 μm were generated from the calculations of Neighbours [A00016] and Cunningham and Laughlin [E66194] who used the Hagen-Rubens relation, and the experimental values of Harmon [A00003]. The accuracy of both provisional curves is about $\pm 20\%$ over the entire temperature range.

TABLE 3-14. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α)

T °C	α	T °K		α
		POLISHED $\lambda = 3.0$	POLISHED $\lambda = 10.6$	
293.	0.137	293.	0.088	
300.	0.138	300.	0.089	
400.	0.143	400.	0.093	
500.	0.148	500.	0.097	
600.	0.154	600.	0.100	
700.	0.156	700.	0.103	
800.	0.165	800.	0.106	
900.	0.170	900.	0.110	
1000.	0.176	1000.	0.113	
1100.	0.180	1100.	0.117	
1200.	0.186	1200.	0.120	
1300.	0.192	1300.	0.123	
1400.	0.196	1400.	0.127	
1500.	0.202	1500.	0.129	
1600.	0.207	1600.	0.132	
1700.	0.212	1700.	0.136	
1727.	0.213	1727.	0.136	




FIGURE 3-10. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE).




TABLE 3-15. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (Temperature Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A00016	Neighbours, J.R., (Editor)	1974	2.8	300		Polished surface condition.
2 A00016	Neighbours, J.R., (Editor)	1974	2.8	300		As received surface condition.
3 A00016	Neighbours, J.R., (Editor)	1974	10.6	300		Polished surface condition.
4 A00016	Neighbours, J.R., (Editor)	1974	10.6	300		As received surface condition.
5 A00016	Neighbours, J.R., (Editor)	1974	3.8	300-1727		Theoretical calculation of absorptance from 300 K to the melting point (1727 K) from the equation $A = A_0 + A_1 T$, based on the assumption that the alloys obey the Drude-Lorentz theory, where $A_0 = 0.122$ and $A_1 = 5.27 \times 10^{-5} \text{ K}^{-1}$.
6 A00016	Neighbours, J.R., (Editor)	1974	10.6	300-1727		The above specimen except $A_0 = 7.91 \times 10^{-2}$ and $A_1 = 3.27 \times 10^{-5} \text{ K}^{-1}$.
7 A00003	Harmon, N.F., (Editor)	1974	10.6	293-773		Averaged values of two runs.
8 E66194	Cunningham, S.S. and Laughlin, W.T.	1974	10.6	300-900		Calculated value of absorptance, which is obtained by evaluating the Hagen-Rubens relation.

TABLE 3-16. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF AISI 304 STAINLESS STEEL (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; ABSORPTANCE, α)

T	α	T	α	CURVE 6 $\lambda = 10.6$	T	α	CURVE 8 (CONT.)
300.	0.21	300.	0.089		900.	0.111	
		400.	0.092				
		500.	0.095				
		600.	0.099				
		700.	0.102				
		800.	0.105				
		900.	0.108				
		1000.	0.112				
		1100.	0.115				
		1200.	0.118				
		1300.	0.122				
		1400.	0.125				
		1500.	0.128				
		1600.	0.131				
		1700.	0.135				
		1727.	0.136				
				CURVE 7 $\lambda = 10.6$			
				293.	0.088		
				323.	0.090		
				373.	0.093		
				423.	0.095		
				473.	0.097		
				523.	0.099		
				573.	0.101		
				623.	0.104		
				673.	0.106		
					CURVE 8 $\lambda = 10.6$		
					300.	0.089	
					400.	0.095	
					500.	0.099	
					600.	0.103	
					700.	0.106	
					800.	0.108	

h. Transmittance

Although it is true that metals and alloys in the form of extremely thin films may be transparent for a wide wavelength range, they are opaque if the thickness is greater than several hundred angstroms.

As an aircraft/spacecraft structural material, this alloy is not used in the form of extremely thin films and therefore is opaque; that is, its transmittance is zero.

4.4. Titanium Alloy Ti-6Al-4V

Titanium alloy Ti-6Al-4V was first introduced in 1954 [A00008]. Its nominal composition is 6% Al, 4% V, and balance Ti. The melting range of this alloy is 1803 to 1908 K. Its density is 4.424 g cm^{-3} , which is 56% of that of steel. It can be heat-treated to ultimate strength in excess of 170,000 psi and has excellent fatigue properties and crack propagation characteristics.

This alloy has an alpha lean beta composition. Addition of the six percent aluminum stabilizes the alpha phase resulting in an increase in $\alpha + \beta \rightarrow \beta$ transformation temperature from 1156 to 1266 K. It also increases the elevated temperature strength level. Addition of four percent vanadium increases the strength level by two mechanisms: firstly by substitutional solid solution hardening and secondly, by stabilizing the beta or high temperature phase, thereby making β to α hardening reaction possible through heat treatment. The addition of Vanadium improves hot workability by causing more of the ductile β -phase to be present at hot working temperatures.

Descaling of the alloy can be accomplished mechanically by methods such as grinding and grit blasting; and chemically by acid pickling or by immersion in molten caustic or hydride bath.

Pickling of the alloy is generally done either for dimensional reasons or for removing surface (oxygen) contamination. This is done in bath containing HNO_3 and HF with ratios of 10:1. HNO_3 acts as an inhibitor to prevent the titanium from picking up the free hydrogen from the Ti-HF reaction.

This alloy has the following different designations:

Republic Steel Co., Titanium Metal Division: Ti-6Al-4V
Special Metal Division: RS-120A

Crucible Steel Co., Titanium Division: C-120AV

Harvey Aluminum Co., Titanium Division: HA-6510

Reactive Metal Products: MST-6Al-4V

Aeronautical Material Specifications: 4928A

Military designation: OS-10737

a. Normal Spectral Emittance (Wavelength Dependence)

There are four sets of experimental data available for the wavelength dependence (0.3-15 μm) of the normal spectral emittance of Titanium Alloy Ti-6Al-4V for oxidized and anodized surfaces. These are tabulated in Table 4-3 and shown in Figure 4-2.

(1) 0.032 μm Finish Alloy

There are no experimental data available for this alloy; however, the recommended values are tabulated in Table 4-1 and shown in Figure 4-1 for Titanium Alloy Ti-6Al-4V alloy of nominal composition and 0.032 μm finish. These values were calculated from the normal spectral reflectance data for the similar material (see Section 4.5.d).

(2) Oxidized Titanium Alloy Ti-6Al-4V

The recommended values tabulated in Table 4-1 and shown in Figure 4-1 for oxidized material are primarily from the investigation of Gravina and Katz [T22613]. These values are considered accurate to within $\pm 15\%$ over the entire wavelength range. The values calculated from the normal spectral reflectance data of Grimm and Fannin [A00001] for a specimen after heating for 15 minutes in air are in good agreement with the recommended values.

(3) Anodized Titanium Alloy Ti-6Al-4V

The recommended values tabulated in Table 4-1 and shown in Figure 4-1 for chromic acid anodized surface are primarily from the investigation of Cunningham and Funai [T22613]. These values are considered accurate to within 15% over the entire wavelength range. It is very important to note that since different anodizing processes may produce entirely different surface finishes, which in turn will affect the radiative properties. This makes it impossible to give recommended values for general cases. Therefore, the above recommended values are for chromic acid anodized surface only. (See Section 4.1.c for further explanation.)

TABLE 4-1. RECOMMENDED NORMAL SPECTRAL EMMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMMITTANCE, ϵ]

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
0.032 μm FINISH ALLOY $T = 293$							
0.4	0.657	2.8	0.798	2.8	0.778	2.8	0.778
0.5	0.639	3.0	0.785	3.0	0.764	3.0	0.733
1.0	0.577	3.5	0.758	3.5	0.733	3.8	0.714
1.5	0.535	3.8	0.747	4.0	0.744	4.0	0.700
2.0	0.503	4.0	0.744	4.5	0.740	4.5	0.672
2.5	0.474	4.5	0.740	5.0	0.738	5.0	0.646
2.8	0.460	5.0	0.738	5.5	0.735	5.5	0.624
3.0	0.450	5.5	0.735	6.0	0.734	6.0	0.607
3.5	0.429	6.0	0.734	6.3	0.730	6.5	0.595
3.8	0.418	6.3	0.730	6.5	0.726	7.0	0.584
4.0	0.411	6.5	0.726	6.6	0.720	7.5	0.580
4.5	0.396	6.6	0.720	6.8	0.691	6.8	0.575
5.0	0.384	6.8	0.691	7.0	0.646	8.5	0.574
5.5	0.374	7.0	0.646	7.2	0.616	9.0	0.572
6.0	0.365	7.2	0.616	7.4	0.604	9.5	0.571
6.5	0.358	7.4	0.604	7.5	0.603	10.0	0.570
7.0	0.351	7.5	0.603	7.6	0.607	10.5	0.570
7.5	0.346	7.6	0.607	7.8	0.646	10.5	0.570
8.0	0.340	7.8	0.646	8.0	0.746	9.5	0.571
8.5	0.335	8.0	0.746	8.2	0.858	10.0	0.570
9.0	0.330	8.2	0.858	8.4	0.915	10.5	0.570
9.5	0.326	8.4	0.915	8.5	0.928	11.0	0.570
10.0	0.322	8.5	0.928	8.7	0.938	11.5	0.570
10.5	0.318	8.7	0.938	9.0	0.934	12.0	0.570
10.6	0.317	9.0	0.934	9.5	0.923	12.5	0.570
11.0	0.314	9.5	0.923	10.0	0.920	13.0	0.570
11.5	0.308	10.0	0.920	10.5	0.924	13.5	0.570
12.0	0.304	10.5	0.924	11.0	0.929	14.0	0.570
12.5	0.300	11.0	0.929	11.5	0.935	14.5	0.570
13.0	0.295	11.5	0.935	12.0	0.939	15.0	0.570
13.5	0.292	12.0	0.939	12.5	0.940	15.5	0.570
14.0	0.288	12.5	0.940	13.0	0.933	16.0	0.570
14.5	0.284	13.0	0.933	13.5	0.919	16.5	0.570
15.0	0.280	13.5	0.919	14.0	0.903	17.0	0.570
						17.5	0.570




FIGURE 4-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE).




FIGURE 4-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE).

TABLE 4-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T66303	Cunnington, G.R. and Funai, A.J.	1972	0.29-1.81	298		MSFC anodized Ti-6Al-4V; measurements before high temperature measurements.
2 T66308	Cunnington, G.R. and Funai, A.J.	1972	1.5-15	700		The above specimen.
3 T66308	Cunnington, G.R. and Funai, A.J.	1972	0.3-1.81	298		The above specimen; measurements after high temperature measurements.
4 T22613	Gravina, A. and Katz, M.	1961	2-10.5	700		Oxidized specimen.

TABLE 4-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	CURVE 1 $T = 293.$	CURVE 2 (CONT.)	CURVE 3 (CONT.)
0.29	0.919	6.52	0.739	1.10	0.896	
0.32	0.926	6.68	0.717	1.29	0.885	
0.36	0.933	7.00	0.644	1.46	0.866	
0.39	0.932	7.21	0.623	1.59	0.876	
0.41	0.926	7.51	0.598	1.66	0.870	
0.47	0.910	7.68	0.624	1.81	0.870	
0.55	0.894	7.81	0.663			
0.66	0.893	7.99	0.745	CURVE 4 $T = 700.$		
0.73	0.890	8.08	0.613			
0.81	0.679	6.20	0.866			
0.94	0.877	6.31	0.902	2.00	0.706	
1.05	0.873	6.49	0.938	2.31	0.743	
1.25	0.861	6.63	0.942	2.58	0.763	
1.51	0.852	9.02	0.926	3.08	0.763	
1.81	0.840	9.43	0.916	3.48	0.732	
		9.73	0.920	3.96	0.706	
		10.05	0.927	4.89	0.647	
		10.87	0.927	5.56	0.607	
		11.38	0.932	5.99	0.583	
		12.00	0.946	6.25	0.571	
		12.50	0.943	6.77	0.566	
		13.01	0.932	7.26	0.559	
1.50	0.728					
1.86	0.749					
2.21	0.772	13.55	0.920	8.05	0.559	
2.46	0.797	14.18	0.939	8.99	0.562	
2.74	0.797	14.60	0.887	10.51	0.567	
2.96	0.793	15.00	0.860			
3.16	0.780					
3.37	0.757			CURVE 3 $T = 293.$		
3.61	0.745					
3.93	0.745					
4.15	0.750					
4.50	0.750					
4.80	0.741					
5.00	0.729					
5.20	0.729					
5.45	0.737					
5.65	0.737					
5.86	0.729					
6.13	0.729					
6.43	0.739					

b. Normal Spectral Emittance (Temperature Dependence)

There are 22 experimental data sets for the temperature dependence (1100-1700 K) at $\lambda = 0.65 \mu\text{m}$ of the normal spectral emittance of Titanium Alloy Ti-6Al-4V. These are tabulated in Table 4-5 and shown in Figure 4-3. Since no measurements are located at higher wavelengths, no recommendations are made.




FIGURE 4-3. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (TEMPERATURE DEPENDENCE).

TABLE 4-4. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMISSANCE OF TITANIUM ALLOY Ti-6Al-4V (Temperature Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T6979	Betz, H. T., Olson, O. H., Schurin, B. D., and Morris, J. C.	1957	0.665	1152-1665		Nominal composition, specimen as received, cleaned with liquid detergent, measurements in vacuum ($5 \times 10^{-4} \text{ mm Hg}$) with increasing temperature, cycle one; $\theta' \sim 0^\circ$.
2 T6979	Betz, H. T., et al.	1957	0.665	1150-1498		Similar to the above specimen and condition, decreasing temperature, cycle one.
3 T6979	Betz, H. T., et al.	1957	0.665	1303-1669		Similar to the above specimen and condition, increasing temperature, cycle two.
4 T6979	Betz, H. T., et al.	1957	0.665	1156-1280		Similar to the above specimen and condition, decreasing temperature, cycle two.
5 T6979	Betz, H. T., et al.	1957	0.665	1312-1688		Similar to the above specimen and condition, increasing temperature, cycle three.
6 T6979	Betz, H. T., et al.	1957	0.665	1148-1480		Similar to the above specimen and condition, decreasing temperature, cycle three.
7 T6979	Betz, H. T., et al.	1957	0.665	1166-1693		Similar to the above specimen; polished with fine polishing compounds on a buffing wheel, increasing temperature cycle one.
8 T6979	Betz, H. T., et al.	1957	0.665	1439-1167		Similar to the above specimen and condition, decreasing temperature, cycle one.
9 T6979	Betz, H. T., et al.	1957	0.665	1334-1691		Similar to the above specimen and condition, increasing temperature, cycle two.
10 T6979	Betz, H. T., et al.	1957	0.665	1504-1181		Similar to the above specimen and condition, decreasing temperature, cycle two.
11 T6979	Betz, H. T., et al.	1957	0.665	1679		Similar to the above specimen and condition, cycle three.
12 T6979	Betz, H. T., et al.	1957	0.665	1194		Similar to the above specimen and condition, cycle three.
13 T6979	Betz, H. T., et al.	1957	0.665	1136-1654		Similar to the specimen from curve 1 except oxidized in air at red heat for 30 min, increasing temperature, cycle 1.
14 T6979	Betz, H. T., et al.	1957	0.665	1491-1140		Similar to the above specimen and condition, decreasing temperature, cycle one.
15 T6979	Betz, H. T., et al.	1957	0.665	1649-1296		Similar to the above specimen and condition, decreasing temperature, cycle one.
16 T6979	Betz, H. T., et al.	1957	0.665	1312		Similar to the above specimen and condition, cycle two.
17 T6979	Betz, H. T., et al.	1957	0.665	1597-1159		Similar to the above specimen and condition, cycle two.
18 T6979	Betz, H. T., et al.	1957	0.635	1566-1229		Similar to the above specimen and condition, cycle three.
19 T23145	Sklarew, S. and Rebenstein, A. S.	1963	0.65	1556-1229		Titanium alloy 6Al-4V; 5.5-6.5Al, 3.5-4.5V, 0.1 max C, 0.3 max Fe, 0.05 max N, 0.0125 max H ₂ , 0.15 max O ₂ , Ti balance; polished; surface roughness 2 to 3 $\mu\text{in.}$; measurements in vacuum ($3 \times 10^{-4} \text{ mm Hg}$); measurements with decreasing temperature.
20 T23145	Sklarew, S. and Rebenstein, A. S.	1963	0.65	1216-1332		Similar to the above specimen and condition, measurements with increasing temperature.
21* T23145	Sklarew, S. and Rebenstein, A. S.	1963	0.65	1490-1090		Similar to the above specimen except coated with Rokide "C", decreasing temperature.
22* T23145	Sklarew, S. and Rebenstein, A. S.	1963	0.65	1066-1438		Similar to the above specimen except measurements with increasing temperature.

* Not shown in figure.

TABLE 4-5. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (TEMPERATURE DEPENDENCE)


T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ
CURVE 1 $\lambda = 0.665$		CURVE 7 $\lambda = 0.665$		CURVE 13 $\lambda = 0.665$		CURVE 19 $\lambda = 0.65$			
1152.	0.592	1166.	0.500	1136.	0.679	1216.	0.491		
1521.	0.544	1312.	0.485	1366.	0.669	1265.	0.501		
1665.	0.537	1512.	0.455	1483.	0.656	1332.	0.513		
CURVE 2 $\lambda = 0.665$		CURVE 8 $\lambda = 0.665$		CURVE 14 $\lambda = 0.665$		CURVE 20 $\lambda = 0.65$			
1150.	0.564	1167.	0.512	1140.	0.690	1090.	0.600		
1290.	0.565	1247.	0.499	1355.	0.654	1147.	0.722		
1498.	0.548	1439.	0.456	1491.	0.642	1210.	0.705		
CURVE 3 $\lambda = 0.665$		CURVE 9 $\lambda = 0.665$		CURVE 15 $\lambda = 0.665$		CURVE 21 $\lambda = 0.65$			
1303.	0.553	1334.	0.487	1296.	0.669	1410.	0.901		
1508.	0.539	1492.	0.459	1501.	0.643	1490.	0.947		
1669.	0.522	1651.	0.420	1649.	0.634				
CURVE 4 $\lambda = 0.665$		CURVE 10 $\lambda = 0.665$		CURVE 16 $\lambda = 0.665$		1066.	0.600		
1156.	0.575	1181.	0.499	1312.	0.660	1179.	0.850		
1280.	0.572	1504.	0.445			1244.	0.832		
CURVE 5 $\lambda = 0.665$		CURVE 11 $\lambda = 0.665$		CURVE 17 $\lambda = 0.665$		1327.	0.932		
1322.	0.562	1679.	0.428			1374.	0.964		
1518.	0.553					1438.	0.985		
1688.	0.531								
CURVE 6 $\lambda = 0.665$		CURVE 12 $\lambda = 0.665$		CURVE 18 $\lambda = 0.65$					
1148.	0.550	1194.	0.508	1229.	0.512				
1480.	0.567					1349.	0.513		
						1429.	0.552		
						1466.	0.541		
						1513.	0.533		
						1566.	0.512		

c. Angular Spectral Emittance (Wavelength Dependence)

There are no experimental data located in the literature. The recommended values at 293 K tabulated in Table 4-6 and shown in Figure 4-4 are for pickled Titanium Ti-6Al-4V alloy of thickness 40 mil and the incident angle, $\theta = 45^\circ$. These values calculated from the angular spectral reflectance data tabulated in Table 4-12 are considered accurate to within $\pm 15\%$ at reported wavelengths. Unfortunately the authors gave only four data points, so no attempt was made to interpolate their data.

TABLE 4-6. RECOMMENDED ANGULAR SPECTRAL EMITTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ
PICKLED ALLOY	
$T = 293$	
2.8	0.42
3.8	0.37
5.0	0.31
10.6	0.22



d. Normal Spectral Reflectance (Wavelength Dependence)

There are 13 experimental data sets available for the wavelength dependence (2.8-10.6 μm) of the normal spectral reflectance of Titanium Alloy Ti-6Al-4V. These are tabulated in Table 4-9 and shown in Figure 4-6.

(1) 0.032 μm Finish Alloy

The recommended values at 293 K tabulated in Table 4-7 and shown in Figure 4-5 for Titanium Alloy Ti-6Al-4V with 0.032 μm finish are primarily from the investigations of Shipley and Thostesen [T40746]. These values are considered accurate to within $\pm 15\%$ over the entire wavelength range.

(2) Oxidized Titanium Alloy Ti-6Al-4V

The recommended values tabulated in Table 4-7 and shown in Figure 4-5 for oxidized Titanium Alloy Ti-6Al-4V are primarily from the investigation of Grimm and Fannin [A00001] and are for the material which has been heated in air for 15 minutes. These are considered accurate to within $\pm 15\%$ over the entire wavelength range. The values calculated from the normal emittance data of Gravina and Katz [T22613] for similar oxidized Titanium Alloy Ti-6Al-4V are in good agreement with the recommended values.

(3) Anodized Titanium Alloy Ti-6Al-4V

The recommended values tabulated in Table 4-7 and shown in Figure 4-5 for chromic acid anodized surface were calculated from the normal spectral emittance data of Cunningham and Funai [T22613]. These are considered accurate to about $\pm 15\%$ over the entire wavelength range. (See Section 4.1.c and 4.5.a for further details.)

TABLE 4-7. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY TI-6AL-4V (WAVELENGTH DEPENDENCE)

λ	ρ	λ	λ	ρ	λ	λ	ρ
0.032 μm FINISH ANODIZED $T = 293$							
0.4	0.343	2.8	0.202	2.8	0.222	2.8	0.222
0.5	0.361	3.0	0.215	3.0	0.236	3.0	0.236
1.0	0.423	3.5	0.242	3.5	0.267	3.5	0.267
1.5	0.465	3.8	0.253	3.8	0.286	3.8	0.286
2.0	0.497	4.0	0.256	4.0	0.300	4.0	0.300
2.5	0.526	4.5	0.260	4.5	0.328	4.5	0.328
2.8	0.540	5.0	0.262	5.0	0.354	5.0	0.354
3.0	0.553	5.5	0.265	5.5	0.376	5.5	0.376
3.5	0.571	6.0	0.266	6.0	0.397	6.0	0.397
3.8	0.582	6.3	0.270	6.5	0.405	6.5	0.405
4.0	0.589	6.5	0.274	7.0	0.416	7.0	0.416
4.5	0.604	6.6	0.280	7.5	0.420	7.5	0.420
5.0	0.616	6.8	0.309	8.0	0.425	8.0	0.425
5.5	0.626	7.0	0.354	8.5	0.426	8.5	0.426
6.0	0.635	7.2	0.384	9.0	0.428	9.0	0.428
6.5	0.642	7.4	0.396	9.5	0.429	9.5	0.429
7.0	0.649	7.5	0.397	10.0	0.430	10.0	0.430
7.5	0.654	7.6	0.393	10.5	0.430	10.5	0.430
8.0	0.660	7.8	0.354	11.0	0.430	11.0	0.430
8.5	0.665	8.0	0.254	11.5	0.430	11.5	0.430
9.0	0.670	8.2	0.132	12.0	0.430	12.0	0.430
9.5	0.674	8.4	0.085	12.5	0.430	12.5	0.430
10.0	0.678	8.5	0.072	13.0	0.430	13.0	0.430
10.5	0.682	8.7	0.062	13.5	0.430	13.5	0.430
11.0	0.683	9.0	0.066	14.0	0.430	14.0	0.430
11.5	0.692	9.5	0.077	14.5	0.430	14.5	0.430
12.0	0.696	10.5	0.076	15.0	0.430	15.0	0.430
12.5	0.700	11.0	0.071				
13.0	0.705	11.5	0.065				
13.5	0.708	12.0	0.061				
14.0	0.712	12.5	0.060				
14.5	0.716	13.0	0.067				
15.0	0.720	13.5	0.081				




FIGURE 4-5. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE).




TABLE 4-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	A00003	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Rodney Metals, 4 mil.
2	A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
3	A00003	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Rodney metals, 10 mil.
4	A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
5	A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the specimen from curve 3 except sand blasted.
6	A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the specimen from curve 3 except chemically milled.
7	A000C3	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Timet Corp.; 15 mil.
8	A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
9	A00001	Grimm, T.C. and Fannin, E.R.	1972	2.8-10.6	293	Compilation, 125 μin . finish.	
10	A00001	Grimm, T.C. and Fannin, E.R.	1972	2.8-10.6	700	Measurements after being heated in air for 15 min.	
11	A00001	Grimm, T.C. and Fannin, E.R.	1972	2.8-10.6	293	Pickled Ti-6Al-4V; thickness: 40 mil; $\theta = 15^\circ$.	
12	A00001	Grimm, T.C. and Fannin, E.R.	1972	2.8-10.6	293	Similar to the above specimen except heat treated in air at 644 K for one hr.	
13	T40746	Shipley, W.S. and Thorsen, T.O.	1960	0.38-25	300	Nominal composition: "125" finish.	

TABLE 4-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

e. Normal Spectral Reflectance (Temperature Dependence)

There are 10 sets of experimental data available for the temperature dependence of the normal spectral reflectance of Titanium Alloy Ti-6Al-4V under various surface conditions. These are tabulated in Table 4-11 and shown in Figure 4-7. In the absence of sufficient data, no recommendations were made.




FIGURE 4-7. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (TEMPERATURE DEPENDENCE).

TABLE 4-10. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (Temperature Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Rodney Metals, 4 mil.
2 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
3 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Rodney metal, 10 mil.
4 A60003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
5 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the specimen from curve 3 except sand blasted.
6 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the specimen from curve 3 except chemically milled.
7 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Timet Corp.; 15 mil.
8 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
9 A00001	Grimm, T.C. and Fannin, E.R.	1973	10.6	293		Compilation, 125 $\mu\text{ inch}$ finish.
10 A00001	Grimm, T.C. and Fannin, E.R.	1973	10.6	700		Similar to the above specimen, measurements after being heated in air for 15 min.

TABLE 4-11. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

T	ρ	T	ρ
CURVE 1 $\lambda = 10.6$		CURVE 9 $\lambda = 10.6$	
293.	0.800	293.	0.69
CURVE 2 $\lambda = 10.6$		CURVE 10 $\lambda = 10.6$	
293.	0.850	293.	0.43
CURVE 3 $\lambda = 10.6$			
293.	0.650		
CURVE 4 $\lambda = 10.6$			
293.	0.855		
CURVE 5 $\lambda = 10.6$			
293.	0.500		
CURVE 6 $\lambda = 10.6$			
293.	0.355		
CURVE 7 $\lambda = 10.6$			
293.	0.810		
CURVE 8 $\lambda = 10.6$			
293.	0.855		

f. Angular Spectral Reflectance (Wavelength Dependence)

There is only one set of experimental data that is available. This one is tabulated in Table 4-14 and shown in Figure 4-9.

The recommended values tabulated in Table 4-12 and shown in Figure 4-8 are for 40 mil thick pickled Titanium Alloy Ti-6Al-4V with the incident angle, $\theta = 45^\circ$. These values primarily from the investigation of Grimm and Fannin [A00001] are considered accurate to within $\pm 15\%$ at the reported wavelengths.

TABLE 4-12. RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ ')

λ	ρ
PICKLED ALLOY	
$T = 293$	
2.8	0.56
3.8	0.63
5.0	0.69
10.6	0.76




FIGURE 4-8. RECOMMENDED ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY
Ti-6Al-4V (WAVELENGTH DEPENDENCE).




FIGURE 4-9. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE).

TABLE 4-13. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	A00001	Grimm, T.C. and Fanain, E.R.	1972	2.8-10.6	293		Pickled Ti-6Al-4V alloy, 40 mil. thickness; θ = 45°.

TABLE 4-14. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ
CURVE 1	
$T = 293.$	
2.8	0.58
3.6	0.63
5.0	0.69
10.6	0.78

g. Normal Spectral Absorptance (Wavelength Dependence)

There are 16 sets of experimental data available for the wavelength dependence ($2.8 \mu\text{m}$) of the normal spectral absorptance of Titanium Alloy Ti-6Al-4V under various surface conditions. These are tabulated in Table 4-17 and shown in Figure 4-11.

(1) $0.032 \mu\text{m}$ Finish Alloy

The recommended values tabulated in Table 4-15 and shown in Figure 4-10 calculated from the normal spectral emittance data on the identical material are considered accurate to about $\pm 15\%$ over the entire wavelength range (see Section 4.5.a).

(2) Oxidized Titanium Alloy Ti-6Al-4V

The recommended values tabulated in Table 4-15 and shown in Figure 4-10 calculated from the normal spectral emittance data on the identical material are considered accurate to about $\pm 15\%$ over entire wavelength range (see Section 4.5.a).

(3) Anodized Titanium Alloy Ti-6Al-4V

The recommended values for chromic acid anodized surface and tabulated in Table 4-15 and shown in Figure 4-10 calculated from the normal spectral emittance data on the identical material are considered accurate to about $\pm 15\%$ over the entire wavelength region (see Section 4.1.c and 4.5.a).

TABLE 4-15. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE)

λ	α	λ	α	λ	α	λ	α
0.032 μm FINISH ALLOY $T = 293$	0.032 μm FINISH ANODIZED $T = 700$	0.032 μm FINISH OXIDIZED HEATED IN AIR $T = 700$					
0.4	0.657	2.8	0.798	2.8	0.778	2.8	0.778
0.5	0.639	3.0	0.785	3.0	0.764	3.0	0.764
1.0	0.577	3.5	0.758	3.5	0.733	3.5	0.733
1.5	0.535	3.6	0.747	3.6	0.714	3.6	0.714
2.0	0.503	4.0	0.744	4.0	0.700	4.0	0.700
2.5	0.474	4.5	0.740	4.5	0.672	4.5	0.672
2.8	0.460	5.0	0.738	5.0	0.646	5.0	0.646
3.0	0.450	5.5	0.735	5.5	0.624	5.5	0.624
3.5	0.429	6.0	0.734	6.0	0.607	6.0	0.607
3.8	0.410	6.3	0.730	6.5	0.595	6.5	0.595
4.0	0.411	6.5	0.726	7.0	0.584	7.0	0.584
4.5	0.396	6.6	0.720	7.5	0.580	7.5	0.580
5.0	0.384	6.8	0.691	8.0	0.575	8.0	0.575
5.5	0.374	7.0	0.646	8.5	0.574	8.5	0.574
6.0	0.365	7.2	0.616	9.0	0.572	9.0	0.572
6.5	0.358	7.4	0.604	9.5	0.571	9.5	0.571
7.0	0.351	7.5	0.603	10.0	0.570	10.0	0.570
7.5	0.346	7.6	0.607	10.5	0.570	10.5	0.570
8.0	0.340	7.8	0.646	10.6	0.574	10.6	0.574
8.5	0.335	8.0	0.746				
9.0	0.330	8.2	0.868				
9.5	0.326	8.4	0.915				
10.0	0.322	8.5	0.928				
10.5	0.318	8.7	0.938				
10.6	0.317	9.0	0.934				
11.0	0.314	9.5	0.923				
11.5	0.308	10.0	0.920				
12.0	0.304	10.5	0.924				
12.5	0.300	11.0	0.929				
13.0	0.295	11.5	0.935				
13.5	0.292	12.0	0.939				
14.0	0.288	12.5	0.940				
14.5	0.284	13.0	0.933				
15.0	0.280	13.5	0.919				
		14.0	0.903				
		14.5	0.894				
		15.0	0.864				




FIGURE 4-10. RECOMMENDED NORMAL SPECTRAL ABSORBANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE).




FIGURE 4-11. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY
Ti-6Al-4V (WAVELENGTH DEPENDENCE).

TABLE 4-16. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY Ti-6Al-4V (Wavelength Dependence)

Cur. Ref. No.	Author(s) No.	Year 1973	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A30603	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Rodney Metals, 4 mil.
2 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except values for this and curves 4, 6, 8, 10, 12, 14, and 16 are calculated from reflectance data.
3 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Rodney Metals, mechanically polished.
4 A60003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen.
5 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Rodney Metals, 10 mil.
6 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen.
7 A35603	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
8 A00603	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen.
9 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the specimen from curve 3 except chemically milled.
10 A00603	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen.
11 A00603	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the specimen from curve 3 except sand blasted.
12 ACC03	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen.
13 ACC03	Reichman, J. and Leib, K.	1973	10.6	293		Specimen from the Timet Corp.; 15 mil.
14 A00603	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen.
15 ACC03	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen except mechanically polished.
16 A00003	Reichman, J. and Leib, K.	1973	10.6	293		Similar to the above specimen.

TABLE 4-17. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY TZ-6AL-4V (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α)

λ	α	λ	α
CURVE 1 $T = 293.$		CURVE 9 $T = 293.$	
10.6	0.160	10.6	0.140
CURVE 2 $T = 293.$		CURVE 10 $T = 293.$	
10.6	0.230	10.6	0.170
CURVE 3 $T = 293.$		CURVE 11 $T = 293.$	
10.6	0.140	10.6	0.100
CURVE 4 $T = 293.$		CURVE 12 $T = 293.$	
10.6	0.150	10.6	0.500
CURVE 5 $T = 293.$		CURVE 13 $T = 293.$	
10.6	0.120	10.6	0.160
CURVE 6 $T = 293.$		CURVE 14 $T = 293.$	
10.6	0.150	10.6	0.190
CURVE 7 $T = 293.$		CURVE 15 $T = 293.$	
10.6	0.115	10.6	0.130
CURVE 8 $T = 293.$		CURVE 16 $T = 293.$	
10.6	0.145	10.6	0.145

h. Normal Spectral Absorptance (Temperature Dependence)

There is only one set of data located for the temperature dependence (300-800 K) of the normal spectral absorptance of Titanium Alloy Ti-6Al-4V. This is tabulated in Table 4-19 and shown in Figure 4-12. These values were calculated using the Hagen-Ruben relationship. Due to lack of experimental evidence to support these calculations, no recommendations were made.




FIGURE 4-12. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY Ti-6Al-4V (TEMPERATURE DEPENDENCE).

TABLE 4-16. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY Ti-6Al-4V (Temperature Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 E66194	Cunningham, S.S. and Langford, W.T.	1974	10.6	300-800			Calculated from Hagen-Rubens relation.

TABLE 4-19. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF TITANIUM ALLOY Ti-6Al-4V (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α
CURVE 1 $\lambda = 13.6$	
300.	0.136
400.	0.136
500.	0.140
600.	0.141
700.	0.142
800.	0.142

1. Angular Spectral Absorptance (Wavelength Dependence)

There are no experimental data available for this subproperty. The recommended values tabulated in Table 4-20 and shown in Figure 4-13 calculated from the recommended angular spectral emittance for the identical material are considered accurate to within $\pm 15\%$ at the reported wavelengths (see Section 4.5.c).

TABLE 4-20. RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF TITANIUM ALLOY Ti-6Al-4V (WAVELENGTH DEPENDENCE
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α
PICKLED ALLY $T = 293$	
2.8	0.42
3.8	0.37
5.0	0.31
10.6	0.22




FIGURE 4-13. RECOMMENDED ANGULAR SPECTRAL ABSORPTANCE OF TITANIUM ALLOY Ti-6AL-4V (WAVELENGTH DEPENDENCE).

j. Transmittance

Although it is true that metals and alloys in the form of extremely thin films may be transparent for a wide wavelength range, they are opaque if the thickness is greater than several hundred angstroms.

As an aircraft/spacecraft structural material, this alloy is not used in the form of extremely thin films and therefore is opaque; that is, its transmittance is zero.

4.5. Hadfield Manganese Steel

Hadfield manganese steel is an extremely tough nonmagnetic austenitic alloy. It was named after its inventor Sir Robert Abbott Hadfield (1858-1940), an English metallurgist, who was knighted in 1908 for his discovery of this steel in 1883 and many other metallurgical discoveries and inventions. This steel has a nominal composition of 10-14% Mn, 1.0-1.4% C, 0.1-0.3% Si, 0.1% P, and balance Fe. The melting range of this steel is estimated to be about 1470 to 1480 K. This steel is characterized by its high strength, high ductility, and excellent resistance to wear. In the form of castings or of rolled shapes, it serves many industrial requirements economically and has built up an enviable record as the outstanding material for resisting severe service that combines abrasion and heavy impact.

No information on the thermal radiative properties of this or other similar alloy was uncovered from the search of literature. Consequently, tabulation or recommendation of the thermal radiative properties of this alloy is not possible at this time. However, since a metal with thickness greater than several hundred angstroms is opaque, it can be safely stated that the transmittance of this alloy is zero in its bulk form for general applications.

4.6. Aluminum Oxide

The specific type of aluminum oxide for which evaluated data was requested is Wesgo Al-300 which is a dense, vacuum-tight alumina manufactured by the Western Gold and Platinum Company of Belmont, California [A00015]. Wesgo Al-300 contains 97.6% aluminum oxide and has a density of 3.76 g cm^{-3} which is about 95% of the theoretical value, although the manufacturer claims zero porosity. A 1/16 in. flat specimen of this material is white and translucent. The hardness is 75 (Rockwell 45N). The maximum working temperature is 1923 K while the melting point of pure alumina has been reported around 2315 to 2320 K [A00017]. Wesgo Al-300 is made by compacting at pressures higher than conventionally used. Its properties including high abrasion resistance, high thermal conductivity, and excellent dielectric characteristics lead to its use as R.F. windows, high voltage insulators, and vacuum tube envelopes.

A search of the technical literature did not turn up any data on the thermal radiative or optical properties of Wesgo Al-300. Therefore, with no specific data on Wesgo Al-300, no evaluated values can be given for it. However, to give some indication of the thermal radiative properties of alumina it was decided to give evaluated values, where the quantity and quality of data warrants it, for an alumina which has a purity close to Wesgo Al-300. Coors AD 99 is 99% pure aluminum oxide, while Coors AD 96 is 96% pure aluminum oxide and these specific materials are higher and lower in purity, respectively, than the 97.6% purity of Wesgo Al-300. It should be emphasized that any evaluated data for Coors is not a substitute for actual measurements on Wesgo Al-300 and is only given to give an indication of the behavior of another specific alumina. Because evaluated data was requested for Wesgo Al-300, data was generally not extracted for ruby or sapphire.

a. Normal Spectral Emittance (Wavelength Dependence)

A total of 86 sets of experimental data were located for the wavelength dependence of the normal spectral emittance of aluminum oxide as listed in Table 6-3 and shown in Figures 6-1 through 6-6. Curves 1 through 30 are shown in Figures 6-1 and 6-4. Curves 31 through 60 are shown in Figures 6-2 and 6-5. Curves 61 through 86 are shown in Figures 6-3 and 6-6. Specimen characterization and measurement information for the data are given in Table 8-2.

There is no data specifically for Wesgo Al-300, however, there are data for Coors AD 99 and Coors AD 96 which have a purity higher and lower, respectively, compared to Wesgo Al-300. Folweiler [T29570] (curves 22-26) has measured the normal spectral emittance of Coors AD 96. The data was presented in tabular form and for widely spaced

wavelengths leading to the conclusion that giving evaluated values is not justified. Data for Coors AD 99 was presented by Folweiler [T29570] (curves 17-21), Blau, et al. [T16606] (curves 3, 4, and 7), and Blau and Jasperse [T32045] (curve 62). The data for curves 17-20 was presented in tabular form with the remaining curves for Coors AD 99 given in graphical form. Curve 20 at 1423 K gives supporting evidence to curve 21, also at 1423 K, given in graphical form. These two curves form the basis for provisional values for the normal spectral emittance of Coors AD 99 at 1423 K with the values listed in Table 6-1 and shown in Tables 6-1, 6-2, and 6-3. The provisional curve continues only to 11 μm to keep the uncertainty to a 15% value. Curves 4 and 62 for a temperature of 1303 K are very similar to each other and form the basis of the provisional values for Coors AD 99 at 1303 K with the values listed in Table 6-1 and shown in Tables 6-1, 6-2, and 6-3; the uncertainty for this curve is 15%. Beyond 4.8 μm both provisional curves are the same since the stated uncertainty and the curves forming the basis of the provisional values do not justify separate provisional curves.

TABLE 6-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE(COORS AD 99) (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
$T = 1303$		$T = 1303$ (CONT.)		$T = 1303$ (CONT.)		$T = 1423$		$T = 1423$ (CONT.)											
2.0	0.432	5.9	0.926	9.8	0.983	1.0	0.226	5.0	0.798	8.9	0.985	5.0	0.798	8.9	0.985	5.1	0.820	9.0	0.985
2.1	0.436	6.0	0.936	9.9	0.983	1.1	0.226	5.1	0.820	9.0	0.985	5.1	0.820	9.1	0.985	5.2	0.839	9.1	0.985
2.2	0.439	6.1	0.943	10.0	0.982	1.2	0.226	5.2	0.820	9.1	0.985	5.2	0.820	9.2	0.985	5.3	0.857	9.2	0.985
2.3	0.443	6.2	0.950	10.1	0.980	1.3	0.227	5.3	0.820	9.3	0.985	5.3	0.820	9.3	0.985	5.4	0.871	9.3	0.985
2.4	0.448	6.3	0.956	10.2	0.975	1.4	0.228	5.4	0.820	9.4	0.985	5.4	0.820	9.4	0.985	5.5	0.885	9.4	0.985
2.5	0.452	6.4	0.962	10.3	0.976	1.5	0.228	5.5	0.820	9.5	0.985	5.5	0.820	9.5	0.985	5.6	0.897	9.5	0.985
2.6	0.457	6.5	0.966	10.4	0.974	1.6	0.229	5.6	0.820	9.6	0.985	5.6	0.820	9.6	0.985	5.7	0.908	9.6	0.985
2.7	0.462	6.6	0.970	10.5	0.970	1.7	0.230	5.7	0.820	9.7	0.985	5.7	0.820	9.7	0.985	5.8	0.918	9.7	0.985
2.8	0.467	6.7	0.974	10.6	0.966	1.8	0.232	5.8	0.820	9.8	0.985	5.8	0.820	9.8	0.985	5.9	0.926	9.8	0.985
2.9	0.472	6.8	0.976	10.7	0.962	1.9	0.233	5.9	0.820	9.9	0.985	5.9	0.820	9.9	0.985	6.0	0.936	9.9	0.985
3.0	0.476	6.9	0.978	10.8	0.957	2.0	0.235	6.0	0.820	10.0	0.985	6.0	0.820	10.0	0.985	6.1	0.943	10.0	0.985
3.1	0.484	7.0	0.980	10.9	0.951	2.1	0.236	6.1	0.820	10.1	0.985	6.1	0.820	10.1	0.985	6.2	0.950	10.1	0.985
3.2	0.490	7.1	0.981	11.0	0.943	2.3	0.241	6.2	0.820	10.2	0.985	6.2	0.820	10.2	0.985	6.3	0.956	10.2	0.985
3.3	0.498	7.2	0.982	11.2	0.983	2.4	0.244	6.3	0.820	10.3	0.985	6.3	0.820	10.3	0.985	6.4	0.962	10.3	0.985
3.4	0.505	7.3	0.983	11.3	0.984	2.5	0.246	6.4	0.820	10.4	0.985	6.4	0.820	10.4	0.985	6.5	0.966	10.4	0.985
3.5	0.513	7.4	0.984	11.4	0.985	2.6	0.250	6.5	0.820	10.5	0.985	6.5	0.820	10.5	0.985	6.6	0.970	10.5	0.985
3.6	0.522	7.5	0.985	11.5	0.985	2.7	0.254	6.6	0.820	10.6	0.985	6.6	0.820	10.6	0.985	6.7	0.974	10.6	0.985
3.7	0.532	7.6	0.985	11.6	0.985	2.8	0.259	6.7	0.820	10.7	0.985	6.7	0.820	10.7	0.985	6.8	0.976	10.7	0.985
3.8	0.543	7.7	0.985	11.7	0.985	2.9	0.265	6.8	0.820	10.8	0.985	6.8	0.820	10.8	0.985	6.9	0.978	10.8	0.985
3.9	0.556	7.8	0.986	11.8	0.986	3.0	0.274	6.9	0.820	10.9	0.985	6.9	0.820	10.9	0.985	7.0	0.980	10.9	0.985
4.0	0.570	7.9	0.986	11.9	0.986	3.1	0.283	7.0	0.820	11.0	0.985	7.0	0.820	11.0	0.985	7.1	0.981	11.0	0.985
4.1	0.586	8.0	0.986	12.0	0.986	3.2	0.294	7.1	0.820	11.1	0.985	7.1	0.820	11.1	0.985	7.2	0.982	11.1	0.985
4.2	0.604	8.1	0.986	12.1	0.986	3.3	0.306	7.2	0.820	11.2	0.985	7.2	0.820	11.2	0.985	7.3	0.983	11.2	0.985
4.3	0.625	8.2	0.986	12.2	0.986	3.4	0.320	7.3	0.820	11.3	0.985	7.3	0.820	11.3	0.985	7.4	0.984	11.3	0.985
4.4	0.649	8.3	0.986	12.3	0.986	3.5	0.336	7.4	0.820	11.4	0.985	7.4	0.820	11.4	0.985	7.5	0.985	11.4	0.985
4.5	0.674	8.4	0.986	12.4	0.986	3.6	0.354	7.5	0.820	11.5	0.985	7.5	0.820	11.5	0.985	7.6	0.985	11.5	0.985
4.6	0.699	8.5	0.985	12.5	0.985	3.7	0.376	7.6	0.820	11.6	0.985	7.6	0.820	11.6	0.985	7.7	0.985	11.6	0.985
4.7	0.725	8.6	0.985	12.6	0.985	3.8	0.399	7.7	0.820	11.7	0.985	7.7	0.820	11.7	0.985	7.8	0.985	11.7	0.985
4.8	0.746	8.7	0.985	12.7	0.985	3.9	0.428	7.8	0.820	11.8	0.985	7.8	0.820	11.8	0.985	7.9	0.986	11.8	0.985
4.9	0.774	8.8	0.985	12.8	0.985	4.0	0.458	7.9	0.820	11.9	0.985	7.9	0.820	11.9	0.985	8.0	0.486	11.9	0.985
5.0	0.798	8.9	0.985	12.9	0.985	4.1	0.486	8.0	0.820	12.0	0.985	8.0	0.820	12.0	0.985	8.1	0.522	12.0	0.985
5.1	0.820	9.0	0.985	13.0	0.985	4.2	0.522	8.1	0.820	12.1	0.985	8.1	0.820	12.1	0.985	8.2	0.560	12.1	0.985
5.2	0.839	9.1	0.985	13.1	0.985	4.3	0.560	8.2	0.820	12.2	0.985	8.2	0.820	12.2	0.985	8.3	0.600	12.2	0.985
5.3	0.857	9.2	0.985	13.2	0.985	4.4	0.600	8.3	0.820	12.3	0.985	8.3	0.820	12.3	0.985	8.4	0.640	12.3	0.985
5.4	0.871	9.3	0.985	13.3	0.985	4.5	0.640	8.4	0.820	12.4	0.985	8.4	0.820	12.4	0.985	8.5	0.678	12.4	0.985
5.5	0.885	9.4	0.985	13.4	0.985	4.6	0.678	8.5	0.820	12.5	0.985	8.5	0.820	12.5	0.985	8.6	0.714	12.5	0.985
5.6	0.897	9.5	0.984	13.5	0.984	4.7	0.714	8.6	0.820	12.6	0.985	8.6	0.820	12.6	0.985	8.7	0.746	12.6	0.985
5.7	0.908	9.6	0.984	13.6	0.984	4.8	0.746	8.7	0.820	12.7	0.985	8.7	0.820	12.7	0.985	8.8	0.774	12.7	0.985
5.8	0.918	9.7	0.984	13.7	0.984	4.9	0.774	8.8	0.820	12.8	0.985	8.8	0.820	12.8	0.985	8.9	0.805	12.8	0.985




FIGURE 6-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).




FIGURE 6-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).




FIGURE 6-3. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).




FIGURE 6-4. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).




FIGURE 6-5. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).




FIGURE 6-6. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).

TABLE 6-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMMITTANCE OF ALUMINUM OXIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T16606	Blau, H.H., Jr., Marsh, J.B., Martin, W.S., Jaspers, J.R., and Chaffee, E.	1960	2.0-14	873	Coors AD 85	85 Al ₂ O ₃ ; measured in air; measurements made with Perkin-Elmer Model 112c infrared spectrometer with sodium chloride prism; data from figure; θ' = 0°; reported error ±4%.
2 T16606	Blau, H.H., Jr., et al.	1960	1.0-14	1303	Coors AD 85	Similar to the above specimen.
3 T16605	Blau, H.H., Jr., et al.	1960	2.0-14	873	Coors AD 99	Similar to the above specimen except 99 Al ₂ O ₃ .
4 T16606	Blau, H.H., Jr., et al.	1960	2.0-14	1303	Coors AD 99	Similar to the above specimen.
5 T16606	Blau, H.H., Jr., et al.	1960	2.0-14	873	Norton TWA No. 2, A402	Similar to the above specimen except 98.56 Al ₂ O ₃ .
6 T16606	Blau, H.H., Jr., et al.	1960	2.0-14	1323	Norton TWA No. 2, A402	Similar to the above specimen.
7 T16606	Blau, H.H., Jr., et al.	1960	4.2-12	560	Coors AD 99	99 Al ₂ O ₃ ; specimen heated in air; solar furnace used to measure spectral reflectance; data not accurate; data from figure; θ' = 0°.
8 T16606	Blau, H.H., Jr., et al.	1960	4.2-12	560	Norton TWA No. 2, A402	Similar to the above specimen except 98.56 Al ₂ O ₃ .
9 T25922	Grenis, A.F. and Levitin, A.P.	1965	1.0-10	1300		98.55 Al ₂ O ₃ , 0.58 SiO ₂ , 0.31 Na ₂ O, 0.23 MgO, 0.19 CaO, 0.10 Fe ₂ O ₃ , and 0.04 TiO ₂ ; gamma type crystal form; from Norton Refactories; surface roughness 225 μ in.; flame sprayed coating 12 mils thick on mild steel base; density of coating 3.3 g cm ⁻³ , porosity of coating 8-12%; measured in vacuum of 35 to 50 μ pressure; θ' = 0°.
10 T31922	Grenis, A.F. and Levitin, A.P.	1965	1.0-10	1300		Similar to the above specimen except surface finished with polishing papers; flame sprayed coating 15 mils thick on mild steel base.
11 T21922	Stemp, W.S. and Wade, W.R.	1962	1.0-15	923	Norton 5190 alumina	Smooth values from figure; θ' ~ 0°; reported error ±5%.
12 T29570	Folweller, R.C.	1964	1-14	814	Coors AD 995 alumina	99.5 Al ₂ O ₃ ; rotating specimen in furnace used in conjunction with Baird-Atomic infrared spectrometer, model NK-1A, for emittance determination; θ' ~ 0°; reported error 10%.
13 T29570	Folweller, R.C.	1964	1-14	1055	Coors AD 995 alumina	The above specimen.
14 T29570	Folweller, R.C.	1964	1-14	1227	Coors AD 995 alumina	The above specimen.
15 T29570	Folweller, R.C.	1964	1-14	1410	Coors AD 995 alumina	The above specimen.
16 T29570	Folweller, R.C.	1964	1-14	1592	Coors AD 995 alumina	The above specimen.
17 T29570	Folweller, R.C.	1964	1-14	813	Coors AD 95 alumina	Similar to the above specimen except 99 Al ₂ O ₃ .
18 T29570	Folweller, R.C.	1964	1-14	1053	Coors AD 99 alumina	The above specimen.

TABLE 6-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
19 T29570	Folweiler, R.C.	1964	1-14	1188	Coors AD 99 alumina	The above specimen.
20 T29570	Folweiler, R.C.	1964	1-14	1423	Coors AD 99 alumina	The above specimen.
21 T29570	Folweiler, R.C.	1964	1.0-15	1423	Coors AD 99 alumina	Similar to the above specimen except smooth values from figure.
22 T29570	Folweiler, R.C.	1964	1-14	822	Coors AD 96 alumina	96 Al_2O_3 ; $\theta \sim 0^\circ$; reported error, $\pm 10\%$.
23 T29570	Folweiler, R.C.	1964	1-14	1063	Coors AD 96 alumina	The above specimen.
24 T29570	Folweiler, R.C.	1964	1-14	1183	Coors AD 96 alumina	The above specimen.
25 T29570	Folweiler, R.C.	1964	1-14	1401	Coors AD 96 alumina	The above specimen.
26 T29570	Folweiler, R.C.	1964	1-14	1526	Coors AD 96 alumina	The above specimen.
27 T29570	Folweiler, R.C.	1964	1-14	813	Coors AD 94 alumina	94 Al_2O_3 ; rotating specimen in furnace used in conjunction with Baird-Atomic infrared spectrometer, model NK-1A, for emittance determination; $\theta \sim 0^\circ$; reported error $\pm 10\%$.
28 T29570	Folweiler, R.C.	1964	1-14	1035	Coors AD 94 alumina	The above specimen.
29 T29570	Folweiler, R.C.	1964	1-14	1220	Coors AD 94 alumina	The above specimen.
30 T29570	Folweiler, R.C.	1964	1-14	1413	Coors AD 94 alumina	The above specimen.
31 T29570	Folweiler, R.C.	1964	1-14	1591	Coors AD 94 alumina	The above specimen.
32 T29570	Folweiler, R.C.	1964	1-14	811	Coors AD 85 alumina	Similar to the above specimen except 65 Al_2O_3 .
33 T29570	Folweiler, R.C.	1964	1-14	1053	Coors AD 85 alumina	The above specimen.
34 T29570	Folweiler, R.C.	1964	1-14	1208	Coors AD 85 alumina	The above specimen.
35 T29570	Folweiler, R.C.	1964	1-14	1413	Coors AD 85 alumina	The above specimen.
36 T29570	Folweiler, R.C.	1964	1-14	1513	Coors AD 85 alumina	The above specimen.
37 T29570	Folweiler, R.C.	1964	1-14	813	Coors AD 96 alumina	1% CoCO_3 ; rotating specimen in furnace used in conjunction with Baird-Atomic infrared spectrometer, model NK-1A, for emittance determination; $\theta \sim 0^\circ$; reported error $\pm 10\%$.

TABLE 6-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (w' ght percent), Specifications, and Remarks
38 T29570	Folweiler, R.C.	1964	1-14	1053	Coors AD 96 alumina	The above specimen.
39 T29570	Folweiler, R.C.	1964	1-14	1188	Coors AD 96 alumina	The above specimen.
40 T29570	Folweiler, R.C.	1964	1-14	1423	Coors AD 96 alumina	The above specimen.
41 T29570	Folweiler, R.C.	1964	1-14	822	McDaniel AP-35 alumina	9% Al_2O_3 ; slip cast; rotating specimen in furnace used in conjunction with Baird-Atomic infrared spectrometer, model NK-1A, for emittance determinations; $\theta \sim 0^\circ$; reported error 10%.
42 T29570	Folweiler, R.C.	1964	1-14	1063	McDaniel AP-35 alumina	The above specimen.
43 T29570	Folweiler, R.C.	1964	1-14	1183	McDaniel AP-35 alumina	The above specimen.
44 T29570	Folweiler, R.C.	1964	1-14	1401	McDaniel AP-35 alumina	The above specimen.
45 T29570	Folweiler, R.C.	1964	1-14	1523	McDaniel AP-35 alumina	The above specimen.
46 T29570	Folweiler, R.C.	1964	1-14	833	McDaniel AP-35 alumina	Similar to the above specimen except isostatically pressed.
47 T29570	Folweiler, R.C.	1964	1-14	1037	McDaniel AP-35 alumina	The above specimen.
48 T29570	Folweiler, R.C.	1964	1-14	1298	McDaniel AP-35 alumina	The above specimen.
49 T29570	Folweiler, R.C.	1964	1-14	1395	McDaniel AP-35 alumina	The above specimen.
50 T29570	Folweiler, R.C.	1964	1-14	1572	McDaniel AP-35 alumina	The above specimen; value given in document at 2 μm was 0.9, which is probably 22 error, 0.09 presumed.
51 T29570	Folweiler, R.C.	1964	1-14	814	McDaniel AV-30 alumina	96% Al_2O_3 ; vitrified alumina; rotating specimen in furnace used in conjunction with Baird-Atomic Infrared spectrometer, model NK-1A, for emittance determination; $\theta \sim 0^\circ$, reported error 10%.
52 T29570	Folweiler, R.C.	1964	1-14	1053	McDaniel AV-30 alumina	The above specimen.
53 T29570	Folweiler, R.C.	1964	1-14	1125	McDaniel AV-30 alumina	The above specimen.
54 T29570	Folweiler, R.C.	1964	1-14	1408	McDaniel AV-30 alumina	The above specimen.
55 T29570	Folweiler, R.C.	1964	1-14	1592	McDaniel AV-50 alumina	The above specimen.
56 T29570	Folweiler, R.C.	1964	1-14	813	GE Lucalox alumina	Cold-pressed and sintered; MgO added to control grain growth; rotating specimen in furnace used in conjunction with Baird-Atomic infrared spectrometer, model NK-1A, for emittance determination; $\theta \sim 0^\circ$, reported error 10%.

TABLE 6-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
57 T29570	Fowler, R. C.	1964	1-14	1034	GE Lucalox alumina	The above specimen.
58 T29570	Fowler, R. C.	1964	1-14	1220	GE Lucalox alumina	The above specimen.
59 T29570	Fowler, R. C.	1964	1-14	1413	GE Lucalox alumina	The above specimen.
60 T29570	Fowler, R. C.	1964	1-14	1595	GE Lucalox alumina	The above specimen.
61 T32645	Blaau, H.H., Jr., and Jasperse, J.R.	1964	0.92-14	1303	Coors AD 85	85 Al_2O_3 ; ultrasonically machined; measured in air; $\theta^* = 0^\circ$; reported error $\pm 4\%$.
62 T32645	Blaau, H.H., Jr., and Jasperse, J.R.	1964	2.0-14	1303	Coors AD 99	Similar to the above specimen except 99 Al_2O_3 .
63 T32645	Blaau, H.H., Jr., and Jasperse, J.R.	1964	2.1-14	1323	Norton TWA No. 2; A402	Similar to the above specimen except: 96.5 Al_2O_3 .
64 T38726	Clark, H. E.	1965	2-14	1400		Rotating specimen method with hollow cylinder of 7.94 mm wall thickness and diameter of 2.5 cm rotated at 100 rpm in front of a water cooled viewing port; separation distance between specimen and viewing port 0.127 mm; $\theta^* = 0^\circ$.
65 T38726	Clark, H. E.	1965	2-14	1400		Similar to the above specimen except separation distance between specimen and viewing port 0.406 mm.
66 T48368	Richmond, J.C.	1966	1.0-15	1073	AD-5 alumina	Measured at NBS by rotating cylinder method; smooth values from figure; measurement temperature not given explicitly; 1073 K assigned because that figure mentioned is a related context; $\theta^* = 0^\circ$.
67 T48368	Richmond, J.C.	1966	1.0-15	1073	AD-5 alumina	The above specimen except grit blasted.
68 T41606	Clark, H. E. and Moore, D.G.	1966	1.0-15	1600		>99 pure, 0.40 Fe_2O_3 , 0.10 SiO_2 , 0.07 CaO , and 0.02 Na_2O ; porosity 30 percent by volume; polycrystal; cylinder, 0.1375 in. wall thickness; outer surface smooth but not polished; sintered at 1655 K for 27 hr; average of two readings on each of three specimens; rotating specimen method used; $\theta^* = 0^\circ$.
69 T41606	Clark, H. E. and Moore, D.G.	1966	1.0-15	1400		The above specimen.
70 T41606	Clark, H. E. and Moore, D.G.	1966	1.0-15	1200		The above specimen.
71 T50298	Lewis, B.W., Wade, W.R., Stemp, W.S., and Progar, D.J.	1966	1.0-15	1255		Al_2O_3 pure slab; 8.13 mm thick; smooth values from figure; $\theta^* = 0^\circ$.
72 T37398	Schattz, E.A., Counts, C.R., III, and Burks, T.L.	1964	1.0-15	885		99.9 pure powder; from Linde Co.; powder 1 μm particle size; sintered 2 hr at 2023 K; measurement made with help of Baird-Atomic Model NK-1 infrared double beam spectrophotometer; smooth values from figure; $\theta^* \sim 0^\circ$; reported error $\pm 5\%$.
73 T37398	Schattz, E.A., et al.	1364	1.0-15	993		The above specimen.
74 T37398	Schattz, E.A., et al.	1564	1.0-15	1148		The above specimen.
75 T37398	Schattz, E.A., et al.	1964	1.0-15	1273		The above specimen.

TABLE 6-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMISSANCE OF ALUMINUM OXIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
76 T37398	Schatz, E. A., Counts, C. R., III, and Burks, T. L.	1964	1.0-15	373		The above specimens; calculated from spectral reflectance.
77 T35840	Schatz, E. A., Alvarez, G. H., Counts, C. R., III, and Hopke, M. A.	1965	1.0-15	1273	Sintered 1 hr at 1973 K; smooth values from figure; $\theta^* = 0^\circ$.	
78 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		The above specimen except heated at 1273 K in measuring apparatus for 1 hr total in order to study emittance as a function of time of heating at 1273 K.
79 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		The above specimen except heated at 1273 K in measuring apparatus for 2 hr total.
80 T35840	Schatz, E. A., et al.	1965	1.0-15	1273	/	The above specimen except heated at 1273 K in measuring apparatus for 4 hr total.
81 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		Sintering conditions: 1.5 hr at 1273 K; after each sintering operation density measured by mercury displacement; density 1.58 g cm^{-3} ; $\theta^* = 0^\circ$.
82 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		The above specimen with additional 2 hr at 1373 K (to study effect of sintering, specimen removed from apparatus between measurements and heated at increasingly higher temperature) and density 1.60 g cm^{-3} .
83 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		The above specimen with additional 2 hr at 1473 K and density of 1.65 g cm^{-3} .
84 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		The above specimen with additional 2 hr at 1573 K and density of 1.71 g cm^{-3} .
85 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		The above specimen with additional 2 hr at 1673 K and density of 1.77 g cm^{-3} .
86 T35840	Schatz, E. A., et al.	1965	1.0-15	1273		The above specimen with additional 2 hr at 1923 K and density of 3.34 g cm^{-3} .

TABLE II-3. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)

TABLE 6-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM CXICE (WAVELLENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	CURVE 12 $T = 614.$				CURVE 15 (CONT.)				CURVE 16 (CONT.)				CURVE 21 (CONT.)				CURVE 24 $T = 1183.$				CURVE 27 (CONT.)			
1.	0.55	4.	0.39	14.	0.64	7.00	0.983	1.	0.41	4.	0.43	5.	0.76	1.	0.41	4.	0.43	5.	0.76	8.	0.96	1.	0.32		
2.	0.27	5.	0.77	15.	0.97	CURVE 19 $T = 1188.$	8.00	1.000	2.	0.33	5.	0.76	8.	0.96	2.	0.33	5.	0.76	8.	0.96	11.	0.91	3.	0.37	
3.	0.20	6.	0.97	16.	0.94		9.03	1.000	3.	0.34	5.	0.76	11.	0.91	3.	0.34	5.	0.76	8.	0.96	14.	0.67	4.	0.27	
4.	0.31	7.	0.59	17.	0.59		10.0	0.996	4.	0.45	5.	0.69	11.	0.91	4.	0.45	5.	0.69	8.	0.96	14.	0.67	5.	0.27	
5.	0.69	8.	0.98	18.	1.0	CURVE 18 $T = 1592.$	11.0	0.948	5.	0.45	5.	0.69	11.	0.91	5.	0.45	5.	0.69	8.	0.96	11.	0.91	6.	0.27	
6.	0.98	9.	0.98	19.	1.0		12.0	0.799	6.	0.98	5.	0.69	11.	0.91	6.	0.98	5.	0.69	8.	0.96	11.	0.91	7.	0.27	
11.	0.83	10.	0.83	20.	1.0		12.9	0.739	7.	0.98	5.	0.69	11.	0.91	7.	0.98	5.	0.69	8.	0.96	11.	0.91	8.	0.27	
14.	0.57	11.	0.31	21.	0.29		13.7	0.640	8.	0.95	5.	0.69	11.	0.91	8.	0.95	5.	0.69	8.	0.96	11.	0.91	9.	0.27	
15.	0.57	12.	0.23	22.	0.26		14.0	0.631	9.	0.98	5.	0.69	11.	0.91	9.	0.98	5.	0.69	8.	0.96	11.	0.91	10.	0.27	
16.	0.57	13.	0.21	23.	0.17		14.5	0.639	10.	0.98	5.	0.69	11.	0.91	10.	0.98	5.	0.69	8.	0.96	11.	0.91	11.	0.27	
17.	0.40	14.	0.44	24.	0.39		15.0	0.662	11.	0.94	5.	0.69	11.	0.91	11.	0.94	5.	0.69	8.	0.96	11.	0.91	12.	0.27	
18.	0.40	15.	0.40	25.	0.39		15.5	0.662	12.	0.94	5.	0.69	11.	0.91	12.	0.94	5.	0.69	8.	0.96	11.	0.91	13.	0.27	
19.	0.21	16.	0.59	26.	0.59		16.0	0.662	13.	0.94	5.	0.69	11.	0.91	13.	0.94	5.	0.69	8.	0.96	11.	0.91	14.	0.27	
20.	0.19	17.	0.96	27.	0.96		16.5	0.662	14.	0.94	5.	0.69	11.	0.91	14.	0.94	5.	0.69	8.	0.96	11.	0.91	15.	0.27	
21.	0.35	18.	0.94	28.	0.94		17.0	0.662	15.	0.94	5.	0.69	11.	0.91	15.	0.94	5.	0.69	8.	0.96	11.	0.91	16.	0.27	
22.	0.72	19.	0.62	29.	0.62		17.5	0.662	16.	0.94	5.	0.69	11.	0.91	16.	0.94	5.	0.69	8.	0.96	11.	0.91	17.	0.27	
23.	0.98	20.	0.96	30.	0.96		18.0	0.662	17.	0.94	5.	0.69	11.	0.91	17.	0.94	5.	0.69	8.	0.96	11.	0.91	18.	0.27	
24.	0.35	21.	0.94	31.	0.94		18.5	0.662	18.	0.94	5.	0.69	11.	0.91	18.	0.94	5.	0.69	8.	0.96	11.	0.91	19.	0.27	
25.	0.72	22.	0.94	32.	0.94		19.0	0.662	19.	0.94	5.	0.69	11.	0.91	19.	0.94	5.	0.69	8.	0.96	11.	0.91	20.	0.27	
26.	0.98	23.	0.96	33.	0.96		19.5	0.662	20.	0.94	5.	0.69	11.	0.91	20.	0.94	5.	0.69	8.	0.96	11.	0.91	21.	0.27	
27.	0.35	24.	0.96	34.	0.96		20.0	0.662	21.	0.94	5.	0.69	11.	0.91	21.	0.94	5.	0.69	8.	0.96	11.	0.91	22.	0.27	
28.	0.75	25.	0.96	35.	0.96		20.5	0.662	22.	0.94	5.	0.69	11.	0.91	22.	0.94	5.	0.69	8.	0.96	11.	0.91	23.	0.27	
29.	0.97	26.	0.96	36.	0.96		21.0	0.662	23.	0.94	5.	0.69	11.	0.91	23.	0.94	5.	0.69	8.	0.96	11.	0.91	24.	0.27	
30.	0.97	27.	0.96	37.	0.96		21.5	0.662	24.	0.94	5.	0.69	11.	0.91	24.	0.94	5.	0.69	8.	0.96	11.	0.91	25.	0.27	
31.	0.92	28.	0.96	38.	0.96		22.0	0.662	25.	0.94	5.	0.69	11.	0.91	25.	0.94	5.	0.69	8.	0.96	11.	0.91	26.	0.27	
32.	0.66	29.	0.59	39.	0.59		22.5	0.662	26.	0.94	5.	0.69	11.	0.91	26.	0.94	5.	0.69	8.	0.96	11.	0.91	27.	0.27	
33.	0.37	30.	0.18	40.	0.18		23.0	0.662	27.	0.94	5.	0.69	11.	0.91	27.	0.94	5.	0.69	8.	0.96	11.	0.91	28.	0.27	
34.	0.75	31.	0.18	41.	0.18		23.5	0.662	28.	0.94	5.	0.69	11.	0.91	28.	0.94	5.	0.69	8.	0.96	11.	0.91	29.	0.27	
35.	0.97	32.	0.18	42.	0.18		24.0	0.662	29.	0.94	5.	0.69	11.	0.91	29.	0.94	5.	0.69	8.	0.96	11.	0.91	30.	0.27	
36.	0.97	33.	0.18	43.	0.18		24.5	0.662	30.	0.94	5.	0.69	11.	0.91	30.	0.94	5.	0.69	8.	0.96	11.	0.91	31.	0.27	
37.	0.97	34.	0.18	44.	0.18		25.0	0.662	31.	0.94	5.	0.69	11.	0.91	31.	0.94	5.	0.69	8.	0.96	11.	0.91	32.	0.27	
38.	0.97	35.	0.18	45.	0.18		25.5	0.662	32.	0.94	5.	0.69	11.	0.91	32.	0.94	5.	0.69	8.	0.96	11.	0.91	33.	0.27	
39.	0.97	36.	0.18	46.	0.18		26.0	0.662	33.	0.94	5.	0.69	11.	0.91	33.	0.94	5.	0.69	8.	0.96	11.	0.91	34.	0.27	
40.	0.97	37.	0.18	47.	0.18		26.5	0.662	34.	0.94	5.	0.69	11.	0.91	34.	0.94	5.	0.69	8.	0.96	11.	0.91	35.	0.27	
41.	0.97	38.	0.18	48.	0.18		27.0	0.662	35.	0.94	5.	0.69	11.	0.91	35.	0.94	5.	0.69	8.	0.96	11.	0.91	36.	0.27	
42.	0.97	39.	0.18	49.	0.18		27.5	0.662	36.	0.94	5.	0.69	11.	0.91	36.	0.94	5.	0.69	8.	0.96	11.	0.91	37.	0.27	
43.	0.97	40.	0.18	50.	0.18		28.0	0.662	37.	0.94	5.	0.69	11.	0.91	37.	0.94	5.	0.69	8.	0.96	11.	0.91	38.	0.27	
44.	0.97	41.	0.18	51.	0.18		28.5	0.662	38.	0.94	5.	0.69	11.	0.91	38.	0.94	5.	0.69	8.	0.96	11.	0.91	39.	0.27	
45.	0.97	42.	0.18	52.	0.18		29.0	0.662	39.	0.94	5.	0.69	11.	0.91	39.	0.94	5.	0.69	8.	0.96	11.	0.91	40.	0.27	
46.	0.97	43.	0.18	53.	0.18		29.5	0.662	40.	0.94	5.	0.69	11.	0.91	40.	0.94	5.	0.69	8.	0.96	11.	0.91	41.	0.27	
47.	0.97	44.	0.18	54.	0.18		30.0	0.662	41.	0.94	5.	0.69	11.	0.91	41.	0.94	5.	0.69	8.	0.96	11.	0.91	42.	0.27	
48.	0.97	45.	0.18	55.	0.18		30.5	0.662	42.	0.94	5.	0.69	11.	0.91	42.	0.94	5.	0.69	8.	0.96	11.	0.91	43.	0.27	
49.	0.97	46.	0.18	56.	0.18		31.0	0.662	43.	0.94	5.	0.69	11.	0.91	43.	0.94	5.	0.69	8.	0.96	11.	0.91	44.	0.27	
50.	0.97	47.	0.18	57.	0.18		31.5	0.662	44.	0.94	5.	0.69	11.	0.91	44.	0.94	5.	0.69	8.	0.96	11.	0.91	45.	0.27	
51.	0.97	48.	0.18	58.	0.18		32.0	0.662	45.	0.94	5.	0.69	11.	0.91	45.	0.94	5.	0.69	8.	0.96	11.	0.91	46.	0.27	
52.	0.97	49.	0.18	59.	0.18		32.5	0.662	46.	0.94	5.	0.69	11.	0.91	46.	0.94	5.	0.69	8.	0.96	11.	0.91	47.	0.27	
53.	0.97	50.	0.18	60.	0.18		33.0	0.662	47.	0.94	5.	0.69	11.	0.91	47.	0.94	5.	0.69	8.	0.96	11.	0.91	48.	0.27	
54.	0.97	51.	0.18	61.	0.18		33.5	0.662	48.	0.94	5.	0.69	11.	0.91	48.	0.94	5.	0.69	8.	0.96	11.	0.91	49.	0.27	
55.	0.97	52.	0.18	62.	0.18		34.0	0.662	49.	0.94	5.	0.69	11.	0.91	49.	0.94	5.	0.69	8.	0.96	11.	0.91	50.	0.27	
56.	0.97	53.	0.18	63.	0.18		34.5	0.662	50.	0.94	5.	0.69	11.	0.91	50.	0.94	5.	0.69	8.	0.96	11.	0.91	51.	0.27	
57.	0.97	54.	0.18	64.	0.18		35.0	0.662	51.	0.94	5.	0.69	11.	0.91	51.	0.94	5.	0.69	8.	0.96	11.	0.91	52.	0.27	
58.	0.97	55.	0.18	65.	0.18		35.5	0.662	52.	0.94	5.	0.69	11.	0.91	52.	0.94	5.	0.69	8.	0.96	11.	0.91	53.	0.27	
59.	0.97	56.	0.18	66.	0.18		36.0	0.662	53.	0.94	5.	0.69	11.	0.91	53.	0.94	5.	0.69	8.	0.96	11.	0.91	54.	0.27	
60.	0.97	57.	0.18	67.	0.18		36.5	0.662	54.	0.94	5.	0.69	11.	0.91	54.	0.94	5.	0.69	8.	0.96	11.	0.91	55.	0.27	
61.	0.97	58.	0.18	68.	0.18		37.0	0.662	55.	0.94	5.	0.69	11.	0.91	55.	0.94	5.	0.69	8.	0.96	11.	0.91	56.	0.27	
62.	0.97	59.	0.18	69.	0.18		37.5	0.662	56.	0.94	5.	0.69	11.	0.91	56.	0.94	5.	0.69	8.	0.96	11.	0.91	57.	0.27	
63.	0.97	60.	0.18	70.	0.18		38.0	0.662	57.	0.94	5.	0.69	11.	0.91	57.	0.94	5.	0.69	8.	0.96	11.	0.91	58.	0.27	
64.	0.97	61.	0.18	71.	0.18		38.5	0.662	58.	0.94	5.	0.69	11.	0.91	58.	0.94	5.	0.69	8.	0.96	11.	0.91	59.	0.27	
65.	0.97	62.	0.18	72.	0.18		39.0	0.662	59.	0.94	5.	0.69													

TABLE 6-3. EXPERIMENTAL NORMAL SP²CITAL EMISSION^E OF ALUMINUM OXIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)

[WAVELENGTH, λ , μm ; TEMPERATURE, T, K; EMITTANCE, ϵ]

TABLE 6-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
CURVE 50 (CONT.)																			
14.	0.57																		
		CURVE 54. T = 1408.																	
1.		0.34		4.		0.90		14.		0.54		2.07		0.420		2.32		0.223	
CURVE 51 T = 814.		2.	0.43	5.	0.94							2.56		0.447		2.52		0.231	
		3.	0.40	8.	0.95							3.97		0.504		2.66		0.251	
		4.	0.49	11.	0.90							4.99		0.763		2.73		0.397	
1.	0.30			5.	0.78							6.09		0.930		2.78		0.421	
2.	0.47			8.	0.97							7.68		0.972		2.83		0.431	
3.	0.49			11.	0.93							8.13		0.964		2.92		0.422	
				14.	0.60							9.9		0.981		3.01		0.391	
												10.1		0.983		3.19		0.353	
1.	0.30			2.	0.85							11.0		0.912		3.31		0.336	
5.	0.76			3.	0.95							12.0		0.720		3.61		0.384	
8.	1.33			4.	0.89							13.0		0.667		3.81		0.436	
11.	0.95			5.	0.85							14.0		0.633		4.16		0.491	
14.	0.58			6.	0.95							15.0		0.545		4.13		0.545	
				7.	0.95							16.0		0.633		4.21		0.602	
				8.	0.95							17.0		0.988		4.21		0.595	
				9.	0.89							18.0		0.941		4.46		0.652	
				10.	0.95							19.0		0.850		4.60		0.732	
				11.	0.95							20.		0.492		4.86		0.545	
				12.	0.95							21.		0.991		5.19		0.888	
				13.	0.95							22.		0.988		5.49		0.927	
				14.	0.50							23.		0.960		5.63		0.959	
				15.	0.66							24.		0.667		5.83		0.932	
				16.	0.45							25.		0.969		6.03		0.964	
				17.	0.55							26.		0.969		6.23		0.976	
				18.	0.43							27.		0.969		6.43		0.988	
				19.	0.46							28.		0.969		6.63		0.994	
				20.	0.77							29.		0.969		6.83		0.997	
				21.	0.95							30.		0.969		7.03		0.999	
				22.	0.77							31.		0.969		7.23		1.000	
				23.	0.95							32.		0.969		7.43		1.000	
				24.	0.84							33.		0.969		7.63		1.000	
				25.	0.85							34.		0.969		7.83		1.000	
				26.	0.83							35.		0.969		8.03		1.000	
				27.	0.83							36.		0.969		8.23		1.000	
				28.	0.94							37.		0.969		8.43		1.000	
				29.	0.94							38.		0.969		8.63		1.000	
				30.	0.94							39.		0.969		8.83		1.000	
				31.	0.94							40.		0.969		9.03		1.000	
				32.	0.94							41.		0.969		9.23		1.000	
				33.	0.93							42.		0.969		9.43		1.000	
				34.	0.90							43.		0.969		9.63		1.000	
				35.	0.90							44.		0.969		9.83		1.000	
				36.	0.95							45.		0.969		10.03		1.000	
				37.	0.95							46.		0.969		10.23		1.000	
				38.	0.95							47.		0.969		10.43		1.000	
				39.	0.95							48.		0.969		10.63		1.000	
				40.	0.95							49.		0.969		10.83		1.000	
				41.	0.95							50.		0.969		11.03		1.000	
				42.	0.95							51.		0.969		11.23		1.000	
				43.	0.95							52.		0.969		11.43		1.000	
				44.	0.95							53.		0.969		11.63		1.000	
				45.	0.95							54.		0.969		11.83		1.000	
				46.	0.95							55.		0.969		12.03		1.000	
				47.	0.95							56.		0.969		12.23		1.000	
				48.	0.95							57.		0.969		12.43		1.000	
				49.	0.95							58.		0.969		12.63		1.000	
				50.	0.95							59.		0.969		12.83		1.000	
				51.	0.95							60.		0.969		13.03		1.000	
				52.	0.95							61.		0.969		13.23		1.000	
				53.	0.95							62.		0.969		13.43		1.000	
				54.	0.95							63.		0.969		13.63		1.000	
				55.	0.95							64.		0.969		13.83		1.000	
				56.	0.95							65.		0.969		14.03		1.000	
				57.	0.95							66.		0.969		14.23		1.000	
				58.	0.95							67.		0.969		14.43		1.000	
				59.	0.95							68.		0.969		14.63		1.000	
				60.	0.95							69.		0.969		14.83		1.000	
				61.	0.95							70.		0.969		15.03		1.000	
				62.	0.95							71.		0.969		15.23		1.000	
				63.	0.95							72.		0.969		15.43		1.000	
				64.	0.95							73.		0.969		15.63		1.000	
				65.	0.95							74.		0.969		15.83		1.000	
				66.	0.95							75.		0.969		16.03		1.000	
				67.	0.95							76.		0.969		16.23		1.000	
				68.	0.95							77.		0.969		16.43		1.000	
				69.	0.95							78.		0.969		16.63		1.000	
				70.	0.95							79.		0.969		16.83		1.000	
				71.	0.95							80.		0.969		17.03		1.000	
				72.	0.95							81.		0.969		17.23		1.000	
				73.	0.95							82.		0.969		17.43		1.000	
				74.	0.95							83.		0.969		17.63		1.000	
				75.	0.95							84.		0.969		17.83		1.000	
				76.	0.95							85.		0.969		18.03		1.000	
				77.	0.95							86.		0.969		18.23		1.000	
				78.	0.95							87.		0.969		18.43		1.000	
				79.	0.95							88.		0.969		18.63		1.000	
				80.	0.95							89.		0.969		18.83		1.000	
				81.	0.95							90.		0.969		19.03		1.000	
				82.	0.95							91.		0.969		19.23		1.000	
				83.	0.95							92.		0.969		19.43		1.000	
				84.	0.95							93.		0.969		19.63			

TABLE 6-3. EXPERIMENTAL NORMAL SPECTRAL EMISSION OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 6-3. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMMITTANCE, ϵ)

λ	ϵ	CURVE 73(CONT.)			CURVE 75(CONT.)			CURVE 76(CONT.)			CURVE 78(CONT.)			CURVE 79(CONT.)			CURVE 81(CONT.)		
15.0	0.551	6.15	0.626	14.2	0.528	4.08	0.273	11.5	0.773	3.26	0.112	3.52	0.128	3.67	0.137	3.80	0.150		
CURVE 74 $T = 1143.$		6.65	0.870	13.0	0.440	4.45	0.466	12.0	0.696	3.90	0.168	3.98	0.176	4.01	0.198	4.02	0.207		
7.24	0.896	9.46	0.916	10.4	0.923	4.72	0.577	12.3	0.669	3.97	0.137	4.01	0.198	4.02	0.207	4.03	0.217		
		10.5	0.917	11.1	0.847	4.00	0.100	5.19	0.694	13.4	0.662	3.98	0.168	4.01	0.198	4.02	0.207		
1.03	0.194	10.5	0.917	11.6	0.727	2.99	0.102	6.38	0.866	14.7	0.595	4.01	0.198	4.02	0.207	4.03	0.217		
3.09	0.164	10.1	0.847	11.8	0.727	2.99	0.102	6.91	0.903	15.0	0.561	4.02	0.23	4.03	0.24	4.04	0.256		
3.33	0.115	11.6	0.727	11.8	0.703	3.29	0.113	10.1	0.946	5.15	0.665	5.44	0.755	5.70	0.813	5.95	0.877		
3.59	0.126	11.8	0.703	12.0	0.687	3.51	0.146	10.5	0.938	5.44	0.755	5.70	0.813	5.95	0.877	6.17	0.910		
3.87	0.170	12.0	0.687	12.3	0.673	3.75	0.196	10.9	0.914	5.70	0.790	5.95	0.877	6.17	0.910	6.41	0.955		
4.59	0.456	12.3	0.673	13.0	0.665	4.32	0.282	11.0	0.896	6.00	0.100	6.30	0.100	6.50	0.100	6.77	0.100		
5.14	0.606	13.0	0.665	14.5	0.641	4.32	0.460	11.5	0.773	6.30	0.100	6.67	0.100	6.97	0.100	7.17	0.100		
5.71	0.733	14.5	0.641	15.0	0.617	4.67	0.595	12.0	0.696	6.54	0.114	6.45	0.944	6.71	0.959	6.90	0.976		
6.18	0.803	15.0	0.617	15.8	0.588	4.67	0.724	12.3	0.669	6.89	0.174	7.14	0.174	7.39	0.174	7.77	0.174		
6.75	0.364	15.8	0.588	16.4	0.546	4.86	0.866	13.4	0.662	7.24	0.24	7.59	0.24	7.96	0.24	8.39	0.24		
7.42	0.933	16.4	0.546	17.1	0.517	5.17	0.898	13.9	0.641	7.65	0.198	8.08	0.198	8.55	0.198	8.98	0.198		
10.4	0.914	17.1	0.517	17.8	0.461	6.52	0.925	14.7	0.595	8.13	0.13	8.53	0.13	8.99	0.13	9.44	0.13		
10.7	0.961	17.8	0.461	18.3	0.413	7.30	0.953	15.0	0.561	8.56	0.114	8.97	0.114	9.37	0.114	9.72	0.114		
11.1	0.536	18.3	0.413	19.7	0.352	8.52	0.953	16.4	0.561	9.36	0.114	9.58	0.114	9.99	0.114	10.25	0.114		
11.3	0.757	19.7	0.352	20.4	0.344	10.4	0.965	17.9	0.601	9.86	0.114	10.25	0.114	10.59	0.114	10.95	0.114		
21.5	0.722	20.4	0.344	21.2	0.269	10.4	0.965	18.3	0.601	10.25	0.114	10.63	0.114	11.01	0.114	11.38	0.114		
21.7	0.699	21.2	0.269	21.6	0.216	11.0	0.952	19.0	0.641	10.63	0.114	11.01	0.114	11.38	0.114	11.75	0.114		
12.0	0.555	21.6	0.216	22.1	0.384	11.2	0.900	19.8	0.641	11.01	0.114	11.38	0.114	11.75	0.114	12.22	0.114		
12.9	0.656	22.1	0.384	22.6	0.456	11.7	0.817	20.9	0.752	11.51	0.114	11.71	0.114	12.06	0.114	12.46	0.114		
14.0	0.647	22.6	0.456	23.1	0.569	12.5	0.781	21.7	0.752	12.01	0.114	12.23	0.114	12.63	0.114	13.09	0.114		
14.7	0.608	23.1	0.569	23.9	0.671	13.3	0.752	22.5	0.752	12.51	0.114	12.73	0.114	13.23	0.114	13.63	0.114		
15.0	0.504	23.9	0.671	24.5	0.773	12.3	0.715	21.5	0.715	13.3	0.666	12.62	0.808	13.46	0.884	13.83	0.893		
CURVE 75 $T = 1273.$		6.41	0.820	13.3	0.705	3.92	0.203	12.3	0.639	13.46	0.884	13.83	0.893	14.43	0.693	14.85	0.656		
6.63	0.857	13.7	0.696	14.3	0.641	4.08	0.273	13.2	0.629	14.43	0.693	14.85	0.656	15.09	0.635	15.59	0.635		
7.03	0.672	14.3	0.641	15.0	0.590	4.72	0.577	14.5	0.590	15.0	0.539	15.59	0.635	16.09	0.635	16.59	0.635		
7.67	0.697	15.0	0.590	15.8	0.908	5.19	0.694	15.0	0.539	16.09	0.635	16.59	0.635	17.09	0.635	17.59	0.635		
1.30	0.134	16.3	0.908	17.1	0.867	5.75	0.790	16.38	0.866	17.3	0.821	17.73	0.821	18.13	0.821	18.53	0.821		
3.09	0.139	16.6	0.867	17.6	0.821	6.38	0.903	16.91	0.924	17.54	0.924	18.13	0.821	18.73	0.821	19.13	0.821		
3.30	0.115	16.8	0.821	18.4	0.566	7.54	0.924	17.01	0.946	17.01	0.946	17.73	0.821	18.33	0.821	18.93	0.821		
3.60	0.140	17.4	0.566	19.1	0.520	8.31	0.100	17.3	0.946	17.3	0.946	18.33	0.821	19.13	0.821	19.93	0.821		
3.70	0.153	19.1	0.520	19.8	0.520	9.33	0.111	18.5	0.946	18.5	0.946	19.13	0.821	19.93	0.821	20.53	0.821		
4.01	0.240	19.8	0.520	20.3	0.596	10.5	0.111	19.5	0.938	19.5	0.938	20.13	0.821	20.93	0.821	21.53	0.821		
4.62	0.537	20.3	0.596	21.3	0.606	11.3	0.145	20.9	0.946	20.9	0.946	21.73	0.821	22.53	0.821	23.13	0.821		
5.34	0.613	21.3	0.606	21.4	0.600	12.3	0.208	21.5	0.946	21.5	0.946	22.13	0.821	22.93	0.821	23.73	0.821		
5.43	0.713	21.4	0.600	21.4	0.600	12.9	0.208	21.5	0.946	21.5	0.946	22.13	0.821	22.93	0.821	23.73	0.821		

TABLE 6-3. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF ALUMINUM OXIDE (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ) (CONTINUED)

λ	ϵ	CURVE 82 (CONT.)			CURVE 63 (CONT.)			CURVE 84 (CONT.)			CURVE 85 (CONT.)			CURVE 86 (CONT.)		
λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	
3.50	0.99	3.27	0.99	1.99	0.89	3.27	0.90	3.27	0.90	3.27	0.90	3.27	0.90	3.27	0.90	0.90
3.64	0.110	3.50	0.99	2.96	0.89	3.50	0.99	3.50	0.99	3.50	0.99	3.50	0.99	3.50	0.99	0.99
3.80	0.125	3.64	0.110	3.27	0.99	3.64	0.110	3.64	0.110	3.64	0.110	3.64	0.110	3.64	0.110	0.110
3.93	0.135	3.80	0.125	3.50	0.99	3.93	0.125	3.93	0.125	3.93	0.125	3.93	0.125	3.93	0.125	0.125
4.37	0.187	3.93	0.155	3.64	0.110	4.37	0.155	4.37	0.155	4.37	0.155	4.37	0.155	4.37	0.155	0.155
4.24	0.239	4.37	0.187	3.80	0.125	4.24	0.187	4.24	0.187	4.24	0.187	4.24	0.187	4.24	0.187	0.187
4.47	0.323	4.72	0.237	3.93	0.143	4.47	0.237	4.47	0.237	4.47	0.237	4.47	0.237	4.47	0.237	0.237
4.72	0.423	4.45	0.331	4.06	0.168	4.72	0.331	4.72	0.331	4.72	0.331	4.72	0.331	4.72	0.331	0.331
4.94	0.512	4.77	0.449	4.19	0.201	4.94	0.449	4.94	0.449	4.94	0.449	4.94	0.449	4.94	0.449	0.449
5.22	0.601	4.83	0.478	4.38	0.258	5.22	0.601	5.22	0.601	5.22	0.601	5.22	0.601	5.22	0.601	0.601
5.52	0.697	5.94	0.519	4.59	0.322	5.52	0.697	5.52	0.697	5.52	0.697	5.52	0.697	5.52	0.697	0.697
5.80	0.751	5.04	0.566	4.97	0.447	5.80	0.751	5.80	0.751	5.80	0.751	5.80	0.751	5.80	0.751	0.751
6.05	0.825	5.33	0.656	5.24	0.537	6.05	0.825	6.05	0.825	6.05	0.825	6.05	0.825	6.05	0.825	0.825
6.25	0.666	5.53	0.698	5.52	0.620	6.25	0.666	6.25	0.666	6.25	0.666	6.25	0.666	6.25	0.666	0.666
6.53	0.992	5.89	0.763	5.76	0.697	6.53	0.992	6.53	0.992	6.53	0.992	6.53	0.992	6.53	0.992	0.992
6.75	0.927	6.05	0.819	5.94	0.731	6.75	0.927	6.75	0.927	6.75	0.927	6.75	0.927	6.75	0.927	0.927
7.04	0.944	6.24	0.863	6.25	0.792	7.04	0.944	7.04	0.944	7.04	0.944	7.04	0.944	7.04	0.944	0.944
7.40	0.959	6.41	0.873	6.40	0.816	7.40	0.959	7.40	0.959	7.40	0.959	7.40	0.959	7.40	0.959	0.959
7.71	0.963	6.64	0.897	6.60	0.848	7.71	0.963	7.71	0.963	7.71	0.963	7.71	0.963	7.71	0.963	0.963
9.13	0.953	6.81	0.913	6.83	0.872	9.13	0.953	9.13	0.953	9.13	0.953	9.13	0.953	9.13	0.953	0.953
9.50	0.957	7.05	0.931	7.05	0.885	9.50	0.957	9.50	0.957	9.50	0.957	9.50	0.957	9.50	0.957	0.957
9.99	0.947	7.33	0.942	7.33	0.897	9.99	0.947	9.99	0.947	9.99	0.947	9.99	0.947	9.99	0.947	0.947
10.60	0.949	7.41	0.942	7.41	0.897	10.60	0.949	10.60	0.949	10.60	0.949	10.60	0.949	10.60	0.949	0.949
11.22	0.936	8.75	0.935	9.27	0.900	11.22	0.936	11.22	0.936	11.22	0.936	11.22	0.936	11.22	0.936	0.936
11.71	0.926	9.99	0.926	10.60	0.900	11.71	0.926	11.71	0.926	11.71	0.926	11.71	0.926	11.71	0.926	0.926
12.01	0.911	10.60	0.934	10.77	0.900	12.01	0.911	12.01	0.911	12.01	0.911	12.01	0.911	12.01	0.911	0.911
12.28	0.898	11.20	0.926	11.10	0.885	12.28	0.898	12.28	0.898	12.28	0.898	12.28	0.898	12.28	0.898	0.898
12.62	0.868	11.52	0.908	11.53	0.879	12.62	0.868	12.62	0.868	12.62	0.868	12.62	0.868	12.62	0.868	0.868
13.46	0.884	11.89	0.896	12.54	0.863	13.46	0.884	13.46	0.884	13.46	0.884	13.46	0.884	13.46	0.884	0.884
13.83	0.893	12.62	0.895	12.58	0.856	13.83	0.893	13.83	0.893	13.83	0.893	13.83	0.893	13.83	0.893	0.893
14.43	0.893	13.46	0.887	13.74	0.856	14.43	0.893	14.43	0.893	14.43	0.893	14.43	0.893	14.43	0.893	0.893
14.65	0.866	13.83	0.893	14.47	0.851	14.65	0.866	14.65	0.866	14.65	0.866	14.65	0.866	14.65	0.866	0.866
15.03	0.885	14.43	0.893	15.30	0.839	15.03	0.885	15.03	0.885	15.03	0.885	15.03	0.885	15.03	0.885	0.885
CURVE 83 T = 1273.		CURVE 84 T = 1273.	CURVE 85 T = 1273.	CURVE 86 T = 1273.												
1.00	0.995	1.00	0.99	1.00	0.985	1.00	0.99	1.00	0.985	1.00	0.99	1.00	0.99	1.00	0.99	0.99
1.99	0.089	2.00	0.085	2.00	0.089	1.99	0.089	1.99	0.089	1.99	0.089	1.99	0.089	1.99	0.089	0.089
2.96	0.039					2.96	0.039	2.96	0.039	2.96	0.039	2.96	0.039	2.96	0.039	0.039

b. Normal Spectral Emittance (Temperature Dependence)

A total of seven sets of experimental data were located for the temperature dependence of the normal spectral emittance of aluminum oxide as listed in Table 6-6 and shown in Figure 6-8. Specimen characterization and measurement information for the data are given in Table 6-5. All the data are for wavelengths of 1 μm or below.

However, provisional values at 3.8 and 10.6 μm for Coors AD 99 are shown in Figure 6-7 and are listed in Table 6-4. The values were obtained from the two provisional curves in the previous section. The uncertainty in each point is 15%. The lines connecting the two points for each wavelength are not to imply a smooth curve and are used merely as an aid in visualizing and integrating the values presented.

TABLE 6-4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (COORS AD 99) (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

T	ϵ	T	ϵ
$\lambda = 3.8$			$\lambda = 10.6$
1303.	0.543	1303.	0.966
1423.	0.399	1423.	0.966




FIGURE 6-7. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (TEMPERATURE DEPENDENCE).




FIGURE 6-8. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF ALUMINUM OXIDE (TEMPERATURE DEPENDENCE).

TABLE 6-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM OXIDE (Temperature Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T10060	Olsson, O.H. and Morris, J.C.	1959	0.665	1050-1740	Norton LA603	Data from figure; $\theta^* = 0^\circ$.
2 T10060	Olsson, O.H. and Morris, J.C.	1959	0.665	1191-1773	Norton RA4213	Data from figure; $\theta^* = 0^\circ$.
3 T10060	Olsson, O.H. and Morris, J.C.	1959	0.665	1198-1465	Norton Rokide A	Material on stainless steel No. 446; data from figure; $\theta^* = 0^\circ$.
4 T16630	Blair, G.R.	1960	0.640	878-1953	Frenchtown alumina 4402	Ground to size, ultrasonically cleaned, surface polished with 1.5 μm diamond polishing compound until normally mat surface began to reflect light; cleaned, polished with cloth charged with a paste of cerium oxide and kerosene; measured in vacuum; data from figure; emissivity reported; $\theta^* = 0^\circ$; reported error $\sim 10\%$.
5 T16630	Blair, G.R.	1960	1	891-1919	Frenchtown alumina 4402	The above specimen.
6 T16630	Blair, G.R.	1960	0.640	773-1878	Coors alumina AD 99	Similar to the above specimen.
7 T16630	Blair, G.R.	1960	1	773-1880	Coors alumina AD 99	The above specimen.

TABLE 6-5. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF ALUMINUM OXIDE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMMITTANCE, ϵ)

T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ
CURVE 1									
$\lambda = 6.665$									
1036.	0.213	891.	0.985	1191.	0.250	1191.	0.646	1273.	0.259
1339.	0.366	1075.	0.992	1273.	0.337	1339.	0.372	1362.	0.341
1482.	0.353	1276.	0.990	1499.	0.273	960.	0.425	1485.	0.394
1485.	0.394	1397.	0.603	1526.	0.372	1175.	0.400	1645.	0.445
1645.	0.445	1576.	0.762	1654.	0.414	1342.	0.395	1740.	0.603
1740.	0.603	1754.	0.681	1724.	0.434	1521.	0.347	1773.	0.434
CURVE 2									
$\lambda = 0.665$									
1191.	0.250	773.	0.372	1191.	0.445	773.	1.000	1273.	0.476
1273.	0.259	960.	0.425	1273.	0.519	962.	0.657	1339.	0.519
1362.	0.337	1175.	0.400	1339.	0.519	1173.	0.803	1482.	0.519
1499.	0.341	1342.	0.395	1485.	0.519	1335.	0.803	1645.	0.519
1526.	0.273	1521.	0.347	1645.	0.519	1524.	0.687	1740.	0.519
1654.	0.372	1724.	0.550	1724.	0.519	1724.	0.550	1773.	0.519
1724.	0.414	1773.	0.347	1773.	0.519	1880.	0.468	1953.	0.519
CURVE 3									
$\lambda = 0.665$									
1191.	0.445	1173.	0.657	1191.	0.445	1173.	0.803	1273.	0.803
1273.	0.476	1335.	0.803	1273.	0.519	1335.	0.803	1339.	0.803
1339.	0.519	1524.	0.687	1339.	0.519	1524.	0.687	1482.	0.687
1482.	0.519	1724.	0.550	1485.	0.519	1724.	0.550	1645.	0.519
1485.	0.519	1773.	0.519	1645.	0.519	1773.	0.519	1740.	0.519
1645.	0.519	1880.	0.468	1740.	0.519	1880.	0.468	1773.	0.519
CURVE 4									
$\lambda = 0.649$									
876.	0.463	1524.	0.687	876.	0.463	1524.	0.687	1075.	0.430
1075.	0.430	1724.	0.550	1075.	0.430	1724.	0.550	1272.	0.439
1272.	0.439	1773.	0.519	1272.	0.439	1773.	0.519	1339.	0.479
1339.	0.479	1880.	0.468	1339.	0.479	1880.	0.468	1482.	0.519
1482.	0.519	1953.	0.519	1485.	0.519	1953.	0.519	1645.	0.519
1645.	0.519	1953.	0.519	1645.	0.519	1953.	0.519	1740.	0.519
1740.	0.519	1953.	0.519	1740.	0.519	1953.	0.519	1773.	0.519
1773.	0.519	1953.	0.519	1773.	0.519	1953.	0.519	1880.	0.468
CURVE 5									
$\lambda = 1.0$									
891.	0.985	1880.	0.468	891.	0.985	1880.	0.468	1075.	0.992
1075.	0.992	1953.	0.519	1075.	0.992	1953.	0.519	1272.	0.990
1272.	0.990	1953.	0.519	1272.	0.990	1953.	0.519	1339.	0.990
1339.	0.990	1953.	0.519	1339.	0.990	1953.	0.519	1482.	0.990
1482.	0.990	1953.	0.519	1482.	0.990	1953.	0.519	1645.	0.990
1645.	0.990	1953.	0.519	1645.	0.990	1953.	0.519	1740.	0.990
1740.	0.990	1953.	0.519	1740.	0.990	1953.	0.519	1773.	0.990
1773.	0.990	1953.	0.519	1773.	0.990	1953.	0.519	1880.	0.468
CURVE 6									
$\lambda = 0.646$									
1191.	0.372	1880.	0.468	1191.	0.372	1880.	0.468	1273.	0.372
1273.	0.400	1953.	0.519	1273.	0.400	1953.	0.519	1339.	0.400
1339.	0.400	1953.	0.519	1339.	0.400	1953.	0.519	1482.	0.400
1482.	0.400	1953.	0.519	1482.	0.400	1953.	0.519	1645.	0.400
1645.	0.400	1953.	0.519	1645.	0.400	1953.	0.519	1740.	0.400
1740.	0.400	1953.	0.519	1740.	0.400	1953.	0.519	1773.	0.400
1773.	0.400	1953.	0.519	1773.	0.400	1953.	0.519	1880.	0.468
CURVE 7									
$\lambda = 1.0$									
1191.	0.646	1880.	0.468	1191.	0.646	1880.	0.468	1273.	0.646
1273.	0.676	1953.	0.519	1273.	0.676	1953.	0.519	1339.	0.676
1339.	0.676	1953.	0.519	1339.	0.676	1953.	0.519	1482.	0.676
1482.	0.676	1953.	0.519	1482.	0.676	1953.	0.519	1645.	0.676
1645.	0.676	1953.	0.519	1645.	0.676	1953.	0.519	1740.	0.676
1740.	0.676	1953.	0.519	1740.	0.676	1953.	0.519	1773.	0.676
1773.	0.676	1953.	0.519	1773.	0.676	1953.	0.519	1880.	0.468

c. Normal Spectral Reflectance (Wavelength Dependence)

A total of 31 sets of experimental data were located for the wavelength dependence of the normal spectral reflectance of aluminum oxide as listed in Table 6-8 and shown in Figure 6-9. Figure 6-9 does not show the data for curves 4, 9-13, and 30-31. The data for these curves reported in the literature are relative values and some individual data points are over 1.0. The computer program handling the plotting divides any data over 1.0 by 100, and hence the curves having such data were not plotted. Specimen characterization and measurement information for the data are given in Table 6-7.

The data are predominately for wavelengths below 2.7 μm . The data above 2.7 μm are not identified with any specific brand names nor are there confirmatory data for these data sets. For these reasons, taken together, it is not thought justified to pursue developing evaluated data.




FIGURE 6-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE
(WAVELENGTH DEPENDENCE).

TABLE 6-7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (Wavelength Dependence)

Cat. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T10060	Gison, O. H. and Morris, J.C.	1959	0.30-2.7	293	Norton LA663	Working standard magnesium carbonate surface; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; integrating sphere reflectometer used; reflectance factor measured to absolute reflectance values; $\theta = 9^\circ$, $\omega' = 2\pi$; reported error 4%.	
2 T10060	Olson, O. H. and Morris, J.C.	1959	0.30-2.7	293	Norton RA4213	Similar to the above specimen.	
3 T10060	Olson, O. H. and Morris, J.C.	1959	0.31-2.7	293	Norton Rokide A	Similar to the above specimen except material on stainless steel No. 446.	
4 T22272	Schatz, E.A., Goldberg, D.M., Pearson, E.G., and Burke, T.L.	1963	0.23-2.7	293	Sample No. 112	Sintered at 1923 K for 1 hr, settler material Al_2O_3 ; thickness 69 mils; density 3.45 g cm^{-3} , theoretical density 3.97 g cm^{-3} ; MgO reference standard, reflectance data measured and presented relative to MgO ; spectral total reflectance reported; integrating sphere reflectometer, Beckman DK-2A spectrophotometer used; measurement temperature not given explicitly, 293 K assigned; smooth values from figure; $\theta = 5^\circ$, $\omega' = 2\pi$.	
5 T28755	Zerlaut, G.A. and Harada, Y.	1963	0.44-0.60	293	Alucer MC, alpha	Supplied by Gulfon Industries; powder compacted at 10 000 psi; MgO used as standard; measurement temperature not given explicitly, assumed to be 293 K; $\theta \sim 0^\circ$, $\omega' = 2\pi$.	
6 T28755	Zerlaut, G.A. and Harada, Y.	1963	0.44-0.60	293	Alucer MC, alpha	The above specimen except exposed to uv irradiation; 130 ESH with solar factor 3.	
7 T28755	Zerlaut, G.A. and Harada, Y.	1963	0.44-0.60	293	Alucer MA, gamma	Supplied by Gulfon Industries; powder compacted at 10 000 psi; MgO used as standard; absolute values of reflectance reported; integrating sphere reflectometer used; measurement temperature not given explicitly, assumed to be 293 K; $\theta \sim 0^\circ$, $\omega' = 2\pi$.	
8 T28755	Zerlaut, G.A. and Harada, Y.	1963	0.44-0.60	293	Alucer MA, gamma	The above specimen except exposed to uv irradiation; 75 ESH with solar factor 1.5.	
9 T34508	Schatz, E.A.	1966	0.23-2.7	293		>99 pure; compacted powder; compaction pressure 290 psi; MgO reference standard; spectral total reflectance versus MgO presented; Beckman DK-2A spectrophotometer used; measurement temperature not given explicitly, assumed to be 293 K; smooth values from figure; $\theta \sim 0^\circ$, $\omega' = 2\pi$.	
10 T34905	Schatz, E.A.	1966	0.23-2.7	293		Similar to the above specimen except compacted at 1150 psi.	
11 T34908	Schatz, E.A.	1966	0.23-2.7	293		Similar to the above specimen except compacted at 2850 psi.	
12 T34908	Schatz, E.A.	1966	0.23-2.7	293		Similar to the above specimen except compacted at 5760 psi.	
13 T34908	Schatz, E.A.	1966	0.23-2.7	293		Similar to the above specimen except compacted at 11 500 psi.	
14 T34908	Schatz, E.A.	1966	0.23-2.7	293		Similar to the above specimen except compacted at 20 200 psi.	
15 T34908	Schatz, E.A.	1966	0.23-2.7	293		Similar to the above specimen except compacted at 28 800 psi.	
16 T34908	Schatz, E.A.	1966	2.0-15	293		>99 pure; compacted powder; compaction pressure 700 psi; absolute spectral total reflectance reported; blackbody reflectometer used in conjunction with Baird-Atomic model NK-1 spectrophotometer; smooth values from figure; $\theta \sim 0^\circ$, $\omega' = 2\pi$.	
17 T34908	Schatz, E.A.	1966	2.0-15	293		Similar to the above specimen except compacted at 7000 psi.	
18 T34908	Schatz, E.A.	1966	2.0-15	293		Similar to the above specimen except compacted at 28 000 psi.	
19 T34908	Schatz, E.A.	1966	2.0-15	293		Similar to the above specimen except compacted at 42 000 psi.	

TABLE 6-7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
20	T40230	Schatz, F. A.	1967	0.23-2.7	293		Powder; commercially pure; -230 to +270 mesh, pressed at 24,300 Newtons cm ⁻² ; 1.6 mm thick and 22 mm in diameter stainless steel; Beckman DK-2A spectrophotometer used; curves presented relative to smoked MgO standard; measurement temperature not explicitly given, assumed to be 293 K; smooth values from figure; $\theta \sim 0^\circ$, $\omega' = 28^\circ$.
21	T40526	Sulzbach, F. and Turner, A. F.	1966	10.0-36.0	293		Clear film; electron beam deposited at normal incidence on glass at 423 K at 2 to 8×10^{-5} mm Hg; rate of deposit 1 quartwave min ⁻¹ at $\lambda = 0.5 \mu\text{m}$; optical film thickness, index of refraction times thickness equals $10 \lambda/4$ at $2.3 \mu\text{m}$; measurement temperature specified as room temperature, 293 K assigned; Perkin Elmer model 21 and 221 spectrophotometers used for reflectance measurements; $\theta \sim 0^\circ$.
22	T40528	Sulzbach, F. and Turner, A. F.	1966	9.9-37	293		Similar to the above specimen except electron beam deposited at normal incidence on glass at 588 K; index of refraction times thickness equals $10 \lambda/4$ at $2.2 \mu\text{m}$.
23	T40528	Sulzbach, F. and Turner, A. F.	1966	10-37	293		Crystal; polished; smooth values from figure; measurement temperature specified as room temperature, 293 K assigned; Perkin Elmer models 21 and 221 spectrophotometers used for reflectance measurements; $\theta \sim 0^\circ$.
24	T45667	De La Perelle, E.T., and Herbert, H.	1962	0.4-2.2	293	Specimen X64	Integrating sphere reflectometer used with magnesium carbonate as inside liner of sphere; absolute reflectance factor ($\omega = 2\pi$, $\theta' = 0^\circ$) actually measured, equated to reflectance ($\theta = 0^\circ$, $\omega' = 2\pi$), angles θ and θ' presumed to be approx. 0° ; measurement temperature not given explicitly, assumed to be 293 K.
25	T45760	Wilcock, D. F. and Soller, W.	1940	0.28-0.32	293		Dry pigment, packed in shallow steel cell; integrating sphere with magnesium oxide coating on inside used to measure absolute reflectance factor; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$, $\omega' = 2\pi$.
26	T49037	Zerlaut, G. A., Tompkins, E. H., Harada, Y., and Marshall, G. C.	1964	0.32-2.0	293	Sample 34	Pressed compact; Cary spectrophotometer used; presume $\theta = 0^\circ$, $\omega' = 2\pi$; measurement temperature not given explicitly, assumed to be 293 K.
27	T34914	Strindehag, O. M.	1966	0.43-0.54	293	Reflector VIII	Sintered; Al123 and Al124 supplied by Regussa; relative reflectance factor ($\omega = 2\pi$, $\theta' = 0^\circ$), compared to smoked MgO reference standard, actually measured, equated to reflectance factor ($\theta = 0^\circ$, $\omega' = 2\pi$); Zeiss Elrepho photometer used in reflectance measurement, diffuse illumination of specimen with white light and observation direction perpendicular to specimen; measurement temperature not explicitly given, 293 K assigned.
28	T34814	Strindehag, O. M.	1966	0.31-0.59	293	Reflector VII	The above specimen except PMQII spectrometer used with RA3 reflection attachment; RA3 used monochromatic light directed perpendicular to the specimen and integrating measurement of total diffuse reflection made.
29	T34814	Strindehag, O. M.	1966	0.43-0.54	293	Reflector VIII	The above specimen except exposed to 423 K deionized water for 10 days and Elrepho photometer used for measurement.
30	T35340	Schatz, E. A., Alvarez, G.H., Counts, C.B., III, and Hippie, M.A.	1965	0.23-2.7	293		Sintered 15 hr at 1273 K; density 1.55; MgO reference standard; Beckman DK-2A spectrophotometer used; smooth values from figure; measurement temperature not explicitly given, assumed to be 293 K; $\theta = 5^\circ$, $\omega' = 2\pi$.
31	T35840	Schatz, E. A., et al.	1965	0.23-2.7	293		The above specimen except sintered an additional 2 hr at 1323 K; density changed to 3.34.

TABLE 6-8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ]

λ	ρ	λ	ρ	CURVE 2 (CONT.)		CURVE 3 (CONT.)		CURVE 4 (CONT.)		CURVE 5 (CONT.)		CURVE 6 (CONT.)		CURVE 7 (CONT.)		CURVE 8 (CONT.)		CURVE 9 (CONT.)		CURVE 10 (CONT.)		CURVE 11		CURVE 12			
				λ	ρ	λ	ρ	λ	ρ	λ	ρ																
CURVE 1 $T = 293.$		0.588	0.834	1.177	0.684	1.04	0.928	1.04	0.928	1.15	0.934	0.230	1.000	1.04	1.014	1.04	1.000	2.07	1.020	2.20	1.011	2.30	1.012	2.45	1.000	2.60	0.994
	0.394	0.171	0.678	0.668	1.263	0.694	1.15	0.934	0.230	0.940	0.243	1.000	0.230	1.000	0.230	1.000	0.230	1.000	0.230	1.000	0.230	1.000	0.230	1.000	0.230	1.000	
J.389	0.429	0.779	0.881	1.398	0.697	1.24	0.940	0.243	0.952	0.270	1.012	0.270	1.012	0.270	1.012	0.270	1.012	0.270	1.012	0.270	1.012	0.270	1.012	0.270	1.012	0.270	1.012
0.462	0.603	0.852	0.866	1.481	0.676	1.39	0.952	0.270	0.952	0.280	1.021	0.280	1.021	0.280	1.021	0.280	1.021	0.280	1.021	0.280	1.021	0.280	1.021	0.280	1.021	0.280	1.021
0.473	0.616	0.867	0.884	1.710	0.690	1.55	0.956	0.280	0.956	0.290	1.033	0.289	1.033	0.289	1.033	0.289	1.033	0.289	1.033	0.289	1.033	0.289	1.033	0.289	1.033	0.289	1.033
0.519	0.717	0.970	0.887	1.829	0.570	1.75	0.966	0.289	0.966	0.318	1.020	0.318	1.020	0.318	1.020	0.318	1.020	0.318	1.020	0.318	1.020	0.318	1.020	0.318	1.020	0.318	1.020
0.349	0.859	1.08	0.897	1.945	0.583	1.84	0.975	0.347	0.976	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020
0.930	0.363	1.17	0.890	2.375	0.584	1.95	0.976	0.347	0.976	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020	0.347	1.020
0.259	0.857	1.22	0.905	2.188	0.585	2.15	0.995	0.350	0.995	0.350	1.022	0.350	1.022	0.350	1.022	0.350	1.022	0.350	1.022	0.350	1.022	0.350	1.022	0.350	1.022	0.350	1.022
1.09	0.651	1.31	0.944	2.356	0.560	2.24	1.00	0.571	1.00	0.571	1.031	0.571	1.031	0.571	1.031	0.571	1.031	0.571	1.031	0.571	1.031	0.571	1.031	0.571	1.031	0.571	1.031
1.16	0.855	1.36	0.955	2.492	0.594	2.44	1.01	0.849	1.01	0.849	1.030	0.849	1.030	0.849	1.030	0.849	1.030	0.849	1.030	0.849	1.030	0.849	1.030	0.849	1.030	0.849	1.030
1.19	0.856	1.40	0.959	2.585	0.599	2.55	1.01	1.034	1.01	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034	1.034
1.29	0.864	1.50	0.952	2.702	0.613	2.65	1.05	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.35	0.904	1.63	0.923	2.911	0.633	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.39	0.910	1.77	0.911	2.911	0.633	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.43	0.904	1.87	0.896	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.51	0.877	1.93	0.695	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.63	0.334	2.06	0.906	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.66	0.527	2.17	0.924	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.75	0.806	2.26	0.926	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.79	0.891	2.35	0.933	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.87	0.835	2.42	0.942	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
1.95	0.817	2.55	0.974	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.07	0.822	2.6-	1.000	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.14	0.817	2.85	0.926	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.21	0.819	2.95	0.933	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.30	0.829	3.00	0.942	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.41	0.859	3.10	0.513	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.53	0.910	3.07	0.513	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.57	0.933	3.32	0.595	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
2.69	0.977	3.95	0.727	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
CURVE 2 $T = 293.$	0.439	0.750	0.750	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
S.565	0.763	0.763	0.763	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
0.647	0.752	0.752	0.752	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
0.766	0.738	0.738	0.738	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
0.809	0.730	0.730	0.730	2.911	0.635	2.43	1.036	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047	1.047
0.892	0.693	0.693	0.693	2.911	0.635	2.43	1.036	1.047	1.047	1.																	

TABLE 6-8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ρ	CURVE 12 (CONT.)			CURVE 14 $T = 293.$			CURVE 15 (CONT.)			CURVE 17 (CONT.)			CURVE 19 (CONT.)			CURVE 20 (CONT.)		
λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ		
0.344	0.390	0.350	0.925	0.230	0.977	2.40	0.667	6.56	0.285	2.66	0.435	2.07	0.762	0.345	0.762	0.345	0.762		
0.350	0.925	0.421	1.001	0.246	0.964	2.57	0.600	6.89	0.195	2.91	0.352	2.14	0.777	0.352	0.777	0.352	0.777		
0.421	1.001	0.500	1.031	0.256	0.967	2.65	0.537	7.35	0.131	3.11	0.406	2.39	0.819	0.406	0.819	0.406	0.819		
0.500	1.031	0.641	1.006	0.284	0.983	2.84	0.983	8.01	0.108	3.28	0.420	2.39	0.816	0.420	0.816	0.420	0.816		
0.641	1.006	0.956	1.006	0.305	0.975	2.93	0.975	10.0	0.106	3.74	0.536	2.51	0.823	0.536	0.823	0.536	0.823		
0.956	1.006	1.26	1.001	0.330	0.974	2.93	0.974	11.0	0.134	4.65	0.566	2.65	0.821	0.566	0.821	0.566	0.821		
1.26	1.001	1.43	0.989	0.350	0.981	2.98	0.887	11.5	0.208	5.35	0.543	2.14	0.777	0.543	0.777	0.543	0.777		
1.43	0.989	1.69	0.981	0.442	0.982	2.96	0.936	13.8	0.226	5.78	0.475	2.39	0.819	0.475	0.819	0.475	0.819		
1.69	0.981	1.87	0.955	0.652	0.962	2.97	0.874	14.1	0.235	6.23	0.295	2.39	0.816	0.295	0.816	0.295	0.816		
1.87	0.955	2.33	0.949	0.690	0.985	2.97	0.874	15.0	0.235	6.52	0.235	2.39	0.816	0.235	0.816	0.235	0.816		
2.33	0.949	2.56	0.913	1.15	0.969	2.98	0.712	6.95	0.132	10.0	3.073	2.14	0.777	3.073	2.14	0.777	3.073	2.14	
2.56	0.913	2.56	0.869	1.46	0.921	3.01	0.764	7.51	0.092	11.0	0.229	2.39	0.819	0.229	0.819	0.229	0.819		
2.56	0.869	2.65	0.837	1.73	0.874	3.50	0.821	9.01	0.092	12.0	0.288	2.39	0.816	0.288	0.816	0.288	0.816		
2.65	0.837	3.89	0.833	2.21	0.794	4.17	0.837	10.0	0.085	14.0	0.263	2.39	0.816	0.263	0.816	0.263	0.816		
3.89	0.833	2.14	0.796	6.04	0.593	2.00	0.828	11.0	0.120	15.1	0.250	2.39	0.816	0.250	0.816	0.250	0.816		
2.14	0.796	2.20	0.770	6.73	0.365	2.34	0.822	11.6	0.182	16.0	0.238	2.39	0.816	0.238	0.816	0.238	0.816		
2.20	0.770	2.35	0.741	7.53	0.195	2.49	0.757	13.0	0.198	17.1	0.228	2.39	0.816	0.228	0.816	0.228	0.816		
2.35	0.741	2.51	0.708	8.35	0.162	2.65	0.489	14.0	0.208	19.0	0.214	2.39	0.816	0.214	0.816	0.214	0.816		
2.51	0.708	2.59	0.686	9.27	0.27	2.87	0.390	15.0	0.206	20.0	0.212	2.39	0.816	0.212	0.816	0.212	0.816		
2.59	0.686	2.65	0.654	9.98	0.146	3.23	0.454	21.0	0.216	22.1	0.238	2.39	0.816	0.238	0.816	0.238	0.816		
2.65	0.654	3.20	0.624	10.6	0.166	3.63	0.570	22.1	0.209	23.1	0.209	2.39	0.816	0.209	0.816	0.209	0.816		
3.20	0.624	2.93	0.681	11.2	0.219	4.51	0.600	23.1	0.207	23.1	0.207	2.39	0.816	0.207	0.816	0.207	0.816		
2.93	0.681	3.77	0.677	13.7	0.230	5.31	0.525	23.9	0.210	23.9	0.210	2.39	0.816	0.210	0.816	0.210	0.816		
3.77	0.677	3.43	0.981	2.59	0.686	9.27	0.137	3.23	0.454	21.0	0.216	2.39	0.816	0.216	0.816	0.216	0.816		
3.43	0.981	3.50	0.985	2.59	0.686	9.27	0.137	3.23	0.454	21.0	0.216	2.39	0.816	0.216	0.816	0.216	0.816		
3.50	0.985	4.61	0.975	2.23	0.973	14.0	0.246	6.31	0.337	25.1	0.250	2.39	0.816	0.250	0.816	0.250	0.816		
4.61	0.975	6.52	1.003	2.53	0.559	15.6	0.246	6.62	0.249	26.1	0.215	2.39	0.816	0.215	0.816	0.215	0.816		
6.52	1.003	7.82	1.000	2.91	0.982	10.6	0.166	7.20	0.119	27.0	0.221	2.39	0.816	0.221	0.816	0.221	0.816		
7.82	1.000	8.39	0.981	3.31	0.973	11.2	0.219	8.01	0.096	27.4	0.234	2.39	0.816	0.234	0.816	0.234	0.816		
8.39	0.981	9.30	0.992	3.31	0.973	13.0	0.230	5.71	0.525	28.5	0.252	2.39	0.816	0.252	0.816	0.252	0.816		
9.30	0.992	9.85	0.985	2.33	0.973	14.0	0.246	6.31	0.337	29.5	0.259	2.39	0.816	0.259	0.816	0.259	0.816		
9.85	0.985	10.6	0.975	2.53	0.559	15.6	0.246	6.62	0.249	30.5	0.266	2.39	0.816	0.266	0.816	0.266	0.816		
10.6	0.975	11.2	0.988	2.91	0.982	10.6	0.166	7.20	0.119	31.0	0.274	2.39	0.816	0.274	0.816	0.274	0.816		
11.2	0.988	12.9	0.981	3.31	0.973	11.2	0.219	8.01	0.096	31.0	0.285	2.39	0.816	0.285	0.816	0.285	0.816		
12.9	0.981	13.9	0.984	2.53	0.559	14.0	0.246	6.31	0.337	32.0	0.294	2.39	0.816	0.294	0.816	0.294	0.816		
13.9	0.984	14.6	0.985	2.33	0.973	15.6	0.246	6.62	0.337	32.9	0.300	2.39	0.816	0.300	0.816	0.300	0.816		
14.6	0.985	15.6	0.985	2.53	0.559	15.6	0.246	6.62	0.337	33.9	0.309	2.39	0.816	0.309	0.816	0.309	0.816		
15.6	0.985	16.2	0.985	2.91	0.982	10.6	0.166	7.20	0.119	34.0	0.318	2.39	0.816	0.318	0.816	0.318	0.816		
16.2	0.985	17.7	0.981	3.31	0.973	11.2	0.219	8.01	0.096	34.0	0.325	2.39	0.816	0.325	0.816	0.325	0.816		
17.7	0.981	18.39	0.992	2.53	0.559	14.0	0.246	6.31	0.337	35.0	0.334	2.39	0.816	0.334	0.816	0.334	0.816		
18.39	0.992	19.0	0.985	2.33	0.973	15.6	0.246	6.62	0.337	35.9	0.343	2.39	0.816	0.343	0.816	0.343	0.816		
19.0	0.985	19.6	0.985	2.53	0.559	15.6	0.246	6.62	0.337	36.0	0.352	2.39	0.816	0.352	0.816	0.352	0.816		
19.6	0.985	20.29	0.968	2.91	0.982	10.6	0.166	7.20	0.119	37.0	0.361	2.39	0.816	0.361	0.816	0.361	0.816		
20.29	0.968	20.46	0.740	2.46	0.982	11.2	0.219	8.01	0.096	37.0	0.370	2.39	0.816	0.370	0.816	0.370	0.816		
20.46	0.740	20.54	0.740	1.71	0.857	14.0	0.246	6.31	0.337	37.9	0.379	2.39	0.816	0.379	0.816	0.379	0.816		
20.54	0.740	20.78	0.901	0.679	0.991	2.48	0.826	15.0	0.219	38.0	0.388	2.39	0.816	0.388	0.816	0.388	0.816		
20.78	0.901	21.92	0.865	0.958	0.987	2.36	0.580	11.0	0.191	39.0	0.407	2.39	0.816	0.407	0.816	0.407	0.816		
21.92	0.865	22.07	0.846	1.23	0.950	3.45	0.698	13.8	0.205	40.0	0.426	2.39	0.816	0.426	0.816	0.426	0.816		
22.07	0.846	22.46	0.740	1.46	0.982	4.02	0.714	14.1	0.221	41.0	0.445	2.39	0.816	0.445	0.816	0.445	0.816		
22.46	0.740	22.54	0.740	1.71	0.857	4.62	0.705	15.0	0.219	42.0	0.464	2.39	0.816	0.464	0.816	0.464	0.816		
22.54	0.740	22.92	0.680	0.91	0.778	5.15	0.682	11.0	0.191	43.0	0.483	2.39	0.816	0.483	0.816	0.483	0.816		
22.92	0.680	23.65	0.706	1.23	0.950	3.45	0.698	13.8	0.205	44.0	0.502	2.39	0.816	0.502	0.816	0.502	0.816		
23.65	0.706	24.06	0.706	2.06	0.763	5.58	0.598	15.0	0.219	45.0	0.521	2.39	0.816	0.521	0.816	0.521	0.816		
24.06	0.706	24.65	0.706	2.26	0.700	2.00	0.801	11.0	0.191	46.0	0.540	2.39	0.816	0.540	0.816	0.540	0.816		
24.65	0.706	25.26	0.706	2.65	0.778	6.72	0.582	15.0	0.219	47.0	0.559	2.39	0.816	0.559	0.816	0.559	0.816		

TABLE 6-8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 22 (CONT.)		CURVE 23 (CONT.)		CURVE 24 (CONT.)		CURVE 28		CURVE 30 (CONT.)		CURVE 31 (CONT.)			
14.7	0.287	21.9	0.935	1.2	0.906	T = 293.		0.427	0.869	0.863	0.981		
15.0	0.307	23.0	0.854	1.3	0.82		0.3058	0.391	0.504	0.928	0.979		
18.0	0.239	23.9	0.757	1.4	0.771		0.3265	0.514	0.565	0.932	1.03		
19.9	0.268	25.6	0.556	1.5	0.761		0.3589	0.646	0.654	0.943	1.06		
21.9	0.245	25.9	0.547	1.8	0.695		0.3721	0.671	0.777	0.962	1.07		
23.9	0.238	26.3	0.591	2.0	0.639		0.3957	0.708	0.866	0.990	1.07		
25.9	0.247	27.2	0.522	2.1	0.585		0.4525	0.789	1.16	1.17	1.09		
27.9	0.272	27.9	0.489	2.2	0.544		0.4984	0.829	1.29	1.05	2.36		
30.5	0.313	28.5	0.483	2.2	0.544		0.5381	0.822	1.40	1.04	2.65		
32.5	0.305	29.6	0.427	T = 293.			0.5644	0.828	1.60	1.05			
33.1	0.352	30.5	0.431				0.5916	0.840	1.75	1.07			
33.9	0.288	30.9	0.426						1.95	1.03			
35.9	0.233	31.6	0.408						2.06	1.06			
36.9	0.275	32.3	0.406						2.15	1.08			
CURVE 23 T = 293.		32.8	0.415	CURVE 26 T = 293.		CURVE 29 T = 293.		CURVE 31 T = 293.		CURVE 31 T = 293.			
10.0	0.000	33.4	0.413										
10.5	0.036	34.0	0.407										
10.8	0.106	35.8	0.402										
11.0	0.267	37.0	0.368										
CURVE 24 T = 293.				CURVE 26 T = 293.		CURVE 29 T = 293.		CURVE 30 T = 293.		CURVE 30 T = 293.		CURVE 31 T = 293.	
11.3	0.689												
11.7	0.837												
12.3	0.883												
12.7	0.907	0.4	0.78										
13.7	0.924	0.45	0.846										
14.6	0.926	0.5	0.863	1.6	0.97		0.231	0.973	0.235	0.946	0.262	0.950	
15.1	0.913	0.55	0.889	1.8	0.98		0.237	0.954	0.237	0.946	0.268	0.965	
15.4	0.338	0.55	0.908	2.0	0.97		0.252	0.935	0.252	0.946	0.274	0.988	
15.8	0.836	0.6	0.904				0.275	0.914	0.275	0.921	0.291	0.949	
16.2	0.856	0.65	0.923				0.315	0.884	0.315	0.911	0.336	0.941	
19.2	0.164	0.7	0.918				0.323	0.856	0.323	0.904	0.342	0.924	
19.5	0.129	0.75	0.927				0.343	0.835	0.343	0.913	0.362	0.943	
19.7	0.685	0.8	0.92				0.347	0.815	0.350	0.922	0.347	0.969	
20.9	0.698	0.85	0.92				0.361	0.795	0.361	0.931	0.361	0.981	
20.4	0.680	0.9	0.914				0.371	0.775	0.371	0.921	0.371	0.934	
20.8	0.512	0.95	0.937				0.383	0.755	0.383	0.927	0.383	0.950	
23.9	0.899	1.0	0.925				0.398	0.735	0.398	0.937	0.398	0.973	
21.3	0.955	1.1	0.917				0.407	0.836	0.407	0.951	0.407	0.973	

d. Angular Spectral Reflectance (Wavelength Dependence)

A total of 10 sets of experimental data were located for the wavelength dependence of the angular spectral reflectance of aluminum oxide. These data are listed in Table 6-10 and shown in Figure 6-10. Specimen characterization and measurement information for the data are given in Table 6-9.

The data are all for a temperature of 293 K and none of the sets are for Coors alumina or other commercial alumina and, therefore, no data evaluation is possible.




FIGURE 6-10. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).

TABLE 6-9. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T32363	Hass, G. and Tousey, R.	1959	0.058-0.44	293			Al_2O_3 film on SiO coated glass; both films were effectively $\lambda/4$ thick at 3600 Å; angles θ and θ' determined by measurement from diagram of evaporator (see Fig. 1 in T32363); measurement temperature not given explicitly, assumed to be 293 K; $\theta \sim 18^\circ$, $\theta' \sim 18^\circ$.
2 T45912	Arakawa, E. T. and Williams, M. W.	1968	0.0473-0.16	293	Corundum		Single crystal; cut with the optic axis parallel to the reflecting surface; polished using 6 μm diamond paste, followed by a final polish using 0.5 μm diamond paste on a Buehler microcloth wheel; measurement temperature not given explicitly, assumed to be 293 K; $\theta \sim 20^\circ$, $\theta' \sim 20^\circ$; reported error 2%.
3 T45912	Arakawa, E. T. and Williams, M. W.	1968	0.043-0.14	293	Corundum		The above specimen; $\theta = 50^\circ$, $\theta' = 50^\circ$.
4 T45912	Arakawa, E. T. and Williams, M. W.	1968	0.043-0.14	293	Corundum		The above specimen; $\theta = 60^\circ$, $\theta' = 60^\circ$.
5 T45912	Arakawa, E. T. and Williams, M. W.	1968	0.043-0.14	293	Corundum		The above specimen; $\theta = 70^\circ$, $\theta' = 70^\circ$.
6 T34614	Sirindach, O. M.	1966	0.25-6.50	293	Reflector No. VII		Sintered Al23 and Al24 aluminum oxide; supplied by Degussa; relative reflectance factor determined; data reported relative to smoked MgO reference standard; PMQ II spectrometer used with IR-A2 reflection attachment; smooth values from figure; measurement temperature not explicitly given, 293 K assigned; $\theta = 45^\circ$, $\theta' = 0^\circ$.
7 T42891	Stephan, G., Lemontier, J. C., and Robins, S.	1967	0.0229-0.15	293	Corundum		Specimen cut perpendicular to the optic axis; measured in vacuum; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 20^\circ$, $\theta' = 20^\circ$.
8 T30100	McCarthy, D. E.	1963	2-50	293	Sapphire		Synthetic; specimen 2 mm thick, ground and polished to a flatness of seven fringes or better; reference standard was aluminum mirror; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; Beckman IR-5A used in 2-16 μm range and Beckman BR-7 with CsI interstage used in 12.5-50 μm range; $\theta = 30^\circ$, $\theta' = 30^\circ$.
9 T36324	McCarthy, D. E.	1965	2-50	293	Ruby		0.05 Cr, essentially sapphire with the chromium impurity synthetic; specimen 6.10 mm thick; flat to 10 fringes or better; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 30^\circ$, $\theta' = 6^\circ$.
10 T36324	McCarthy, D. E.	1965	2-50	293	Sapphire		Synthetic; specimen 3.0 mm thick; flat to 10 fringes or better; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 30^\circ$, $\theta' = 30^\circ$.

TABLE C-14. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 1		CURVE 2 (CONT.)		CURVE 2 (CONT.)		CURVE 3 (CONT.)		CURVE 4 (CONT.)		CURVE 5 (CONT.)	
		λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
$T = 293$.													
0.0579	0.163	0.0642	0.288	0.149	0.131	0.118	0.243	0.100	0.339	0.0709	0.530		
0.0731	0.181	0.0656	0.274	0.153	0.131	0.120	0.238	0.104	0.330	0.0708	0.511		
0.0907	0.151	0.0692	0.267	0.156	0.127	0.120	0.239	0.106	0.321	0.0742	0.501		
0.106	0.151	0.0730	0.245	0.158	0.123	0.122	0.233	0.107	0.312	0.0770	0.471		
0.119	0.151	0.0712	0.250	0.127	0.250	0.126	0.225	0.110	0.307	0.0784	0.467		
0.118	0.152	0.0742	0.232	0.129	0.233	0.129	0.233	0.113	0.299	0.0926	0.467		
0.118	0.153	0.0765	0.217	0.131	0.237	0.121	0.237	0.116	0.297	0.0849	0.467		
0.126	0.155	0.0784	0.213	0.134	0.236	0.119	0.288	0.0896	0.475				
0.136	0.158	0.0826	0.218	0.135	0.230	0.120	0.284	0.0511	0.466				
0.147	0.153	0.0849	0.219	0.137	0.224	0.122	0.284	0.0946	0.458				
0.160	0.157	0.0892	0.244	0.141	0.368	0.122	0.288	0.0976	0.451				
0.181	0.123	0.0911	0.247	0.149	0.403	0.124	0.273	0.100	0.433				
0.193	0.099	0.0946	0.248	0.152	0.398	0.126	0.275	0.105	0.416				
0.219	0.091	0.0976	0.236	0.152	0.428	0.126	0.277	0.105	0.416				
0.233	0.076	0.1030	0.231	0.155	0.439	0.127	0.283	0.107	0.402				
0.266	0.043	0.1044	0.225	0.157	0.442	0.130	0.288	0.110	0.401				
0.223	0.022	0.105	0.229	0.159	0.423	0.131	0.284	0.112	0.398				
0.296	0.017	0.107	0.209	0.160	0.395	0.134	0.281	0.119	0.363				
0.306	0.022	0.110	0.196	0.163	0.412	0.136	0.275	0.118	0.378				
0.308	0.030	0.113	0.193	0.164	0.396	0.136	0.275	0.119	0.387				
0.315	0.044	0.115	0.194	0.167	0.377	0.139	0.266	0.120	0.376				
0.339	0.076	0.116	0.192	0.169	0.355	0.139	0.260	0.121	0.353				
0.359	0.104	0.118	0.183	0.170	0.342	0.157	0.332	0.124	0.372				
0.399	0.151	0.120	0.175	0.172	0.338	0.159	0.324	0.124	0.365				
0.440	0.178	0.122	0.175	0.174	0.322	0.167	0.315	0.125	0.376				
		0.122	0.188	0.177	0.291	0.139	0.260	0.126	0.363				
$T = 293$.													
0.0433	0.073	0.127	0.179	0.182	0.291	0.0645	0.469	0.0433	0.605	0.129	0.369		
0.0456	0.102	0.127	0.181	0.185	0.287	0.0666	0.452	0.0454	0.513	0.131	0.372		
0.0465	0.123	0.130	0.183	0.189	0.296	0.0688	0.430	0.0471	0.623	0.131	0.352		
0.0469	0.162	0.131	0.185	0.192	0.311	0.0700	0.406	0.0482	0.641	0.133	0.363		
0.0525	0.216	0.139	0.174	0.194	0.320	0.0712	0.406	0.0508	0.642	0.134	0.354		
0.0636	0.293	0.140	0.156	0.195	0.315	0.0645	0.469	0.0433	0.605	0.137	0.348		
0.0576	0.302	0.142	0.151	0.197	0.316	0.0665	0.452	0.0539	0.678	0.139	0.343		
0.0640	0.253	0.143	0.156	0.198	0.316	0.0742	0.388	0.0527	0.652				
0.0596	0.303	0.144	0.156	0.198	0.316	0.0770	0.355	0.0539	0.678				
0.0688	0.293	0.144	0.156	0.198	0.316	0.0832	0.357	0.0596	0.691				
0.0607	0.249	0.145	0.156	0.198	0.316	0.0849	0.351	0.0607	0.552				
0.0635	0.302	0.145	0.156	0.198	0.316	0.0898	0.368	0.0635	0.602				
0.0642	0.253	0.145	0.156	0.198	0.316	0.0918	0.370	0.0642	0.593				
0.0666	0.252	0.145	0.156	0.198	0.316	0.0953	0.366	0.0666	0.571				
0.0688	0.293	0.145	0.156	0.198	0.316	0.0976	0.356	0.0688	0.551				
$T = 293$.													
0.0770	0.293	0.146	0.157	0.199	0.317	0.0770	0.355	0.0770	0.642				
0.0784	0.252	0.146	0.157	0.199	0.317	0.0784	0.357	0.0784	0.642				
0.0793	0.251	0.146	0.157	0.199	0.317	0.0793	0.357	0.0793	0.642				
0.0796	0.252	0.146	0.157	0.199	0.317	0.0806	0.357	0.0806	0.642				
0.0818	0.252	0.146	0.157	0.199	0.317	0.0818	0.357	0.0818	0.642				
0.0832	0.252	0.146	0.157	0.199	0.317	0.0832	0.357	0.0832	0.642				
0.0849	0.249	0.146	0.156	0.198	0.316	0.0849	0.351	0.0849	0.642				
0.0865	0.252	0.146	0.156	0.198	0.316	0.0865	0.355	0.0865	0.642				
0.0882	0.252	0.146	0.156	0.198	0.316	0.0882	0.355	0.0882	0.642				
0.0898	0.252	0.146	0.156	0.198	0.316	0.0898	0.358	0.0898	0.642				
0.0918	0.252	0.146	0.156	0.198	0.316	0.0918	0.358	0.0918	0.642				
0.0936	0.252	0.146	0.156	0.198	0.316	0.0936	0.358	0.0936	0.642				
0.0953	0.252	0.146	0.156	0.198	0.316	0.0953	0.358	0.0953	0.642				
0.0976	0.252	0.146	0.156	0.198	0.316	0.0976	0.358	0.0976	0.642				
0.1000	0.252	0.146	0.156	0.198	0.316	0.1000	0.358	0.1000	0.642				
0.1044	0.252	0.146	0.156	0.198	0.316	0.1044	0.358	0.1044	0.642				
0.1088	0.252	0.146	0.156	0.198	0.316	0.1088	0.358	0.1088	0.642				
0.1132	0.252	0.146	0.156	0.198	0.316	0.1132	0.358	0.1132	0.642				
0.1176	0.252	0.146	0.156	0.198	0.316	0.1176	0.358	0.1176	0.642				
0.1220	0.252	0.146	0.156	0.198	0.316	0.1220	0.358	0.1220	0.642				
0.1264	0.252	0.146	0.156	0.198	0.316	0.1264	0.358	0.1264	0.642				
0.1308	0.252	0.146	0.156	0.198	0.316	0.1308	0.358	0.1308	0.642				
0.1352	0.252	0.146	0.156	0.198	0.316	0.1352	0.358	0.1352	0.642				
0.1396	0.252	0.146	0.156	0.198	0.316	0.1396	0.358	0.1396	0.642				
0.1440	0.252	0.146	0.156	0.198	0.316	0.1440	0.358	0.1440	0.642				
0.1484	0.252	0.146	0.156	0.198	0.316	0.1484	0.358	0.1484	0.642				
0.1528	0.252	0.146	0.156	0.198	0.316	0.1528	0.358	0.1528	0.642				
0.1572	0.252	0.146	0.156	0.198	0.316	0.1572	0.358	0.1572	0.642				
0.1616	0.252	0.146	0.156	0.198	0.316	0.1616	0.358	0.1616	0.642				
0.1660	0.252	0.146	0.156	0.198	0.316	0.1660	0.358	0.1660	0.642				
0.1704	0.252	0.146	0.156	0.198	0.316	0.1704	0.358	0.1704	0.642				
0.1748	0.252	0.146	0.156	0.198	0.316	0.1748	0.358	0.1748	0.642				
0.1792	0.252	0.146	0.156	0.198	0.316	0.1792	0.358	0.1792	0.642				
0.1836	0.252	0.146	0.156	0.198	0.316	0.1836	0.358	0.1836	0.642				
0.1880	0.252	0.146	0.156	0.198	0.316	0.1880	0.358	0.1880	0.642				
0.1924	0.252	0.146	0.156	0.198	0.316	0.1924	0.358	0.1924	0.642				
0.1968	0.252	0.146	0.156	0.198	0.316	0.1968	0.358	0.1968	0.642				
0.2012	0.252	0.146	0.156	0.198	0.316	0.2012	0.358	0.2012	0.642				
0.2056	0.252	0.146	0.156	0.198	0.316	0.2056	0.358	0.2056	0.642				
0.2100	0.252	0.146	0.156	0.198	0.316	0.2100	0.358	0.2100	0.642				
0.2144	0.252	0.146	0.156	0.198	0.316	0.2144	0.358	0.2144	0.642				
0.2188	0.252												

TABLE 6-13. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE) (CONTINUE¹)
(WAVELENGTH, λ ; μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	CURVE 6 (CONT.)	λ	ρ	CURVE 8 (CONT.)	λ	ρ	CURVE 9 (CONT.)	λ	ρ	CURVE 9 (CONT.)	λ	ρ	CURVE 10 (CONT.)		
0.2825	0.135	5.6	0.057	2.0	0.088	4.3.6	0.306	24.2	0.594	24.2	0.594	45.7	0.284	25.4	0.520	
0.3063	0.369	7.9	0.047	3.8	0.088	46.7	0.257	26.4	0.547	26.4	0.547	47.5	0.234	27.1	0.464	
0.3255	0.468	8.8	0.034	5.2	0.063	47.5	0.244	27.1	0.464	27.1	0.464	50.0	0.244	27.5	0.439	
0.3605	0.506	10.0	0.020	6.4	0.042	50.0	0.244	27.5	0.439	27.5	0.439	50.0	0.244	28.6	0.423	
0.3732	0.538	10.2	0.200	8.5	0.026	50.0	0.244	28.6	0.423	28.6	0.423	50.0	0.244	29.9	0.375	
0.4365	0.723	10.6	0.327	9.2	0.000	50.0	0.244	29.9	0.375	32.7	0.379	50.0	0.244	34.3	0.363	
0.4926	0.791	11.5	0.459	10.6	0.035	50.0	0.244	34.3	0.363	36.8	0.369	50.0	0.244	36.8	0.369	
CURVE 7 $T = 293.$		12.4	0.036	11.1	0.362	50.0	0.244	36.8	0.369	41.4	0.369	50.0	0.244	41.4	0.369	
12.6		0.299	11.4	0.713	2.0	0.100	50.0	0.244	41.4	0.369	45.4	0.352	50.0	0.244	45.4	0.352
13.2		0.363	11.4	0.713	3.8	0.100	50.0	0.244	45.4	0.352	50.0	0.244	50.0	0.244	50.0	0.340
0.0268	0.112	13.5	0.543	11.9	0.914	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.3336	0.015	13.8	0.575	12.9	0.968	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0395	0.322	14.3	0.517	13.2	0.991	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0473	0.322	15.3	0.423	14.0	0.991	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0444	0.32	16.0	0.405	15.1	0.944	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0474	0.444	16.6	0.442	15.5	0.900	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0522	0.373	17.2	0.518	15.6	0.894	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.3555	0.387	17.7	0.552	15.2	0.804	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.3997	0.094	18.0	0.571	16.7	0.705	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0640	0.397	18.7	0.571	17.4	0.663	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0658	0.394	20.0	0.503	17.6	0.494	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0713	0.335	21.0	0.451	18.2	0.405	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0738	0.085	22.2	0.400	19.3	0.258	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0796	0.094	23.5	0.364	19.9	0.347	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.3667	0.113	25.1	0.326	20.1	0.265	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0696	0.116	26.6	0.300	20.5	0.227	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0391	0.115	28.7	0.274	20.8	0.564	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.0365	0.120	31.0	0.253	21.0	0.790	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.109	0.134	33.6	0.234	21.5	0.876	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.116	0.146	35.0	0.227	22.3	0.771	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.128	0.172	36.6	0.209	22.6	0.616	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.131	0.175	41.4	0.223	23.9	0.461	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
0.153	0.127	45.5	0.226	25.7	0.414	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
CURVE 8 $T = 293.$		46.5	0.244	26.4	0.502	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
47.8		0.265	27.4	0.441	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244		
48.8		0.308	28.6	0.399	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244		
50.6		6.339	33.0	0.362	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244		
2.0	0.093	34.0	0.364	22.1	0.859	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
3.8	0.098	38.5	0.364	22.6	0.798	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	
4.5	0.398	40.9	0.351	23.8	0.657	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	50.0	0.244	

e. Normal Spectral Absorptance (Wavelength Dependence)

A total of five sets of experimental data were located for the wavelength dependence of the normal spectral absorptance of aluminum oxide. This data is listed in Table 6-12 and shown in Figure 6-11. Specimen characterization and measurement information for the data are given in Table 6-11.

The data are all for wavelengths below 1 μm and, hence, no data evaluation is justified.

Since $\alpha = \epsilon$ by Kirchhoff's law (Eq. 2.3-7), the provisional values for normal spectral emittance of Coors AD 99 also apply to the normal spectral absorptance. See Table 6-1 for a listing of these provisional values and Figures 6-1, 6-2, and 6-3 for a graphical presentation.




FIGURE 6-11. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).

TABLE 6-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM OXIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T40412	Schutt, J. B. and Macklin, B. A.	1964	0.3-0.5	293		High purity γ - Al_2O_3 ; measured in vacuum; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$.
2 T40412	Schutt, J. B. and Macklin, B. A.	1964	0.3-0.5	293		The above specimen except subjected to 50 solar actinic hr using Hanovia 673A high pressure mercury lamp in a vacion system.
3 T40412	Schutt, J. B. and Macklin, B. A.	1964	0.3-0.5	293		High purity γ - Al_2O_3 ; slurred with 0.02 mole % H_2SO_4 , dried, pressed into a pellet; measured in vacuum; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$.
4 T40412	Schutt, J. B. and Macklin, B. A.	1964	0.3-0.4	293		The above specimen except subjected to 50 solar actinic hr using Hanovia 673A high pressure mercury lamp in a vacion system.
5 T40563	Dubs, C. W.	1966	0.30-0.70	293	Alucer MC	Compacted powder; data from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta \sim 0^\circ$.

TABLE 6-12. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

λ	α
CURVE 1 $T = 293.$	
0.3	0.96
0.5	0.95
CURVE 2 $T = 293.$	
0.3	0.75
0.5	0.90
CURVE 3 $T = 293.$	
0.3	0.76
0.5	0.92
CURVE 4 $T = 293.$	
0.3	0.44
0.4	0.66
CURVE 5 $T = 293.$	
0.305	0.696
0.351	0.924
0.406	0.927
0.450	0.922
0.505	0.913
0.550	0.915
0.600	0.917
0.650	0.920
0.705	0.924

f. Normal Spectral Absorptance (Temperature Dependence)

No experimental data was found for the temperature dependence of the normal spectral absorptance of aluminum oxide.

By Kirchhoff's law (Eq. 2.3-7) the provisional values for the temperature dependence of the normal spectral emittance are equal to the values for the temperature dependence of the normal spectral absorptance. See Table 6-4 for the listing of the provisional values and Figure 6-7 for a visual presentation.

g. Hemispherical Spectral Transmittance (Wavelength Dependence)

A total of 16 sets of experimental data were located for the wavelength dependence of the hemispherical spectral transmittance of aluminum oxide. These data are listed in Table 6-14 and shown in Figure 6-12. Specimen characterization and measurement information for the data are given in Table 6-13.

The data are all at room temperature and cover a wavelength range of 1 to 8 μm . The data are widely spaced, having come from tabular form, and drawing a smooth curve through the points for data evaluation is not justified. Lines are drawn between the data points in Figure 6-12 to aid in visualizing the data and do not imply a smooth curve connecting the data points.




FIGURE 6-12. EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).

TABLE 6-13. MEASUREMENT INFORMATION ON THE HEMISPHERICAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T29570	Folweiler, R.C.	1964	1-8	293	McDanel AV30 alumina	96 pure; vitrified alumina; specimen 0.25 by 0.62 in. in cross section and 0.127 mm thick; measurement temperature not given explicitly, assumed to be 293 K; diffusing screen used in front of specimen; $\omega = 2\pi$, $\theta \sim 0^\circ$; reported error $\pm 5\%$.
2 T29570	Folweiler, R.C.	1964	1-8	293	McDanel AV30 alumina	Similar to the above specimen except 0.254 mm thick.
3 T29570	Folweiler, R.C.	1964	1-8	293	McDanel AP35 alumina, No. 3	Similar to the above specimen except 99 pure and 0.127 mm thick.
4 T29570	Folweiler, R.C.	1964	1-8	293	McDanel AP35 alumina, No. 3	Similar to the above specimen except 0.254 mm thick.
5 T29570	Folweiler, R.C.	1964	1-8	293	McDanel AP35 alumina, No. 4	Similar to the above specimen except 0.254 mm thick.
6 T29570	Folweiler, R.C.	1964	1-8	293	McDanel AP35 alumina, No. 4	Similar to the above specimen except 0.254 mm thick.
7 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-85 alumina	Similar to the above specimen except 85 pure and 0.127 mm thick.
8 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-85 alumina	Similar to the above specimen except 0.254 mm thick.
9 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-94 alumina	Similar to the above specimen except 94 pure and 0.127 mm thick.
10 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-94 alumina	Similar to the above specimen except 0.254 mm thick.
11 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-96 alumina	Similar to the above specimen except 96 pure and 0.127 mm thick.
12 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-96 alumina	Similar to the above specimen except 0.254 mm thick.
13 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-99 alumina	Similar to the above specimen except 99 pure and 0.127 mm thick.
14 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-99 alumina	Similar to the above specimen except 0.254 mm thick.
15 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-96 alumina	Similar to the above specimen except 1 Co ₃ O ₄ and 0.005 in. thick.
16 T29570	Folweiler, R.C.	1964	1-8	293	Coors AD-96 alumina	Similar to the above specimen except 0.010 in. thick.

TABLE 6-14. EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
CURVE 1 $T = 293.$											
1.	0.480	5.	0.483								
2.	0.453	6.	0.119								
4.	0.517	CURVE 5 (CONT.)									
5.	0.531	CURVE 6 $T = 293.$									
5.	0.000										
CURVE 2 $T = 293.$											
1.	0.357	1.	0.338								
2.	0.310	2.	0.383								
4.	0.419	4.	0.397								
5.	0.348	5.	0.346								
6.	0.330	6.	0.023								
CURVE 3 $T = 293.$											
1.	0.471	1.	0.435								
2.	0.437	2.	0.365								
4.	0.462	4.	0.443								
5.	0.430	5.	0.303								
6.	0.003	6.	0.000								
CURVE 4 $T = 293.$											
1.	0.325	1.	0.303								
2.	0.371	2.	0.202								
4.	0.363	4.	0.216								
5.	0.339	CURVE 3 $T = 293.$									
6.	0.003										
CURVE 5 $T = 293.$											
1.	0.458	1.	0.414								
2.	0.539	2.	0.373								
4.	0.495	4.	0.358								
			0.398								
			0.000								
			0.000								
			0.446								
			0.445								
			0.433								

CURVE 16

T = 293.

0.378

0.380

0.080

1.

0.306

0.237

0.390

0.326

0.000

1.

0.322

0.276

0.296

0.268

0.043

1.

0.306

0.237

0.390

0.326

0.000

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

0.268

0.043

1.

0.322

0.276

0.296

h. Normal Spectral Transmittance (Wavelength Dependence)

A total of 18 sets of experimental data were located for the wavelength dependence of the normal spectral transmittance of aluminum oxide. These data are listed in Table 6-16 and shown in Figure 6-13. Specimen characterization and measurement information for the data are given in Table 6-15.

Because the data that are potentially useful are widely spaced, no evaluated data can be given. The lines connecting such data points do not imply a smooth curve.




FIGURE 6-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE).

TABLE 6-15. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T29570	Folweiler, R.C.	1964	1-7	293	Linde	Singic crystal from Linde; specimen dimensions 0.125 by 0.5 by 1.5 in.; measurement temperature specified as room temperature, 293 K assigned; $\theta \sim 0^\circ$, $\theta' \sim 0^\circ$; reported error $\pm 5\%$. The above specimen.
2 T29570	Folweiler, R.C.	1964	1-7	785	Linde	The above specimen.
3 T29570	Folweiler, R.C.	1964	1-7	960	Linde	The above specimen.
4 T29570	Folweiler, R.C.	1964	1-7	1177	Linde	The above specimen.
5 T29570	Folweiler, R.C.	1964	1-7	1411	Linde	The above specimen.
6 T29570	Folweiler, R.C.	1964	1-7	1567	Linde	The above specimen.
7 T29570	Folweiler, R.C.	1964	1-7	1671	Linde	The above specimen.
8 T34908	Schartz, E.A.	1966	0.35-2.7	293		>99 pure; specimen 0.0185 in. thick; compacted powder; compaction pressure 11 800 psi; smooth values from figure.
9 T24968	Schartz, E.A.	1966	0.35-2.7	293		Similar to the above specimen except compaction pressure 75 500 psi.
10 T34913	Forestier, A.F. and Grimes, H.H.	1966	2.19-0.74	293		High purity α - Al_2O_3 ; disc specimen 1/10 in. thick and 3/8 in. in diameter; c-axis 60° from the normal of the specimen surface; polished, notched for alignment purposes and annealed in air for 1 hr at 1273 K; surface reflections included; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$, $\theta' = 0^\circ$.
11 T36324	McCarthy, D.E.	1965	2.0-6.7	293	Ruby	0.05 Cr, essentially sapphire with the chromium impurity; synthetic; specimen 6.10 mm thick; flat to 10 fringes or better; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$, $\theta' = 0^\circ$.
12 T36324	McCarthy, D.E.	1965	2.0-7.0	293	Sapphire	Synthetic; specimen 3.0 mm flat; flat to 10 fringes or better; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; black of absorption band at 2.7 μ , compared to T30100 (see curve No. 30); attributed to this present specimen having impurities eliminated; $\theta = 0^\circ$, $\theta' = 0^\circ$. Specimen 0.5 mm thick; reflection lenses included; smooth values from figure; $\theta \sim 0^\circ$, $\theta' \sim 0^\circ$.
13 T5481	Boldt, G.	1965	0.14-0.35	293		Similar to the above specimen except 2 mm thick.
14 T45451	Boldt, G.	1965	0.14-0.35	293		99% pure; rhombohedral crystal structure; disk 1 mm thick and 12 mm in diameter; Baird Associates Model B spectrophotometer used; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
15 T3470	Brame, E.G., Jr., and Margrave, J.L., and Meloche, V.W.	1957	2-16	293		Synthetic; specimen 2 mm thick; ground and polished to a flatness of seven fringes or better; reference standard was aluminum mirror; smooth values from figure; IR-5A used in 2-16 μm range; $\theta = 0^\circ$, $\theta' = 0^\circ$. Author reports measured transmissivity; data from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$, $\theta' = 15/4\pi$.
16 T3470	McCarthy, D.E.	1953	2.0-6.6	293	Sapphire	Similar to the above specimen.
17 T39365	Hobbs, H.A. and Folweiler, R.C.	1966	1.0-5.0	293	AD-995	
18 T39365	Hobbs, H.A. and Folweiler, R.C.	1966	1.0-5.0	293	AD-85	

TABLE 6-16. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
CURVE 1 $T = 293.$													
1.	0.76	7.	0.60	1.0	0.149	1.009	6.0	0.154	6.0	0.107	3.60	0.806	
2.	0.63	CURVE 5 $T = 1411.$		1.0	0.208	0.011	6.2	0.055	6.144	0.02	4.02	0.804	
3.	0.84	CURVE 5 $T = 1411.$		1.0	0.027	1.780	6.7	0.000	6.147	0.171	4.21	0.823	
4.	0.66	1.	0.73	2.148	0.046	2.419	0.058	0.064	6.152	0.243	4.35	0.833	
5.	0.68	2.	0.83	2.419	0.064	2.650	0.064	CURVE 12 $T = 293.$		0.157	0.311	4.72	0.829
6.	0.34	3.	0.80	2.650	0.064	CURVE 9 $T = 293.$		2.0	0.887	0.162	0.370	4.88	0.817
7.	0.00	4.	0.73	2.650	0.064	CURVE 9 $T = 293.$		3.8	0.887	0.159	0.443	5.00	0.815
CURVE 2 $T = 785.$													
1.	0.76	5.	0.16	0.350	0.000	4.5	0.876	0.187	0.587	5.85	0.838		
2.	0.83	6.	0.61	0.649	0.006	5.1	0.843	0.192	0.617	6.01	0.802		
3.	0.84	7.	0.60	1.0	0.021	5.3	0.593	0.198	0.646	6.38	0.752		
4.	0.81	CURVE 6 $T = 1567.$		1.0	0.147	1.045	5.7	0.379	0.206	0.678	6.15	0.756	
5.	0.40	2.	0.73	1.475	0.045	6.2	0.130	0.215	0.707	6.17	0.632		
6.	0.03	3.	0.63	1.765	0.079	6.4	0.056	0.223	0.728	6.23	0.712		
7.	0.00	4.	0.62	1.984	0.110	7.0	0.000	0.233	0.746	6.45	0.778		
CURVE 3 $T = 960.$													
1.	0.76	5.	0.71	2.185	0.151	2.479	0.199	CURVE 13 $T = 293.$		0.248	0.766	6.67	0.795
2.	0.81	6.	0.63	2.479	0.199	2.593	0.215	0.261	0.779	6.92	0.773		
3.	0.84	7.	0.62	2.593	0.215	2.650	0.208	0.289	0.793	7.11	0.746		
4.	0.81	CURVE 10 $T = 293.$		4.	0.71	0.208	0.144	0.476	0.311	0.806	6.23	0.766	
5.	0.15	5.	0.15	0.62	0.147	0.552	0.147	0.552	0.333	0.821	7.42	0.779	
6.	0.01	6.	0.01	0.62	0.149	0.595	0.149	0.595	0.350	0.829	7.52	0.779	
7.	0.00	CURVE 10 $T = 293.$		7.	0.6	CURVE 7 $T = 1671.$		0.152	0.621	0.289	0.766	8.30	0.762
CURVE 4 $T = 1177.$													
1.	0.73	2.	0.93	0.193	0.624	0.200	0.659	0.158	0.656	8.56	0.754		
2.	0.82	3.	0.82	0.229	0.702	0.305	0.755	0.165	0.691	8.79	0.683		
3.	0.80	4.	0.73	0.73	0.755	0.73	0.755	0.173	0.718	9.12	0.638		
5.	0.33	1.	0.33	0.83	0.492	0.794	0.73	0.191	0.764	2.00	0.664		
6.	0.01	2.	0.33	0.52	0.738	0.794	0.73	0.204	0.766	2.23	0.699		
7.	0.00	3.	0.15	0.71	0.794	0.794	0.73	0.222	0.608	2.36	0.72		
CURVE 11 $T = 293.$													
1.	0.76	2.	0.93	0.193	0.624	0.200	0.659	0.158	0.656	3.71	0.660		
2.	0.82	3.	0.82	0.229	0.702	0.305	0.755	0.165	0.691	3.71	0.645		
3.	0.80	4.	0.73	0.73	0.755	0.73	0.755	0.173	0.718	3.71	0.67		
5.	0.33	1.	0.33	0.52	0.738	0.794	0.73	0.204	0.766	2.70	0.690		
6.	0.01	2.	0.15	0.71	0.794	0.794	0.73	0.222	0.608	2.76	0.625		
7.	0.00	CURVE 11 $T = 293.$		7.	0.6	0.200	0.659	0.266	0.825	2.79	0.470	10.60	0.533
CURVE 15 $T = 293.$													
1.	0.73	2.	0.83	0.193	0.624	0.200	0.659	0.301	0.629	2.82	0.436		
2.	0.83	3.	0.81	0.226	0.702	0.305	0.755	0.326	0.633	3.58	0.386		
3.	0.81	4.	0.79	0.73	0.738	0.73	0.738	0.350	0.635	2.94	0.448		
4.	0.78	5.	0.60	0.71	0.794	0.794	0.73	0.400	0.240	12.74	0.145		
5.	0.28	6.	0.01	0.359	0.003	0.64	0.406	0.253	0.32	0.747	13.04		
6.	0.01	CURVE 15 $T = 293.$		6.	0.650	0.004	0.650	0.253	0.660	3.32	0.760	13.63	
										3.68	0.795	14.26	

TABLE 6-16. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ALUMINUM OXIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ]

λ τ
 CURVE 15 (CONT.)

14.65	0.145
14.94	0.172
15.43	0.225
15.74	0.280
16.06	0.349

CURVE 16
 $T = 293.$

2.0	0.869
2.5	0.855
2.8	0.825
3.4	0.835
3.8	0.863
4.6	0.827
5.4	0.494
5.7	0.297
6.0	0.152
6.3	0.057
6.6	0.000

CURVE 17
 $T = 293.$

1.05	0.047
2.30	0.059
3.36	0.065
4.30	0.100
4.97	0.150

CURVE 18
 $T = 293.$

1.00	0.0254
2.00	0.0126
3.00	0.0115
4.00	0.0462
5.00	0.0029

4.7. Boron Nitride

Boron nitride is a material that is man-made and has no counterpart in nature. It exists in several forms. There is a soft hexagonal form, a hard cubic form, and a hard hexagonal form. Pure boron nitride sublimes at 3273 K and 1 atmosphere while the commercial forms sublime at 3003 K and one atmosphere [E12808].

The soft hexagonal form has a layer-lattice structure similar to graphite. It can be made in two ways. One method of manufacture is by hot pressing. The second method is by chemical vapor deposition (CVD) with this type also known as pyrolytic boron nitride.

The hard cubic form has a zincblende structure. The density is 3.45 g cm^{-3} [A00014]. Borazon, a trademark of the General Electric Company, is cubic boron nitride manufactured by the GE Specialty Materials Department, Worthington, Ohio. The Russian names for cubic boron nitride are Elbor and Cubonite. The cubic form is harder than diamond and is probably the hardest material on earth.

The hard hexagonal form has a wurtzite structure and only small amounts have been synthesized.

The application of boron nitride includes furnace insulation, high temperature lubrication (the graphite-like form), dielectrics, wave guides, heat shields for plasmas, and nose cone windows.

a. Normal Spectral Emittance (Wavelength Dependence)

A total of 19 sets of experimental data were located for the wavelength dependence of the normal spectral emittance of boron nitride. The data are listed in Table 7-3 and shown in Figures 7-1 and 7-2. Specimen characterization and measurement information for the data are given in Table 7-2.

Seven sets of data are for pyrolytic boron nitride (curves 11-17) specimens manufactured by High Temperature Materials, Inc., of Lowell, Massachusetts. Only for three data sets (curves 15-17) were specimen dimensions given. These three data sets cover a temperature range of 1280 to 2020 K and are very close to each other. A set of provisional values is, therefore, based on curves 15, 16, and 17 with these values valid within the following context: a 0.5 in. thick specimen of polished pyrolytic boron nitride manufactured by High Temperature Materials, Inc., with the surface parallel to the basal planes radiating. The values, within an uncertainty of 15%, hold for temperatures of 1280, 1670, and 2020 K. The provisional values are listed in Table 7-1 and shown in Figure 7-1.

Four sets of data (curves 7, 8, 10, and 18) are for 97% pure boron nitride manufactured by the Carborundum Corporation. The material for curve 9 reported by Browning, [T3747&] had a density close to the density of the material for curves 7, 8, 10, and 18 and was, therefore, probably 97% pure.

The crystal structure for the remaining data sets was not reported and, therefore, these sets cannot be used for developing evaluated data.

TABLE 7-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF DOPED NITRIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
PYROLYtic, POLISH 1.27CM THICK $T = 1670$									
PYROLYtic, POLISH 1.27CM THICK $T = 1670$ (CONT.)									
2.5	0.759	6.3	0.648	9.6	0.834	13.2	0.634		
2.6	0.762	6.4	0.808	9.7	0.838	13.3	0.641		
2.7	0.765	6.5	0.754	9.8	0.642	13.4	0.647		
2.8	0.770	6.6	0.680	9.9	0.645	13.5	0.653		
2.9	0.774	6.7	0.620	10.0	0.648	13.6	0.658		
3.0	0.778	6.8	0.535	10.1	0.651	13.7	0.663		
3.1	0.781	6.9	0.480	10.2	0.654	13.8	0.668		
3.2	0.785	7.0	0.442	10.3	0.657	13.9	0.672		
3.3	0.789	7.05	0.422	10.4	0.660	14.0	0.676		
3.4	0.792	7.12	0.404	10.5	0.663	14.1	0.680		
3.5	0.796	7.15	0.389	10.6	0.666	14.2	0.684		
3.6	0.799	7.20	0.377	10.7	0.669	14.3	0.686		
3.7	0.803	7.25	0.371	10.8	0.672	14.4	0.692		
3.8	0.806	7.30	0.369	10.9	0.675	14.5	0.696		
3.9	0.810	7.35	0.370	11.0	0.678	14.6	0.699		
4.0	0.814	7.40	0.377	11.1	0.681	14.7	0.704		
4.1	0.819	7.45	0.387	11.2	0.684	14.8	0.707		
4.2	0.824	7.50	0.400	11.3	0.687	14.9	0.911		
4.3	0.831	7.55	0.416	11.4	0.690	15.0	0.914		
4.4	0.839	7.60	0.443	11.5	0.693				
4.5	0.846	7.70	0.495	11.6	0.696				
4.6	0.856	7.8	0.543	11.7	0.698				
4.7	0.865	7.9	0.572	11.8	0.700				
4.8	0.874	8.0	0.651	11.9	0.702				
4.9	0.894	8.1	0.690	12.0	0.703				
5.0	0.892	8.2	0.718	12.1	0.704				
5.1	0.901	8.3	0.737	12.2	0.704				
5.2	0.909	8.4	0.752	12.3	0.704				
5.3	0.916	8.5	0.763	12.4	0.704				
5.4	0.924	8.6	0.774	12.5	0.703				
5.5	0.931	8.7	0.783	12.6	0.700				
5.6	0.936	8.8	0.791	12.7	0.699				
5.7	0.938	8.9	0.798	12.8	0.671				
5.8	0.943	9.0	0.805	12.9	0.647				
5.9	0.939	9.1	0.811	12.95	0.633				
6.0	0.935	9.2	0.816	12.99	0.629				
6.1	0.930	9.3	0.820	13.0	0.628				
6.2	0.921	9.4	0.825	13.05	0.627				
	0.890	9.5	0.830	13.1	0.626				

PYROLYtic, POLISH
1.27CM THICK
 $T = 1670$ (CONT.)




FIGURE 7-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH: DEPENDENCE).




TABLE 7-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T16606	Blau, H.H., Jr., Marsh, J.B., Martin, W.S., Jasperse, J.R., and Chaffee, E. et al.	1960	2-14	873		Measured in air; measurements made with Perkin-Elmer Model 12C Infrared Spectrometer with sodium chloride prism; data from figure; $\theta^* = 0^\circ$; reported error $\pm 4\%$.
2 T16606	Blau, H.H., Jr., et al.	1960	2-14	1063		Similar to the above specimen.
3 T16606	Blau, H.H., Jr., et al.	1960	1.5-14	1353		Similar to the above specimen.
4 T16666	Blau, H.H., Jr., et al.	1960	0.85-13	2273		Specimen heated in air/solar furnace used in attempt to measure spectral reflectance in 1273-3273 K region; data not accurate; data from figure; $\theta^* = 0^\circ$.
5 T26088	Walker, G.H. and Casey, F.W., Jr.	1962	0.5-15	1033		Specimen 0.643 cm thick and in form of a semicircle; pressed; machined from 10.15 cm diameter round stock, initial specimens carefully polished on decreasing grits of emery paper to insure a uniform surface, dried at 373 K to remove any absorbed water; $\theta^* = 0^\circ$.
6 T26088	Walker, G.H. and Casey, F.W., Jr.	1962	0.6-15	1033		The above specimen, second test.
7 T35502	Grais, A.F. and Levitt, A.P.	1965	1-10	1300		97.00 BN, 2.40 B_2O_3 , 0.20 Al_2O_3 and SiO_2 , 0.10 alkaline earth oxides, and 0.008 C; hexagonal crystal structure; machine finished; from Carborundum Co., New Products Branch, Niagara Falls, N.Y.; surface roughness 110 μ in.; bulk density 2.15 g cm^{-3} ; measured in vacuum of 35 to 50 μ of pressure; smooth values from figure; $\theta^* = 0^\circ$.
8 T35502	Grais, A.F. and Levitt, A.P.	1965	1-10	1300		Similar to the above specimen except surface finished by polishing with silk cloth.
9 T37478	Brownrigg, M.E.	1963	1.0-15	1273		Sintered; from Carborundum Corp.; density 2.09 g cm^{-3} ; reference standard MgO ; smooth values from figure; $\theta^* = 0^\circ$; reported error $\pm 5\%$.
10 T52946	Autio, G.W. and Scala, E.	1968	0.53-11	1098		97.0 BN, 2-40 methanol soluble borate, 0.10 alkaline earth oxides, 0.20 alumina and silica, and 0.008 carbon, polycrystalline; hot-pressed; fabricated by Carborundum Co.; surfaces mechanically polished; density 2.1 g cm^{-3} ; specimen temperature between 1093 and 1103 K; measured in purified hydrogen atm; probing technique used; data from figure; $\theta^* = 0^\circ$.
11 T52946	Autio, G.W. and Scala, E.	1968	0.55-11	1098	Pyrolytic	Purity < 0.010 total metallic impurities; measured from A-face (c -axis parallel to surface of (1010) faces); pyrolytic, made by vapor deposition process; prepared by High Temperature Materials, Inc.; surface mechanically polished; density $\sim 2.2 \text{ g cm}^{-3}$, specimen temperature between 1093 and 1103 K; measured in purified hydrogen atm; probing technique used; data from figure; $\theta^* = 0^\circ$.
12 T52946	Autio, G.W. and Scala, E.	1968	0.56-11	1098	Pyrolytic	Similar to the above specimen and conditions except measured from C-face (a -axis parallel to surface of (0001) face).
13 T52946	Autio, G.W. and Scala, E.	1968	1.1-2.6	1103	Pyrolytic	Similar to the above specimen and conditions except measured from A-face and polarizer axis parallel to c -axis.
14 T52946	Autio, G.W. and Scala, E.	1968	1.1-2.6	1103	Pyrolytic	Similar to the above specimen and conditions except polarizer axis perpendicular to c -axis.

TABLE 7-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMMITTANCE OF BORON NITRIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
15 T34724	Durand, J. L. and Houston, K.C.	1966	2.5-15	~1280	Pyrolytic	Specimen size about 2 x 3 x 0.5 in.; manufactured by High Temperature Materials, Inc., Lowell, Mass.; surface polished to a 4-6 μm finish; AB surface (surface parallel to basal planes or planes of deposition) radiating; Beckman IR-9 spectrophotometer used; data from figure; θ* = 0°.
16 T34724	Durand, J. L. and Houston, K.C.	1966	2.5-15	1670	Pyrolytic	Similar to the above specimen.
17 T34724	Durand, J. L. and Houston, K.C.	1966	2.5-15	2020	Pyrolytic	Similar to the above specimen.
18 T22272	Schatz, E. A., Goldberg, D.M., Pearson, F.G., and Surka, T.L.	1963	1-15	1273	Sample No. 97	97 pure; sintered by Carborundum Co.; thickness 50 mils; density 2.09 g cm ⁻³ , theoretical density 2.27 g cm ⁻³ ; smooth values from figure; θ* = 0°.
19 T22272	Schatz, E.A., et al.	1963	1-15	1223	Sample No. 98	100 pure; sintered at 2123 K for 2 hr, sinter material BN; density 2.00 g cm ⁻³ , theoretical density 2.27 g cm ⁻³ ; smooth values from figure; θ* = 0°.

TABLE 7-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)
 {WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ }

TABLE 7-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	CURVE 9 (CONT.)	λ	ϵ	CURVE 9 (CONT.)	λ	ϵ	CURVE 9 (CONT.)	λ	ϵ	CURVE 10 (CONT.)	λ	ϵ	CURVE 11 (CONT.)
1.52	0.185	4.40	0.799	7.59	0.734	11.47	0.826	1.50	0.437	9.00	0.887			
1.57	0.178	4.46	0.812	7.59	0.758	11.52	0.613	1.77	0.439	10.0	0.897			
1.65	0.178	4.58	0.793	7.66	0.776	11.58	0.618	2.13	0.463	11.0	0.926			
1.69	0.163	4.64	0.800	7.80	0.779	11.77	0.618	2.43	0.477					
1.75	0.174	4.70	0.791	7.88	0.791	11.84	0.611	2.58	0.623					
1.79	0.171	4.76	0.809	8.07	0.791	12.01	0.612	3.28	0.687					
1.81	0.161	5.00	0.609	9.11	0.781	12.09	0.803	4.22	0.878					
1.96	0.161	5.08	0.816	8.15	0.781	12.20	0.803	5.15	0.905	0.560	0.336			
2.15	0.166	5.11	0.827	8.20	0.769	12.26	0.848	5.75	0.905	1.12	0.190			
2.20	0.175	5.15	0.818	8.33	0.768	12.31	0.859	6.12	0.918	1.30	0.332			
2.26	0.203	5.20	0.616	3.37	0.761	12.38	0.851	6.51	0.753	1.55	0.376			
2.36	0.209	5.21	0.829	8.45	0.766	12.44	0.861	7.05	0.566	1.63	0.426			
2.55	0.306	5.29	0.821	8.74	0.767	12.55	0.861	7.42	0.632	2.14	0.547			
2.55	0.326	5.33	0.841	8.75	0.786	12.58	0.854	8.20	0.804	2.36	0.571			
2.62	0.345	5.38	0.841	8.79	0.786	12.61	0.854	8.71	0.793	2.61	0.735			
2.63	0.369	5.42	0.834	8.35	0.763	12.87	0.858	8.99	0.815	3.31	0.743			
2.80	0.423	5.45	0.646	9.05	0.767	12.95	0.858	10.0	0.852	4.25	0.750			
2.86	0.423	5.51	0.843	9.07	0.761	13.00	0.849	10.9	0.895	5.22	0.786			
2.91	0.453	5.52	0.855	9.12	0.761	13.06	0.856	5.60	0.817					
2.94	0.477	5.57	0.655	9.16	0.775	13.12	0.851	6.11	0.791					
3.05	0.477	5.61	0.643	3.20	0.775	13.39	0.851	6.58	0.642					
3.09	0.488	5.67	0.857	9.52	0.772	13.46	0.860	7.00	0.386					
3.13	0.488	5.97	0.862	9.27	0.761	13.54	0.859	0.550	0.354	7.42	0.309			
3.18	0.508	6.03	0.877	9.78	0.772	13.90	0.859	1.10	0.218	8.23	0.654			
3.23	0.508	6.28	0.861	9.87	0.772	13.94	0.853	1.23	0.300	8.69	0.779			
3.28	0.531	6.32	0.827	9.92	0.798	14.09	0.863	1.53	0.363	9.04	0.727			
3.31	0.552	6.35	0.814	9.98	0.787	14.43	0.864	1.81	0.411	10.1	0.746			
3.42	0.596	6.40	0.814	10.44	0.800	14.49	0.859	2.11	0.486	11.0	0.768			
3.47	0.675	6.42	0.786	10.52	0.811	14.56	0.862	2.37	0.541					
3.52	0.711	6.47	0.766	10.69	0.812	14.82	0.862	2.56	0.777					
3.57	0.711	6.49	0.726	10.73	0.820	14.87	0.881	3.28	0.842					
3.63	0.734	6.56	0.732	10.81	0.825	14.94	0.889	4.23	0.889					
3.70	0.740	6.60	0.716	11.03	0.825	15.00	0.886	5.15	0.934	1.13	0.226			
3.70	0.759	6.66	0.709	11.07	0.833	5.72	0.915	1.23	0.309					
3.82	0.780	6.74	0.710	11.15	0.817	6.10	0.926	1.53	0.376					
4.00	0.780	6.86	0.683	11.20	0.830	6.51	0.778	1.82	0.386					
4.15	0.781	7.00	0.705	11.25	0.829	7.00	0.656	2.13	0.484					
4.20	0.758	7.30	0.705	11.29	0.818	7.42	0.745	2.44	0.554					
4.26	0.771	7.39	0.719	11.38	0.818	8.20	0.847	2.60	0.770					
4.33	0.749	7.48	0.719	11.42	0.826	8.73	0.871							

CURVE 11
 $T = 1090$.

CURVE 11
 $T = 1090$.

CURVE 13
 $T = 1103$.

TABLE 7-3. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF 308NM NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	CURVE 14 $T = 1103.$			CURVE 15 (CONT.) $T = 1260.$			CURVE 16 (CONT.) $T = 1670.$			CURVE 17 $T = 2020.$			CURVE 18 (CONT.) $T = 1273.$			
1.14	0.196	12.97	0.786	1.406	0.884	1.00	0.380	9.14	0.919	4.35	0.943	4.47	0.933	4.55	0.925	4.50	0.944
1.24	0.292	13.46	0.661	14.99	0.917	1.04	0.356	9.37	0.904	4.47	0.933	4.55	0.925	4.50	0.944	4.50	0.965
1.53	0.352	13.99	0.677	14.60	0.854	1.21	0.273	9.83	0.901	5.01	0.924	5.01	0.924	5.01	0.925	5.01	0.965
1.81	0.365	14.98	0.906	14.98	0.906	1.50	0.212	16.1	0.914	5.01	0.924	5.01	0.924	5.01	0.925	5.01	0.965
2.13	0.448	2.46	0.760	2.46	0.875	1.68	0.186	10.1	0.927	6.01	0.976	6.30	0.945	6.52	0.832	6.52	0.945
2.44	0.525	2.73	0.863	2.02	0.201	1.86	0.170	11.0	0.933	6.30	0.945	6.52	0.832	6.52	0.945	6.52	0.965
2.61	0.732	2.98	0.849	2.13	0.227	2.02	0.170	11.1	0.926	6.52	0.945	6.70	0.765	6.70	0.765	6.70	0.965
2.99	0.726	3.23	0.849	2.24	0.208	2.13	0.227	11.4	0.935	6.86	0.926	7.01	0.804	7.01	0.804	7.01	0.965
3.24	0.733	3.47	0.828	2.49	0.565	2.49	0.249	11.6	0.926	7.01	0.926	7.50	0.839	7.50	0.839	7.50	0.965
3.48	0.739	3.73	0.837	2.71	0.673	2.71	0.673	12.3	0.949	7.50	0.949	7.68	0.884	7.68	0.884	7.68	0.965
3.74	0.761	4.00	0.830	2.82	0.668	2.82	0.668	12.8	0.922	8.03	0.935	8.03	0.889	8.03	0.889	8.03	0.965
3.98	0.833	4.23	0.828	3.17	0.854	3.17	0.854	12.9	0.937	8.03	0.937	8.03	0.889	8.03	0.889	8.03	0.965
4.24	0.726	4.49	0.881	3.31	0.931	3.31	0.931	13.0	0.925	8.24	0.925	8.52	0.855	8.52	0.855	8.52	0.965
4.49	0.814	4.74	0.865	3.60	1.000	3.60	1.000	13.9	0.935	8.52	0.935	8.82	0.858	8.82	0.858	8.82	0.965
4.74	0.838	4.99	0.914	4.03	1.000	4.03	1.000	14.0	0.926	8.82	0.926	9.34	0.894	9.34	0.894	9.34	0.965
4.98	0.882	5.21	0.920	4.21	0.970	4.21	0.970	14.5	0.934	9.49	0.934	9.97	0.927	9.97	0.927	9.97	0.965
5.24	0.900	4.96	0.911	5.73	0.936	4.41	0.989	14.6	0.927	9.53	0.927	10.0	0.852	10.0	0.852	10.0	0.965
5.48	0.914	5.22	0.920	5.96	0.965	4.84	0.996	14.8	0.996	10.0	0.996	14.0	0.945	14.0	0.945	14.0	0.965
5.72	0.894	5.45	0.931	6.48	0.839	5.07	0.993	15.0	1.000	10.5	0.967	10.5	0.867	10.5	0.867	10.5	0.965
5.99	0.916	5.71	0.959	6.98	0.504	5.12	1.000	15.1	0.993	11.1	0.903	11.1	0.866	11.1	0.866	11.1	0.965
6.49	0.708	5.95	0.983	7.47	0.359	5.18	0.998	15.3	0.996	11.3	0.866	11.3	0.866	11.3	0.866	11.3	0.965
6.98	0.882	6.47	0.774	7.98	0.651	5.38	0.996	15.4	0.993	12.0	0.672	12.0	0.672	12.0	0.672	12.0	0.965
7.46	0.407	6.97	0.419	5.49	0.755	5.84	0.993	15.5	0.993	12.1	0.672	12.1	0.672	12.1	0.672	12.1	0.965
7.99	0.670	7.47	0.380	5.96	0.605	5.93	0.985	15.6	0.993	12.2	0.672	12.2	0.672	12.2	0.672	12.2	0.965
8.46	0.757	7.96	0.684	6.49	0.627	6.08	0.993	15.7	0.993	12.3	0.672	12.3	0.672	12.3	0.672	12.3	0.965
8.99	0.800	8.46	0.773	7.47	0.359	5.38	0.996	15.8	0.996	12.4	0.672	12.4	0.672	12.4	0.672	12.4	0.965
9.46	0.823	8.95	0.614	10.46	1.072	6.51	0.843	15.9	1.000	12.5	0.933	12.5	0.933	12.5	0.933	12.5	0.965
9.97	0.838	9.45	0.831	10.97	0.865	6.64	0.789	16.0	0.843	13.0	0.921	13.0	0.921	13.0	0.921	13.0	0.965
10.47	0.853	11.44	0.915	13.47	0.846	7.65	0.789	16.1	0.843	13.4	0.910	13.4	0.910	13.4	0.910	13.4	0.965
10.97	0.871	12.45	0.917	13.99	0.894	7.84	0.912	16.2	0.917	13.6	0.917	13.6	0.917	13.6	0.917	13.6	0.965
11.46	0.887	12.96	0.825	14.98	0.986	7.92	0.994	16.3	0.917	14.1	0.914	14.1	0.914	14.1	0.914	14.1	0.965
11.97	0.904	13.44	0.867	14.98	0.986	7.92	0.986	16.4	0.949	14.4	0.902	14.4	0.902	14.4	0.902	14.4	0.965
12.46	0.909	13.95	0.876	14.98	0.986	8.03	0.915	16.5	0.949	14.6	0.912	14.6	0.912	14.6	0.912	14.6	0.965

b. Normal Spectral Emittance (Temperature Dependence)

A total of two sets of experimental data were located for the temperature dependence of the normal spectral emittance. The data are listed in Table 7-6 and shown in Figures 7-3 and 7-4. Specimen characterization and measurement information for the data are given in Table 7-5.

Both sets of data are for 0.650 μm and, therefore, no data from these sources can be used for evaluation at 3.8 and 10.6 μm . However, using the provisional values in the previous section for pyrolytic boron nitride, values for 3.8 and 10.6 μm were obtained for temperatures of 1280, 1670, and 2020 K. The provisional values are listed in Table 7-4 and shown in Figure 7-3. The uncertainty is 15%. The context within which these values are valid is the following: a 0.5 in. thick specimen of polished pyrolytic boron nitride manufactured by High Temperature Materials, Inc., with the surface parallel to the basal planes radiating. Since the provisional values in the previous section are the same for 1280, 1670, and 2022 K, the emittance in this temperature range for either 3.8 or 10.6 μm is temperature independent (see Figure 7-3).

TABLE 7--4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T ; K; EMITTANCE, ϵ)

T	ϵ	T	ϵ
PYROLYTIC-POLISHED 1.27CM THICK $\lambda = 3.8$			
1280.	9.805	1280.	6.866
1670.	6.606	1670.	0.866
2020.	6.606	2020.	0.866

6




FIGURE 7-3. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE).




FIGURE 7-4. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE).

TABLE 7-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (Temperature Dependence)

Cur. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	T14404	Serebryakova, T. I., Paderno, Yu. B., and Samsonov, G. V.	1960	0.650	1123-1923		Layer of paste, approx. 100 μm thick, on tantalum cylinder; paste prepared from fine powder, 2-3 μm , of BN suspended in nitrate binder and dried at 313 to 333 K; $\theta^* = 0^\circ$.
2	T32220	Samsonov, G. V., Fomenko, V. S., and Paderno, Yu. B.	1962	0.650	1073-1973		Similar to the above specimen except BN suspended in nitrocellulose binder, applied to outer surface of cylinder, and dried at 313 to 333 K.

TABLE 7-6. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF BORON NITRIDE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T	ϵ
CURVE 1 $\lambda = 0.650$	
1123.	0.58
1223.	0.59
1323.	0.59
1423.	0.59
1523.	0.60
1623.	0.60
1723.	0.60
1823.	0.60
1923.	0.60
CURVE 2 $\lambda = 0.650$	
1073.	0.64
1173.	0.64
1273.	0.64
1373.	0.63
1473.	0.63
1573.	0.63
1673.	0.63
1773.	0.62
1873.	0.62
1973.	0.62

c. Normal Spectral Reflectance (Wavelength Dependence)

A total of 28 sets of experimental data were located for the wavelength dependence of the normal spectral reflectance of boron nitride. The data are listed in Table 7-9 and shown in Figures 7-5 and 7-6. Specimen characterization and measurement information for the data are given in Table 7-8.

All sets of data, with the exception of one, are for 293 K. No data for higher temperatures was located. Two typical curves are given, one for a pyrolytic specimen and one for a cubic specimen. These are labeled typical because of the lack of complete specimen dimensions and the uncertainty of these values can be 30% or larger. The typical curve for pyrolytic boron nitride at 293 K is based on curve 2 and holds for a specimen from High Temperature Materials, Inc., for linearly polarized light with the electric field vector parallel to the c-axis of the crystal, and $\theta = 0^\circ$ and $\theta' = 0^\circ$. The typical curve for cubic boron nitride at 293 K is based on curve 5 and holds for a polished specimen with density approaching the theoretical value of 3.50 g cm^{-3} . The typical values are listed in Table 7-7 and shown in Figure 7-5.

TABLE 7-7. TYPICAL NORMAL SPECTRAL REFLECTIONS OF DIAMON NITRIDE (WAVELENGTH DEPENDENCE)

PYROLYTIC T = 293		PYROLYTIC T = 293 (CONT.)		CUBIC POLISHED T = 293		CUBIC POLISHED T = 293 (CONT.)		CURVIC POLISHED T = 293	
λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
5.00	0.392	13.0	0.114	5.340	0.096	9.268	0.817		
5.10	0.389	13.2	0.116	5.263	0.097	9.320	0.817		
5.21	0.067	10.6	0.098	5.467	0.094	9.407	0.816		
5.33	0.384	11.0	0.098	5.747	0.089	9.434	0.806		
5.44	0.381	11.2	0.062	5.356	0.090	9.569	0.737		
5.56	0.071	11.4	0.065	5.00	0.077	9.681	0.661		
5.68	0.364	11.7	0.144	6.101	0.075	9.614	0.586		
5.80	0.056	11.9	0.125	5.215	0.067	9.950	0.501		
5.95	0.342	12.0	0.016	5.447	0.059	10.60	0.487		
6.08	0.339	12.1	0.069	5.540	0.047	10.12	0.451		
6.09	0.036	12.3	0.478	6.784	0.039	10.33	0.410		
6.17	0.053	12.3	0.702	6.354	0.025	10.62	0.373		
6.24	0.085	12.7	0.774	7.00	0.021	10.88	0.350		
6.29	0.129	12.9	0.580	7.382	0.016	11.00	0.362		
6.33	0.168	13.0	0.490	7.143	0.012	11.14	0.332		
6.37	0.219	13.1	0.408	7.225	0.012	11.55	0.313		
6.39	0.268	13.2	0.333	7.299	0.019	12.00	0.297		
6.44	0.305	13.5	0.291	7.364	0.028	12.02	0.296		
6.47	0.329	13.6	0.262	7.402	0.059	12.56	0.280		
6.58	0.345	14.0	0.224	7.452	0.16%	13.00	0.271		
6.66	0.328	14.3	0.212	7.324	0.012	13.30	0.264		
6.76	0.289	14.8	0.200	7.307	0.010	14.27	0.249		
6.84	0.269	15.3	0.194	7.379	0.010	15.02	0.240		
6.93	0.238	16.2	0.175	7.628	0.537	16.03	0.231		
7.0	0.226	17.3	0.172	7.722	0.72%				
7.05	0.221	18.6	0.157	7.749	0.771				
7.12	0.202	20.1	0.162	7.843	0.76%				
7.26	0.189	21.7	0.159	7.987	0.805				
7.47	0.177	23.9	0.159	8.03	0.806				
7.69	0.163	26.4	0.157	8.091	0.816				
7.94	0.160	29.9	0.153	8.137	0.820				
8.0	0.157	33.3	0.152	8.333	0.820				
8.22	0.148			8.496	0.810				
8.50	0.144			8.643	0.801				
8.84	0.143			8.787	0.796				
9.0	0.137			8.929	0.796				
9.10	0.133			9.00	0.801				
9.46	0.126			9.107	0.806				
9.83	0.116			9.200	0.813				




FIGURE 7-5. TYPICAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).




FIGURE 7-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).

TABLE 7-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T37478	Browning, M. E.	1963	0.23-2.65	293		Sintered; from Carbonium Corp.; density 2.09 g cm^{-3} ; reference standard MgO ; smooth values from figure; integrating sphere reflectometer, Beckman DK-2a spectrophotometer, used; author reports spectral total reflectance; $\theta = \sim 5^\circ$, $\omega = 2\pi$.
2 T39203	Geick, R., Perry, C.H., and Rupprecht, G.	1966	5-33	293	Pyrolytic	Hexagonal structure; sample supplied by High Temperature Materials, Inc.; linearly polarized light used with E parallel to c-axis of crystal; Perkin-Elmer Model 521 spectrophotometer with reflection attachment used; measurement temperature not given explicitly, assumed to be 293 K; smooth values from figure; $\theta=0^\circ$, $\theta=0^\circ$.
3 T39203	Geick, R., et al.	1966	5-33	293	Pyrolytic	Similar to the above specimen except linearly polarized light used with E perpendicular to c-axis of crystal.
4 T42872	Gielisse, P.J., Nitra, S.S., Plendl, J.N., Griffis, R.D., Mansur, L.C., Marshall, R., and Pascoe, E.A.	1967	5.6-25	293		Cubic boron nitride; specimen approx. 6 mm in diameter; specimen manufactured by being subjected to very high pressures and temperatures; opaque; density approaches theoretical value of 3.50 g cm^{-3} ; ground and polished on one side with successively finer diamond powder to a perfectly flat, homogeneous, mirror-like finish; Perkin-Elmer Model 521 and 221 infrared spectrophotometers, together with appropriate attachments, used to measure reflectivity; data from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$, $\theta' = 0^\circ$.
5 T42872	Gielisse, P.J., et al.	1967	5.0-16	293		Similar to the above specimen except smooth values from figure.
6 T42872	Gielisse, P.J., et al.	1967	5.0-13	77		Similar to the above specimen except measured at liquid nitrogen temperature, 77.3 K.
7 T42872	Gielisse, P.J., et al.	1967	6.3-10	293		Similar to the above specimen except annealed in air at 623 K for 15 min and subsequently measured at room temperature, 293 K assigned.
8 T40523	Sulzbach, F. and Turner, A.F.	1966	4.0-34	293		Film; optical thickness 10 quarterwaves at $\lambda = 1.7 \mu\text{m}$; electron beam deposited in vacuum, $2-8 \times 10^{-5} \text{ mm Hg}$, at normal incidence onto glass substrate heated to 588 K; rate of depositing 1 quarterwave per min at $\lambda = 0.5 \mu\text{m}$; clear dark brown in appearance; measurements made at room temperature, 293 K assigned; Perkin-Elmer Models 21 and 221 spectrophotometers used; data from figure; $\theta = 0^\circ$.
9 T40523	Sulzbach, F. and Turner, A.F.	1966	3.1-37	293		Polished; massive BN; measurements made at room temperature, 293 K assigned; Perkin-Elmer Models 21 and 221 spectrophotometers used; smooth values from figure; $\theta = 0^\circ$.
10 T22272	Schatz, E.A., Goldberg, D.M., Pearson, E.G., and Barke, T.L.	1963	0.23-2.7	293	Sample No. 97	97 pure; sintered specimen; from Carbonundum Co.; density 2.09 g cm^{-3} ; theoretical density 2.27 g cm^{-3} ; thickness 50 mils; reference standard MgO , reflectance data measured and presented relative to MgO ; spectral total reflectance reported; integrating sphere reflectometer, Beckman DK-2a spectrophotometer used; measurement temperature not explicitly given, 293 K assigned; smooth values from figure; $\theta = \sim 5^\circ$, $\omega = 2\pi$.
11 T22272	Schatz, E.A., et al.	1963	0.23-2.7	293	Sample No. 98	100 pure; sintered at 2123 K for 2 hr, seter material BN; density 2.00 g cm^{-3} , theoretical density 2.27 g cm^{-3} ; thickness 65 mils; reference standard MgO , reflectance data measured and presented relative to MgO ; spectral total reflectance reported; integrating sphere reflectometer, Beckman DK-2a spectrophotometer used; measurement temperature not explicitly given, 293 K assigned; smooth values from figure; $\theta = \sim 5^\circ$, $\omega = 2\pi$.

TABLE 7-6. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Designation	Composition (weight percent). Specifications, and Remarks
12 T28755	Zerlaut, G.A. and Harada, Y.	1963	0.44-0.60	293	HC 0021	Manufactured by Carborundum Co.; powder compacted at 10 000 psi; MgO used as standard; absolute values of reflectance reported; integrating sphere reflectometer used; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 0^\circ$, $\omega = 2\pi$.
13 T28755	Zerlaut, G.A.	1963	0.44-0.60	293	HC 0021	The above specimen and conditions except exposed to uv irradiation; 75 ESH with solar factor 1.5.
14 T37398	Schatz, E.A., Counts, C.R., III, and Burris, T.L.	1964	0.23-2.7	293		99.5 pure powder; from Carborundum Co.; mesh size 325; compacted at 290 361 with highly polished stainless steel ram; curves measured and presented relative to freshly prepared smoked MgO reference samples; Beckman DR-2A spectroradiometer used; measurement temperature not given explicitly, assumed to be 293 K; smooth values from figure; $\theta = 0^\circ$, $\omega = 2\pi$; reported error $\pm 3\%$.
15 T37398	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 1150 psi.
16 T37398	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 2580 psi.
17 T37398	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 5760 psi.
18 T37398	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 11 500 psi.
19 T37398	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 20 200 psi.
20 T37398	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 28 800 psi.
21 T37393	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 31 700 psi.
22 T37398	Schatz, E.A., et al.	1964	0.23-2.7	293		Similar to the above specimen except compacted at 34 600 psi.
23 T37398	Schatz, E.A., et al.	1964	2.0-15	293		Commercial sintered sample; surface machine grooved to roughness 55-40 μm ; black-body reflectometer used in conjunction with Haird-Alomic Model NK-1 spectrophotometer; reflectance factor ($\omega = 2\pi$; $\theta = 0^\circ$) actually measured, equated to reflectance ($\theta = 0^\circ$; $\omega = 2\pi$); smooth values from figure.
24 T37398	Schatz, E.A., et al.	1964	2.0-15	253		Similar to the above specimen except surface roughness 300-400 μm .
25 T37398	Schatz, E.A., et al.	1964	2.0-36	293		Similar to the above specimen except surface roughness 1800-2200 μm .
26 T27556	Martin, T.P., Massa, J.D., and Turner, A.F.	1963	2-35	293		Pressed powder; measurement temperature not given explicitly, assumed to be 293 K; smooth values from figure; $\theta = 0^\circ$.
27 A00027, A00002	Cunnington, G.R.	1975	1.0-24	293		97.0 BN, 2.4 boric oxide, 0.2 aluminum and silicon, 0.1 alkaline earth oxides, and <0.01 carbon (this typical composition given by supplier); manufactured by Carborundum Co.; hot-pressed; no specification of density given; G.D. heated cavity used for measurement; reflectance factor with $\omega = 2\pi$, $\theta = 20^\circ$ actually measured, equated here to reflectance with $\theta = 30^\circ$, $\omega = 2\pi$; measurement temperature not given explicitly, assumed to be 293 K.
28 A00027, A00002	Cunnington, G.R.	1975	0.29-2.11	293		97.0 BN, 2.4 boric oxide, 0.2 aluminum and silicon, 0.1 alkaline earth oxides, and <0.01 carbon (this typical composition given by supplier); manufactured by Carborundum Co.; hot-pressed; no specification of density given; G.D. integrating sphere used for measurement; reflectance factor measured; direct or indirect made not explicitly given; direct made with $\theta = 20^\circ$, $\omega = 2\pi$ presumed; measurement temperature not given explicitly, assumed to be 293 K.

TABLE 7-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T ; K; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 293.$		CURVE 1 (CONT.)		CURVE 1 (CONT.)		CURVE 1 (CONT.)		CURVE 2 (CONT.)		CURVE 3 $T = 293.$	
		λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
0.230	0.563	0.4170	0.729	1.461	0.782	2.437	0.594	8.22	0.146	0.080	0.080	5.00	5.00
0.2326	0.535	0.4440	0.755	1.514	0.760	2.471	0.574	8.50	0.144	0.077	0.077	5.11	5.11
0.2462	0.495	0.4620	0.762	1.521	0.756	2.498	0.574	8.64	0.143	0.069	0.069	5.21	5.21
0.2425	0.483	0.4720	0.764	1.236	0.753	2.545	0.566	9.10	0.133	0.126	0.126	5.32	5.32
0.2456	0.476	0.5020	0.792	1.579	0.753	2.567	0.559	9.46	0.126	0.067	0.067	5.43	5.43
0.2491	0.472	0.5210	0.811	1.607	0.750	2.620	0.562	9.83	0.116	0.051	0.051	5.55	5.55
0.2547	0.472	0.5556	0.813	1.638	0.756	2.650	0.571	10.2	0.110	0.042	0.042	5.68	5.68
0.2558	0.474	0.5690	0.824	1.653	0.755	2.695	0.598	10.6	0.106	0.033	0.033	5.78	5.78
0.2580	0.469	0.5950	0.824	1.721	0.769	2.740	0.608	11.0	0.088	0.025	0.025	5.87	5.87
0.2603	0.472	0.6076	0.822	1.723	0.774	2.741	0.602	11.2	0.082	0.009	0.009	5.93	5.93
0.2662	0.475	0.6500	0.822	1.764	0.781	2.785	0.604	11.4	0.065	0.004	0.004	6.00	6.00
0.2679	0.473	0.6700	0.821	1.783	0.785	2.805	0.609	11.7	0.044	0.000	0.000	6.10	6.10
0.2724	0.486	0.6840	0.811	1.815	0.785	2.815	0.609	11.9	0.025	0.000	0.000	6.18	6.18
0.2750	0.493	0.6960	0.824	1.827	0.783	2.837	0.607	12.0	0.010	0.000	0.000	6.09	6.09
0.2757	0.501	0.7500	0.819	1.841	0.785	2.855	0.604	12.1	0.049	0.043	0.043	6.13	6.13
0.2779	0.514	0.8140	0.816	1.864	0.792	2.882	0.601	12.3	0.478	0.087	0.087	6.18	6.18
0.2816	0.517	0.8280	0.820	1.888	0.788	2.902	0.596	12.3	0.702	0.222	0.194	6.22	6.22
0.2823	0.521	0.9510	0.820	1.897	0.784	2.912	0.594	12.7	0.774	0.344	0.344	6.23	6.23
0.2850	0.526	0.9730	0.816	1.911	0.783	2.933	0.592	12.9	0.560	0.476	0.476	6.28	6.28
0.2889	0.545	0.9860	0.817	1.921	0.780	2.952	0.595	13.1	0.408	0.572	0.572	6.30	6.30
0.2913	0.552	0.9860	0.815	1.955	0.780	2.980	0.596	13.2	0.333	0.642	0.642	6.34	6.34
0.2938	0.552	1.066	0.813	1.994	0.774	3.017	0.505	13.5	0.291	0.697	0.697	6.39	6.39
0.2983	0.562	1.096	0.812	2.017	0.762	3.047	0.564	12.7	0.774	0.762	0.762	6.46	6.46
0.3006	0.571	1.125	0.814	2.051	0.745	3.079	0.529	14.0	0.224	0.803	0.803	6.55	6.55
0.3046	0.571	1.156	0.810	2.071	0.739	3.109	0.512	14.3	0.212	0.829	0.829	6.63	6.63
0.3069	0.569	1.166	0.813	2.094	0.739	3.139	0.517	14.6	0.200	0.849	0.849	6.72	6.72
0.3113	0.579	1.183	0.813	2.098	0.731	3.169	0.519	15.3	0.194	0.857	0.857	6.84	6.84
0.3200	0.608	1.212	0.810	2.115	0.731	3.215	0.44	16.2	0.175	0.862	0.862	6.93	6.93
0.3247	0.621	1.216	0.810	2.150	0.721	3.250	0.47	17.3	0.172	0.863	0.863	7.05	7.05
0.3258	0.629	1.216	0.810	2.166	0.717	3.265	0.48	18.6	0.157	0.858	0.858	7.13	7.13
0.3276	0.629	1.266	0.809	2.223	0.711	3.286	0.29	20.1	0.162	0.836	0.836	7.21	7.21
0.3336	0.646	1.263	0.811	2.249	0.706	3.305	0.44	21.7	0.159	0.805	0.805	7.28	7.28
0.3400	0.660	1.296	0.808	2.269	0.706	3.320	0.46	23.9	0.159	0.758	0.758	7.32	7.32
0.3410	0.660	1.318	0.810	2.283	0.711	3.345	0.43	26.4	0.157	0.756	0.756	7.39	7.39
0.3436	0.566	1.345	0.804	2.308	0.718	3.362	0.202	29.9	0.153	0.435	0.435	7.45	7.45
0.3500	0.575	1.359	0.807	2.325	0.716	3.382	0.19	33.3	0.152	0.528	0.528	7.52	7.52
0.3500	0.694	1.385	0.807	2.344	0.710	3.402	0.17	37.7	0.177	0.484	0.484	7.67	7.67
0.3660	0.703	1.399	0.802	2.367	0.688	3.422	0.163	37.9	0.163	0.435	0.435	7.80	7.80
0.3750	0.716	1.426	0.802	2.423	0.620	3.442	0.202	33.3	0.152	0.402	0.402	7.80	7.80

TABLE 7-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)

λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 5 (CONT.)	λ	ρ	CURVE 6 (CONT.)	λ	ρ	CURVE 7 (CONT.)	λ	ρ
7.93	0.369	7.143	0.000	7.143	0.012	14.27	0.249	6.767	0.614	7.626	0.537					
8.08	0.347	7.220	0.016	7.225	0.012	15.02	0.240	6.953	0.619	7.675	0.641					
8.20	0.333	7.369	0.066	7.299	0.019	16.03	0.231	9.141	0.627	7.776	0.697					
8.50	0.308	7.463	0.211	7.364	0.026	7.05	0.226	9.242	0.631	7.905	0.750					
6.77	0.279	7.536	0.422	7.402	0.059	7.402	0.059	9.320	0.631	7.981	0.774					
9.12	0.271	7.663	0.569	7.452	0.165	7.452	0.165	9.407	0.816	8.117	0.798					
9.41	0.252	7.962	0.718	7.524	0.307	7.524	0.307	9.434	0.806	8.285	0.825					
9.84	0.243	8.052	0.754	7.570	0.410	8.052	0.410	9.569	0.737	8.525	0.839					
10.2	0.235	8.203	0.781	7.628	0.537	8.203	0.537	9.661	0.661	8.718	0.837					
10.6	0.226	8.340	0.803	7.675	0.641	8.340	0.641	9.814	0.887	8.897	0.830					
11.2	0.217	8.475	0.816	7.722	0.728	8.475	0.728	9.960	0.960	9.132	0.812					
11.7	0.208	8.606	0.828	7.740	0.771	8.606	0.771	10.09	0.92	9.328	0.789					
12.0	0.196	8.772	0.826	7.843	0.785	8.772	0.785	10.24	0.96	9.434	0.896					
12.4	0.184	8.945	0.827	7.987	0.805	8.945	0.827	10.45	0.979	9.443	0.767					
12.8	0.177	9.091	0.802	8.091	0.816	12.8	0.816	10.67	0.348	9.569	0.737					
13.0	0.199	9.225	0.766	8.137	0.820	13.0	0.820	11.05	0.318	9.681	0.661					
13.0	0.256	9.560	0.576	8.333	0.820	13.0	0.820	11.47	0.296	9.814	0.586					
13.2	0.282	9.970	0.450	8.496	0.810	13.2	0.810	11.88	0.274	9.960	0.501					
13.5	0.265	11.06	0.321	8.643	0.801	13.5	0.801	12.32	0.254							
14.3	0.239	12.42	0.275	8.787	0.792	14.3	0.792	10.67	0.348	9.569	0.737					
15.3	0.228	14.22	0.251	8.929	0.798	15.3	0.798	11.05	0.318	9.681	0.661					
16.2	0.221	16.64	0.232	9.107	0.806	16.2	0.806	11.47	0.296	9.814	0.586					
17.3	0.215	19.96	0.225	9.200	0.813	17.3	0.813	12.32	0.254	9.960	0.501					
18.6	0.215	25.00	0.217	9.268	0.817	18.6	0.817	10.67	0.348	9.569	0.737					
20.0	0.211	20.0	0.211	9.320	0.817	20.0	0.817	9.299	0.019	5.10	0.075					
21.9	0.211	21.9	0.211	9.407	0.816	21.9	0.816	7.364	0.026	6.70	0.073					
24.0	0.208	24.0	0.208	9.434	0.806	24.0	0.806	7.402	0.059	6.258	0.067					
26.4	0.205	29.4	0.205	9.569	0.737	26.4	0.737	7.452	0.165	6.285	0.067					
33.3	0.203	33.3	0.203	9.681	0.661	33.3	0.661	7.524	0.307	6.447	0.059					
5.040	0.097	9.814	0.586	7.628	0.537	5.040	0.586	7.570	0.410	6.640	0.047					
5.260	0.097	9.960	0.501	7.675	0.641	5.260	0.501	7.675	0.641	6.784	0.039					
5.467	0.094	10.12	0.451	7.722	0.728	5.467	0.451	7.722	0.728	7.082	0.016					
5.747	0.088	10.33	0.410	7.740	0.771	5.747	0.410	7.740	0.771	7.143	0.012					
5.956	0.080	11.55	0.313	7.831	0.807	5.956	0.313	7.831	0.807	7.225	0.012					
6.075	0.077	12.08	0.332	7.981	0.823	6.075	0.332	7.981	0.823	7.299	0.019					
6.447	0.059	11.14	0.313	8.084	0.832	6.447	0.313	8.084	0.832	7.364	0.026					
6.640	0.047	11.55	0.313	8.183	0.837	6.640	0.313	8.183	0.837	7.402	0.059					
6.784	0.035	12.56	0.296	8.264	0.837	6.784	0.296	8.264	0.837	7.452	0.165					
6.954	0.025	12.56	0.280	8.453	0.828	6.954	0.280	8.453	0.828	7.524	0.097					
7.364	0.026	12.56	0.280	8.666	0.817	7.364	0.280	8.666	0.817	7.602	0.165					
7.402	0.059	13.30	0.264	8.845	0.817	7.402	0.264	8.845	0.817	7.886	0.165					

TABLE 7-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; REFLECTANCE, ρ)

λ	ρ	CURVE 9 T = 293.	λ	ρ	CURVE 10 (CONT.)	λ	ρ	CURVE 11 (CONT.)	λ	ρ	CURVE 14 (CONT.)	λ	ρ	CURVE 15 (CONT.)
3.10	0.066	0.280	0.514	0.559	2.60	0.559	1.69	0.656	0.350	0.467	0.976	0.760	0.467	0.976
4.60	0.063	0.290	0.550	0.570	2.65	0.570	2.15	0.650	0.360	0.477	1.11	0.786	0.477	1.11
5.20	0.041	0.300	0.570	0.570	2.70	0.570	2.25	0.667	0.589	0.632	1.32	0.808	0.632	1.32
5.70	0.010	0.310	0.570	0.570	2.75	0.570	2.43	0.681	0.681	0.684	1.84	0.639	0.684	1.84
6.10	0.000	0.320	0.607	0.607	2.80	0.607	2.51	0.761	0.703	0.662	1.97	0.844	0.703	1.97
6.40	0.233	0.330	0.635	0.635	2.85	0.635	2.60	0.748	0.717	0.671	2.29	0.844	0.717	2.29
6.40	0.448	0.340	0.660	0.660	2.90	0.660	2.65	0.770	0.717	0.679	2.36	0.837	0.770	2.36
6.40	0.448	0.345	0.663	0.663	2.95	0.663	2.33	0.529	0.717	0.679	2.45	0.791	0.529	2.45
7.00	0.469	0.350	0.675	0.675	3.00	0.675	2.36	0.499	0.800	0.724	2.52	0.777	0.724	2.52
7.10	0.483	0.350	0.700	0.700	3.05	0.700	2.45	0.452	0.901	0.761	2.62	0.776	0.761	2.62
7.30	0.474	0.379	0.719	0.719	3.10	0.719	2.60	0.486	1.05	0.801	2.65	0.765	0.801	2.65
7.60	0.255	0.447	0.757	0.757	3.15	0.757	2.80	0.472	1.30	0.835	3.00	0.835	0.835	3.00
7.80	0.225	0.513	0.813	0.813	3.20	0.813	2.90	0.476	0.440	0.865	3.20	0.864	0.865	3.20
8.10	0.193	0.548	0.813	0.813	3.25	0.813	2.94	0.473	0.600	0.925	3.30	0.976	0.925	3.30
8.80	0.166	0.569	0.827	0.827	3.30	0.827	3.00	0.467	2.08	0.883	3.30	0.883	0.883	3.30
11.0	0.146	0.673	0.823	0.823	3.35	0.823	3.10	0.504	2.19	0.887	3.30	0.887	0.887	3.30
11.7	0.122	0.683	0.811	0.811	3.40	0.811	3.19	0.543	2.33	0.895	3.30	0.895	0.895	3.30
12.3	0.092	0.700	0.828	0.828	3.45	0.828	3.27	0.562	2.37	0.876	3.30	0.876	0.876	3.30
12.4	0.056	0.789	0.618	0.618	3.50	0.618	3.40	0.550	0.440	0.650	3.40	0.833	0.650	3.40
12.5	0.193	0.854	0.623	0.623	3.55	0.623	3.50	0.531	0.600	0.840	3.50	0.829	0.840	3.50
12.9	0.213	0.950	0.623	0.623	3.60	0.623	3.60	0.518	2.65	0.840	3.60	0.840	0.840	3.60
13.4	0.213	1.05	0.819	0.819	3.65	0.819	3.87	0.592	2.19	0.887	3.60	0.887	0.887	3.60
14.3	0.179	1.15	0.812	0.812	3.70	0.812	3.13	0.587	2.33	0.895	3.60	0.895	0.895	3.60
14.9	0.135	1.35	0.807	0.807	3.75	0.807	4.48	0.641	2.37	0.876	3.60	0.876	0.876	3.60
15.4	0.101	1.44	0.799	0.799	3.80	0.799	4.97	0.720	0.440	0.650	3.60	0.833	0.650	3.60
16.1	0.087	1.50	0.762	0.762	3.85	0.762	5.51	0.772	0.230	0.540	3.60	0.833	0.650	3.60
16.4	0.082	1.53	0.754	0.754	3.90	0.754	5.62	0.765	0.240	0.479	3.60	0.833	0.650	3.60
33.4	0.082	1.60	0.749	0.749	4.00	0.749	6.03	0.777	0.243	0.475	3.60	0.833	0.650	3.60
34.8	0.062	1.67	0.786	0.786	4.05	0.786	6.52	0.744	0.245	0.460	3.60	0.833	0.650	3.60
35.5	0.043	1.79	0.786	0.786	4.10	0.786	7.02	0.724	0.249	0.462	3.60	0.833	0.650	3.60
36.4	0.045	1.83	0.785	0.785	4.15	0.785	7.24	0.724	0.253	0.453	3.60	0.833	0.650	3.60
37.0	0.057	1.86	0.794	0.794	4.20	0.794	7.24	0.701	0.259	0.457	3.60	0.833	0.650	3.60
1.91	0.781	0.757	0.701	0.701	4.25	0.757	7.81	0.701	0.254	0.454	3.60	0.833	0.650	3.60
1.99	0.773	0.785	0.687	0.687	4.30	0.785	7.31	0.731	0.272	0.460	3.60	0.833	0.650	3.60
2.10	0.731	0.675	0.790	0.790	4.35	0.731	7.31	0.790	0.276	0.459	3.60	0.833	0.650	3.60
2.26	0.707	1.04	0.809	0.809	4.40	0.707	7.24	0.724	0.265	0.466	3.60	0.833	0.650	3.60
2.32	0.718	1.06	0.801	0.801	4.45	0.718	7.18	0.718	0.259	0.457	3.60	0.833	0.650	3.60
2.36	0.699	1.15	0.826	0.826	4.50	0.699	7.15	0.826	0.254	0.454	3.60	0.833	0.650	3.60
2.45	0.586	1.24	0.836	0.836	4.55	0.586	7.14	0.836	0.252	0.453	3.60	0.833	0.650	3.60
2.47	0.573	1.30	0.844	0.844	4.60	0.573	7.08	0.844	0.253	0.453	3.60	0.833	0.650	3.60
2.55	0.566	1.65	0.849	0.849	4.65	0.566	7.07	0.849	0.259	0.457	3.60	0.833	0.650	3.60
0.230	0.562	2.32	0.809	0.809	4.70	0.562	7.01	0.809	0.254	0.454	3.60	0.833	0.650	3.60
0.240	0.494	2.36	0.826	0.826	4.75	0.494	6.99	0.826	0.252	0.452	3.60	0.833	0.650	3.60
0.250	0.470	2.45	0.836	0.836	4.80	0.470	6.98	0.836	0.251	0.451	3.60	0.833	0.650	3.60
0.260	0.470	2.47	0.844	0.844	4.85	0.470	6.97	0.844	0.250	0.450	3.60	0.833	0.650	3.60
0.270	0.483	2.55	0.849	0.849	4.90	0.483	6.96	0.849	0.249	0.449	3.60	0.833	0.650	3.60

TABLE 7-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELLENGTH DÉPENDENCE) (CONTINUED)

TABLE 7-S. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

CURVE 23(CONT.)				CURVE 24(CONT.)				CURVE 25(CONT.)				CURVE 26(CONT.)				CURVE 27(CONT.)			
λ	ρ	λ	ρ	λ	ρ														
11.3	0.215	7.44	0.336	5.93	0.103	6.72	0.395	1.36	0.777	7.04	0.731								
11.7	0.236	7.68	0.271	6.08	0.118	6.94	0.437	1.42	0.791	7.08	0.722								
11.9	0.249	7.82	0.243	6.13	0.147	7.17	0.446	1.51	0.800	7.17	0.643								
12.0	0.249	8.00	0.225	6.18	0.306	7.44	0.448	1.60	0.800	7.28	0.520								
12.1	0.228	8.54	0.220	6.28	0.335	7.61	0.260	1.71	0.795	7.35	0.468								
12.1	0.184	8.92	0.199	6.6	0.337	7.99	0.223	1.80	0.760	7.46	0.401								
12.2	0.178	9.62	0.191	6.72	0.377	8.31	0.189	1.88	0.772	7.57	0.356								
12.5	0.215	9.80	0.196	6.98	0.369	8.70	0.167	1.99	0.751	7.72	0.321								
13.0	0.239	11.2	0.203	7.22	0.369	9.33	0.146	2.05	0.723	7.86	0.283								
15.0	0.245	11.5	0.210	7.29	0.379	10.0	0.130	2.10	0.667	8.06	0.261								
		11.9	0.250	7.39	0.303	10.6	0.114	2.14	0.580	8.31	0.238								
CURVE 24		12.0	0.250	7.45	0.280	12.0	0.060	2.17	0.550	8.60	0.215								
T = 293.		12.1	0.226	7.62	0.244	12.4	0.075	2.22	0.470	9.01	0.197								
		12.1	0.191	7.79	0.221	12.6	0.108	2.28	0.397	9.51	0.186								
2.00	0.661	12.1	0.169	8.00	0.204	12.6	0.143	2.35	0.323	10.00	0.183								
2.09	0.691	12.2	0.166	8.59	0.211	12.7	0.165	2.43	0.269	10.60	0.175								
2.20	0.691	12.6	0.207	8.79	0.195	13.3	0.169	2.52	0.224	10.94	0.172								
2.54	0.422	13.0	0.226	9.06	0.179	15.2	0.128	2.68	0.166	11.24	0.172								
2.60	0.356	15.0	0.234	9.50	0.175	15.7	0.088	2.66	0.127	11.50	0.178								
2.63	0.261	10.3	0.168	10.3	0.168	16.2	0.077	3.00	0.106	11.84	0.162								
2.65	0.206	10.6	0.186	10.9	0.186	16.9	0.071	3.19	0.089	12.31	0.194								
2.73	0.197	11.5	0.201	11.3	0.201	17.3	0.073	3.34	0.078	12.67	0.203								
		11.6	0.231	19.3	0.093	3.49	0.072	13.09	0.210										
3.01	0.252	2.00	0.670	12.0	0.231	21.4	0.122	3.80	0.072	13.31	0.204								
3.09	0.242	2.08	0.680	12.1	0.217	22.4	0.139	4.00	0.076	13.73	0.189								
3.14	0.181	2.15	0.680	12.1	0.166	23.5	0.143	4.28	0.074	14.05	0.179								
3.22	0.143	2.25	0.661	12.2	0.166	24.5	0.142	4.67	0.062	14.51	0.176								
3.35	0.123	2.41	0.527	12.6	0.199	26.0	0.118	4.92	0.062	15.13	0.173								
3.50	0.103	2.45	0.477	2.45	0.477	33.7	0.101	5.00	0.058	16.02	0.167								
3.93	0.103	2.56	0.405	2.62	0.202	34.6	0.093	5.50	0.046	16.65	0.167								
5.06	0.123	2.66	0.173	2.66	0.173	35.2	0.082	5.99	0.031	17.01	0.172								
6.14	0.234	2.66	0.173	2.66	0.173	35.9	0.064	6.09	0.040	17.40	0.176								
6.21	0.361	2.70	0.188	2.00	0.074	6.16	0.056	17.66	0.192										
6.28	0.410	2.49	0.222	3.29	0.077	6.20	0.091	18.02	0.186										
6.62	0.492	3.03	0.243	4.26	0.071	6.29	0.325	18.73	0.187										
6.80	0.511	3.08	0.232	5.16	0.052	6.51	0.504	20.06	0.189										
7.03	0.511	3.13	0.193	5.85	0.035	1.00	0.519	6.60	0.569	22.00	0.188								
7.23	0.480	3.16	0.149	6.28	0.046	1.05	0.563	6.71	0.638	22.34	0.191								
7.29	0.440	3.21	0.126	6.47	0.076	1.19	0.680	6.82	0.694	24.99	0.194								
7.36	0.383	3.50	0.103	6.60	0.124	1.31	0.747	6.92	0.722	24.00	0.193								
CURVE 25		T = 293.		CURVE 26		T = 293.		CURVE 27		T = 293.									

TABLE 7-5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BURON NITRIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ
CURVE 28 $T = 293.$	
0.29	0.589
0.29	0.493
0.35	0.477
0.41	0.605
0.47	0.811
0.50	0.828
0.59	0.862
0.66	0.891
0.86	0.891
1.05	0.876
1.26	0.860
1.41	0.855
1.61	0.842
1.70	0.815
1.91	0.790
2.01	0.770
2.11	0.741

d. Angular Spectral Reflectance (Wavelength Dependence)

A total of three sets of experimental data were located for the wavelength dependence of the angular spectral reflectance. The data are listed in Table 7-12 and shown in Figures 7-7 and 7-8. Specimen characterization and measurement information for the data are given in Table 7-11.

A provisional set of values, based on curve 2, is listed in Table 7-10 and shown in Figure 7-7. These room temperature values hold for a polished, 1/32 in. thick specimen of pyrolytic boron nitride manufactured by High Temperature Materials, Inc., with the angles θ and θ' both equal to 20° . An uncertainty of 30% or less is assigned.

TABLE 7-10. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ
PYROLYTIC, POLISH 0.79MM THICK $T = 293$						PYROLYTIC, POLISH 0.79MM THICK $T = 293$ (CONT.)	
						PYROLYTIC, POLISH 0.79MM THICK $T = 293$ (CONT.)	
3.0	0.101	6.6	0.352	10.2	0.155	17.3	0.153
3.1	0.092	6.7	0.424	11.4	0.151		
3.2	0.085	6.8	0.496	10.5	0.150		
3.3	0.080	6.9	0.574	10.6	0.146		
3.4	0.076	6.95	0.620	10.7	0.147		
3.5	0.073	6.98	0.631	10.8	0.145		
3.6	0.071	7.0	0.635	10.9	0.143		
3.7	0.069	7.04	0.630	11.0	0.142		
3.8	0.067	7.1	0.595	11.1	0.140		
3.9	0.066	7.2	0.540	11.2	0.139		
4.0	0.065	7.3	0.490	11.3	0.137		
4.1	0.064	7.4	0.444	11.4	0.136		
4.2	0.063	7.5	0.404	11.5	0.134		
4.3	0.062	7.6	0.364	11.6	0.132		
4.4	0.061	7.7	0.332	11.7	0.131		
4.5	0.060	7.8	0.302	11.8	0.129		
4.6	0.059	7.9	0.277	11.9	0.128		
4.7	0.058	8.0	0.256	12.0	0.126		
4.8	0.056	8.1	0.240	12.1	0.124		
4.9	0.055	8.2	0.226	12.2	0.122		
5.0	0.054	8.3	0.214	12.3	0.120		
5.1	0.052	8.4	0.204	12.4	0.122		
5.2	0.050	8.5	0.196	12.5	0.120		
5.3	0.048	8.6	0.190	12.6	0.1175		
5.4	0.044	8.7	0.184	12.6	0.115		
5.5	0.041	8.8	0.180	12.7	0.114		
5.6	0.037	8.9	0.177	12.8	0.1159		
5.7	0.032	9.0	0.176	12.9	0.1169		
5.8	0.026	9.1	0.174	13.0	0.1175		
5.85	0.023	9.2	0.172	13.1	0.1160		
5.9	0.022	9.3	0.170	13.2	0.1164		
5.93	0.021	9.4	0.168	13.3	0.1165		
5.96	0.027	9.5	0.167	13.4	0.1166		
6.0	0.032	9.6	0.165	13.5	0.1164		
6.1	0.074	9.7	0.163	13.6	0.1162		
6.2	0.122	9.8	0.162	13.7	0.1177		
6.3	0.172	9.9	0.160				
6.4	0.226	10.0	0.158				
6.5	0.288	10.1	0.156				




FIGURE 7-7. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).




FIGURE 7-8. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).

TABLE 7-11. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T51145	McCarthy, D. E.	1968	2.2-50	293			Synthetic specimen; thickness 6.0 mm; flat to 10 fringes or better; reference standard aluminum mirror; commercial double-beam instrument used; temperature not explicitly given, assumed to be 293 K; smooth values from figure; $\theta=30^\circ$, $\theta'=30^\circ$.
2 T3472*	Durand, S. L. and Houston, K.C.	1966	0.3-25	293		Pyrolytic	Specimen size about $2 \times 3 \times 0.5$ in.; final dimensions 1 in. diameter, 1/32 in. thick; manufactured by High Temperature Materials, Inc., Lowell, Mass.; both surfaces ground to a finish of approx. 18 μ in.; AB surface (surface parallel to basal planes or planes of deposition) radiating; Gier Dunkle Reflectometer used; data from figure; specimen cemented to 1 in. diameter aluminum disk with 3 M black low reflectivity paint which served as an opaque substrate; (no change in reflectivity from normal incidence to about 25° from normal); measurement temperature specified as room temperature, 293 K assigned; $\theta = 20^\circ$, $\theta' = 20^\circ$.
3 T40525	McCarthy, D. E.	1966	2.5-50	313			Poly crystalline specimen; thickness 6 mm; ground and polished to 5 fringes or better; smooth values from figure; $\theta = 30^\circ$, $\theta' = 30^\circ$.

TABLE 7-12. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ]

λ	ρ	CURVE 1 $T = 293.$		CURVE 2 $T = 293.$		CURVE 2 (CONT.)		CURVE 3 (CONT.)		CURVE 3 (CONT.)	
		λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
2.20	0.094	0.30	0.432	3.19	0.068	13.31	0.196	7.1	0.869	38.1	0.153
2.80	0.096	0.32	0.508	3.45	0.068	13.77	0.173	7.4	0.806	40.1	0.153
3.80	0.092	0.36	0.542	3.82	0.068	16.58	0.174	7.6	0.730	41.1	0.151
6.00	0.300	0.38	0.607	4.96	0.050	17.21	0.181	7.7	0.604	42.0	0.151
6.20	0.027	0.39	0.647	4.30	0.067	17.66	0.194	7.7	0.504	43.2	0.154
6.10	0.379	0.39	0.682	4.58	0.055	18.08	0.205	7.7	0.407	44.2	0.154
6.30	0.459	0.43	0.727	4.79	0.055	18.40	0.205	7.9	0.331	45.5	0.154
6.60	0.800	0.43	0.756	4.99	0.050	19.99	0.199	6.9	0.295	45.8	0.154
6.90	0.872	0.49	0.787	5.17	0.050	19.43	0.228	6.3	0.255	46.9	0.154
7.10	0.803	0.49	0.812	5.35	0.041	19.97	0.202	6.7	0.226	48.1	0.154
7.40	0.705	0.51	0.834	5.61	0.038	20.40	0.223	9.1	0.206	50.0	0.154
7.50	0.395	0.54	0.847	5.93	0.021	20.99	0.213	10.0	0.206		
7.70	0.298	0.57	0.835	6.06	0.054	21.47	0.220	10.6	0.184		
8.00	0.253	0.67	0.835	6.19	0.084	21.99	0.220	11.4	0.169		
8.50	0.221	0.71	0.823	6.34	0.145	22.38	0.230	11.7	0.164		
9.00	0.211	0.74	0.796	6.37	0.225	22.69	0.230	12.0	0.180		
9.60	0.201	0.78	0.768	6.57	0.347	23.14	0.220	12.0	0.202		
10.5	0.177	0.62	0.761	6.66	0.401	23.65	0.222	12.2	0.250		
11.5	0.170	0.85	0.745	6.71	0.464	24.38	0.219	12.2	0.289		
11.8	0.180	0.89	0.761	6.86	0.532	25.00	0.235	12.6	0.344		
11.8	0.203	0.92	0.741	6.86	0.583			12.6	0.321		
12.1	0.360	0.97	0.722	7.00	0.635			12.7	0.246		
12.2	0.285	1.00	0.702	7.11	0.565			12.7	0.142		
12.5	0.143	1.00	0.657	7.31	0.465			13.2	0.172		
12.7	0.143	1.10	0.624	7.50	0.434			13.3	0.200		
12.9	0.200	1.30	0.580	7.66	0.353			13.6	0.165		
13.4	0.161	1.49	0.533	7.80	0.300			13.7	0.154		
14.9	0.154	1.78	0.423	7.18	0.255			15.0	0.154		
22.7	0.172	1.93	0.367	8.42	0.201			17.3	0.158		
25.3	0.190	1.93	0.361	8.68	0.185			18.7	0.167		
26.5	0.190	2.03	0.333	8.95	0.177			20.0	0.172		
28.2	0.168	2.15	0.322	9.82	0.158			22.2	0.187		
29.7	0.143	2.28	0.281	10.25	0.158			25.0	0.187		
31.7	0.132	2.43	0.202	10.96	0.142			26.3	0.167		
35.0	0.154	2.50	0.167	11.45	0.142			28.3	0.137		
50.0	0.156	2.77	0.112	11.90	0.131			30.1	0.134		
		2.86	0.151	12.43	0.117			31.6	0.133		
		2.97	0.133	12.64	0.143			33.4	0.142		
		2.97	0.109	12.69	0.169			35.0	0.154		
					7.0			37.1	0.150		

CURVE 3
 $T = 313.$

CURVE 3
 $T = 313.$

e. Normal Spectral Transmittance (Wavelength Dependence)

A total of seven sets of experimental data were located for the wavelength dependence of the normal spectral transmittance of boron nitride. The data are listed in Table 7-15 and shown in Figures 7-9 and 7-10. Specimen characterization and measurement information for the data are given in Table 7-14.

For the purposes of this report, the first four data sets are useless in aiding to arrive at evaluated data. Curve 5 forms the basis of a typical set of values which are valid at room temperature for platelets of yellow, undoped, single-crystals of cubic boron nitride. An assignment of typical is necessitated because of uninformed specimen dimensions. The uncertainty assigned is 30% or more.

TABLE 7-13. TYPICAL NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE)




FIGURE 7-9. TYPICAL NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).




FIGURE 7-10. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (WAVELENGTH DEPENDENCE).

TABLE 7-14. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF BORON NITRIDE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T51145		McCarthy, D.E.	1968	15-50	293		Synthetic specimen; thickness 6.0 mm; flat to 10 fringes or better; reference standard aluminum mirror; commercial double-beam instrument used; temperature not explicitly given, presumed to be 293 K; smooth values from figure; $\theta = 0^\circ$, $\theta' = 0^\circ$.
2 T58818		Miller, F.A. and Wilkins, C.H.	1952	2.0-16	293		Pure; fine powder suspended in Nujol; measurements made with Baird Model A spectrophotometer; smooth values from figure; wavelength measurements accurate to approx. $\pm 0.03 \mu$; portion of spectra from 2 to just over 7 μ m run in fluorolube; dip in spectra just below 14 μ m a Nujol band; measurement temperature not given explicitly, assumed to be 293 K.
3 T60470		Brame, E.G., Jr., Margrave, J.L., and Meloche, V.W.	1957	2-16	293		Hexagonal crystal structure; disk 1 mm thick and 12 mm in diameter; Baird Associates Model B spectrophotometer used; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
4 T29708		Redfield, D. and Baum, R.L.	1961	4-15	293		1 mg BN in 300 mg KBr-5 pressed at 270 000 psi to an 0.375 in diameter and 0.025 in thickness; smooth values from figure.
5 A00014		DeVries, R.C.	1972	0.2-13	293		Single-crystal (yellow, undoped); data taken on assemblage of small hexagonal-shaped platelets of cubic BN; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
6 T42872		Gelisse, P.J., Mitra, S.S., Plendl, J.N., Griffis, R.D., Mansur, L.C., Marshall, R., and Pascoe, E.A.	1967	2.7-24	293		Single crystal platelets with cubic structure (30 μ m thick); grown at very high pressure and temperature; $10^9 \Omega$ cm electrical resistivity; smooth values from figure; percent absorption reported on figure, normal spectral transmittance arrived at by equating percent normal spectral transmittance to 1.0 minus percent absorption.
7 T42872		Gelisse, P.J., et al.	1967	2.6-27	293		Similar to the above specimen except beryllium doped.

TABLE 7-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF RORON NITRIDE (WAVELENGTH DEPENDENCE)¹

TABLE 7-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF 3050N NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ
CURVE 6 (CONT.)		CURVE 6 (CONT.)		CURVE 6 (CONT.)		CURVE 7 (CONT.)	
2.82	0.462	11.60	0.364	11.12	0.299		
2.87	0.474	12.48	0.490	13.23	0.331		
2.93	0.481	13.02	0.513	17.33	0.349		
3.09	0.493	14.06	0.505	25.88	0.364		
3.25	0.525	16.84	0.536				
3.32	0.593	15.36	0.512				
3.34	0.633	16.42	0.491				
3.42	0.647	17.61	0.506				
3.56	0.643	17.95	0.560				
3.70	0.635	24.27	0.774				
3.92	0.643			CURVE 7			
4.037	0.633			T = 293.			
4.107	0.622						
4.177	0.634						
4.246	0.655						
4.307	0.624						
4.429	0.547						
4.695	0.442						
4.873	0.374						
4.951	0.289						
4.548	0.207						
5.005	0.163						
5.123	0.185						
5.160	0.200						
5.294	0.220						
5.414	0.241						
5.492	0.201						
5.492	0.175						
5.634	0.180						
5.640	0.251						
5.705	0.347						
5.952	0.388						
6.761	0.454						
7.310	0.483						
7.593	0.433						
7.794	0.231						
7.968	0.000						
10.34	0.000						
10.73	0.140						
11.07	0.235						
		11.07	0.235				

4.8. Calcium Aluminum Silicate

Since data evaluation was asked to be carried out on the specific kind of calcium aluminum silicate known as Corning 9753, the treatment in this section will concentrate on that material.

Corning 9753 is a solid solution of 30% CaO, 40% Al₂O₃, and 30% SiO₂ and is an infrared transmitting glass. It is a product of the Corning Glass Works, Corning, New York 14830. Other names by which it is known include Corning Code 9753, glass 9753, CGW-Glass 9753, Corning 9753 glass, and Cortran Code 9753. Cortran is a secondary trademark of the Corning Glass Works.

This material has several interesting physical properties which lead to its suitability for airborne applications. It melts around 1723 to 1773 K [T28664]. According to the Corning Glass Works specification sheet for Code 9753, copyrighted in 1970, other physical properties are as follows: It has a softening point (extrapolated) of 1254 K, an annealing point of 1105 K, and a strain point of 1073 K. The linear expansion coefficient between 298 and 573 K is $59.5 \times 10^{-7} \text{ C}^{-1}$ while between 29.8 and 973 K it is $72 \times 10^{-7} \text{ C}^{-1}$. Code 9753 has a density of 2.798 g cm^{-3} , a Young's modulus of $14.3 \times 10^6 \text{ psi}$, a shear modulus of $5.6 \times 10^6 \text{ psi}$, and a Poisson's ratio of 0.28. The Knoop hardness is 657.5 for a 100 g load and 601 for a 500 g load. These values of hardness makes this material highly suitable for high-speed airborne applications and coupled with its infrared transmitting properties leads to its use on heat-seeking missiles. The refractive index at 0.4867 μm is 1.61251, at 0.5893 μm is 1.60475, and at 0.6563 μm is 1.60151. The dielectric constant at 1 Mc and 298 K is 8.87 while for the same frequency it is 9.51 at 773 K; it is 8.28 at 298 K, 8.59 at 573 K, 8.66 at 673 K, and 8.76 at 773 K, all at 8600 Mc. The loss tangent at 1 Mc and 298 K is 0.0025 while for the same frequency it is 0.0029 at 773 K; it is 0.011 at 298 K, 0.01 at 573 K, 0.01 at 673 K, and 0.01 at 773 K, all at 8600 Mc. The log of the dc resistivity (ohm-cm) is 18.0 at 523 K, 15.0 at 623 K, and 11.8 at 773 K.

a. Normal Spectral Emittance (Wavelength Dependence)

There are six sets of experimental data available for the wavelength dependence of the normal spectral emittance, $\epsilon(\theta' \approx 0^\circ)$, of calcium aluminum silicate all of which apply to Corning 9753. The data is listed in Table 8-3 and shown in Figures 8-1 and 8-2. Specimen characterization and measurement information for the data are given in Table 8-2. Three data sets are for a specimen 0.3175 cm thick measured at temperatures 473 to 873 K. The remaining three data sets are for a 1.27 cm thick specimen covering the same temperature range.

It is observed that each of the six data sets is for a different combination of thickness and temperature and hence there is no direct confirmatory evidence for an individual data set. As a consequence of this lack of confirmatory evidence, only provisional values are justified. Two provisional curves are given for Corning 9753 for a specimen of 0.3175 cm with one curve applicable to 473 K and the other curve to 873 K. The provisional values are listed in Table 8-1 and shown in Figure 8-1. The thickness of 0.3175 cm is selected so as to be close to a thickness of 0.2 to 0.4 cm which is often used in reporting measurements. These two provisional curves are the same as curves 1 and 3 in Table 8-3 and Figure 8-1 with additional values reported. The uncertainty for the provisional values is within 30%.

It is noted that for curves 1-6 in Tables 8-2 and 8-3, data is not available for wavelengths below 1.5 μm and above 8.0 μm . In addition, data is unavailable over the entire wavelength region for temperatures above 873 K.

Assuming that the normal spectral emittance above 8.0 μm continues at a high and roughly constant value, the magnitude of emittance will be about 0.8 for a 3.175 mm thick specimen from 473 to 873 K.

Corroborating evidence of a high and roughly constant value above 8 μm for a slightly different thickness comes from the provisional values at 293 K for a specimen of 2 mm thick. These values are listed in Table 8-1 and shown in Figure 8-1. They were generated by using Eq. (2.3-2) to find α and using Kirchhoff's law, Eq. (2.3-4), to find the normal spectral emittance. The values of the normal spectral transmittance used in Eq. (2.3-2) are the provisional values listed in Table 8-12 and shown in Figure 8-9; these values apply to a temperature of 293 K and a specimen thickness of 2 mm. From 5.0 to 15 μm it was assumed the transmittance was zero. The values of the normal spectral reflectance used in Eq. (2.3-2) are the provisional values listed in Table 8-5 and shown in Figure 8-4; these values apply to a temperature of 293 K and a thickness of 1.99 mm. The uncertainty is thought to be well within 30% over most of the wavelength region.

TABLE 8-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (CORNING 9753) (WAVELENGTH DEPENDENCE)

(WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T = 293						T = 293 (CONT.)						T = 293 (CONT.)						T = 473						T = 473 (CONT.)					
2.00MM THICK			2.00MM THICK			2.00MM THICK			2.00MM THICK			3.175MM THICK			3.175MM THICK			3.175MM THICK			3.175MM THICK			3.175MM THICK					
λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ		
0.40	0.101	5.10	0.966	7.00	0.973	12.9	0.916	2.40	0.116	4.60	0.676	0.50	0.029	5.20	0.966	3.10	0.915	2.47	0.103	4.64	0.700	0.60	0.017	5.30	0.967	9.29	0.915		
0.50	0.029	5.20	0.966	7.10	0.965	13.0	0.915	2.50	0.099	4.70	0.756	0.60	0.015	5.40	0.967	9.30	0.934	2.59	0.090	4.71	0.775	0.70	0.022	5.50	0.968	9.40	0.916		
0.60	0.017	5.30	0.967	7.20	0.954	13.1	0.915	2.60	0.089	4.74	0.805	0.70	0.015	5.60	0.968	9.50	0.902	2.70	0.080	4.74	0.823	0.80	0.024	5.80	0.968	9.60	0.916		
0.80	0.015	5.40	0.967	7.30	0.934	13.2	0.915	2.70	0.070	4.77	0.832	0.90	0.028	5.80	0.968	9.60	0.886	2.73	0.060	4.77	0.869	1.00	0.024	6.00	0.968	9.70	0.916		
0.90	0.022	5.50	0.968	7.40	0.902	13.3	0.915	2.80	0.050	4.80	0.854	1.00	0.024	6.20	0.968	9.80	0.886	2.81	0.040	4.80	0.886	1.20	0.024	6.40	0.968	9.90	0.916		
1.00	0.024	5.60	0.968	7.50	0.886	13.4	0.916	2.90	0.030	4.83	0.886	1.20	0.026	6.40	0.969	10.0	0.873	2.93	0.020	4.83	0.916	1.40	0.026	6.60	0.969	10.1	0.916		
1.10	0.026	5.70	0.969	7.60	0.873	13.5	0.915	3.00	0.010	4.86	0.914	1.40	0.026	6.80	0.969	10.2	0.864	3.03	0.000	4.86	0.941	1.60	0.026	7.00	0.969	10.3	0.916		
1.20	0.027	5.80	0.969	7.70	0.864	13.6	0.914	3.10	0.000	4.89	0.941	1.60	0.028	7.20	0.969	10.3	0.854	3.13	0.000	4.89	0.975	1.80	0.028	7.40	0.969	10.4	0.916		
1.30	0.028	5.90	0.970	7.80	0.856	13.7	0.912	3.20	0.000	4.92	0.975	1.80	0.028	7.60	0.970	10.4	0.846	3.23	0.000	4.92	0.975	2.00	0.028	7.80	0.970	10.5	0.916		
1.40	0.028	6.00	0.970	7.90	0.846	13.8	0.910	3.30	0.000	4.95	0.975	2.00	0.028	7.80	0.971	10.5	0.841	3.33	0.000	4.95	0.975	2.20	0.028	8.00	0.971	10.6	0.916		
1.50	0.028	6.10	0.971	10.0	0.841	13.9	0.903	3.40	0.000	4.98	0.975	2.20	0.027	8.00	0.971	10.6	0.832	3.43	0.000	4.98	0.975	2.40	0.027	8.20	0.971	10.7	0.916		
1.60	0.027	6.20	0.971	10.1	0.832	14.0	0.905	3.50	0.000	5.01	0.975	2.40	0.027	8.10	0.972	10.7	0.825	3.53	0.000	5.01	0.975	2.60	0.026	8.30	0.972	10.8	0.916		
1.70	0.027	6.30	0.972	10.2	0.825	14.1	0.905	3.60	0.000	5.04	0.975	2.60	0.026	8.20	0.973	10.8	0.825	3.63	0.000	5.04	0.975	2.80	0.026	8.40	0.973	10.9	0.916		
1.80	0.026	6.40	0.973	10.3	0.825	14.2	0.905	3.70	0.000	5.07	0.975	2.80	0.026	8.30	0.974	10.9	0.825	3.73	0.000	5.07	0.975	3.00	0.026	8.50	0.974	11.0	0.916		
2.00	0.026	6.50	0.974	10.4	0.820	14.3	0.905	3.80	0.000	5.10	0.975	3.00	0.025	8.40	0.975	11.0	0.820	3.85	0.000	5.10	0.975	3.20	0.025	8.60	0.975	11.1	0.916		
2.30	0.025	6.60	0.975	10.5	0.820	14.4	0.905	3.90	0.000	5.13	0.975	3.20	0.025	8.50	0.975	11.0	0.820	3.95	0.000	5.13	0.975	3.40	0.025	8.70	0.975	11.1	0.916		
2.40	0.026	6.70	0.976	10.6	0.820	14.5	0.902	4.00	0.000	5.16	0.975	3.40	0.026	8.60	0.976	11.1	0.820	4.05	0.000	5.16	0.975	3.60	0.026	8.80	0.976	11.2	0.916		
2.50	0.027	6.80	0.977	10.7	0.821	14.6	0.902	4.10	0.000	5.19	0.975	3.60	0.026	8.70	0.977	11.2	0.822	4.15	0.000	5.19	0.975	3.80	0.026	8.90	0.977	11.3	0.916		
2.60	0.031	6.90	0.978	10.8	0.822	14.7	0.902	4.20	0.000	5.22	0.975	3.80	0.026	8.80	0.978	11.3	0.823	4.25	0.000	5.22	0.975	4.00	0.026	9.00	0.978	11.4	0.916		
2.70	0.036	7.00	0.979	10.9	0.823	14.8	0.902	4.30	0.000	5.25	0.975	4.00	0.026	8.90	0.979	11.4	0.823	4.35	0.000	5.25	0.975	4.20	0.026	9.10	0.979	11.5	0.916		
2.80	0.045	7.10	0.980	11.0	0.826	14.9	0.905	4.40	0.000	5.28	0.975	4.20	0.026	9.00	0.980	11.5	0.826	4.45	0.000	5.28	0.975	4.40	0.026	9.20	0.980	11.6	0.916		
2.90	0.062	7.20	0.981	11.1	0.837	15.0	0.905	4.50	0.000	5.31	0.975	4.40	0.026	9.10	0.981	11.6	0.837	4.55	0.000	5.31	0.975	4.60	0.026	9.30	0.981	11.7	0.916		
3.20	0.066	7.30	0.982	11.2	0.835	15.1	0.905	4.60	0.000	5.34	0.975	4.60	0.026	9.20	0.982	11.7	0.835	4.65	0.000	5.34	0.975	4.70	0.026	9.40	0.982	11.8	0.916		
3.30	0.064	7.40	0.983	11.3	0.844	15.2	0.905	4.70	0.000	5.37	0.975	4.80	0.026	9.30	0.983	11.8	0.844	4.75	0.000	5.37	0.975	4.80	0.026	9.50	0.983	11.9	0.916		
3.40	0.064	7.50	0.984	11.4	0.849	15.3	0.905	4.80	0.000	5.40	0.975	4.90	0.026	9.40	0.984	11.9	0.849	4.85	0.000	5.40	0.975	4.90	0.026	9.60	0.984	12.0	0.916		
3.50	0.064	7.60	0.986	11.5	0.855	15.4	0.905	4.90	0.000	5.43	0.975	5.10	0.026	9.50	0.986	12.0	0.860	4.95	0.000	5.43	0.975	5.20	0.026	9.70	0.986	12.1	0.916		
3.60	0.066	7.70	0.987	11.6	0.860	15.5	0.905	5.00	0.000	5.46	0.975	5.20	0.026	9.60	0.987	12.1	0.865	5.05	0.000	5.46	0.975	5.30	0.026	9.80	0.987	12.2	0.916		
3.90	0.100	7.80	0.989	11.7	0.866	15.6	0.905	5.10	0.000	5.49	0.975	5.30	0.026	9.70	0.989	12.2	0.866	5.15	0.000	5.49	0.975	5.40	0.026	9.90	0.989	12.3	0.916		
4.00	0.116	7.90	0.990	11.8	0.871	15.7	0.905	5.20	0.000	5.52	0.975	5.40	0.026	9.80	0.990	12.3	0.871	5.25	0.000	5.52	0.975	5.50	0.026	10.00	0.990	12.4	0.916		
4.10	0.151	8.00	0.996	11.9	0.876	15.8	0.905	5.30	0.000	5.55	0.975	5.50	0.026	9.90	0.996	12.4	0.876	5.35	0.000	5.55	0.975	5.60	0.026	10.10	0.996	12.5	0.916		
4.20	0.202	8.10	1.00	12.0	0.880	15.9	0.905	5.40	0.000	5.58	0.975	5.60	0.026	10.00	1.00	12.0	0.880	5.45	0.000	5.58	0.975	5.70	0.026	10.20	1.00	12.1	0.880		
4.30	0.272	8.20	1.00	12.1	0.885	16.0	0.905	5.50	0.000	5.61	0.975	5.70	0.026	10.10	1.00	12.1	0.885	5.56	0.000	5.61	0.975	5.80	0.026	10.30	1.00	12.2	0.885		
4.40	0.391	8.30	1.00	12.2	0.890	16.1	0.905	5.60	0.000	5.64	0.975	5.80	0.026	10.20	1.00	12.2	0.890	5.61	0.000	5.64	0.975	5.90	0.026	10.40	1.00	12.3	0.890		
4.50	0.543	8.40	1.00	12.3	0.895	16.2	0.905	5.70	0.000	5.67	0.975	5.90	0.026	10.30	1.00	12.3	0.895	5.66	0.000	5.67	0.975	6.00	0.026	10.50	1.00	12.4	0.895		
4.60	0.715	8.50	1.00	12.4	0.905	16.3	0.905	5.80	0.000	5.70	0.975	6.00	0.026	10.40	1.00	12.4	0.905	5.75	0.000	5.70	0.975	6.10	0.026	10.60	1.00	12.5	0.905		
4.70	0.824	8.60	1.00	12.5	0.910	16.4	0.905	5.90	0.000	5.73	0.975	6.10	0.026	10.50	1.00	12.5	0.910	5.80	0.000	5.73	0.975	6.20	0.026	10.70	1.00	12.6	0.910		
4.80	0.900																												

TABLE 8-1. PROVISIONAL NORMAL SPECTRAL EMISSANCE OF CALCIUM ALUMINUM SILICATE (CORNING 9753) (WAVELENGTH DEPENDENCE) (CONTINUED)

T = 473 (CONT.)			T = 873			T = 473 (CONT.)			T = 873 (CONT.)		
λ	ϵ		λ	ϵ		λ	ϵ		λ	ϵ	
3.175MM THICK			3.175MM THICK			3.175MM THICK			3.175MM THICK		
6.50	0.880		6.52	0.643		6.10	0.324		6.57	0.632	
6.53	0.879		6.56	0.641		6.26	0.446		6.63	0.632	
6.60	0.874		6.70	0.637		6.20	0.402		6.70	0.632	
6.64	0.871		6.90	0.634		6.30	0.440		6.80	0.632	
6.70	0.862		6.86	0.632		6.40	0.565		6.90	0.633	
6.76	0.852		6.90	0.631		6.49	0.635		7.03	0.633	
6.80	0.845		7.00	0.630		6.50	0.640		7.10	0.633	
6.86	0.833		7.10	0.628		6.60	0.702		7.20	0.633	
6.90	0.826		7.19	0.628		6.63	0.721		7.30	0.632	
6.97	0.818		7.20	0.628		6.70	0.763		7.40	0.631	
7.00	0.817		7.30	0.631		6.75	0.807		7.50	0.630	
7.09	0.818		7.34	0.632		6.80	0.819		7.63	0.632	
7.10	0.816		7.40	0.635		6.82	0.827		7.70	0.635	
7.16	0.820		7.50	0.640		6.90	0.846		7.80	0.637	
7.20	0.822		7.59	0.645		6.91	0.846		7.90	0.639	
7.30	0.826		7.60	0.646		6.99	0.860		8.00	0.642	
7.40	0.834		7.70	0.651		7.00	0.861				
7.42	0.835		7.76	0.653		7.09	0.869				
7.50	0.837		7.80	0.656		7.10	0.870				
7.59	0.835		7.90	0.666		7.20	0.876				
7.60	0.835		7.99	0.673		7.30	0.878				
7.68	0.831		8.00	0.674		7.36	0.876				
7.70	0.830		8.10	0.682		7.40	0.875				
7.80	0.826		8.20	0.690		7.50	0.880				
7.84	0.822		8.26	0.696		7.55	0.878				
7.90	0.819		8.30	0.699		7.60	0.878				
8.00	0.811		8.40	0.711		7.67	0.875				
			8.44	0.716		7.70	0.873				
			8.50	0.724		7.75	0.866				
			8.56	0.733		7.80	0.860				
			8.60	0.740		7.89	0.856				
			8.69	0.759		7.93	0.854				
			8.70	0.763		8.00	0.847				
			8.80	0.796		8.05	0.842				
			8.82	0.804		8.10	0.839				
			8.90	0.823		8.15	0.833				
			8.99	0.867		8.20	0.832				
			9.00	0.873		8.40	0.834				




FIGURE 8-1. PROVISIONAL NORMAL SPECTRAL EMISSANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).




FIGURE 8-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).

TABLE 8-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMMITTANCE OF CALCIUM ALUMINUM SILICATE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 A00009	A00009	Kandach, G.S.	1975	2.5-8.0	473	Corning 9753	Specimen 0.3175 cm (1/8 in.) thick; spectral emittance; smooth values from figure.
2 A00009	A00009	Kandach, G.S.	1975	1.6-8.0	673	Corning 9753	Similar to the above specimen.
3 A00009	A00009	Kandach, G.S.	1975	1.5-8.0	873	Corning 9753	Similar to the above specimen.
4 A00009	A00009	Kandach, G.S.	1975	2.5-7.9	473	Corning 9753	Specimen 1.27 cm (1/2 in.) thick; spectral emittance; smooth values from figure.
5 A00009	A00009	Kandach, G.S.	1975	1.8-8.0	673	Corning 9753	Similar to the above specimen.
6 A00009	A00009	Kandach, G.S.	1975	1.5-8.0	873	Corning 9753	Similar to the above specimen.

TABLE 8-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	CURVE 1		CURVE 1 (CONT.)		CURVE 2		CURVE 2 (CONT.)		CURVE 3		CURVE 3 (CONT.)		CURVE 4		CURVE 4 (CONT.)	
		$T = 473.$	$T = 673.$	$T = 473.$	$T = 673.$	$T = 473.$	$T = 673.$	$T = 473.$	$T = 673.$	$T = 473.$	$T = 673.$	$T = 473.$	$T = 673.$	$T = 473.$	$T = 673.$	$T = 473.$	$T = 673.$
2.47	0.103	6.53	6.79	4.66	0.795	3.44	0.116	3.20	0.230	5.66	0.945	3.29	0.254	6.71	0.932	6.76	0.910
2.59	0.090	6.64	6.871	4.69	0.827	3.56	0.133	3.29	0.254	5.99	0.887	3.37	0.280	6.91	0.891	6.82	0.891
2.73	0.077	6.76	0.652	4.72	0.846	3.69	0.159	3.44	0.204	5.53	0.343	3.53	0.343	6.91	0.857	6.91	0.853
2.81	0.069	6.86	0.833	4.76	0.859	3.82	0.204	3.44	0.267	6.63	0.400	3.63	0.400	6.99	0.853	6.99	0.853
2.91	0.065	6.97	0.618	4.81	0.873	3.99	0.267	3.44	0.317	3.70	0.438	7.11	0.347	7.11	0.347	7.11	0.347
3.04	0.060	7.09	0.818	4.88	0.882	4.08	0.317	3.70	0.446	3.83	0.507	7.28	0.847	7.28	0.847	7.28	0.847
3.14	0.056	7.18	0.823	4.94	0.891	4.26	0.446	3.83	0.565	3.83	0.507	7.46	0.655	7.46	0.655	7.46	0.655
3.21	0.060	7.42	0.835	5.55	0.898	4.40	0.565	3.91	0.635	3.99	0.572	7.58	0.661	7.58	0.661	7.58	0.661
3.31	0.065	7.59	0.635	5.24	0.898	4.48	0.635	4.08	0.721	4.08	0.605	7.72	0.851	7.72	0.851	7.72	0.851
3.46	0.079	7.68	0.831	5.33	0.895	4.63	0.721	4.75	0.783	4.08	0.655	7.92	0.849	7.92	0.849	7.92	0.849
3.57	0.095	7.84	0.822	5.44	0.887	4.70	0.783	4.80	0.807	4.18	0.657	7.92	0.849	7.92	0.849	7.92	0.849
3.70	0.122	8.00	0.811	5.58	0.874	4.75	0.807	4.82	0.827	4.26	0.700	7.92	0.849	7.92	0.849	7.92	0.849
3.96	0.167	8.00	0.167	5.71	0.861	4.82	0.827	4.88	0.848	4.33	0.759	7.92	0.849	7.92	0.849	7.92	0.849
4.02	0.195	8.00	0.195	5.83	0.851	4.91	0.848	4.94	0.869	4.39	0.799	7.92	0.849	7.92	0.849	7.92	0.849
4.09	0.227	8.00	0.227	5.91	0.846	4.99	0.869	5.09	0.869	4.43	0.829	7.92	0.849	7.92	0.849	7.92	0.849
4.18	0.278	8.00	0.278	6.00	0.840	5.09	0.869	5.20	0.876	4.51	0.861	7.92	0.849	7.92	0.849	7.92	0.849
4.24	0.332	8.00	0.332	5.55	0.642	6.22	0.832	5.36	0.878	4.58	0.886	7.92	0.849	7.92	0.849	7.92	0.849
4.36	0.453	8.00	0.453	1.70	0.636	6.35	0.828	5.36	0.878	4.65	0.903	7.92	0.849	7.92	0.849	7.92	0.849
4.46	0.534	8.00	0.466	1.88	0.630	6.51	0.822	5.55	0.878	4.73	0.923	7.92	0.849	7.92	0.849	7.92	0.849
4.58	0.643	8.00	0.58	2.01	0.632	6.72	0.822	5.67	0.875	4.82	0.933	7.92	0.849	7.92	0.849	7.92	0.849
4.64	0.700	8.00	0.644	2.17	0.632	6.85	0.825	5.99	0.855	4.91	0.941	7.92	0.849	7.92	0.849	7.92	0.849
4.71	0.775	8.00	0.775	2.30	0.636	7.09	0.831	6.12	0.846	4.99	0.941	7.92	0.849	7.92	0.849	7.92	0.849
4.74	0.835	8.00	0.835	2.52	0.641	7.26	0.831	6.32	0.838	5.08	0.948	7.92	0.849	7.92	0.849	7.92	0.849
4.77	0.823	8.00	0.823	2.67	0.648	7.36	0.827	6.57	0.832	5.14	0.948	7.92	0.849	7.92	0.849	7.92	0.849
4.82	0.841	8.00	0.841	2.78	0.655	7.66	0.810	7.20	0.833	5.28	0.939	7.92	0.849	7.92	0.849	7.92	0.849
4.87	0.854	8.00	0.854	2.98	0.733	7.81	0.804	7.50	0.830	5.25	0.921	7.92	0.849	7.92	0.849	7.92	0.849
4.91	0.366	8.00	0.366	3.30	0.106	8.30	0.798	7.70	0.835	5.38	0.896	7.92	0.849	7.92	0.849	7.92	0.849
4.96	0.869	8.00	0.869	3.49	0.124	8.49	0.842	8.00	0.842	5.45	0.886	7.92	0.849	7.92	0.849	7.92	0.849
5.03	0.869	8.00	0.869	3.59	0.140	8.59	0.842	8.00	0.842	5.52	0.880	7.92	0.849	7.92	0.849	7.92	0.849
5.02	0.860	8.00	0.860	3.66	0.159	8.66	0.843	8.00	0.843	5.63	0.874	7.92	0.849	7.92	0.849	7.92	0.849
5.42	0.435	8.00	0.435	3.82	0.202	8.72	0.842	8.00	0.842	5.78	0.874	7.92	0.849	7.92	0.849	7.92	0.849
5.53	0.829	8.00	0.829	3.97	0.242	1.52	0.043	5.96	0.878	5.95	0.599	6.36	0.22	6.36	0.22	6.36	0.22
5.65	0.820	8.00	0.820	4.04	0.274	1.69	0.032	2.52	0.196	5.99	0.887	6.01	0.636	6.01	0.636	6.01	0.636
5.76	0.820	8.00	0.820	4.11	0.307	2.10	0.028	2.66	0.190	6.09	0.897	6.07	0.714	6.07	0.714	6.07	0.714
5.85	0.824	8.00	0.824	4.16	0.337	2.19	0.028	2.74	0.167	6.18	0.914	6.12	0.767	6.12	0.767	6.12	0.767
5.93	0.835	8.00	0.835	4.23	0.397	2.34	0.032	2.84	0.187	6.29	0.936	6.17	0.805	6.17	0.805	6.17	0.805
6.18	0.858	8.00	0.858	4.31	0.468	2.59	0.045	2.92	0.190	6.37	0.951	6.22	0.835	6.22	0.835	6.22	0.835
6.29	0.869	8.00	0.869	4.41	0.574	2.76	0.053	3.00	0.195	6.45	0.963	6.29	0.859	6.29	0.859	6.29	0.859
6.38	0.876	8.00	0.876	4.49	0.647	2.99	0.073	3.06	0.200	6.56	0.963	6.36	0.869	6.36	0.869	6.36	0.869
6.43	0.879	8.00	0.879	4.58	0.737	3.26	0.096	3.13	0.215	6.62	0.955	6.42	0.918	6.42	0.918	6.42	0.918

TABLE 8-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DÉPENDENCE) (CONTINUED)

λ	ϵ	λ	ϵ	CURVE 5 (CONT.)	λ	ϵ	CURVE 6 (CONT.)
4.48	0.929	2.92	0.151				
4.55	0.935	2.98	0.167				
4.64	0.942	3.05	0.187				
4.74	0.947	3.11	0.204				
4.94	0.947	3.16	0.224				
5.13	0.943	3.27	0.267				
5.39	0.932	3.36	0.303				
5.63	0.919	3.45	0.346				
5.77	0.912	3.55	0.406				
5.95	0.904	3.66	0.478				
6.09	0.904	3.75	0.533				
6.28	0.916	3.88	0.601				
6.38	0.913	4.02	0.679				
6.49	0.913	4.10	0.729				
6.56	0.919	4.26	0.771				
6.63	0.930	4.29	0.811				
6.73	0.877	4.38	0.845				
6.81	0.859	4.49	0.885				
6.88	0.850	4.53	0.900				
6.96	0.841	4.66	0.902				
7.03	0.834	4.98	0.861				
7.17	0.829	5.08	0.874				
7.31	0.824	5.25	0.874				
7.61	0.821	5.42	0.886				
8.00	0.818	5.50	0.882				
CURVE 6 $T = 873^\circ$		5.57	0.884				
		5.69	0.884				
		5.80	0.877				
		5.91	0.870				
		6.01	0.864				
		6.30	0.861				
		6.60	0.859				
		6.91	0.849				
		7.09	0.845				
		7.41	0.845				
		7.70	0.849				
		8.00	0.849				

b. Normal Spectral Emittance (Temperature Dependence)

No original experimental data were located for the temperature dependence of the normal spectral emittance of Corning 9753. However, using the interpolated values of curves 1, 2, and 3 of Figure 8-1 and Table 8-3, provisional values for a specimen thickness of 3.175 mm have been derived for 2.8, 3.8, and 5.0 μm . These provisional values are listed in Table 8-4 and shown in Figure 8-3. The uncertainty of the provisional values is within 30%. It is noted these values only go to 873 K and there are no values for higher temperatures for the thickness of 3.175 mm.

It is observed that the value of normal spectral emittance of Corning 9753 over the temperature range of 473 to 873 K is a constant, to a first approximation. Assuming that this constancy extends to the melting range of 1723 to 1773 K, it would be concluded that, in that temperature range, the numerical value of the normal spectral emittance of Corning 9753 would be 0.06 at 2.8 μm , 0.2 at 3.8 μm , and 0.9 at 5.0 μm .

TABLE 6-4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF CALCIUM ALUMINUM SILICATE (CORNING 9753) (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

	T	ϵ		T	ϵ		T	ϵ
3.175MM THICK								
3.175MM THICK								
$\lambda = 2.8$			$\lambda = 3.8$			$\lambda = 5.0$		
473.	0.068		473.	0.144		473.	0.869	
673.	0.057		673.	0.198		673.	0.895	
873.	0.057		873.	0.199		873.	0.861	




FIGURE 8-3. PROVISIONAL NORMAL SPECTRAL EMISSANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

Only one data set was found for the wavelength dependence of the normal spectral reflectance. This is curve number 5 ($T = 293\text{ K}$, specimen thickness 1.99 mm) with the data listed in Table 8-7 and shown in Figures 8-4 and 8-5. Specimen characterization and measurement information for the data set are given in Table 8-6.

Values for other conditions have been generated for the normal spectral reflectance. Values for curve number 1 in Tables 8-6 and 8-7 were calculated using equation (2.6-15) which holds for a polished, uncoated, plane-parallel plate, taking into account multiple internal reflectance, and assuming zero absorption. The refractive index data was taken from curve number 1 in Table 8-9 and shown in Figure 8-6. Specimen characterization and measurement information for the refractive index data are given in Table 8-8.

Values of reflectance for a specimen thickness of 3.175 mm at 473 , 673 , and 873 K were calculated from normal transmittance and normal emittance data with details of the calculation mentioned in Table 8-6 for curves 2, 3, and 4.

Two provisional curves are given with one applicable to $T = 293\text{ K}$ and a specimen thickness of 1.99 mm and the other for $T = 873\text{ K}$ and a specimen thickness of 3.175 mm . The latter is shown to give an indication of the effect of temperature and thickness change. The uncertainty of these values can be large because of the small values of reflectance involved. However, over most of the wavelength region, the uncertainty should not exceed 30%. The provisional values are listed in Table 8-5 and shown in Figure 8-4.

It is noted that no reflectance data are available above 873 K and even the values for 473 , 673 , and 873 K do not go beyond $8\text{ }\mu\text{m}$.

TABLE 8-5. PROVISIONAL NORMAL SPECTRAL REFLECTANCE^a OF CALCIUM ALUMINUM SILICATE:CORNING 97531 (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
1.99MM THICK		1.99MM THICK		1.99MM THICK		1.99MM THICK		1.99MM THICK		1.99MM THICK	
$T = 293$		$T = 293$ (CONT.)		$T = 293$ (CONT.)		$T = 293$ (CONT.)		$T = 293$ (CONT.)		$T = 293$ (CONT.)	
0.40	0.10 ⁴	4.30	0.075	9.20	0.000	12.1	0.115	2.00	0.125	6.00	0.146
0.50	0.103	4.40	0.065	9.30	0.001	12.2	0.110	2.10	0.120	6.10	0.153
0.60	0.102	4.50	0.047	9.40	0.000	12.3	0.103	2.20	0.115	6.20	0.158
0.70	0.101	4.60	0.040	9.50	0.000	12.4	0.095	2.30	0.107	6.30	0.161
0.80	0.103	4.70	0.038	9.60	0.000	12.5	0.090	2.40	0.099	6.40	0.164
0.90	0.100	4.80	0.037	9.70	0.002	12.6	0.086	2.50	0.083	6.50	0.166
1.00	0.099	4.90	0.036	9.80	0.010	12.7	0.084	2.60	0.077	6.60	0.168
1.10	0.099	5.00	0.035	9.90	0.018	12.8	0.084	2.80	0.102	6.70	0.168
1.20	0.099	5.10	0.034	9.90	0.027	12.9	0.084	2.90	0.105	6.80	0.168
1.30	0.098	5.20	0.034	9.90	0.035	13.0	0.084	3.00	0.092	6.90	0.167
1.40	0.096	5.30	0.033	9.90	0.046	13.1	0.084	3.10	0.082	7.00	0.167
1.50	0.096	5.40	0.033	9.90	0.066	13.2	0.084	3.20	0.076	7.10	0.167
1.60	0.095	5.50	0.032	9.90	0.098	13.3	0.084	3.30	0.071	7.20	0.167
1.70	0.097	6.60	0.032	9.90	0.114	13.4	0.084	3.40	0.068	7.30	0.168
1.80	0.097	5.70	0.031	9.90	0.127	13.5	0.085	3.50	0.076	7.40	0.169
1.90	0.096	5.80	0.031	9.90	0.136	13.6	0.086	3.60	0.102	7.50	0.170
2.00	0.096	5.90	0.030	9.90	0.144	13.7	0.086	3.70	0.092	7.60	0.168
2.10	0.095	6.00	0.030	9.90	0.152	13.8	0.090	3.80	0.073	7.70	0.165
2.20	0.095	6.10	0.029	10.0	0.159	13.9	0.092	3.90	0.058	7.80	0.163
2.30	0.095	6.20	0.029	10.1	0.166	14.0	0.095	4.00	0.049	7.90	0.161
2.40	0.094	6.30	0.028	10.2	0.175	14.1	0.099	4.10	0.040	8.00	0.158
2.50	0.094	6.40	0.027	10.3	0.175	14.2	0.104	4.20	0.016		
2.60	0.193	6.50	0.026	10.4	0.160	14.3	0.110	4.30	0.022		
2.70	0.093	6.60	0.025	10.5	0.180	14.4	0.115	4.40	0.040		
2.80	0.092	6.70	0.024	10.6	0.180	14.5	0.118	4.50	0.064		
2.90	0.091	6.80	0.023	10.7	0.179	14.6	0.121	4.60	0.102		
3.00	0.091	6.90	0.022	10.8	0.178	14.7	0.123	4.70	0.105		
3.10	0.090	7.00	0.021	10.9	0.177	14.8	0.127	4.80	0.123		
3.20	0.090	7.10	0.020	11.0	0.174	14.9	0.134	4.90	0.139		
3.30	0.089	7.20	0.019	11.1	0.163	15.0	0.139	5.00	0.139		
3.40	0.088	7.30	0.018	11.2	0.161	15.1	0.130	5.10	0.130		
3.50	0.088	7.40	0.017	11.3	0.156	15.2	0.124	5.20	0.124		
3.60	0.086	7.50	0.016	11.4	0.151	15.3	0.122	5.30	0.122		
3.70	0.085	7.60	0.014	11.5	0.145	15.4	0.121	5.40	0.121		
3.80	0.084	7.70	0.013	11.6	0.140	15.5	0.120	5.50	0.120		
3.90	0.084	7.80	0.011	11.7	0.134	15.6	0.122	5.60	0.122		
4.00	0.084	7.90	0.010	11.8	0.129	15.7	0.127	5.70	0.127		
4.10	0.079	8.00	0.004	11.9	0.124	15.8	0.134	5.80	0.134		
4.20	0.075	8.10	0.000	12.0	0.120	15.9	0.140	5.90	0.140		

3.175MM THICK

T = 673 (CONT.)

T = 673

T = 673 (CONT.)




FIGURE 8-4. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).




FIGURE 8-5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).

TABLE S-6. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 E62600, A00009		0.50-4.0	293	Glass 9753		Calculated from refractive index data [see Ref. A60009] and using $(n-1)^2/(n^2+1)$ which applies to a polished, uncoated, plane-parallel plate, takes into account multiple internal reflections, and assumes zero absorption; measurement temperature for refractive index data not given explicitly, assumed to be 293 K.
2 A00009		2.4-8.0	473	Corning 9753		Specimen thickness 0.3175 cm (1/8 in.); calculated using $\rho = 1.0 - \alpha - \tau$, and $\alpha = \epsilon$. where data for ϵ from curve no. 1 of Tables 8-2 and 8-3, data for τ from curve no. 7 of Tables 8-13 and 8-14, from 4.9 to 8.0 μm , τ taken to be 0.000.
3 A00009		2.0-8.0	673	Corning 9753		Specimen thickness 0.3175 cm (1/8 in.); calculated using $\rho = 1.0 - \alpha - \tau$ and $\alpha = \epsilon$ where data for ϵ from curve no. 2 of Tables 8-2 and 8-3, data for τ from curve no. 8 of Tables 8-13 and 8-14, from 4.80 to 8.0 μm , τ taken to be 0.000.
4 A00009		2.0-8.0	873	Corning 9753		Specimen thickness 0.3175 cm (1/8 in.); calculated using $\rho = 1.0 - \alpha - \tau$ and $\alpha = \epsilon$ where data for ϵ from curve no. 3 of Tables 8-2 and 8-3, data for τ from curve no. 9 of Tables 8-13 and 8-14, from 4.94 to 8.0 μm , τ taken to be 0.000.
5 A00013	Plummer, W.A.	2.5-15	293	Code 9753		Specimen 1.99 mm thick; reflectance vs. aluminum reported; smooth values from figure; measurement 221 infrared spectrophotometer used; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.

TABLE 8-7. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ]

λ	ρ	CURVE $T = 293$.	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 4 (CONT.)
			λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
0.500	0.103	3.40	0.112	7.40	0.166	4.90	0.116	2.40	0.099	6.50	0.166	3.50	0.083	5.60	0.168	6.60	0.168	6.70	0.168	
0.594	0.132	3.50	0.102	7.50	0.163	5.00	0.105	2.50	0.083	6.60	0.168	3.60	0.077	5.70	0.168	6.80	0.168	6.90	0.168	
0.694	0.161	3.60	0.092	7.60	0.165	5.10	0.100	2.60	0.077	6.70	0.167	3.70	0.077	5.80	0.168	6.90	0.167	7.00	0.167	
0.834	0.160	3.70	0.085	7.70	0.170	5.20	0.100	2.80	0.077	6.80	0.167	3.80	0.077	5.90	0.167	7.00	0.167	7.10	0.167	
1.001	0.199	3.80	0.081	7.80	0.174	5.30	0.104	2.90	0.075	6.90	0.167	3.90	0.075	7.00	0.167	7.10	0.167	7.20	0.167	
1.112	0.039	3.90	0.078	7.90	0.181	5.40	0.110	3.00	0.092	7.00	0.167	4.00	0.082	7.10	0.167	7.20	0.167	7.30	0.167	
1.202	0.099	4.00	0.081	8.00	0.189	5.50	0.118	3.10	0.092	7.10	0.167	4.10	0.076	7.20	0.167	7.30	0.167	7.40	0.167	
1.346	0.098	4.20	0.054	8.10	0.173	5.60	0.128	3.20	0.076	7.30	0.167	4.20	0.076	7.40	0.167	7.50	0.167	7.60	0.167	
1.495	0.098	4.30	0.061	8.20	0.177	5.70	0.137	3.30	0.071	7.40	0.167	4.30	0.068	7.50	0.167	7.60	0.167	7.70	0.167	
1.730	0.097	4.40	0.097	8.30	0.174	5.80	0.146	3.40	0.078	7.50	0.167	4.40	0.092	7.60	0.167	7.70	0.167	7.80	0.167	
2.003	0.396	4.50	0.094	8.40	0.174	5.90	0.146	3.50	0.092	7.60	0.167	4.50	0.102	7.70	0.167	7.80	0.167	7.90	0.167	
2.274	0.095	4.60	0.125	8.50	0.175	6.00	0.154	3.60	0.092	7.70	0.167	4.60	0.092	7.80	0.167	7.90	0.167	8.00	0.167	
2.489	0.095	4.70	0.125	8.60	0.175	6.10	0.154	3.70	0.092	7.80	0.167	4.70	0.092	7.90	0.167	8.00	0.167	8.10	0.167	
2.613	0.394	4.80	0.118	8.70	0.178	6.20	0.154	3.80	0.092	7.90	0.167	4.80	0.092	8.00	0.167	8.10	0.167	8.20	0.167	
2.767	0.094	4.90	0.142	8.80	0.180	6.30	0.154	3.90	0.092	8.00	0.167	4.90	0.092	8.10	0.167	8.20	0.167	8.30	0.167	
2.352	0.693	5.00	0.136	8.90	0.182	6.40	0.154	4.00	0.092	8.10	0.167	5.00	0.092	8.20	0.167	8.30	0.167	8.40	0.167	
2.357	0.393	5.10	0.132	9.00	0.182	6.50	0.154	4.10	0.092	8.20	0.167	5.10	0.092	8.30	0.167	8.40	0.167	8.50	0.167	
3.112	0.392	5.20	0.136	9.10	0.182	6.60	0.154	4.20	0.092	8.30	0.167	5.20	0.092	8.40	0.167	8.50	0.167	8.60	0.167	
3.260	0.391	5.30	0.149	9.20	0.182	6.70	0.154	4.30	0.092	8.40	0.167	5.30	0.092	8.50	0.167	8.60	0.167	8.70	0.167	
3.352	0.391	5.40	0.160	9.30	0.182	6.80	0.154	4.40	0.092	8.50	0.167	5.40	0.092	8.60	0.167	8.70	0.167	8.80	0.167	
3.495	0.390	5.50	0.168	9.40	0.182	6.90	0.154	4.50	0.092	8.60	0.167	5.50	0.092	8.70	0.167	8.80	0.167	8.90	0.167	
3.610	0.390	5.60	0.177	9.50	0.182	7.00	0.154	4.60	0.092	8.70	0.167	5.60	0.092	8.80	0.167	8.90	0.167	9.00	0.167	
3.723	0.399	5.70	0.182	9.60	0.182	7.10	0.154	4.70	0.092	8.80	0.167	5.70	0.092	8.90	0.167	9.00	0.167	9.10	0.167	
3.847	0.383	5.80	0.175	9.70	0.182	7.20	0.154	4.80	0.092	8.90	0.167	5.80	0.092	9.00	0.167	9.10	0.167	9.20	0.167	
4.000	0.087	5.90	0.172	9.80	0.182	7.30	0.154	4.90	0.092	9.00	0.167	5.90	0.092	9.10	0.167	9.20	0.167	9.30	0.167	
6.10	0.151	9.90	0.163	9.90	0.163	7.40	0.154	5.00	0.092	9.10	0.167	6.00	0.092	9.20	0.167	9.30	0.167	9.40	0.167	
6.10	0.140	10.00	0.182	10.00	0.182	7.50	0.154	5.10	0.092	9.20	0.167	6.10	0.092	9.30	0.167	9.40	0.167	9.50	0.167	
6.30	0.130	10.10	0.175	10.10	0.175	7.60	0.154	5.20	0.092	9.30	0.167	6.20	0.092	9.40	0.167	9.50	0.167	9.60	0.167	
6.40	0.123	10.20	0.123	10.20	0.123	7.70	0.154	5.30	0.092	9.40	0.167	6.30	0.092	9.50	0.167	9.60	0.167	9.70	0.167	
6.50	0.114	10.30	0.120	10.30	0.120	7.80	0.154	5.40	0.092	9.50	0.167	6.40	0.092	9.60	0.167	9.70	0.167	9.80	0.167	
6.60	0.104	10.40	0.114	10.40	0.114	7.90	0.154	5.50	0.092	9.60	0.167	6.50	0.092	9.70	0.167	9.80	0.167	9.90	0.167	
6.70	0.095	10.50	0.105	10.50	0.105	8.00	0.154	5.60	0.092	9.70	0.167	6.60	0.092	9.80	0.167	9.90	0.167	10.00	0.167	
6.80	0.086	10.60	0.095	10.60	0.095	8.10	0.154	5.70	0.092	9.80	0.167	6.70	0.092	9.90	0.167	10.00	0.167	10.10	0.167	
6.90	0.077	10.70	0.086	10.70	0.086	8.20	0.154	5.80	0.092	9.90	0.167	6.80	0.092	10.00	0.167	10.10	0.167	10.20	0.167	
7.00	0.068	10.80	0.077	10.80	0.077	8.30	0.154	5.90	0.092	10.00	0.167	6.90	0.092	10.10	0.167	10.20	0.167	10.30	0.167	
7.10	0.059	10.90	0.068	10.90	0.068	8.40	0.154	6.00	0.092	10.10	0.167	7.00	0.092	10.20	0.167	10.30	0.167	10.40	0.167	
7.20	0.050	11.00	0.059	11.00	0.059	8.50	0.154	6.10	0.092	10.20	0.167	7.10	0.092	10.30	0.167	10.40	0.167	10.50	0.167	
7.30	0.041	11.10	0.050	11.10	0.050	8.60	0.154	6.20	0.092	10.30	0.167	7.20	0.092	10.40	0.167	10.50	0.167	10.60	0.167	
7.40	0.032	11.20	0.041	11.20	0.041	8.70	0.154	6.30	0.092	10.40	0.167	7.30	0.092	10.50	0.167	10.60	0.167	10.70	0.167	
7.50	0.023	11.30	0.032	11.30	0.032	8.80	0.154	6.40	0.092	10.50	0.167	7.40	0.092	10.60	0.167	10.70	0.167	10.80	0.167	
7.60	0.014	11.40	0.023	11.40	0.023	8.90	0.154	6.50	0.092	10.60	0.167	7.50	0.092	10.70	0.167	10.80	0.167	10.90	0.167	
7.70	0.005	11.50	0.014	11.50	0.014	9.00	0.154	6.60	0.092	10.70	0.167	7.60	0.092	10.80	0.167	10.90	0.167	11.00	0.167	
7.80	0.000	11.60	0.005	11.60	0.005	9.10	0.154	6.70	0.092	10.80	0.167	7.70	0.092	10.90	0.167	11.00	0.167	11.10	0.167	
7.90	0.000	11.70	0.000	11.70	0.000	9.20	0.154	6.80	0.092	10.90	0.167	7.80	0.092	11.00	0.167	11.10	0.167	11.20	0.167	
8.00	0.000	11.80	0.000	11.80	0.000	9.30	0.154	6.90	0.092	11.00	0.167	7.90	0.092	11.10	0.167	11.20	0.167	11.30	0.167	
8.10	0.000	11.90	0.000	11.90	0.000	9.40	0.154	7.00	0.092	11.10	0.167	8.00	0.092	11.20	0.167	11.30	0.167	11.40	0.167	
8.20	0.000	12.00	0.000	12.00	0.000	9.50	0.154	7.10	0.092	11.20	0.167	8.10	0.092	11.30	0.167	11.40	0.167	11.50	0.167	
8.30	0.000	12.10	0.000	12.10	0.000	9.60	0.154	7.20	0.092	11.30	0.167	8.20	0.092	11.40	0.167	11.50	0.167	11.60	0.167	
8.40	0.000	12.20	0.000	12.20	0.000	9.70	0.154	7.30	0.092	11.40	0.167	8.30	0.092	11.50	0.167	11.60	0.167	11.70	0.167	
8.50	0.000	12.30	0.000	12.30	0.000	9.80	0.154	7.40	0.092	11.50	0.167	8.40	0.092	11.60	0.167	11.70	0.167	11.80	0.167	
8.60	0.000	12.40	0.000	12.40	0.000	9.90	0.154	7.50	0.092	11.60	0.167	8.50	0.092	11.70	0.167	11.80	0.167	11.90	0.167	
8.70	0.000	12.50	0.000	12.50	0.000	10.00	0.154	7.60	0.092	11.70	0.167	8.60	0.092	11.80	0.167	11.90	0.167	12.00	0.167	

TABLE 2-7. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 5 (CONT.)
16.00	0.159	
16.18	0.175	
16.30	0.175	
16.38	0.190	
16.60	0.180	
16.99	0.175	
17.36	0.164	
17.22	0.161	
17.74	0.132	
12.24	0.113	
12.38	0.096	
12.59	0.084	
13.53	0.085	
13.39	0.055	
14.21	0.105	
14.43	0.110	
14.79	0.125	
14.87	0.136	
14.92	0.133	




FIGURE 8-6. EXPERIMENTAL REFRACTIVE INDEX OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).

TABLE 8-8. MEASUREMENT INFORMATION ON THE REFRACTIVE INDEX OF CALCIUM ALUMINUM SILICATE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 A00009		Kandrich, G.S.	1975	0.50-4.0	293	Glass 9753	Smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.

TABLE 8-9. EXPERIMENTAL REFRACTIVE INDEX OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFRACTIVE INDEX, n]

λ	n
CURVE 1 $T = 293^\circ\text{K}$	
0.500	1.6096
0.594	1.6046
0.697	1.6002
0.834	1.5965
1.001	1.5931
1.112	1.5914
1.202	1.5902
1.346	1.5883
1.492	1.5855
1.735	1.5837
2.000	1.5803
2.274	1.5767
2.469	1.5736
2.613	1.5717
2.707	1.5702
2.852	1.5679
2.967	1.5654
3.112	1.5630
3.260	1.5600
3.382	1.5576
3.495	1.5551
3.610	1.5525
3.723	1.5499
3.847	1.5467
4.000	1.5422

d. Normal Spectral Reflectance (Temperature Dependence)

Using values from curves 2, 3, and 4 of the previous section, provisional values have been generated for 2.8, 3.8, and 5.0 μm . These values listed in Table 8-10 and shown in Figure 8-7 are valid for a thickness of 3.175 mm. The uncertainty should not exceed 30%. Note that for the three lowest wavelengths, values are not given above 873 K and no values are given for 10.6 μm above room temperature.

TABLE 8-10. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE COPING 97531 (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

T	ρ	T	ρ	T	ρ
3.175MM THICK					
$\lambda = 2.80$					
473.	0.076	473.	0.081	473.	0.130
673.	0.078	673.	0.068	673.	0.105
873.	0.102	873.	0.073	873.	0.135




FIGURE 8-7. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

No original experimental data were located for the normal spectral absorptance of Corning 9753. However, by applying Kirchhoff's law, the provisional values of the normal spectral absorptance are generated which are equal to the provisional values of the normal spectral emittance. For a discussion of the uncertainties see the section on the normal spectral emittance (wavelength dependence) of calcium aluminum silicate. The provisional values of the normal spectral absorptance are listed in Table 8-11 and shown in Figure 8-8.

For the temperature dependence of the normal spectral absorptance, see the section on the normal spectral emittance (temperature dependence) of calcium aluminum silicate.

TABLE 8-11. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF CALCIUM ALUMINUM SILICATE (CORNING 4/53) (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

$T = 293$		$T = 293$ (CONT.)		$T = 293$ (CONT.)		$T = 293$ (CONT.)		$T = 473$		$T = 473$ (CONT.)	
2.00MM THICK		2.00MM THICK		2.00MM THICK		2.00MM THICK		2.00MM THICK		2.00MM THICK	
λ	α	λ	α	λ	α	λ	α	λ	α	λ	α
0.40	0.101	5.10	0.966	9.00	0.973	12.9	0.916	2.40	0.110	4.60	0.676
0.50	0.029	5.20	0.956	9.10	0.965	13.0	0.916	2.47	0.103	4.64	0.700
0.60	0.017	5.30	0.967	9.20	0.954	13.1	0.916	2.50	0.099	4.70	0.756
0.80	0.016	5.40	0.967	9.30	0.934	13.2	0.916	2.59	0.090	4.71	0.775
0.90	0.023	5.50	0.968	9.42	0.902	13.3	0.916	2.60	0.069	4.74	0.805
1.00	0.024	5.60	0.968	9.50	0.886	13.4	0.916	2.70	0.080	4.77	0.823
1.10	0.026	5.70	0.969	9.60	0.873	13.5	0.915	2.73	0.077	4.80	0.832
1.20	0.027	5.80	0.969	9.70	0.864	13.6	0.914	2.80	0.070	4.82	0.841
1.30	0.028	5.90	0.970	9.80	0.856	13.7	0.912	2.81	0.069	4.87	0.854
1.40	0.029	6.00	0.970	9.90	0.848	13.8	0.910	2.90	0.065	4.90	0.856
1.50	0.028	6.10	0.971	10.0	0.841	13.9	0.908	2.91	0.065	4.91	0.860
1.60	0.027	6.20	0.971	10.1	0.832	14.0	0.905	3.00	0.061	4.96	0.869
1.70	0.027	6.30	0.972	10.2	0.825	14.1	0.901	3.04	0.060	5.00	0.870
1.80	0.026	6.40	0.973	10.3	0.825	14.2	0.896	3.10	0.059	5.08	0.869
2.00	0.026	6.50	0.974	10.4	0.820	14.3	0.896	3.20	0.060	5.10	0.866
2.30	0.025	6.60	0.975	10.5	0.820	14.4	0.885	3.21	0.060	5.20	0.862
2.40	0.026	6.70	0.976	10.6	0.820	14.5	0.882	3.30	0.064	5.22	0.860
2.50	0.027	6.80	0.977	10.7	0.821	14.6	0.879	3.31	0.065	5.30	0.851
2.60	0.031	6.90	0.976	10.8	0.822	14.7	0.877	3.40	0.073	5.40	0.840
2.70	0.036	7.00	0.979	10.9	0.823	14.8	0.873	3.46	0.079	5.42	0.838
2.80	0.040	7.10	0.980	11.0	0.826	14.9	0.866	3.50	0.074	5.50	0.832
2.90	0.062	7.20	0.981	11.1	0.837	15.0	0.857	3.57	0.095	5.53	0.828
3.20	0.066	7.30	0.982	11.2	0.839	15.0	0.850	3.60	0.101	5.60	0.823
3.30	0.064	7.40	0.983	11.3	0.844	15.1	0.844	3.70	0.122	5.65	0.820
3.40	0.064	7.50	0.984	11.4	0.849	15.2	0.844	3.80	0.144	5.70	0.818
3.50	0.064	7.60	0.986	11.5	0.855	15.3	0.844	3.90	0.167	5.76	0.820
3.80	0.080	7.70	0.987	11.6	0.860	15.4	0.855	4.00	0.190	5.80	0.822
3.90	0.103	7.80	0.989	11.7	0.866	15.5	0.862	4.02	0.195	5.85	0.824
4.00	0.118	7.90	0.993	11.8	0.871	15.6	0.870	4.09	0.227	5.93	0.828
4.10	0.151	8.00	0.996	11.9	0.876	15.7	0.876	4.10	0.229	5.98	0.835
4.20	0.202	8.10	1.000	12.0	0.880	15.8	0.880	4.16	0.276	6.03	0.837
4.30	0.272	8.20	1.000	12.1	0.885	15.9	0.885	4.20	0.294	6.10	0.849
4.40	0.391	8.30	1.000	12.2	0.890	16.0	0.892	4.24	0.332	6.16	0.856
4.50	0.543	8.40	1.000	12.3	0.897	16.1	0.897	4.30	0.363	6.20	0.860
4.60	0.715	8.50	1.000	12.4	0.905	16.2	0.905	4.38	0.453	6.29	0.869
4.70	0.824	8.60	1.000	12.5	0.910	16.3	0.910	4.40	0.469	6.30	0.870
4.80	0.900	8.70	0.998	12.6	0.914	16.4	0.914	4.46	0.534	6.36	0.876
4.90	0.944	8.80	0.996	12.7	0.916	16.5	0.916	4.50	0.580	6.48	0.877
5.00	0.965	8.90	0.982	12.8	0.916	16.6	0.916	4.56	0.646	6.43	0.879

(WAVELENGTH, λ ; μm ; TEMPERATURE, T , K ; ABSORBTION, α)

λ	α	λ	α	λ	α	λ	α	λ	α	λ	α
3.175MM THICK											
$T = 473$ (CONT.)											
6.50	0.810	1.52	0.043	4.10	0.326	6.57	0.632				
6.53	0.873	1.60	0.041	4.20	0.402	6.60	0.832				
6.60	0.874	1.70	0.037	4.26	0.446	6.70	0.832				
6.64	0.871	1.80	0.034	4.30	0.480	6.80	0.832				
6.70	0.862	1.86	0.032	4.40	0.565	6.90	0.833				
6.76	0.852	1.90	0.031	4.46	0.635	7.00	0.833				
6.80	0.845	2.00	0.030	4.50	0.644	7.10	0.833				
6.86	0.833	2.10	0.028	4.60	0.702	7.20	0.833				
6.90	0.826	2.19	0.028	4.63	0.721	7.30	0.832				
6.97	0.818	2.20	0.028	4.70	0.763	7.40	0.831				
7.00	0.817	2.30	0.031	4.75	0.807	7.50	0.830				
7.09	0.816	2.34	0.032	4.80	0.819	7.60	0.832				
7.10	0.815	2.40	0.035	4.92	0.827	7.70	0.835				
7.18	0.822	2.50	0.040	4.97	0.846	7.80	0.837				
7.20	0.820	2.59	0.045	4.98	0.848	7.90	0.839				
7.30	0.828	2.60	0.046	4.99	0.860	8.00	0.842				
7.40	0.834	2.70	0.051	5.09	0.861						
7.42	0.835	2.76	0.053	5.09	0.869						
7.50	0.837	2.80	0.056	5.10	0.870						
7.59	0.835	2.90	0.066	5.23	0.876						
7.60	0.835	2.99	0.073	5.32	0.878						
7.68	0.831	3.00	0.074	5.36	0.878						
7.70	0.830	3.10	0.082	5.46	0.879						
7.80	0.826	3.20	0.090	5.50	0.880						
7.84	0.822	3.26	0.096	5.55	0.878						
7.90	0.819	3.30	0.099	5.60	0.876						
8.00	0.811	3.40	0.111	5.67	0.875						
		3.44	0.116	5.70	0.873						
		3.50	0.124	5.80	0.866						
		3.56	0.133	5.90	0.860						
		3.60	0.140	5.93	0.855						
		3.69	0.159	6.00	0.854						
		3.70	0.163	6.10	0.847						
		3.80	0.196	6.12	0.846						
		3.82	0.204	6.20	0.842						
		3.90	0.232	6.34	0.839						
		3.99	0.267	6.32	0.836						
		4.00	0.273	6.40	0.835						
		4.08	0.317	6.50	0.814						




FIGURE 8-8. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).

f. Normal Spectral Transmittance (Wavelength Dependence)

There are 17 sets of experimental data available for the wavelength dependence of the normal spectral transmittance of calcium aluminum silicate, 13 of which apply to Corning 9753. The data is listed in Table 8-14 and shown in Figures 8-9 and 8-10. Specimen characterization and measurement information for the data are given in Table 8-13.

There are three data sets which are for a specimen thickness of 2.00 mm at room temperature (curves 1, 4, and 5). These three curves were used to determine a provisional curve. The provisional values are listed in Table 8-12 and shown in Figure 8-9. For values of transmittance over 0.5, the uncertainty is within 5% but around a transmittance value of 0.1, the uncertainty can reach 20%. These uncertainties are determined taking into account the slightly different thicknesses and the slightly different temperatures of the specimens for the data sets that formed the basis of these provisional value sets.

In order to show the effect of temperature on the normal spectral transmittance of Corning 9753, another provisional curve is given and is applicable to a specimen 2.00 mm thick at a temperature of 1173K. The provisional values are listed in Table 8-12 and shown in Figure 8-9. The uncertainty is within 20% for this set of values.

It is noted that the provisional curve for 1173 K is above the provisional curve for 293 K in the region 1 to about 2.7 μm . However, the provisional curve for 1173 K is below the provisional curve for 293 K in the wavelength region of 3.3 to 4.9 μm .

For a specimen of 2.00 mm thick there is no normal spectral transmittance data above 1173 K and only one set available between 1173 K and room temperature. For specimen thicknesses of 3.175 and 12.7 mm, the highest temperature for which normal spectral transmittance data is available is 873 K.

TABLE 8-12. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (CORNING 9753) (WAVELLENGTH DEPENDENCE)

λ	τ	0.00MM THICK			2.00MM THICK			2.00MM THICK			2.00MM THICK			2.00MM THICK		
λ	τ	$T = 293$ (CONT.)			$T = 293$ (CONT.)			$T = 293$ (CONT.)			$T = 293$ (CONT.)			$T = 293$ (CONT.)		
0.319	0.000	2.30	0.880	4.75	0.101	1.00	0.887	3.69	0.739	3.70	0.736	3.79	0.797	3.80	0.704	3.80
0.324	0.123	2.40	0.880	4.79	0.069	1.19	0.891	3.70	0.736	3.79	0.797	3.80	0.704	3.80	0.681	3.80
0.331	0.063	2.50	0.879	4.80	0.063	1.11	0.891	3.70	0.736	3.79	0.797	3.80	0.704	3.80	0.681	3.80
0.337	0.108	2.60	0.876	4.83	0.047	1.20	0.892	3.70	0.736	3.79	0.797	3.80	0.704	3.80	0.681	3.80
0.341	0.141	2.70	0.871	4.87	0.026	1.39	0.892	3.70	0.736	3.79	0.797	3.80	0.704	3.80	0.681	3.80
0.345	0.204	2.80	0.860	4.90	2.623	1.40	0.892	3.70	0.736	3.79	0.797	3.80	0.704	3.80	0.660	3.80
0.353	0.352	2.86	0.850	4.92	0.014	1.50	0.892	3.70	0.736	3.79	0.797	3.80	0.704	3.80	0.640	3.80
0.359	0.463	2.90	0.847	4.95	0.004	1.63	0.891	4.00	0.610	4.02	0.602	4.02	0.602	4.02	0.555	4.02
0.364	0.538	2.98	0.843	5.00	0.000	1.62	0.891	4.00	0.610	4.02	0.602	4.02	0.602	4.02	0.555	4.02
0.371	0.626	3.06	0.842	5.00	0.000	1.70	0.890	4.10	0.555	4.10	0.555	4.10	0.555	4.10	0.506	4.10
0.377	0.674	3.16	0.843	5.00	0.000	1.80	0.890	4.17	0.506	4.17	0.506	4.17	0.506	4.17	0.486	4.17
0.387	0.734	3.20	0.844	5.00	0.000	1.90	0.889	4.20	0.486	4.20	0.486	4.20	0.486	4.20	0.440	4.20
0.394	0.771	3.30	0.847	5.00	0.000	2.00	0.889	4.26	0.440	4.26	0.440	4.26	0.440	4.26	0.404	4.26
0.400	0.795	3.40	0.848	5.00	0.000	2.10	0.887	4.30	0.404	4.30	0.404	4.30	0.404	4.30	0.314	4.30
0.42	0.824	3.50	0.848	5.00	0.000	2.20	0.886	4.40	0.314	4.40	0.314	4.40	0.314	4.40	0.300	4.40
0.45	0.843	3.56	0.848	5.00	0.000	2.30	0.885	4.41	0.300	4.41	0.300	4.41	0.300	4.41	0.212	4.41
0.46	0.862	3.61	0.845	5.00	0.000	2.36	0.885	4.50	0.212	4.50	0.212	4.50	0.212	4.50	0.140	4.50
0.50	0.868	3.69	0.840	5.00	0.000	2.43	0.885	4.57	0.140	4.57	0.140	4.57	0.140	4.57	0.110	4.57
0.53	0.874	3.74	0.836	5.00	0.000	2.50	0.885	4.60	0.110	4.60	0.110	4.60	0.110	4.60	0.103	4.60
0.54	0.876	3.80	0.830	5.00	0.000	2.56	0.885	4.61	0.103	4.61	0.103	4.61	0.103	4.61	0.074	4.61
0.56	0.878	3.86	0.822	5.00	0.000	2.63	0.884	4.64	0.074	4.64	0.074	4.64	0.074	4.64	0.049	4.64
0.60	0.881	3.90	0.816	5.00	0.000	2.73	0.880	4.70	0.049	4.70	0.049	4.70	0.049	4.70	0.000	4.70
0.64	0.883	3.96	0.806	5.00	0.000	2.71	0.879	4.79	0.021	4.79	0.021	4.79	0.021	4.79	0.017	4.79
0.67	0.884	4.00	0.798	5.00	0.000	2.80	0.870	4.80	0.017	4.80	0.017	4.80	0.017	4.80	0.000	4.80
0.73	0.885	4.04	0.788	5.00	0.000	2.86	0.857	4.87	0.000	4.87	0.000	4.87	0.000	4.87	0.000	4.87
0.80	0.884	4.10	0.770	5.00	0.000	2.90	0.853	4.90	0.000	4.90	0.000	4.90	0.000	4.90	0.000	4.90
0.90	0.880	4.16	0.744	5.00	0.000	2.97	0.847	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.00	0.877	4.20	0.723	5.00	0.000	3.00	0.846	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.04	0.876	4.25	0.690	5.00	0.000	3.04	0.847	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.10	0.875	4.30	0.653	5.00	0.000	3.10	0.851	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.20	0.874	4.36	0.590	5.00	0.000	3.19	0.849	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.30	0.874	4.40	0.544	5.00	0.000	3.20	0.848	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.40	0.874	4.47	0.460	5.00	0.000	3.26	0.843	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.50	0.874	4.50	0.410	5.00	0.000	3.30	0.838	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.60	0.875	4.53	0.358	5.00	0.000	3.34	0.831	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.70	0.876	4.63	0.245	5.00	0.000	3.40	0.818	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.80	0.877	4.65	0.193	5.00	0.000	3.45	0.801	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
1.90	0.878	4.69	0.148	5.00	0.000	3.50	0.791	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00
2.00	0.878	4.70	0.136	5.00	0.000	3.60	0.769	5.00	0.000	5.00	0.000	5.00	0.000	5.00	0.000	5.00




FIGURE 8-9. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).




FIGURE 8-10. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE).

TABLE 8-13. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 A00009	Kandrich, G.S.	1975	1.0-5.0	293	Corning 9753	Specimen 2.02 mm thick; spectral transmittance; smooth values from figure.
2 A00009	Kandrich, G.S.	1975	1.0-4.9	773	Corning 9753	Similar to the above specimen.
3 A00009	Kandrich, G.S.	1975	1.0-4.9	1173	Corning 9753	Similar to the above specimen.
4 A00009	Kandrich, G.S.	1975	0.22-0.70	293	CGW-Glass 9753	Specimen 2.02 mm thick; spectral transmittance; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
5 A00009	Kandrich, G.S.	1975	0.31-4.7	293	Corning 9753 glass	Specimen typically 2.00 mm thick; spectral transmittance; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
6 A00009	Kandrich, G.S.	1975	2.0-5.0	293	Corning 9753	Specimen 0.3175 cm (1/8 in.) thick; spectral transmittance; smooth values from figure; measurement temperature specified as ambient temperature, 293 K assigned.
7 A00009	Kandrich, G.S.	1975	2.0-4.9	473	Corning 9753	Specimen 0.3175 cm (1/8 in.) thick; spectral transmittance; smooth values from figure.
8 A00009	Kandrich, G.S.	1975	2.0-4.7	673	Corning 9753	Similar to the above specimen.
9 A00009	Kandrich, G.S.	1975	2.0-4.9	873	Corning 9753	Similar to the above specimen.
10 A00009	Kandrich, G.S.	1975	2.0-4.7	293	Corning 9753	Specimen 1.27 cm (0.5 in.) thick; spectral transmittance; smooth values from figure; temperature called ambient temperature, 293 K assigned.
11 A00009	Kandrich, G.S.	1975	2.0-4.7	473	Corning 9753	Specimen 1.27 cm (0.5 in.) thick; spectral transmittance; smooth values from figure.
12 A00009	Kandrich, G.S.	1975	2.0-4.7	673	Corning 9753	Similar to the above specimen.
13 A00009	Kandrich, G.S.	1975	2.0-4.5	873	Corning 9753	Similar to the above specimen.
14 T39835	Florence, J.M., Glaze, F.W., and Black, M.H.	1955	2.0-5.5	293	C-1458	52.0 CaO, 41.2 Al ₂ O ₃ , and 6.8 SiO ₂ ; specimen 2.18 mm thick; data from figure.
15 T39835	Florence, J.M., et al.	1955	2.0-5.3	293	C-1458	Similar to the above specimen except thickness 4.10 mm.
16 T39835	Florence, J.M., et al.	1955	2.0-5.4	293	C-1474	49.5 CaO, 43.7 Al ₂ O ₃ , and 6.8 SiO ₂ ; specimen 2.02 mm thick; data from figure.
17 T39835	Florence, J.M., et al.	1955	2.0-5.4	293	C-1474	Similar to the above specimen except thickness 4.16 mm.

TABLE 6-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 1 $T = 298.$		CURVE 2 $T = 773.$		CURVE 3 (CONT.)		CURVE 4 (CONT.)		CURVE 5 (CONT.)		CURVE 6 $T = 293.$		CURVE 7 (CONT.)	
		λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
1.05	0.873	1.00	0.862	2.00	0.870	0.400	0.795	4.42	0.500	2.59	0.650	3.00	0.844	3.31	0.651
1.23	0.875	1.39	0.856	2.88	0.857	0.409	0.517	4.55	0.317	2.83	0.651	3.31	0.844	3.31	0.651
1.48	0.872	1.53	0.868	2.97	0.847	0.417	0.533	4.64	0.198	2.91	0.862	3.31	0.844	3.31	0.862
1.66	0.872	2.00	0.866	3.04	0.847	0.429	0.548	4.74	0.090	3.01	0.854	3.31	0.844	3.31	0.854
2.00	0.880	2.24	0.865	3.19	0.849	0.443	0.558	4.81	0.000	3.12	0.843	3.31	0.844	3.31	0.843
2.29	0.889	2.53	0.870	3.24	0.843	0.461	0.566	4.86	0.874	3.23	0.844	3.31	0.844	3.31	0.844
2.61	0.876	2.65	0.870	3.45	0.861	0.510	0.863	4.91	0.000	3.41	0.844	3.31	0.844	3.31	0.844
2.74	0.871	2.74	0.864	3.60	0.766	0.532	0.862	5.00	0.861	3.54	0.814	3.31	0.814	3.31	0.814
2.86	0.861	2.97	0.834	3.69	0.739	0.700	0.882	5.12	0.854	4.01	0.725	3.31	0.725	3.31	0.725
3.00	0.845	3.25	0.834	3.79	0.707	0.763	0.851	5.23	0.854	4.05	0.711	3.31	0.711	3.31	0.711
3.19	0.845	3.23	0.844	3.65	0.681	0.83	0.853	5.31	0.853	4.10	0.698	3.31	0.698	3.31	0.698
3.30	0.849	3.33	0.844	3.94	0.643	0.81	0.845	5.41	0.845	4.15	0.679	3.31	0.679	3.31	0.679
3.52	0.849	3.45	0.836	4.02	0.602	0.78	0.836	5.52	0.836	4.20	0.652	3.31	0.652	3.31	0.652
3.67	0.842	3.56	0.822	4.17	0.506	0.31	0.416	5.63	0.431	4.23	0.629	3.31	0.629	3.31	0.629
3.60	0.831	3.71	0.796	4.26	0.440	0.38	0.740	5.59	0.401	4.26	0.598	3.31	0.598	3.31	0.598
3.92	0.815	3.96	0.741	4.41	0.309	0.40	0.799	5.83	0.770	4.35	0.496	3.31	0.496	3.31	0.496
4.00	0.803	4.02	0.724	4.57	0.140	0.42	0.824	4.01	0.746	4.44	0.399	3.31	0.399	3.31	0.399
4.07	0.769	4.36	0.706	4.61	0.103	0.45	0.843	4.07	0.733	4.53	0.299	3.31	0.299	3.31	0.299
4.12	0.772	4.12	0.676	4.64	0.074	0.48	0.856	4.15	0.702	4.64	0.173	3.31	0.173	3.31	0.173
4.16	0.753	4.22	0.693	4.70	0.049	0.53	0.669	4.27	0.636	4.67	0.142	3.31	0.142	3.31	0.142
4.20	0.731	4.31	0.542	4.79	0.021	0.59	0.879	4.37	0.564	4.72	0.102	3.31	0.102	3.31	0.102
4.24	0.708	4.38	0.472	4.87	0.000	0.68	0.896	4.39	0.498	4.78	0.051	3.31	0.051	3.31	0.051
4.29	0.674	4.49	0.339	4.91	0.81	0.886	0.444	4.44	0.444	4.84	0.026	3.31	0.026	3.31	0.026
4.37	0.593	4.60	0.214	4.95	1.00	0.875	4.49	0.389	4.90	0.000	CURVE 4 $T = 293.$				
4.46	0.485	4.65	0.155	4.95	1.35	0.875	4.59	0.301	CURVE 5 $T = 293.$						
4.57	0.324	4.70	0.112	4.76	2.69	0.882	4.70	0.172	CURVE 6 $T = 293.$						
4.52	0.245	4.76	0.076	4.81	2.91	0.829	4.74	0.115	CURVE 7 $T = 293.$						
4.65	0.193	4.81	0.037	4.89	3.31	0.847	4.76	0.096	CURVE 8 $T = 293.$						
4.69	0.148	4.89	0.000	4.89	3.54	0.847	4.79	0.079	CURVE 7 $T = 473.$						
4.75	0.101	4.95	0.023	4.95	3.37	0.108	3.64	0.054	CURVE 8 $T = 473.$						
4.79	0.069	4.97	0.047	4.97	3.41	0.141	3.72	0.035	CURVE 7 $T = 1173.$						
4.83	0.047	4.97	0.028	4.97	3.53	0.204	3.83	0.000	CURVE 8 $T = 1173.$						
4.87	0.028	4.97	0.000	4.97	3.53	0.352	3.90	0.012	CURVE 7 $T = 1173.$						
4.92	0.014	4.97	0.027	4.97	3.59	0.460	3.97	0.097	CURVE 8 $T = 1173.$						
5.00	0.000	4.97	0.000	4.97	3.64	0.538	4.03	0.035	CURVE 7 $T = 1173.$						
5.00	0.000	4.97	0.000	4.97	3.64	0.626	4.10	0.000	CURVE 8 $T = 1173.$						
5.06	0.000	4.97	0.000	4.97	3.72	0.631	4.17	0.000	CURVE 7 $T = 1173.$						
5.11	0.000	4.97	0.000	4.97	3.72	0.734	4.21	0.000	CURVE 8 $T = 1173.$						
5.12	0.000	4.97	0.000	4.97	3.72	0.837	4.21	0.000	CURVE 7 $T = 1173.$						
5.14	0.000	4.97	0.000	4.97	3.72	0.934	4.21	0.000	CURVE 8 $T = 1173.$						

TABLE 3-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 8-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (WAVELENGTH DEPENDENCE) (CONTINUED)

[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ]

λ	τ	λ	τ	λ	τ	λ	τ
CURVE 15 (CONT.)							
4.54	0.552	4.25	0.794	3.82	0.698		
4.61	0.510	4.33	0.780	3.91	0.719		
4.68	0.464	4.40	0.763	4.02	0.736		
4.75	0.437	4.48	0.746	4.10	0.736		
4.83	0.410	4.54	0.738	4.16	0.739		
4.89	0.362	4.62	0.719	4.26	0.709		
4.95	0.311	4.67	0.689	4.33	0.687		
4.99	0.266	4.74	0.660	4.40	0.643		
5.05	0.160	4.82	0.636	4.47	0.610		
5.15	0.084	4.89	0.576	4.55	0.619		
5.30	0.024	4.96	0.518	4.61	0.552		
CURVE 16 (CONT.)							
$= 293.$							
2.06	0.917	5.00	0.470	4.63	0.509		
2.11	0.917	5.06	0.351	4.74	0.469		
2.26	0.917	5.16	0.253	4.83	0.426		
2.37	0.914	5.30	0.139	4.99	0.359		
2.46	0.909	5.39	0.109	4.96	0.301		
2.46	0.909	5.39	0.109	4.99	0.247		
2.63	0.909	5.39	0.109	5.05	0.137		
2.70	0.904	5.09	0.109	5.17	0.076		
2.86	0.554	2.11	0.917	5.28	0.026		
2.89	0.449	2.26	0.917	5.40	0.036		
2.99	0.435	2.37	0.914				
3.10	0.424	2.60	0.909				
3.19	0.543	2.70	0.904				
3.25	0.626	2.80	0.441				
3.33	0.649	2.88	0.239				
3.41	0.679	2.95	0.231				
3.46	0.706	3.07	0.271				
3.54	0.719	3.16	0.318				
3.61	0.746	3.25	0.410				
3.68	0.763	3.33	0.458				
3.75	0.774	3.41	0.513				
3.81	0.777	3.48	0.561				
3.90	0.792	3.55	0.589				
4.00	0.797	3.61	0.627				
4.10	0.797	3.68	0.658				
4.19	0.797	3.75	0.679				

CURVE 17
 $T = 293.$

g. Normal Spectral Transmittance (Temperature Dependence)

There are 10 sets of experimental data available for the temperature dependence of the normal spectral transmittance of calcium aluminum silicate all of which apply to Corning 9753. The data is listed in Table 8-17 and shown in Figures 8-11 and 8-12. Specimen characterization and measurement information for the data are given in Table 8-16.

The 10 data sets are all for a thickness of 2 mm and cover a wavelength range of 3.5 to 4.7 μm . The temperature range covered is from slightly over 300 K to about 1175 K which is above the strain point (1073 K) but below the melting range (1723 to 1773 K).

A provisional curve is given for Corning 9753 at a wavelength of 3.8 μm . The provisional values are listed in Table 8-15 and shown in Figure 8-11. The provisional values were obtained by using linear interpolation between the 3.75 μm data (curve number 2 in Tables 8-16 and 8-17) and the 4.0 μm data (curve number 3 in Tables 8-16 and 8-17). Values of transmittance were read for the same values of temperatures and then linear interpolation performed. The uncertainty of the provisional values are no larger than 15%.

TABLE A-15. PROVISIONAL NORMAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (COFNING 9753) (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

T	τ
2MM THICK	
$\lambda = 3.6$	
310.	0.821
323.	0.819
373.	0.815
400.	0.814
473.	0.811
500.	0.808
573.	0.802
600.	0.798
673.	0.792
700.	0.788
773.	0.779
806.	0.774
873.	0.761
900.	0.756
973.	0.744
1000.	0.739
1073.	0.727
1100.	0.720
1173.	0.701




FIGURE 8-11. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE).




FIGURE 8-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE).

TABLE 8-16. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (Temperature Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K.	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A00009	Kandrich, G.S.	1975	3.5	307-1174	Code 9753	Specimen 2 mm thick; smooth values from figure; additional information supplied by Corning Glass Works.
2 A00009	Kandrich, G.S.	1975	3.75	310-1174	Code 9753	Similar to the above specimen.
3 A00009	Kandrich, G.S.	1975	4.0	306-1174	Code 9753	Similar to the above specimen.
4 A00009	Kandrich, G.S.	1975	4.1	307-1173	Code 9753	Similar to the above specimen.
5 A00009	Kandrich, G.S.	1975	4.2	311-1171	Code 9753	Similar to the above specimen.
6 A00009	Kandrich, G.S.	1975	4.3	309-1171	Code 9753	Similar to the above specimen.
7 A00009	Kandrich, G.S.	1975	4.4	303-1171	Code 9753	Similar to the above specimen.
8 A00009	Kandrich, G.S.	1975	4.5	304-1169	Code 9753	Similar to the above specimen.
9 A00009	Kandrich, G.S.	1975	4.6	303-1169	Code 9753	Similar to the above specimen.
10 A00009	Kandrich, G.S.	1975	4.7	303-1169	Code 9753	Similar to the above specimen.

TABLE 3-17. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF CALCIUM ALUMINUM SILICATE (TEMPERATURE DEPENDENCE)

T	T	T	T	CURVE 1 $\lambda = 3.5$	CURVE 2 $\lambda = 3.75$	CURVE 3 (CONT.)	CURVE 4 $\lambda = 4.0$	CURVE 5 $\lambda = 4.2$	CURVE 6 $\lambda = 4.3$	CURVE 7 $\lambda = 4.4$	CURVE 8 (CONT.)	CURVE 9 $\lambda = 4.6$	CURVE 10 (CONT.)	T	T	T	T	CURVE 10 $\lambda = 4.7$	
307.	9.838	846.	0.716	399.	0.660	398.	0.416	74.8.	0.119	433.	0.411	873.	0.104	303.	3.163	303.	3.163	303.	
447.	0.639	913.	0.696	383.	0.652	495.	0.399	95.9.	0.091	495.	0.399	95.9.	0.091	352.	0.157	352.	0.157	352.	
542.	0.838	972.	0.683	466.	0.637	562.	0.385	1072.	0.074	562.	0.385	1072.	0.074	470.	0.151	470.	0.151	470.	
637.	0.833	1026.	0.666	475.	0.637	621.	0.372	1169.	0.066	621.	0.372	1169.	0.066	527.	0.148	527.	0.148	527.	
696.	0.831	1075.	0.653	517.	0.627	621.	0.372	1169.	0.066	621.	0.372	1169.	0.066	586.	0.142	586.	0.142	586.	
769.	0.827	1174.	0.618	531.	0.608	695.	0.354	1169.	0.066	695.	0.354	1169.	0.066	670.	0.137	670.	0.137	670.	
879.	0.816	CURVE 4 $\lambda = 4.1$	1174.	0.618	0.74.	0.582	768.	0.333	1169.	0.066	768.	0.333	1169.	0.066	649.	0.132	649.	0.132	649.
591.	0.811	1190.	0.607	337.	0.778	957.	0.492	1009.	0.267	957.	0.492	1009.	0.267	1056.	0.254	1056.	0.254	1056.	
1112.	0.806	1112.	0.606	386.	0.766	1017.	0.472	1056.	0.254	1017.	0.472	1056.	0.254	1095.	0.242	1095.	0.242	1095.	
1174.	0.800	1174.	0.600	477.	0.755	1074.	0.457	1095.	0.242	1074.	0.457	1095.	0.242	1169.	0.215	1169.	0.215	1169.	
CURVE 2 $\lambda = 3.75$	525.	525.	0.746	1131.	0.447	1169.	0.417	1169.	0.215	1131.	0.447	1169.	0.215	1169.	0.215	1169.	0.215	1169.	
310.	0.826	623.	0.729	1171.	0.417	CURVE 9 $\lambda = 4.6$	0.304	1169.	0.215	1171.	0.417	CURVE 9 $\lambda = 4.6$	0.304	1169.	0.215	1169.	0.215	1169.	
430.	0.821	667.	0.733.	1171.	0.417	CURVE 7 $\lambda = 4.4$	0.282	1169.	0.215	1171.	0.417	CURVE 7 $\lambda = 4.4$	0.282	1169.	0.215	1169.	0.215	1169.	
479.	0.819	794.	0.693	0.671	0.642	303.	0.574	303.	0.282	303.	0.574	303.	0.282	407.	0.272	407.	0.272	407.	
264.	0.812	876.	0.676	0.671	0.642	408.	0.558	446.	0.269	408.	0.558	446.	0.269	533.	0.262	533.	0.262	533.	
677.	0.804	970.	0.608	1076.	0.608	505.	0.546	534.	0.254	505.	0.546	534.	0.254	534.	0.254	534.	0.254	534.	
719.	0.798	1173.	0.573	1173.	0.573	565.	0.538	565.	0.245	565.	0.538	565.	0.245	609.	0.245	609.	0.245	609.	
775.	0.791	0.791	0.573	578.	0.774	CURVE 5 $\lambda = 4.2$	0.245	561.	0.521	561.	0.521	561.	0.521	671.	0.234	671.	0.234	671.	
969.	0.762	969.	0.573	11132.	0.742.	674.	0.488	725.	0.222	674.	0.488	725.	0.222	731.	0.222	731.	0.222	731.	
1076.	0.745	1076.	0.573	11116.	0.741	311.	0.746	788.	0.453	788.	0.453	788.	0.453	872.	0.193	872.	0.193	872.	
11132.	0.734	11132.	0.573	11174.	0.723	412.	0.723	847.	0.435	847.	0.435	962.	0.435	962.	0.175	962.	0.175	962.	
11174.	0.723	11174.	0.573	477.	0.710	910.	0.412	1071.	0.151	910.	0.412	1071.	0.151	1169.	0.130	1169.	0.130	1169.	
CURVE 3 $\lambda = 4.0$	676.	676.	0.664	1073.	0.355	1073.	0.355	1169.	0.215	1169.	0.355	1169.	0.215	1169.	0.215	1169.	0.215	1169.	
366.	0.830	615.	0.625	1145.	0.327	1171.	0.317	1169.	0.215	1171.	0.327	1169.	0.215	1169.	0.215	1169.	0.215	1169.	
378.	0.793	902.	0.580	1171.	0.317	CURVE 8 $\lambda = 4.5$	0.157	1169.	0.215	1171.	0.317	CURVE 8 $\lambda = 4.5$	0.157	1169.	0.215	1169.	0.215	1169.	
439.	0.737	1017.	0.562	1072.	0.399	1072.	0.399	1169.	0.215	1072.	0.399	1169.	0.215	1169.	0.215	1169.	0.215	1169.	
553.	0.779	1079.	0.543	1128.	0.523	1128.	0.523	1171.	0.505	1128.	0.523	1171.	0.505	1171.	0.422	1171.	0.422	1171.	
675.	0.752	1128.	0.523	1171.	0.505	304.	0.425	304.	0.152	304.	0.425	304.	0.152	304.	0.152	304.	0.152	304.	
745.	0.744	1171.	0.505	352.	0.422	352.	0.422	352.	0.152	352.	0.422	352.	0.152	352.	0.152	352.	0.152	352.	
792.	0.731	1171.	0.505	352.	0.422	352.	0.422	352.	0.152	352.	0.422	352.	0.152	352.	0.152	352.	0.152	352.	

4.9. Magnesium Fluoride

Since data evaluation was asked to be carried out on the specific kind of magnesium fluoride known as Irtran 1, the treatment in this section will concentrate on that material.

Irtran 1, produced by the Eastman Kodak Company, is a hot-pressed, polycrystalline solid of magnesium fluoride, MgF_2 . The word "Irtran" is a trademark of the Eastman Kodak Company. Because it is polycrystalline it does not exhibit cleavage. The visual appearance of Irtran 1 is transparent in colors ranging from tan to green [E62600]. According to Kodak [E62600], the long-range infrared cut-off frequency is approximately $7.5 \mu\text{m}$ for a 2 mm thick specimen for which the transmittance is 10%. It has a Knoop hardness of 576 and is approximately as hard as soft steel. The density is 3.18 g cm^{-3} at 298 K. Other physical properties include a modulus of rupture of 21,800 psi at 298 K, and an expansion coefficient of $11.0 \times 10^{-6} \text{ C}^{-1}$ between 298 and 473 K. It is insoluble in water and there is no change in transmittance or weight upon both inorganic and organic chemical immersion. It has a melting point of 1528 K [T39947] and a high thermal shock resistance. It is used as windows, domes, prisms, and filter substrates for infrared systems.

a. Normal Spectral Emittance (Wavelength Dependence)

A total of 20 sets of experimental data were located for the wavelength dependence of the normal spectral emittance of Irtran 1. The data are listed in Table 9-3 and shown in Figures 9-1 and 9-2. Specimen characterization and measurement information for the data are given in Table 9-2.

Numerical values of the data are low at $4.5 \mu\text{m}$, being less than 0.16 and above $5.5 \mu\text{m}$ they increase sharply such that above $10 \mu\text{m}$ all the data are above 0.75. There is a conflicting element in the data. Stierwalt, et al. [T33450] presented data for a 2 mm thick specimen at 333 K (curve 17), 393 K (curve 18), and 453 K (curve 19). Above $10 \mu\text{m}$ the values of the normal spectral emittance for these curves are between 0.75 and 0.90. Hatch [T76525] presented an argument that the emittance for specimen thicknesses of 1 mm or greater should be greater than 0.99 from 293 to 970 K and between 10 and $15 \mu\text{m}$. The argument of Hatch and the data of Stierwalt, et al. are incompatible. As a consequence it was decided to consider evaluated data only within a restricted wavelength range of 3 to $6.4 \mu\text{m}$.

Provisional values for a 2 mm thick specimen at a temperature of 293 K for a wavelength region of 3 to $6.4 \mu\text{m}$ are listed in Table 9-1 and shown in Figure 9-1. These values were generated by using the Kodak scheme, Eqs. (2.6-13) and (2.6-15), for

calculating emittance from transmittance and refractive index data. The transmittance data used was data from curve 22 in Tables 9-17 and 9-18. The refractive index data used was taken from the data of curve 2 in Tables 9-4 and 9-5. The refractive index data is shown in Figure 9-3. Provisional values for a specimen thickness of 3.8 mm at a temperature of 589 K for a wavelength range of 3 to 6.4 μm are given, as well as a set of provisional values for a thickness of 3.8 mm, a temperature of 970 K, and a wavelength range of 3 to 6.0 μm . The provisional values for 589 K are based on curve 8 while those for 970 K are based on curve 11. The values are listed in Table 9-1 and shown in Figure 9-1. Because of the low value of emittance, the uncertainty for all three provisional curves can be as high as 25%.

TABLE 9-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE(IRRAN 1) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	λ	ϵ
2MM THICK		3.0MM THICK		3.0MM THICK	
$T = 293$		$T = 589$		$T = 973$	
3.00	0.089	3.0	0.154	3.0	0.177
3.03	0.085	3.11	0.124	3.07	0.155
3.10	0.079	3.24	0.102	3.31	0.109
3.19	0.074	3.42	0.076	3.56	0.053
3.27	0.069	3.60	0.053	3.90	0.071
3.36	0.065	4.0	0.048	4.0	0.070
3.49	0.060	4.14	0.045	4.42	0.066
3.80	0.060	4.64	0.045	4.61	0.076
3.98	0.059	4.97	0.052	4.98	0.081
4.00	0.060	5.0	0.054	5.0	0.084
4.46	0.060	5.09	0.061	5.23	0.111
4.68	0.060	5.25	0.078	5.47	0.094
4.78	0.057	5.46	0.062	5.65	0.111
4.88	0.052	5.60	0.051	5.84	0.154
4.95	0.056	5.79	0.077	6.00	0.167
5.00	0.057	6.0	0.107		
5.04	0.056	6.01	0.108		
5.13	0.050	6.20	0.145		
5.23	0.046	6.35	0.165		
5.32	0.044	6.4	0.197		
5.59	0.045				
5.69	0.050				
5.79	0.054				
5.87	0.060				
6.00	0.071				
6.16	0.087				
6.34	0.109				
6.40	0.116				




FIGURE 9-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).




FIGURE 9-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE
(WAVELENGTH DEPENDENCE).

TABLE 9-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMISSANCE OF MAGNESIUM FLUORIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T39952	Stierwalt, D.L.	1966	3.5-45	77	Irtran 1	Sample 2.0 mm thick; material from Eastman Kodak Co.; smooth values from figure; $\theta' = 0^\circ$.
2 T17017	Ballard, N.E., McCarthy, K.A., and Wolfe, W.L.	1961	1.5-10	673	Irtran 1	Specimen thickness 1.75 mm; emissivity; information in this reference was obtained from Eastman Kodak Co. sales literature dated 15 June 1959 and 23 February 1961; $\theta' = 0^\circ$.
3 T17017	Ballard, S.S., et al.	1961	1.5-10	873	Irtran 1	Similar to the above specimen.
4 T17017	Ballard, S.S., et al.	1961	1.5-9.1	1073	Irtran 1	Similar to the above specimen.
5 T76525	Hatch, S.E.	1962	2.0-10	647	Irtran 1	Specimen 1 mm thick; specimen holder uncoated stainless steel; smooth values from figure.
6 T76525	Hatch, S.E.	1962	2.0-10	865	Irtran 1	The above specimen.
7 T76525	Hatch, S.E.	1962	1.5-10	647	Irtran 1	The above specimen except specimen holder gold plated.
8 T76525	Hatch, S.E.	1962	2.2-8.5	589	Irtran 1	Specimen 3.8 mm thick; specimen holder uncoated stainless steel; smooth values from figure.
9 T76525	Hatch, S.E.	1962	2.2-8.5	647	Irtran 1	The above specimen.
10 T76525	Hatch, S.E.	1962	2.2-8.5	865	Irtran 1	The above specimen.
11 T76525	Hatch, S.E.	1962	2.2-8.0	970	Irtran 1	The above specimen.
12 T76525	Hatch, S.E.	1962	1.5-8.0	647	Irtran 1	The above specimen except specimen holder gold plated.
13 T76525	Hatch, S.E.	1962	1.5-8.2	594	Irtran 1	Specimen 7.6 mm thick; specimen holder uncoated stainless steel; smooth values from figure.
14 T76525	Hatch, S.E.	1962	1.5-8.0	647	Irtran 1	The above specimen.
15 T76525	Hatch, S.E.	1962	1.5-7.7	865	Irtran 1	The above specimen.
16 T76525	Hatch, S.E.	1962	1.5-8.0	970	Irtran 1	The above specimen.
17 T33450	Stierwalt, D.L., Kirk, D.D., and Bernstein, J.B.	1963	3.0-11	333	Irtran 1	Specimen 2 mm thick; smooth values from figure.
18 T33450	Stierwalt, D.L., et al.	1963	3.0-15	393	Irtran 1	Similar to the above specimen.
19 T33450	Stierwalt, D.L., et al.	1963	3.0-15	453	Irtran 1	Similar to the above specimen.
20 T76525	Hatch, S.E.	1962	10-15	293	Irtran 1	Thickness 1 mm or greater; argument given on p. 597 of this reference that emissance between 10 and 15 μ is greater than 0.99 from ambient temperature, 293 K assigned, to 970 K; $\theta' = 0^\circ$.

TABLE 9-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)

λ	ϵ	CURVE 1 $T = 77.$	CURVE 2 $T = 673.$	CURVE 3 (CONT.)	CURVE 4 (CONT.)	CURVE 5 (CONT.)	CURVE 6 (CONT.)
3.49	0.065	1.45	0.071	2.18	0.088	2.81	0.083
5.52	0.062	1.66	0.079	2.61	0.091	2.96	0.064
5.86	0.076	1.83	0.086	3.01	0.091	3.11	0.043
6.71	0.190	2.01	0.092	4.02	0.067	3.34	0.032
7.05	0.179	2.28	0.096	4.64	0.059	3.80	0.033
7.43	0.245	2.84	0.098	5.38	0.050	4.80	0.033
7.87	0.528	3.16	0.093	5.57	0.052	5.01	0.042
9.27	0.957	3.45	0.085	5.74	0.052	5.19	0.059
9.68	0.985	3.86	0.077	5.97	0.050	5.35	0.042
13.1	1.50	4.27	0.065	6.13	0.100	6.42	0.033
14.3	1.00	4.63	0.057	6.27	0.127	6.21	0.042
15.1	0.943	5.27	0.057	6.38	0.152	6.49	0.059
15.6	0.962	5.56	0.059	6.44	0.172	6.81	0.114
16.0	0.421	5.69	0.074	6.56	0.186	6.90	0.214
16.4	0.267	5.9	0.093	6.75	0.198	7.02	0.254
16.8	0.114	6.12	0.126	7.11	0.304	7.09	0.336
20.5	0.089	6.23	0.145	7.61	0.455	7.16	0.417
21.2	0.101	6.36	0.172	7.98	0.559	7.28	0.524
21.7	0.152	6.44	0.201	8.25	0.628	7.49	0.467
22.2	0.233	6.65	0.236	8.39	0.664	7.60	0.597
22.7	0.565	6.97	0.302	8.49	0.691	7.65	0.650
23.1	0.690	7.26	0.392	8.64	0.716	7.76	0.701
23.6	0.713	7.59	0.465	8.80	0.736	7.99	0.761
24.4	0.572	7.63	0.552	8.98	0.753	8.16	0.804
25.2	0.588	8.14	0.633	9.29	0.763	8.33	0.827
26.0	0.716	8.40	0.703	9.52	0.775	8.67	0.831
26.6	0.730	8.56	0.730	10.00	0.776	8.77	0.851
27.6	0.838	8.78	0.753	8.60	0.863	8.86	0.957
29.6	0.917	9.62	0.773	9.07	0.863	9.79	0.957
32.1	0.979	9.40	0.783	9.60	0.873	10.03	0.973
33.0	0.987	9.60	0.794	10.00	0.794	10.34	1.000
33.8	0.971	10.00	0.794	1.45	0.079	CURVE 5 $T = 647.$	CURVE 6 $T = 865.$
35.3	0.797	1.69	0.087	1.58	0.098	1.47	0.100
36.0	0.667	1.58	0.098	2.28	0.102	1.65	0.079
39.4	0.536	1.45	0.102	2.90	0.102	1.88	0.059
39.6	0.252	1.45	0.102	2.15	0.114	2.10	0.048
41.6	0.568	1.45	0.102	2.30	0.063	2.38	0.048
42.7	0.627	1.66	0.074	2.44	0.063	2.51	0.063
44.5	0.645	1.91	0.079	2.63	0.063	2.68	0.063

TABLE 9-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	CURVE 7 (CONT.)	λ	ϵ	CURVE 7 (CONT.)	λ	ϵ	CURVE 8 (CONT.)	λ	ϵ	CURVE 9 (CONT.)	λ	ϵ	CURVE 10 (CONT.)	λ	ϵ	CURVE 11 (CONT.)	λ	ϵ	CURVE 12
2.85	0.062	10.00	6.977	7.76	0.987	8.03	0.945	7.37	0.831	7.14	0.870									
3.04	0.042	10.24	6.986	7.89	0.909	8.23	0.965	7.49	0.878	7.28	0.908									
3.36	0.024	10.49	0.986	8.04	0.933	8.46	0.977	7.64	0.909	7.44	0.948									
3.63	0.016					8.22	0.955			7.74	0.932	7.73	0.977							
3.80	0.013					8.46	0.969			7.90	0.952	8.00	0.993							
4.10	0.005									8.13	0.977									
4.60	0.005									8.46	0.988									
4.86	0.013																			
5.26	0.028																			
5.43	0.018																			
5.12	0.018																			
5.55	0.015																			
5.70	0.015																			
5.99	0.022																			
6.07	0.038																			
6.23	0.062																			
6.39	0.103																			
6.48	0.133																			
6.59	0.156																			
6.74	0.174																			
6.88	0.174																			
7.33	0.168																			
7.18	0.169																			
7.29	0.181																			
7.39	0.199																			
7.47	0.236																			
7.59	0.299																			
7.76	0.397																			
7.91	0.478																			
8.07	0.550																			
8.29	0.602																			
8.33	0.661																			
8.52	0.724																			
8.55	0.765																			
8.82	0.805																			
9.04	0.855																			
9.19	0.890																			
9.42	0.926																			
9.58	0.946																			
9.78	0.965																			

T = 647.

T = 865.

T = 970.

T =

TABLE 9-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	CURVE 12 (CONT.)		CURVE 13 (CONT.)		CURVE 14 (CONT.)		CURVE 15 (T = 865.)		CURVE 15 (CONT.)		CURVE 16 (CONT.)	
6.18	0.152	4.42	0.134	4.42	0.111	2.12	0.322	1.49	0.600	7.16	0.947	5.94	0.381
6.26	0.189	4.53	0.153	4.53	0.149	2.29	0.338	2.08	0.314	7.31	0.965	6.97	0.452
6.42	0.223	4.67	0.167	4.67	0.160	2.43	0.362	1.55	0.541	7.47	0.978	6.18	0.509
6.52	0.276	4.77	0.177	4.77	0.170	2.55	0.402	1.63	0.488	7.68	0.987	6.29	0.524
6.66	0.332	4.93	0.184	4.93	0.184	2.71	0.491	1.77	0.425	7.68	0.987	6.37	0.706
6.88	0.432	5.33	0.121	5.33	0.121	2.79	0.466	1.91	0.393	6.49	0.830	5.94	0.381
7.03	0.514	5.11	0.137	5.11	0.137	2.94	0.314	2.08	0.373	6.58	0.852	6.07	0.452
7.18	0.605	5.18	0.163	5.18	0.163	3.14	0.223	2.22	0.373	6.67	0.887	5.67	0.509
7.32	0.713	5.35	0.134	5.35	0.134	3.34	0.176	2.39	0.394	6.62	0.927	6.80	0.425
7.46	0.807	5.45	0.119	5.45	0.119	3.53	0.129	2.57	0.434	6.58	0.955	6.93	0.555
7.55	0.346	5.53	0.119	5.53	0.119	3.60	0.106	2.70	0.525	6.62	0.526	7.16	0.971
7.66	0.887	5.73	0.128	5.73	0.128	4.00	0.100	2.79	0.447	7.72	0.474	7.35	0.965
7.82	0.918	5.81	0.147	5.81	0.147	4.22	0.107	2.95	0.352	7.84	0.431	7.59	1.000
8.00	0.944	5.93	0.177	5.93	0.177	4.41	0.133	3.11	0.274	7.98	0.407	8.00	0.939
6.33		6.33	0.223	6.33	0.223	4.69	0.113	3.29	0.207	7.07	0.393	6.33	0.691
6.17		6.17	0.272	6.17	0.272	4.84	0.113	3.48	0.155	2.18	0.393	3.25	0.674
6.30		6.30	0.333	6.30	0.333	5.00	0.137	3.72	0.122	2.33	0.412	3.54	0.661
6.43		6.43	0.385	6.43	0.385	5.17	0.184	3.80	0.111	2.46	0.435	3.80	0.652
6.49		6.49	0.443	6.49	0.443	5.45	0.150	4.03	0.112	2.56	0.477	4.01	0.654
6.60		6.60	0.511	6.60	0.511	5.56	0.150	4.22	0.121	2.71	0.565	3.25	0.674
6.70		6.70	0.603	6.70	0.603	5.68	0.170	4.40	0.148	2.78	0.490	3.80	0.661
6.79		6.79	0.720	6.79	0.720	5.86	0.197	4.61	0.133	2.91	0.404	3.80	0.652
6.84		6.84	0.771	6.84	0.771	5.95	0.250	4.77	0.133	3.36	0.318	4.01	0.654
6.91		6.91	0.613	6.91	0.613	6.09	0.312	4.91	0.147	3.22	0.257	4.61	0.646
7.04		7.04	0.653	7.04	0.653	6.22	0.379	5.03	0.179	3.39	0.290	4.82	0.650
7.16		7.16	0.896	7.16	0.896	6.38	0.475	5.19	0.204	3.64	0.151	5.07	0.650
7.28		7.28	0.930	7.28	0.930	6.50	0.556	5.41	0.193	3.39	0.130	5.32	0.643
7.47		7.47	0.954	7.47	0.954	6.61	0.658	5.56	0.193	3.94	0.123	5.58	0.643
7.62		7.62	0.965	7.62	0.965	6.69	0.724	5.70	0.223	4.09	0.123	5.78	0.654
7.86		7.86	0.980	7.86	0.980	6.77	0.794	5.81	0.255	4.24	0.137	5.94	0.665
8.15		8.15	0.987	8.15	0.987	6.85	0.845	5.97	0.315	4.41	0.154	6.07	0.665
8.33		8.33	0.253	8.33	0.253	6.97	0.886	6.12	0.395	4.53	0.147	6.23	0.125
8.51		8.51	0.155	8.51	0.155	7.11	0.917	6.26	0.482	4.77	0.157	6.36	0.141
8.72		8.72	0.128	8.72	0.128	6.34	0.560	5.36	0.560	4.97	0.178	6.53	0.175
8.93		8.93	0.103	8.93	0.103	7.42	0.961	6.49	0.674	5.69	0.202	5.54	0.180
9.13		9.13	0.58	9.13	0.58	7.67	0.977	6.60	0.753	5.16	0.225	6.65	0.136
9.32		9.32	0.368	9.32	0.368	7.81	0.978	6.65	0.695	5.42	0.219	6.81	0.176
9.52		9.52	0.394	9.52	0.394	8.02	0.986	6.73	0.847	5.54	0.233	6.97	0.176
9.72		9.72	0.322	9.72	0.322	7.25	0.943	6.34	0.560	4.97	0.178	6.53	0.215

TABLE 9-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 17 (CONT.)				CURVE 18 (CONT.)				CURVE 19 (CONT.)				CURVE 20 (CONT.)			
λ	ϵ	λ	ϵ												
7.34	0.242	6.94	0.174	5.07	0.050	12.	>0.99	5.32	0.043	13.	>0.99	5.28	0.043	14.	>0.99
7.42	0.265	7.12	0.191	5.32	0.043	13.	>0.99	5.28	0.043	14.	>0.99	5.73	0.054	15.	>0.99
7.50	0.294	7.22	0.215	5.73	0.054	15.	>0.99	5.73	0.054	15.	>0.99	5.265	0.064	15.	>0.99
7.53	0.349	7.34	0.242	5.99	0.064	15.	>0.99	6.11	0.080	16.	>0.99	6.34	0.109	17.	>0.99
7.56	0.349	7.42	0.265	6.11	0.080	16.	>0.99	6.34	0.109	17.	>0.99	6.51	0.146	18.	>0.99
7.66	0.433	7.42	0.265	6.66	0.168	18.	>0.99	6.66	0.168	19.	>0.99	6.93	0.191	20.	>0.99
7.75	0.513	7.50	0.294	7.50	0.191	20.	>0.99	7.12	0.215	21.	>0.99	7.22	0.242	22.	>0.99
7.82	0.566	7.52	0.316	7.52	0.215	21.	>0.99	7.30	0.242	22.	>0.99	7.34	0.265	23.	>0.99
7.93	0.596	7.66	0.362	7.66	0.242	22.	>0.99	7.67	0.265	23.	>0.99	7.75	0.294	24.	>0.99
8.12	0.649	7.75	0.466	7.75	0.294	23.	>0.99	7.93	0.316	24.	>0.99	8.07	0.466	25.	>0.99
8.29	0.674	7.82	0.525	7.82	0.316	24.	>0.99	8.22	0.466	25.	>0.99	8.32	0.525	26.	>0.99
5.51	0.717	7.97	0.537	7.97	0.362	25.	>0.99	8.57	0.525	26.	>0.99	8.73	0.610	27.	>0.99
6.77	0.764	8.15	0.630	8.15	0.466	26.	>0.99	9.07	0.610	27.	>0.99	9.32	0.755	28.	>0.99
8.96	0.783	8.41	0.673	8.41	0.525	27.	>0.99	9.57	0.755	28.	>0.99	9.82	0.835	29.	>0.99
9.29	0.629	8.78	0.725	8.78	0.610	28.	>0.99	10.07	0.835	29.	>0.99	10.37	0.914	30.	>0.99
5.50	0.613	8.99	0.760	8.99	0.610	29.	>0.99	10.57	0.914	30.	>0.99	10.87	0.993	31.	>0.99
9.94	0.835	9.32	0.783	9.32	0.610	30.	>0.99	11.07	0.993	31.	>0.99	11.37	0.993	32.	>0.99
16.66	0.834	9.57	0.800	9.57	0.610	31.	>0.99	11.57	0.993	32.	>0.99	11.87	0.993	33.	>0.99
18.81	0.834	9.92	0.817	9.92	0.610	32.	>0.99	12.07	0.817	33.	>0.99	12.37	0.835	34.	>0.99
11.39	0.838	10.27	0.816	10.27	0.610	33.	>0.99	12.57	0.835	34.	>0.99	12.87	0.854	35.	>0.99
5.50	0.613	10.60	0.619	10.60	0.610	34.	>0.99	13.07	0.854	35.	>0.99	13.37	0.873	36.	>0.99
9.94	0.835	10.95	0.618	10.95	0.610	35.	>0.99	13.57	0.873	36.	>0.99	13.87	0.892	37.	>0.99
16.66	0.834	11.38	0.827	11.38	0.610	36.	>0.99	14.07	0.892	37.	>0.99	14.37	0.911	38.	>0.99
18.81	0.834	11.92	0.847	11.92	0.610	37.	>0.99	14.57	0.911	38.	>0.99	14.87	0.930	39.	>0.99
11.39	0.838	12.48	0.872	12.48	0.610	38.	>0.99	15.07	0.930	39.	>0.99	15.37	0.949	40.	>0.99
5.50	0.613	12.84	0.886	12.84	0.610	39.	>0.99	15.57	0.949	40.	>0.99	15.87	0.968	41.	>0.99
9.94	0.835	13.33	0.694	13.33	0.610	40.	>0.99	16.07	0.892	41.	>0.99	16.37	0.911	42.	>0.99
16.66	0.834	13.72	0.897	13.72	0.610	41.	>0.99	17.07	0.892	42.	>0.99	17.37	0.911	43.	>0.99
18.81	0.834	14.17	0.682	14.17	0.610	42.	>0.99	17.57	0.892	43.	>0.99	17.87	0.911	44.	>0.99
11.39	0.838	14.62	0.862	14.62	0.610	43.	>0.99	18.07	0.862	44.	>0.99	18.37	0.881	45.	>0.99
5.50	0.613	15.00	0.691	15.00	0.610	44.	>0.99	18.57	0.881	45.	>0.99	18.87	0.900	46.	>0.99
9.94	0.835	15.47	0.774	15.47	0.610	45.	>0.99	19.07	0.774	46.	>0.99	19.37	0.838	47.	>0.99
16.66	0.834	15.87	0.774	15.87	0.610	46.	>0.99	19.57	0.774	47.	>0.99	19.87	0.849	48.	>0.99
18.81	0.834	16.27	0.774	16.27	0.610	47.	>0.99	20.07	0.774	48.	>0.99	20.37	0.849	49.	>0.99
11.39	0.838	16.67	0.774	16.67	0.610	48.	>0.99	20.57	0.774	49.	>0.99	20.87	0.817	50.	>0.99
5.50	0.613	17.07	0.774	17.07	0.610	49.	>0.99	21.07	0.774	50.	>0.99	21.37	0.788	51.	>0.99
9.94	0.835	17.47	0.774	17.47	0.610	50.	>0.99	21.57	0.774	51.	>0.99	21.87	0.788	52.	>0.99
16.66	0.834	17.87	0.774	17.87	0.610	51.	>0.99	22.07	0.774	52.	>0.99	22.37	0.788	53.	>0.99
18.81	0.834	18.27	0.774	18.27	0.610	52.	>0.99	22.57	0.774	53.	>0.99	22.87	0.788	54.	>0.99
11.39	0.838	18.67	0.774	18.67	0.610	53.	>0.99	23.07	0.774	54.	>0.99	23.37	0.788	55.	>0.99
5.50	0.613	19.07	0.774	19.07	0.610	54.	>0.99	23.57	0.774	55.	>0.99	23.87	0.788	56.	>0.99
9.94	0.835	19.47	0.774	19.47	0.610	55.	>0.99	24.07	0.774	56.	>0.99	24.37	0.788	57.	>0.99
16.66	0.834	19.87	0.774	19.87	0.610	56.	>0.99	24.57	0.774	57.	>0.99	24.87	0.788	58.	>0.99
18.81	0.834	20.27	0.774	20.27	0.610	57.	>0.99	25.07	0.774	58.	>0.99	25.37	0.788	59.	>0.99
11.39	0.838	20.67	0.774	20.67	0.610	58.	>0.99	25.57	0.774	59.	>0.99	25.87	0.788	60.	>0.99
5.50	0.613	21.07	0.774	21.07	0.610	59.	>0.99	26.07	0.774	60.	>0.99	26.37	0.788	61.	>0.99
9.94	0.835	21.47	0.774	21.47	0.610	60.	>0.99	26.57	0.774	61.	>0.99	26.87	0.788	62.	>0.99
16.66	0.834	21.87	0.774	21.87	0.610	61.	>0.99	27.07	0.774	62.	>0.99	27.37	0.788	63.	>0.99
18.81	0.834	22.27	0.774	22.27	0.610	62.	>0.99	27.57	0.774	63.	>0.99	27.87	0.788	64.	>0.99
11.39	0.838	22.67	0.774	22.67	0.610	63.	>0.99	28.07	0.774	64.	>0.99	28.37	0.788	65.	>0.99
5.50	0.613	23.07	0.774	23.07	0.610	64.	>0.99	28.57	0.774	65.	>0.99	28.87	0.788	66.	>0.99
9.94	0.835	23.47	0.774	23.47	0.610	65.	>0.99	29.07	0.774	66.	>0.99	29.37	0.788	67.	>0.99
16.66	0.834	23.87	0.774	23.87	0.610	66.	>0.99	29.57	0.774	67.	>0.99	29.87	0.788	68.	>0.99
18.81	0.834	24.27	0.774	24.27	0.610	67.	>0.99	30.07	0.774	68.	>0.99	30.37	0.788	69.	>0.99
11.39	0.838	24.67	0.774	24.67	0.610	68.	>0.99	30.57	0.774	69.	>0.99	30.87	0.788	70.	>0.99
5.50	0.613	25.07	0.774	25.07	0.610	69.	>0.99	31.07	0.774	70.	>0.99	31.37	0.788	71.	>0.99
9.94	0.835	25.47	0.774	25.47	0.610	70.	>0.99	31.57	0.774	71.	>0.99	31.87	0.788	72.	>0.99
16.66	0.834	25.87	0.774	25.87	0.610	71.	>0.99	32.07	0.774	72.	>0.99	32.37	0.788	73.	>0.99
18.81	0.834	26.27	0.774	26.27	0.610	72.	>0.99	32.57	0.774	73.	>0.99	32.87	0.788	74.	>0.99
11.39	0.838	26.67	0.774	26.67	0.610	73.	>0.99	33.07	0.774	74.	>0.99	33.37	0.788	75.	>0.99
5.50	0.613	27.07	0.774	27.07	0.610	74.	>0.99	33.57	0.774	75.	>0.99	33.87	0.788	76.	>0.99
9.94	0.835	27.47	0.774	27.47	0.610	75.	>0.99	34.07	0.774	76.	>0.99	34.37	0.788	77.	>0.99
16.66	0.834	27.87	0.774	27.87	0.610	76.	>0.99	34.57	0.774	77.	>0.99	34.87	0.788	78.	>0.99
18.81	0.834	28.27	0.774	28.27	0.610	77.	>0.99	35.07	0.774	78.	>0.99	35.37	0.788	79.	>0.99
11.39	0.838	28.67	0.774	28.67	0.610	78.	>0.99	35.57	0.774	79.	>0.99	35.87	0.788	80.	>0.99
5.50	0.613	29.07	0.774	29.07	0.610	79.	>0.99	36.07	0.774	80.	>0.99	36.37	0.788	81.	>0.99
9.94	0.835	29.47	0.774	29.47	0.610	80.	>0.99	36.57	0.774	81.	>0.99	36.87	0.788	82.	>0.99
16.66	0.834	29.87	0.774	29.87	0.610	81.	>0.99	37.07	0.774	82.	>0.99	37.37	0.788	83.	>0.99
18.81	0.834	30.27	0.774	30.27	0.610	82.	>0.99	37.57	0.774	83.	>0.99	37.87	0.788	84.	>0.99
11.39	0.838	30.67	0.774	30.67	0.610	83.	>0.99	38.07	0.774	84.	>0.99	38.37	0.788	85.	>0.99
5.50	0.613	31.07	0.774	31.07	0.610	84.	>0.99	38.57	0.774	85.	>0.99	38.87	0.788	86.	>0.99
9.94	0.835	31.47	0.774	31.47	0.610	85.	>0.99	39.07	0.774	86.	>0.99	39.37	0.788	87.	>0.99
16.66	0.834	31.87	0.774	31.87	0.610	86.	>0.99	39.57	0.774	87.	>0.99	39.87	0.788	88.	>0.99
18.81	0.834	32.27	0.774	32.27	0.610	87.	>0.99	40.07	0.774	88.	>0.99	40.37	0.788		




FIGURE 9-3. EXPERIMENTAL REFRACTIVE INDEX OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).

TABLE 9-4. MEASUREMENT INFORMATION ON THE REFRACTIVE INDEX OF MAGNESIUM FLUORIDE (Wavelength Dependence)

Car. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T17017	Ballard, S. S., McCarty, K.A., and Wolfe, W.L.	1965	1.0-6.3	293	Irtran 1	Information in this reference was obtained from Eastman Kodak Co. sales literature dated 15 June 1959 and 23 February 1961; measurement temperature not explicitly given, assumed to be 293 K.
2 E62600	Eastman Kodak Co.	1971	1.0-9.0	293	Irtran 1	Measurements taken, constants in Herzberger dispersion equation determined by least squares method; numerical values quoted here calculated from Herzberger dispersion equation: $n = n_0 + bL + cL^2 + dL^3 + eL^4$, where $L = 1.0 / \lambda^2 - 0.025$. $n_0 = 1.3776955$, $b = 1.3513539 \times 10^{-4}$, $c = 2.1254304 \times 10^{-6}$, $d = -1.5031172 \times 10^{-8}$, $e = -4.4109708 \times 10^{-10}$, and λ is in micrometers, range of validity $1-\infty \mu$; measurement temperature not explicitly given, assumed to be 293 K.

TABLE 9-5. EXPERIMENTAL REFRACTIVE INDEX OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFRACTIVE INDEX, n)

	λ	n	λ	n	CURVE 2 (CONT.)
CURVE 1					
$T = 293^\circ$					
1.0146	1.3776	7.2500	1.2865		
1.5295	1.3747	7.5000	1.2792		
2.4526	1.3708	7.7500	1.2715		
2.4374	1.3688	8.0000	1.2634		
3.3033	1.3639	8.2500	1.2549		
3.4138	1.3594	8.5000	1.2463		
4.253	1.3439	8.7500	1.2367		
4.866	1.3462	9.0000	1.2269		
5.136	1.3346				
6.238	1.3122				
CURVE 2					
$T = 293^\circ$					
1.0000	1.3778				
1.2500	1.3763				
1.5000	1.3749				
1.7500	1.3735				
2.0000	1.3720				
2.2500	1.3702				
2.5000	1.3683				
2.7500	1.3563				
3.0000	1.3546				
3.2500	1.3514				
3.5000	1.3507				
3.7500	1.3536				
4.0000	1.3526				
4.2500	1.3492				
4.5000	1.3453				
4.7500	1.3416				
5.0000	1.3374				
5.2500	1.3329				
5.5000	1.3282				
5.7500	1.3232				
6.0000	1.3179				
6.2500	1.3122				
6.5000	1.3063				
6.7500	1.3000				
7.0000	1.2934				

b. Normal Spectral Emittance (Temperature Dependence)

No experimental data was found for the temperature dependence of the normal spectral emittance of Irtran 1. However, using curves 8, 9, 10, and 11 of Tables 9-2 and 9-3, a set of provisional values for a specimen thickness of 3.8 mm and a wavelength of 3.8 μm were generated. The provisional values are listed in Table 9-6 and shown in Figure 9-4. The uncertainty is assigned a value of not more than 25%.

TABLE 9-6. PROVISIONAL NCPCM SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (IRTRAN 1) (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

T	ϵ
3.0MM THICK	
$\lambda = 3.00$	
569.	0.053
647.	0.053
865.	0.059
970.	0.071




FIGURE 9-4. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF MAGNESIUM FLUORIDE (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

Only one set of experimental data was located for the wavelength dependence of the normal spectral reflectance of magnesium fluoride. The data is listed in Table 9-9 and shown in Figures 9-5 and 9-6. Specimen characterization and measurement information for the data are given in Table 9-8.

Calculations were carried out using the Kodak scheme, Eqs. (2.6-13) and (2.6-14), to determine the reflectance at 293 K over a range of thickness from 0.5 mm to 12 mm (curves 2-7). In addition, Hatch[T76525] presented an argument concerning the reflectance from 10 to 15 μm with the conclusion the reflectance is less than 1% (curve 8).

Values for a provisional curve at 293 K for a 2 mm thick specimen are listed in Table 9-7 and shown in Figure 9-5. These values cover a wavelength range of 3 to 6.4 μm to agree with the wavelength range for the provisional curve at 293 K for the wavelength dependence of the normal spectral emittance. The uncertainty is thought to be no more than 25%.

TABLE 9-7. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (IRTFAN 1) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : REFLECTANCE, ρ)

λ	ρ
2MM THICK	
T = 293	
3.00	0.342
3.03	0.043
3.10	0.043
3.19	0.043
3.27	0.043
3.36	0.043
3.49	0.043
3.60	0.042
3.76	0.041
4.00	0.041
4.46	0.040
4.53	0.040
4.76	0.039
4.88	0.039
4.95	0.139
5.00	0.039
5.01	0.039
5.13	0.036
5.23	0.236
5.32	0.039
5.59	0.037
5.69	0.036
5.79	0.036
5.87	0.035
6.00	0.034
6.16	0.033
6.34	0.032
6.40	0.031




FIGURE 9-5. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).




FIGURE 9-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).

TABLE 9-S. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (Wavelength Dependence)

Car. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T4771	Schaefer, J.C. and Hill, E.R.	1965	2.5-35	293	Magnesium Fluoride	Thick crystal; measurement temperature not given explicitly, assumed to be 293 K; $\theta \approx 0^\circ, \theta' \approx 0^\circ$.
2 E6260		1971	0.5-9.2	293	Irtran 1	Specimen thickness 0.5 mm; temperature not explicitly given, presumed to be room temperature, 293 K assigned; calculated from transmittance and refractive index; see pp. 16-18 and p. 52, [E62600].
3 E6260		1971	0.5-6.5	293	Irtran 1	Similar to the above specimen except 1 mm thick.
4 E6260		1971	0.5-8.0	293	Irtran 1	Similar to the above specimen except 2 mm thick.
5 E6260		1971	0.5-7.9	293	Irtran 1	Similar to the above specimen except 3 mm thick.
6 E6260		1971	0.65-7.7	293	Irtran 1	Similar to the above specimen except 6 mm thick.
7 E6260		1971	0.54-7.6	293	Irtran 1	Similar to the above specimen except 12 mm thick.
8 T7652	Hatch, S.E.	1962	10-15	293	Irtran 1	Thicknesses of 1 mm or greater; applicable temperature is ambient, 293 K assigned; measurements performed on a Perkin-Elmer Model 221 spectrometer with reflection attachment; reflectance less than 1 percent from 10 to 15 μm argument presented on p. 597 of this reference that reflectance not expected to change significantly within the range of 10-15 μ up to 970 K.

TABLE 9-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 293^\circ\text{K}$	λ	ρ	CURVE 1 (CONT.)	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 3 $T = 293^\circ\text{K}$	λ	ρ	CURVE 3 (CONT.)	
2.50	0.022	14.83	0.032	30.58	0.021	3.49	0.944	6.50	0.032	6.98	0.029	7.10	0.023	7.20	0.027
3.029	0.022	15.17	0.057	31.45	0.000	3.86	0.443	0.50	0.030	0.76	0.035	0.92	0.028	1.10	0.025
3.346	0.017	15.41	0.081	32.05	0.023	3.85	0.043	0.76	0.035	0.92	0.037	1.00	0.027	1.15	0.027
3.354	0.022	15.65	0.121	32.57	0.492	4.35	0.442	0.82	0.040	0.89	0.039	1.28	0.026	1.35	0.026
4.895	0.021	15.85	0.202	32.89	0.576	4.69	0.041	0.92	0.039	1.00	0.040	1.35	0.025	1.43	0.025
4.890	0.012	15.95	0.363	33.33	0.592	4.93	0.049	0.92	0.040	1.00	0.040	1.43	0.025	1.50	0.025
5.258	0.022	16.16	0.386	33.56	0.652	4.99	0.040	1.13	0.041	1.19	0.042	1.47	0.024	1.53	0.023
5.141	0.022	16.31	0.455	34.84	0.657	5.18	0.339	1.13	0.041	1.19	0.042	1.53	0.023	1.58	0.023
5.160	0.017	16.41	0.489	35.34	0.703	5.70	0.037	1.19	0.042	1.53	0.042	1.53	0.023	1.58	0.023
5.173	0.022	17.02	0.569	35.34	0.903	6.03	0.036	1.32	0.043	1.56	0.022	1.56	0.022	1.56	0.022
5.266	0.022	18.15	0.637	35.34	0.903	6.25	0.035	1.42	0.044	1.53	0.023	1.53	0.023	1.53	0.023
5.294	0.019	18.62	0.663	36.50	0.933	6.50	0.033	1.50	0.044	1.70	0.019	1.70	0.019	1.70	0.019
5.312	0.022	18.62	0.672	36.68	0.932	6.68	0.032	1.63	0.044	1.74	0.017	1.74	0.017	1.74	0.017
5.577	0.022	18.93	0.679	36.87	0.931	6.87	0.031	1.73	0.045	1.78	0.017	1.78	0.017	1.78	0.017
5.619	0.016	18.93	0.692	36.90	0.935	7.06	0.039	1.14	0.045	1.81	0.016	1.81	0.016	1.81	0.016
5.624	0.022	19.19	0.655	36.99	0.939	7.21	0.029	2.31	0.045	1.84	0.015	1.84	0.015	1.84	0.015
5.679	0.022	19.65	0.709	37.77	0.641	7.34	0.023	2.42	0.045	1.87	0.015	1.87	0.015	1.87	0.015
5.807	0.018	20.24	0.715	38.83	0.642	7.41	0.027	2.55	0.045	1.93	0.015	1.93	0.015	1.93	0.015
5.913	0.013	20.70	0.715	38.89	0.643	7.50	0.026	2.62	0.045	1.96	0.014	1.96	0.014	1.96	0.014
5.973	0.007	20.73	0.694	39.94	0.643	7.54	0.026	2.67	0.044	2.03	0.014	2.03	0.014	2.03	0.014
6.353	0.011	21.37	0.606	41.64	0.644	7.63	0.025	2.71	0.043	2.11	0.014	2.11	0.014	2.11	0.014
6.416	0.009	21.83	0.553	41.88	0.645	7.70	0.024	2.73	0.043	2.14	0.014	2.14	0.014	2.14	0.014
6.523	0.010	22.62	0.310	42.60	0.645	7.83	0.019	2.77	0.043	2.17	0.013	2.17	0.013	2.17	0.013
6.579	0.007	23.72	0.159	43.35	0.646	7.86	0.017	2.79	0.043	2.26	0.012	2.26	0.012	2.26	0.012
6.598	0.007	23.64	0.301	43.45	0.646	7.89	0.016	2.86	0.044	2.35	0.013	2.35	0.013	2.35	0.013
6.492	0.000	23.81	0.363	43.59	0.646	7.95	0.016	2.92	0.044	2.51	0.012	2.51	0.012	2.51	0.012
16.01	0.000	24.33	0.286	43.59	0.646	8.01	0.015	3.05	0.044	3.05	0.044	3.05	0.044	3.05	0.044
13.94	0.000	24.45	0.258	43.61	0.646	8.06	0.015	3.49	0.043	3.49	0.043	3.49	0.043	3.49	0.043
12.25	0.203	24.61	0.251	43.64	0.646	8.12	0.014	3.80	0.043	3.80	0.043	3.80	0.043	3.80	0.043
11.61	0.000	25.19	0.200	43.63	0.645	8.25	0.014	3.99	0.042	3.99	0.042	3.99	0.042	3.99	0.042
12.82	0.000	25.77	0.157	43.65	0.645	2.65	0.045	4.49	0.044	4.49	0.044	4.49	0.044	4.49	0.044
12.17	0.000	26.53	0.146	43.71	0.644	2.71	0.044	4.77	0.044	4.77	0.044	4.77	0.044	4.77	0.044
13.19	0.000	26.88	0.120	43.72	0.641	2.72	0.041	5.07	0.043	5.07	0.043	5.07	0.043	5.07	0.043
13.61	0.000	27.93	0.105	43.72	0.644	2.72	0.044	5.27	0.043	5.27	0.043	5.27	0.043	5.27	0.043
13.76	0.000	28.27	0.076	43.75	0.644	2.75	0.044	5.58	0.043	5.58	0.043	5.58	0.043	5.58	0.043
13.85	0.000	29.41	0.061	43.76	0.645	2.81	0.045	5.93	0.043	5.93	0.043	5.93	0.043	5.93	0.043
14.31	0.006	29.41	0.048	43.76	0.645	2.88	0.045	6.09	0.041	6.09	0.041	6.09	0.041	6.09	0.041
14.84	0.019	30.39	0.040	43.76	0.645	3.00	0.045	9.17	0.040	9.17	0.040	9.17	0.040	9.17	0.040

CURVE 3
T = 293°^a

CURVE 3
T = 293°^b

TABLE 9-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 5 (CONT.)	λ	ρ	CURVE 5 (CONT.)	λ	ρ	CURVE 6 (CONT.)	λ	ρ	CURVE 6 (CONT.)	
0.56	0.337	5.32	0.538	0.030	5.65	0.036	1.51	0.034	5.28	0.036	5.43	0.035	5.61	0.035	5.79	0.035	5.88	0.033
1.08	0.338	5.59	0.637	0.031	5.73	0.036	1.58	0.035	5.43	0.036	5.61	0.036	5.79	0.035	5.94	0.035	6.10	0.035
1.14	0.339	5.69	0.036	0.034	5.87	0.035	1.66	0.036	5.61	0.036	5.79	0.037	5.94	0.037	6.14	0.037	6.30	0.033
1.22	0.340	5.79	0.036	0.034	6.00	0.034	1.74	0.037	5.79	0.037	5.94	0.037	6.14	0.037	6.30	0.037	6.47	0.033
1.29	0.340	5.87	0.635	0.035	6.15	0.033	1.84	0.037	5.88	0.037	6.03	0.037	6.27	0.037	6.42	0.037	6.59	0.033
1.34	0.341	6.00	0.634	0.036	6.27	0.032	1.94	0.038	5.99	0.038	6.14	0.038	6.30	0.038	6.47	0.038	6.64	0.032
1.40	0.341	6.16	0.633	0.039	6.45	0.030	2.02	0.039	6.10	0.039	6.26	0.039	6.41	0.039	6.58	0.039	6.75	0.035
1.50	0.342	6.34	0.632	0.040	6.61	0.028	2.14	0.039	6.21	0.029	6.36	0.039	6.53	0.039	6.70	0.039	6.87	0.035
1.59	0.342	6.50	0.030	0.041	6.68	0.026	2.29	0.040	6.67	0.026	6.83	0.026	7.00	0.026	7.17	0.026	7.34	0.024
1.68	0.343	6.67	0.629	0.041	7.01	0.024	2.36	0.041	7.02	0.022	7.18	0.022	7.35	0.022	7.52	0.022	7.69	0.022
1.75	0.343	6.82	0.628	0.042	7.06	0.024	2.42	0.041	7.19	0.023	7.35	0.024	7.52	0.023	7.69	0.023	7.86	0.023
1.88	0.343	6.99	0.026	0.042	7.16	0.023	2.51	0.041	7.19	0.019	7.35	0.023	7.52	0.023	7.69	0.023	7.86	0.019
2.00	0.344	7.10	0.025	0.043	7.23	0.022	2.56	0.041	7.26	0.019	7.43	0.022	7.60	0.022	7.77	0.019	7.94	0.019
2.14	0.344	7.18	0.624	0.043	7.28	0.021	2.63	0.040	7.32	0.018	7.49	0.021	7.66	0.021	7.83	0.018	8.00	0.018
2.30	0.344	7.25	0.624	0.043	7.36	0.021	2.68	0.040	7.39	0.017	7.55	0.021	7.72	0.021	7.89	0.017	8.06	0.017
2.43	0.344	7.29	0.623	0.043	7.45	0.020	2.74	0.039	7.46	0.016	7.63	0.020	7.79	0.020	8.00	0.016	8.17	0.016
2.60	0.344	7.35	0.622	0.043	7.63	0.019	2.70	0.035	7.52	0.016	7.70	0.019	7.86	0.019	8.03	0.016	8.20	0.016
2.71	0.343	7.39	0.622	0.043	7.71	0.019	2.74	0.036	7.62	0.015	7.81	0.018	7.98	0.018	8.15	0.015	8.32	0.015
2.73	0.343	7.43	0.621	0.043	7.72	0.017	2.77	0.037	7.68	0.015	7.88	0.017	8.05	0.015	8.22	0.015	8.39	0.015
2.73	0.343	7.43	0.621	0.043	7.73	0.017	2.81	0.038	7.74	0.015	7.94	0.017	8.11	0.015	8.28	0.015	8.45	0.015
2.76	0.344	7.48	0.621	0.043	7.73	0.017	2.86	0.038	7.74	0.015	7.94	0.017	8.11	0.015	8.28	0.015	8.45	0.015
2.80	0.342	7.52	0.620	0.043	7.73	0.019	2.73	0.039	7.73	0.015	7.93	0.019	8.10	0.015	8.27	0.015	8.44	0.015
2.68	0.342	7.58	0.619	0.041	7.76	0.019	2.76	0.039	7.76	0.015	7.96	0.019	8.13	0.015	8.30	0.015	8.47	0.015
2.95	0.342	7.63	0.017	0.041	7.82	0.017	2.87	0.041	7.77	0.015	7.97	0.017	8.14	0.015	8.31	0.015	8.48	0.015
3.33	0.343	7.70	0.016	0.042	7.92	0.017	2.87	0.042	7.87	0.014	8.07	0.017	8.24	0.014	8.41	0.014	8.58	0.014
3.10	0.343	7.74	0.015	0.042	7.99	0.017	2.99	0.042	7.90	0.014	8.10	0.017	8.27	0.017	8.44	0.017	8.61	0.017
3.19	0.343	7.76	0.615	0.043	8.08	0.018	3.02	0.042	8.00	0.017	8.17	0.018	8.34	0.017	8.51	0.017	8.68	0.017
3.27	0.343	7.81	0.015	0.042	8.15	0.018	3.02	0.042	8.15	0.015	8.32	0.018	8.49	0.018	8.66	0.018	8.83	0.018
3.36	0.343	7.85	0.014	0.042	8.32	0.018	3.04	0.042	8.32	0.015	8.49	0.018	8.66	0.018	8.83	0.018	9.00	0.018
3.49	0.343	7.89	0.014	0.042	8.49	0.018	3.04	0.042	8.49	0.015	8.66	0.018	8.83	0.018	9.00	0.018	9.17	0.018
3.80	0.342	7.92	0.014	0.042	8.70	0.018	3.07	0.042	8.65	0.017	8.82	0.027	9.00	0.017	9.17	0.017	9.34	0.017
3.98	0.341	8.02	0.014	0.041	8.80	0.018	3.08	0.042	8.71	0.017	8.88	0.027	9.05	0.017	9.22	0.017	9.40	0.017
4.46	0.340	8.43	0.014	0.040	9.43	0.018	3.04	0.040	9.43	0.017	9.60	0.027	9.77	0.017	9.94	0.017	10.11	0.017
4.63	0.340	8.49	0.014	0.040	9.49	0.018	3.04	0.040	9.49	0.017	9.66	0.027	9.83	0.017	9.99	0.017	10.16	0.017
4.78	0.339	8.52	0.014	0.040	9.52	0.018	3.04	0.040	9.52	0.017	9.69	0.027	9.86	0.017	10.03	0.017	10.20	0.017
4.86	0.339	8.56	0.014	0.041	9.60	0.018	3.04	0.041	9.60	0.017	9.77	0.027	9.94	0.017	10.11	0.017	10.28	0.017
4.95	0.339	8.62	0.014	0.041	9.62	0.018	3.04	0.041	9.62	0.017	9.79	0.027	9.96	0.017	10.13	0.017	10.35	0.017
5.01	0.339	8.69	0.014	0.041	9.69	0.018	3.04	0.041	9.69	0.017	9.86	0.027	10.03	0.017	10.20	0.017	10.37	0.017
5.13	0.339	8.74	0.014	0.042	9.74	0.018	3.04	0.042	9.74	0.017	9.91	0.027	10.08	0.017	10.25	0.017	10.44	0.017
5.23	0.338	8.76	0.014	0.042	9.76	0.018	3.04	0.042	9.76	0.017	9.92	0.027	10.15	0.017	10.32	0.017	10.51	0.017
5.38	0.338	8.82	0.014	0.042	9.82	0.018	3.04	0.042	9.82	0.017	10.08	0.027	10.25	0.017	10.42	0.017	10.59	0.017
5.50	0.328	9.05	0.014	0.042	9.85	0.018	3.04	0.042	9.85	0.017	10.22	0.027	10.39	0.017	10.56	0.017	10.73	0.017
5.59	0.627	9.14	0.014	0.038	9.89	0.018	3.04	0.040	9.89	0.017	10.38	0.027	10.55	0.017	10.72	0.017	10.89	0.017
5.70	0.627	9.22	0.014	0.038	9.92	0.018	3.04	0.040	9.92	0.017	10.48	0.027	10.65	0.017	10.82	0.017	10.99	0.017
5.75	0.629	9.27	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	10.58	0.027	10.75	0.017	10.92	0.017	11.09	0.017
5.75	0.629	9.38	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	10.68	0.027	10.85	0.017	11.02	0.017	11.19	0.017
5.23	0.338	9.38	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	10.78	0.027	10.95	0.017	11.12	0.017	11.30	0.017
5.05	0.338	9.43	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	10.88	0.027	11.05	0.017	11.22	0.017	11.40	0.017
4.95	0.339	9.46	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	10.98	0.027	11.15	0.017	11.32	0.017	11.50	0.017
4.78	0.339	9.49	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.08	0.027	11.25	0.017	11.42	0.017	11.60	0.017
4.66	0.339	9.52	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.18	0.027	11.35	0.017	11.52	0.017	11.70	0.017
4.50	0.339	9.56	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.28	0.027	11.45	0.017	11.62	0.017	11.80	0.017
4.38	0.339	9.59	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.38	0.027	11.55	0.017	11.72	0.017	11.90	0.017
4.26	0.339	9.62	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.48	0.027	11.65	0.017	11.82	0.017	11.99	0.017
4.14	0.339	9.65	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.58	0.027	11.75	0.017	11.92	0.017	12.10	0.017
4.02	0.339	9.68	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.68	0.027	11.85	0.017	12.02	0.017	12.19	0.017
3.90	0.339	9.71	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.78	0.027	11.95	0.017	12.12	0.017	12.29	0.017
3.80	0.339	9.74	0.014	0.038	9.97	0.018	3.04	0.040	9.97	0.017	11.88	0.027	12.05	0.017	12.22	0.017	12.39	0.017
3.70	0.339	9.76	0.014	0.038														

TABLE 9-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 7 (CONT.)	λ	CURVE 7 (CONT.)	ρ
2.69	0.036		5.44	0.033	
2.70	0.035		5.55	0.032	
2.73	0.031		5.64	0.031	
2.74	0.030		5.71	0.031	
2.77	0.031		5.79	0.033	
2.50	0.031		5.90	0.029	
2.63	0.032		6.00	0.028	
2.86	0.032		6.35	0.027	
2.91	0.033		6.13	0.026	
2.95	0.034		6.23	0.025	
3.04	0.035		6.33	0.023	
3.39	0.037		6.49	0.022	
3.16	0.030		6.58	0.021	
3.25	0.036		6.63	0.023	
3.27	0.037		6.68	0.020	
3.33	0.037		6.72	0.019	
3.39	0.037		6.80	0.019	
3.49	0.036		6.88	0.019	
3.53	0.035		7.00	0.018	
3.65	0.036		7.09	0.017	
3.74	0.036		7.19	0.017	
3.83	0.036		7.26	0.016	
3.85	0.035		7.33	0.016	
4.01	0.077		7.45	0.016	
4.56	0.036		7.59	0.015	
4.66	0.035				
4.77	0.035				
4.84	0.025	CURVE 3 $T = 293.$			
4.88	0.034				
4.92	0.034		10.	< 0.01	
4.97	0.033		11.	< 0.01	
5.01	0.032		12.	< 0.01	
5.03	0.033		13.	< 0.01	
5.04	0.033		14.	< 0.01	
5.07	0.033		15.	< 0.01	
5.11	0.034				
5.15	0.034				
5.19	0.034				
5.23	0.034				
5.35	0.033				

d. Angular Spectral Reflectance (Wavelength Dependence)

One set of experimental data was located for the wavelength dependence of the angular spectral reflectance of Irtran 1. Three sets are for magnesium fluoride. The data are listed in Table 9-11 and shown in Figure 9-7. Specimen characterization and measurement information for the data are given in Table 9-10.

All four sets are for room temperature measurements. The one set for Irtran 1 measured by McCarthy [T30100] is for a polished specimen 2 mm thick with the measurement taken at an angle of incidence, θ , of 30° and an angle of reflection, θ' , of 30° . The data shows a decrease from about 0.04 at $4 \mu\text{m}$ to zero value at $9.5 \mu\text{m}$. Because of the wide range in cut off exemplified by the data for the wavelength dependence of normal spectral reflectance (see the section on the wavelength dependence of the normal spectral transmittance and Figure 9-12), it was decided not to give evaluated data in this angular spectral reflectance section.




FIGURE 9-7. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE
(WAVELENGTH DEPENDENCE).

TABLE 9-10. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T30100	McCarty, D. E.	1963	2-50	293	Irtran 1		Specimen 2 mm thick; pressed and sintered; ground and polished to a flatness of seven fringes or better; reference standard was aluminum mirror; smooth values from figure; temperature presumed to be room temperature, 293 K assigned; $\theta = 30^\circ$, $\theta' = 30^\circ$.
2 T38423	Barker, A. S., Jr.	1964	5.0-130	293	MgF_2		Single crystal; cut and polished; electric vector of infrared beam perpendicular to c-axis; one sample contained 1 Ni and 1 Co and had a pink-orange color; other specimen 0.5 Ni and was optically clear; no feature of spectrum could be associated with Ni and Co doping; angle of incidence was near 15° ; measurement temperature specified as room temperature, 293 K assigned; $\theta \approx 15^\circ$, $\theta' \approx 15^\circ$.
3 T38423	Barker, A. S., Jr.	1964	5.0-35	293	MgF_2		Similar to the above specimen except electric vector is parallel to c-axis.
4 T33043	Hunt, G. R., Perry, C. H., and Ferguson, J.	1964	13-5000	293	MgF_2		Not a single crystal; grown at Bell Telephone Laboratories; smooth values from figure; measurement temperature specified as room temperature, 293 K assigned; $\theta = 15^\circ$, $\theta' = 15^\circ$.

TABLE 9-11. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 293^\circ\text{K}$	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 4 (CONT.)
2.03	0.339	8.7	0.625	34.9	0.901	16.4	0.549	15.0	0.064	15.0	0.06	31.0	0.158	31.0	0.06	31.0	0.06	31.0	0.158	
3.80	0.342	9.6	0.015	37.4	0.912	16.7	0.628	15.0	0.24	15.0	0.24	31.85	0.120	31.85	0.24	31.85	0.24	31.85	0.120	
7.40	0.333	10.7	0.015	33.9	0.896	16.8	0.73	15.4	0.096	15.4	0.096	32.47	0.104	32.47	0.096	32.47	0.096	32.47	0.104	
9.40	0.300	11.7	0.016	40.6	0.707	17.0	0.685	15.72	0.125	15.72	0.125	33.11	0.124	33.11	0.125	33.11	0.124	33.11	0.124	
14.4	0.330	12.7	0.016	40.8	0.572	17.2	0.705	15.87	0.150	15.87	0.150	33.56	0.206	33.56	0.150	33.56	0.150	33.56	0.206	
15.4	0.350	13.8	0.016	45.3	0.348	17.5	0.706	16.63	0.178	16.63	0.178	34.13	0.499	34.13	0.178	34.13	0.178	34.13	0.499	
16.0	0.302	14.9	0.038	50.0	0.282	17.8	0.706	16.16	0.220	16.16	0.220	34.25	0.521	34.25	0.220	34.25	0.220	34.25	0.521	
17.7	0.723	15.4	0.679	55.0	0.235	19.0	0.705	16.31	0.304	16.31	0.304	34.60	0.532	34.60	0.304	34.60	0.304	34.60	0.532	
19.0	0.838	15.8	0.166	59.7	0.200	18.2	0.726	16.45	0.470	16.45	0.470	35.21	0.524	35.21	0.470	35.21	0.524	35.21	0.524	
20.3	0.855	16.8	0.492	64.3	0.195	18.4	0.742	16.53	0.516	16.53	0.516	35.46	0.467	35.46	0.516	35.46	0.467	35.46	0.467	
21.7	0.796	17.3	0.698	69.7	0.195	18.6	0.764	16.67	0.550	16.67	0.550	35.56	0.473	35.56	0.550	35.56	0.473	35.56	0.473	
22.1	0.700	18.9	0.747	74.7	0.193	19.0	0.783	16.75	0.578	16.75	0.578	36.50	0.482	36.50	0.578	36.50	0.482	36.50	0.482	
23.4	0.383	23.0	0.781	85.1	0.193	20.0	0.836	16.98	0.602	16.98	0.602	37.04	0.197	37.04	0.602	37.04	0.197	37.04	0.197	
24.7	0.577	23.6	0.737	89.4	0.193	20.9	0.856	17.21	0.614	17.21	0.614	37.59	0.50	37.59	0.614	37.59	0.50	37.59	0.50	
25.1	0.483	21.5	0.667	94.5	0.193	21.9	0.855	17.42	0.621	17.42	0.621	38.61	0.480	38.61	0.621	38.61	0.480	38.61	0.480	
25.6	0.495	21.9	0.580	99.3	0.193	23.0	0.823	17.95	0.621	17.95	0.621	39.22	0.444	39.22	0.621	39.22	0.444	39.22	0.444	
27.2	0.293	22.4	0.452	97.6	0.193	23.4	0.907	18.21	0.617	18.21	0.617	40.32	0.404	40.32	0.617	40.32	0.404	40.32	0.404	
29.9	0.234	23.0	0.335	95.3	0.187	23.8	0.764	19.16	0.632	19.16	0.632	44.05	0.320	44.05	0.632	44.05	0.320	44.05	0.320	
36.8	0.168	23.6	0.244	90.7	0.187	25.0	0.692	19.57	0.656	19.57	0.656	46.51	0.235	46.51	0.656	46.51	0.235	46.51	0.235	
32.1	0.055	23.8	0.207	87.3	0.184	25.9	0.776	20.28	0.681	20.28	0.681	51.81	0.271	51.81	0.681	51.81	0.271	51.81	0.271	
32.9	0.000	24.1	0.188	83.3	0.180	25.9	0.377	20.70	0.697	20.70	0.697	56.62	0.255	56.62	0.697	56.62	0.255	56.62	0.255	
33.6	0.227	24.2	0.207	90.26	0.180	25.0	0.310	21.10	0.697	21.10	0.697	67.14	0.541	67.14	0.697	67.14	0.541	67.14	0.541	
34.1	0.294	24.2	0.281	76.92	0.180	26.9	0.275	21.55	0.683	21.55	0.683	81.97	0.239	81.97	0.683	81.97	0.239	81.97	0.239	
32.9	0.359	24.7	0.293	80.4	0.293	35.0	0.243	21.98	0.601	21.98	0.601	95.00	0.222	95.00	0.601	95.00	0.222	95.00	0.222	
37.6	0.463	24.0	0.313	70.7	0.293	31.0	0.239	22.42	0.510	22.42	0.510	74.00	0.217	74.00	0.510	74.00	0.217	74.00	0.217	
39.4	0.743	24.6	0.263	74.7	0.253	32.0	0.232	23.75	0.49	23.75	0.49	36.30	0.214	36.30	0.49	36.30	0.214	36.30	0.214	
40.9	0.510	25.0	0.258	62.5	0.258	33.0	0.225	24.10	0.390	24.10	0.390	23.00	0.217	23.00	0.390	23.00	0.217	23.00	0.217	
42.6	0.375	25.7	0.220	50.0	0.020	34.0	0.215	24.27	0.374	24.27	0.374	25.25	0.217	25.25	0.374	25.25	0.217	25.25	0.217	
44.3	0.239	26.1	0.191	60.1	0.020	35.0	0.211	24.45	0.386	24.45	0.386	26.71	0.217	26.71	0.386	26.71	0.217	26.71	0.217	
46.7	0.171	26.0	0.168	70.1	0.020	32.0	0.211	24.51	0.450	24.51	0.450	26.95	0.217	26.95	0.450	26.95	0.217	26.95	0.217	
50.0	0.151	27.2	0.149	60.1	0.020	33.0	0.209	24.75	0.462	24.75	0.462	26.39	0.217	26.39	0.462	26.39	0.217	26.39	0.217	
						9.0	0.013	24.88	0.449	24.88	0.449	26.88	0.217	26.88	0.449	26.88	0.217	26.88	0.217	
						10.0	0.006	25.25	0.388	25.25	0.388	27.71	0.339	27.71	0.388	27.71	0.339	27.71	0.339	
						11.0	0.036	25.71	0.324	25.71	0.324	26.25	0.311	26.25	0.324	26.25	0.311	26.25	0.311	
						11.9	0.006	13.51	0.024	13.51	0.024	14.08	0.024	14.08	0.024	14.08	0.024	14.08	0.024	
						13.0	0.006	14.35	0.028	14.35	0.028	14.78	0.219	14.78	0.028	14.78	0.219	14.78	0.219	
						13.0	0.006	14.56	0.037	14.56	0.037	15.82	0.190	15.82	0.037	15.82	0.190	15.82	0.190	
						16.0	0.027	14.84	0.052	14.84	0.052	16.04	0.174	16.04	0.052	16.04	0.174	16.04	0.174	

e. Normal Spectral Absorptance (Wavelength Dependence)

Three sets of experimental data were located for the wavelength dependence of the normal spectral absorptance of Irtran 1. The data are listed in Table 9-14 and shown in Figures 9-8 and 9-9. Specimen characterization and measurement information for the data are given in Table 9-13.

The three sets of data were results of measurements by Stierwalt, et al. [T45698] for a 2 mm thick specimen. The measurement temperatures were 333, 393, and 453 K. The values are between 0.1 and 0.01 within the wavelength range 3 to 6 μm , rise rapidly in the range of 6.5 to 8.5 μm , and are within the range of 0.75 to 0.9 above 10 μm . This data is very similar to the normal spectral emittance data of Stierwalt, et al. [T33450] in Tables 9-2 and 9-3 and Figures 9-1 and 9-2 (curves 17, 18, and 19).

Calculations were carried out to determine the absorptance using transmittance and refractive index data. See the section on the wavelength dependence of the normal spectral emittance for more details. The results of the calculations are curves 4-9 in Table 9-14 and Figures 9-8 and 9-9.

For wavelengths greater than 7 μm , the calculations show the absorptance reaching 0.98 or greater. However, the data of Stierwalt, et al. for the lowest temperature, 333 K, does not reach 0.98. The same type of difficulty manifested itself in the data for the normal spectral emittance.

However, in a lower wavelength region, the calculations for a 2 mm thick specimen (curve 6) and the data for a 2 mm thick specimen at 333 K agree reasonably well. Therefore, between 3 and 6.4 μm , the calculated values are taken as the provisional values for 293 K with an uncertainty of 25%. The provisional values are listed in Table 9-12 and shown in Figure 9-8.

Applying Kirchhoff's law, equating normal spectral absorptance to normal spectral emittance, two more provisional curves are given (see the section on the wavelength dependence of the normal spectral emittance). One applies to a specimen thickness of 3.8 mm, a temperature of 589 K, and a wavelength range of 3 to 6.4 μm ; the other applies to a thickness of 3.8 mm, a temperature of 970 K, and a wavelength range of 3 to 6.0 μm . These values are also listed in Table 9-12 and shown in Figure 9-8. Because of the low value of absorptance, the uncertainty can be as high as 25%.

TABLE 9-12. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (IRTRAN 1) (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	λ	α	λ	α	λ	α
2MM THICK		3.0MM THICK		3.8MM THICK			
T = 293		T = 589		T = 973			
3.00	0.089	3.0	0.154	3.0	0.177		
3.03	0.055	3.11	0.124	3.37	0.155		
3.10	0.079	3.24	0.102	3.31	0.109		
3.19	0.074	3.42	0.076	3.56	0.083		
3.27	0.069	3.80	0.053	3.80	0.071		
3.38	0.065	4.0	0.048	4.0	0.070		
3.49	0.060	4.14	0.045	4.42	0.066		
3.60	0.060	4.64	0.045	4.81	0.076		
3.98	0.059	4.97	0.052	4.98	0.081		
4.00	0.060	5.0	0.054	5.6	0.084		
4.46	0.060	5.09	0.061	5.23	0.111		
4.68	0.060	5.25	0.078	5.47	0.094		
4.78	0.057	5.46	0.061	5.65	0.111		
4.88	0.052	5.60	0.061	5.84	0.154		
4.95	0.058	5.79	0.077	6.00	0.187		
5.00	0.057	6.0	0.107				
5.01	0.058	6.01	0.108				
5.13	0.050	6.20	0.145				
5.23	0.046	6.35	0.165				
5.32	0.044	6.4	0.197				
5.59	0.045						
5.69	0.050						
5.79	0.054						
5.87	0.060						
6.00	0.071						
6.16	0.087						
6.34	0.109						
6.40	0.118						




FIGURE 9-8. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).




FIGURE 9-9. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).

TABLE 9-13. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T45598	Stierwalt, D. L., Bersstein, J. B., and Kirk, D. D.	1963	3.0-11	333	Irtran 1	Specimen 2 mm thick; hot pressed; measured in vacuum; smooth values from figure; $\theta = 0^\circ$.
2 T45598	Stierwalt, D. L., et al.	1963	3-15	393	Irtran 1	Similar to the above specimen.
3 T45598	Stierwalt, D. L., et al.	1963	3-15	453	Irtran 1	Similar to the above specimen.
4 E62603		1971	0.5-9.2	293	Irtran 1	Specimen thickness 0.5 mm; temperature not explicitly given, presumed to be room temperature, 293 K assigned; calculated from transmittance and refractive index, see PP. 16-15 and p. 52, [E62600].
5 E62600		1971	0.5-8.5	293	Irtran 1	Similar to the above specimen except 1 mm thick.
6 E62600		1971	0.5-8.0	293	Irtran 1	Similar to the above specimen except 2 mm thick.
7 E62600		1971	0.5-7.9	293	Irtran 1	Similar to the above specimen except 3 mm thick.
8 E62600		1971	0.65-7.7	293	Irtran 1	Similar to the above specimen except 6 mm thick.
9 E62600		1971	0.84-7.6	293	Irtran 1	Similar to the above specimen except 12 mm thick.

TABLE 9-14. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	CURVE 1 $T = 333.$		CURVE 3 $T = 453.$		CURVE 4 (CONT.)		CURVE 4 (CONT.)		CURVE 5 (CONT.)		CURVE 5 (CONT.)		CURVE 5 (CONT.)	
		λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α
3.00	0.09	3.00	0.09	2.01	0.044	8.06	0.708	2.81	0.362	8.35	0.566	8.00	0.51	8.51	0.988
3.70	0.36	3.70	0.05	2.63	0.039	8.12	0.731	2.92	0.056	8.51	0.51	8.51	0.988		
4.10	0.35	4.60	0.64	2.65	0.051	8.25	0.763	3.05	0.050	8.51	0.51	8.51	0.988		
4.95	0.95	4.90	0.25	2.71	0.076	8.33	0.796	3.49	0.346	8.51	0.51	8.51	0.988		
5.50	6.34	5.60	0.04	2.72	0.142	8.56	0.854	3.99	0.044	8.51	0.51	8.51	0.988		
5.10	0.07	6.15	0.66	2.72	0.073	8.72	0.895	4.49	0.038	8.51	0.51	8.51	0.988		
6.60	0.18	6.40	0.12	2.75	0.054	8.77	0.906	4.77	0.035	8.51	0.51	8.51	0.988		
7.00	0.18	6.70	0.16	2.81	0.045	8.91	0.926	5.07	0.030	8.51	0.51	8.51	0.988		
7.40	0.24	7.03	0.16	2.68	0.042	9.02	0.945	5.27	0.028	8.51	0.51	8.51	0.988		
7.60	0.33	7.30	0.24	3.00	0.039	9.17	0.990	5.63	0.330	8.51	0.51	8.51	0.988		
7.80	0.54	7.80	0.32	3.49	0.037	9.33	0.937	5.93	0.337	8.51	0.51	8.51	0.988		
6.10	0.62	6.30	0.66	3.60	0.036	9.36	0.936	6.09	0.343	8.51	0.51	8.51	0.988		
6.40	0.68	6.39	0.69	3.35	0.033	6.26	0.052	6.50	0.052	8.51	0.51	8.51	0.988		
6.80	0.76	7.10	0.72	4.76	0.027	6.50	0.648	6.98	0.072	8.51	0.51	8.51	0.988		
9.20	0.84	11.0	0.77	4.93	0.023	6.76	0.367	7.10	0.134	8.51	0.51	8.51	0.988		
11.2	0.84	12.1	0.80	4.99	0.027	6.82	0.315	7.20	0.149	8.51	0.51	8.51	0.988		
		12.8	0.81	5.18	0.021	6.89	0.263	7.28	0.166	8.51	0.51	8.51	0.988		
		13.5	0.84	5.70	0.023	6.92	0.239	7.35	0.181	8.51	0.51	8.51	0.988		
		15.0	0.78	6.00	0.029	7.00	0.210	7.43	0.201	8.51	0.51	8.51	0.988		
				6.25	0.035	7.10	0.160	7.47	0.219	8.51	0.51	8.51	0.988		
				6.50	0.044	7.19	0.153	7.53	0.243	8.51	0.51	8.51	0.988		
				6.68	0.051	7.32	0.134	7.56	0.276	8.51	0.51	8.51	0.988		
				6.87	0.061	7.42	0.115	7.63	0.364	8.51	0.51	8.51	0.988		
				7.05	0.072	7.50	0.103	7.70	0.468	8.51	0.51	8.51	0.988		
				7.21	0.084	7.63	0.089	7.74	0.541	8.51	0.51	8.51	0.988		
				7.34	0.096	7.73	0.032	7.76	0.598	8.51	0.51	8.51	0.988		
				7.41	0.108	7.84	0.022	7.81	0.682	8.51	0.51	8.51	0.988		
				7.50	0.130	7.93	0.053	7.94	0.729	8.51	0.51	8.51	0.988		
				7.54	0.141	7.42	0.048	7.67	0.787	8.51	0.51	8.51	0.988		
				7.59	0.162	7.55	0.049	7.90	0.819	8.51	0.51	8.51	0.988		
				7.63	0.118	7.62	0.053	7.92	0.847	8.51	0.51	8.51	0.988		
				7.70	0.299	7.67	0.062	7.94	0.871	8.51	0.51	8.51	0.988		
				7.78	0.401	7.70	0.078	7.98	0.892	8.51	0.51	8.51	0.988		
				7.83	0.495	7.71	0.108	8.03	0.913	8.51	0.51	8.51	0.988		
				7.86	0.557	7.73	0.197	8.05	0.923	8.51	0.51	8.51	0.988		
				7.89	0.585	7.73	0.146	8.17	0.933	8.51	0.51	8.51	0.988		
				7.95	0.641	7.77	0.091	8.17	0.945	8.51	0.51	8.51	0.988		
				8.01	0.681	2.79	0.079	8.26	0.957	8.51	0.51	8.51	0.988		

TABLE 9-14. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	α	CURVE 5 (CONT.)	λ	α	CURVE 6 (CONT.)	λ	α	CURVE 7 (CONT.)	λ	α	CURVE 8	λ	α	CURVE 9 (CONT.)	λ	α	CURVE 9 (CONT.)
3.19	0.074	7.78	0.847	3.08	0.093	3.54	0.105	1.66	0.608	1.95	0.536	3.71	0.098	1.01	0.608	1.66	0.608
3.27	0.069	7.81	0.884	3.20	0.084	0.65	0.973	3.80	0.397	1.97	0.485	0.71	0.880	4.21	0.099	2.09	0.429
3.36	0.065	7.65	0.914	3.32	0.076	0.76	0.832	4.58	0.103	2.15	0.431	0.83	0.774	4.70	0.105	2.24	0.369
3.49	0.060	7.89	0.940	3.49	0.070	0.76	0.832	0.98	0.663	2.05	0.105	0.98	0.663	4.85	0.110	2.39	0.321
3.65	0.060	7.92	0.955	3.76	0.063	0.83	0.774	0.98	0.663	2.24	0.105	0.98	0.663	4.85	0.110	2.39	0.321
3.96	0.029	8.02	0.986	3.80	0.063	0.98	0.663	2.39	0.110	2.46	0.299	0.98	0.594	4.90	0.116	2.46	0.299
4.46	0.361	4.43	0.065	4.43	0.065	1.68	0.594	2.39	0.110	2.46	0.299	1.14	0.553	4.90	0.116	2.46	0.299
4.66	0.060	4.54	0.068	4.54	0.068	1.27	0.493	4.97	0.143	2.50	0.286	1.36	0.436	5.37	0.103	2.54	0.280
4.76	0.057	4.69	0.069	4.69	0.069	1.27	0.493	4.97	0.143	2.61	0.276	1.43	0.403	5.18	0.092	2.61	0.276
4.88	0.052	4.85	0.064	4.85	0.064	1.36	0.436	5.37	0.103	2.69	0.280	1.51	0.372	5.28	0.093	2.69	0.280
4.95	0.058	5.03	0.916	5.02	0.065	1.43	0.403	5.18	0.092	2.73	0.280	1.51	0.372	5.43	0.093	2.73	0.280
5.01	0.058	5.09	0.651	5.14	0.058	1.51	0.403	5.61	0.112	2.73	0.280	1.58	0.347	5.99	0.116	2.73	0.280
5.13	0.050	6.70	0.726	5.22	0.052	1.58	0.372	5.61	0.112	2.73	0.280	1.66	0.321	5.79	0.130	2.74	0.280
5.23	0.045	5.75	0.657	5.52	0.053	1.66	0.321	5.79	0.130	2.74	0.280	1.74	0.295	5.88	0.142	2.77	0.280
5.32	0.044	6.80	0.569	5.65	0.056	1.74	0.295	5.88	0.142	2.77	0.280	1.84	0.269	5.99	0.164	2.80	0.445
5.59	0.045	6.83	0.522	5.78	0.061	1.84	0.269	5.99	0.164	2.80	0.445	1.94	0.246	6.10	0.191	2.83	0.445
5.69	0.050	6.84	0.480	5.67	0.067	1.94	0.246	6.10	0.191	2.84	0.445	2.02	0.226	6.21	0.224	2.84	0.445
5.79	0.054	5.93	0.458	6.00	0.083	2.04	0.226	6.21	0.224	2.85	0.445	2.14	0.204	6.67	0.377	2.91	0.265
5.87	0.263	6.97	0.376	5.15	0.103	2.12	0.175	6.67	0.377	2.91	0.265	5.27	0.123	6.75	0.395	2.91	0.265
6.00	0.371	1.09	0.322	6.27	0.123	2.29	0.175	6.75	0.395	2.91	0.265	6.45	0.160	6.83	0.395	2.91	0.265
6.16	0.367	1.29	0.246	6.42	0.160	2.36	0.160	7.02	0.295	2.95	0.336	6.58	0.178	7.10	0.523	2.95	0.336
6.34	0.109	1.39	0.212	6.61	0.198	2.42	0.153	7.10	0.523	2.95	0.336	6.61	0.212	7.19	0.556	2.95	0.336
6.50	0.132	1.50	0.185	6.88	0.260	2.51	0.145	7.19	0.556	2.95	0.336	6.88	0.260	7.52	0.784	2.95	0.336
6.67	0.159	1.59	0.167	7.01	0.291	2.58	0.145	7.26	0.602	3.16	0.261	7.06	0.394	7.32	0.634	3.21	0.249
6.82	0.182	1.67	0.155	7.06	0.304	2.68	0.159	7.32	0.634	3.21	0.249	7.16	0.178	7.39	0.683	3.21	0.249
6.39	0.213	1.76	0.145	7.16	0.332	2.68	0.178	7.39	0.683	3.21	0.249	7.45	0.216	7.46	0.734	3.21	0.249
7.10	0.236	2.04	0.122	7.23	0.358	2.69	0.229	7.46	0.734	3.23	0.249	7.51	0.260	7.55	0.784	3.23	0.249
7.18	0.260	2.22	0.109	7.28	0.380	2.70	0.316	7.52	0.784	3.33	0.249	7.51	0.316	7.62	0.854	3.33	0.249
7.25	0.276	2.43	0.097	7.36	0.413	2.74	0.263	7.62	0.854	3.43	0.249	7.59	0.443	7.68	0.935	3.43	0.249
7.29	0.291	2.59	0.090	7.41	0.443	2.77	0.243	7.74	0.935	3.53	0.249	7.63	0.481	7.74	0.985	3.53	0.249
7.35	0.320	2.63	0.090	7.47	0.481	2.81	0.216	7.74	0.985	3.66	0.249	7.76	0.216	7.85	0.985	3.66	0.249
7.39	0.335	2.71	0.098	7.51	0.523	2.86	0.200	7.84	0.985	3.74	0.249	7.86	0.200	7.95	0.985	3.74	0.249
7.43	0.363	2.72	0.142	7.57	0.605	2.91	0.183	7.95	0.985	3.80	0.249	7.95	0.183	8.05	0.985	3.80	0.249
7.48	0.388	2.73	0.249	7.65	0.745	2.99	0.167	8.05	0.985	3.95	0.249	8.05	0.167	8.15	0.985	3.95	0.249
7.52	0.423	2.73	0.190	7.73	0.858	3.06	0.152	8.15	0.985	4.05	0.249	8.15	0.152	8.25	0.985	4.05	0.249
7.54	0.152	2.91	0.143	7.76	0.886	3.13	0.139	8.25	0.985	4.16	0.249	8.25	0.139	8.35	0.985	4.16	0.249
7.56	0.593	2.83	0.131	7.78	0.916	3.20	0.130	8.35	0.985	4.26	0.249	8.35	0.130	8.45	0.985	4.26	0.249
7.63	0.583	2.87	0.121	7.82	0.942	3.27	0.122	8.45	0.985	4.37	0.249	8.45	0.122	8.55	0.985	4.37	0.249
7.70	0.729	2.92	0.111	7.84	0.957	3.34	0.114	8.55	0.985	4.47	0.249	8.55	0.114	8.65	0.985	4.47	0.249
7.74	0.791	2.99	0.100	7.90	0.986	3.44	0.110	8.65	0.985	4.56	0.249	8.65	0.110	8.75	0.985	4.56	0.249

CURVE 9
 $T = 293^\circ$

TABLE 9-14. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α)

λ	α
CURVE 9 (CONT.)	
4.92	0.214
4.97	0.234
5.01	0.259
5.03	0.230
5.04	0.214
5.07	0.199
5.11	0.189
5.15	0.164
5.19	0.190
5.23	0.179
5.35	0.180
5.44	0.136
5.55	0.197
5.64	0.205
5.71	0.220
5.79	0.237
5.93	0.273
6.03	0.302
6.05	0.322
6.12	0.356
6.23	0.400
6.33	0.448
6.49	0.525
6.59	0.577
6.63	0.602
6.68	0.628
6.72	0.653
6.83	0.681
6.95	0.719
7.00	0.745
7.09	0.777
7.13	0.805
7.28	0.846
7.33	0.858
7.45	0.913
7.59	0.385

f. Normal Spectral Absorptance (Temperature Dependence)

No experimental data was found for the temperature dependence of the normal spectral absorptance of Irtran 1. However, using curves 8, 9, 10, and 11 of Tables 9-2 and 9-3 together with Kirchhoff's law, Eq. (2.3-7), a set of provisional values for a specimen thickness of 3.8 mm and at a wavelength of 3.8 μm was generated. The provisional values are listed in Table 9-15 and shown in Figure 9-10. The uncertainty is assigned a value of not more than 25%.

TABLE 3-15. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (IRIFAN 1) (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

T	α
3.8MM THICK	
$\lambda = 3.80$	
509.	0.053
647.	0.053
865.	0.059
970.	0.071




FIGURE 9-10. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF MAGNESIUM FLUORIDE (TEMPERATURE DEPENDENCE).

g. Normal Spectral Transmittance (Wavelength Dependence)

A total of 30 sets of experimental data were found for the wavelength dependence of the normal spectral transmittance of magnesium fluoride. The data are listed in Table 9-18 and shown in Figures 9-11 and 9-12. Specimen characterization and measurement information for the data are given in Table 9-17.

The data reported by Linsteadt [T38121] (curves 8 and 9) was supposedly for a 1.02 mm thick specimen of Irtran 1. However, the shape is so different from curves 15, 21, and 26, all of which apply to an approximately 1 mm thick specimen at room temperature, that the conclusion is reached that the material is not Irtran 1 contrary to what was reported for curves 8 and 9.

A look at curves 15 and 21 shows there is considerable difference in the high wavelength cut-off region. The data of curve 15 applies to a specimen thickness of 1.02 mm at a temperature of 300 K; the data in curve 21 applies to a specimen thickness of 1 mm at 293 K. Above 8 μm , curve 15 is considerably above curve 21. In addition, curve 15 reaches zero transmittance at 9.93 μm while for curve 21 it is 8.51 μm .

A comparison between curve 22, a specimen thickness of 2 mm, a measurement temperature of 293 K, and curve 1, a specimen thickness of 2 mm and a measurement temperature of 293 K shows differences. For most of the wavelength region from 7 to 10 μm , curve 1 is considerably above curve 22. For example, at 8 μm curve 22 is near zero while curve 1 is 0.432. The absorption band in the range 2.7-2.8 μm also shows differences between the two curves. Curve 1 at 2.80 μm is 0.607 while curve 22 is 0.842.

Because of these differences, a provisional curve at 293 K for a specimen thickness of 2 mm is only given for the wavelength range 3 to 7 μm . The uncertainty at 7 μm is 12% and, therefore, this uncertainty is assigned to this curve. These provisional values are based on curve 22 and the values are listed in Table 9-16 and shown in Figure 9-11.

Transmittance data was given by Ballard, et al. [T17017] for a 1.75 mm thick specimen at several high temperatures: curve 17 at 673 K, curve 18 at 873 K, and curve 19 at 1073 K. Curve 16 is at 299 K for the same thickness. The curves are identical up to 5.4 μm but above that wavelength the effect of increasing temperature is to decrease the transmittance and also to decrease the wavelength at which the transmittance reaches zero. Since the shape of curve 16, for 299 K and 1.75 mm thick, is different enough from curve 22 for 293 K and 2 mm thick, it is not thought justified to give evaluated data over a range of wavelengths for the highest temperature, i.e., 1073 K.

However, one fact that will be used in the next section is pertinent to make here. From curves 16 through 19, it is noted the transmittance has the same value for 299, 673, 873, and 1033 K at a wavelength of 3.8 μ m.

TABLE 9-16. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE(FIRTRAN II) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ
2MM THICK	
T = 293	
3.00	0.869
3.03	0.972
3.10	0.973
3.19	0.993
3.27	0.888
3.36	0.892
3.49	0.897
3.60	0.898
3.98	0.899
4.00	0.899
4.46	0.900
4.68	0.900
4.76	0.904
4.88	0.909
4.95	0.903
5.00	0.904
5.01	0.913
5.13	0.912
5.23	0.916
5.32	0.918
5.59	0.916
5.69	0.914
5.79	0.910
5.87	0.905
6.00	0.895
6.16	0.880
6.34	0.859
6.40	0.851
6.50	0.836
6.67	0.812
6.82	0.790
6.99	0.761
7.00	0.756




FIGURE 9-11. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).




FIGURE 9-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE).

TABLE 9-17. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T30100 McCarthy, D. E.	1963	2-50	293	Irran 1		Specimen 2 mm thick; pressed and sintered; ground and polished to a flatness of seven fringes or better; reference standard was aluminum mirror; smooth values from figure; temperature presumed to be room temperature, 293 K; assigned; Beckman IR-5A used in 2-16 μ range and Beckman IR-7 with CsI interchange used in 12.5-50 μ range; θ = 0°, θ' = 0°.
2 T35674 Gillespie, D.T., Olset, A.L., and Nichols, L.W.	1965	2-12	298	Irran 1		Specimen 3.150 cm in diameter and 2.60 mm thick; hot-pressed; optically polished flat to within 5 green mercury fringes and a parallelism tolerance of ± 2.5 μ; smooth values from figure; Perkin-Elmer Model 21 spectrophotometer with sodium chloride optics used; θ = 0°, θ' = 0°.
3 T35674 Gillespie, D.T., T20810 et al.	1965	2-12	373	Irran 1		The above specimen.
4 T35674 Gillespie, D.T., T20810 et al.	1965	2-12	473	Irran 1		The above specimen.
5 T35674 Gillespie, D.T., T20810 et al.	1965	2-12	573	Irran 1		The above specimen.
6 T35674 Gillespie, D.T., T20810 et al.	1965	2-12	673	Irran 1		The above specimen.
7 T44164 McCarthy, D.E.	1967	0.31-3.1	293	Irran 1		Specimen 2.0 mm thick; specimen flat to within ten fringes or better of mercury green line surfaces were parallel to within 0.001 mm/mm of length; pressed and sintered; measurements made on commercial double-beam instruments; reported error ± 2%.
8 T35674 Linsteadt, G.	1964	1.0-15	50	Irran 1		Specimen 1.27 cm in diameter and 1.02 mm thick; measurements made on Perkin-Elmer Model 221 spectrophotometer with NaCl optics; θ = 0°, θ' = 0°.
9 T35674 Linsteadt, G.	1964	1.0-15	300	Irran 1		The above specimen.
10 T35646 Olsen, A.L. and McBride, W.R.	1963	0.44-2.0	293	Irran 1		Poly-crystalline compact; cut, ground, and polished to provide plane parallel samples of thickness 0.110 in. (2.70 mm). values of thickness given in paper; grown by Stockbarger method and obtained from Semi-Elements, Inc., Saxonburg, Pennsylvania; comparative Knoop hardness number under 100 g load was 41.5; measurements performed with Cary 14 spectrometer; measurement temperature not given explicitly, assumed to be 293 K; θ = 0°, θ' = 0°.
11 T35646 Olsen, A.L. and McBride, W.R.	1963	2.0-10	293	Irran 1		The above specimen except measurement performed with a Perkin-Elmer 221 spectrometer.
12 T35646 Olsen, A.L. and McBride, W.R.	1963	0.20-2.0	293	Magnesium fluoride		99.95 pure (estimate) prior to growth; single crystal; cut, ground, and polished to provide plane parallel samples of thickness 0.110 in. (2.70 mm). values of thickness given in paper; grown by Stockbarger method and obtained from Semi-Elements, Inc., Saxonburg, Pennsylvania; comparative Knoop hardness number under 100 g load was 41.5; measurements performed with Cary 14 spectrometer; measurement temperature not given explicitly, assumed to be 293 K; θ = 0°, θ' = 0°.
13 T35646 Olsen, A.L. and McBride, W.R.	1963	2.0-11	293	Magnesium fluoride		The above specimen except measurement performed with a Perkin-Elmer 221 spectrometer.
14 T35548 Linsteadt, G.	1965	1.0-9.9	50	Irran 1		Specimen 1.27 cm in diameter and 1.02 mm thick; measurements made on Perkin-Elmer Model 221 spectrophotometer with NaCl optics; θ = 0°, θ' = 0°.
15 T35548 Linsteadt, G.	1965	1.0-9.9	300	Irran 1		The above specimen.

TABLE 9-17. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
16 T17017	Ballard, S.S., McCarthy, K.A., and Wolfe, W.L.	1961	1.0-10.0	293	Irtran 1		Specimen 1.75 mm thick; specular transmittance; information in this reference was obtained from Eastman Kodak Co. sales literature dated 15 June 1959 and 23 February 1961.
17 T17017	Ballard, S.S., et al.	1961	1.0-9.5	673	Irtran 1		Similar to the above specimen.
18 T17017	Ballard, S.S., et al.	1961	1.0-9.2	673	Irtran 1		Similar to the above specimen.
19 T17017	Ballard, S.S., et al.	1961	1.0-8.8	1073	Irtran 1		Similar to the above specimen.
20 E62600	Eastman Kodak Co.	1971	0.50-9.2	293	Irtran 1		Specimen thickness 0.5 mm; uncoated; spectral transmittance; temperature not explicitly mentioned, presumed to be room temperature, 293 K assigned; smooth values from figure.
21 E62600	Eastman Kodak Co.	1971	0.5-8.5	293	Irtran 1		Similar to the above specimen except thickness 1 mm.
22 E62600	Eastman Kodak Co.	1971	0.5-8.0	293	Irtran 1		Similar to the above specimen except thickness 2 mm.
23 E62600	Eastman Kodak Co.	1971	0.5-7.9	293	Irtran 1		Similar to the above specimen except thickness 3 mm.
24 E62600	Eastman Kodak Co.	1971	0.65-7.7	293	Irtran 1		Similar to the above specimen except thickness 6 mm.
25 E62600	Eastman Kodak Co.	1971	0.84-7.6	293	Irtran 1		Similar to the above specimen except thickness 12 mm.
26 T76325	Hatch, S.E.	1962	1.0-9.0	293	Irtran 1		Specimen thickness 1 mm; smooth values from figure; called "ambient transmittance"; presumed room temperature, 293 K assigned; $\theta = 0^\circ$, $\theta' = 0^\circ$.
27 T76325	Hatch, S.E.	1962	1.0-9.0	293	Irtran 1		Similar to the above specimen except thickness 3.4 mm.
28 T76325	Hatch, S.E.	1962	1.0-9.0	293	Irtran 1		Similar to the above specimen except thickness 7.6 mm.
29 T53988	Ballard, S.S.	1965	0.93-8.3	293	Irtran 1		Specimen 6.2 mm thick; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
30 T76325	Hatch, S.E.	1962	10-15	293	Irtran 1		Thicknesses of 1 mm or greater; transmittance essentially zero in this wavelength range (argument presented on p. 597 of this reference that transmittance essentially zero in this wavelength range to 970 K); the applicable temperature is ambient, 293 K assigned; $\theta = 0^\circ$, $\theta' = 0^\circ$.

TABLE 9-18. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, T]

λ	τ	CURVE 1 $T = 293.$			CURVE 2 (CONT.) $T = 298.$			CURVE 3 (CONT.) $T = 473.$			CURVE 4 (CONT.) $T = 473.$			CURVE 5 (CONT.)		
2.00	0.852	5.05	0.619	2.74	0.750	2.00	0.649	7.88	0.324	6.70	0.575	7.88	0.02	6.83	0.594	
2.50	0.375	5.08	0.853	2.78	0.201	2.28	0.704	8.02	0.231	8.33	0.162	7.02	0.087	7.02	0.597	
2.80	0.667	5.14	0.883	2.81	0.610	2.33	0.689	8.65	0.165	8.85	0.087	7.15	0.056	7.15	0.569	
3.00	0.895	5.24	0.899	2.83	0.684	2.36	0.710	8.85	0.054	7.39	0.466	7.39	0.054	7.39	0.466	
3.50	0.985	5.98	0.898	2.94	0.696	2.43	0.725	9.09	0.026	7.60	0.374	7.60	0.026	7.60	0.374	
4.50	0.937	6.28	0.655	3.04	0.771	2.51	0.725	9.42	0.013	7.63	0.341	7.63	0.013	7.63	0.341	
6.80	0.875	6.49	0.819	3.15	0.807	2.58	0.705	10.0	0.000	7.74	0.320	7.74	0.000	7.74	0.320	
7.50	0.795	6.53	0.783	3.31	0.829	2.74	0.750	12.0	0.000	8.06	0.174	8.06	0.000	8.06	0.174	
7.60	0.529	6.68	0.567	3.63	0.858	2.78	0.807	2.78	0.201	8.49	0.087	8.49	0.087	8.49	0.087	
6.20	0.384	6.75	0.663	4.46	0.867	2.81	0.610	2.81	0.231	8.77	0.046	8.77	0.046	8.77	0.046	
9.00	0.241	6.89	0.700	4.63	0.889	2.83	0.684	2.63	0.03	9.03	0.021	9.03	0.021	9.03	0.021	
9.40	0.356	6.93	0.733	4.90	0.871	2.94	0.696	2.94	0.000	9.50	0.000	9.50	0.000	9.50	0.000	
16.1	0.025	7.67	0.732	5.31	0.632	3.04	0.771	3.04	0.649	12.0	0.390	12.0	0.390	12.0	0.390	
10.9	0.037	7.25	0.692	5.68	0.647	3.15	0.607	2.29	0.697	8.49	0.087	8.49	0.087	8.49	0.087	
11.5	0.006	7.34	0.641	5.14	0.878	3.31	0.629	2.31	0.689	8.77	0.046	8.77	0.046	8.77	0.046	
56.6	0.006	7.46	0.631	5.29	0.896	3.63	0.714	2.38	0.725	9.03	0.021	9.03	0.021	9.03	0.021	
7.59	0.505	5.579	0.92	0.896	3.63	0.658	2.43	0.725	2.00	0.697	2.29	0.697	2.29	0.697	2.29	0.697
5.05	0.516	5.055	0.12	0.877	4.46	0.887	2.43	0.725	2.52	0.725	2.29	0.697	2.29	0.697	2.29	0.697
6.44	0.516	6.44	0.811	4.80	0.889	3.15	0.697	2.94	0.725	2.56	0.702	2.56	0.702	2.56	0.702	
6.57	0.367	6.57	0.762	4.90	0.871	5.01	0.632	2.64	0.702	2.31	0.699	2.31	0.699	2.31	0.699	
6.36	0.377	6.69	0.574	5.09	0.657	5.09	0.819	2.75	0.749	2.38	0.714	2.38	0.714	2.38	0.714	
3.15	0.315	6.76	0.123	6.93	0.696	5.15	0.867	2.78	0.201	2.43	0.725	2.43	0.725	2.43	0.725	
8.76	0.123	6.78	0.696	5.12	0.877	4.46	0.887	2.84	0.666	2.52	0.725	2.52	0.725	2.52	0.725	
6.33	0.683	6.713	0.99	0.074	7.67	0.698	5.23	0.984	2.94	0.725	2.56	0.725	2.56	0.725	2.56	0.725
2.36	0.725	9.21	0.046	7.21	0.667	5.37	0.891	2.96	0.692	2.56	0.725	2.56	0.725	2.56	0.725	
2.43	0.725	9.49	0.225	7.37	0.608	5.94	0.882	3.02	0.731	2.64	0.702	2.64	0.702	2.64	0.702	
2.51	0.725	9.73	0.044	7.42	0.605	6.10	0.853	3.17	0.803	2.75	0.749	2.75	0.749	2.75	0.749	
2.58	0.725	10.0	0.000	7.57	0.534	6.29	0.828	3.53	0.831	2.78	0.201	2.78	0.201	2.78	0.201	
2.74	0.725	12.0	0.000	7.66	0.466	6.46	0.783	4.41	0.879	2.84	0.666	2.84	0.666	2.84	0.666	
2.76	0.201	7.73	0.466	6.58	0.738	4.85	0.883	2.96	0.883	2.56	0.682	2.56	0.682	2.56	0.682	
2.31	0.613	7.96	0.329	6.62	0.575	4.96	0.804	3.02	0.804	3.02	0.731	3.02	0.731	3.02	0.731	
2.93	0.634	8.06	0.273	6.75	0.624	5.01	0.632	3.17	0.632	3.17	0.933	3.17	0.933	3.17	0.933	
2.94	0.696	8.18	0.270	6.85	0.637	5.10	0.613	3.53	0.831	3.53	0.831	3.53	0.831	3.53	0.831	
3.04	0.771	8.32	0.17	6.94	0.545	5.17	0.869	4.41	0.879	2.84	0.666	2.84	0.666	2.84	0.666	
3.12	0.327	8.32	0.039	7.06	0.645	5.29	0.830	4.85	0.883	2.96	0.682	2.96	0.682	2.96	0.682	
3.31	0.329	8.33	0.669	8.99	0.058	5.66	0.877	4.96	0.804	3.02	0.731	3.02	0.731	3.02	0.731	
3.63	0.633	8.33	0.669	7.13	0.208	7.36	0.542	6.01	0.861	5.01	0.632	5.01	0.632	5.01	0.632	
4.45	0.887	2.36	0.26	7.30	0.607	7.49	0.584	6.17	0.834	5.13	0.813	5.13	0.813	5.13	0.813	
4.89	0.889	2.43	0.725	7.49	0.017	7.49	0.584	6.42	0.766	5.17	0.813	5.17	0.813	5.17	0.813	
5.01	0.632	2.51	0.725	7.64	0.403	7.64	0.646	6.59	0.868	5.29	0.853	5.29	0.853	5.29	0.853	
4.90	0.871	2.58	0.000	7.64	0.725	7.64	0.403	6.59	0.868	5.29	0.853	5.29	0.853	5.29	0.853	

TABLE 3-16. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 6 (CONT.)		CURVE 7 (CONT.)		CURVE 8 (CONT.)		CURVE 9 (CONT.)		CURVE 10 (CONT.)		CURVE 11 (CONT.)		CURVE 12 (CONT.)	
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
5.6	6.672	6.752	0.436	10.99	0.716	14.92	0.116	2.68	0.760	9.57	0.469	6.67	0.037	5.6	7
5.8	6.859	6.857	0.482	11.60	0.716	15.00	0.116	2.73	0.372	9.45	0.023	6.85	0.023	5.8	7
6.0	6.814	6.877	0.534	11.85	0.723	12.11	0.723	2.77	0.702	9.77	0.023	6.81	0.390	6.0	7
6.3	7.76	6.921	0.577	12.47	0.696	12.47	0.733	2.84	0.706	16.28	0.390	7.76	0.023	6.3	7
6.4	7.42	6.995	0.627	12.73	0.686	13.78	0.686	2.92	0.737	6.97	0.779	7.42	0.023	6.4	7
6.5	6.379	6.663	1.07	0.442	0.000	0.553	0.000	3.03	0.808	3.03	0.779	6.379	0.023	6.5	7
6.6	6.379	6.699	1.13	0.553	0.000	0.624	0.018	3.13	0.826	3.13	0.799	6.379	0.023	6.6	7
6.7	5.567	6.21	2.729	13.57	0.657	13.94	0.657	3.29	0.845	3.29	0.839	5.567	0.023	6.7	7
7.0	5.53	6.28	0.760	14.14	0.622	0.699	0.041	3.61	0.859	3.61	0.825	5.53	0.023	7.0	7
7.2	4.91	6.36	0.738	14.49	0.426	0.792	0.074	3.86	0.879	3.86	0.920	4.91	0.023	7.2	7
7.4	4.24	6.43	0.829	14.49	0.269	0.868	0.122	4.07	0.894	4.07	0.940	4.24	0.023	7.4	7
7.5	3.71	6.50	0.825	14.64	0.119	0.979	0.195	4.65	0.894	4.65	0.949	3.71	0.023	7.5	7
7.7	3.203	6.61	0.344	14.73	0.051	1.077	0.262	4.90	0.874	4.90	0.953	3.203	0.023	7.7	7
7.8	3.141	6.75	0.662	14.79	0.051	1.169	0.321	4.98	0.663	4.98	0.958	3.141	0.023	7.8	7
8.0	2.47	6.13	0.679	15.00	0.372	1.266	0.382	5.02	0.842	5.02	0.963	2.47	0.023	8.0	7
8.2	2.07	6.38	0.893	2.08	0.484	1.366	0.436	5.06	0.876	5.06	0.976	2.07	0.023	8.2	7
8.5	2.018	6.915	2.19	0.905	1.458	0.493	5.15	0.902	5.15	0.982	2.018	0.023	8.5	7	
9.0	2.000	6.300	2.32	0.907	1.532	0.523	6.00	0.902	6.00	0.985	2.000	0.023	9.0	7	
9.5	1.20	6.000	2.62	0.907	1.629	0.569	6.16	0.845	6.16	0.943	1.20	0.023	9.5	7	
10.0	0.000	2.73	0.687	1.50	0.472	1.732	0.508	6.47	0.822	6.47	0.943	0.000	0.023	10.0	7
10.5	0.000	2.74	0.716	1.24	0.563	1.817	0.630	6.56	0.790	6.56	0.943	0.000	0.023	10.5	7
11.0	0.000	2.80	0.402	1.35	0.616	1.895	0.660	6.68	0.589	6.68	0.943	0.000	0.023	11.0	7
11.5	0.000	2.84	0.890	1.79	0.616	2.000	0.686	6.75	0.691	6.75	0.943	0.000	0.023	11.5	7
12.0	0.000	2.91	0.902	2.11	0.662	2.11	0.671	6.80	0.718	6.80	0.943	0.000	0.023	12.0	7
12.5	0.000	3.06	0.898	2.20	0.671	3.08	0.694	6.90	0.740	6.90	0.943	0.000	0.023	12.5	7
13.0	0.000	3.06	0.903	4.54	0.717	6.03	0.735	7.07	0.740	7.07	0.943	0.000	0.023	13.0	7
13.5	0.000	3.06	0.903	10.02	0.736	10.99	0.707	7.34	0.655	7.34	0.943	0.000	0.023	13.5	7
14.0	0.000	3.06	0.903	11.21	0.698	11.21	0.698	7.43	0.606	7.43	0.943	0.000	0.023	14.0	7
14.5	0.000	3.06	0.903	11.53	0.692	2.15	0.688	7.53	0.526	7.53	0.943	0.000	0.023	14.5	7
15.0	0.000	3.06	0.903	11.78	0.705	2.24	0.715	7.62	0.528	7.62	0.943	0.000	0.023	15.0	7
15.5	0.000	3.06	0.903	12.22	0.705	2.26	0.705	7.74	0.486	7.74	0.943	0.000	0.023	15.5	7
16.0	0.000	3.06	0.903	12.75	0.659	2.33	0.733	7.89	0.423	7.89	0.943	0.000	0.023	16.0	7
16.5	0.000	3.06	0.903	13.38	0.632	2.38	0.737	8.05	0.308	8.05	0.943	0.000	0.023	16.5	7
17.0	0.000	3.06	0.903	13.78	0.594	2.45	0.737	8.18	0.398	8.18	0.943	0.000	0.023	17.0	7
17.5	0.000	3.06	0.903	14.57	0.530	2.51	0.718	8.41	0.236	8.41	0.943	0.000	0.023	17.5	7
18.0	0.000	3.06	0.903	14.97	0.457	2.56	0.730	8.49	0.198	8.49	0.943	0.000	0.023	18.0	7
18.5	0.000	3.06	0.903	15.76	0.321	2.63	0.736	8.65	0.105	8.65	0.943	0.000	0.023	18.5	7
19.0	0.000	3.06	0.903	16.28	0.231	2.69	0.736	8.77	0.092	8.77	0.943	0.000	0.023	19.0	7
19.5	0.000	3.06	0.903	16.76	0.126	2.77	0.736	8.89	0.082	8.89	0.943	0.000	0.023	19.5	7
20.0	0.000	3.06	0.903	17.25	0.077	2.84	0.736	8.99	0.072	8.99	0.943	0.000	0.023	20.0	7

TABLE 3-16. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELÉNGTH DEPENDENCE) (CONTINUED)

CURVE 13 (CONT.)		CURVE 14 (CONT.)		CURVE 15 (CONT.)		CURVE 16 (CONT.)		CURVE 17 (CONT.)		CURVE 18 (CONT.)	
λ	T										
1.00	0.577	6.83	0.826	4.97	0.854	2.65	0.777	2.46	0.806	2.46	0.806
1.40	0.762	6.97	0.856	5.03	0.916	2.75	0.652	2.59	0.806	2.58	0.806
1.50	0.303	7.12	0.671	5.67	0.931	2.79	0.817	2.65	0.777	2.65	0.777
1.74	0.839	7.33	0.671	5.26	0.952	2.92	0.838	2.75	0.652	2.75	0.652
1.94	0.869	7.47	0.659	6.03	0.953	3.13	0.659	2.79	0.817	2.79	0.817
2.00	0.577	7.55	0.836	6.19	0.941	3.49	0.878	2.92	0.836	2.92	0.836
1.45	0.762	8.04	0.568	6.30	0.917	3.98	0.901	3.13	0.859	3.13	0.859
1.56	0.803	9.63	0.333	6.41	0.892	4.51	0.922	3.49	0.876	3.49	0.876
1.74	0.839	9.19	0.315	6.35	0.859	5.05	0.936	3.98	0.901	3.98	0.901
1.94	0.869	9.35	0.287	6.54	0.817	5.73	0.936	4.51	0.922	4.51	0.922
2.00	0.577	8.69	0.422	6.63	0.817	6.15	0.921	5.05	0.936	5.05	0.936
1.45	0.762	8.86	0.390	6.68	0.727	6.46	0.905	5.73	0.936	5.63	0.936
1.56	0.803	9.03	0.333	6.74	0.767	6.46	0.905	5.73	0.936	5.63	0.936
1.74	0.839	9.19	0.315	6.35	0.813	6.76	0.870	5.93	0.919	5.81	0.924
1.94	0.869	9.35	0.287	7.00	0.829	7.06	0.835	6.16	0.895	5.99	0.896
2.00	0.577	9.42	0.236	7.14	0.837	7.27	0.789	6.37	0.846	6.19	0.859
1.45	0.762	9.54	0.159	7.37	0.837	7.50	0.736	6.61	0.792	6.41	0.813
1.56	0.803	9.74	0.104	7.52	0.820	7.69	0.685	6.87	0.741	6.59	0.766
1.74	0.839	9.87	0.000	7.71	0.738	7.90	0.622	7.06	0.685	6.77	0.711
1.94	0.869	9.95	0.884	7.92	0.584	8.14	0.554	7.32	0.935	6.97	0.655
2.00	0.577	9.95	0.236	8.05	0.532	8.36	0.475	7.63	0.521	7.12	0.628
1.45	0.762	9.95	0.159	8.20	0.515	8.61	0.372	7.84	0.450	7.33	0.533
1.56	0.803	9.95	0.104	8.39	0.470	8.86	0.265	8.09	0.346	7.51	0.467
1.74	0.839	9.95	0.000	8.83	0.321	9.34	0.297	8.34	0.268	7.68	0.404
1.94	0.869	9.95	0.884	9.12	0.256	9.17	0.166	8.57	0.197	7.64	0.347
2.00	0.577	9.95	0.236	9.38	0.204	9.35	0.122	8.81	0.143	8.02	0.237
1.45	0.762	9.95	0.159	9.93	0.000	9.60	0.674	9.05	0.085	5.17	0.237
1.56	0.803	9.95	0.104	9.93	0.000	9.83	0.041	9.28	0.034	8.38	0.179
1.74	0.839	9.95	0.000	10.00	0.019	9.45	0.000	8.59	0.125	8.79	0.024
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.60	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
2.00	0.577	9.95	0.236	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.45	0.762	9.95	0.159	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.56	0.803	9.95	0.104	9.95	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.74	0.839	9.95	0.000	9.45	0.000	9.45	0.000	8.59	0.000	9.13	0.000
1.94	0.869	9.95	0.884	9.95	0.000	9.4					

TABLE 3-16. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ]

λ	T	λ	τ	CURVE 19(CONT.)			CURVE 20(CONT.)			CURVE 21(CONT.)			CURVE 22(CONT.)		
1.79	0.666	0.63	0.780	7.50	0.844	2.31	0.902	7.84	0.256	2.43	0.678	2.43	0.678	2.43	0.678
2.04	0.730	0.69	0.802	7.54	0.833	2.42	0.907	7.87	0.206	2.60	0.881	2.60	0.881	2.60	0.881
2.24	0.771	0.94	0.821	7.59	0.813	2.55	0.907	7.93	0.166	2.71	0.868	2.71	0.868	2.71	0.868
2.46	0.806	0.99	0.838	7.63	0.777	2.52	0.932	7.92	0.139	2.73	0.726	2.73	0.726	2.73	0.726
2.53	0.806	1.08	0.850	7.70	0.680	2.67	0.994	7.94	0.115	2.73	0.765	2.73	0.765	2.73	0.765
2.65	0.777	1.15	0.864	7.78	0.580	2.70	0.879	7.98	0.094	2.76	0.816	2.76	0.816	2.76	0.816
2.75	0.652	1.26	0.674	7.93	0.487	2.71	0.850	8.03	0.073	2.60	0.642	2.60	0.642	2.60	0.642
2.79	0.817	1.35	0.884	7.86	0.426	2.73	0.764	8.05	0.063	2.65	0.555	2.65	0.555	2.65	0.555
2.92	0.338	1.45	0.890	7.89	0.399	2.73	0.813	8.11	0.053	2.95	0.865	2.95	0.865	2.95	0.865
3.13	0.859	1.59	0.697	7.95	0.343	2.77	0.866	8.17	0.042	3.03	0.972	3.03	0.972	3.03	0.972
3.49	0.878	1.56	0.906	8.31	0.304	2.79	0.878	8.26	0.030	3.10	0.878	3.10	0.878	3.10	0.878
3.98	0.901	2.01	0.913	8.38	0.258	2.77	0.86	8.94	0.021	3.19	0.693	3.19	0.693	3.19	0.693
4.51	0.522	2.44	0.916	8.42	0.255	2.92	0.903	8.51	0.000	3.27	0.639	3.27	0.639	3.27	0.639
5.05	0.936	2.63	0.916	8.25	0.223	3.05	0.966	8.38	0.38	3.38	0.292	3.38	0.292	3.38	0.292
5.43	0.936	2.65	0.904	8.38	0.191	3.49	0.909	8.49	0.597	3.49	0.597	3.49	0.597	3.49	0.597
5.64	0.917	2.71	0.886	8.49	0.165	3.83	0.912	8.63	0.592	3.64	0.592	3.64	0.592	3.64	0.592
5.81	0.901	2.72	0.817	8.58	0.134	3.99	0.914	8.96	0.699	3.98	0.699	3.98	0.699	3.98	0.699
6.32	0.970	2.72	0.683	8.72	0.693	4.49	0.921	9.00	0.506	4.46	0.900	4.46	0.900	4.46	0.900
6.35	0.904	2.75	0.902	8.77	0.963	4.77	0.925	9.25	0.63	4.73	0.904	4.73	0.904	4.73	0.904
6.42	0.970	2.75	0.683	8.91	0.563	5.07	0.931	9.31	0.68	4.93	0.904	4.93	0.904	4.93	0.904
6.50	0.904	2.75	0.910	9.10	0.564	5.27	0.933	9.53	0.76	5.23	0.905	5.23	0.905	5.23	0.905
6.96	0.579	3.00	0.916	9.16	0.000	5.17	0.933	9.33	0.765	5.15	0.905	5.15	0.905	5.15	0.905
7.25	0.474	3.49	0.919	9.33	0.927	5.93	0.927	9.50	0.82	5.50	0.905	5.50	0.905	5.50	0.905
7.52	0.359	3.50	0.921	9.49	0.922	6.09	0.922	9.61	0.86	5.13	0.912	5.13	0.912	5.13	0.912
7.69	0.308	3.85	0.921	9.53	0.926	6.14	0.914	9.68	0.814	5.23	0.910	5.23	0.910	5.23	0.910
7.84	0.254	3.55	0.925	9.58	0.926	6.50	0.896	9.65	0.645	5.32	0.918	5.32	0.918	5.32	0.918
8.37	0.194	4.59	0.932	9.65	0.932	6.98	0.851	9.71	0.53	5.53	0.915	5.53	0.915	5.53	0.915
8.22	0.147	4.93	0.937	9.76	0.598	7.10	0.838	9.72	0.569	5.69	0.914	5.69	0.914	5.69	0.914
8.41	0.142	4.99	0.933	9.82	0.648	7.20	0.624	9.74	0.722	5.79	0.914	5.79	0.914	5.79	0.914
6.58	0.359	5.18	0.946	9.89	0.701	7.28	0.803	9.79	0.763	6.67	0.905	6.67	0.905	6.67	0.905
8.71	0.031	5.70	0.940	9.92	0.722	7.35	0.794	9.78	0.778	6.00	0.895	6.00	0.895	6.00	0.895
8.34	0.006	6.00	0.935	1.00	0.750	7.43	0.774	9.40	0.791	6.45	0.880	6.45	0.880	6.45	0.880
6.25	0.930	6.25	0.930	1.10	0.779	7.47	0.757	1.14	0.721	6.59	0.880	6.59	0.880	6.59	0.880
6.50	0.923	1.19	0.923	1.19	0.806	7.53	0.734	1.50	0.807	6.34	0.859	6.34	0.859	6.34	0.859
6.53	0.917	1.32	0.823	1.32	0.823	7.56	0.702	1.68	0.631	6.67	0.818	6.67	0.818	6.67	0.818
6.87	0.908	1.42	0.841	1.42	0.841	7.63	0.616	1.79	0.941	6.82	0.790	6.82	0.790	6.82	0.790
7.06	0.696	1.50	0.853	1.50	0.853	7.70	0.514	1.68	0.848	6.99	0.761	6.99	0.761	6.99	0.761
6.41	0.637	7.21	0.867	1.63	0.867	7.74	0.442	2.00	0.857	7.10	0.739	7.10	0.739	7.10	0.739
6.69	0.701	7.34	0.876	1.73	0.873	7.78	0.385	2.11	0.862	7.18	0.716	7.18	0.716	7.18	0.716
6.77	0.751	7.41	0.865	2.14	0.892	7.81	0.302	2.30	0.872	7.25	0.698	7.25	0.698	7.25	0.698
CURVE 20															
T = 293.															
0.50	0.560	6.50	0.923	1.19	0.806	7.53	0.734	1.59	0.819	6.50	0.638	6.50	0.638	6.50	0.638
0.60	0.637	6.53	0.917	1.32	0.823	7.56	0.702	1.68	0.631	6.67	0.818	6.67	0.818	6.67	0.818
0.69	0.701	7.34	0.876	1.73	0.873	7.78	0.385	2.11	0.862	7.18	0.716	7.18	0.716	7.18	0.716
0.77	0.751	7.41	0.865	2.14	0.892	7.81	0.302	2.30	0.872	7.25	0.698	7.25	0.698	7.25	0.698

TABLE 9-16. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 22 (CONT.)				CURVE 23 (CONT.)				CURVE 24 (CONT.)				CURVE 25 (CONT.)			
λ	τ	λ	τ												
7.29	0.636	2.59	0.667	7.41	0.537	2.69	0.733	7.46	0.256	3.33	0.745	3.39	0.757	3.39	0.757
7.35	0.623	2.63	0.667	7.47	0.501	2.70	0.647	7.52	0.200	3.40	0.739	3.49	0.771	3.49	0.771
7.39	0.643	2.71	0.859	7.51	0.459	2.74	0.701	7.62	0.101	3.49	0.730	3.55	0.730	3.55	0.730
7.43	0.619	2.72	0.817	7.57	0.373	2.77	0.723	7.68	0.055	3.55	0.730	3.60	0.730	3.60	0.730
7.43	0.594	2.73	0.714	7.65	0.239	2.81	0.746	7.74	0.009	3.60	0.730	3.66	0.730	3.66	0.730
7.52	0.557	2.73	0.771	7.73	0.127	2.86	0.762	7.80	0.000	3.66	0.730	3.76	0.730	3.76	0.730
7.54	0.329	2.31	0.616	7.76	0.093	2.91	0.776	7.86	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.56	0.479	2.83	0.628	7.82	0.069	2.99	0.794	7.94	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.58	0.473	2.37	0.836	7.92	0.344	3.36	0.803	8.03	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.63	0.413	2.92	0.647	7.84	0.629	3.13	0.821	8.13	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.73	0.255	2.92	0.558	7.90	0.000	3.20	0.830	8.20	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.74	0.194	2.39	0.653	7.90	0.000	3.27	0.837	8.27	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.76	0.138	3.03	0.665	7.95	0.000	3.34	0.845	8.34	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.81	0.101	3.29	0.674	7.95	0.000	3.44	0.849	8.44	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.85	0.072	3.32	0.892	7.95	0.000	3.44	0.849	8.44	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.86	0.046	3.49	0.898	7.95	0.000	3.54	0.854	8.54	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.92	0.031	3.70	0.895	7.95	0.000	3.74	0.861	8.74	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.96	0.031	3.60	0.895	7.95	0.000	3.80	0.863	8.80	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.98	0.031	4.43	0.955	7.95	0.000	4.21	0.862	9.21	0.000	3.60	0.730	3.85	0.730	3.85	0.730
7.99	0.031	4.54	0.892	7.95	0.000	4.53	0.859	9.53	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.02	0.031	3.60	0.895	7.95	0.000	4.70	0.657	10.70	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.02	0.031	3.60	0.895	7.95	0.000	4.76	0.853	10.76	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.04	0.031	4.43	0.955	7.95	0.000	4.85	0.847	10.85	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.05	0.031	4.54	0.892	7.95	0.000	4.90	0.847	10.90	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.06	0.031	4.69	0.892	7.95	0.000	4.97	0.847	10.97	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.06	0.031	4.69	0.892	7.95	0.000	5.03	0.859	11.03	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.08	0.031	4.69	0.892	7.95	0.000	5.10	0.859	11.10	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.09	0.031	4.69	0.892	7.95	0.000	5.17	0.859	11.17	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.10	0.031	4.69	0.892	7.95	0.000	5.24	0.859	11.24	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.11	0.031	4.69	0.892	7.95	0.000	5.31	0.859	11.31	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.12	0.031	4.69	0.892	7.95	0.000	5.38	0.859	11.38	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.13	0.031	4.69	0.892	7.95	0.000	5.45	0.859	11.45	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.14	0.031	4.69	0.892	7.95	0.000	5.52	0.859	11.52	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.15	0.031	4.69	0.892	7.95	0.000	5.59	0.859	11.59	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.16	0.031	4.69	0.892	7.95	0.000	5.66	0.859	11.66	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.17	0.031	4.69	0.892	7.95	0.000	5.73	0.859	11.73	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.18	0.031	4.69	0.892	7.95	0.000	5.80	0.859	11.80	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.19	0.031	4.69	0.892	7.95	0.000	5.87	0.859	11.87	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.20	0.031	4.69	0.892	7.95	0.000	5.94	0.859	11.94	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.21	0.031	4.69	0.892	7.95	0.000	6.01	0.859	12.01	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.22	0.031	4.69	0.892	7.95	0.000	6.08	0.859	12.08	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.23	0.031	4.69	0.892	7.95	0.000	6.15	0.859	12.15	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.24	0.031	4.69	0.892	7.95	0.000	6.22	0.859	12.22	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.25	0.031	4.69	0.892	7.95	0.000	6.29	0.859	12.29	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.26	0.031	4.69	0.892	7.95	0.000	6.36	0.859	12.36	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.27	0.031	4.69	0.892	7.95	0.000	6.43	0.859	12.43	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.28	0.031	4.69	0.892	7.95	0.000	6.50	0.859	12.50	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.29	0.031	4.69	0.892	7.95	0.000	6.57	0.859	12.57	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.30	0.031	4.69	0.892	7.95	0.000	6.64	0.859	12.64	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.31	0.031	4.69	0.892	7.95	0.000	6.71	0.859	12.71	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.32	0.031	4.69	0.892	7.95	0.000	6.78	0.859	12.78	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.33	0.031	4.69	0.892	7.95	0.000	6.85	0.859	12.85	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.34	0.031	4.69	0.892	7.95	0.000	6.92	0.859	12.92	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.35	0.031	4.69	0.892	7.95	0.000	6.99	0.859	12.99	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.36	0.031	4.69	0.892	7.95	0.000	7.06	0.859	13.06	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.37	0.031	4.69	0.892	7.95	0.000	7.13	0.859	13.13	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.38	0.031	4.69	0.892	7.95	0.000	7.20	0.859	13.20	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.39	0.031	4.69	0.892	7.95	0.000	7.27	0.859	13.27	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.40	0.031	4.69	0.892	7.95	0.000	7.34	0.859	13.34	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.41	0.031	4.69	0.892	7.95	0.000	7.41	0.859	13.41	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.42	0.031	4.69	0.892	7.95	0.000	7.48	0.859	13.48	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.43	0.031	4.69	0.892	7.95	0.000	7.55	0.859	13.55	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.44	0.031	4.69	0.892	7.95	0.000	7.62	0.859	13.62	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.45	0.031	4.69	0.892	7.95	0.000	7.69	0.859	13.69	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.46	0.031	4.69	0.892	7.95	0.000	7.76	0.859	13.76	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.47	0.031	4.69	0.892	7.95	0.000	7.83	0.859	13.83	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.48	0.031	4.69	0.892	7.95	0.000	7.90	0.859	13.90	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.49	0.031	4.69	0.892	7.95	0.000	7.97	0.859	13.97	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.50	0.031	4.69	0.892	7.95	0.000	8.04	0.859	14.04	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.51	0.031	4.69	0.892	7.95	0.000	8.11	0.859	14.11	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.52	0.031	4.69	0.892	7.95	0.000	8.18	0.859	14.18	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.53	0.031	4.69	0.892	7.95	0.000	8.25	0.859	14.25	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.54	0.031	4.69	0.892	7.95	0.000	8.32	0.859	14.32	0.000	3.60	0.730	3.85	0.730	3.85	0.730
8.55	0.031	4.69	0.892	7.95	0.000	8.39	0.859	14.39	0.000	3.60	0.730	3.85			

TABLE 9-18. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T; K; TRANSMITTANCE, τ)

λ	τ	λ	τ	CURVE 26 (CONT.)		CURVE 27 (CONT.)		CURVE 28 (CONT.)		CURVE 29 T = 293.	
6.072	0.328	5.96	0.639	3.19	0.882	1.63	0.469	6.89	0.457	0.0	0.0
6.039	0.309	6.24	0.919	3.43	0.907	1.83	0.539	6.96	0.468	10.	0.0
6.088	0.273	6.49	0.688	3.65	0.918	2.03	0.613	7.06	0.469	11.	0.0
7.006	0.237	6.72	0.853	3.60	0.918	2.21	0.671	7.15	0.454	12.	0.0
7.099	0.216	6.89	0.677	4.37	0.918	2.32	0.693	7.21	0.429	13.	0.0
7.019	0.173	7.01	0.877	4.62	0.913	2.45	0.715	7.43	0.268	14.	0.0
7.028	0.144	7.21	0.652	4.76	0.902	2.54	0.715	7.54	0.153	15.	0.0
7.333	0.126	7.41	0.623	4.8+	0.874	2.62	0.697	7.66	0.066		
7.045	0.071	7.52	0.801	4.89	0.831	2.66	0.629	7.70	0.432		
7.59	0.004	7.69	0.776	4.95	0.895	2.66	0.556	7.85	0.010		
		7.76	0.655	5.32	0.919	2.73	0.582	9.09	0.005		
CURVE 26 T = 293.		7.82	0.551	5.16	0.939	2.73	0.601				
		7.84	0.495	5.21	0.939	2.78	0.623				
		7.92	0.441	5.78	0.917	2.90	0.649				
		5.34	0.421	5.99	0.896	2.94	0.720				
2.016	0.709	3.17	0.421	6.13	0.856	3.01	0.755	3.93	0.295		
2.129	0.935	3.26	0.394	6.24	0.823	3.12	0.796	1.66	0.491		
1.442	0.323	8.41	0.335	6.37	0.767	3.21	0.629	2.25	0.616		
1.73	0.371	3.57	0.286	6.61	0.624	3.34	0.254	2.50	0.638		
1.58	0.900	8.62	0.225	6.73	0.571	3.55	0.563	2.82	0.645		
2.25	0.915	9.09	0.169	6.84	0.690	3.80	0.666	2.96	0.639		
2.57	0.915			6.99	0.690	4.10	0.656	3.14	0.623		
2.63	0.582			7.13	0.671	4.17	0.448	3.70	0.547		
2.65	0.773			7.33	0.572	4.24	0.623	4.19	0.716		
2.57	0.755			7.52	0.441	4.29	0.642	5.02	0.733		
2.71	0.782			7.73	0.214	4.37	0.633	5.87	0.742		
2.73	0.891			7.87	0.082	4.45	0.633	5.97	0.744		
2.91	0.312			7.99	0.047	4.90	0.672	5.72	0.748		
3.32	0.333			8.19	0.047	5.02	0.330	6.84	0.655		
3.19	0.545			8.34	0.035	5.14	0.376	7.14	0.539		
4.33	0.945			8.50	0.016	5.49	0.576	7.42	0.722		
4.12	0.935			8.14	0.000	5.72	0.361	7.66	0.241		
4.13	0.927			8.37	0.619	5.91	0.828	7.79	0.138		
4.32	0.948			8.53	0.815	6.06	0.300	7.85	0.373		
4.79	0.943			8.64	0.802	6.14	0.762	7.93	0.031		
4.38	0.935			8.69	0.684	6.29	0.674	8.03	0.018		
4.56	0.917			8.71	0.36	6.58	0.469	8.26	0.006		
5.91	0.937			8.79	0.739	1.00	0.672				
5.14	0.949			8.49	0.813	1.18	0.190				
5.61	0.949			8.60	0.854	1.33	0.304				
				8.60	0.854	1.47	0.384	6.79	0.429		

h. Normal Spectral Transmittance (Temperature Dependence)

No experimental data was found for the temperature dependence of the normal spectral transmittance of Irtran 1. However, a provisional curve at $3.8 \mu\text{m}$, with an uncertainty of 12%, and applying to a specimen thickness of 1.75 mm is listed in Table 9-19 and shown in Figure 9-13. Several considerations were relevant in arriving at this provisional curve. The data of curves 16, 17, 18, and 19 of the previous section show the transmittance as constant at temperatures of 299, 673, 873, and 1073 K. The uncertainty of 12% takes account of the slight variation at $3.8 \mu\text{m}$ by curves 2-6 of the previous section. The constant value selected at $3.8 \mu\text{m}$ was the value from the provisional curve in the preceding section.

TABLE 9-19. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUOPIDÉ (IRTRAN 1) (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

T

τ
1.75MM THICK

$\lambda = 3.6$

299.	0.698
673.	0.898
873.	0.896
1073.	0.898




FIGURE 9-13. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF MAGNESIUM FLUORIDE (TEMPERATURE DEPENDENCE).

4.10. Pyroceram

Pyroceram is a generic name for a group of glass-ceramic materials, which were developed by the Corning Glass Works, Corning, New York 14830. The word "Pyroceram" is a trademark of Corning Glass Works and is registered with the United States Patent Office. Pyrocerams are microcrystalline materials formed originally from a noncrystalline glass.

The specific Pyroceram that is of interest for the purposes of this report is Corning Code 9606, therefore, specific properties mentioned in this general section will be for Corning 9606. In addition, in the data sections pertaining to Pyroceram, the aim is to give evaluated data, when appropriate, for Corning 9606. Data was extracted not only for Corning 9606 but also for any other material subsumed under the name of Pyroceram or that was labeled as a Pyroceramic type material. This was done in order to see the similarities and differences of the various Pyrocerams with the purpose of aiding data evaluation.

Corning Code 9606 is a magnesia aluminosilicate glass ceramic (composed of silicon dioxide, aluminum oxide, magnesium oxide, and a small amount of titanium dioxide). The ingredients are melted together at temperatures of the order of 1900 K using special techniques to insure uniform composition, constant density, freedom from bubbles and striations, and uniform electrical properties. Pyroceram 9606 is non-porous, considerably harder than glass, opaque, and gray in color.

Code 9606 is primarily used in military products and specifically as missile radomes since it has uniform electrical properties throughout the material at elevated temperatures and the ability to pass R.F. signals. Other properties which make it good for radome applications are good thermal shock and rain erosion characteristics.

According to 9606 Data Sheets [A00009], its physical properties include a softening point of 1623 K, a density of 2.6 g/cm^3 , a porosity (void volume) of 0.00%, water absorption of 0.00%, and the property of being impermeable to gas. Mechanical properties of Corning Code 9606 include a strength to weight ratio (modulus of rupture to specific gravity) of $13.5 \times 10^3 \text{ psi}$ at 293 K, Young's modulus of $17.4 \times 10^6 \text{ psi}$ at 293 K, a shear modulus of $6.9 \times 10^6 \text{ psi}$ at 293 K, Poisson's ratio of 0.245 at 293 K, a modulus of rupture of $35 \times 10^3 \text{ psi}$ at 293 K, a Knoop hardness of 619 kg/mm^2 with a 500 gram load, and a Knoop hardness of 698 kg/mm^2 with a 100 gram load. Thermal properties include a coefficient of linear expansion of $57 \times 10^{-7} \text{ C}^{-1}$ over a temperature range of 293 to 593 K, a mean thermal conductivity of $0.034 \text{ W cm}^{-1} \text{ C}^{-1}$ over a temperature range of 293 to 1093 K, a mean thermal diffusivity of $0.0127 \text{ cm}^2 \text{ s}^{-1}$ over a temperature range of 293 to 1093 K, and a

mean specific heat of 0.233 cal g⁻¹ C⁻¹ over the temperature range of 298 to 673 K. Electrical properties include a loss factor of 0.8% at 293 K and a dielectric strength of 350 volts rms mil⁻¹ at 293 K and 60 cps.

a. Normal Spectral Emittance (Wavelength Dependence)

There are four sets of experimental data available for the wavelength dependence of the normal spectral emittance of Corning 9606 as listed in Table 10-2 and shown in Figure 10-1. Specimen characterization and measurement information for the data are given in Table 10-1.

The data for Corning 9606 covers a temperature range of 813 to 1403 K. Four sets of experimental also are available for another kind of Pyroceram known as Corning 9608 which shows the same general trend as Corning 9606, but the values are different enough that using data of Corning 9608 to help in generating evaluated data for Corning 9606 is not justified.

It is noted that the data for Corning 9606 are widely separated and, therefore, there is not enough factual evidence to justify giving evaluated values.

The lines in Figure 10-1 connecting the data points are not meant to imply that they represent a smooth curve. The data for all eight curves in Figure 10-1 and Tables 10-1 and 10-2 were extracted from tabular data. A smooth curve should not be drawn through the data points because of the widely spaced nature of the data. In addition, it is not justified to generate values for a plot of normal spectral emittance as a function of temperature for 3.8 and 10.6 μ m.

Data for the wavelength dependence of the normal spectral emittance of Corning 9606 below 813 K and above 1403 K were not located.




FIGURE 10-1. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF PYROCERAM.
(WAVELENGTH DEPENDENCE).

TABLE 10-1. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF PYROCERAM (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T29570	Folweiler, R.C.	1964	1-14	813	Corning 9606	Method of measurement used was rotating sample method; rotating specimen in furnace used in conjunction with Baird-Atomic infrared spectrometer, model NK-1A, for emittance measurement; $\theta \sim 0^\circ$, reported error ± 10 . The above specimen.
2 T29570	Folweiler, R.C.	1964	1-14	1021	Corning 9606	The above specimen.
3 T29570	Folweiler, R.C.	1964	1-14	1205	Corning 9606	The above specimen.
4 T29570	Folweiler, R.C.	1964	1-14	1403	Corning 9606	The above specimen.
5 T29570	Folweiler, R.C.	1964	1-14	813	Corning 9606	Method of measurement used was rotating sample method; rotating specimen in furnace used in conjunction with Baird-Atomic infrared spectrometer, model NK-1A, for emittance measurement; value reported at 5 μ of 1.04 obviously in error, it cannot be greater than 1.0; $\theta \sim 0^\circ$, reported error ± 10 . The above specimen.
6 T29570	Folweiler, R.C.	1964	1-14	1018	Corning 9606	The above specimen.
7 T29570	Folweiler, R.C.	1964	1-14	1205	Corning 9606	The above specimen.
8 T29570	Folweiler, R.C.	1964	1-14	1405	Corning 9606	The above specimen except value reported at 11 μ of 1.04 obviously in error, it cannot be greater than 1.0.

TABLE IJ-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF PYROCELLAM (WAVELENGTH DEPENDENCE)

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
CURVE 1 $T = 813.$							
1.	0.67	4.	0.58	14.	0.96		
2.	0.19	5.	0.64				
3.	0.32	6.	0.98	CURVE 8 $T = 1405.$			
4.	0.45	11.	0.79				
5.	0.83	14.	0.83				
8.	1.03	CURVE 5 $T = 813.$					
11.	0.34						
14.	0.64						
CURVE 2 $T = 1021.$							
1.	0.33	1.	0.73				
2.	0.26	2.	0.23				
3.	0.33	3.	0.81				
4.	0.46	4.	0.85				
5.	0.63						
8.	0.88	CURVE 6 $T = 1018.$					
11.	0.90						
14.	0.92						
CURVE 3 $T = 1205.$							
1.	0.50	1.	0.74				
2.	0.29	2.	0.22				
3.	0.37	3.	0.79				
4.	0.49	4.	0.66				
5.	0.35	5.	0.93				
8.	0.39	6.	0.92				
11.	0.79	7.	0.90				
14.	0.84	14.	0.92				
CURVE 4 $T = 1403.$							
1.	0.29	1.	0.58				
2.	0.27	2.	0.55				
3.	0.30	3.	0.77				
		4.	0.67				
		5.	0.55				
		8.	0.99				
		11.	0.92				

b. Normal Spectral Emittance (Temperature Dependence)

There is one set of experimental data available for the temperature dependence of the normal spectral emittance of Corning 9606 as well as three sets for Corning 9608. These data sets are tabulated in Table 10-4 and shown graphically in Figure 10-2. The specimen characterization and measurement information are given in Table 10-3.

The one data set for Corning 9606 covers a temperature range of 1191 to 1456 K and for a wavelength of 0.665 μm . Because of the lack of data at 3.8 and 10.6 μm , no evaluated values can be given.




TABLE 10-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF PYROCERAM (Temperature Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T10060	Olson, O.H. and Morris, J.C.	1959	c. 665	1191-1456	Pyrocram 9606	Data from figure; $\theta^{\circ}=0^{\circ}$.
2 T10060	Olson, O.H. and Morris, J.C.	1959	0.665	1195-1460	Pyrocram 9608	Data from figure; $\theta^{\circ}=0^{\circ}$.
3 T18630	Blair, G.R.	1960	0.640		Corning body 9608	Ground to size, ultrasonically cleaned, surface polished with 1-5 μm diamond polishing compound until normally mat surface began to reflect light, cleaned, polished with cloth charged with a paste of cerium oxide and kerosene; measured in vacuum; data from figure; emissivity reported; $\theta^{\circ}=0^{\circ}$, reported error ~10%.
4 T18630	Blair, G.R.	1960	1		Corning body 9608	The above specimen.

TABLE 10-4. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF PYROCERAM (TEMPERATURE DEPENDENCE,
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T	ϵ
CURVE 1 $\lambda = 0.665$	
1191.	0.423
1327.	0.472
1466.	0.525
CURVE 2 $\lambda = 0.665$	
1195.	0.492
1327.	0.465
1466.	0.507
CURVE 3 $\lambda = 0.640$	
913.	0.277
1119.	0.247
1339.	0.294
1473.	0.254
CURVE 4 $\lambda = 1.$	
619.	0.393
1119.	0.934
1336.	0.827
1473.	0.714

c. Normal Spectral Reflectance (Wavelength Dependence)

There is one set of experimental data applicable to Corning 9606 and one to Corning 9608 for the wavelength dependence of normal spectral reflectance as listed in Table 10-7 and shown in Figures 10-3 and 10-4. Specimen characterization and measurement information for the data are given in Table 10-6. The data obtained by Olson and Morris [T10060] (curve 1) is applicable only at room temperature and only covers the wavelength range of 0.30 to 2.7 μm . Confirmatory data for Corning 9606 over this wavelength range is lacking and no data has been found in the wavelength range of 2.7 to 15 μm . In addition, no data was located above room temperature for any portion of the wavelength range of interest.

Provisional values for Corning 9606 are listed in Table 10-5 and shown in Figure 10-3. The structure was kept at 1.36 and 1.78 μm because Corning 9608 also shows this structure which indicates the structure is characteristic of the Pyroceram class of materials.

The context within which this set of provisional values is valid is the following: (1) they hold for room temperature, 293 K, (2) the geometrical conditions are that incidence is for near normal, specifically $\theta = 9^\circ$, while the viewed conditions are over a hemisphere, i.e., 2π , and (3) the wavelength range covered is from 0.3 to 2.7 μm . The estimate of the uncertainty is that for wavelengths between 0.35 and 2.7 μm it is thought to be of the order of 10% and for wavelengths less than 0.35 μm it would be larger in percentage value.

TABLE 10-5. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF PYROCERAM (CORNING 9606) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ
$T = 293$			
0.297	0.062	2.1	0.939
0.310	0.142	2.12	0.938
0.339	0.224	2.2	0.933
0.446	0.529	2.32	0.925
0.460	0.582	2.3	0.926
0.5	0.588	2.39	0.913
0.516	0.593	2.4	0.915
0.6	0.612	2.45	0.890
0.639	0.619	2.5	0.862
0.7	0.636	2.51	0.852
0.710	0.642	2.59	0.819
0.795	0.706	2.6	0.817
0.8	0.706	2.68	0.791
0.9	0.770	2.7	0.786
0.952	0.800	2.72	0.780
1.0	0.817		
1.05	0.835		
1.1	0.844		
1.16	0.852		
1.2	0.854		
1.21	0.854		
1.28	0.854		
1.3	0.853		
1.35	0.850		
1.4	0.853		
1.41	0.853		
1.49	0.889		
1.5	0.896		
1.58	0.919		
1.6	0.917		
1.64	0.912		
1.7	0.899		
1.77	0.891		
1.8	0.894		
1.83	0.900		
1.9	0.923		
1.94	0.934		
1.99	0.944		
2.0	0.944		

T = 293 (CONT.)




FIGURE 10-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF PYROCERAM
(WAVELENGTH DEPENDENCE).




FIGURE 10-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).

TABLE 10-6. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF PYROCERAM (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T10060	Olson, O.H. and Morris, J.C.	1959	0.30-2.7	293	PyroceraM 9606	Integrating sphere reflectometer used; reflectance factor measured then values converted to absolute reflectance values; working standard magnesium carbonate surface; smooth values from figure; temperature presumed to be room temperature, 293 K assigned; $\theta=9^\circ$, $\omega'=2\pi$; reported error 4%.
2 T10060	Olson, O.H. and Morris, J.C.	1959	0.30-2.7	293	PyroceraM 9608	Integrating sphere reflectometer used; reflectance factor measured then values converted to absolute reflectance values; working standard magnesium carbonate surface; smooth values from figure; temperature presumed to be room temperature, 293 K assigned; $\theta=9^\circ$, $\omega'=2\pi$; reported error 4%.

TABLE 10-7. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF PYROCEAN (WAVELLENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ	CURVE 1 $T = 293$.	CURVE 2 (CONT.)
6.297	0.062	6.338	0.499		
6.318	0.142	6.355	0.601		
6.339	0.224	6.372	0.702		
6.476	0.529	6.391	0.603		
6.486	0.532	6.407	0.639		
6.516	0.593	6.440	0.805		
6.639	0.619	6.493	0.652		
6.716	0.642	6.534	0.697		
6.745	0.700	6.623	0.802		
6.952	0.822	6.623	0.875		
1.05	0.935	6.696	0.673		
1.15	0.652	6.755	0.676		
1.21	0.354	6.792	0.681		
1.23	0.857	6.661	0.874		
1.35	0.950	6.915	0.658		
1.41	0.855	1.001	0.838		
1.49	0.389	1.035	0.829		
1.58	0.318	1.139	0.834		
1.64	0.912	1.246	0.825		
1.77	0.892	1.312	0.612		
1.83	0.900	1.352	0.601		
1.94	0.934	1.397	0.792		
1.99	0.944	1.557	0.792		
2.12	0.938	1.625	0.779		
2.32	0.925	1.700	0.746		
2.39	0.919	1.798	0.701		
2.45	0.893	1.960	0.681		
2.51	0.852	2.981	0.570		
2.53	0.819	2.017	0.659		
2.68	0.791	2.099	0.603		
2.72	0.783	2.191	0.547		
		2.251	0.520		
		2.303	0.502		
		2.392	0.483		
		2.463	0.435		
		2.509	0.398		
		2.596	0.339		
		2.658	0.303		
		2.736	0.276		
		CURVE 2 $T = 293$.			
6.298	0.103				
6.312	0.196				
6.317	0.299				
6.326	0.400				

d. Hemispherical Spectral Transmittance (Wavelength Dependence)

There are four sets of experimental data for the wavelength dependence of the hemispherical spectral transmittance of Pyroceram with two data sets applicable to the specific material of interest here in this report, i.e., Corning 9606, and two data sets to a different Pyroceram, Corning 9608. The data for these four sets are listed in Table 10-9 and shown in Figure 10-5. Specimen characterization and measurement information for the data are given in Table 10-8.

The two sets of measurements of Folweiler [T29570] (curves 1 and 2) for Corning 9606 are both for room temperature. One set (curve 1) is for a specimen 0.005 inches thick and the second set (curve 2) is for a greater thickness of 0.016 in. As expected, the data for the greater thickness (curve 2) is less than the data for curve 1. The data for these two sets was given in tabular form and over widely spaced wavelengths. Because of this fact, no evaluated values are justified. It should further be pointed out that straight lines connecting the data points, as in Figure 10-5, are not meant to imply a smooth curve but are done that way for ease of visual presentation.




FIGURE 10-5. EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF PYROCERAM
(WAVELENGTH DEPENDENCE).

TABLE 10-8. MEASUREMENT INFORMATION ON THE HEMISPHERICAL SPECTRAL TRANSMITTANCE OF PYTOCERAM (Wavelength Dependence)

Cat. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specif. cations, and Remarks
1 T29370	Folweiler, R.C.	1964	1-8	293	Corning 9606	Specimen 0.005 in. thick, cross-sectional dimensions 0.25 by 0.02 in., diffusing screen used in front of specimen; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\omega=2\pi$, reported error $\pm 3\%$.
2 T29370	Folweiler, R.C.	1964	1-8	293	Corning 9606	Similar to the above specimen except specimen is 0.010 in. thick.
3 T29370	Folweiler, R.C.	1964	1-8	293	Corning 9608	Specimen 0.008 in. thick, cross-sectional dimensions 0.25 by 0.02 in.; diffusing screen used in front of specimen; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\omega=2\pi$, reported error $\pm 3\%$.
4 T29370	Folweiler, R.C.	1964	1-8	293	Corning 9608	Similar to the above specimen except specimen is 0.016 in. thick.

TABLE 15-9. EXPERIMENTAL HEMISPHERICAL SPECTRAL TRANSMITTANCE OF PYREX CERAM (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; TRANSMITTANCE, τ)

λ	τ
CURVE 1 T = 293.	
1.	0.315
2.	0.385
4.	0.424
5.	0.0
8.	0.0
CURVE 2 T = 293.	
1.	0.188
2.	0.259
7.	0.274
5.	0.0
8.	0.0
CURVE 3 T = 293.	
1.	0.349
2.	0.532
4.	0.814
5.	0.243
8.	0.000
CURVE 4 T = 293.	
1.	0.225
2.	0.435
4.	0.707
5.	0.084
8.	0.000

e. Normal Spectral Transmittance (Wavelength Dependence)

A total of 23 sets of experimental data were located for the wavelength dependence of the normal spectral transmittance of Pyroceram. These data sets are listed in Table 10-12 and shown in Figures 10-6 and 10-7. Specimen characterization and measurement information for the data are given in Table 10-11.

Of the 23 data sets only nine are specifically for Corning 9606 with data of eight reported by Folweiler [T29570] (curves 1-8) and data of the ninth reported by Hobbs and Folweiler [T39365], (curve 17). Data of curves 1 through 4 were given in tabular form and reported for integral wavelengths from 1 to 5 μm . On the other hand, data of curves 5-8 were given in graphical form and hence the shape of the curves is known. Curves 5-8 cover the wavelength range of 1 to 5 μm and data are reported for 293, 770, 900, and 1040 K. Data of curve 17 covers the wavelength region of 1 to 5 μm and is applicable to a temperature of 293 K.

Provisional values for 293 K and 1040 K are listed in Table 10-10 and shown in Figure 10-6 and apply to a specimen 3.18 mm thick. The values for 293 K are based on curve 5 while the values for 1040 K are based on curve 8. These values are called provisional because of the lack of much confirmatory evidence. The data of curve 17 is disregarded because the preponderance of evidence shows the transmittance reaching zero at 5 μm (curves 1 and 5 in Table 10-12 and Figure 10-7 together with curves 1 and 2 in Table 10-9 and Figure 10-5) whereas the data of curve 17 does not show this behavior. It is thought the uncertainty assigned to the two provisional curves is 20%.

TABLE 10-10. PROVISIONAL NORMAL SPOT CAL TRANSMITTANCE OF PYROCERAM (CORNING 9636) (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ
3.16MM THICK		3.15MM THICK		3.18MM THICK		3.18MM THICK	
T = 293		T = 293 (CONT.)		T = 1340		T = 1040 (CONT.)	
1.00	0.681	3.15	0.227	1.61	0.600	3.50	0.219
1.10	0.703	3.26	0.236	1.13	0.633	3.63	0.219
1.08	0.700	3.21	0.239	1.14	0.653	3.71	0.219
1.20	0.723	3.30	0.269	1.20	0.656	3.80	0.219
1.30	0.742	3.37	0.300	1.39	0.677	3.90	0.219
1.33	0.748	3.40	0.314	1.47	0.696	4.00	0.219
1.40	0.761	3.46	0.350	1.42	0.700	4.10	0.216
1.50	0.775	3.50	0.360	1.53	0.714	4.11	0.216
1.53	0.773	3.58	0.400	1.60	0.732	4.20	0.210
1.60	0.766	3.60	0.420	1.66	0.743	4.30	0.202
1.70	0.503	3.67	0.443	1.70	0.746	4.31	0.200
1.80	0.607	3.70	0.454	1.80	0.754	4.40	0.193
1.82	0.609	3.74	0.467	1.84	0.757	4.42	0.191
1.86	0.611	3.80	0.485	1.90	0.760	4.50	0.177
1.90	0.612	3.86	0.500	1.94	0.761	4.60	0.159
2.00	0.813	3.90	0.507	2.00	0.757	4.62	0.154
2.09	0.807	3.92	0.511	2.10	0.747	4.67	0.139
2.10	0.806	4.00	0.513	2.16	0.743	4.70	0.134
2.20	0.796	4.10	0.514	2.20	0.730	4.73	0.125
2.21	0.794	4.19	0.500	2.30	0.704	4.78	0.100
2.23	0.778	4.20	0.499	2.31	0.700	4.80	0.094
2.30	0.774	4.30	0.481	2.40	0.656	4.86	0.060
2.31	0.759	4.39	0.457	2.44	0.641	4.90	0.064
2.40	0.744	4.40	0.452	2.50	0.600	4.91	0.060
2.43	0.734	4.46	0.423	2.55	0.546	4.95	0.040
2.50	0.703	4.50	0.408	2.60	0.510	4.98	0.026
2.54	0.692	4.52	0.400	2.61	0.530	5.00	0.000
2.60	0.638	4.60	0.355	2.66	0.444		
2.64	0.600	4.62	0.343	2.70	0.400		
2.70	0.538	4.69	0.300	2.80	0.300		
2.73	0.500	4.70	0.292	2.86	0.262		
2.80	0.400	4.77	0.241	2.90	0.244		
2.90	0.266	4.80	0.214	2.93	0.236		
2.86	0.300	4.82	0.206	3.00	0.222		
2.91	0.255	4.87	0.142	3.06	0.219		
2.95	0.236	4.90	0.116	3.10	0.219		
3.00	0.226	4.92	0.100	3.20	0.219		
3.07	0.223	4.96	0.045	3.30	0.219		
3.10	0.224	5.00	0.000	3.40	0.219		




FIGURE 10-6. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).




FIGURE 10-7. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE).

TABLE 10-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T29570	Folwiler, R.C.	1964	1-5	293	Pyroceram Glass 9606	Specimen dimensions 0.125 by 0.5 by 1.5 in.; $\theta=0^\circ$, $\theta'=0^\circ$; reported error $\pm 5\%$.	
2 T29570	Folwiler, R.C.	1964	1-5	770	Pyroceram Glass 9606	The above specimen.	
3 T29570	Folwiler, R.C.	1964	1-5	900	Pyroceram Glass 9606	The above specimen.	
4 T29570	Folwiler, R.C.	1964	1-5	1040	Pyroceram Glass 9606	The above specimen.	
5 T29570	Folwiler, R.C.	1964	1-5	293	Pyroceram Glass 9606	Similar to the above specimen except measurement temperature specified as room temperature, 293 K assigned, author reports transmissivity, uncorrected for surface reflectance, and data from figure.	
6 T29570	Folwiler, R.C.	1964	1-5	770	Pyroceram Glass 9606	The above specimen.	
7 T29570	Folwiler, R.C.	1964	1-5	900	Pyroceram Glass 9606	The above specimen.	
8 T29570	Folwiler, R.C.	1964	1-5	1040	Pyroceram Glass 9606	The above specimen.	
9 T29570	Folwiler, R.C.	1964	1-5	293	Corning 9608	Specimen dimensions 0.125 by 0.5 by 1.5 in.; uncorrected for surface reflectance; measurement temperature specified as room temperature, 293 K assigned; data from figure; $\theta=0^\circ$, $\theta'=0^\circ$; reported error $\pm 5\%$.	
10 T29570	Folwiler, R.C.	1964	1-5	784	Corning 9608	The above specimen.	
11 T29570	Folwiler, R.C.	1964	1-5	919	Corning 9608	The above specimen.	
12 T29570	Folwiler, R.C.	1964	1-5	1070	Corning 9608	The above specimen.	
13 T29570	Folwiler, R.C.	1964	1-5	1182	Corning 9608	The above specimen.	
14 T31344	Kroeckel, O.	1964	0.77-3.3	293	Pyroceramic Material	Contains crystallites of about 0.5 μm diameter; little change in curve noted at 1173 K; smooth values from figure; reported error $\pm 5\%$.	
15 T10360	Olson, O.H. and Morris, J.C.	1959	1.1-2.8	2.3	Pyroceram 9608	Integrating sphere reflectometer adopted for diffuse transmission measurements; smooth values from figure; $\theta=0^\circ$, $\omega=\pi/2$.	
16 T20771	Fiskeletz, I.S.	1958	2-16	295	Pyroceram	Smooth values from figure; $\theta=0^\circ$, $\theta'=0^\circ$.	
17 T39365	Hobbs, H.A. and Folwiler, R.C.	1966	1.0-5.0	293	Pyroceram 9606	Fully dense, no porosity; grain size optically indeterminate; thickness presumably 0.0152 cm (0.006 in.); author reports measured transmissivity; data from figure and smooth curve; $\theta=0^\circ$, $\theta'=0^\circ$, $\omega=1.5/\pi$.	
18 T39365	Hobbs, H.A. and Folwiler, R.C.	1966	1.0-5.0	293	Pyroceram 9608	Fully dense, no porosity; grain size optically indeterminate; thickness presumably 0.0152 cm (0.006 in.); author reports measured transmissivity; data from figure and smooth curve; $\theta=0^\circ$, $\theta'=0^\circ$, $\omega=1.5/\pi$.	
19 T ₇ ,J77	Troitskii, O.A. and Shmurak, S.Z.	19C3	2.1-5.0	293	Pyroceram	62 SiO ₂ , 29 Al ₂ O ₃ , 6.5 Li ₂ O, and additives containing TiO ₂ as a catalyst; vitreous structure; specimen 1.5 mm thick and 25 x 25 cm, ground and polished to obtain plane-parallel sides; measurements made on a UR-10 spectrophotometer with a precision of $\pm 10 \text{ cm}^{-1}$; smooth values from figure of infrared absorption spectra; measurement temperature not given explicitly, assumed to be 293 K; data taken to mean normal spectral transmittance; $\theta=0^\circ$.	

TABLE 10-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
20	T40977	Troitskii, O. A. and Shnurak, S. Z.	1966	2.1-5.0	293	Pyroceram	Similar to the above specimen except heated at 923 K for 10 hr.
21	T40977	Troitskii, O. A. and Shnurak, S. Z.	1966	2.1-5.0	293	Pyroceram	Similar to the above specimen except heated at 923 K for 10 hr and then heated at 1053 K for 0.5 hr; crystalline structure.
22	T40977	Troitskii, O. A. and Shnurak, S. Z.	1966	2.1-5.0	293	Pyroceram	Similar to the above specimen except heated at 923 K for 10 hr and then heated at 1053 K for 1 hr; crystalline structure.
23	T40977	Troitskii, O. A. and Shnurak, S. Z.	1966	2.1-5.0	293	Pyroceram	Similar to the above specimen except heated at 923 K for 10 hr and then heated at 1053 K for 7 hr; crystalline structure.

TABLE IJ-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, T]

TABLE 10-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCHROM (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T
CURVE 10 (CONT.)													
3.	0.22	2.16	0.597	2.60	0.027	4.57	0.0793	4.72	0.466	2.59	0.303		
4.	0.40	2.40	0.649	5.99	0.025	4.70	0.3797	4.79	0.427	3.13	0.400		
5.	0.0	2.56	0.671	14.6	0.024	4.84	0.0808	4.84	0.396	3.58	0.575		
CURVE 11													
$T = 919.$		2.74	0.592	14.1	0.021	4.88	0.0837	4.88	0.365	3.79	0.704		
1.	0.36	2.83	0.536	14.7	0.014	4.93	0.323	4.93	0.323	3.92	0.684		
2.	0.86	2.92	0.473	15.3	0.008	5.00	0.266	5.00	0.266	4.10	0.586		
3.	0.19	3.06	0.552	16.0	0.008	CURVE 18		CURVE 19		4.39	0.293		
4.	0.22	3.17	0.613	1.00	-	$T = 293.$		$T = 293.$		4.57	0.119		
5.	0.3	3.29	0.679	1.03	-	CURVE 17		CURVE 21		5.00	0.200		
CURVE 12													
$T = 1671.$		1.06	0.603	1.00	0.0182	1.08	0.314	2.14	0.892				
$T = 293.$		1.39	0.449	1.28	0.0200	1.14	0.356	2.24	0.897				
1.	0.56	1.54	0.110	1.46	0.0228	1.22	0.400	2.33	0.907				
2.	0.73	1.83	0.166	1.50	0.0240	1.37	0.475	2.46	0.692	2.14	0.977		
3.	0.12	1.99	0.235	1.62	0.0251	1.46	0.516	2.59	0.884	2.27	0.593		
4.	0.18	2.09	0.288	1.77	0.0262	1.55	0.543	2.75	0.639	2.42	0.509		
5.	0.3	2.15	0.352	2.00	0.0273	1.66	0.572	2.82	0.316	2.49	0.982		
CURVE 13													
$T = 1182.$		2.19	0.257	2.00	0.0273	1.85	0.628	3.10	0.391	2.73	0.591		
$T = 293.$		2.24	0.266	2.29	0.0273	2.00	0.657	3.56	0.683	2.76	0.507		
1.	0.42	2.32	0.370	2.47	0.0288	2.13	0.655	3.68	0.699	2.79	0.205		
2.	0.35	2.36	0.392	2.40	0.0288	2.45	0.655	3.60	0.694	2.84	0.157		
3.	0.37	2.40	0.380	2.57	0.0288	2.63	0.659	3.94	0.557	2.90	0.296		
4.	0.14	2.49	0.302	2.69	0.0253	2.83	0.3258	2.77	0.661	3.28	0.594		
5.	0.5	2.53	0.269	3.00	0.0249	3.00	0.667	4.13	0.463	3.42	0.735		
CURVE 14													
$T = 293.$		2.59	0.304	3.16	0.0319	3.22	0.676	4.29	0.333	3.62	0.774		
1.	0.63	2.63	0.389	3.53	0.0467	3.16	0.682	4.44	0.188	4.00	0.716		
2.	0.65	2.65	0.363	3.65	0.0523	3.50	0.688	4.69	0.071	4.10	0.693		
3.	0.67	2.67	0.273	3.80	0.0580	4.12	0.693	4.82	0.021	5.00	0.304		
4.	0.5	2.71	0.215	3.89	0.0615	4.32	0.636	4.39	0.394	4.39	0.888		
5.	0.164	2.75	0.164	4.00	0.0659	4.39	0.610	4.46	0.385	4.47	0.485		
CURVE 21													
$T = 293.$		2.74	0.592	3.16	0.0213	2.95	0.475	3.33	0.308	3.42	0.292		
1.	0.56	2.83	0.473	3.50	0.014	3.00	0.516	3.56	0.37	4.44	0.44		
2.	0.86	2.92	0.414	3.55	0.014	3.22	0.543	3.68	0.333	3.62	0.232		
3.	0.19	3.06	0.352	3.80	0.014	3.36	0.682	4.44	0.188	4.00	0.716		
4.	0.45	3.17	0.309	3.89	0.014	3.50	0.688	4.69	0.071	4.10	0.693		
5.	0.541	3.45	0.273	4.00	0.014	4.12	0.693	4.82	0.021	5.00	0.304		
CURVE 22													
$T = 293.$		2.74	0.592	3.16	0.0213	2.95	0.475	3.33	0.308	3.42	0.292		
1.	0.56	2.83	0.473	3.50	0.014	3.00	0.516	3.56	0.37	4.44	0.44		
2.	0.86	2.92	0.414	3.55	0.014	3.22	0.543	3.68	0.333	3.62	0.232		
3.	0.19	3.06	0.352	3.80	0.014	3.36	0.682	4.44	0.188	4.00	0.716		
4.	0.45	3.17	0.309	3.89	0.014	3.50	0.688	4.69	0.071	4.10	0.693		
5.	0.541	3.45	0.273	4.00	0.014	4.12	0.693	4.82	0.021	5.00	0.304		

TABLE 10-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF PYROCERAM (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, T)

CURVE 22 (CONT.)

λ	T
2.47	0.877
2.56	0.990
2.63	0.857
2.75	0.399
2.80	0.162
2.82	0.154
3.34	0.659
3.46	0.738
3.64	0.759
3.85	0.738
4.00	0.668
4.44	0.147
4.65	0.026
5.00	0.003

CURVE 23
 $T = 293$.

2.14	0.907
2.38	0.923
2.43	0.895
2.58	0.958
2.62	0.859
2.73	0.445
2.76	0.146
2.80	0.152
3.18	0.632
3.32	0.748
3.46	0.803
3.69	0.785
3.89	0.733
4.02	0.604
4.08	0.491
4.24	0.299
4.39	0.113
4.59	0.041
5.00	0.003

f. Normal Spectral Transmittance (Temperature Dependence)

No experimental data sets specifically for the temperature dependence of the normal spectral transmittance of Corning 9606 were found. However, from curves 5, 6, 7, and 8 of the previous section (see Tables 10-11 and 10-12), the transmittance value at $3.80 \mu\text{m}$ is 0.485, 0.239, 0.263, and 0.219 at 293 K, 770 K, 900 K, and 1040 K, respectively.

4.11. Silica(Vitreous)

This material is labeled "Silica(Vitreous)" in the above heading so that in alphabetization this material will fall under "s". However, in this discussion the wording "vitreous silica" will be used for ease in reading.

Vitreous silica is a glass which is composed essentially of SiO_2 . The most general and unambiguous term that refers to the entire range of noncrystalline silica is vitreous silica. It is also known as fused silica, silica glass, and fused quartz. Additional information is available concerning the terminology and naming [T76945, T76946, A00026]. The two general types of vitreous silica are transparent and nontransparent. The latter arises from microscopic bubbles in the material. The emphasis in this section is to give evaluated data for the transparent type of vitreous silica.

Vitreous silica has many interesting physical properties. One source [T34753] gives a range for the melting point of 1950 to 2000 K while another source [A00017] identifies the melting point as 1996 K. It boils at 2500 K. The density is about 2.2 g cm^{-3} . One distinction for vitreous silica is that the coefficient of thermal expansion is among the lowest of all known materials. In the range of 273-573 K, the range for the linear expansion coefficient is between 5.4 and $5.6 \times 10^{-7} \text{ C}^{-1}$. At approximately 293 K, Young's modulus is 730 kbar, the shear modulus 311 kbar, and Poisson's ratio 0.17. The Knoop hardness falls in the range of $545\text{-}575 \text{ kg mm}^{-2}$.

a. Normal Spectral Emittance (Wavelength Dependence)

A total of six sets of experimental data were located for the wavelength dependence of the normal spectral emittance of vitreous silica. The data are listed in Table 11-3 and shown in Figures 11-1 and 11-2. Specimen characterization and measurement information for the data are given in Table 11-2.

Stierwalt [T16961] (curve 1) reported data for a specimen 0.84 nm thick at a temperature of 313 K. Dumbaugh and Schultz [T76945] reported calculations of Parker for a 0.50 in. thick specimen at room temperature (curve 2) and also for a 0.250 in. thick specimen (curve 3). Champetier and Friese [A00012] reported data for Optosil 1 at a temperature of 373 K for parallel polarization of the light emitted (curve 4), for perpendicular polarization (curve 5), and for unpolarized light (curve 6).

Above $5 \mu\text{m}$, all the data show the same general trend. From 5 to $6 \mu\text{m}$ the emittance is greater than 0.9. From that region the values fall, in the wavelength range of 8 to $9 \mu\text{m}$, to a minimum. From the minimum, the values rise and above $11 \mu\text{m}$ the

values are greater than 0.85. In addition, above 5 μm the data of curves 1 and 2 are close together. The value of the wavelength at which the minimum occurs for two groups of data is different. For curves 5 and 6 (Honeywell data), the wavelength at which the minimum occurs is 8.3 μm while for curves 1 and 2 it is 8.9 μm .

Calculations were carried out to determine the emittance for radiation that is polarized perpendicular to the plane of incidence (curves 7-9), the emittance for radiation that is polarized parallel to the plane of incidence (curves 10-12), and the emittance for unpolarized radiation (curves 13-15). The calculation for emittance with radiation polarized perpendicular to the plane of incidence was carried out in the following sequence: First the Fresnel equation for specular reflection for radiation polarized perpendicular to the plane of incidence was used, Eq. (2.4-1). Kirchhoff's law was then applied and Eq. (2.4-6) used to determine the emittance for radiation polarized perpendicular to the plane of incidence. The appropriate equations were used for radiation polarized parallel to the plane of incidence (see Eqs. (2.4-2) and (2.4-7)) and for unpolarized radiation (see Eqs. (2.4-5) and (2.4-8)).

The calculations of the emittance, or absorptance, using Eqs. (2.4-6) through (2.4-8) are based on the fact the material is opaque, i.e., the transmittance is zero. Champetier and Friese [A00012] reported transmittance for a 1 mm thick specimen of Optosil 1 at 293 K from 3.7 to 16 μm and found it to be opaque (see curve 38, Table 11-23). Hence, direct evidence exists for opaqueness to 16 μm and, therefore, calculations were not carried out past 16 μm .

The Fresnel equations are functions of the index of refraction n and the absorption index k as well as the angle of incidence θ . The index of refraction of vitreous silica is shown in Figure 11-3 and listed in Table 11-5. Specimen characterization and measurement information for the data of the index of refraction are given in Table 11-4. The absorption index of vitreous silica is shown in Figure 11-4 and listed in Table 11-7. Specimen characterization and measurement information for the data of absorption index are given in Table 11-6. Table 11-5 lists four places below the decimal point for wavelength values and five places below the decimal point for index of refraction values. If original data was given to more decimal places, the computer program generating Table 11-5 truncated and dropped the additional digits. The original data of curve 2 was given for up to five places below the decimal point for wavelength values and the original data for wavelength values of curves 1, 3-7, and 12 was given for up to six places below the decimal point. The original data for index of refraction of curves 3-7 was given for six places below the decimal point. The index of refraction and the absorption index values

used in the calculations were taken from Champetier and Friese [A00012, p. 61]. The index of refraction from Champetier and Friese is curve 11 in Figure 11-3 and in Tables 11-4 and 11-5; the absorption index is curve 3 in Figure 11-4 and Tables 11-6 and 11-7. The Champetier and Friese data is for a wavelength range of 7 to 26 μm , a temperature of 293 K, and is based on data in the literature. Below 9 μm it is based on the data of Zolotorev [T60820] and above 9 μm it is based on the data of Popova, Tolstykh, and Vorobev [E64849].


The calculations using the Fresnel equations were programmed and carried out for all wavelengths from 7 to 16 μm for which refractive index and absorption index data were given by Champetier and Friese. The calculations are valid for an optically smooth surface of vitreous silica, a temperature of 293 K, and a wavelength range of 7 to 16 μm . The lower range of the calculations were 7 μm since the data of the index of refraction and absorption index needed in the Fresnel equations only started at 7 μm . Optically smooth means the surface is "smooth in comparison with the wavelength of the incident radiation so that specular reflections result" [p. 111, T52053].

Because of the comment made in [A00012] questioning the validity of the data reported as curves 4, 5, and 6, this data was disregarded in developing evaluated values. A set of provisional values for vitreous silica at 293 K is listed in Table 11-1 and shown in Figure 11-1. Below 7 μm the provisional values are based on curve 2 and, therefore, apply to a 0.50 in. thick specimen of Corning 7940 vitreous silica. From 7 to 16 μm , the provisional values were calculated for unpolarized radiation. The calculated provisional values hold for an optically smooth specimen at 293 K that is opaque and has a viewing angle of 0°.

Because of the index of refraction and absorption index data are not themselves fully evaluated, the calculated emittance is called provisional. Below 7 μm the values for Corning 7940 do not have supporting evidence and it is only justified in labeling them provisional. Another reason for calling the calculated values above 7 μm provisional is that these values are close to curve 2 but do differ. An uncertainty of within 30% is therefore assigned to the provisional values. The provisional value at 10.6 μm of the normal spectral emittance at 293 K is 0.89. It is noted that high temperature normal spectral emittance data was not located.

TABLE II-1. PROVISIONAL NOFIAL SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ]

λ	ϵ	CORNING 7940 1.27CM THICK $T = 293$ (CONT.)			OPTICALLY SMOOTH $T = 293$			OPTICALLY SMOOTH $T = 293$ (CONT.)		
		λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ
2.14	0.026	4.49	0.970	7.00	0.999	10.4	0.955			
2.32	0.042	4.55	0.976	7.10	1.000	10.6	0.887			
2.42	0.062	4.66	0.980	7.20	1.000	10.8	0.889			
2.50	0.083	4.81	0.973	7.30	1.000	11.0	0.897			
2.52	0.131	4.99	0.973	7.40	1.000	11.2	0.902			
2.52	0.252	5.00	0.974	7.50	0.999	11.4	0.909			
2.50	0.498	5.27	0.779	7.60	0.997	11.6	0.915			
2.51	0.439	5.56	0.986	7.70	0.990	11.8	0.923			
2.54	0.473	5.77	0.986	7.80	0.980	12.0	0.923			
2.58	0.568	5.88	0.986	7.90	0.949	12.2	0.917			
2.58	0.643	6.00	0.986	8.00	0.865	12.4	0.901			
2.58	0.682	6.18	0.969	8.10	0.732	12.6	0.894			
2.58	0.762	6.40	0.993	8.20	0.686	12.8	0.881			
2.63	0.914	6.62	0.994	8.30	0.694	13.0	0.890			
2.62	0.957	6.78	0.993	8.40	0.664	13.2	0.896			
2.68	0.970	6.90	0.993	8.50	0.632	13.4	0.903			
2.76	0.957			8.60	0.578	13.6	0.911			
2.81	0.889			8.65	0.539	13.8	0.919			
2.81	0.687			8.70	0.475	14.0	0.923			
2.85	0.623			8.75	0.433	14.2	0.926			
2.95	0.524			8.80	0.368	14.4	0.857			
3.00	0.450			8.85	0.321	14.6	0.935			
3.03	0.395			8.90	0.298	14.8	0.960			
3.03	0.313			8.95	0.281					
3.09	0.299			9.00	0.330					
3.22	0.302			9.05	0.382					
3.39	0.315			9.10	0.535					
3.50	0.332			9.15	0.470					
3.57	0.410			9.20	0.526					
3.61	0.471			9.30	0.547					
3.67	0.547			9.35	0.584					
3.74	0.642			9.40	0.685					
3.80	0.699			9.50	0.657					
3.88	0.903			9.60	0.687					
3.95	0.990			9.70	0.716					
4.00	0.907			9.80	0.746					
4.05	0.927			9.90	0.771					
4.21	0.952			10.1	0.795					
4.37	0.965			10.2	0.834					






FIGURE 11-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICA(VITREOUS).
(WAVELENGTH DEPENDENCE).

TABLE II-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICA(VITREOUS) (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T16661	Stierwalt, D.L.	1961	3.0-14	313	Fused quartz	Plate 0.84 mm thick; measured in vacuum; smooth values from figure; spectral emissivity reported; $\theta' \sim 6^\circ$.
2 T76945	Dumbaugh, W.H. and Schultz, P.C.	1969	2.1-25	293	Corning Code 7940 vitreous silica	Specimen 0.50 in. thick; emissivity calculated by C. J. Parker from room temperature (293 K assigned) measurements of transmittance and reflectance.
3 T76945	Dumbaugh, W.H. and Schultz, F.C.	1969	2.1-25	293	Corning Code 7940 vitreous silica	Similar to the above specimen except specimen 0.250 in. thick.
4 A60012	Champetier, R.J. and Friese, G.J.	1974	3.8-7.5	373	Optoell 1	Specimen thickness 0.125 in.; polished disk; Honeywell spectral emittance used which includes a Leiss double prism monochromator with prisms of p-titanium or cesium bromide; computed system band width 0.19 μm ; optics, chopper, and enclosure near 300 K while sample and black body reference are heated to 373 K; polarization of monochromator which is present has not been removed from data; 0° data taken but not reported, the 0° and 12° data were identical; emittance data for parallel polarization; a conclusion in this report [A60012] is that "Honeywell emittance currently produces incorrect data at angles greater than 40 degrees and previously generated data cannot be used with confidence in their validity"; smooth values from figure; because of overlap of curves, data could not be extracted for full wavelength range for which data reported; $\theta' = 12^\circ$.
5 A60012	Champetier, R.J. and Friese, G.J.	1974	4.3-24	373	Optoell 1	Similar to the above specimen except for perpendicular polarization.
6 A60012	Champetier, R.J. and Friese, G.J.	1974	3.9-20	373	Optoell 1	Similar to the above specimen except for unpolarized light.
7 A60012		1975	7.0-16	293		Calculations for fused silica performed for a homogeneous, smooth surface and for perpendicular component of radiation, equations (2.4-6), (2.4-1), (2.4-3), and (2.4-4); data for index of refraction, n_s , and absorption index, k_s from [A60012]; $\theta' = 0^\circ$.
8 A60012		1975	7.0-16	293		Similar to the above specimen except $\theta' = 5^\circ$.
9 A60012		1975	7.0-16	293		Similar to the above specimen except $\theta' = 10^\circ$.
10 A60012		1975	7.0-16	293		Similar to the above specimen except for parallel component of radiation, equation (2.4-7), and $\theta' = 0^\circ$.
11 A60012		1975	7.0-16	293		Similar to the above specimen except $\theta' = 5^\circ$.
12 A60012		1975	7.0-16	293		Similar to the above specimen except $\theta' = 10^\circ$.
13 A60012		1975	7.0-16	293		Similar to the above specimen except for unpolarized radiation, equation (2.4-6), and $\theta' = 0^\circ$.
14 A60012		1975	7.0-16	293		Similar to the above specimen except $\theta' = 5^\circ$.
15 A60012		1975	7.0-16	293		Similar to the above specimen except $\theta' = 10^\circ$.

TABLE 11-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICA GLASS CURVES (WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	CURVE 1 $T = 313^\circ$	λ	ϵ	CURVE 2 (CONT.)	λ	ϵ	CURVE 2 (CONT.)	λ	ϵ	CURVE 3 (CONT.)	λ	ϵ	CURVE 3 (CONT.)
2.50	0.071	2.50	0.062	2.50	0.90	2.97	0.90	16.77	0.982	2.54	0.473	0.61	0.728	
2.50	0.054	2.50	0.762	2.50	1.14	0.997	1.14	17.24	0.987	2.58	0.566	0.12	0.681	
2.63	0.114	2.63	0.514	2.63	7.36	1.997	7.36	17.55	0.385	2.58	0.643	0.26	0.638	
2.62	0.227	2.62	0.957	2.62	7.49	0.992	7.49	18.37	0.955	2.58	0.652	0.39	0.600	
2.60	0.97	2.60	0.970	2.60	7.29	0.970	7.29	19.66	0.990	2.97	0.651	0.539	0.539	
2.76	0.398	2.76	0.957	2.76	7.71	0.926	7.71	18.89	0.997	2.75	0.289	0.62	0.496	
2.81	0.517	2.81	0.669	2.81	6.01	0.722	6.01	19.14	0.386	2.77	0.513	0.62	0.449	
2.81	0.801	2.81	0.667	2.81	6.12	0.681	6.12	19.29	0.965	2.82	0.403	0.68	0.430	
2.85	0.956	2.85	0.623	2.85	6.29	0.636	6.29	19.47	0.937	2.87	0.299	0.75	0.393	
2.95	0.986	2.95	0.524	2.95	6.39	0.600	6.39	19.55	0.905	2.87	0.240	0.78	0.361	
3.03	0.999	3.03	0.395	3.03	6.55	0.539	6.55	19.61	0.670	2.92	0.211	0.78	0.313	
6.64	0.999	3.03	0.313	3.03	6.62	0.496	6.62	19.76	0.825	3.10	0.162	0.86	0.298	
7.56	0.990	3.09	0.299	3.09	6.52	0.449	6.52	19.92	0.734	3.44	0.203	0.94	0.269	
7.90	0.909	3.22	0.302	3.22	6.68	0.430	6.68	20.48	0.485	3.60	0.243	0.66	0.313	
8.10	0.756	3.39	0.315	3.39	7.75	0.393	7.75	20.55	0.467	3.74	0.322	0.15	0.429	
8.41	0.684	3.50	0.322	3.50	8.75	0.361	8.75	20.66	0.451	3.80	0.377	0.23	0.493	
8.54	0.596	3.57	0.410	3.57	9.78	0.313	9.78	20.80	0.444	3.86	0.401	0.51	0.649	
8.84	0.374	3.61	0.471	3.61	10.66	0.296	10.66	21.00	0.453	3.90	0.569	0.80	0.758	
9.17	0.603	3.67	0.547	3.67	11.94	0.269	11.94	21.16	0.486	3.97	0.572	1.18	0.838	
9.67	0.803	3.74	0.642	3.74	12.06	0.313	12.06	21.74	0.586	4.09	0.762	10.60	0.886	
10.2	0.905	3.80	0.399	3.80	12.42	0.429	12.42	21.99	0.623	4.22	0.869	10.65	0.904	
11.0	0.973	3.88	0.603	3.88	12.23	0.493	12.23	22.39	0.670	4.53	0.970	11.41	0.921	
12.0	0.999	3.95	0.690	3.95	13.51	0.645	13.51	22.79	0.704	4.66	0.974	11.60	0.936	
13.0	1.00	4.05	0.927	4.05	14.00	0.756	14.00	23.21	0.728	4.81	0.973	11.99	0.956	
14.0	1.00	4.21	0.952	4.21	15.18	0.835	15.18	23.74	0.751	4.99	0.973	12.11	0.956	
		4.37	0.965	4.37	16.60	0.886	16.60	24.35	0.775	5.27	0.979	12.27	0.937	
		4.49	0.970	4.49	17.05	0.904	17.05	24.91	0.801	5.56	0.986	12.47	0.925	
		4.55	0.970	4.55	11.41	0.921	11.41			5.77	0.986	12.71	0.922	
		4.66	0.974	4.66	11.68	0.936	11.68			5.88	0.986	13.21	0.922	
		4.81	0.973	4.81	11.99	0.956	11.99			6.00	0.986	13.69	0.940	
		4.99	0.973	4.99	12.11	0.956	12.11			6.16	0.989	14.61	0.961	
		5.27	0.979	5.27	12.27	0.937	12.27			6.40	0.993	15.59	0.974	
		5.56	0.986	5.56	12.47	0.925	12.47			6.62	0.994	16.69	0.977	
		5.77	0.996	5.77	12.71	0.922	12.71			6.78	0.993	16.49	0.977	
		5.86	0.996	5.86	13.21	0.922	13.21			6.90	0.993	16.77	0.982	
		6.00	0.996	6.00	13.89	0.940	13.89			7.14	0.997	17.24	0.987	
		6.16	0.993	6.16	14.61	0.961	14.61			7.36	0.997	17.55	0.985	
		6.40	0.993	6.40	15.39	0.974	15.39			7.49	0.992	18.37	0.985	
		6.62	0.994	6.62	16.50	0.977	16.50			7.59	0.976	18.66	0.990	
		6.76	0.993	6.76	16.49	0.977	16.49			7.71	0.926	18.89	0.997	

CURVE 3
 $T = 293^\circ$ CURVE 2
 $T = 293^\circ$

TABLE 11-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICA(WITTEOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ ; μm ; TEMPERATURE, T ; κ : EMITTANCE, ϵ]

λ	ϵ	CURVE 3 (CONT.)	λ	ϵ	CURVE 4 (CONT.)	λ	ϵ	CURVE 5 (CONT.)	λ	ϵ	CURVE 6 (CONT.)	λ	ϵ	CURVE 6 (CONT.)
19.14	0.988	7.36	0.810	10.60	0.650	21.71	0.477	7.94	0.585	20.00	0.656			
19.29	0.965	7.36	0.789	10.82	0.676	21.83	0.483	8.29	0.556					
19.47	0.937	7.50	0.754	11.01	0.696	21.99	0.530	8.42	0.564					
19.55	0.905			11.49	0.690	22.35	0.536	8.73	0.630					
19.63	0.870			12.24	0.676	22.53	0.565	9.08	0.682					
19.76	0.825			12.63	0.676	22.60	0.593	9.48	0.782	7.00	0.99940			
19.92	0.738			12.86	0.683	22.76	0.593	9.80	0.826	7.10	0.99960			
20.48	0.485	4.26	1.000	13.25	0.887	22.88	0.604	10.21	0.871	7.20	0.9999			
20.55	0.467	4.37	0.982	13.49	0.895	22.88	0.615	10.47	0.886	7.30	0.9999			
20.66	0.451	4.54	0.967	13.61	0.895	23.03	0.623	10.60	0.889	7.40	0.9995			
20.80	0.444	4.54	0.956	14.36	0.903	23.15	0.656	10.95	0.904	7.50	0.9985			
21.00	0.453	4.65	0.942	14.58	0.916	23.28	0.661	11.28	0.915	7.60	0.9969			
21.16	0.466	5.14	0.939	14.85	0.926	23.28	0.666	11.98	0.915	7.70	0.9904			
21.74	0.586	5.30	0.932	15.31	0.923	23.44	0.576	12.13	0.908	7.20	0.9796			
21.99	0.623	5.58	0.941	15.60	0.928	23.51	0.659	12.32	0.895	7.90	0.9489			
22.36	0.670	6.00	0.941	15.72	0.922	23.65	0.662	12.61	0.895	8.00	0.8649			
22.79	0.704	6.19	0.947	15.91	0.933	23.79	0.674	13.08	0.904	8.13	0.7319			
23.21	0.728	6.45	0.939	16.37	0.928	23.93	0.666	13.31	0.914	8.20	0.6863			
23.74	0.751	6.58	0.918	16.54	0.932	24.03	0.689	13.60	0.914	8.30	0.6936			
24.35	0.775	6.77	0.896	15.91	0.932			13.94	0.924	8.40	0.6640			
24.91	0.801	6.77	0.879	17.10	0.936			14.10	0.916	8.50	0.6318			
		6.99	0.642	17.27	0.942			14.26	0.920	8.60	0.5784			
		7.20	0.787	17.43	0.935			14.44	0.932	8.65	0.5387			
		7.65	0.640	18.06	0.937			14.44	0.932	8.65	0.4793			
3.60	0.955	7.67	0.614	18.14	0.950	3.96	0.956	14.56	0.926	8.75	0.4334			
4.09	0.936	7.80	0.605	18.35	0.956	4.21	0.962	14.76	0.935	8.80	0.3675			
4.38	0.943	7.91	0.570	18.57	0.944	4.34	0.959	14.95	0.931	8.85	0.3206			
4.96	0.945	8.06	0.535	18.86	0.951	4.65	0.967	15.67	0.947	8.90	0.2982			
5.11	0.961	8.31	0.509	19.03	0.945	5.08	0.965	16.85	0.955	8.95	0.2813			
5.42	0.948	8.47	0.509	19.29	0.945	5.41	0.932	17.06	0.948	9.00	0.3296			
5.90	0.948	8.51	0.524	19.69	0.904	5.46	0.944	17.37	0.954	9.05	0.3824			
6.15	0.955	8.79	0.561	19.83	0.869	6.05	0.953	17.69	0.954	9.10	0.5351			
6.32	0.955	8.94	0.617	20.15	0.762	6.47	0.951	18.50	0.966	9.15	0.4699			
6.51	0.943	9.16	0.664	20.19	0.666	6.71	0.922	18.85	0.967	9.20	0.5256			
6.73	0.929	9.45	0.736	20.66	0.540	6.91	0.895	18.99	0.962	9.30	0.5473			
6.83	0.911	9.76	0.784	20.87	0.475	7.29	0.803	19.20	0.940	9.35	0.5836			
6.92	0.893	9.96	0.819	21.13	0.436	7.60	0.713	19.50	0.931	9.40	0.6894			
7.07	0.883	9.96	0.824	21.32	0.418	7.60	0.686	19.60	0.906	9.50	0.6567			
7.22	0.847	10.20	0.642	21.45	0.421	7.94	0.593	19.82	0.971	9.70	0.7159			

CURVE 4
 $T = 373^\circ$.
 $T = 373^\circ$.

CURVE 5
 $T = 373^\circ$.

CURVE 6
 $T = 373^\circ$.

TABLE II-3. EXPERIMENTAL NORMAL SPECTRAL EXTINCTION OF SILICA (VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EXTINCTION, ϵ)

λ	ϵ	CURVE 7 (CONT.)	λ	ϵ	CURVE 8 (CONT.)	λ	ϵ	CURVE 9 (CONT.)	λ	ϵ	CURVE 10 (CONT.)	λ	ϵ	CURVE 10 (CONT.)
9.00	0.7479	7.90	9.477	12.4	9.926	8.95	0.2769	10.4	0.8548	10.4	0.8548	10.6	0.8874	10.6
9.90	0.7705	8.00	0.2615	12.0	0.8929	9.00	2.1249	10.6	0.8874	10.6	0.8874	10.6	0.8886	10.6
10.0	0.7950	8.10	0.7269	12.0	0.8903	9.05	0.3775	10.6	0.8886	10.6	0.8886	10.6	0.8971	11.0
10.2	0.8335	8.20	0.6824	13.0	0.8991	9.10	0.5293	11.0	0.8971	11.0	0.8971	11.0	0.9023	11.2
10.4	0.8548	8.30	0.6902	13.2	0.8974	9.15	1.46-5	11.2	0.9023	11.2	0.9023	11.2	0.9085	11.4
10.6	0.8874	8.40	0.6611	13.4	0.9023	9.20	0.7200	11.4	0.9085	11.4	0.9085	11.4	0.9152	11.6
10.8	0.8896	8.50	0.6291	13.6	0.9105	9.30	0.5416	11.6	0.9152	11.6	0.9152	11.6	0.9225	11.8
11.0	0.8971	8.60	0.5760	13.8	0.9163	9.35	0.5779	11.8	0.9225	11.8	0.9225	11.8	0.9225	12.0
11.2	0.9023	8.65	0.5363	14.0	0.9227	9.40	0.6838	12.0	0.9229	12.0	0.9229	12.0	0.9229	12.0
11.4	0.9085	8.70	0.4772	14.2	1.9271	9.50	0.6511	12.2	0.9172	12.2	0.9172	12.2	0.9172	12.4
11.6	0.9152	8.75	0.4315	14.4	0.8557	9.60	0.6816	12.4	0.9034	12.4	0.9034	12.4	0.9034	12.6
11.8	0.9225	8.80	0.3659	14.6	0.9342	9.70	0.7105	12.6	0.8937	12.6	0.8937	12.6	0.8937	12.8
12.0	0.9229	8.85	0.3192	15.0	0.9598	9.80	0.7428	12.8	0.7319	12.8	0.7319	12.8	0.7319	13.0
12.2	0.9172	8.90	0.2969	9.90	1.99	10.0	0.7655	13.0	0.6963	13.0	0.6963	13.0	0.6963	13.2
12.4	0.3034	8.95	0.2802	10.2	0.7902	10.0	0.8232	13.2	0.6936	13.2	0.6936	13.2	0.6936	13.4
12.6	0.6937	9.00	0.3284	10.4	0.8232	10.2	0.40	13.4	0.6640	13.4	0.6640	13.4	0.6640	13.6
12.8	0.8814	9.05	0.3812	10.4	0.8520	10.4	0.50	13.6	0.6319	13.6	0.6319	13.6	0.6319	13.8
13.0	0.8899	9.10	0.5336	7.00	0.9993	10.6	0.80- C	13.8	0.5784	13.8	0.5784	13.8	0.5784	14.0
13.2	0.8982	9.15	0.4696	7.10	0.9995	10.8	0.48- C	14.0	0.5347	14.0	0.5347	14.0	0.5347	14.2
13.4	0.9030	9.20	0.5242	7.20	0.9998	11.0	0.8938	14.2	0.4793	14.2	0.4793	14.2	0.4793	14.4
13.6	0.9113	9.30	0.5459	7.30	0.9999	11.2	0.8992	14.4	0.4334	14.4	0.4334	14.4	0.4334	14.6
13.8	0.9190	9.35	0.5122	7.40	0.9995	11.4	0.3054	14.6	0.3675	14.6	0.3675	14.6	0.3675	14.8
14.0	0.9234	9.40	0.6860	7.50	0.9994	11.6	0.9123	14.8	0.3206	14.8	0.3206	14.8	0.3206	15.0
14.2	0.9277	9.50	0.6553	7.60	0.9986	11.8	0.9197	15.0	0.2962	15.0	0.2962	15.0	0.2962	15.2
14.4	0.8507	9.60	0.6056	7.70	0.9897	12.0	0.9201	15.2	0.2613	15.2	0.2613	15.2	0.2613	15.4
14.6	0.9346	9.70	0.7146	7.80	0.9773	12.2	0.9144	15.4	0.3296	15.4	0.3296	15.4	0.3296	15.6
16.0	0.9602	9.80	0.7466	7.90	0.9439	12.4	0.9002	16.0	0.3824	16.0	0.3824	16.0	0.3824	16.2
16.0	0.9602	9.80	0.7632	9.00	0.8510	12.6	1.8903	16.2	0.5351	16.2	0.5351	16.2	0.5351	16.4
17.0	0.7938	9.10	0.7112	12.6	0.8776	9.15	0.4699	16.4	0.4699	16.4	0.4699	16.4	0.4699	16.6
17.2	0.6324	9.20	0.6705	13.0	0.8865	9.20	0.5256	16.6	0.5256	16.6	0.5256	16.6	0.5256	16.8
17.4	0.8538	9.30	0.6850	13.2	0.8950	9.30	0.5473	16.8	0.5473	16.8	0.5473	16.8	0.5473	17.0
17.6	0.9994	9.40	0.8866	9.40	0.6527	13.4	0.8999	17.0	0.5836	17.0	0.5836	17.0	0.5836	17.2
17.8	0.9996	9.50	0.8678	9.50	0.6212	13.6	0.9083	17.2	0.6894	17.2	0.6894	17.2	0.6894	17.4
18.0	0.9998	9.60	0.8963	9.60	0.5686	13.8	0.9162	17.4	0.6567	17.4	0.6567	17.4	0.6567	17.6
18.2	0.9999	9.70	0.9015	9.65	0.5295	14.0	0.9207	17.6	0.6871	17.6	0.6871	17.6	0.6871	17.8
18.4	0.9995	9.80	0.9077	9.70	0.4713	14.2	0.9251	17.8	0.7159	17.8	0.7159	17.8	0.7159	18.0
18.6	0.9985	9.90	0.9145	9.75	0.4259	14.4	0.8525	18.0	0.7479	18.0	0.7479	18.0	0.7479	18.2
18.8	0.9968	10.0	0.9219	9.80	0.3613	14.6	0.9324	18.2	0.7705	18.2	0.7705	18.2	0.7705	18.4
19.0	0.9968	10.0	0.9222	9.85	0.3150	14.8	0.9586	18.4	0.7950	18.4	0.7950	18.4	0.7950	18.6
19.2	0.9972	10.2	0.9165	9.90	1.2931	15.0	0.6335	18.6	0.6902	18.6	0.6902	18.6	0.6902	18.8

TABLE II-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICA (VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)
(WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	CURVE 11 (CONT.)			CURVE 11 (CONT.)			CURVE 12 (CONT.)			CURVE 13 (CONT.)			CURVE 13 (CONT.)			CURVE 14 (CONT.)		
0.30	0.6970	13.2	0.8990	9.15	0.4753	7.19	0.9936	10.8	0.8866	10.8	0.50	0.6318							
0.40	0.6668	13.4	0.9039	9.20	0.5312	7.20	0.9999	11.0	0.8971	11.0	0.60	0.5784							
0.50	0.6344	13.6	0.9120	9.30	0.5529	7.30	0.9999	11.2	0.9023	11.2	0.65	0.5386							
0.60	0.5609	13.8	0.9197	9.35	0.5894	7.40	0.9995	11.4	0.9085	11.4	0.70	0.4793							
0.65	0.5439	14.0	0.9241	9.40	0.6949	7.50	0.9985	11.6	0.9152	11.6	0.75	0.4334							
0.70	0.4814	14.2	0.9283	9.50	0.6623	7.60	0.9969	11.8	0.9225	11.8	0.80	0.3675							
0.75	0.4353	14.4	0.8577	9.60	0.6926	7.70	0.9944	12.0	0.9229	12.0	0.85	0.3205							
0.80	0.3692	14.6	0.9354	9.70	0.7212	7.80	0.9796	12.2	0.9172	12.2	0.90	0.2982							
0.85	0.3220	16.0	0.9606	9.80	1.7531	7.90	1.9489	12.4	0.9034	12.4	0.95	0.2813							
0.90	0.2994	3.90			0.7754	8.00	1.8649	12.6	0.8937	12.6	0.90	0.3296							
0.95	0.2824				10.0	0.7997	8.10	0.7319	12.8	0.8814	12.8	0.95	0.3824						
0.00	0.3307				10.2	0.8379	8.20	0.6863	13.0	0.8899	13.0	0.10	0.5351						
9.05	0.3637				10.4	0.6559	8.30	0.6936	13.2	0.8962	13.2	0.4699							
9.10	0.5365	7.00	0.9994	10.6	0.8909	8.40	0.6640	13.4	0.9030	13.4	0.20	0.5256							
9.15	0.4713	7.10	0.9996	10.8	0.8920	8.50	0.6318	13.6	0.9113	13.6	0.30	0.5473							
9.20	0.5270	7.20	0.9999	11.0	0.9004	8.60	0.5784	13.8	0.9190	13.8	0.35	0.5036							
9.30	0.5437	7.30	0.9999	11.2	0.9055	8.65	0.5387	14.0	0.9234	14.0	0.40	0.6894							
9.35	0.5051	7.40	0.9995	11.4	0.9115	8.70	0.4793	14.2	0.9277	14.2	0.50	0.6567							
9.40	0.6908	7.50	0.9986	11.6	0.9181	8.75	0.4334	14.4	0.8567	14.4	0.60	0.6871							
9.50	0.6581	7.60	0.9971	11.8	0.9251	8.80	0.3675	14.6	0.3348	14.6	0.70	0.7159							
9.60	0.6885	7.70	0.9911	12.0	0.9256	8.85	0.3206	15.0	0.9602	15.0	0.80	0.7479							
9.70	0.7172	7.80	0.9813	12.2	0.9201	8.90	0.2982	15.0	0.7705	15.0	0.90								
9.80	0.7492	7.90	0.9536	12.4	0.9066	8.95	0.2813	15.0	0.7950	15.0	0.70								
9.90	0.7717	8.00	0.8777	12.6	0.8970	9.00	0.3296	15.2	0.9335	15.2	0.20								
10.0	0.7961	8.10	0.7503	12.8	0.8949	9.05	0.3824	15.4	0.8546	15.4	0.40								
10.2	0.6346	8.20	0.7005	13.5	0.6937	9.10	0.5351	17.0	0.9994	17.0	0.60	0.8874							
10.4	0.6556	8.30	0.7062	13.2	0.9014	9.15	0.4699	17.0	0.9996	17.0	0.80	0.8886							
10.6	0.5803	8.40	0.6747	13.4	0.9062	9.20	0.5256	17.2	0.9999	17.2	0.60	0.6971							
10.8	0.6895	8.50	0.6419	13.6	0.9142	9.30	0.5473	17.30	0.9999	17.30	0.70	0.9023							
11.0	0.8979	8.60	0.5876	13.6	0.9216	9.35	0.5836	17.40	0.9995	17.40	0.80	0.9085							
11.2	0.9031	8.65	0.5475	14.0	0.9261	9.40	0.6894	17.50	0.9985	17.50	0.90	0.9152							
11.4	0.9092	8.70	0.4874	14.2	0.9302	9.50	0.6567	17.60	0.9969	17.60	0.90	0.9225							
11.6	0.9159	8.75	0.4093	14.4	0.8609	9.60	0.6871	17.70	0.9904	17.70	0.90	0.9229							
11.8	0.9231	8.80	0.3743	14.6	0.9372	9.70	0.7159	17.80	0.9796	17.80	0.92	0.9172							
12.0	0.9235	8.85	0.3261	16.0	0.9616	9.80	0.7479	17.90	0.9469	17.90	0.94	0.9034							
12.2	0.9179	8.90	0.3032	16.0	0.9715	9.90	0.7715	18.0	0.6646	18.0	0.96	0.8937							
12.4	0.9042	8.95	0.2856	16.0	0.7950	9.10	0.7319	18.0	0.8814	18.0	0.96								
12.6	0.8945	9.00	0.3342	16.2	0.9335	9.20	0.6863	18.0	0.8839	18.0	0.96								
12.8	0.8623	9.05	0.3974	16.4	0.8548	9.30	0.6936	18.2	0.8982	18.2	0.96								
13.0	0.8807	9.10	0.5409	16.4	0.8874	9.40	0.6640	18.4	0.9030	18.4	0.96								

T = 293.

T = 293.

TABLE II-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICA(VITROUS) (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
CURVE 14 (CONT.)						CURVE 15 (CONT.)	
13.6	0.9113	9.30	0.5473	13.6	0.9190	9.35	0.5836
14.0	0.9234	9.40	0.6094	14.2	0.9277	9.50	0.6567
14.4	0.8567	9.60	0.6871	14.6	0.9346	9.70	0.7159
16.0	0.9602	9.80	0.7479			9.90	0.7704
CURVE 15						10.3	0.7949
$T = 293^\circ\text{K}$							
7.00	0.9994	10.4	0.0546	7.10	0.9996	10.6	0.0874
7.20	0.9999	10.8	0.0886	7.30	0.9999	11.0	0.0971
7.40	0.3995	11.2	0.9023	7.50	0.9985	11.4	0.9084
7.60	0.9969	11.6	0.9152	7.70	0.9904	12.0	0.9226
7.80	0.9796	12.2	0.9172	7.90	0.3686	12.4	0.9034
8.00	0.3663	12.6	0.8935	8.10	0.7317	12.8	0.6813
8.20	0.6856	13.0	0.8699	8.30	0.6931	13.2	0.8982
8.40	0.6637	13.4	0.9030	8.50	0.6316	13.6	0.9113
8.60	0.5782	13.8	0.9190	8.65	0.5385	14.0	0.9234
8.70	0.4792	14.2	0.9277	8.75	0.4334	14.4	0.8567
8.80	0.3675	14.6	0.9348	8.85	0.3206	16.0	0.9602
8.90	0.2982			8.95	0.2813		
9.00	0.3296			9.05	0.3351		
9.10	0.3624			9.15	0.4699		
9.20	0.5256						




FIGURE 11-3. EXPERIMENTAL REFRACTIVE INDEX OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).

TABLE 11-4. MEASUREMENT INFORMATION ON THE REFRACTIVE INDEX OF SILICA(VITREOUS) (Wavelength Dependence)

Car. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A00010	Thermal American Fused Quartz Company	1970	0.24-0.77	297	Spectrosil Synthetic Fused Quartz	<0.00001 Ca, <0.00001 Fe, 0.000004 Na, <0.000002 Al, <0.000001 B, <0.000004 Ca, <0.000004 K, <0.000001 P, <0.000001 Mn, <0.000002 As, <0.0000002 Cu, and 0.0000001 Sb (see Fletcher, G., and Bell, L. W., "Analysis of High- Purity Synthetic Vitreous Silicas," Physics and Chemistry of Glasses, S(5), 206- 8, 1967, [A00011]).
2 A00010	Thermal American Fused Quartz Company	1970	0.41-3.5	293	Vitreosil	99.8% SiO ₂ ; measurement temperature not given explicitly, assumed to be 293 K.
3 T76891	Corning Glass Works	1971	0.21-3.7	293	Corning Code 7940 Fused Silica	Typical analysis 0.0010-0.0100 Cl, 0.00001-0.0001 Ca, 0.00001-0.0010 Ti, 0.000005- 0.0005 Al, 0.000005-0.0005 B, 0.000035-0.0005 Zn, 0.000001-0.00001 Bi, 0.000001-0.000005 Cu, 0.000001-0.0005 Fe, 0.000001-0.00001 K, 0.000001- 0.00001 Na, 0.000001-0.00001 P, 0.000001-0.00001 V, 0.000001-0.000005 As, 0.000001-0.000003 Cr, 0.000001-0.00001 Mn, and 0.000001-0.000005 Sb; maximum total impurities other than water do not exceed 0.01, water content estimated at 0.1 or less; amorphous; made by flame hydrolysis.
4 E21758	Mallison, I.H.	1965	0.21-3.7	293	Dynasil High- Purity Synthetic Fused Silica	Material submitted for testing was from four different production runs.
5 E21758	Mallison, I.H.	1965	0.21-3.7	293	General Electric Type 151	Material submitted for testing was from four different production runs.
6 E21758	Mallison, I.H.	1965	0.21-3.7	293	Corning Code 7940 Fused Silica	Material submitted for testing was from four different production runs.
7 E21758	Mallison, I.H.	1965	0.21-3.7	293	Fused Silica	Refractive index for high-purity optical quality fused silica made by three companies determined; materials Corning 7940 fused silica, Dynasil high purity synthetic fused silica, and General Electric type 151; minimum deviation method used; data fitted to three-term Sellmeier dispersion equation $n^2 - 1 = (0.6861663 \lambda^2 / (\lambda^2 -$ $(0.000403)^2)) + (0.407946 \lambda^2 / (\lambda^2 - (0.1162414)^2)) + (0.8974794 \lambda^2 / (\lambda^2 -$ $(9.896161)^2))$ with λ in μm; average of absolute values of residuals = 10.5×10^{-6} ;
8 E64850	Crozier, D. and Donglas, R.W.	1965	7.4-14.8	293	Fused Silica	100 SiO ₂ ; blown films prepared, selected areas struck on copper wire loops and ab- sorption spectra determined on a Grubb Parsons double-beam spectrometer; thin film method of Blain and Douglass used to analyze spectra to give refractive index and absorption index; measurement temperature not given explicitly, assumed to be 293 K.
9 T60620	Zolotarev, V.M.	1970	7.1-11	293	Fused Quartz	Several overlapping methods used to determine refractive index; measurement tem- perature not explicitly given, assumed to be 293 K.
10 E64849	Popova, S.L., Tolstykh, T.S., and Vorobev, V.T.	1972	7.1-50	293	Amorphous Quartz	Total impurity content (CaCO ₃ , sodium chloride, and oxides of Al, Mg, Cu, Ca, and Fe) <0.097; SiO ₂ samples of grades KV and KI used; refractive index n and absorp- tion index k derived from reflectance spectra; measurement temperature not given explicitly, assumed to be 293 K.
11 A00012	Champetier, R.J. and Friese, G.J.	1974	7.0-26	293	Fused Silica	Refractive index values for wavelengths shorter than 9 μm based on data in [T60620] (curve 9 above), for longer wavelengths based on data in [E64849] (curve 10 above).

TABLE 11-4. MEASUREMENT INFORMATION ON THE REFRACTIVE INDEX OF SILICA(VITREOUS) (Wavelength Dependence) (continued)

Cur. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks	
12	E19326	Jerrard, H.G. and Turpin, J.	1965	0.20-0.30	291.7	Optical Quality Fused Silica, Spectrosil A	Specimen supplied by the Thermal Syndicate, Wallsend, England; light source was copper arc and wavelength values taken from table (44th edition of Handbook of Chemistry and Physics); values reported are mean values for three different experiments conducted in air; most of the deviations found in the fifth decimal place in range 0.00002 to 0.00004.	

TABLE 11-E. EXPERIMENTAL REFRACTIVE INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFRACTIVE INDEX, n)

λ	n	CURVE 1 $T = 297.$		CURVE 3 (CONT.) $T = 293.$		CURVE 4 (CONT.) $T = 293.$		CURVE 5 (CONT.) $T = 293.$		CURVE 5 (CONT.) $T = 293.$	
0.2378	1.51478	0.2267	1.52281	1.2139	1.53426	1.3622	1.44619	0.3403	1.47857	3.422	1.43882
0.2536	1.50559	0.2307	1.52035	1.2144	1.53370	1.3950	1.44564	0.3466	1.47745	3.5070	1.40566
0.2654	1.5002	0.2482	1.50839	1.2267	1.52261	1.4695	1.44496	0.3610	1.47512	3.5564	1.40415
0.2603	1.49409	0.2652	1.50030	1.2302	1.52005	1.5295	1.44427	0.3650	1.47451	3.7067	1.39938
0.2967	1.48875	0.2752	1.49592	1.2376	1.51403	1.6606	1.44265	0.4046	1.46962	4.046	1.46962
0.3023	1.48718	0.2967	1.48872	1.2393	1.51336	1.6332	1.44225	0.4678	1.46429	4.422	1.46429
0.3132	1.48434	0.3021	1.48719	1.2492	1.50839	1.7031	1.44206	0.4861	1.46313	4.738	1.53427
0.3341	1.47976	0.3341	1.47976	1.2532	1.50303	1.8110	1.44069	0.5085	1.46186	5.3377	1.53337
0.3650	1.47456	0.3466	1.47745	1.2598	1.49804	1.9700	1.43553	0.5460	1.46007	6.267	1.52228
0.4046	1.46965	0.3616	1.47512	1.2752	1.49592	2.0581	1.43721	0.5769	1.45885	7.267	1.52228
0.4358	1.46673	0.4046	1.46961	1.2803	1.49403	2.3254	1.43292	0.5790	1.45877	8.202	1.52005
0.4799	1.46354	0.4358	1.46669	1.2893	1.49101	2.4374	1.43093	0.5875	1.45846	9.278	1.51474
0.4861	1.46317	0.4678	1.46429	1.2967	1.48872	2.4639	1.41314	0.5892	1.45841	10.337	1.51337
0.5460	1.46011	0.4861	1.46313	1.3021	1.49719	2.6668	1.41253	0.6438	1.45671	11.840	1.50840
0.5875	1.45850	0.5460	1.46007	1.3302	1.49054	3.3026	1.41156	0.6562	1.45637	12.652	1.49999
0.6438	1.45674	0.5875	1.45846	1.3341	1.47976	3.422	1.40522	0.6678	1.45607	13.678	1.49805
0.6562	1.45641	0.5892	1.45640	1.3403	1.47858	3.5070	1.40565	0.7065	1.45515	14.752	1.49591
0.7682	1.45393	0.6438	1.45670	1.3466	1.47745	3.5564	1.40414	0.8521	1.45247	15.803	1.49403
0.6562	1.45637	1.3510	1.47512	1.37067	1.39937	3.7067	1.45104	0.8943	1.45104	16.293	1.49100
0.6678	1.45607	1.3650	1.47452	1.3650	1.47452	1.0139	1.45024	0.2967	1.48872	17.872	1.48872
0.7065	1.45515	1.4052	1.46561	1.4046	1.46561	1.0829	1.44941	0.3021	1.48718	18.872	1.48718
0.8521	1.45246	1.4359	1.46669	1.4359	1.46669	1.1286	1.44867	0.3302	1.48054	19.795	1.48054
0.4101	1.46973	0.8943	1.45194	1.4678	1.46429	1.3622	1.44620	0.3341	1.47975	20.795	1.47975
0.4367	1.46686	1.0829	1.44940	1.4861	1.46313	1.3950	1.44583	0.3403	1.47859	21.795	1.47859
0.4861	1.46333	1.3622	1.44619	1.5085	1.46146	1.2144	1.53370	1.4695	1.44498	22.666	1.47745
0.5269	1.46029	1.4695	1.44498	1.5463	1.46307	1.2267	1.52262	1.5295	1.44426	23.513	1.47513
0.5895	1.45866	1.6606	1.44265	1.5759	1.45884	1.2302	1.52005	1.6606	1.44265	24.550	1.47452
0.6562	1.45655	1.7091	1.44206	1.5790	1.45177	1.2378	1.51474	1.681	1.44242	25.450	1.46961
0.7103	1.45530	1.9130	1.44260	1.5875	1.45166	1.2399	1.51337	1.6932	1.44226	26.558	1.46669
1.0000	1.447	1.9700	1.43853	1.5892	1.45540	1.2482	1.50840	1.7091	1.44205	27.670	1.46429
2.0000	1.432	2.1526	1.43574	1.6438	1.45670	1.2652	1.50001	1.8130	1.44069	28.610	1.46313
3.0000	1.416	2.4374	1.43093	1.6562	1.45637	1.2698	1.49105	1.9700	1.43850	29.850	1.46186
3.5000	1.40	3.2439	1.41314	1.6678	1.45607	1.2752	1.49591	2.0581	1.43721	30.560	1.46006
3.026	1.41156	1.7065	1.45515	1.6852	1.45246	1.2803	1.49402	1.43577	1.43577	31.5769	1.45885
3.422	1.40822	1.8521	1.45246	1.6913	1.45186	1.2893	1.49101	1.44205	1.44205	32.567	1.45885
3.5564	1.40414	1.8943	1.45184	1.6967	1.45184	1.2967	1.48973	1.45184	1.45184	33.5790	1.45885
3.7067	1.39937	1.0139	1.45024	1.3021	1.46719	1.2939	1.48719	1.41314	1.45184	34.5875	1.45886
0.2138	1.53426	1.0829	1.44940	1.3302	1.46054	1.2668	1.46668	1.41253	1.45184	35.636	1.45671
0.2144	1.53370	1.0705	1.45515	1.3341	1.47452	1.2752	1.47452	1.41156	1.47452	36.652	1.45637

TABLE II-5. EXPERIMENTAL REFRACTIVE INDEX OF SILICA (VITREOUS) (WAVELLENGTH DEPENDENCE) (CONTINUED)

TABLE II-5. EXPERIMENTAL REFRACTIVE INDEX OF SILICA(VITREOUS) (WAVELLENGTH DEPENDENCE). T, K: REFRACTIVE INDEX, n

(WAVELLENGTH, λ , μm ; TEMPERATURE, T, K)

(CONTINUED)

λ	n	λ	n	λ	n	λ	n
CURVE 10 (CONT.)		CURVE 11 (CONT.)		CURVE 11 (CONT.)		CURVE 12 (CONT.)	
23.81	2.77	9.3	2.35	23.6	2.77	0.2530	1.50272
24.39	2.71	9.35	2.50	24.6	2.75	3.2599	1.50231
25.00	2.62	9.4	2.76	26.0	2.60	0.2609	1.50180
26.57	2.33	9.5	2.98			0.2618	1.50139
33.33	2.19	9.6	3.00			0.2666	1.49932
46.00	2.12	9.7	2.98			0.2689	1.49634
50.00	2.06	9.8	2.87			0.2700	1.49781
CURVE 11		3.9	2.77	0.1999	1.55337	0.2713	1.49735
T = 291.7		10.0	2.62	0.2035	1.54700	0.2718	1.49714
10.2		2.36		0.2035	1.54570	0.2745	1.49610
10.4		2.22		0.2037	1.54553	0.2769	1.49516
10.6		2.00		0.2043	1.54471	0.2824	1.49321
10.8		1.99		0.2054	1.54337	0.2937	1.49274
11.0		1.93		0.2087	1.53956	0.2877	1.49138
7.0		1.05		0.2104	1.53772	0.2961	1.48679
7.1		1.04		0.2112	1.53695		
7.2		1.02		0.2122	1.53581		
7.3		1.00		0.2125	1.53549		
7.4		0.96		0.2135	1.53447		
7.5		0.93		0.2149	1.53318		
7.6		0.90		0.2179	1.53029		
7.7		0.83		0.2189	1.52921		
7.8		0.76		0.2192	1.52899		
7.9		0.645		0.2210	1.52737		
8.0		0.50		0.2218	1.52670		
8.1		0.374		0.2242	1.52463		
8.2		0.36		0.2246	1.52427		
8.3		0.417		0.2276	1.52193		
8.4		0.45		0.2294	1.52055		
8.5		0.448		0.2336	1.51752		
8.6		0.433		0.2359	1.51521		
8.7		0.42		0.2400	1.51324		
8.8		0.39		0.2403	1.51333		
8.9		0.37		0.2424	1.51172		
9.0		0.33		0.2473	1.50846		
9.1		0.32		0.2485	1.50616		
9.2		0.32		0.2506	1.50704		
9.3		0.336		0.2529	1.50577		
9.4		0.46		0.2544	1.50500		
9.5		0.74		0.2559	1.50365		
9.6		1.14		0.2571	1.50365		
9.7		1.64					
9.8		1.95					
9.9		2.20					




FIGURE 11-4. EXPERIMENTAL ABSORPTION INDEX OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).

TABLE 11-6. MEASUREMENT INFORMATION ON THE ABSORPTION INDEX OF SILICA(VITREOUS) (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 E45777	Zolotorev, V.M.	1970	7.1-11	~293	Fused Quartz	Several overlapping methods used to determine absorption index; measurement temperature not explicitly given, assumed to be 293 K.	
2 E64849	Popova, S.I., Tolstykh, T.S., and Verobev, V.T.	1972	7.1-50	293	Amorphous Quartz	Total impurity content (CaCO_3 , sodium chloride, and oxides of Al, Mg, Cu, Ca, and Fe) < 0.007; SiO_2 samples of grades KU and K1 used; refractive index n and absorption index k derived from reflectance spectra; measurement temperature not given explicitly, assumed to be 293 K.	
3 A00012	Champetier, R.J. and Fries, G.J.	1974	7.0-26.0	293	Fused Silica	Absorption index values for wavelengths shorter than 9 μm based on data in [T608320] (curve 1 above), for longer wavelengths based on data in [E64849] (curve 2 above).	
4 E4850	Crozier, D. and Douglas, R.W.	1965	7.5-14	293	Fused Silica	100 SiO_2 ; blown films prepared, selected areas etched on copper wire loops and absorption spectra determined on a Grubb Parsons double-beam spectrometer; thin film method of Blain and Douglas used to analyze spectra to give refractive index and absorption index; measurement temperature not given explicitly, assumed to be 293 K.	

TABLE 11-7. EXPERIMENTAL ABSORPTION INDEX OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTION INDEX, k)

λ	k	CURVE 1 $T = 293$.		CURVE 2 $T = 293$.		CURVE 2 (CONT.)		CURVE 3 3 (CONT.)		CURVE 3 (CONT.)		CURVE 4 4 (CONT.)	
		λ	k	λ	k	λ	k	λ	k	λ	k	λ	k
7.143	0.914	7.143	0.012	14.29	0.008	0.0	0.2500	12.6	0.3650	0.921	2.37		
7.299	0.016	7.407	0.023	14.71	0.009	0.1	0.3950	12.8	0.3250	0.905	2.56		
7.463	0.022	7.692	0.065	15.15	0.009	0.2	0.5570	13.0	0.2500	0.050	2.63		
7.634	0.041	7.913	0.17	15.63	0.10	0.3	0.6300	13.2	0.1940	9.132	2.52		
7.692	0.055	7.937	0.29	16.13	0.13	0.4	0.7800	13.4	0.1400	9.346	1.86		
7.752	0.066	8.000	0.42	16.67	0.14	0.5	0.9600	13.6	0.1050	9.568	1.15		
7.813	0.080	8.065	0.54	17.24	0.19	0.6	2.9700	13.8	0.7820	9.852	0.51		
7.874	0.10	8.197	0.72	17.86	0.24	0.65	1.0500	14.0	0.0860	9.946	0.29		
7.937	0.15	8.333	0.87	19.32	0.32	0.7	1.1500	14.2	0.0800	10.03	0.19		
8.000	0.25	8.403	0.93	19.23	0.42	0.75	1.2400	14.4	0.0800	10.21	0.12		
8.065	0.35	8.475	1.00	20.00	0.87	0.8	1.3500	14.6	0.0800	10.46	0.06		
8.130	0.45	8.621	1.18	20.41	1.39	0.85	1.5000	16.0	0.1220	10.93	0.00		
8.197	0.55	8.772	1.52	20.83	2.16	0.9	1.6500	16.0	0.2750	11.20	0.00		
8.264	0.65	8.850	1.77	21.05	2.16	0.95	2.1000	19.0	0.3860	11.36	0.04		
8.333	0.72	8.929	2.13	21.28	2.39	0.95	2.4400	20.0	0.8700	11.56	0.12		
8.403	0.78	9.091	2.82	21.74	1.92	0.95	2.7100	20.5	1.5200	11.82	0.24		
8.475	0.82	9.174	2.60	22.22	1.52	0.91	2.3000	21.0	2.3700	12.09	0.37		
8.547	0.94	9.259	2.33	22.73	1.18	0.95	2.8100	21.5	2.1100	12.36	0.37		
8.621	1.05	9.346	2.03	23.26	0.94	0.92	2.5500	22.0	1.7200	12.61	0.29		
8.696	1.15	9.434	1.77	23.81	0.71	0.93	2.4400	23.0	1.0400	12.89	0.18		
8.772	1.30	9.524	1.43	24.39	0.54	0.95	2.2100	24.0	0.6100	13.14	0.13		
8.850	1.50	9.615	1.13	25.00	0.41	0.94	1.3700	26.0	0.2800	13.48	0.09		
8.929	1.76	9.804	0.61	26.57	0.16	0.95	1.5200	26.0	0.1500	13.99	0.09		
9.009	2.40	10.00	0.26	33.33	0.11	0.96	1.2100	26.0	0.9000	0.90	0.06		
9.091	2.58	10.20	0.19	40.60	0.05	0.97	0.9000	26.0	0.6100	0.6100			
9.174	2.60	10.42	0.14	50.00	0.03	0.98	0.4100	26.0	0.4100	0.4100			
9.259	2.35	10.60	0.123	CURVE 3 $T = 293$.		10.0	0.2804	7.634	0.03	7.485	0.03		
9.346	2.05	10.64	0.12	CURVE 3 $T = 293$.		10.2	0.1900	7.758	0.16	7.049	0.11		
9.434	1.70	10.67	0.14	CURVE 3 $T = 293$.		10.4	0.1400	7.849	0.11	7.943	0.19		
9.524	1.42	11.11	0.15	CURVE 3 $T = 293$.		7.0	0.0137	10.6	0.1210	8.065	0.31		
9.615	1.12	11.36	0.19	CURVE 3 $T = 293$.		7.1	0.0139	10.8	0.1330	8.183	0.46		
9.709	0.90	11.63	0.20	CURVE 3 $T = 293$.		7.2	0.0144	11.0	0.1430	8.306	0.61		
9.804	0.55	11.90	0.24	CURVE 3 $T = 293$.		7.3	0.0160	11.2	0.1620	8.453	0.79		
9.901	0.42	12.20	0.32	CURVE 3 $T = 293$.		7.4	0.0187	11.4	0.1900	8.532	0.95		
10.00	0.33	12.50	0.37	CURVE 3 $T = 293$.		7.5	0.0205	11.6	0.1980	8.628	1.24		
10.10	0.22	12.82	0.31	CURVE 3 $T = 293$.		7.6	0.0235	11.8	0.2210	8.696	1.45		
10.42	0.18	13.16	0.20	CURVE 3 $T = 293$.		7.7	0.0500	12.0	0.2600	8.772	1.78		
10.75	0.17	13.51	0.12	CURVE 3 $T = 293$.		7.8	0.0750	12.2	0.3200	8.857	2.13		
11.11	0.16	13.69	0.08	CURVE 3 $T = 293$.		7.9	0.1140	12.4	0.3600				

b. Angular Spectral Emittance (Wavelength Dependence)

A total of 11 sets of experimental data were located for the wavelength dependence of the angular spectral emittance of vitreous silica. The data are listed in Table 11-10 and shown in Figures 11-5 and 11-6. Specimen characterization and measurement information for the data are given in Table 11-9.

All 11 sets apply to Optosil 1 and were measured at a specimen temperature of 373 K using the Honeywell spectral emissometer. The minima in the curves are closer to 8 μm than 9 μm which was the same phenomenon observed for Honeywell data in the normal spectral emittance section.

A set of provisional values for optically smooth vitreous silica at 293 K, a viewing angle θ' of 40°, and a wavelength range of 7.0 to 16.0 μm is listed in Table 11-8 and shown in Figure 11-5. The values were calculated using Eqs. (2.4-1) to (2.4-5) and Eq. (2.4-8). Equation (2.4-8) includes Kirchhoff's law equating the emittance to the absorptance. The index of refraction and absorption index data were taken from Champetier and Friese [A00012] as mentioned in the section on the wavelength dependence of the normal spectral emittance. Because the index of refraction and absorption index data are themselves not evaluated and because good experimental data has not been located, the values for the angular spectral emittance are called provisional with an uncertainty which is thought to be within 30%.

TABLE 11-3. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T, K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ
OPTICALLY SMOOTH $\theta = 40^\circ$ $T = 293$			
7.00	0.999	10.4	0.849
7.10	0.999	13.6	0.891
7.20	1.000	13.6	0.882
7.30	1.000	11.0	0.690
7.40	0.999	11.2	0.696
7.50	0.996	11.4	0.902
7.60	0.995	11.6	0.906
7.70	0.981	11.8	0.915
7.80	0.950	12.0	0.916
7.90	0.822	12.2	0.916
8.00	0.683	12.4	0.696
8.10	0.577	12.6	0.867
8.20	0.566	12.6	0.875
8.30	0.615	13.0	0.883
8.40	0.609	13.2	0.891
8.50	0.585	13.4	0.896
8.60	0.541	13.6	0.904
8.65	0.507	13.6	0.912
8.70	0.455	14.0	0.917
8.75	0.414	14.2	0.921
8.80	0.354	14.4	0.848
8.85	0.312	14.6	0.926
8.90	0.293	16.0	0.954
8.95	0.260		
9.00	0.330		
9.05	0.384		
9.10	0.534		
9.15	0.472		
9.20	0.527		
9.30	0.548		
9.35	0.584		
9.40	0.687		
9.50	0.656		
9.60	0.686		
9.70	0.714		
9.80	0.745		
9.90	0.767		
10.0	0.791		
	0.828		

OPTICALLY SMOOTH
 $\theta = 40^\circ$
 $T = 293$ (CONT.)




FIGURE 11-5. PROVISIONAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).




FIGURE 11-6. EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).

TABLE 11-9. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A66C12	Champetier, R.J. and Friese, G.J.	1974	4.1-7.0	373	Optosil 1		Specimen thickness 0.125 in.; polished disk; Honeywell spectral emissometer used which includes a Leiss double prism monochromator with prisms of potassium or cesium bromide; computed system band width 0.19 μm; optics, chopper, and enclosure near 300 K while sample and black body reference are heated to 373 K; polarization of monochromator which is present has not been removed from data; 0° data taken but not reported, the 0° and 12° data were identical; emittance data for parallel polarization; a conclusion included in this report [A00012] is that "Honeywell emissometer currently produces incorrect data at angles greater than 40 degrees and previously generated data cannot be used with confidence in their validity"; smooth values from figure; because of overlap of curves, data could not be extracted for full wavelength range for which data reported; θ* = 30°.
2 A00012	Champetier, R.J. and Friese, G.J.	1974	3.8-7.0	373	Optosil 1		Similar to the above specimen; θ* = 40°.
3 A66012	Champetier, R.J. and Friesc, G.J.	1974	3.8-30	373	Optosil 1		Similar to the above specimen except data extracted for full wavelength range for which it is reported; θ* = 50°.
4 A00012	Champetier, R.J. and Friese, G.J.	1974	3.6-30	373	Optosil 1		Similar to the above specimen except data reported for θ* of 70° and 75°; however, it could not be extracted due to overlap of curves; θ* = 60°.
5 A00012	Champetier, R.J. and Friese, G.J.	1974	4.1-19	373	Optosil 1		Similar to the above specimen except data reported for perpendicular polarization and because of overlap of curves, data could not be extracted for full wavelength range; θ* = 30°.
6 A00012	Champetier, R.J. and Friese, G.J.	1974	3.9-19	373	Optosil 1		Similar to the above specimen; θ* = 40°.
7 A66012	Champetier, R.J. and Friese, G.J.	1974	3.7-30	373	Optosil 1		Similar to the above specimen except data extracted for full wavelength range for which it is reported; in addition, data reported for θ* of 60°, 70°, and 75°; however, it could not be extracted due to overlap of curves; θ* = 50°.
8 A00012	Champetier, R.J. and Friese, G.J.	1974	3.9-20	373	Optosil 1		Similar to the above specimen except data reported for unpolarized radiation and because of overlap of curves, data could not be extracted for the full wavelength range for which data reported; θ* = 30°.
9 A00012	Champetier, R.J. and Friese, G.J.	1974	3.5-20	373	Optosil 1		Similar to the above specimen; θ* = 40°.
10 A00012	Champetier, R.J. and Friese, G.J.	1974	3.5-30	373	Optosil 1		Similar to the above specimen except data extracted for full wavelength range for which it is reported; θ* = 50°.
11 A30012	Champetier, R.J. and Friese, G.J.	1974	3.7-30	373	Optosil 1		Similar to the above specimen except data reported for θ* of 70° and 75°; however, it could not be extracted due to the overlap of the curves; θ* = 60°.

TABLE 11-10. EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITRE CUS) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	CURVE 1 $T = 373^\circ\text{K}$		CURVE 3 (CONT.)		CURVE 3 (CONT.)		CURVE 4 (CONT.)		CURVE 4 (CONT.)	
		λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
4.10	0.936	3.89	0.826	16.93	0.619	25.86	0.598	5.79	0.176	21.90	0.135
4.23	0.930	3.96	0.827	17.41	0.587	26.36	0.548	5.94	0.161	22.08	0.144
4.45	0.938	4.13	0.827	17.71	0.595	26.49	0.519	6.21	0.180	22.53	0.156
4.69	0.945	4.33	0.837	17.94	0.612	26.63	0.512	6.44	0.166	22.76	0.149
5.15	0.940	4.65	0.813	16.15	0.631	26.86	0.526	6.76	0.137	22.95	0.153
5.65	0.934	4.76	0.784	16.35	0.631	26.86	0.547	7.15	0.121	23.14	0.153
6.05	0.939	5.10	0.740	18.66	0.621	26.79	0.590	7.32	0.112	23.36	0.158
6.39	0.932	5.32	0.712	19.06	0.623	26.96	0.621	7.55	0.112	23.67	0.146
6.79	0.914	5.37	0.697	19.74	0.574	27.26	0.646	7.91	0.123	23.89	0.148
6.83	0.911	5.58	0.686	20.04	0.557	27.49	0.648	8.36	0.143	24.03	0.142
6.92	0.893	5.63	0.669	20.17	0.535	27.71	0.643	8.68	0.162	24.25	0.149
7.00	0.889	5.78	0.656	20.27	0.514	27.82	0.628	9.33	0.164	24.45	0.147
6.33	0.932	6.11	0.649	20.49	0.501	27.82	0.610	10.04	0.156	24.67	0.207
6.62	0.932	6.20	0.620	20.49	0.467	27.98	0.598	10.52	0.152	24.86	0.215
6.62	0.932	6.57	0.593	20.71	0.425	28.13	0.620	10.60	0.151	24.85	0.243
6.86	0.930	6.50	0.577	20.85	0.398	28.28	0.645	10.69	0.148	25.03	0.224
7.00	0.928	6.44	0.530	21.05	0.391	28.42	0.651	11.64	0.151	25.29	0.198
3.80	0.945	7.02	0.500	21.30	0.398	28.63	0.644	12.14	0.158	25.58	0.187
3.87	0.918	7.33	0.446	21.56	0.441	28.98	0.541	12.55	0.154	25.58	0.169
3.99	0.905	7.67	0.402	21.90	0.477	29.13	0.545	13.79	0.157	25.88	0.164
4.15	0.913	7.78	0.391	22.24	0.486	29.13	0.575	14.20	0.137	26.06	0.149
4.28	0.913	7.99	0.402	22.60	0.544	29.22	0.581	14.47	0.137	26.24	0.115
4.44	0.888	8.69	0.501	22.70	0.553	29.39	0.706	15.08	0.162	26.62	0.122
4.54	0.888	9.48	0.599	22.98	0.547	29.46	0.716	15.44	0.174	26.76	0.146
4.63	0.895	9.66	0.611	23.39	0.590	29.69	0.722	15.83	0.174	26.83	0.197
4.68	0.906	10.12	0.611	23.54	0.590	29.76	0.716	16.55	0.162	26.95	0.214
5.05	0.901	10.47	0.618	23.65	0.583	30.00	0.677	17.46	0.141	27.01	0.236
5.36	0.926	10.60	0.618	23.65	0.569	30.39	0.706	17.91	0.152	27.16	0.224
5.63	0.920	10.85	0.618	23.83	0.565	30.65	0.715	18.44	0.158	27.59	0.170
6.02	0.920	11.35	0.610	23.98	0.576	30.80	0.777	18.63	0.133	28.39	0.163
6.21	0.910	12.65	0.626	24.19	0.571	30.99	0.777	18.88	0.179	28.50	0.167
6.32	0.894	13.20	0.626	24.43	0.555	3.63	0.406	18.83	0.148	28.00	0.187
6.53	0.861	13.68	0.619	24.66	0.563	3.80	0.386	19.07	0.139	28.07	0.194
6.79	0.821	14.28	0.598	24.86	0.651	4.04	0.331	19.42	0.139	28.20	0.185
7.00	0.786	14.47	0.580	24.94	0.704	4.23	0.301	19.65	0.133	28.39	0.163
7.04	0.807	14.71	0.570	25.04	0.715	4.49	0.287	19.93	0.133	28.50	0.167
7.33	0.861	15.00	0.580	25.24	0.705	4.68	0.256	20.37	0.112	28.64	0.151
7.55	0.823	15.35	0.623	25.41	0.663	5.03	0.236	20.91	0.121	28.88	0.167
7.69	0.854	15.85	0.654	25.60	0.646	5.27	0.219	21.17	0.117	28.88	0.145
7.84	0.867	16.15	0.654	25.60	0.626	5.50	0.182	21.64	0.135	29.01	0.142

CURVE 4
 $T = 373^\circ\text{K}$

TABLE 11-10. EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	CURVE 4 (CONT.)	λ	ϵ	CURVE 5 (CONT.)	λ	ϵ	CURVE 6 (CONT.)	λ	ϵ	CURVE 7 (CONT.)	λ	ϵ	CURVE 7 (CONT.)
29.18	0.173	10.26	0.790	8.01	0.395	4.11	0.774	15.86	0.561	25.35	0.427	0.401	25.66	0.401
29.32	0.173	10.42	0.815	8.18	0.385	4.23	0.768	16.37	0.581	25.66	0.401	0.405	25.87	0.405
29.46	0.235	10.60	0.829	8.60	0.427	4.43	0.769	16.67	0.571	25.95	0.399	0.399	25.95	0.399
29.57	0.247	10.99	0.845	8.88	0.467	4.62	0.747	17.27	0.530	25.95	0.380	0.380	25.95	0.380
29.73	0.229	11.34	0.655	8.93	0.539	4.97	0.724	17.59	0.522	25.95	0.365	0.365	26.18	0.365
29.73	0.213	11.54	0.655	9.34	0.633	4.97	0.704	18.10	0.571	26.26	0.355	0.355	26.26	0.355
30.00	0.199	12.26	0.836	10.22	0.746	5.09	0.688	18.21	0.585	26.26	0.343	0.343	26.26	0.343
CURVE 5		12.71	0.836	10.60	0.764	5.51	0.665	18.38	0.592	26.42	0.343	0.343	26.42	0.343
T = 373.		13.40	0.659	11.23	0.806	5.51	0.651	18.59	0.577	26.42	0.343	0.343	26.42	0.343
4.10	0.970	14.09	0.868	11.46	0.803	5.66	0.639	18.97	0.569	26.50	0.304	0.304	26.50	0.304
4.11	0.941	14.63	0.887	11.79	0.801	6.07	0.626	19.25	0.523	26.58	0.394	0.394	26.58	0.394
4.09	0.923	15.93	0.887	11.86	0.785	6.27	0.607	19.42	0.502	26.90	0.401	0.401	26.90	0.401
4.39	0.915	16.50	0.899	12.11	0.794	6.41	0.576	19.55	0.468	27.04	0.424	0.424	27.04	0.424
4.59	0.902	16.93	0.911	12.42	0.785	6.37	0.568	19.72	0.453	27.09	0.498	0.498	27.09	0.498
4.96	0.902	17.54	0.911	12.87	0.791	6.62	0.516	19.81	0.423	27.25	0.513	0.513	27.25	0.513
5.33	0.915	16.60	0.934	13.03	0.811	6.74	0.471	20.18	0.384	27.34	0.502	0.502	27.34	0.502
5.63	0.915	16.79	0.882	14.01	0.821	6.89	0.441	20.18	0.351	27.34	0.465	0.465	27.34	0.465
5.93	0.928	19.00	0.674	14.18	0.834	7.07	0.386	20.49	0.289	27.49	0.461	0.461	27.49	0.461
6.13	0.928	16.93	0.915	14.53	0.838	7.39	0.325	20.72	0.246	27.49	0.445	0.445	27.49	0.445
6.32	0.912	16.59	0.862	15.01	0.838	7.54	0.282	20.84	0.216	27.61	0.447	0.447	27.61	0.447
6.45	0.898	16.61	0.871	16.61	0.871	8.24	0.224	21.57	0.214	27.73	0.470	0.470	27.73	0.470
6.71	0.838	3.93	0.944	17.28	0.876	8.39	0.244	21.69	0.234	27.81	0.451	0.451	27.81	0.451
6.93	0.778	4.13	0.940	17.46	0.869	8.94	0.331	22.01	0.245	28.06	0.445	0.445	28.06	0.445
7.24	0.692	4.22	0.930	17.59	0.862	9.25	0.387	22.40	0.285	28.14	0.372	0.372	28.14	0.372
7.65	0.536	4.21	0.901	18.09	0.880	9.81	0.447	22.62	0.307	28.17	0.436	0.436	28.17	0.436
7.84	0.501	4.31	0.883	19.39	0.888	10.60	0.581	22.76	0.317	28.27	0.456	0.456	28.27	0.456
8.02	0.461	4.54	0.874	18.58	0.882	11.67	0.495	22.98	0.320	28.44	0.495	0.495	28.44	0.495
8.20	0.441	4.91	0.877	18.80	0.882	11.90	0.485	23.18	0.316	28.44	0.437	0.437	28.44	0.437
8.48	0.453	5.29	0.877	19.00	0.874	12.45	0.485	23.49	0.341	28.63	0.410	0.410	28.63	0.410
8.64	0.485	5.53	0.887	13.00	0.494	13.00	0.494	23.70	0.351	28.81	0.442	0.442	28.81	0.442
8.77	0.500	6.26	0.870	13.28	0.500	24.16	0.355	28.98	0.469	29.36	0.558	0.558	29.36	0.558
8.91	0.504	6.51	0.820	13.95	0.584	24.35	0.373	28.92	0.512	29.10	0.487	0.487	29.10	0.487
8.91	0.538	7.13	0.638	14.46	0.492	24.52	0.395	29.30	0.401	29.67	0.571	0.571	29.67	0.571
9.33	0.632	7.28	0.600	14.77	0.487	24.67	0.487	29.67	0.571	29.67	0.443	0.443	29.67	0.443
9.41	0.678	7.26	0.561	14.77	0.487	24.89	0.487	29.67	0.571	29.67	0.443	0.443	29.67	0.443
9.56	0.712	7.55	0.501	15.10	0.521	25.19	0.438	29.46	0.524	29.46	0.465	0.465	29.46	0.465
9.97	0.760	7.60	0.472	15.41	0.544	25.27	0.443	29.62	0.571	29.62	0.437	0.437	29.62	0.437
10.07	0.781	7.64	0.426	15.60	0.571	25.35	0.437	29.69	0.491	29.69	0.491	0.491	29.69	0.491

TABLE II-10. EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELLENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	CURVE 7 (CONT.)	λ	ϵ	CURVE 8 (CONT.)	λ	ϵ	CURVE 9 (CONT.)	λ	ϵ	CURVE 10 (CONT.)
30.00	0.519	13.31	0.914	5.44	0.912	19.55	0.875	9.83	0.578	21.90	0.410
		13.60	0.914	5.84	0.912	19.80	0.835	10.22	0.505	22.16	0.422
		13.94	0.924	6.15	0.906	20.00	0.812	10.60	0.505	22.35	0.450
		14.10	0.910	6.36	0.887			11.07	0.591	22.53	0.470
		14.28	0.920	6.61	0.852			11.40	0.584	22.87	0.481
		14.79	0.918	6.92	0.794			11.56	0.580	23.26	0.486
		15.04	0.926	7.11	0.741			11.95	0.580	23.52	0.500
		15.39	0.930	7.45	0.661	3.47	0.848	12.41	0.587	23.84	0.494
		15.52	0.926	7.60	0.623	3.57	0.832	12.87	0.584	24.03	0.505
		15.95	0.936	7.67	0.592	3.62	0.800	13.22	0.589	24.19	0.522
		16.31	0.936	7.81	0.569	3.75	0.789	13.55	0.594	24.46	0.524
		16.56	0.940	8.03	0.547	3.80	0.789	14.20	0.558	24.66	0.537
		16.71	0.940	8.21	0.547	3.97	0.792	14.37	0.550	24.78	0.561
		16.89	0.942	8.60	0.563	4.05	0.766	15.01	0.583	25.02	0.580
		17.12	0.938	8.95	0.645	4.05	0.771	15.24	0.599	25.13	0.610
		17.49	0.945	9.06	0.682	4.24	0.763	15.33	0.608	25.22	0.616
		17.76	0.942	9.48	0.782	4.47	0.763	15.59	0.622	25.34	0.611
		18.05	0.942	9.60	0.826	4.99	0.739	15.73	0.631	25.46	0.570
		18.46	0.949	10.07	0.853	5.28	0.708	16.00	0.631	25.87	0.562
		18.70	0.949	11.60	0.871	5.53	0.684	16.16	0.628	26.05	0.535
		18.93	0.945	11.95	0.881	5.65	0.654	16.54	0.617	26.27	0.503
		19.12	0.933	11.22	0.881	5.83	0.643	16.80	0.585	26.38	0.490
		19.34	0.914	11.77	0.890	6.12	0.638	17.28	0.561	26.58	0.469
		19.51	0.897	12.12	0.880	6.25	0.625	17.76	0.592	26.73	0.485
		20.00	0.842	12.36	0.875	6.31	0.597	18.04	0.612	26.80	0.499
				12.64	0.875	6.52	0.572	18.47	0.612	27.02	0.572
				13.12	0.885	6.74	0.566	18.89	0.596	27.08	0.610
				13.44	0.893	6.99	0.451	19.30	0.572	27.16	0.620
				13.71	0.893	7.26	0.398	19.61	0.547	27.25	0.616
				14.05	0.889	7.57	0.368	19.96	0.512	27.41	0.560
				14.45	0.896	7.69	0.345	19.96	0.478	27.65	0.529
				14.93	0.897	7.94	0.345	20.22	0.461	27.97	0.549
				15.33	0.907	8.14	0.381	20.31	0.431	28.25	0.573
				15.73	0.907	8.57	0.427	20.44	0.415	28.52	0.576
				16.20	0.906	8.57	0.448	20.44	0.362	28.85	0.539
				16.73	0.920	8.78	0.473	20.68	0.339	28.95	0.522
				17.55	0.916	8.98	0.505	20.90	0.323	29.17	0.519
				19.00	0.916	9.08	0.555	21.22	0.323	29.36	0.559
				19.61	0.925	9.07	0.524	21.54	0.360	29.57	0.546
				19.81	0.913	9.31	0.917	21.54	0.311	29.77	0.565
				20.02	0.933	19.02	0.909	21.72	0.377	29.97	0.546

TABLE II-10. EXPERIMENTAL ANGULAR SPECTRAL EMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ]

λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
CURVE 10 (CONT.)		CURVE 11 (CONT.)		CURVE 11 (CONT.)		CURVE 11 (CONT.)	
29.73	0.557	19.	22	19.	22	30.00	0.133
30.00	0.556	19.	45	19.	97	0.683	
CURVE 11		T = 373.		T = 373.		T = 373.	
3.67	0.295	21.	15	21.	15	0.673	
3.80	0.284	21.	42	21.	42	0.640	
4.69	0.252	21.	55	21.	55	0.097	
4.70	0.203	22.	33	22.	33	0.097	
4.81	0.184	24.	14	24.	14	0.104	
5.12	0.176	24.	28	24.	28	0.111	
5.25	0.159	24.	54	24.	54	0.111	
5.52	0.147	24.	64	24.	64	0.129	
5.62	0.130	24.	75	24.	75	0.146	
6.21	0.126	24.	95	24.	95	0.146	
6.44	0.109	25.	61	25.	61	0.112	
6.60	0.085	25.	86	25.	86	0.114	
7.07	0.077	26.	00	26.	00	0.109	
7.41	0.077	26.	00	26.	00	0.095	
8.06	0.097	26.	26	26.	26	0.086	
8.94	0.116	26.	45	26.	45	0.093	
9.39	0.118	26.	56	26.	56	0.109	
10.19	0.114	27.	07	27.	07	0.133	
10.60	0.114	27.	24	27.	24	0.133	
13.93	0.114	27.	55	27.	55	0.105	
14.13	0.106	27.	87	27.	87	0.121	
14.69	0.103	28.	21	28.	21	0.121	
14.99	0.121	28.	47	28.	47	0.112	
15.57	0.130	28.	47	28.	47	0.102	
15.67	0.130	28.	67	28.	67	0.080	
16.89	0.106	28.	83	28.	83	0.080	
17.47	0.106	28.	91	28.	91	0.106	
17.74	0.116	29.	00	29.	00	0.133	
18.02	0.116	29.	34	29.	43	0.152	
18.39	0.106	29.	43	29.	43	0.143	
18.59	0.105	29.	43	29.	43	0.125	
18.82	0.114	29.	58	29.	58	0.121	

c. Normal Spectral Reflectance (Wavelength Dependence)

A total of 16 sets of experimental data were located for the wavelength dependence of the normal spectral reflectance of vitreous silica. The data are listed in Table 11-13 and shown in Figures 11-7 and 11-8. Specimen characterization and measurement information for the data are given in Table 11-12. Calculations were carried out using the Fresnel equations for specular reflection, Eqs. (2.4-1), (2.4-2), and (2.4-5). These calculations appear as curves 17 to 25 in Tables 11-12 and 11-13 and in Figures 11-7 and 11-8.

The data above 7 μm shows a general trend. It rises sharply above 7.4 μm to a peak at about 9 μm and then decreases to about 0.1 at 12 μm . All the data is for room temperature, with the exception of Gaskell's [T39543] which were measured at up to 1173 K.

Provisional values are listed in Table 11-11 and shown in Figure 11-7. One curve is based on calculations using the Fresnel equations and is valid with the context of an optically smooth specimen, a temperature of 293 K, unpolarized radiation, a wavelength range of 7 to 16.0 μm , an angle of incidence, θ , of 0°, and a viewing angle, θ' , of 0°. The calculated values and curve 16 differ by about 30% at 12.8 μm and, therefore, the uncertainty for these provisional values are within 30%. A provisional curve for 1173 K is also given with a wavelength range of validity between 7.7 and 14 μm . These values are also listed in Table 11-11 and shown in Figure 11-7. These values are based on curve 10 and an uncertainty of 30% is assigned because of the lack of confirmatory data.

TABLE II-II. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ
OPTICALLY SMOOTH							
$T = 293$		$T = 293$ (CONT.)		$T = 1173$			
7.00	0.001	10.4	0.145	7.05	0.000		
7.10	0.000	10.6	0.113	7.13	0.009		
7.20	0.000	10.8	0.111	7.35	0.037		
7.30	0.000	11.0	0.103	7.5	0.057		
7.40	0.000	11.2	0.098	8.15	0.099		
7.50	0.001	11.4	0.091	8.31	0.215		
7.60	0.003	11.6	0.085	8.63	0.309		
7.70	0.016	11.8	0.077	9.74	0.345		
7.80	0.020	12.0	0.077	9.8	0.475		
7.90	0.051	12.2	0.063	10.06	1.505		
8.00	0.135	12.4	0.097	10.15	0.518		
8.10	0.266	12.6	0.106	10.25	0.497		
8.20	0.314	12.8	0.119	10.59	0.366		
8.30	0.315	13.0	0.110	10.8	0.278		
8.40	0.336	13.2	0.102	11.6	0.247		
8.50	0.368	13.4	0.097	12.1	0.220		
8.60	0.422	13.6	0.089	12.5	0.160		
8.65	0.461	13.8	0.081	13.9	0.120		
8.70	0.521	14.0	0.077	14.0	0.116		
8.75	0.567	14.2	0.072	11.5	0.087		
8.80	0.632	14.4	0.143	11.9	0.070		
8.85	0.679	14.6	0.065	12.0	0.077		
8.90	0.792	16.0	0.039	12.2	0.078		
8.95	0.719			12.7	0.066		
9.00	0.670			13.0	0.068		
9.05	0.618			13.3	0.079		
9.10	0.466			13.5	0.076		
9.15	0.530						
9.20	0.474						
9.30	0.453						
9.35	0.416						
9.40	0.311						
9.50	0.343						
9.60	0.313						
9.70	0.294						
9.80	0.252						
9.90	0.229						
10.0	0.205						
10.2	0.166						




FIGURE 11-7. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).




FIGURE 11-8. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICIC VITREOUS (WAVELENGTH DEPENDENCE).

TABLE 11-12. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T31731	Johnson, B.K.	1941	0.13-0.20	293	Fused quartz	Reflecting surface polished, back surface ground to prevent reflection from it; measured in vacuum (0.001 mm Hg); measurement temperature not given explicitly, assumed to be 293 K; data reported called reflection coefficient; $\theta \sim 0^\circ$, $\theta' \sim 0^\circ$.
2 T40526	Salzbach, F. and Turner, A.F.	1966	5.8-38	293	Fused quartz	Measurement temperature specified as room temperature, 293 K assigned; data extracted from smooth curve; Perkin Elmer models 21 and 221 spectrophotometers used for reflectance measurements; $\theta \sim 0^\circ$.
3 T40528	Salzbach, F. and Turner, A.F.	1966	7.7-38	293		Clear film; electron beam deposited at normal incidence on glass at 588 K at 2 to 8×10^{-4} mm Hg; rate of deposit one quartwave min ⁻¹ at $\lambda = 0.5 \mu\text{m}$; optical film thickness, i.e., index of refraction times thickness equals $10 \lambda/4$ at $2.5 \mu\text{m}$; measurement temperature specified as room temperature, 293 K assigned; data from figure; Perkin Elmer models 21 and 221 spectrophotometers used for reflectance measurements; $\theta \sim 0^\circ$.
4 T40528	Salzbach, F. and Turner, A.F.	1966	5.9-34	293	Vitreous silica	Unlined glass substrate; measurement temperature specified as room temperature, 293 K assigned; data from figure; Perkin Elmer models 21 and 221 spectrophotometers used for reflectance measurement; $\theta \sim 0^\circ$.
5 T39543	Gaskell, P.H.	1965	7.5-14	293	Vitreous silica	Plate specimen; author reports reflectivity; Perkin Elmer 12c spectrometer used; smooth values from figure; $\theta \sim 7^\circ$, $\theta' \sim 7^\circ$.
6 T39543	Gaskell, P.H.	1965	7.5-14	480	Vitreous silica	Similar to the above specimen.
7 T39543	Gaskell, P.H.	1965	7.5-14	636	Vitreous silica	Similar to the above specimen.
8 T39543	Gaskell, P.H.	1965	7.6-14	796	Vitreous silica	Similar to the above specimen.
9 T39543	Gaskell, P.H.	1965	7.7-14	1035	Vitreous silica	Similar to the above specimen.
10 T39543	Gaskell, P.H.	1965	7.7-14	1173	Vitreous silica	Similar to the above specimen.
11 E62600,			0.30-3.9	293	Fused silica	Normal spectral reflectance calculated from $(n-1)^2/(n^2+1)$ (for polished, uncoated, plane-parallel plate, considering multiple internal reflections, and assuming zero absorption) where refractive index n was calculated using $n-1 = 0.6361663 \lambda^2 / (\lambda^2 - (0.0084643)^2) + 0.407946 \lambda^2 / (\lambda^2 - (0.1162914)^2) + 0.894754 \lambda^2 / (\lambda^2 - (9.896161)^2)$ with wavelength λ in microns [E21758]; $\theta = 0^\circ$, $\theta' = 0^\circ$.
12 T76947	General Dynamics Convair Aerospace Division	1974	2.5-24	293	Optosil 1	Specimen thickness 0.125 in.; polished disk; specimen provided by Aerospace Corp. who obtained it from Amersil, Inc., Hillsdale, New Jersey; measurements made using the General Dynamics Convair Aerospace ellipsoidal reflectometer and a Perkin Elmer Model 210 monochromator for dispersion; data gathered without use of polarizers; reflectance obtained by comparison of reflected energy from specimen with that reflected by Convair vacuum-deposited gold sample; data gathered at atmospheric pressure; measurement temperature specified as room temperature, 293 K assigned; five readings taken of the gold standard and five of the specimen, average values used in determination of reflectance; $\theta = 12^\circ$, $\theta' = 12^\circ$.
13 T76947	General Dynamics Convair Aerospace Division	1974	10-22	293	Optosil 1, Convair Sample F	Specimen thickness 0.125 in.; polished disk; specimen provided by Aerospace Corp. who obtained it from Amersil, Inc., Hillsdale, New Jersey; measurements made using the General Dynamics Convair Aerospace ellipsoidal reflectometer and a Perkin Elmer Model 210 monochromator for dispersion and Advanced Ballistic Missile Defense Agency wire grid polarizers which were mounted as close as possible to the thermocouple detector; data gathered at atmospheric pressure; measurement temperature specified as room temperature, 293 K assigned; absolute reflectance determined directly; reflectance values reported are for component parallel to plane of incidence; five readings taken and average used in determining reflectance; data from figure; $\theta = 12^\circ$, $\theta' = 12^\circ$.

TABLE II-12. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
14 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen except reflectance values reported are for component perpendicular to the plane of incidence.
15 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen except reflectance values reported are for average of the two polarized components.
16 T30490	Howard, L.E. and Spitzer, W.G.	1961	1.9-29	293	Vitreous silica	Reflectivity measured by comparison with front surface aluminum mirror; Perkin Elmer single-beam double pass spectrometer used; measurement temperature not given explicitly, assumed to be 293 K; $\theta \sim 0^\circ$, $\theta' \sim 0^\circ$.
17 A00012		1975	7.0-16	293		Calculations for fused silica performed for a homogeneous, smooth surface and for perpendicular component (eq. 2.4-1) of incident radiation; data for index of refraction, n, and absorption index, k, from A00012; $\theta = 0^\circ$, $\theta' = 0^\circ$.
18 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta = 5^\circ$, $\theta' = 5^\circ$.
19 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta = 10^\circ$, $\theta' = 10^\circ$.
20 A00012		1975	7.0-16	293		Similar to the above specimen except for parallel component (eq. 2.4-2) of incident radiation and $\theta = 0^\circ$, $\theta' = 0^\circ$.
21 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta = 5^\circ$, $\theta' = 5^\circ$.
22 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta = 10^\circ$, $\theta' = 10^\circ$.
23 A00012		1975	7.0-16	293		Similar to the above specimen except for unpolarized radiation (eq. 2.4-5) and $\theta = 0^\circ$, $\theta' = 0^\circ$.
24 A00012		1975	7.0-16	293		Similar to the above specimen except for $\theta = 5^\circ$, $\theta' = 5^\circ$.
25 A00012		1975	7.0-16	293		Similar to the above specimen except for $\theta = 10^\circ$, $\theta' = 10^\circ$.

TABLE 11-13. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 1 $T = 293.$																			
CURVE 2 $T = 293.$																			
0.1347	0.09	23.6	0.293	14.81	0.056	14.81	0.056	7.43	0.003	9.36	0.420	7.67	0.000	7.67	0.000	7.67	0.000	7.67	0.000
0.1438	0.11	24.2	0.273	13.73	0.152	13.73	0.152	7.76	0.026	9.62	0.333	7.86	0.019	7.86	0.019	7.86	0.019	7.86	0.019
0.1570	0.08	24.7	0.235	20.76	0.235	20.76	0.235	7.91	0.085	9.93	0.234	8.01	0.068	8.01	0.068	8.01	0.068	8.01	0.068
0.1640	0.05	25.0	0.225	21.27	0.248	21.27	0.248	8.66	0.232	10.3	0.164	8.24	0.199	8.24	0.199	8.24	0.199	8.24	0.199
0.1649	0.05	25.7	0.208	21.75	0.239	21.75	0.239	8.15	0.275	11.2	0.091	8.51	0.296	8.51	0.296	8.51	0.296	8.51	0.296
0.1757	0.04	26.5	0.197	33.50	0.100	33.50	0.100	8.42	0.341	11.8	0.065	8.74	0.365	8.74	0.365	8.74	0.365	8.74	0.365
0.1901	0.02	27.5	0.186	28.8	0.178	28.8	0.178	8.55	0.387	12.2	0.076	9.01	0.516	9.01	0.516	9.01	0.516	9.01	0.516
0.2026	0.02	32.0	0.171	32.0	0.171	32.0	0.171	8.62	0.431	12.6	0.091	9.10	0.531	9.10	0.531	9.10	0.531	9.10	0.531
CURVE 5 $T = 293.$																			
34.4	0.257	7.1	0.005	8.89	0.646	8.89	0.646	13.0	0.000	9.17	0.520	13.0	0.000	9.17	0.520	13.0	0.000	9.17	0.520
35.2	0.150	7.3	0.023	8.96	0.652	8.96	0.652	13.3	0.001	9.36	0.452	13.3	0.001	9.36	0.452	13.3	0.001	9.36	0.452
38.0	0.145	7.82	0.051	9.02	0.643	9.02	0.643	13.5	0.076	9.79	0.297	13.5	0.076	9.79	0.297	13.5	0.076	9.79	0.297
CURVE 3 $T = 293.$																			
6.00	0.042	7.40	0.011	7.86	0.990	7.86	0.990	9.32	0.434	10.3	0.171	10.3	0.171	10.3	0.171	10.3	0.171	10.3	0.171
7.00	0.0212	8.00	0.237	9.27	0.284	9.27	0.284	10.2	0.162	11.7	0.075	11.7	0.075	11.7	0.075	11.7	0.075	11.7	0.075
8.00	0.333	8.20	0.353	7.73	0.012	7.73	0.012	10.6	0.122	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076
8.40	0.466	8.68	0.270	8.20	0.318	8.20	0.318	11.4	0.078	12.6	0.043	12.6	0.043	12.6	0.043	12.6	0.043	12.6	0.043
9.00	0.736	9.04	0.430	9.55	0.374	9.55	0.374	11.8	0.050	8.66	0.134	8.66	0.134	8.66	0.134	8.66	0.134	8.66	0.134
9.20	0.473	10.60	0.156	9.55	0.422	9.55	0.422	12.2	0.076	8.16	0.207	8.16	0.207	8.16	0.207	8.16	0.207	8.16	0.207
9.40	0.379	12.56	0.105	9.87	0.716	9.87	0.716	12.7	0.076	8.26	0.251	8.26	0.251	8.26	0.251	8.26	0.251	8.26	0.251
9.80	0.285	19.79	0.022	8.92	0.720	8.92	0.720	12.7	0.094	8.49	0.313	8.49	0.313	8.49	0.313	8.49	0.313	8.49	0.313
9.90	0.247	21.35	0.163	8.95	0.716	8.95	0.716	13.0	0.086	8.62	0.365	8.62	0.365	8.62	0.365	8.62	0.365	8.62	0.365
10.4	0.196	23.54	0.179	9.19	0.496	9.19	0.496	13.3	0.081	8.76	0.433	8.76	0.433	8.76	0.433	8.76	0.433	8.76	0.433
11.1	0.139	26.26	0.142	9.33	0.420	9.33	0.420	13.5	0.073	9.00	0.559	9.00	0.559	9.00	0.559	9.00	0.559	9.00	0.559
11.5	0.109	29.89	0.122	9.68	0.301	9.68	0.301	13.0	0.086	9.08	0.565	9.08	0.565	9.08	0.565	9.08	0.565	9.08	0.565
12.0	0.095	33.80	0.122	9.89	0.239	9.89	0.239	13.5	0.133	9.42	0.413	9.42	0.413	9.42	0.413	9.42	0.413	9.42	0.413
13.3	0.058	38.00	0.120	10.1	0.175	10.1	0.175	11.4	0.073	9.73	0.307	9.73	0.307	9.73	0.307	9.73	0.307	9.73	0.307
15.7	0.056	10.3	0.164	11.0	0.094	11.0	0.094	11.4	0.073	10.4	0.150	10.4	0.150	10.4	0.150	10.4	0.150	10.4	0.150
18.0	0.010	10.6	0.119	12.2	0.078	12.2	0.078	12.6	0.061	11.6	0.073	11.6	0.073	11.6	0.073	11.6	0.073	11.6	0.073
18.6	0.012	10.4	0.094	12.6	0.095	12.6	0.095	13.0	0.061	13.0	0.086	13.0	0.086	13.0	0.086	13.0	0.086	13.0	0.086
19.3	0.042	11.4	0.073	11.8	0.057	11.8	0.057	12.2	0.026	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076
19.7	0.145	11.45	0.045	11.8	0.057	11.8	0.057	12.2	0.026	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076
20.4	0.468	8.82	0.233	9.43	0.324	9.43	0.324	9.85	0.42	10.4	0.150	10.4	0.150	10.4	0.150	10.4	0.150	10.4	0.150
20.7	0.555	10.45	0.237	10.45	0.237	10.45	0.237	11.0	0.061	11.6	0.073	11.6	0.073	11.6	0.073	11.6	0.073	11.6	0.073
21.2	0.533	10.45	0.237	11.0	0.061	11.0	0.061	11.4	0.061	11.6	0.073	11.6	0.073	11.6	0.073	11.6	0.073	11.6	0.073
21.6	0.490	11.00	0.104	11.3	0.060	11.3	0.060	11.8	0.060	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076	12.2	0.076
21.8	0.443	13.76	0.056	13.5	0.078	13.5	0.078	13.8	0.061	9.01	0.615	9.01	0.615	9.01	0.615	9.01	0.615	9.01	0.615
22.1	0.393	17.95	0.114	14.0	0.106	14.0	0.106	14.5	0.061	9.07	0.595	9.07	0.595	9.07	0.595	9.07	0.595	9.07	0.595
22.4	0.106	18.37	0.172	14.5	0.106	14.5	0.106	15.0	0.061	9.21	0.495	9.21	0.495	9.21	0.495	9.21	0.495	9.21	0.495

TABLE II-13. EXPERIMENTAL NORMAL REFLECTANCE OF SILICATE VITREOUS (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 10 (CONT.)											
10.9	0.120	3.10	0.658	13.3	0.631	CURVE 12 (CONT.)		CURVE 16 $T = 293.$		CURVE 17 (CONT.)	
11.5	0.087	3.20	0.657	21.0	0.257	1.90	0.239	21.4	0.475	9.10	0.4649
11.9	0.078	3.30	0.657	21.0	0.553	2.86	0.037	21.9	0.405	9.15	0.5301
12.2	0.076	3.40	0.656	22.3	0.386	3.99	0.031	23.5	0.264	9.20	0.4744
12.7	0.069	3.50	0.655	23.9	0.286	4.93	0.925	23.9	0.236	9.30	0.4527
13.0	0.068	3.60	0.655	24.0	0.227	5.92	0.021	24.4	0.222	9.35	0.4164
13.3	0.0786	3.70	0.654			6.75	0.011	25.9	0.191	9.40	0.3106
13.5	0.076	3.80	0.653			7.73	0.174	27.0	0.175	9.50	0.3433
		3.90	0.652			7.89	0.259	28.0	0.169	9.60	0.3129
CURVE 11											
		CURVE 12 $T = 293.$		13.3	0.194	6.33	0.371	CURVE 16 $T = 293.$		9.90	0.2235
0.30	0.074	2.5	0.156	11.3	0.099	6.37	0.468	10.0	0.2050		
0.40	0.073	3.0	0.085	13.0	0.086	6.56	0.606	10.2	0.1665		
0.50	0.068	3.5	0.071	16.0	0.044	6.59	0.707	10.4	0.1452		
0.60	0.067	4.0	0.058	22.0	0.384	6.91	0.662	10.6	0.1226		
0.70	0.066	4.5	0.058			6.94	0.547	7.10	0.0904		
0.80	0.066	5.0	0.029			9.04	0.475	7.20	0.0001		
0.90	0.066	5.5	0.029			9.08	0.427	7.30	0.0001		
1.00	0.062	6.0	0.028			9.33	0.338	7.40	0.0005		
1.10	0.065	6.5	0.023			9.53	0.278	7.50	0.0415		
1.20	0.065	6.5	0.020			9.67	0.224	7.60	0.0775		
1.30	0.065	7.0	0.012			10.0	0.151	7.70	0.0001		
1.40	0.064	7.5	0.013			10.5	0.108	7.80	0.3204		
1.50	0.064	8.0	0.225			11.4	0.092	7.90	0.0511		
1.60	0.064	8.5	0.402			12.2	0.081	8.00	0.1351		
1.70	0.063	9.0	0.667			12.9	0.069	8.14	0.2681		
1.80	0.063	9.5	0.347			13.9	0.065	8.20	0.3137		
1.90	0.063	10.0	0.195			14.9	0.053	8.30	0.3064		
2.00	0.063	10.5	0.128			16.0	0.047	8.40	0.3360		
2.10	0.062	11.0	0.100			16.9	0.035	8.50	0.3682		
2.20	0.062	11.5	0.075			17.9	0.025	8.60	0.4216		
2.30	0.061	12.0	0.073			18.9	0.039	8.65	0.4613		
2.40	0.061	12.5	0.098			19.3	0.075	8.75	0.5666		
2.50	0.061	13.0	0.086			19.6	0.146	8.80	0.6325		
2.60	0.060	14.0	0.061			19.9	0.280	8.85	0.6794		
2.70	0.060	15.0	0.049			20.2	0.406	8.90	0.7018		
2.80	0.059	16.0	0.044			20.3	0.503	8.95	0.7187		
2.90	0.059	17.0	0.036			20.7	0.554	9.00	0.6764		
3.00	0.056	18.0	0.032			21.2	0.508	9.05	0.6176		

TABLE II-13. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE II-13. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELLENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 21 (CONT.)	λ	ρ	CURVE 22 (CONT.)	λ	ρ	CURVE 23 (CONT.)	λ	ρ	CURVE 24 (CONT.)	λ	ρ	CURVE 25
10.0	0.1105	8.50	0.3581	13.6	0.0050	9.30	0.4527	7.30	0.0001	11.2	0.0977	10.0	0.2050	8.10
11.0	0.1021	8.60	0.4122	13.8	0.0782	9.35	0.4164	7.40	0.3025	11.4	0.0915	11.2	0.0004	0.2693
11.2	0.1969	8.65	0.4525	14.0	0.0739	9.40	0.3106	7.50	0.0015	11.6	0.0848	10.2	0.1665	8.20
11.4	0.0938	8.70	0.5126	14.2	0.0696	9.53	0.3433	7.60	0.0031	11.8	0.0775	10.4	0.1452	8.30
11.6	0.0841	8.75	0.5592	14.4	0.1391	9.60	0.3129	7.70	0.0096	12.0	0.0771	10.6	0.1126	8.40
11.8	0.0769	8.80	0.6260	14.6	0.0623	9.70	0.2841	7.80	0.0204	12.2	0.0828	10.8	0.1147	8.50
12.0	0.0765	8.85	0.6739	16.0	0.0382	9.80	0.2521	7.90	0.0511	12.4	0.0966	11.0	0.2050	8.60
12.2	0.0821	8.90	0.6968	9.90	0.2295	8.00	0.1352	12.6	0.1063	12.6	0.1063	10.2	0.1665	8.70
12.4	0.0958	8.95	0.7144	10.0	0.2050	8.10	0.2681	12.8	0.2050	13.0	0.1101	10.4	0.1452	8.80
12.6	0.1055	9.00	0.6658	10.2	0.1665	8.20	0.3137	13.0	0.1101	13.2	0.1016	10.6	0.1126	8.90
12.8	0.1177	9.05	0.6126	10.4	0.1452	8.30	0.3064	13.4	0.0970	13.4	0.0970	10.8	0.2050	8.90
13.0	0.1093	9.10	0.4591	7.00	0.3006	10.6	0.1126	8.40	0.3360	13.6	0.0807	11.0	0.1665	8.90
13.2	0.1010	9.15	0.5247	7.10	0.0004	10.8	0.1114	8.50	0.3682	13.6	0.0810	11.2	0.1452	8.90
13.4	0.0962	9.20	0.4683	7.20	0.0091	11.0	0.1029	8.60	0.4216	13.8	0.0766	11.4	0.1233	8.90
13.6	0.0880	9.30	0.4471	7.30	0.0001	11.2	0.0977	8.65	0.4614	14.0	0.0723	11.6	0.1016	8.90
13.8	0.0803	9.35	0.4161	7.40	0.0001	11.4	0.0915	8.70	0.5207	14.2	0.0652	11.8	0.0848	8.90
14.0	0.0759	9.40	0.3051	7.50	0.0015	11.6	0.0848	8.75	0.5666	14.4	0.0652	12.0	0.0632	8.90
14.2	0.0717	9.50	0.3377	7.60	0.0031	11.8	0.0775	8.80	0.6325	14.6	0.0632	12.2	0.06794	16.0
14.4	0.1423	9.60	0.3074	7.70	0.0096	12.0	0.0771	8.85	0.7018	14.8	0.0398	12.4	0.07167	T = 293.
14.6	0.0646	9.70	0.2768	7.80	0.0204	12.2	0.0826	8.90	0.7167	15.0	0.0006	12.6	0.6704	T = 293.
14.8	0.0394	9.80	0.2469	7.90	0.0511	12.4	0.0966	8.95	0.7167	15.2	0.0004	12.8	0.6704	T = 293.
15.0	9.90	0.2249	8.00	0.1351	12.6	0.1063	9.00	0.6704	15.4	0.0004	13.0	0.6704	T = 293.	
10.0	0.2063	6.00	0.2681	12.8	0.1186	9.05	0.6176	15.6	0.0004	13.2	0.6176	13.0	0.6176	T = 293.
10.2	0.1622	6.20	0.3137	13.0	0.1101	9.10	0.4649	15.8	0.0004	13.4	0.4649	13.2	0.4649	T = 293.
10.4	0.1412	6.30	0.3064	13.2	0.1018	9.15	0.5301	16.0	0.0004	13.6	0.5301	13.4	0.5301	T = 293.
10.6	0.1091	6.40	0.3360	13.4	0.0970	9.20	0.4744	16.2	0.0004	13.8	0.4744	13.6	0.4744	T = 293.
10.8	0.1080	5.50	0.3682	13.6	0.0887	9.30	0.4527	16.4	0.0004	14.0	0.4527	13.8	0.4527	T = 293.
11.0	0.0996	6.50	0.4216	13.8	0.0810	9.35	0.4164	16.6	0.0005	14.2	0.4164	14.0	0.4164	T = 293.
11.2	0.0945	6.65	0.4613	14.0	0.0766	9.40	0.3106	16.8	0.0005	14.4	0.3106	14.2	0.3106	T = 293.
11.4	0.0905	6.70	0.5207	14.2	0.0723	9.50	0.3433	17.0	0.0005	14.6	0.3433	14.4	0.3433	T = 293.
11.6	0.0619	6.75	0.5666	14.4	0.1433	9.60	0.3129	17.2	0.0005	14.8	0.3129	14.6	0.3129	T = 293.
11.8	0.0749	6.80	0.6325	14.6	0.0652	9.70	0.2841	17.4	0.0005	15.0	0.2841	14.8	0.2841	T = 293.
12.0	0.0744	6.85	0.6744	16.0	0.3986	9.80	0.2521	17.6	0.0005	15.2	0.2521	15.0	0.2521	T = 293.
12.2	0.0799	6.90	0.7018	17.0	0.2295	9.90	0.2295	17.8	0.0005	15.4	0.2295	15.2	0.2295	T = 293.
12.4	0.0934	6.95	0.7167	17.2	0.2050	8.10	0.2050	18.0	0.0005	15.6	0.2050	15.4	0.2050	T = 293.
12.6	0.1030	9.00	0.6704	17.4	0.1665	8.20	0.1665	18.2	0.0005	15.8	0.1665	15.6	0.1665	T = 293.
12.8	0.1151	9.05	0.6176	17.6	0.1452	8.30	0.1452	18.4	0.0005	16.0	0.1452	15.8	0.1452	T = 293.
13.0	0.1067	9.10	0.4649	17.8	0.1126	8.40	0.1126	18.6	0.0005	16.2	0.1126	16.0	0.1126	T = 293.
13.2	0.0936	9.15	0.5301	18.0	0.0906	8.50	0.0906	18.8	0.0005	16.4	0.0906	16.2	0.0906	T = 293.
13.4	0.3253	9.20	0.4744	18.2	0.0723	8.60	0.0723	19.0	0.0005	16.6	0.0723	16.4	0.0723	T = 293.

TABLE II-13. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ
CURVE 25 (CONT.)			CURVE 25 (CONT.)
6.65	0.4615	14.0	0.0766
6.70	0.5208	14.2	0.0723
6.75	0.5666	14.4	0.1433
6.80	0.6325	14.6	0.0652
6.95	0.6734	16.0	0.0395
6.90	0.7318		
6.95	0.7187		
6.90	0.6704		
9.05	0.6175		
9.10	0.4649		
9.15	0.5321		
9.20	0.4744		
9.30	0.4527		
9.35	0.4164		
9.40	0.3156		
9.50	0.3433		
9.60	0.3129		
9.70	0.2841		
9.80	0.2521		
9.90	0.2296		
10.0	0.2051		
10.2	0.1665		
10.4	0.1452		
10.6	0.1126		
10.8	0.1114		
11.0	0.1229		
11.2	0.0977		
11.4	0.0916		
11.6	0.0848		
11.8	0.0776		
12.0	0.0772		
12.2	0.0626		
12.4	0.0956		
12.6	0.1064		
12.8	0.1187		
13.0	0.1101		
13.2	0.1018		
13.4	0.0970		
13.6	0.0887		
13.8	0.0810		

d. Normal Spectral Reflectance (Temperature Dependence)

No experimental data sets were found for the temperature dependence of the normal spectral reflectance of vitreous silica. However, a provisional curve was generated for 10.6 μm from curves 5-10 of Tables 11-12 and 11-13 together with the provisional values at 293 K for the wavelength dependence of the normal spectral reflectance. The values are listed in Table 11-14 and shown in Figure 11-9. An uncertainty of within 30% is assigned. It is noted that from 293 to 1173 K, there is an increase in the normal spectral reflectance.

TABLE II-14. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (TEMPERATURE DÉPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

T	ρ
$\lambda = 10.6$	
293°	0.113
480°	0.122
636°	0.134
796°	0.136
1035°	0.138
1173°	0.150




FIGURE 11-9. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICA(VITREOUS)
(TEMPERATURE DEPENDENCE).

e. Angular Spectral Reflectance (Wavelength Dependence)

A total of 32 sets of experimental data were located for the wavelength dependence of the angular spectral reflectance of vitreous silica. One additional data set for synthetic quartz was located and included. The data are listed in Table 11-17 and shown in Figures 11-10 and 11-11. Specimen characterization and measurement information for the data are given in Table 11-16. Curves 20 and 21 are not shown on Figures 11-10 and 11-11, since the computer plotting routine cannot plot 33 curves.

The data above 1 μm are all for 293 K and is widely spaced. Lines connecting such widely spaced points (see Figure 11-11) do not imply a smooth curve connecting the points but are used for ease in visualizing the points belonging to the same curve.

Using the Fresnel equations, a set of provisional values was generated for angular spectral reflectance for unpolarized radiation (see Eqs. (2.4-1)-(2.4-5)). The values are for angles of incidence and reflection of 40°, for a temperature of 293 K, and hold within the wavelength range of 7.0-16.0 μm for an optically smooth specimen. The provisional values are listed in Table 11-15 and shown in Figure 11-10. An uncertainty within 30% is assigned.

TABLE II-15. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITROUS) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ
OPTICALLY SMOOTH $\theta = 0^\circ = 40^\circ$ $T = 293$ (CONT.)					
7.00	0.031	10.4	0.151		
7.10	0.001	10.6	0.119		
7.20	0.000	10.6	0.116		
7.30	0.003	11.0	0.110		
7.40	0.001	11.2	0.104		
7.50	0.002	11.4	0.098		
7.60	0.005	11.6	0.092		
7.70	0.019	11.8	0.085		
7.80	0.050	12.0	0.084		
7.90	0.178	12.2	0.090		
8.00	0.312	12.4	0.104		
8.10	0.423	12.6	0.113		
8.20	0.412	12.8	0.125		
8.30	0.385	13.0	0.117		
8.40	0.391	13.2	0.109		
8.50	0.415	13.4	0.104		
8.60	0.459	13.6	0.096		
8.65	0.493	13.8	0.088		
8.70	0.545	14.0	0.083		
8.75	0.586	14.2	0.079		
8.80	0.646	14.4	0.075		
8.85	0.688	14.6	0.072		
8.90	0.707	16.0	0.045		
8.95	0.720				
9.00	0.670				
9.05	0.614				
9.10	0.466				
9.15	0.478				
9.20	0.473				
9.30	0.452				
9.35	0.416				
9.40	0.313				
9.50	0.344				
9.60	0.314				
9.70	0.266				
9.80	0.255				
9.90	0.233				
10.0	0.209				
10.2	0.172				




FIGURE 11-10. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).




TABLE 11-16. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF SILICA (VITREOUS) (Wavelength Dependence)

Cur. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T27141	Bogdan, L.	1964	0.80-2.6	293	Fused quartz	Disk specimen 0.375 in. in diameter and 0.0625 in. thick; clear fused quartz blank; aluminum mirror used as reference standard, reported measurements corrected; data from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 45^\circ$, $\theta^* = 45^\circ$.
2 T36639	Rabinovitch, K., Canfield, L.R., and Madden, R.P.	1965	0.056-0.19	293	Silica	Specimen 6 mm thick; measured in vacuum with the plane of incidence perpendicular to exit slit of the monochromator; measurement temperature not given explicitly, assumed to be 293 K; $\theta = 45^\circ$, $\theta^* = 45^\circ$.
3 T36639	Rabinovitch, K., et al.	1965	0.058-0.19	293	Silica	The above specimen except measured with the plane of incidence parallel to exit slit of the monochromator.
4 T47322	Platzoder, K. and Steinmann, W.	1968	0.057-0.15	293	Fused quartz, type Suprasil	Specimens 1 mm thick; carefully cleaned and outgassed before measurement; samples supplied by Quarzschmelze Hieraus-Hanau; temperature specified as room temperature, 293 K assigned; $\theta = 20^\circ$.
5 T47322	Platzoder, K. and Steinmann, W.	1968	0.059-0.15	423	Fused quartz, type Suprasil	Similar to the above specimen except measured at 423 K.
6 T47322	Platzoder, K. and Steinmann, W.	1968	0.1216	293	Fused quartz, type Suprasil	Similar to the above specimen presumed to be room temperature, 293 K assigned; $\theta = 40^\circ$.
7 T47322	Platzoder, K. and Steinmann, W.	1968	0.1216	293	Fused quartz, type Suprasil	Similar to the above specimen; $\theta = 50^\circ$.
8 T47322	Platzoder, K. and Steinmann, W.	1968	0.1216	293	Fused quartz, type Suprasil	Similar to the above specimen; $\theta = 60^\circ$.
9 T47322	Platzoder, K. and Steinmann, W.	1968	0.1216	293	Fused quartz, type Suprasil	Similar to the above specimen; $\theta = 70^\circ$.
10 T47322	Platzoder, K. and Steinmann, W.	1968	0.1216	293	Fused quartz, type Suprasil	Similar to the above specimen; $\theta = 76^\circ$.
11 T30100	McCarthy, D.E.	1963	2.0-50	293	Quartz	Synthetic; specimen 10 mm thick; ground and polished to a flatness of seven fringes or better; reference standard was aluminum mirror; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; Beckman IR-5A used in 2-16 μm range; $\theta = 30^\circ$, $\theta^* = 30^\circ$.
12 T6647	General Dynamics Convair Aerospace Division	1974	9.0-22	293	Optosil 1, Convair Sample F	Specimen thickness 0.125 in.; polished disk; specimen provided by Aerospace Corp. who obtained it from Amersil, Inc., Hillsdale, New Jersey; measurements made using the General Dynamics Convair Aerospace ellipsoidal reflectometer and a Perkin Elmer Model 210 monochromator for dispersion and Advanced Ballistic Missile Defense Agency wire grid polarizers which were mounted as close as possible to the thermocouple detector; data gathered at atmospheric pressure; measurement temperature specified as room temperature, 253 K assigned; absolute reflectance determined directly; reflectance values reported are for component parallel to plane of incidence; five readings taken and average used in determining reflectance; data from figure; $\theta = 20^\circ$, $\theta^* = 20^\circ$.
13 T76347	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen; $\theta = 30^\circ$, $\theta^* = 30^\circ$.

TABLE 11-16. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
14 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 40^\circ$, $\theta' = 40^\circ$.
15 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta \approx 50^\circ$, $\theta' = 50^\circ$.
16 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 60^\circ$, $\theta' = 60^\circ$.
17 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 70^\circ$, $\theta' = 70^\circ$.
18 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 75^\circ$, $\theta' = 75^\circ$.
19 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen except reflectance measurements reported are for the component perpendicular to the plane of incidence; $\theta = 20^\circ$, $\theta' = 20^\circ$.
20 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 30^\circ$, $\theta' = 30^\circ$.
21 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 40^\circ$, $\theta' = 40^\circ$.
22 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 50^\circ$, $\theta' = 50^\circ$.
23 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 60^\circ$, $\theta' = 60^\circ$.
24 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 70^\circ$, $\theta' = 70^\circ$.
25 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 75^\circ$, $\theta' = 75^\circ$.
26 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen except reflectance values reported are for average of polarized components; $\theta = 20^\circ$, $\theta' = 20^\circ$.
27 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Opotil 1, Convair Sample F	The above specimen; $\theta = 30^\circ$, $\theta' = 30^\circ$.

TABLE 11-16. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
28 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen; $\theta = 40^\circ$, $\theta' = 40^\circ$.
29 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen; $\theta = 50^\circ$, $\theta' = 50^\circ$.
30 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen; $\theta = 60^\circ$, $\theta' = 60^\circ$.
31 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen; $\theta = 70^\circ$, $\theta' = 70^\circ$.
32 T76947	General Dynamics Convair Aerospace Division	1974	5.0-22	293	Optosil 1, Convair Sample F	The above specimen; $\theta = 75^\circ$, $\theta' = 75^\circ$.
33 T40853	Purty, C.H. and Wrigley, J.D., Jr.	1967	7-32	293	Fused quartz	Two faces polished; smooth values from figure; measurement temperature specified as room temperature, 293 K assigned; $\theta = 15^\circ$, $\theta' = 15^\circ$.

TABLE 11-17. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 1 $T = 293.$											
0.800	0.073	0.6574	0.082	0.0596	0.081	0.1216	0.244	20.1	0.897	5.0	0.007
0.850	0.077	0.0633	0.100	0.0684	0.111	0.0873	0.114	21.0	0.896	9.0	0.637
0.900	0.078	0.0681	0.115	0.0747	0.114	0.0780	0.106	22.3	0.309	10.0	0.120
0.950	0.069	0.3702	0.119	0.0788	0.106	0.0838	0.106	24.3	0.050	11.0	0.052
1.00	0.061	0.0721	0.121	0.0873	0.126	0.1216	0.310	24.7	0.762	13.0	0.041
1.20	0.055	0.0746	0.119	0.0906	0.129	0.0919	0.122	26.9	0.256	16.0	3.018
1.40	0.056	0.0779	0.108	0.0936	0.129	0.0919	0.122	27.9	0.208	22.0	0.314
1.60	0.051	0.0813	0.104	0.0956	0.116	0.0956	0.116	35.5	0.110	CURVE 14 $T = 293.$	
1.80	0.047	0.0836	0.107	0.0970	0.120	0.0970	0.120	36.5	0.104	CURVE 15 $T = 293.$	
2.00	0.036	0.0871	0.126	0.1026	0.134	0.1216	0.393	37.2	0.221	CURVE 16 $T = 293.$	
2.40	0.035	0.0877	0.132	0.1067	0.146	0.1080	0.142	38.7	0.167	5.0	0.000
2.60	0.024	0.0894	0.134	0.1127	0.146	0.1127	0.118	39.9	0.147	9.0	0.612
CURVE 2 $T = 298.$											
0.0584	0.150	0.1046	0.150	0.1215	0.203	0.1243	0.188	2.0	0.046	4.3.2	0.077
0.0736	0.176	0.1063	0.153	0.1277	0.166	0.1195	0.194	3.6	0.025	11.0	0.025
0.1026	0.163	0.1075	0.151	0.1337	0.142	0.1067	0.203	6.7	0.000	13.0	0.018
0.1216	0.252	0.1092	0.141	0.1404	0.102	0.1491	0.084	7.4	0.022	16.0	0.006
0.1436	0.136	0.1104	0.132	0.1547	0.077	0.1547	0.077	7.7	0.479	22.0	0.275
0.1606	0.110	0.1139	0.113	0.1216	0.202	0.1491	0.084	8.7	0.000	CURVE 12 $T = 293.$	
0.1930	0.093	0.1150	0.111	0.1547	0.077	0.1547	0.077	9.0	0.670	5.0	0.006
CURVE 3 $T = 298.$											
0.0584	0.062	0.1221	0.200	0.1221	0.200	0.1279	0.161	10.0	0.182	CURVE 13 $T = 293.$	
0.0736	0.091	0.1316	0.135	0.1375	0.117	0.1216	0.207	12.4	0.457	16.0	0.003
0.1026	0.095	0.1407	0.108	0.1436	0.103	0.1216	0.217	12.9	0.152	22.0	0.236
0.1216	0.149	0.1407	0.108	0.1465	0.093	0.1491	0.088	13.3	0.066	CURVE 14 $T = 293.$	
0.1436	0.067	0.1436	0.103	0.1465	0.097	0.1491	0.088	14.3	0.131	5.0	0.012
0.1606	0.050	0.1465	0.093	0.1491	0.088	0.1216	0.202	16.3	0.051	9.0	0.657
0.1930	0.051	0.1491	0.088	0.1216	0.202	0.1216	0.217	17.3	0.025	10.0	0.042
CURVE 4 $T = 293.$											
0.800	0.073	0.0574	0.082	0.0596	0.081	0.1216	0.244	21.0	0.931	5.0	0.007
0.850	0.077	0.0633	0.100	0.0684	0.111	0.0873	0.114	21.8	0.896	9.0	0.637
0.900	0.078	0.0681	0.115	0.0747	0.114	0.0906	0.129	22.3	0.309	10.0	0.120
0.950	0.069	0.3702	0.119	0.0788	0.106	0.0838	0.106	24.3	0.050	11.0	0.052
1.00	0.061	0.0721	0.121	0.0873	0.126	0.1216	0.310	24.7	0.762	13.0	0.041
1.20	0.055	0.0746	0.119	0.0906	0.129	0.0919	0.122	26.9	0.256	16.0	3.018
1.40	0.056	0.0779	0.108	0.0936	0.129	0.0919	0.122	27.9	0.208	22.0	0.314
1.60	0.051	0.0813	0.104	0.0956	0.116	0.0956	0.116	35.5	0.110	CURVE 14 $T = 293.$	
1.80	0.047	0.0836	0.107	0.0970	0.120	0.0970	0.120	36.5	0.104	CURVE 15 $T = 293.$	
2.00	0.036	0.0871	0.126	0.1026	0.134	0.1216	0.393	37.2	0.221	CURVE 16 $T = 293.$	
2.40	0.035	0.0877	0.132	0.1067	0.146	0.1080	0.142	38.7	0.167	5.0	0.000
2.60	0.024	0.0894	0.134	0.1127	0.146	0.1127	0.118	39.9	0.147	9.0	0.612
CURVE 5 $T = 423.$											
0.800	0.073	0.0574	0.082	0.0596	0.081	0.1216	0.244	21.0	0.931	5.0	0.007
0.850	0.077	0.0633	0.100	0.0684	0.111	0.0873	0.114	21.8	0.896	9.0	0.637
0.900	0.078	0.0681	0.115	0.0747	0.114	0.0906	0.129	22.3	0.309	10.0	0.120
0.950	0.069	0.3702	0.119	0.0788	0.106	0.0838	0.106	24.3	0.050	11.0	0.052
1.00	0.061	0.0721	0.121	0.0873	0.126	0.1216	0.310	24.7	0.762	13.0	0.041
1.20	0.055	0.0746	0.119	0.0906	0.129	0.0919	0.122	26.9	0.256	16.0	3.018
1.40	0.056	0.0779	0.108	0.0936	0.129	0.0919	0.122	27.9	0.208	22.0	0.314
1.60	0.051	0.0813	0.104	0.0956	0.116	0.0956	0.116	35.5	0.110	CURVE 14 $T = 293.$	
1.80	0.047	0.0836	0.107	0.0970	0.120	0.0970	0.120	36.5	0.104	CURVE 15 $T = 293.$	
2.00	0.036	0.0871	0.126	0.1026	0.134	0.1216	0.393	37.2	0.221	CURVE 16 $T = 293.$	
2.40	0.035	0.0877	0.132	0.1067	0.146	0.1080	0.142	38.7	0.167	5.0	0.000
2.60	0.024	0.0894	0.134	0.1127	0.146	0.1127	0.118	39.9	0.147	9.0	0.612
CURVE 6 $T = 298.$											
0.0584	0.150	0.1046	0.150	0.1215	0.203	0.1243	0.188	2.0	0.046	4.3.2	0.077
0.0736	0.176	0.1063	0.153	0.1277	0.166	0.1195	0.194	3.6	0.025	11.0	0.025
0.1026	0.163	0.1075	0.151	0.1337	0.142	0.1067	0.203	6.7	0.000	13.0	0.018
0.1216	0.252	0.1092	0.141	0.1404	0.102	0.1491	0.084	7.4	0.022	16.0	0.006
0.1436	0.136	0.1104	0.132	0.1547	0.077	0.1547	0.077	7.7	0.479	22.0	0.275
0.1606	0.110	0.1139	0.113	0.1621	0.202	0.1491	0.084	8.7	0.000	CURVE 12 $T = 293.$	
0.1930	0.093	0.1150	0.111	0.1547	0.077	0.1547	0.077	9.0	0.670	5.0	0.006
CURVE 7 $T = 298.$											
0.0584	0.150	0.1046	0.150	0.1215	0.203	0.1243	0.188	2.0	0.046	4.3.2	0.077
0.0736	0.176	0.1063	0.153	0.1277	0.166	0.1195	0.194	3.6	0.025	11.0	0.025
0.1026	0.163	0.1075	0.151	0.1337	0.142	0.1067	0.203	6.7	0.000	13.0	0.018
0.1216	0.252	0.1092	0.141	0.1404	0.102	0.1491	0.084	7.4	0.022	16.0	0.006
0.1436	0.136	0.1104	0.132	0.1547	0.077	0.1547	0.077	7.7	0.479	22.0	0.275
0.1606	0.110	0.1139	0.113	0.1621	0.202	0.1491	0.084	8.7	0.000	CURVE 12 $T = 293.$	
0.1930	0.093	0.1150	0.111	0.1547	0.077	0.1547	0.077	9.0	0.670	5.0	0.006
CURVE 8 $T = 298.$											
0.0584	0.150	0.1046	0.150	0.1215	0.203	0.1243	0.188	2.0	0.046	4.3.2	0.077
0.0736	0.176	0.1063	0.153	0.1277	0.166	0.1195	0.194	3.6	0.025	11.0	0.025
0.1026	0.163	0.1075	0.151	0.1337	0.142	0.1067	0.203	6.7	0.000	13.0	0.018
0.1216	0.252	0.1092	0.141	0.1404	0.102	0.1491	0.084	7.4	0.022	16.0	0.006
0.1436	0.136	0.1104	0.132	0.1547	0.077	0.1547	0.077	7.7	0.479	22.0	0.275
0.1606	0.110	0.1139	0.113	0.1621	0.202	0.1491	0.084	8.7	0.000	CURVE 12 $T = 293.$	
0.1930	0.093	0.1150	0.111	0.1547	0.077	0.1547	0.077	9.0	0.670	5.0	0.006
CURVE 9 $T = 298.$											
0.0584	0.150	0.1046	0.150	0.1215	0.203	0.1243	0.188	2.0	0.046	4.3.2	0.077
0.0736	0.176	0.1063	0.153	0.1277	0.166	0.1195	0.194	3.6	0.025	11.0	0.025
0.1026	0.163	0.1075	0.151	0.1337	0.142	0.1067	0.203	6.7	0.000	13.0	0.018
0.1216	0.252	0.1092	0.141	0.1404	0.102	0.1491	0.084	7.4	0.022	16.0	0.006
0.1436	0.136	0.1104	0.132	0.1547	0.077	0.1547	0.077	7.7	0.479	22.0	0.275
0.											

TABLE 11-17. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 17 (CONT.)			CURVE 21 (CONT.)		CURVE 25 $T = 293.$		CURVE 29 $T = 293.$		CURVE 33 $T = 293.$			
22.0	0.230	11.0	0.171	10.0	0.662	5.0	0.043	6.25	0.019			
CURVE 18 $T = 293.$		13.0	0.149	11.0	0.540	9.0	0.663	7.47	0.007			
16.0	0.084	16.0	0.084	13.0	0.515	10.0	0.220	7.62	0.049			
22.0	0.475			16.0	0.415	11.0	0.121	6.02	0.257			
5.0	0.111	CURVE 22 $T = 293.$		22.0	0.760	13.0	0.106	6.11	0.294			
10.0	0.089					16.0	0.064	6.33	0.325			
11.0	0.070			CURVE 26 $T = 293.$		22.0	0.401	6.56	0.405			
13.0	0.079	5.0	0.064					6.68	0.483			
16.0	0.108	9.0	0.766	10.0	0.361	5.0	0.033	6.81	0.656			
22.0	0.267					9.0	0.674	6.91	0.698			
CURVE 19 $T = 293.$		11.0	0.225	13.0	0.199	10.0	0.206	9.25	0.447			
16.0	0.122	16.0	0.122	11.0	0.109	9.0	0.668	9.70	0.261			
22.0	0.528					11.0	0.091	10.0	0.232	10.0	0.162	
5.0	0.024	CURVE 23 $T = 293.$		13.0	0.528	13.0	0.051	11.0	0.148	11.4	0.075	
9.0	0.693			16.0	0.528	16.0	0.051	13.0	0.141	11.6	0.065	
10.0	0.222			22.0	0.409	16.0	0.006	12.0	0.085	12.5	0.040	
11.0	0.117	CURVE 27 $T = 293.$				22.0	0.409	15.7	0.040			
13.0	0.100	5.0	0.109	10.0	0.811	9.0	0.031	16.9	0.015			
16.0	0.053	9.0	0.811	11.0	0.450	5.0	0.682	19.4	0.056			
22.0	0.411			11.0	0.306	10.0	0.207	19.8	0.164			
CURVE 20 $T = 293.$		13.0	0.281	13.0	0.196	11.0	0.106	20.6	0.498			
16.0	0.251	16.0	0.196	22.0	0.603	13.0	0.092	20.8	0.479			
22.0						16.0	0.051	22.5	0.298			
5.0	0.029	CURVE 24 $T = 293.$				22.0	0.393	11.0	0.212	23.7	0.241	
9.0	0.710							26.0	0.183			
10.0	0.251							26.0	0.202	28.9	0.146	
11.0	0.138								31.7	0.140		
13.0	0.119	5.0	0.219									
16.0	0.064	9.0	0.867	10.0	0.576	5.0	0.034					
22.0	0.436					11.0	0.447	5.0	0.685			
CURVE 21 $T = 293.$		13.0	0.415	10.0	0.212	10.0	0.212	5.0	0.196			
16.0	0.315	16.0	0.315	11.0	0.113	11.0	0.113	10.0	0.401			
22.0	0.708					13.0	0.099	11.0	0.310			
5.0	0.041					16.0	0.055	13.0	0.312			
9.0	0.734					22.0	0.399	16.0	0.264			
10.0	0.297							22.0	0.558			

f. Normal Spectral Absorptance (Wavelength Dependence)

One set of experimental data was located for the wavelength dependence of the normal spectral absorptance of vitreous silica. In addition, two sets of experimental data for crystalline quartz was located. The data are listed in Table 11-20 and shown in Figures 11-12 and 11-13. Specimen characterization and measurement information for the data are given in Table 11-19.

The data of Bogdan [T27141] (curve 3) is for a temperature of 293 K and covers a wavelength range of 0.8 to 2.60 μm . That data was calculated from reflectance and transmittance data.

Calculations were carried out to determine the wavelength dependence of the normal spectral absorptance for radiation that is polarized perpendicular to the plane of incidence (curves 4-6), the absorptance that is parallel to the plane of incidence (curves 7-9), and the absorptance for unpolarized radiation (curves 10-12). The calculations used the Fresnel equations, Eqs. (2.4-1)-(2.4-5), together with Eq. (2.4-8). For a discussion of the index of refraction and absorption index data that were used in the calculations, see the section on the wavelength dependence of the normal spectral emittance.

Provisional values for the wavelength dependence of the normal spectral absorptance were generated. The values are listed in Table 11-18 and shown in Figure 11-12. The values here were equated to the provisional values for the wavelength dependence of the normal spectral emittance. Below 7 μm the provisional values apply to a 0.50 in. thick specimen of Corning 7940 vitreous silica at 293 K and Kirchhoff's law was used to equate the normal spectral absorptance to the normal spectral emittance. Above 7 μm the provisional values are the calculated values using the Fresnel equations for unpolarized radiation, Eqs. (2.4-1)-(2.4-5) and (2.4-8). The calculated values hold for an optically smooth specimen at 293 K that is opaque and the angle of incidence is 0° . An uncertainty of 30% is assigned. For more details see the section on the wavelength dependence of the normal spectral emittance for vitreous silica. The value of the normal spectral absorptance at 10.6 μm and 293 K is 0.89.

TABLE 11-1. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICA (VITREOUS) (WAVELLENGTH DEPENDENCE)




FIGURE 11-12. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).




FIGURE 11-13. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).

TABLE 11-19. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T45698	1 T45698	Stierwalt, D. L., Bernstein, J. B., and Kirk, D. D.	1963	2.9-24	373	Crystalline Quartz	Measurement for ordinary ray; a Beckman IR-3 spectrophotometer, modified, used for measurement; this instrument evacuable and its temperature controlled by a water bath system; smooth values from figure; emittance measured, absorbance determined by applying Kirchhoff's Law, $\theta=0^\circ$.
2 T5698	2 T5698	Stierwalt, D. L., et al.	1963	3.0-23	373	Crystalline Quartz	Similar to the above specimen except measurement made for extraordinary ray.
3 T27141	3 T27141	Bogdan, L.	1964	0.80-2.60	293	Fused Quartz	Disk specimen 0.375 in. in diameter and 0.0625 in. thick; clear fused quartz blank; data from figure; temperature not given explicitly, assumed to be 293 K; author calculates absorbance (θ) from $1.0 - \rho(45^\circ, 45^\circ) - \tau(0^\circ, 0^\circ)$, angle θ presumed to be 0° .
4 A00012	4 A00012		1975	7.0-16	293		Calculations for fused silica performed for a homogeneous; smooth surface and for perpendicular component of radiation, equations (2.4-6), (2.4-1), (2.4-3), and (2.4-4); data for index of refraction, n , and absorption index, k , from [A00012]; $\theta=0^\circ$.
5 A00012	5 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta=3^\circ$.
6 A00012	6 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta=10^\circ$.
7 A00012	7 A00012		1975	7.0-16	293		Similar to the above specimen except for parallel component of radiation; equation (2.4-7) and $\theta=0^\circ$.
8 A00012	8 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta=5^\circ$.
9 A00012	9 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta=10^\circ$.
10 A00012	10 A00012		1975	7.0-16	293		Similar to the above specimen except for unpolarized radiation, equation (2.4-6) and $\theta=0^\circ$.
11 A00012	11 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta=5^\circ$.
12 A00012	12 A00012		1975	7.0-16	293		Similar to the above specimen except $\theta=10^\circ$.

TABLE 11-20. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

λ	α	CURVE 1 $T = 373.$	CURVE 1(CONT.) $T = 373.$	λ	α	CURVE 2 $T = 373.$	CURVE 2(CONT.) $T = 373.$	λ	α	CURVE 3 CURVE 3(CONT.)	λ	α	CURVE 4 CURVE 4(CONT.)
2.93	0.190	10.60	0.881	12.08	0.734	1.40	0.368	9.30	0.5473				
3.11	0.238	11.04	0.915	3.01	0.151	1.3.13	0.827	1.60	0.021	9.35	0.5836		
3.11	0.266	11.63	0.942	3.22	0.185	13.29	1.871	1.80	0.919	9.40	0.6894		
3.26	0.288	12.19	0.966	3.47	0.343	13.70	0.913	2.00	0.223	9.50	0.6567		
3.43	0.327	12.44	0.951	3.64	0.495	14.13	0.921	2.20	0.036	9.60	0.6871		
3.53	0.479	12.65	0.731	3.80	0.621	14.89	0.939	2.40	0.051	9.70	0.7159		
3.74	0.659	12.72	0.706	4.07	0.752	15.73	0.959	2.60	0.349	9.80	0.7479		
3.80	0.681	12.84	0.839	4.31	0.930	16.96	3.987	10.0	0.7705				
3.81	0.761	13.06	0.882	4.74	0.951	17.41	0.389	16.2	0.8335				
3.97	0.798	13.37	0.906	5.48	0.966	17.71	0.965	10.4	0.0546				
3.97	0.856	13.66	0.923	6.72	0.988	17.97	0.896	7.30	0.99940				
4.05	0.900	14.16	0.934	7.39	0.988	18.22	0.668	7.19	0.99960				
4.12	0.926	14.39	0.893	7.73	0.953	18.35	0.556	7.20	0.9999				
4.31	0.949	14.60	0.916	7.91	0.928	18.43	1.524	7.30	0.9999				
4.70	0.963	14.99	0.924	7.95	0.600	18.75	3.478	7.40	0.9995				
5.43	0.976	16.28	0.558	7.97	0.869	19.12	0.472	7.50	0.9985				
6.12	0.988	17.72	0.986	8.15	0.481	19.41	0.502	7.60	0.9969				
6.68	0.997	18.39	0.996	8.33	0.307	19.59	0.586	7.70	0.9071				
7.46	0.997	18.87	0.996	8.33	0.254	19.89	0.383	7.80	0.9796				
7.64	0.974	19.16	0.983	8.52	0.230	19.98	0.322	7.90	0.9489				
7.91	0.928	19.36	0.947	9.60	0.246	20.13	0.302	8.00	0.8649				
7.97	0.869	19.48	0.861	9.72	0.229	20.36	0.355	8.10	0.7319				
7.95	0.600	19.52	0.651	9.84	0.211	20.50	0.448	8.20	0.6863				
8.15	0.481	19.87	0.395	8.93	0.161	20.65	0.518	8.30	0.6936				
8.32	0.314	20.07	0.249	9.09	0.147	21.03	0.554	8.40	0.640				
8.49	0.264	20.37	0.196	9.16	0.181	21.64	0.590	8.50	0.6318				
8.56	0.349	20.71	0.165	9.27	0.244	21.95	0.618	8.60	0.5784				
8.64	0.402	21.06	0.155	9.35	0.345	22.24	0.659	8.65	0.5387				
8.76	0.292	21.55	0.173	9.50	0.625	22.53	0.693	8.70	0.4793				
8.85	0.225	21.84	0.202	9.54	0.711	22.76	0.725	8.75	0.4334				
9.01	0.163	22.15	0.294	9.63	0.719	23.45	0.779	8.80	0.3675				
9.16	0.189	22.38	0.448	9.79	0.766	10.30	0.829	8.85	0.3206				
9.27	0.244	22.51	0.577	10.60	0.619	10.60	0.858	8.90	0.2982				
9.35	0.345	22.60	0.294	11.03	0.897	11.03	0.903	9.00	0.2813				
9.50	0.625	23.07	0.672	11.43	0.924	11.43	0.609	9.05	0.3296				
9.54	0.711	23.24	1.3.13	12.36	0.951	12.36	0.650	9.10	0.3824				
9.66	0.746	23.41	0.774	12.51	0.950	12.51	0.602	9.15	0.5351				
9.85	0.797	23.88	0.840	12.51	0.875	12.76	0.779	9.20	0.4699				
10.20	0.845	12.76	0.779	12.76	0.011	12.76	0.011	12.80	0.5256				
										CURVE 5 $T = 293.$			

TABLE II-26. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORBTANCE, α)

λ	α	CURVE 5 (CONT.)	λ	α	CURVE 5 (CONT.)	λ	α	CURVE 6 (CONT.)	λ	α	CURVE 7 (CONT.)	λ	α	CURVE 8 (CONT.)
7.30	0.9999	11.2	0.9015	11.65	0.5295	14.0	0.9207	9.40	0.9094	7.50	0.9905			
7.40	0.9995	11.4	0.9077	11.70	0.4719	14.2	0.9231	9.50	0.9567	7.60	0.9969			
7.50	0.9985	11.6	0.9145	11.75	0.4259	14.4	0.9255	9.60	0.6871	7.70	0.9906			
7.60	0.9968	11.8	0.9218	11.80	0.3610	14.6	0.9324	9.70	0.7159	7.80	0.9800			
7.70	0.9903	12.0	0.9222	11.85	0.3150	15.0	0.9516	9.80	0.7479	7.90	0.9500			
7.80	0.9792	12.2	0.9165	11.90	0.2932	15.2	0.9705	9.90	0.8681	8.00	0.7370			
7.90	0.9477	12.4	0.9026	11.95	0.2769	15.4	0.7950	10.0	0.7950	8.10	0.6902			
8.00	0.3615	12.6	0.8924	12.00	0.3249	15.6	0.8335	10.2	0.8335	8.20	0.6970			
8.10	0.7268	12.8	0.8635	12.05	0.3775	15.8	0.8548	10.4	0.8548	8.30	0.6970			
8.20	0.6824	13.0	0.8891	12.10	0.5293	16.0	0.8874	10.6	0.8874	8.40	0.6668			
8.30	0.6902	13.2	0.6974	12.15	0.4645	16.2	0.9996	10.8	0.9886	8.50	0.6344			
8.40	0.6611	13.4	0.9023	12.20	0.5203	16.4	0.9999	11.0	0.9971	8.60	0.5009			
8.50	0.6291	13.6	0.9105	12.30	0.5416	16.6	0.9939	11.2	0.9023	8.65	0.5049			
8.60	0.5750	13.8	0.9183	12.35	0.5779	16.8	0.9985	11.4	0.9085	8.70	0.4614			
8.65	0.5363	14.0	0.9227	12.40	0.6034	17.0	0.9985	11.5	0.9152	8.75	0.4353			
8.70	0.4772	14.2	0.9271	12.50	0.6511	17.2	0.9969	11.6	0.9225	8.80	0.3692			
8.75	0.4315	14.4	0.8557	12.60	0.6816	17.4	0.9904	12.0	0.9229	8.85	0.3220			
8.80	0.3659	14.6	0.9342	12.70	0.7105	17.6	0.9796	12.2	0.9172	8.90	0.2994			
8.85	0.3192	16.0	0.9598	12.80	0.7426	17.90	0.9439	12.4	0.9034	8.95	0.2824			
8.90	0.2969	16.2	0.8600	12.90	0.7655	18.00	0.8649	12.6	0.8937	9.00	0.3307			
8.95	0.2802	16.4	0.7902	13.00	0.7902	18.20	0.7319	12.8	0.8814	9.05	0.3637			
9.00	0.3284	16.6	0.8292	13.20	0.8508	18.40	0.6863	13.0	0.8899	9.10	0.5365			
9.05	0.3812	16.8	0.8512	13.40	0.8940	18.6	0.6936	13.2	0.8982	9.15	0.4713			
9.10	0.5336	17.0	0.9993	13.60	0.8852	18.80	0.6318	13.5	0.9113	9.20	0.5270			
9.15	0.4686	17.20	0.9995	13.80	0.8935	19.00	0.5794	13.8	0.9190	9.35	0.5851			
9.20	0.5242	17.30	0.9996	14.00	0.9999	19.20	0.6537	14.0	0.9234	9.40	0.6908			
9.30	0.5459	17.40	0.9995	14.20	0.9054	19.40	0.4791	14.2	0.9277	9.50	0.6581			
9.35	0.5822	17.50	0.9984	14.40	0.9123	19.70	0.4334	14.4	0.9567	9.60	0.6885			
9.40	0.6680	17.60	0.9966	14.60	0.9197	19.80	0.3675	14.6	0.9346	9.70	0.7172			
9.50	0.6553	17.70	0.9897	14.80	0.9201	20.00	0.3206	14.8	0.9602	9.80	0.7492			
9.60	0.6858	17.80	0.9779	15.00	0.9144	20.20	0.2982	15.0	0.9902	9.90	0.7717			
9.70	0.7146	17.90	0.9439	15.20	0.9002	20.40	0.2813	15.2	0.7961	10.0	0.7961			
9.80	0.7466	18.00	0.8510	15.40	0.8903	20.60	0.3296	15.4	0.8346	10.2	0.8346			
9.90	0.7692	18.20	0.7112	15.60	0.8774	20.80	0.3824	15.6	0.8558	10.4	0.8558			
1.00	0.7938	18.40	0.6705	15.80	0.8165	21.00	0.3531	15.8	0.9994	10.6	0.8883			
1.02	0.8324	18.60	0.6809	16.00	0.8150	21.20	0.4699	16.0	0.9996	10.8	0.8895			
1.04	0.6538	18.80	0.6527	16.20	0.8999	21.40	0.5256	16.2	0.9999	11.0	0.8979			
1.06	0.6666	19.00	0.6212	16.40	0.9013	21.60	0.5473	16.4	0.9999	11.2	0.9031			
1.08	0.8978	19.20	0.6606	16.60	0.9162	21.80	0.5836	16.6	0.9995	11.4	0.9092			
1.10	0.8963	19.40	0.6000	16.80	0.9002	22.00	0.7293	16.8	0.7293	10.0	0.7293			

TABLE II-20. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELLENGTH DEPENDENCE) (CONTINUED)

(WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	CURVE 8 (CONT.)				CURVE 9 (CONT.)				CURVE 10 (CONT.)				CURVE 11 (CONT.)				CURVE 12 (CONT.)			
11.6	0.9159	6.75	0.4408	14.4	0.8609	9.60	0.6871	7.70	0.9946	12.6	0.9229	7.70	0.9946	12.6	0.9229	7.70	0.9946	12.6	0.9229	7.70	0.9946
11.8	0.9231	5.30	0.3740	14.6	0.9372	9.70	0.7159	7.80	0.9796	12.2	0.9172	7.80	0.9796	12.2	0.9172	7.80	0.9796	12.2	0.9172	7.80	0.9796
12.0	0.9235	6.25	0.3261	15.0	1.9613	9.80	0.7479	7.90	0.9489	12.4	0.9034	7.90	0.9489	12.4	0.9034	7.90	0.9489	12.4	0.9034	7.90	0.9489
12.2	0.9179	8.90	0.3032	9.90	0.7715	8.09	0.8646	12.5	0.8937	12.5	0.8937	8.09	0.8646	12.5	0.8937	8.09	0.8646	12.5	0.8937	8.09	0.8646
12.4	0.9042	9.35	0.2856	9.05	0.7956	10.0	0.7319	12.6	0.8814	12.6	0.8814	10.0	0.7319	12.6	0.8814	10.0	0.7319	12.6	0.8814	10.0	0.7319
12.6	0.8945	9.00	0.3342	9.00	0.7335	10.2	0.6863	13.0	0.8899	12.6	0.9229	10.2	0.6863	13.0	0.8899	10.2	0.6863	13.0	0.8899	10.2	0.6863
12.8	0.8823	9.05	0.3674	9.05	0.7649	7.00	0.9946	10.4	0.8548	13.2	0.8982	10.4	0.9946	13.2	0.8982	10.4	0.9946	13.2	0.8982	10.4	0.9946
13.0	0.8907	9.10	0.5409	9.10	0.7475	7.13	0.9946	10.6	0.8874	13.4	0.9030	10.6	0.9946	13.4	0.9030	10.6	0.9946	13.4	0.9030	10.6	0.9946
13.2	0.8990	9.15	0.6475	9.15	0.7512	7.20	0.9946	11.0	0.8971	13.6	0.9113	11.0	0.9946	13.6	0.9113	11.0	0.9946	13.6	0.9113	11.0	0.9946
13.4	0.8936	9.20	0.5312	9.20	0.7523	7.30	0.9946	11.2	0.9023	14.0	0.9234	11.2	0.9946	14.0	0.9234	11.2	0.9946	14.0	0.9234	11.2	0.9946
13.6	0.9120	9.30	0.5523	9.30	0.7512	7.40	0.9946	11.4	0.9065	14.2	0.9277	11.4	0.9946	14.2	0.9277	11.4	0.9946	14.2	0.9277	11.4	0.9946
13.8	0.9197	9.35	0.5894	9.35	0.6949	7.50	0.9946	11.6	0.9152	14.4	0.8567	11.6	0.9946	14.4	0.8567	11.6	0.9946	14.4	0.8567	11.6	0.9946
14.0	0.9241	9.40	0.6949	9.40	0.6949	7.60	0.9946	11.8	0.9225	14.6	0.9344	11.8	0.9946	14.6	0.9344	11.8	0.9946	14.6	0.9344	11.8	0.9946
14.2	0.9263	9.50	0.6623	9.50	0.6926	7.70	0.9946	12.0	0.9229	14.8	0.9602	12.0	0.9946	14.8	0.9602	12.0	0.9946	14.8	0.9602	12.0	0.9946
14.4	0.8577	9.60	0.7212	9.60	0.7212	7.80	0.9796	12.2	0.9172	15.0	0.9796	12.2	0.9796	15.0	0.9796	12.2	0.9796	15.0	0.9796	12.2	0.9796
14.6	0.9354	9.70	0.7531	9.60	0.7531	7.90	0.9489	12.4	0.9034	15.2	0.9813	12.4	0.9489	15.2	0.9813	12.4	0.9489	15.2	0.9813	12.4	0.9489
14.8	0.9606	9.80	0.7754	9.80	0.7854	9.30	0.8549	12.6	0.8937	15.4	0.9991	12.6	0.8549	15.4	0.9991	12.6	0.8549	15.4	0.9991	12.6	0.8549
15.0	0.9606	9.90	0.7797	9.90	0.7797	9.10	0.7313	12.8	0.8814	15.6	0.9991	12.8	0.7313	15.6	0.9991	12.8	0.7313	15.6	0.9991	12.8	0.7313
15.2	0.9354	9.70	0.8378	10.2	0.8588	9.20	0.6663	13.0	0.8899	15.8	0.9994	9.20	0.8588	15.8	0.9994	9.20	0.8588	15.8	0.9994	9.20	0.8588
15.4	0.9606	9.80	0.8920	10.6	0.8920	9.30	0.6910	13.2	0.8982	16.0	0.9996	9.30	0.8920	16.0	0.9996	9.30	0.8920	16.0	0.9996	9.30	0.8920
15.6	0.9606	9.90	0.9044	11.0	0.9044	9.60	0.5784	13.4	0.9030	16.2	0.9999	9.60	0.9044	16.2	0.9999	9.60	0.9044	16.2	0.9999	9.60	0.9044
15.8	0.9999	11.0	0.9055	11.2	0.9055	9.65	0.5387	14.0	0.9234	16.4	0.9999	9.65	0.9055	16.4	0.9999	9.65	0.9055	16.4	0.9999	9.65	0.9055
16.0	0.9996	11.4	0.9115	9.70	0.4793	14.2	0.9277	16.6	0.9567	16.6	0.9567	14.2	0.9277	16.6	0.9567	14.2	0.9277	16.6	0.9567	14.2	0.9277
16.2	0.9996	11.6	0.9181	9.75	0.4334	14.4	0.9567	16.8	0.9871	17.0	0.9344	14.4	0.9567	16.8	0.9871	14.4	0.9567	16.8	0.9871	14.4	0.9567
16.4	0.9971	11.8	0.9251	9.80	0.3675	14.6	0.9348	17.0	0.9796	17.2	0.9796	14.6	0.9348	17.0	0.9796	14.6	0.9348	17.0	0.9796	14.6	0.9348
16.6	0.9911	12.0	0.9256	9.85	0.3206	16.0	0.9602	17.2	0.9796	17.4	0.9796	16.0	0.9602	17.2	0.9796	16.0	0.9602	17.2	0.9796	16.0	0.9602
16.8	0.9813	12.2	0.9201	9.90	0.2982	9.30	0.8994	17.4	0.7765	17.6	0.8643	9.30	0.8994	17.6	0.8643	9.30	0.8994	17.6	0.8643	9.30	0.8994
17.0	0.9536	12.4	0.9066	9.95	0.2813	9.30	0.7950	17.6	0.7765	17.8	0.7307	9.30	0.7950	17.8	0.7307	9.30	0.7950	17.8	0.7307	9.30	0.7950
17.2	0.8777	12.6	0.8970	9.30	0.3296	9.05	0.3824	10.4	0.8548	18.0	0.6931	9.05	0.3824	18.0	0.6931	9.05	0.3824	18.0	0.6931	9.05	0.3824
17.4	0.9813	13.0	0.8933	9.10	0.5351	7.00	0.9994	10.6	0.8874	18.2	0.6637	9.10	0.9994	18.2	0.6637	9.10	0.9994	18.2	0.6637	9.10	0.9994
17.6	0.9813	13.2	0.9014	9.15	0.4699	7.13	0.9996	10.8	0.8866	18.4	0.6316	9.15	0.9996	18.4	0.6316	9.15	0.9996	18.4	0.6316	9.15	0.9996
17.8	0.6474	13.4	0.9062	9.20	0.5256	7.23	0.9999	11.0	0.8971	18.6	0.5782	9.20	0.9999	18.6	0.5782	9.20	0.9999	18.6	0.5782	9.20	0.9999
18.0	0.6419	13.6	0.9142	9.30	0.5473	7.30	0.9999	11.2	0.9023	18.8	0.5385	9.30	0.9999	18.8	0.5385	9.30	0.9999	18.8	0.5385	9.30	0.9999
18.2	0.5876	13.8	0.9210	9.40	0.5836	7.40	0.9995	11.4	0.9152	19.0	0.4792	9.40	0.9995	19.0	0.4792	9.40	0.9995	19.0	0.4792	9.40	0.9995
18.4	0.6455	14.0	0.9261	9.40	0.6846	7.40	0.9985	11.6	0.9152	19.2	0.4334	9.40	0.9985	19.2	0.4334	9.40	0.9985	19.2	0.4334	9.40	0.9985
18.6	0.4874	14.2	0.9302	9.50	0.7062	7.50	0.9969	11.8	0.9229	19.4	0.3675	9.50	0.9969	19.4	0.3675	9.50	0.9969	19.4	0.3675	9.50	0.9969

TABLE 11-20. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)
(CONTINUED)

λ	α	λ	α	CURVE 12 (CONT.)	CURVE 12 (CONT.)	λ	α
8.05	0.3206	8.90	0.2982	16.0	0.9602		
8.95	0.2813	9.00	0.3236				
9.05	0.3824	9.10	0.5351				
9.15	0.4679	9.20	0.5256				
9.30	0.5473	9.35	0.5836				
9.40	0.6894	9.50	0.6567				
9.60	0.6871	9.70	0.7159				
9.80	0.7479	9.90	0.7704				
10.0	0.7949	10.2	0.8335				
10.4	0.8546	10.6	0.8874				
10.8	0.8886	11.0	0.8971				
11.2	0.9023	11.4	0.9084				
11.6	0.9152	11.8	0.9224				
12.0	0.9228	12.2	0.9172				
12.4	0.9074	12.6	0.8936				
12.8	0.8613	13.0	0.8699				
13.2	0.8962	13.4	0.9030				
13.6	0.9113	13.8	0.9190				
14.0	0.9234	14.2	0.9277				
14.4	0.8567	14.6	0.9348				

g. Angular Spectral Absorptance (Wavelength Dependence)

No experimental data sets were found for the wavelength dependence of the angular spectral absorptance of vitreous silica. However, a set of provisional values is listed in Table 11-21 and shown in Figure 11-14. The values were calculated using the Fresnel equations for specular reflection for unpolarized radiation (see Eqs. (2.4-1)-(2.4-5) and (2.4-8)). The context within which the provisional values are valid is a temperature of 293 K, a wavelength range of 7.0 to 16.0 μm , an angle of incidence, θ , of 40°, and an optically smooth specimen. An uncertainty of within 30% is assigned. See the section on the wavelength dependence of the angular spectral emittance for more discussion of the reasoning for the assignment of this uncertainty.

TABLE 11-21. PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	λ	α
OPTICALLY SMOOTH $T = 293$			OPTICALLY SMOOTH $\theta = 40^\circ$ $T = 293$ (CONT.)
7.00	0.999	10.4	0.849
7.10	0.999	10.6	0.881
7.20	1.000	10.8	0.882
7.30	1.000	11.0	0.890
7.40	0.999	11.2	0.896
7.50	0.998	11.4	0.902
7.60	0.995	11.6	0.908
7.70	0.951	11.8	0.915
7.80	0.950	12.0	0.916
7.90	0.822	12.2	0.910
8.00	0.686	12.4	0.896
8.10	0.577	12.6	0.867
8.20	0.588	12.8	0.875
8.30	0.615	13.0	0.883
8.40	0.609	13.2	0.891
8.50	0.585	13.4	0.896
8.60	0.541	13.6	0.904
8.65	0.507	13.8	0.912
8.70	0.455	14.0	0.917
8.75	0.414	14.2	0.921
8.80	0.354	14.4	0.848
8.85	0.312	14.6	0.928
8.90	0.293	14.8	0.954
8.95	0.280	9.00	0.330
9.05	0.384	9.10	0.534
9.15	0.472	9.20	0.527
9.30	0.544	9.35	0.564
9.40	0.687	9.50	0.656
9.60	0.686	9.70	0.714
9.80	0.745	9.90	0.767
10.0	0.791	10.2	0.828




FIGURE 11-14. PROVISIONAL ANGULAR SPECTRAL ABSORPTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).

h. Normal Spectral Transmittance (Wavelength Dependence)

A total of 38 sets of experimental data were located and processed for the category of the wavelength dependence of the normal spectral transmittance of vitreous silica. The data are listed in Table 11-24 and shown in Figures 11-15 to 11-18. Specimen characterization and measurement information for the data are given in Table 11-23. The plots of the raw data connected by lines is broken up into two figures, Figure 11-17 and 11-18. The reason for this is that the plotting routine can only plot 32 curves without repeating a symbol used to plot a curve. Therefore, it was decided to plot curves 1 through 30 on Figure 11-17 and curves 31 through 38 on Figure 11-18. The same idea was used in showing the provisional values against the background of data points in Figures 11-15 and 11-16.

With the exception of the work of Gillespie, Olsen, and Nichols [T38674] (curves 2-5) and Kroeckel [T31344] (curves 34-36), all the reported data are for room temperature. Most of the room temperature data show the usual behavior - a transmittance over 80% between 1 and 2 μm and a cut off between 4 and 5 μm . The data not showing this behavior are for a specimen 0.022 mm thick (curves 15 and 16), a specimen 6500 Å thick (curve 17), opal (curve 18), silica gel (curve 20), and fused quartz in 2 gm polyethylene binder (curve 21).

A strong word of caution needs to be expressed concerning the absorption band that can exist in the area of 2.8 to 2.9 μm . The decrease in transmittance due to this absorption band can be very large (see curves 22, 24, and 26) or barely exist (see curve 25). This decrease depends on the type of vitreous silica.

Provisional values, for various situations, are listed in Table 11-22 and shown in Figures 11-15 and 11-16. One set of values is for Dynasil 1000 and holds for a 10 mm thick specimen at 293 K with a coverage of wavelength from 0.157 to 4.39 μm . Another is applicable to a 1 mm thick specimen of Optosil 1 at 293 K. The transmittance is less than 0.005 from 5 to 16 μm . The only high temperature data that includes 3.8 μm is the data of Gillespie [T38674] (curves 1-5) for the G.E. type 106 fused quartz kind of vitreous silica. To cover the effect of temperature, two provisional curves for G.E. type 106 fused quartz are given. Both are for a 2.8 mm thick specimen and polished. One curve is for a temperature of 373 K and the other is for 673 K. An uncertainty of within 30% is assigned to all these curves because the transmittance values are low in some places with a consequently high percentage and because there is not confirmatory data for individual data sets.

TABLE I1-22. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ ; μm ; TEMPERATURE, T ; K; TRANSMITTANCE, τ)

λ	τ	DYNASIL 1000 1MM THICK $T = 293$	DYNASIL 1000 2MM THICK $T = 293$ (CONT.)	DYNASIL 1000 1MM THICK $T = 293$ (CONT.)	GE TYPE 10E 2.8MM THICK $T = 373$	GE TYPE 10E 2.9MM THICK $T = 673$	OPTOSIL 1 1MM THICK $T = 293$
0.157	0.017	1.48	0.928	3.33	0.118	2.00	0.933
0.160	0.243	1.55	0.930	4.00	0.096	2.30	0.528
0.166	0.500	1.64	0.928	4.05	0.077	2.52	0.919
0.169	0.657	1.75	0.922	4.19	0.047	2.84	0.919
0.171	0.746	1.84	0.914	4.39	0.030	3.09	0.899
0.173	0.792	1.93	0.903			3.14	0.861
0.175	0.817	1.98	0.884			3.49	0.861
0.178	0.832	2.00	0.892			3.61	0.799
0.184	0.852	2.02	0.871			3.72	0.697
0.186	0.865	2.06	0.846			3.77	0.620
0.197	0.880	2.08	0.816			3.83	0.663
0.204	0.893	2.14	0.701			3.86	0.562
0.211	0.898	2.17	0.635			3.94	0.562
0.215	0.900	2.20	0.600			4.00	0.437
0.220	0.908	2.24	0.624			4.09	0.552
0.230	0.915	2.33	0.754			4.02	0.549
0.236	0.918	2.40	0.841			4.16	0.403
0.242	0.923	2.43	0.850			4.22	0.319
0.246	0.924	2.47	0.840			4.26	0.306
0.252	0.927	2.53	0.703			4.33	0.201
0.266	0.932	2.55	0.654			4.37	0.130
0.281	0.932	2.61	0.335			4.43	0.084
0.299	0.932	2.64	0.144			4.60	0.100
0.339	0.933	2.65	0.100			4.71	0.060
0.398	0.933	2.70	0.057			4.76	0.000
0.493	0.934	2.77	0.042			5.00	0.000
0.560	0.935	2.83	0.061			5.00	0.000
0.743	0.937	2.89	0.102			6.00	0.000
0.805	0.937	2.92	0.415				
1.00	0.933	2.93	0.609				
1.22	0.930	2.95	0.743				
1.27	0.921	3.00	0.776				
1.29	0.903	3.04	0.782				
1.31	0.882	3.10	0.773				
1.32	0.869	3.38	0.529				
1.34	0.859	3.66	0.304				
1.37	0.870	3.77	0.203				
1.41	0.896	3.80	0.182				
1.43	0.915	3.84	0.154				




FIGURE 11-15. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).




FIGURE 11-16. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE).




FIGURE 11-17. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS)
(WAVELENGTH DEPENDENCE).




TABLE 11-23. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T33674	Gillespie, D. T., Giesen, A. L., and Nichols, L. W.	1965	2.0-6.0	298	Fused Quartz; GE Type 106	Disk specimen 3.150 cm in diameter and 2.8 mm thick; polished optically flat to within five green mercury fringes and a parallelism tolerance of $\pm 2.5 \mu\text{m}$; smooth values from figure; Perkin-Elmer model 21 spectrophotometer used; $\theta=0^\circ$, $\theta^*=0^\circ$. The above specimen.
2 T38674	Gillespie, D. T., et al.	1965	2.0-6.0	373	Fused Quartz; GE Type 106	The above specimen.
3 T38674	Gillespie, D. T., et al.	1965	2.0-6.0	473	Fused Quartz; GE Type 106	The above specimen.
4 T33674	Gillespie, D. T., et al.	1965	2.0-6.0	573	Fused Quartz; GE Type 106	The above specimen.
5 T35674	Gillespie, D. T., et al.	1965	2.0-6.0	673	Fused Quartz; GE Type 106	The above specimen.
6 T27141	Bogdan, L.	1964	0.80-2.6	293	Fused Quartz	Disk specimen 0.375 in. in diameter and 0.0625 in. thick; clear fused quartz blank; data from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.
7 T33655	Laulainen, N.S. and McDermott, M.N.	1966	0.19-0.30	293	Fused Silica; Suprasil II	Two 0.0625 in. disks with an air space in between disks; measurements made with Cary model 14 spectrophotometer; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.
8 T23965	Laulainen, N.S. and McDermott, M.N.	1966	0.19-0.30	293	Fused Silica; Suprasil II	Similar to the above specimen except cemented by 0.0002 in. thick d-xylene obtained from Dico Labs, Detroit.
9 T45017	Sviridov, A. A. and Sukovskaya, N. V.	1967	0.19-0.42	293	Fused Quartz	Specimen 35 mm in diameter and 2 mm thick; surfaces plane-parallel; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.
10 T34663	Calinger, G., Zeror, S. J., and Stair, R.	1936	0.31-4.0	293	Quartz	Smooth fused quartz; amorphous; cylindrical specimen approx. 5/8 in. in diameter and 5/16 in. thick; two flat surfaces polished; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.
11 T39011	Heath, D. F. and Sacher, P.A.	1966	0.16-0.30	293	Fused Silica; Dynasil Optical Grade	High purity; specimen 6.46 mm thick; measured with aid of McPherson Model 225 monochromator; possibly measured in vacuum; data from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.
12 T39011	Heath, D. F. and Sacher, P.A.	1966	0.16-0.30	293	Fused Silica; Dynasil Optical Grade	The above specimen except irradiated with 10^{14} electrons cm^{-2} at 1.0 Mev and then 10^{14} electrons cm^{-2} at 2.0 Mev, irradiation times 30 min at each energy.
13 T36011	Heath, D. F. and Sacher, P.A.	1966	0.16-0.30	293	Fused Silica; Dynasil 1850 Å	Specimen 2.04 mm thick; data from figure; possibly measured in vacuum; measure- ment temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.
14 T39011	Heath, D. F. and Sacher, P.A.	1966	0.16-0.30	293	Fused Silica; Dynasil 1850 Å	The above specimen except irradiated with 10^{14} electrons cm^{-2} at 2.0 Mev incident through a sapphire shield, 6.4 mm thick.
15 T38719	Hanek, R.	1965	3.7-7.5	293	Fused Silica	Specimen $22 \pm 2 \times 10^{-3}$ mm thick; cut and ground but not polished; smooth values from figure; Perkin-Elmer model 13U instrument used below 15 μm and above Perkin- Elmer model 201 spectrophotometer used; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.
16 T38719	Hanna, R.	1965	7.1-20	293	Fused Silica	The above specimen.
17 T30490	Howard, L.E. and Spitzer, W.G.	1961	1.0-30	293	Vitreous Silica	Specimen 6500 Å thick; Perkin-Elmer single-beam double-pass spectrometer used; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta^*=0^\circ$.

TABLE 11-2B. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICA (VITREOUS) (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature, K.	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
18 T51507	Coblenz, M. W.	1906	1.1-7.5	293	Opal	$\text{SiO}_2 + \text{H}_2\text{O}$ (opal contains varying amount of water from 5 to 30%); massive; transparent; thickness 0.12 mm; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta'=0^\circ$.
19 T35536	Grenis, A. F. and Matkovich, M. J.	1965	1.0-4.6	293	Fused Silica	Specimen approx. 5.08 cm in diameter and 3.18 mm thick; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta'=0^\circ$.
20 T43741	Bartlett, R. W. and Cage, P. R.	1964	2.0-15	293	Silica Gel	Smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta'=0^\circ$.
21 T34168	Engelhardt, A.	1965	5.9-39	293	Fused Quartz	50 mg crushed fused quartz in 2 gm polyethylene binder; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; $\theta=0^\circ$, $\theta'=0^\circ$.
22 T77041	Dynasil Corporation of America	1973	0.16-4.4	293	Dynasil 1000 Fused Silica	Typical analysis has total metallic impurity content approx. 0.0001-0.0002, water content approx. 0.06-0.1, 0.0085 Cl, <0.0001 B, 0.000020 Fe, 0.000020 Li, <0.000008 Cd, <0.000006 Ge, <0.000003 Tl, <0.000004 Bi, <0.000003 Be, <0.000002 Al, <0.000002 Ca, 0.000002 Na, 0.000006 Cr, 0.0000025 Br, 0.0000001 Au, 0.000001 Cu, 0.00000064 Sb, and the following not detected, As, Cs, Cu, Mn, Rb, Ag, Ti, V, and Zn; specimen thickness 10 mm; smooth values from figure; temperature not given explicitly, presumed to be room temperature, 293 K assigned; reflection losses are included.
23 T77041	Dynasil Corporation of America	1973	0.18-4.4	293	Dynasil 4000 Fused Silica	Similar to the above specimen.
24 A00010	Thermal American Fused Quartz Co.	0.17-4.0	293	Spectrosil Synthetic Fused Quartz	<0.00001 Ca, <0.00001 Fe, 0.000004 Na, <0.000002 Al, <0.000001 B, <0.0000004 Ga, <0.000004 K, <0.0000001 P, <0.0000001 Mn, <0.0000002 As, <0.0000002 Cu, and 0.0000001 Sb (see Hetherington, G. and Bell, L. W., "Analysis of High-Purity Synthetic Vitreous Slices," Physics and Chemistry of Glasses, 5(5), 206-8, 1967, [A00011]); 10 mm path; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.	
25 A00010	Thermal American Fused Quartz Co.	0.20-4.0	293	Vitresil I.R.	99.8% SiO_2 ; 10 mm path; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.	
26 T75991	Corning Glass Works	1971	0.16-4.4	293	Corning Code 7940 Fused Silica	Typical analysis 0.0010-0.0100 Cl, 0.00001-0.0001 Ca, 0.00001-0.0001 Ti, 0.000005-0.0005 Al, 0.000005-0.0005 Be, 0.000005-0.0005 Zn, 0.000001-0.00001 Bi, 0.00001-0.00005 Cu, 0.000001-0.0005 Fe, 0.000001-0.00001 K, 0.000001-0.00001 Mg, 0.000001-0.0001 P, 0.000001-0.00001 V, 0.000001-0.000005 As, 0.0000001-0.000005 Cr, 0.0000001-0.000001 Mn, and 0.000001-0.000005 Sb, maximum total impurities other than water do not exceed 0.01, water content estimated at 0.1 or less; amorphous, made by flame hydrolysis; specimen 10 mm thick; minimum transmittance for U.V. grades; surface reflections included; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
27 T76891	Corning Glass Works	1971	0.18-4.4	293	Corning Code 7940 Fused Silica	Similar to the above specimen except minimum transmittance values for optical and industrial grades.
28 T76891	Corning Glass Works	1971	0.16-0.19	293	Corning Code 7940 Fused Silica	Same typical analysis, impurity content, and method of fabrication as above; specimen 10 mm thick; U.V. grade; surface reflections included smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K.
29 T76891	Corning Glass Works	1971	0.16-0.18	293	Corning Code 7940 Fused Silica	Similar to the above specimen except 5 mm thick.

TABLE 11-23. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
30 T76991	Corning Glass Works	1971	0.15-0.19	293	Corning Code 7940 Fused Silica	Similar to the above specimen except 1 mm thick.
31 T76991	Corning Glass Works	1971	0.15-0.19	293	Corning Code 7940 Fused Silica	Similar to the above specimen except 0.5 mm thick.
32 T76991	Corning Glass Works	1971	1.0-4.6	298	Corning Code 7940 Fused Silica	Same typical analysis, impurity content, and method of fabrication as above; specimen 5.0 mm thick.
33 T31344	Kroeckel, O.	1964	0.82-3.2	293	Quartz Glass	Smooth values from figure; relative error in transmission of 3.5%; $\theta=0^\circ$, $\theta'=0^\circ$.
34 T31344	Kroeckel, O.	1964	0.83-3.2	773	Quartz Glass	Similar to the above specimen.
35 T31344	Kroeckel, O.	1964	0.84-3.2	973	Quartz Glass	Similar to the above specimen.
36 T31344	Kroeckel, O.	1964	0.83-3.2	1173	Quartz Glass	Similar to the above specimen.
37 T30300	McCarthy, D.E.	1963	2.0-50	293	Quartz	Synthetic; specimen 2 mm thick; ground and polished to a flatness of seven fringes or better; reference standard was aluminum mirror; smooth values from figure; measurement temperature not given explicitly, assumed to be 293 K; Beckman IR-5A used in 2-15 μm range and Beckman IR-7 with Csl interchanger used in 12.5-50 μm range; $\theta=0^\circ$, $\theta'=0^\circ$.
38 A00000	Champetier, R.J. and Friese, G.J.	1974	3.7-16	293	Optoeil 1 Fused Silica	Specimen 1 mm thick; measured at Aerospace Corporation's Material Sciences Laboratory; measurement temperature not given explicitly, assumed to be 293 K; complete opacity (< 0.005 transmittance from 3.7 to at least 16 μm) ; $\theta=0^\circ$, $\theta'=0^\circ$.

TABLE II-20. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, T]

λ	τ	CURVE 1 $T = 298.$			CURVE 2 (CONT.)			CURVE 4 (CONT.)			CURVE 6			CURVE 8 (CONT.)			CURVE 10 $T = 293.$			CURVE 12 $T = 293.$			
2.00	0.933	4.33	0.201	1.52	0.863	0.734	0.400	0.920	0.243	0.921	0.1697	0.591	0.1601	0.000	0.1614	0.002	0.1628	0.029	0.1641	0.071	0.1652	0.148	
2.31	0.926	4.37	0.130	1.69	0.734	0.544	0.400	0.920	0.291	0.942	0.1748	0.696	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
2.53	0.919	4.46	0.084	3.92	0.544	0.402	0.473	0.921	0.850	0.921	0.1795	0.769	0.1620	0.045	0.1636	0.091	0.1639	0.117	0.1641	0.141	0.1652	0.167	
2.64	0.919	4.60	0.100	4.02	0.473	0.402	0.473	0.921	0.900	0.926	0.1849	0.795	0.1620	0.045	0.1636	0.091	0.1639	0.117	0.1641	0.141	0.1652	0.167	
2.77	0.620	4.71	0.060	4.07	0.440	0.407	0.440	0.921	0.950	0.924	0.1896	0.817	0.1620	0.045	0.1636	0.091	0.1639	0.117	0.1641	0.141	0.1652	0.167	
3.15	0.881	4.76	0.228	4.15	0.349	1.60	0.928	0.1946	0.243	0.921	0.1697	0.591	0.2097	0.077	0.2148	0.0837	0.2196	0.901	0.2247	0.907	0.2296	0.924	
3.49	0.881	4.86	0.000	4.20	0.274	1.20	0.936	0.1997	0.291	0.942	0.1748	0.696	0.2045	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
3.72	0.715	6.00	0.000	4.29	0.256	1.40	0.934	0.2045	0.349	1.60	0.929	0.1896	0.817	0.2100	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939
3.77	0.620	4.77	0.578	4.34	0.167	1.60	0.929	0.2097	0.310	0.912	0.1896	0.817	0.2097	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
3.84	0.578	4.83	0.565	4.44	0.074	2.00	0.939	0.2148	0.750	0.914	0.1896	0.817	0.2148	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.22	0.328	4.72	0.074	4.72	0.435	2.20	0.939	0.2196	0.915	0.915	0.1896	0.817	0.2196	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.30	0.318	4.80	0.933	4.78	0.022	2.40	0.929	0.2247	0.915	0.915	0.1896	0.817	0.2247	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.34	0.196	4.31	0.926	4.86	0.000	2.69	0.944	0.2296	0.915	0.915	0.1896	0.817	0.2296	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.40	0.119	2.52	0.919	6.00	0.000	2.46	0.914	0.2400	0.915	0.915	0.1896	0.817	0.2400	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.48	0.085	2.84	0.919	3.14	0.881	2.85	0.909	0.2449	0.915	0.915	0.1896	0.817	0.2449	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.60	0.125	3.52	0.662	3.52	0.662	3.00	0.933	0.2497	0.915	0.915	0.1896	0.817	0.2497	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.65	0.097	3.52	0.662	3.68	0.734	3.14	0.919	0.2550	0.915	0.915	0.1896	0.817	0.2550	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.76	0.035	3.68	0.734	3.84	0.549	2.00	0.933	0.2598	0.915	0.915	0.1896	0.817	0.2598	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.86	0.000	3.84	0.549	4.00	0.933	2.98	0.765	0.2649	0.915	0.915	0.1896	0.817	0.2649	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
6.00	0.000	3.98	0.516	2.30	0.928	2.20	0.831	0.2697	0.915	0.915	0.1896	0.817	0.2697	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.10	0.406	4.10	0.406	2.52	0.919	2.22	0.864	0.2748	0.915	0.915	0.1896	0.817	0.2748	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.20	0.267	4.20	0.267	2.64	0.919	2.45	0.887	0.2798	0.915	0.915	0.1896	0.817	0.2798	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.30	0.176	4.35	0.176	3.37	0.872	3.37	0.872	0.2846	0.915	0.915	0.1896	0.817	0.2846	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.38	0.124	4.48	0.084	3.52	0.852	3.67	0.721	0.2898	0.915	0.915	0.1896	0.817	0.2898	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
4.52	0.919	4.70	0.658	3.83	0.490	3.97	0.121	0.3000	0.915	0.915	0.1896	0.817	0.3000	0.0867	0.2148	0.0837	0.2247	0.901	0.2296	0.924	0.2348	0.939	
2.00	0.933	4.919	0.224	3.90	0.459	0.193	0.739	0.000	0.2550	0.849	0.1601	0.000	0.1601	0.000	0.1614	0.002	0.1628	0.029	0.1641	0.071	0.1652	0.148	
2.30	0.929	4.86	0.600	4.00	0.437	2.00	0.761	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
2.52	0.919	4.70	0.658	4.76	0.224	1.17	0.246	0.222	0.817	0.1620	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148		
3.14	0.881	4.86	0.600	4.11	0.352	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
3.49	0.881	4.86	0.600	4.11	0.352	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
3.61	0.799	4.71	0.697	4.71	0.224	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
3.72	0.620	5.73	0.573	4.31	0.224	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
3.86	0.562	2.00	0.933	4.47	0.052	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
3.94	0.562	2.31	0.928	4.71	0.031	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
4.62	0.549	4.66	0.403	4.86	0.224	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
4.16	0.403	4.86	0.600	4.86	0.224	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
4.22	0.316	4.86	0.919	4.86	0.224	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	
4.28	0.308	3.14	0.681	4.76	0.224	0.210	0.800	0.1620	0.3000	0.851	0.1601	0.000	0.1620	0.018	0.1620	0.018	0.1628	0.029	0.1641	0.071	0.1652	0.148	

TABLE 11-24. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA (VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 12 (CONT.)		CURVE 13 (CONT.)		CURVE 14 (CONT.)		CURVE 15 (CONT.)		CURVE 16 (CONT.)		CURVE 17 (CONT.)	
0.1848	0.698	0.1952	0.861	0.2051	0.894	0.44	0.719	1.43	0.856	21.20	0.336		
0.1697	0.725	0.1999	0.872	0.2110	0.902	0.76	0.706	2.13	0.992	21.38	0.284		
0.1948	0.736	0.2053	0.875	0.2143	0.909	0.95	0.687	2.53	0.956	21.65	0.235		
0.1997	0.749	0.2102	0.886	0.2250	0.901	7.15	0.663	3.51	0.894	22.36	0.276		
0.2046	0.735	0.2150	0.899	0.2301	0.910	7.34	0.619	4.51	0.910	22.87	0.360		
0.2097	0.740	0.2200	0.905	0.2351	0.922	7.52	0.574	5.50	0.948	23.43	0.456		
0.2148	0.753	0.2249	0.903	0.2399	0.914	6.45	0.907	24.42	0.580				
0.2197	0.756	0.2300	0.912	0.2450	0.921	7.02	1.00	25.04	0.644				
0.2247	0.784	0.2350	0.912	0.2499	0.919	7.71	0.931	25.89	0.730				
0.2298	0.793	0.2400	0.908	0.2550	0.927	7.93	0.858	26.98	0.786				
0.2347	0.817	0.2453	0.921	0.2599	0.923	7.14	0.680	27.55	0.811				
0.2396	0.841	0.2500	0.918	0.2643	0.923	7.29	0.654	28.35	0.840				
0.2448	0.855	0.2550	0.928	0.2731	0.927	7.43	0.617	29.04	0.861				
0.2496	0.869	0.2600	0.936	0.2752	0.924	7.51	0.556	0.403	30.42	0.895			
0.2549	0.885	0.2646	0.939	0.2799	0.927	7.79	0.590	0.170	1.07				
0.2599	0.890	0.2704	0.940	0.2853	0.929	7.91	0.026	9.10	0.049				
0.2648	0.891	0.2751	0.942	0.2932	0.929	8.04	0.000	9.54	0.116				
0.2697	0.913	0.2796	0.928	0.2948	0.926	9.94	0.000	9.69	0.236				
0.2748	0.916	0.2850	0.929	0.3030	0.907	10.1	0.057	9.71	0.278				
0.2799	0.930	0.2902	0.937	0.3080	0.413	9.85	0.360	1.19	0.662				
0.2848	0.928	0.2946	0.942	0.2932	0.493	9.99	0.461	1.32	0.574				
0.2899	0.929	0.3000	0.927	0.3080	0.456	10.06	0.552	1.40	0.669				
0.2951	0.925	0.3000	0.929	0.3080	0.677	10.16	0.646	1.49	0.880				
0.3000	0.929	CURVE 14 $T = 293.$		11.6	0.034	10.00	0.782	1.55	0.897				
0.1595	0.004	0.1599	0.011	0.1793	0.000	11.78	0.831	1.79	0.910				
0.1607	0.044	0.2200	0.909	0.44	0.810	12.0	0.106	12.09	0.758				
0.1631	0.193	0.1649	0.359	0.1631	0.193	13.1	0.168	12.48	0.686				
0.1647	0.359	0.1667	0.560	0.1667	0.612	13.5	0.212	12.92	0.803				
0.1656	0.469	0.1667	0.612	0.1702	0.762	14.0	0.236	13.41	0.866				
0.1667	0.576	0.1667	0.612	0.1750	0.849	14.7	0.245	14.47	0.908				
0.1701	0.763	0.1799	0.669	0.1750	0.849	15.5	0.229	16.37	0.911				
0.1749	0.924	0.1850	0.875	0.1904	0.881	16.9	0.156	17.37	0.895				
0.1803	0.845	0.1951	0.896	0.1951	0.899	18.2	0.075	18.65	0.876				
0.1850	0.853	0.1999	0.900	0.1999	0.900	19.5	0.000	19.61	0.853				
0.1901	0.855	0.1999	0.900	0.1999	0.900	20.76	0.544	20.47	0.606				
				6.37	0.713	20.96	0.453	3.11	0.664				
					1.03	0.983		3.20	0.889				

TABLE II-24. EXPERIMENTAL NCFL SPETRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 18 (CONT.)				CURVE 19 (CONT.)				CURVE 20 (CONT.)				CURVE 21 (CONT.)				CURVE 22 (CONT.)				CURVE 22 (CONT.)									
λ	T	λ	T																										
3.34	0.217	2.39	0.936	4.6	1.297	9.97	0.178	0.832	2.06	0.946	0.502	0.164	0.852	2.08	0.816	0.502	0.164	0.852	2.08	0.816	0.502	0.164	0.852	2.08					
3.47	0.373	2.58	0.902	4.6	0.241	10.5	0.215	0.900	2.14	0.701	0.513	0.188	0.865	2.14	0.701	0.513	0.188	0.865	2.14	0.701	0.513	0.188	0.865	2.14					
3.62	0.512	2.67	0.843	3.1	0.175	10.6	0.197	0.880	2.17	0.635	0.132	0.748	0.197	0.880	2.17	0.635	0.132	0.748	0.197	0.880	2.17	0.635	0.132	0.748	0.197				
3.82	0.606	2.81	0.900	3.2	0.132	10.9	0.197	0.880	2.17	0.635	0.901	0.127	0.722	0.204	0.890	2.20	0.600	0.901	0.127	0.722	0.204	0.890	2.20	0.600	0.901	0.127	0.722	0.204	
3.94	0.613	3.02	0.891	3.3	0.127	11.0	0.204	0.890	2.20	0.600	0.891	0.127	0.722	0.204	0.890	2.20	0.600	0.891	0.127	0.722	0.204	0.890	2.20	0.600	0.891	0.127	0.722	0.204	
4.06	0.556	3.26	0.896	3.4	0.157	11.4	0.211	0.890	2.24	0.624	0.896	0.157	0.751	0.211	0.890	2.24	0.624	0.896	0.157	0.751	0.211	0.890	2.24	0.624	0.896	0.157	0.751	0.211	
4.10	0.512	3.37	0.882	3.5	0.407	11.6	0.215	0.900	2.33	0.754	0.882	0.672	0.681	0.215	0.900	2.33	0.754	0.882	0.672	0.681	0.215	0.900	2.33	0.754	0.882	0.672	0.681	0.215	
4.21	0.467	3.67	0.567	3.6	0.672	13.0	0.220	0.908	2.40	0.841	0.567	1.9	0.554	0.220	0.908	2.40	0.841	0.567	1.9	0.554	0.220	0.908	2.40	0.841	0.567	1.9	0.554	0.220	
4.33	0.485	3.86	0.531	3.9	0.715	13.1	0.457	0.730	0.915	2.43	0.850	0.715	12.1	0.457	0.730	0.915	2.43	0.850	0.715	12.1	0.457	0.730	0.915	2.43	0.850	0.715	12.1	0.457	0.730
4.47	0.495	4.15	0.579	4.3	0.735	13.3	0.431	0.736	0.916	2.47	0.860	0.735	12.4	0.431	0.736	0.916	2.47	0.860	0.735	12.4	0.431	0.736	0.916	2.47	0.860	0.735	12.4	0.431	0.736
4.58	0.457	4.26	0.543	4.5	0.726	13.5	0.444	0.742	0.923	2.53	0.793	0.543	12.5	0.444	0.742	0.923	2.53	0.793	0.543	12.5	0.444	0.742	0.923	2.53	0.793	0.543	12.5	0.444	0.742
4.74	0.367	4.49	0.077	4.9	0.710	13.6	0.643	0.924	2.55	0.654	0.077	12.6	0.643	0.924	0.924	2.55	0.654	0.077	12.6	0.643	0.924	0.924	2.55	0.654	0.077	12.6	0.643	0.924	
4.85	0.247	4.62	0.000	5.3	0.635	13.9	0.252	0.927	2.61	0.335	0.635	13.0	0.720	0.252	0.927	2.61	0.335	0.635	13.0	0.720	0.252	0.927	2.61	0.335	0.635	13.0	0.720	0.252	
5.00	0.162	5.11	0.165	5.5	0.880	14.0	0.910	0.932	2.64	0.144	0.880	13.2	0.910	0.932	0.932	2.64	0.144	0.880	13.2	0.910	0.932	0.932	2.64	0.144	0.880	13.2	0.910	0.932	
5.22	0.103	5.27	0.091	5.6	0.767	15.1	0.281	0.932	2.65	0.107	0.767	13.2	0.908	0.281	0.932	2.65	0.107	0.767	13.2	0.908	0.281	0.932	2.65	0.107	0.767	13.2	0.908	0.281	
5.33	0.100	5.33	0.100	5.9	0.714	15.2	0.339	0.933	2.77	0.042	0.714	13.3	0.933	0.339	0.933	2.77	0.042	0.714	13.3	0.933	0.339	0.933	2.77	0.042	0.714	13.3	0.933	0.339	
5.46	0.146	5.46	0.146	6.3	0.525	15.5	0.903	0.934	2.83	0.061	0.525	13.5	0.903	0.934	0.934	2.83	0.061	0.525	13.5	0.903	0.934	0.934	2.83	0.061	0.525	13.5	0.903	0.934	
5.55	0.168	5.55	0.143	6.7	0.594	14.5	0.901	0.935	2.89	0.415	0.168	14.5	0.901	0.935	0.935	2.89	0.415	0.168	14.5	0.901	0.935	0.935	2.89	0.415	0.168	14.5	0.901	0.935	
5.65	0.143	5.74	0.114	7.0	0.576	14.9	0.878	0.999	2.93	0.689	0.143	14.9	0.878	0.999	0.999	2.93	0.689	0.143	14.9	0.878	0.999	0.999	2.93	0.689	0.143	14.9	0.878	0.999	
5.74	0.096	5.82	0.068	7.4	0.683	15.1	0.827	0.913	2.97	0.743	0.096	15.0	0.827	0.913	0.913	2.97	0.743	0.096	15.0	0.827	0.913	0.913	2.97	0.743	0.096	15.0	0.827	0.913	
5.82	0.068	5.94	0.024	7.8	0.775	15.2	0.847	0.913	3.00	0.776	0.068	15.2	0.847	0.913	0.913	3.00	0.776	0.068	15.2	0.847	0.913	0.913	3.00	0.776	0.068	15.2	0.847	0.913	
6.00	0.020	6.00	0.020	8.4	0.791	15.4	0.202	0.921	3.10	0.773	0.020	15.4	0.791	0.202	0.921	3.10	0.773	0.020	15.4	0.791	0.202	0.921	3.10	0.773	0.020	15.4	0.791	0.202	
6.14	0.129	6.25	0.052	4.5	0.632	15.5	0.822	0.903	3.18	0.529	0.129	15.5	0.632	0.822	0.903	3.18	0.529	0.129	15.5	0.632	0.822	0.903	3.18	0.529	0.129	15.5	0.632	0.822	
6.35	0.096	6.35	0.096	5.7	0.914	15.7	0.884	0.939	3.24	0.862	0.096	15.7	0.884	0.939	0.939	3.24	0.862	0.096	15.7	0.884	0.939	0.939	3.24	0.862	0.096	15.7	0.884	0.939	
6.45	0.084	6.45	0.084	6.0	0.942	16.0	0.51	0.659	3.31	0.869	0.084	16.0	0.51	0.659	0.659	3.31	0.869	0.084	16.0	0.51	0.659	0.659	3.31	0.869	0.084	16.0	0.51	0.659	
6.56	0.084	6.74	0.076	6.3	0.941	16.3	0.695	0.625	3.45	0.864	0.084	16.3	0.695	0.625	0.625	3.45	0.864	0.084	16.3	0.695	0.625	0.625	3.45	0.864	0.084	16.3	0.695	0.625	
6.84	0.062	6.84	0.062	6.5	0.954	16.5	0.521	0.521	3.57	0.864	0.062	16.5	0.521	0.521	0.521	3.57	0.864	0.062	16.5	0.521	0.521	0.521	3.57	0.864	0.062	16.5	0.521	0.521	
7.07	0.041	7.07	0.041	6.8	0.901	16.7	0.667	0.466	3.71	0.864	0.041	16.7	0.667	0.466	0.466	3.71	0.864	0.041	16.7	0.667	0.466	0.466	3.71	0.864	0.041	16.7	0.667	0.466	
7.31	0.015	7.49	0.000	7.4	0.968	17.4	0.392	0.117	3.89	0.864	0.015	17.4	0.392	0.117	0.117	3.89	0.864	0.015	17.4	0.392	0.117	0.117	3.89	0.864	0.015	17.4	0.392	0.117	
7.49	0.000	7.49	0.000	7.6	0.971	17.6	0.297	0.160	3.97	0.864	0.000	17.6	0.297	0.160	0.160	3.97	0.864	0.000	17.6	0.297	0.160	0.160	3.97	0.864	0.000	17.6	0.297	0.160	
1.00	0.938	1.00	0.938	8.0	0.533	17.9	0.762	0.095	4.06	0.864	0.533	0.017	0.171	0.017	0.171	4.06	0.864	0.533	0.017	0.171	0.017	0.171	4.06	0.864	0.533	0.017	0.171	0.017	

TABLE 11-24. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ ; μm ; TEMPERATURE, T ; K; TRANSMITTANCE, τ)

λ	τ	CURVE 23(CONT.)		CURVE 23(CONT.)		CURVE 24(CONT.)		CURVE 24(CONT.)		CURVE 25(CONT.)		CURVE 25(CONT.)		CURVE 26(CONT.)	
0.186	0.046	2.14	0.701	0.177	0.865	2.866	0.640	0.275	0.954	0.231	0.816	0.209	0.840	0.231	0.816
0.197	0.061	2.17	0.635	0.179	0.932	2.922	0.711	0.246	0.964	0.209	0.840	0.220	0.869	0.220	0.869
0.204	0.141	2.20	0.600	0.161	0.924	3.026	1.775	0.304	0.969	0.169	0.565	0.169	0.565	0.169	0.565
0.211	0.207	2.24	0.624	0.153	0.940	3.130	0.824	0.329	0.969	0.172	0.636	0.172	0.636	0.172	0.636
0.216	0.269	2.33	0.754	0.189	0.953	3.243	0.868	1.000	0.957	0.181	0.718	0.181	0.718	0.181	0.718
0.221	0.357	2.40	0.841	0.195	0.963	3.412	0.804	2.535	0.957	0.251	0.906	0.261	0.909	0.261	0.909
0.230	0.511	2.43	0.650	0.207	0.973	3.491	0.716	2.605	0.941	0.250	0.903	0.330	0.911	0.330	0.911
0.236	0.672	2.47	0.840	0.227	0.961	3.563	0.599	2.666	0.878	0.267	0.888	0.398	0.911	0.398	0.911
0.242	0.787	2.53	0.703	0.279	0.969	3.602	0.467	2.785	0.909	0.300	0.864	1.000	0.911	1.000	0.911
0.246	0.834	2.55	0.654	0.329	0.969	3.626	0.387	2.816	0.909	0.333	0.850	1.126	0.911	1.126	0.911
0.252	0.971	2.61	0.335	0.350	0.969	3.699	0.315	2.892	0.885	0.373	0.850	1.215	0.903	1.215	0.903
0.266	0.396	2.54	0.144	1.126	0.969	3.778	0.267	3.025	0.873	0.469	0.866	1.267	0.888	1.267	0.888
0.281	0.913	2.65	0.100	1.177	0.982	3.874	0.267	3.231	0.869	0.500	0.864	1.303	0.864	1.303	0.864
0.296	0.522	2.70	0.057	1.217	0.960	3.897	0.242	3.318	0.802	0.533	0.853	1.333	0.850	1.333	0.850
0.339	0.926	2.77	0.642	1.330	0.967	4.000	0.231	3.446	0.639	0.551	0.850	1.395	0.850	1.395	0.850
0.398	0.931	2.83	0.661	1.351	0.973	3.800	0.267	3.478	0.486	0.551	0.850	1.437	0.860	1.437	0.860
0.493	0.934	2.89	0.102	1.407	0.996	3.996	0.231	3.531	0.362	0.551	0.850	1.471	0.877	1.471	0.877
0.560	0.335	2.92	0.415	1.523	0.993	3.993	0.231	3.605	0.289	0.551	0.850	1.551	0.907	1.551	0.907
0.743	0.937	2.93	0.689	1.692	0.988	3.993	0.231	3.637	0.264	0.551	0.850	1.727	0.907	1.727	0.907
0.805	0.937	2.95	0.743	1.845	0.976	3.993	0.231	3.679	0.254	0.551	0.850	1.795	0.911	1.795	0.911
1.00	0.933	3.00	0.776	2.001	0.957	3.993	0.201	3.795	0.246	0.551	0.850	2.020	0.902	2.020	0.902
1.22	0.930	3.04	0.742	2.072	0.942	3.993	0.205	4.25	0.225	0.551	0.850	2.134	0.633	2.134	0.633
1.27	0.921	3.10	0.773	2.136	0.951	3.993	0.208	4.67	0.213	0.551	0.850	2.157	0.616	2.157	0.616
1.29	0.903	3.38	0.529	2.156	0.670	3.925	0.211	5.36	0.210	0.551	0.850	2.184	0.609	2.184	0.609
1.31	0.882	3.66	0.304	2.184	0.564	3.925	0.215	6.32	0.242	0.551	0.850	2.218	0.619	2.218	0.619
1.32	0.869	3.77	0.203	2.261	0.765	3.925	0.219	7.28	0.222	0.551	0.850	2.242	0.653	2.242	0.653
1.34	0.859	3.80	0.182	2.293	0.877	3.925	0.222	7.64	0.222	0.551	0.850	2.313	0.856	2.313	0.856
1.37	0.870	3.84	0.154	2.327	0.925	3.925	0.225	7.81	0.225	0.551	0.850	2.336	0.867	2.336	0.867
1.41	0.898	3.93	0.116	2.403	0.368	3.925	0.229	7.81	0.229	0.551	0.850	2.452	0.857	2.452	0.857
1.43	0.915	4.06	0.177	2.445	0.745	3.925	0.232	7.60	0.232	0.551	0.850	2.519	0.867	2.519	0.867
1.48	0.925	4.19	0.047	2.445	0.612	3.925	0.236	7.10	0.236	0.551	0.850	2.459	0.857	2.459	0.857
1.55	0.930	4.39	0.000	2.517	0.544	3.925	0.239	7.01	0.239	0.551	0.850	2.463	0.860	2.463	0.860
1.64	0.928	4.37	0.070	2.575	0.456	3.925	0.242	7.01	0.242	0.551	0.850	2.560	0.453	2.560	0.453
1.75	0.922	4.06	0.177	2.601	0.579	3.925	0.245	7.19	0.245	0.551	0.850	2.652	0.214	2.652	0.214
1.84	0.914	4.06	0.136	2.601	0.236	3.925	0.248	7.52	0.248	0.551	0.850	2.718	0.057	2.718	0.057
1.93	0.903	4.06	0.061	2.629	0.061	3.925	0.250	7.94	0.250	0.551	0.850	2.745	0.027	2.745	0.027
1.98	0.888	4.165	0.123	2.661	0.008	3.925	0.255	8.59	0.255	0.551	0.850	2.799	0.013	2.799	0.013
2.02	0.871	4.165	0.229	2.799	0.000	3.925	0.257	9.01	0.257	0.551	0.850	2.863	0.023	2.863	0.023
2.06	0.946	4.168	0.423	2.831	0.206	3.925	0.261	9.23	0.261	0.551	0.850	2.898	0.037	2.898	0.037
2.08	0.915	4.174	0.711	2.931	0.526	3.925	0.267	9.34	0.267	0.551	0.850	2.908	0.071	2.908	0.071

TABLE 11-24. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 11-24. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (WAVELENGTH DEPENDENCE) (CONTINUED)


λ	τ	CURVE 32(CONT.)		CURVE 32(CONT.)		CURVE 33(CONT.)		CURVE 33(CONT.)		CURVE 35 $T = 973.$		CURVE 36(CONT.)		CURVE 36(CONT.)		CURVE 37(CONT.)	
1.425	0.931	3.995	0.394	2.043	0.905	1.95	0.972	45.0	0.166	2.06	0.864	46.1	0.213	4.0	0.972	45.0	0.166
1.597	0.934	4.135	0.219	2.941	0.928	0.84	0.873	2.06	0.864	2.17	0.876	2.31	0.864	47.7	0.297	47.7	0.297
2.027	0.934	4.266	0.159	2.96	0.944	0.93	0.876	2.13	0.876	2.31	0.879	2.40	0.866	50.0	0.373	50.0	0.373
2.071	0.926	4.291	0.111	2.99	0.950	1.13	0.879	2.40	0.866	2.40	0.897	2.46	0.862	4.0	0.952	4.0	0.952
2.106	0.896	4.377	0.047	3.05	0.950	1.20	0.897	2.46	0.897	2.46	0.909	2.51	0.852	4.5	<0.005	4.5	<0.005
2.148	0.634	4.427	0.000	3.10	0.942	1.28	0.909	2.51	0.842	2.55	0.891	4.0	<0.005	4.0	<0.005	4.0	<0.005
2.171	0.754	4.469	0.000	3.15	0.927	1.38	0.909	2.61	0.884	2.65	0.648	4.5	<0.005	4.5	<0.005	4.5	<0.005
2.191	0.721	4.522	0.024	4.05	0.905	1.45	0.902	2.65	0.891	2.73	0.679	6.0	<0.005	6.0	<0.005	6.0	<0.005
2.214	0.738	4.577	0.024	4.05	0.902	1.57	0.902	2.58	0.733	3.7	<0.005	4.0	<0.005	4.0	<0.005	4.0	<0.005
2.214	0.612	4.615	0.000	4.15	0.913	1.77	0.913	2.61	0.884	2.65	0.648	4.5	<0.005	4.5	<0.005	4.5	<0.005
2.256	0.887	CURVE 33 $T = 293.$		0.83	0.936	2.30	0.909	2.69	0.603	5.0	<0.005	5.5	<0.005	5.5	<0.005	5.5	<0.005
2.309	0.912	2.369	0.312	1.06	0.936	2.45	0.903	2.73	0.679	6.0	<0.005	6.5	<0.005	6.5	<0.005	6.5	<0.005
2.409	0.695	2.492	0.800	1.13	0.927	2.53	0.889	2.77	0.726	6.5	<0.005	7.0	<0.005	7.0	<0.005	7.0	<0.005
2.492	0.600	2.575	0.700	1.19	0.920	2.56	0.864	2.79	0.706	6.5	<0.005	7.0	<0.005	7.0	<0.005	7.0	<0.005
2.575	0.652	2.609	0.689	1.30	0.925	2.60	0.812	2.82	0.817	7.0	<0.005	7.5	<0.005	7.5	<0.005	7.5	<0.005
2.609	0.652	2.637	0.108	1.35	0.930	2.66	0.722	2.85	0.840	7.5	<0.005	8.0	<0.005	8.0	<0.005	8.0	<0.005
2.637	0.024	2.678	0.000	1.23	0.955	1.49	0.935	2.66	0.692	2.87	0.852	8.5	<0.005	8.5	<0.005	8.5	<0.005
2.678	0.000	2.730	0.000	1.32	0.964	1.63	0.932	2.68	0.643	2.95	0.859	9.0	<0.005	9.0	<0.005	9.0	<0.005
2.730	0.000	2.805	0.032	1.75	0.964	2.41	0.932	2.70	0.766	3.06	0.859	9.5	<0.005	9.5	<0.005	9.5	<0.005
2.805	0.364	2.805	0.024	1.95	0.967	2.46	0.920	2.74	0.776	3.22	0.852	10.0	<0.005	10.0	<0.005	10.0	<0.005
2.832	0.501	2.861	0.599	2.02	0.965	2.57	0.899	2.79	0.852	3.45	0.852	10.5	<0.005	10.5	<0.005	10.5	<0.005
2.861	0.599	2.730	0.000	2.09	0.960	2.59	0.871	2.82	0.871	3.68	0.882	11.0	<0.005	11.0	<0.005	11.0	<0.005
2.886	0.703	2.886	0.032	2.02	0.965	2.62	0.836	2.91	0.882	3.95	0.882	11.5	<0.005	11.5	<0.005	11.5	<0.005
2.912	0.749	2.912	0.749	2.09	0.960	2.66	0.920	2.74	0.876	4.22	0.882	12.0	<0.005	12.0	<0.005	12.0	<0.005
2.957	0.782	2.957	0.782	2.09	0.936	2.63	0.643	2.73	0.706	4.45	0.594	12.5	<0.005	12.5	<0.005	12.5	<0.005
3.029	0.627	3.029	0.627	2.54	0.917	2.73	0.706	2.77	0.776	4.70	0.594	13.0	<0.005	13.0	<0.005	13.0	<0.005
3.093	0.649	3.093	0.649	2.57	0.899	2.74	0.776	3.09	0.873	5.00	0.594	13.5	<0.005	13.5	<0.005	13.5	<0.005
3.201	0.871	3.250	0.971	2.59	0.871	2.79	0.852	3.23	0.971	5.30	0.652	14.0	<0.005	14.0	<0.005	14.0	<0.005
3.416	0.858	3.416	0.794	2.65	0.836	2.83	0.876	3.40	0.940	5.44	0.813	14.5	<0.005	14.5	<0.005	14.5	<0.005
3.494	0.794	3.562	0.696	2.66	0.722	2.92	0.918	3.57	0.940	5.67	0.813	15.0	<0.005	15.0	<0.005	15.0	<0.005
3.636	0.603	3.693	0.499	2.68	0.643	3.07	0.916	4.26	0.655	4.77	0.000	4.77	<0.005	4.77	<0.005	4.77	<0.005
3.746	0.435	3.746	0.435	2.74	0.776	3.13	0.913	4.37	0.873	4.87	0.000	4.87	<0.005	4.87	<0.005	4.87	<0.005
3.800	0.417	3.914	0.417	2.79	0.852	3.22	0.914	4.64	0.966	5.37	0.136	5.37	<0.005	5.37	<0.005	5.37	<0.005
3.914	0.417	3.914	0.417	2.79	0.884	3.79	0.873	5.74	0.972	6.40	0.136	6.40	<0.005	6.40	<0.005	6.40	<0.005

i. Normal Spectral Transmittance (Temperature Dependence)

No experimental data sets were found for the temperature dependence of the normal spectral transmittance of vitreous silica. However, a provisional curve was arrived at for the G. E. type 106 fused quartz kind of vitreous silica for $3.8 \mu\text{m}$ by using curves 1-5 from the previous section on the wavelength dependence of the normal spectral transmittance. The values are listed in Table 11-25 and shown in Figure 11-19. The provisional values are valid for a 2.8 mm thick specimen of polished G. E. type 106 fused quartz at 298, 373, 473, 573, and 673 K.

TABLE II-25. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICA(VITREOUS) (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; TRANSMITTANCE, τ)

T	τ
GE TYPE 106	
2.6MM THICK	
$\lambda = 3.6$	
298.	0.600
373.	0.600
473.	0.590
573.	0.560
673.	0.531



4.12. Silicon

Silicon crystallizes in a face centered cubic crystal of the A4 diamond type which is very stable from 293-1573 K. The lattice parameter of high purity silicon is 5.43089 Å at 296 K [E30683] and 5.445 Å at 1573 K [A00007]. Its density is 2.42 g cm⁻³ at 293 K. At 300 K, the intrinsic resistivity of very high purity silicon is about 2.5×10^5 ohm-cm.. The energy band gap is 1.1 eV. Silicon melts at 1687 K and boils at about 2753 K. Below 1273 K it is a brittle material, but it can be caused to undergo substantial plastic deformation at higher temperatures.

The thermal radiative properties of silicon depend on the method used in producing the crystal, especially in the 9 μm region where the presence of occluded oxygen causes a broad absorption band. In general, the bulk oxygen content is high for crystals grown by the Czochralski method and other methods where there is direct contact between the molten silicon and silica containers, and the 9 μm peak will be correspondingly higher for these crystals. Floating zone or pedestal methods have been developed in order to circumvent the problem of contamination of the crystal by the container. Oxygen is known to be present in Czochralski-grown crystals in concentrations in the range (0.5-2.0) × 10¹⁸ atoms cm⁻³. Crystals grown by float zone and pedestal methods contain essentially no oxygen. Pagot [E65870] and Hu and Patrick [E66704] have discussed various methods of determining the bulk oxygen content of a crystal and have examined the effect of bulk oxygen on the magnitude of the 9 μm absorption band in crystals grown by the different methods.

The thermal radiative properties of silicon may be altered by surface oxidation as well as by bulk oxygen occluded in crystal growth. Silicon oxidizes rapidly at room temperature to form a protective layer of silica about 10 Å thick. More complete oxidation begins at 920 K but is not rapid up to about 1500 K. The oxide layer is amorphous to about 1500 K, crystalline above 1500 K, and is somewhat volatile above 1873 K. Silicon semiconductor devices are generally protected with a silica layer by oxidizing at 1400-1600 K.

Silicon is used as the starting material for silicone resins, oils, and elastomers and as an alloying element to strengthen aluminum, magnesium, copper and other metals. It has a deoxidizing effect on steel and in relatively large concentrations it confers chemical inertness on ferrous alloys. High purity silicon is used in semiconductor devices such as rectifiers and transistors, and in solar batteries. High purity silicon has also been studied for use as an infrared dome material for small air to air missiles [T10703]. For this purpose it can be used in the 1-12 μm range up to about 520 K. Above

this temperature it becomes increasingly opaque due to absorption by free carriers thermally excited to the conduction band. Extremely small amounts of impurities greatly curtail its transmittance. For dome construction, the most feasible fabrication method appears to be a form of shell casting [T48097]. The transmittance of the castings was found to be similar to grown polycrystalline material. Vapor deposited domes have improved transmission characteristics in the $9 \mu\text{m}$ region due to a lesser bulk oxygen content, but their transmission in the $1-8 \mu\text{m}$ region was found to be considerably lower than that of cast domes due to scattering by voids in the silicon about $1 \mu\text{m}$ in diameter [T48097]. In applications as infrared optical components, silicon is normally coated with other materials in order to reduce reflection losses at desired wavelengths.

The electrical and thermal radiative properties of silicon are significantly changed by additions of small amounts of impurities or dopants. Elements of the third group of the periodic table (boron, aluminum, indium, gallium) can be added to pure or intrinsic material to produce p-type silicon which conducts current by migration of electron vacancies or holes. The introduction of Group V elements (arsenic, antimony, phosphorus) produces n-type silicon in which current is carried by migration of extra electrons. The resistivity of silicon is greatly reduced by addition of these impurities, to as low a value as $10^{-4} \text{ ohm}\cdot\text{cm}$. Although very pure silicon with a room temperature resistivity of the order of $10^5 \text{ ohm}\cdot\text{cm}$ and which becomes an intrinsic conductor at as low a temperature as 313 K has been produced, the term "high resistivity silicon" in the following discussion has generally been applied to silicon with a room temperature resistivity of $5 \text{ ohm}\cdot\text{cm}$ or greater.

The absorption mechanisms responsible for the main thermal radiative characteristics of silicon can be classified into four different types [T48288]: i) intrinsic absorption associated with excitation of electrons from the valence band to the conduction band across the energy gap; ii) absorption associated with impurities or defects in the lattice; iii) absorption due to the presence of free carriers; and iv) absorption due to lattice vibrations. Intrinsic absorption accounts for the sharp increase of the emittance and sharp decrease of the transmittance of silicon at around $1 \mu\text{m}$. At longer wavelengths, the radiation has insufficient energy to excite an electron across the energy gap, and the absorption and emittance are low with correspondingly high transmittance. In the $6-15 \mu\text{m}$ wavelength range, absorption bands associated with lattice vibrations are evident. At room temperature, absorption due to free carriers is not great for silicon of ordinary purity, but as the temperature is raised, the silicon becomes intrinsic as electrons are thermally excited to the conduction band. The free carrier absorption increases rapidly with temperature and finally becomes the dominant absorption mechanism.

It should be noted that the following sections concentrate on pure silicon with relatively low dopant levels. The experimental data for doped silicon samples shown in the following tables and figures by no means represent an exhaustive coverage of the available data for doped samples in the 1-15 μm range.

a. Normal Spectral Emittance (Wavelength Dependence)

Fifty-one experimental data sets for the wavelength dependence (1-14 μm) of the normal spectral emittance of silicon covering the temperature range 77-1075 K are shown in Table 12-3 and Figures 12-2 and 12-3. Of the 51 data sets, 30 sets are for specimens with relatively low dopant levels and high resistivities. Data for relatively pure specimens are shown in Figure 12-2 and for doped, low resistivity specimens in Figure 12-3.

Silicon is a partially transparent material to which the McMahon [T20468] relations (Eq. 2.6-10 to 2.6-12) apply. As the relations indicate, the normal spectral emittance of silicon depends on the thickness of the specimen, unless the specimen is thick enough or at high enough temperatures to be opaque. In this case, the normal spectral emittance is given by Eq. 2.6-1, where $\rho(\lambda, T)$ is the single surface reflectance given by Eq. 2.4-11 and Eq. 2.6-6. For high purity silicon in the 2-15 μm wavelength range, the index of absorption is small compared to the refractive index and can be neglected in Eq. 2.4-11. Both measurements of the refractive index and of the reflectance of opaque specimens indicate that the single surface reflectance of polished, high purity silicon at room temperature has a nearly constant value of 0.30 over the entire 2-15 μm wavelength range. The room temperature emittance of a polished, opaque specimen of relatively pure silicon can therefore be given as 0.70 in the 2-15 μm region. The uncertainty of this value should not be greater than $\pm 5\%$.

The normal spectral emittance of transparent specimens of relatively pure silicon has been extensively investigated by Stierwalt [T16961, T28823] (curves 25-38) Stierwalt and Potter [T32537] (curves 4-9) and Sato [T41640] (curves 39-45). Stierwalt, investigating primarily the emittance due to lattice vibrations, observed emission bands at 5.85, 7.0, 7.8, 9.0, 10.4, 11.3, 12.25, 12.8, and 13.6 μm . Both n-type and p-type silicon show the same emission bands. The 9 μm band is due to bulk oxygen impurities. Stierwalt found that the 9.0 and 11.3 μm bands shift to longer wavelengths as the temperature is increased, the shift being about 0.1 μm when the temperature was raised from 333 to 433 K. Sato and other investigators have observed similar lattice emission bands. Sato found, from measurements on a 15 ohm-cm, n-type specimen, that the lattice emission

increases with temperature from 340 K, reaches a maximum at 493 K, and then decreases with further increasing temperature.

The recommended values for 330 K shown in Table 12-1 and Figure 12-1 are based on Stierwalt's data (curve 25) for a 2.03 mm thick, n-type, 30-60 ohm-cm silicon single crystal. In the 1-3 μm region, the recommended values were generated in a manner consistent with transmittance and reflectance data and with the general trend of Sato's data for higher temperatures. Stierwalt's data were not followed closely in the 9 μm region; rather, an average peak height was chosen for the emission band due to occluded oxygen, because the height of the peak is known to vary greatly according to the method used to grow the crystal. Stierwalt also performed measurements (curves 4-9, 31-34) on two 1.68 mm thick, p-type samples of similar resistivity. In the 7-14 μm region, these samples show a lower emittance than the slightly thicker n-type sample. Thus, the 330 K recommended values may be considered to apply to a 2 mm thick, n-type silicon single crystal of relatively high purity and resistivity. They do not apply to highly doped specimens.

The uncertainties of the values recommended for 330 K vary according to the wavelength. Due to the rapid increase in emittance near the absorption edge (1-1.5 μm), the values in this region must be considered typical only; their uncertainty may be as great as 50%. In the 2-5 μm region, the emittance is very small, varying from about 0.01 to 0.03 for the n-type and p-type specimens with thicknesses of about 2 mm. In the 6-14 μm range, the uncertainty should not be greater than $\pm 15\%$, with the exception of the 9 μm emission peak, where experimental measurements for crystals grown by different methods may differ from the tabulated values by as much as 80-90%.

The recommended values for 1075 K shown in Table 12-1 and Figure 12-1 are based on Sato's data (curve 45) for a 1.77 mm thick, n-type, 15 ohm-cm single crystal. At this high temperature, silicon is opaque in the 2-15 μm range, and absorption due to free carriers dominates the lattice absorption. Sato's data shows that the normal spectral emittance is within $\pm 5\%$ of 0.710 over the entire 2-15 μm range. This value for the emittance, along with Eq. 2.6-1 for opaque materials, gives a single surface reflectance of 0.290 at 1075 K, which compares favorably with the room temperature value of 0.30. Because of the high temperature opacity of silicon, the 1075 recommended values are applicable to relatively pure, high resistivity, single crystal silicon of any thickness. The uncertainty of the recommended values should not exceed $\pm 8\%$.

No recommendations have been made for highly doped p-type or n-type specimens. The normal spectral emittance of silicon specimens which are sufficiently doped to be

opaque can be calculated by use of the free carrier absorption theory. Using this theory, Sato [T41640] performed calculations (curves 50, 51) at 543 and 893 K which show good agreement with experimental data (curves 46, 49) for an n-type specimen. Calculations performed by Liebert [T47262], showed agreement with experimental data to within 14%, for both n-type and p-type specimens for temperatures from 300 to 1075 K and wavelengths from 3.5 to 14.8 μm . The Hagen-Rubens theory is inadequate for doped silicon in the 1-15 μm region [T47262].

TABLE 12-1. RECOMMENDED NORMAL SPECTRAL EMISSANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)
(WAVELENGTH, $\lambda \cdot \mu\text{m}$; TEMPERATURE, T , K; EMISSANCE, ϵ)

λ	ϵ	λ	ϵ	SINGLE CRYSTAL 2.0 MM THICK $T = 330$ (CONT.)	λ	ϵ	SINGLE CRYSTAL 2.0 MM THICK $T = 330$ (CONT.)	λ	ϵ	SINGLE CRYSTAL OPAQUE $T = 1375$
1.00	0.665	0.23	0.104	12.10	0.390	1.00	0.564	1.00	0.564	1.00
1.10	0.575	0.30	0.114	12.20	0.410	1.50	0.607	1.50	0.607	1.50
1.20	0.2208†	0.40	0.146	12.30	0.397	2.00	0.700	2.00	0.700	2.00
1.30	0.0248	0.50	0.1798†	12.40	0.395	2.50	0.712	2.50	0.712	2.50
1.40	0.0178	0.60	0.2208	12.50	0.391	3.00	0.714	3.00	0.714	3.00
1.50	0.0148	0.70	0.2809	12.60	0.402	3.50	0.714	3.50	0.714	3.50
1.60	0.0138	0.80	0.3668	12.70	0.417	4.00	0.714	4.00	0.714	4.00
1.70	0.0124	0.90	0.4358	12.80	0.427	4.50	0.715	4.50	0.715	4.50
1.80	0.0114	0.00	0.4728	12.90	0.433	5.00	0.716	5.00	0.716	5.00
1.90	0.0114	0.10	0.4708	13.00	0.439	6.00	0.716	6.00	0.716	6.00
2.00	0.0104	0.20	0.4208	13.10	0.443	7.00	0.716	7.00	0.716	7.00
2.20	0.0104	0.30	0.3209	13.20	0.451	9.00	0.716	9.00	0.716	9.00
2.40	0.0104	0.40	0.1868	13.30	0.460	9.00	0.716	9.00	0.716	9.00
2.60	0.0094	0.50	0.165	13.40	0.470	10.00	0.716	10.00	0.716	10.00
2.80	0.0094	0.60	0.158	13.50	0.482	10.60	0.716	10.60	0.716	10.60
3.00	0.0094	0.70	0.169	13.60	0.478	11.00	0.716	11.00	0.716	11.00
3.80	0.0094	0.80	0.190	13.70	0.446	12.00	0.716	12.00	0.716	12.00
4.00	0.0094	0.90	0.210	13.80	0.414	13.00	0.713	13.00	0.713	13.00
5.00	0.0104	1.00	0.234	13.90	0.367	14.00	0.712	14.00	0.712	14.00
5.50	0.0134	1.0.10	0.260	14.00	0.310	15.00	0.710	15.00	0.710	15.00
5.85	0.0124	10.20	0.284							
6.00	0.022	10.30	0.305							
6.20	0.121	10.40	0.309							
6.40	0.023	10.50	0.306							
6.60	0.038	10.60	0.308							
6.80	0.003	10.70	0.329							
6.90	0.105	10.80	0.350							
7.00	0.112	10.90	0.373							
7.10	0.104	11.00	0.394							
7.20	0.100	11.10	0.410							
7.30	0.100	11.20	0.417							
7.40	0.104	11.30	0.417							
7.50	0.115	11.40	0.409							
7.60	0.125	11.50	0.392							
7.70	0.130	11.60	0.375							
7.80	0.122	11.70	0.356							
7.90	0.113	11.80	0.350							
8.00	0.103	11.90	0.350							
8.10	0.100	12.00	0.368							

† VALUE FOLLOWED BY AN "M" IS PROVISIONAL AND BY A "B" IS TYPICAL.




FIGURE 12-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)




FIGURE 12-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF HIGH-RESISTIVITY SILICON
(WAVELENGTH DEPENDENCE).




FIGURE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF LOW-RESISTIVITY, DOPED SILICON (WAVELENGTH DEPENDENCE).

TABLE 12-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON (Wavelength Dependence)

Cur. No.	Ref. No.	Author(s)	Year 1966	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	T33952	Sierwalt, D.L.	1966	16-42	77	Single crystal; n-type; 2 mm thick; 10^{-4} torr pressure; smoothed values extracted from figure.	
2	T33952	Sierwalt, D.L.	1966	16-42	203	Similar to the above specimen.	
3	T33952	Sierwalt, D.L.	1966	16-42	373	Similar to the above specimen.	
4	T32537	Sierwalt, D.L. and Potter, R.F.	1962	2-24	323	Single crystal; p-type; thickness 1.68 mm; cut to size with ultrasonic tool; optical surfaces prepared using standard lapping and polishing techniques; not etched; resistivity of 30 ohm-cm; data presented in figure.	
						The above specimen measured at 373 K.	
5	T32537	Sierwalt, D.L. and Potter, R.F.	1962	2-24	373	The above specimen measured at 423 K.	
6	T32537	Sierwalt, D.L. and Potter, R.F.	1962	2-24	423	The above specimen measured at 473 K.	
7	T32537	Sierwalt, D.L. and Potter, R.F.	1962	2-24	473	Single crystal; p-type; thickness 13.4 mm; cut to size with ultrasonic tool; optical surfaces prepared using standard lapping and polishing techniques; not etched; resistivity of 2000 ohm-cm; data presented in figure.	
8	T32537	Sierwalt, D.L. and Potter, R.F.	1962	2-9	473	The above specimen measured with increased gain.	
9	T32537	Sierwalt, D.L. and Potter, R.F.	1962	2-7	473	n-type single crystal; doped with arsenic; carrier concentration 2.2×10^{19} electrons cm^{-3} (accurate to $\pm 1\%$); opaque disk 23 mm diameter and 1.6 mm thick cut from doped ingots made by Allegheny Electron Chemicals Co; optically polished and etched; width of ridges produced by polishing about 0.5 μm; measured in air; hohlräum and Perkin Elmer Model 13 spectrophotometer used; data presented in figure; oxidation effects considered to be negligible; resistivity about 0.00644 ohm-cm at 862 K; reported error $\pm 4.7\%$.	
10	T47262	Lieber, C.H.	1967	3.5-14.8	882	The above specimen measured at 1074 K; resistivity about 0.00793 ohm cm at 1074 K. The above specimen; normal spectral emissivity calculated from measurements of near normal (6°) specular reflectivity using hohlräum and Perkin Elmer Model 521 spectrophotometer, with aluminum mirror as standard; data reported in figure; resistivity about 0.00329 at 300 K.	
11	T47262	Lieber, C.H.	1967	3.5-14.8	1074	n-type single crystal doped with arsenic; carrier concentration 3.7×10^{19} electrons cm^{-3} (accurate to $\pm 1\%$); opaque disk 23 mm in diameter and 1.6 mm thick cut from ingots made by Allegheny Electron Chemicals Co; optically polished and etched; width of ridges produced by polishing 0.5 μm; measured in air using hohlräum and Perkin Elmer Model 13 spectrophotometer; oxidation effects considered to be negligible; data presented in figure; resistivity about 0.00429 ohm cm at 882 K; reported error $\pm 4.7\%$.	
12	T47262	Lieber, C.H.	1967	2.5-35	300	The above specimen measured at 1074 K; resistivity about 0.00524 ohm-cm at 1074 K. The above specimen; normal spectral emissivity calculated from measurements of near normal (6°) specular reflectivity using hohlräum and Perkin-Elmer Model 521 spectrophotometer with aluminum mirror as standard; data reported in figure; resistivity about 0.00206 ohm-cm at 300 K.	
14	T47262	Lieber, C.H.	1967	3.5-14.8	1074		
15	T47262	Lieber, C.H.	1967	2.5-35	300		

TABLE 12-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s) No.	Year μm	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
16 T47262	Liebert, C.H.	1967	3.5-14.8	882	n-type single crystal doped with arsenic; carrier concentration 8.5×10^{19} electrons cm^{-3} (accurate to $\pm 1\%$); opaque disk 2.3 mm diameter and 1.6 mm thick cut from ingot made by Allegheny Electron Chemicals Co; optically polished and etched; width of ridges produced by polishing about 0.5 μm ; measured in air using hohbraun and Perkin Elmer Model 13 spectrophotometer; oxidation effects using hohbraun and Perkin Elmer Model 13 spectrophotometer; oxidation effects considered to be negligible; data presented in figure; electrical resistivity about 0.00238 ohm-cm at 882 K; reported error $\pm 4-7\%$.	
17 T47262	Liebert, C.H.	1967	3.5-14.8	1074	The above specimen measured at 1074 K; resistivity about 0.00292 ohm-cm at 1074 K.	
18 T47262	Liebert, C.H.	1967	2.5-35	300	The above specimen; normal spectral emissivity calculated from measurements of near normal (6°) specular reflectivity using hohbraun and Perkin Elmer Model 521 spectrophotometer with aluminum mirror as standard; data reported in figure; electrical resistivity about 0.00115 ohm-cm at 300 K.	
19 T47262	Liebert, C.H.	1967	3.5-14.8	882	p-type single crystal doped with boron; carrier concentration 6.2×10^{19} holes- cm^{-3} (accurate to $\pm 1\%$); opaque disk 2.3 mm in diameter and 1.6 mm thick cut from ingot made by Allegheny Electron Chemicals Co; optically polished and etched; width of ridges produced by polishing about 0.5 μm ; measured in air using hohbraun and Perkin Elmer Model 13 spectrophotometer; oxidation effects considered to be negligible; data presented in figure; electrical resistivity about 0.00479 ohm cm at 882 K; reported error $\pm 4-7\%$.	
20 T47262	Liebert, C.H.	1967	3.5-14.8	1074	The above specimen measured at 1074 K; electrical resistivity about 0.00588 ohm cm at 1074 K.	
21 T47262	Liebert, C.H.	1967	2.5-35	300	The above specimen; normal spectral emissivity calculated from measurements of near normal (6°) specular reflectivity using hohbraun and Perkin Elmer Model 521 spectrophotometer with aluminum mirror as standard; data presented in figure; electrical resistivity about 0.00218 ohm cm at 300 K.	
22 T47262	Liebert, C.H.	1967	3.5-14.8	882	p-type single crystal doped with boron; carrier concentration 1.4×10^{19} holes- cm^{-3} (accurate to $\pm 1\%$); opaque disk 2.3 mm in diameter and 1.6 mm thick cut from ingot made by Allegheny Electron Chemicals Co; optically polished and etched; width of ridges produced by polishing about 0.5 μm ; measured in air using hohbraun and Perkin Elmer Model 13 spectrophotometer; oxidation effects considered to be negligible; data presented in figure; electrical resistivity about 0.00281 ohm-cm at 882 K; reported error $\pm 4-7\%$.	
23 T47262	Liebert, C.H.	1967	3.5-14.8	1074	The above specimen measured at 1074 K; electrical resistivity about 0.00348 ohm-cm at 1074 K.	
24 T47262	Liebert, C.H.	1967	2.5-35	300	The above specimen; normal spectral emissivity calculated from measurements of near normal (6°) specular reflectivity using hohbraun and Perkin Elmer Model 521 spectrophotometer with aluminum mirror as standard; data presented in figure; electrical resistivity about 0.00124 ohm-cm at 300 K.	
25 T16961	Stiervalt, D.L.	1961	3-15	333	n-type, single crystal; 2.03 mm thick; ground and polished on top and bottom surfaces; measured in vacuum using modified Beckman IR-3 spectrophotometer; electrical resistivity 30-60 ohm cm; data presented in figure.	
26 T16961	Stiervalt, D.L.	1961	3-15	353	The above specimen measured at 353 K.	
27 T16961	Stiervalt, D.L.	1961	3-15	373	The above specimen measured at 373 K.	
28 T16961	Stiervalt, D.L.	1961	3-15	393	The above specimen measured at 393 K.	

TABLE 12-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
29	T16961	Stierwalt, D.L.	1961	3-15	413	The above specimen measured at 413 K.	
30	T16961	Stierwalt, D.L.	1961	3-15	433	The above specimen measured at 433 K.	
31	T16961	Stierwalt, D.L.	1961	3-15	313	p-type, single crystal; 1.68 mm thick; ground and polished on top and bottom surfaces; measured in vacuum using modified Beckman IR-3 spectrophotometer; data presented in figure.	
32	T16961	Stierwalt, D.L.	1961	3-15	353	The above specimen measured at 353 K.	
33	T16961	Stierwalt, D.L.	1961	3-15	393	The above specimen measured at 393 K.	
34	T16961	Stierwalt, D.L.	1961	3-15	433	The above specimen measured at 433 K.	
35	T28823	Stierwalt, D.	1960	3-15	313	The above specimen measured at 433 K.	
36	T28823	Stierwalt, D.	1960	3-15	363	1.65 mm thick sample.	
37	T28823	Stierwalt, D.	1960	3-15	393	The above specimen.	
38	T28823	Stierwalt, D.	1960	3-15	433	The above specimen.	
39	T41640	Sato, T.	1967	0.4-15	543	n-type, phosphorus doped, single crystal disk with 23 mm diameter and 1.77 mm thickness; resistivity 15 ohm-cm; ground and polished plane parallel using metallographic and then optical techniques; two measurement methods used; direct method compared specimen to V-shaped graphite cavity using Japan Spectroscopic IR-S spectrophotometer with NaCl prism in 2.5-15 μm range and a double pass spectrophotometer with LiF prism below 2.5 μ; indirect method obtained emissivity from measurements of reflectance and transmittance; measured under 10 ⁻⁴ mm Hg to preclude oxidation; due to difficulties in reading scale of figure, values above 10 μm are uncertain.	
40	T41640	Sato, T.	1967	0.4-15	623	The above specimen measured at 623 K.	
41	T41640	Sato, T.	1967	0.4-15	693	The above specimen measured at 693 K.	
42	T41640	Sato, T.	1967	0.4-15	743	The above specimen measured at 743 K.	
43	T41640	Sato, T.	1967	0.4-15	793	The above specimen measured at 793 K.	
44	T41640	Sato, T.	1967	0.4-15	873	The above specimen measured at 873 K.	
45	T41640	Sato, T.	1967	0.4-15	1073	The above specimen measured at 1073 K.	
46	T41640	Sato, T.	1967	2-15	543	n-type, phosphorous doped, single crystal disk with 23 mm diameter and 0.2 mm thickness; resistivity 0.007 ohm-cm at 300 K; polished and measured in manner similar to the above specimen; practically opaque even at low temperatures; due to difficulties in reading scale of figure, values above 10 μm are uncertain.	
47	T41640	Sato, T.	1967	2-15	693	The above specimen measured at 693 K.	
48	T41640	Sato, T.	1967	2-15	793	The above specimen measured at 793 K.	
49	T41640	Sato, T.	1967	2-15	893	The above specimen measured at 893 K.	
50	T41640	Sato, T.	1967	2-15	543	Calculation of the emittance of the above specimen at 543 K.	
51	T41640	Sato, T.	1967	2-15	893	Calculation of the emittance of the above specimen at 893 K.	

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF VARIED PURITY SILICON (WAVELLENGTH DEPENDENCE)

WAVELENGTH, λ , μm ; TEMPERATURE, T ; K; EMITTANCE, ϵ

λ	ϵ	CURVE 1 $T = 77.$	CURVE 2 (CONT.) $T = 77.$	CURVE 3 (CONT.) $T = 373.$	CURVE 4 (CONT.) $T = 373.$	CURVE 5 (CONT.) $T = 423.$	CURVE 6 $T = 423.$
16.00	0.330	17.49	6.265	33.00	0.097	12.99	0.306
16.32	0.466	17.10	6.291	32.03	0.081	13.39	0.353
16.50	0.475	16.33	0.265	34.00	0.075	13.67	1.235
16.63	0.456	19.03	0.217	35.00	0.082	14.10	0.204
16.79	0.344	19.48	0.227	39.00	0.083	14.34	0.166
16.98	0.253	20.07	0.205	40.00	0.079	15.27	0.196
17.23	0.220	21.44	0.126	41.48	0.079	15.56	0.220
17.52	0.230	22.00	0.100	41.48	0.082	15.82	0.304
17.87	0.236	24.00	0.079	41.48	0.100	16.29	0.591
18.20	0.224	26.00	0.073	41.48	0.079	16.49	0.564
18.92	0.176	28.00	0.060	3.12	0.022	17.16	0.366
19.39	0.187	30.00	0.063	3.69	0.022	17.36	0.349
19.87	0.166	32.00	0.057	3.95	0.020	17.65	0.354
20.44	0.122	34.00	0.051	4.15	0.021	18.57	0.306
20.86	0.101	36.00	0.048	4.33	0.015	19.01	0.291
21.33	0.086	39.00	0.046	4.68	0.015	19.35	0.296
21.77	0.072	40.00	0.041	5.99	0.016	19.52	0.296
22.00	0.065	41.91	0.041	6.43	0.022	20.00	0.259
24.00	0.045	26.00	0.039	7.4	0.039	21.72	0.170
26.00	0.039	28.00	0.032	9.93	0.076	22.70	0.137
28.00	0.032	30.00	0.027	7.50	0.080	15.45	0.231
30.00	0.027	32.00	0.027	8.01	0.064	15.03	0.251
32.00	0.027	34.00	0.025	3.3	0.096	16.18	0.637
34.00	0.025	36.00	0.026	16.63	0.567	16.32	0.652
36.00	0.026	38.00	0.026	17.25	0.409	2.33	0.027
40.00	0.026	40.00	0.026	17.48	0.399	2.86	0.030
41.66	0.026	41.66	0.026	18.23	0.399	3.45	0.030
41.91	0.026	41.91	0.026	18.39	0.399	4.15	0.021
42.00	0.026	42.00	0.026	18.27	0.389	10.94	0.07
42.15	0.026	42.15	0.026	18.65	0.369	10.34	0.224
42.30	0.026	42.30	0.026	19.92	0.317	10.73	0.244
42.45	0.026	42.45	0.026	19.23	0.324	11.34	0.295
42.60	0.026	42.60	0.026	19.02	0.317	11.18	0.309
42.75	0.026	42.75	0.026	18.65	0.369	11.64	0.251
42.90	0.026	42.90	0.026	18.40	0.369	11.75	0.242
43.05	0.026	43.05	0.026	18.15	0.369	11.92	0.250
43.20	0.026	43.20	0.026	17.80	0.369	12.09	0.274
43.35	0.026	43.35	0.026	17.45	0.369	12.34	0.279
43.50	0.026	43.50	0.026	17.10	0.369	12.59	0.277
43.65	0.026	43.65	0.026	16.75	0.369	12.84	0.275
43.80	0.026	43.80	0.026	16.40	0.369	13.09	0.273
43.95	0.026	43.95	0.026	16.05	0.369	13.34	0.271
44.10	0.026	44.10	0.026	15.70	0.369	13.59	0.269
44.25	0.026	44.25	0.026	15.35	0.369	13.84	0.267
44.40	0.026	44.40	0.026	15.00	0.369	14.09	0.265
44.55	0.026	44.55	0.026	14.65	0.369	14.34	0.263
44.70	0.026	44.70	0.026	14.30	0.369	14.59	0.261
44.85	0.026	44.85	0.026	13.95	0.369	14.84	0.259
45.00	0.026	45.00	0.026	13.60	0.369	15.09	0.257
45.15	0.026	45.15	0.026	13.25	0.369	15.34	0.255
45.30	0.026	45.30	0.026	12.90	0.369	15.59	0.253
45.45	0.026	45.45	0.026	12.55	0.369	15.84	0.251
45.60	0.026	45.60	0.026	12.20	0.369	16.09	0.249
45.75	0.026	45.75	0.026	11.85	0.369	16.34	0.247
45.90	0.026	45.90	0.026	11.50	0.369	16.59	0.245
46.05	0.026	46.05	0.026	11.15	0.369	16.84	0.243
46.20	0.026	46.20	0.026	10.80	0.369	17.09	0.241
46.35	0.026	46.35	0.026	10.45	0.369	17.34	0.239
46.50	0.026	46.50	0.026	10.10	0.369	17.59	0.237
46.65	0.026	46.65	0.026	9.75	0.369	17.84	0.235
46.80	0.026	46.80	0.026	9.40	0.369	18.09	0.233
46.95	0.026	46.95	0.026	9.05	0.369	18.34	0.231
47.10	0.026	47.10	0.026	8.70	0.369	18.59	0.229
47.25	0.026	47.25	0.026	8.35	0.369	18.84	0.227
47.40	0.026	47.40	0.026	8.00	0.369	19.09	0.225
47.55	0.026	47.55	0.026	7.65	0.369	19.34	0.223
47.70	0.026	47.70	0.026	7.30	0.369	19.59	0.221
47.85	0.026	47.85	0.026	6.95	0.369	19.84	0.219
48.00	0.026	48.00	0.026	6.60	0.369	20.09	0.217
48.15	0.026	48.15	0.026	6.25	0.369	20.34	0.215
48.30	0.026	48.30	0.026	5.90	0.369	20.59	0.213
48.45	0.026	48.45	0.026	5.55	0.369	20.84	0.211
48.60	0.026	48.60	0.026	5.20	0.369	21.09	0.209
48.75	0.026	48.75	0.026	4.85	0.369	21.34	0.207
48.90	0.026	48.90	0.026	4.50	0.369	21.59	0.205
49.05	0.026	49.05	0.026	4.15	0.369	21.84	0.203
49.20	0.026	49.20	0.026	3.80	0.369	22.09	0.201
49.35	0.026	49.35	0.026	3.45	0.369	22.34	0.199
49.50	0.026	49.50	0.026	3.10	0.369	22.59	0.197
49.65	0.026	49.65	0.026	2.75	0.369	22.84	0.195
49.80	0.026	49.80	0.026	2.40	0.369	23.09	0.193
49.95	0.026	49.95	0.026	2.05	0.369	23.34	0.191
50.10	0.026	50.10	0.026	1.70	0.369	23.59	0.189
50.25	0.026	50.25	0.026	1.35	0.369	23.84	0.187
50.40	0.026	50.40	0.026	1.00	0.369	24.09	0.185
50.55	0.026	50.55	0.026	6.55	0.369	24.34	0.183
50.70	0.026	50.70	0.026	3.10	0.369	24.59	0.181
50.85	0.026	50.85	0.026	0.65	0.369	24.84	0.179
51.00	0.026	51.00	0.026	0.30	0.369	25.09	0.177
51.15	0.026	51.15	0.026	0.05	0.369	25.34	0.175
51.30	0.026	51.30	0.026	-0.20	0.369	25.59	0.173
51.45	0.026	51.45	0.026	-0.55	0.369	25.84	0.171
51.60	0.026	51.60	0.026	-0.90	0.369	26.09	0.169
51.75	0.026	51.75	0.026	-1.25	0.369	26.34	0.167
51.90	0.026	51.90	0.026	-1.60	0.369	26.59	0.165
52.05	0.026	52.05	0.026	-1.95	0.369	26.84	0.163
52.20	0.026	52.20	0.026	-2.30	0.369	27.09	0.161
52.35	0.026	52.35	0.026	-2.65	0.369	27.34	0.159
52.50	0.026	52.50	0.026	-3.00	0.369	27.59	0.157

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMMITTANCE, ϵ)

λ	ϵ	CURVE 6 (CONT.)	λ	ϵ	CURVE 7 (CONT.)	λ	ϵ	CURVE 8 (CONT.)	λ	ϵ	CURVE 9 (CONT.)	λ	ϵ	CURVE 10	λ	ϵ	CURVE 11	λ	ϵ	CURVE 12	λ	ϵ	CURVE 13	λ	ϵ	CURVE 14	λ	ϵ	CURVE 15	λ	ϵ
16.04	0.605	9.49	0.243	5.56	0.066	5.36	0.0036	5.36	0.692	2.7	0.692	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631				
16.34	0.721	10.03	0.255	5.73	0.077	6.16	0.1076	6.16	0.692	3.3	0.692	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631								
16.95	0.467	10.27	0.298	6.02	0.061	6.31	0.1127	6.31	0.701	4.0	0.701	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631				
17.29	0.451	10.71	0.320	5.20	0.109	6.47	0.1250	6.47	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
17.51	0.469	11.29	0.412	5.49	0.127	6.52	0.127	6.52	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
17.73	0.469	11.84	0.363	5.61	0.205	6.61	0.205	6.61	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
17.93	0.452	12.07	0.384	5.61	0.205	6.61	0.205	6.61	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
17.93	0.431	12.22	0.416	6.01	0.395	6.81	0.395	6.81	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
18.43	0.424	12.41	0.409	6.86	0.476	7.03	0.476	7.03	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
18.94	0.394	12.63	0.426	7.03	0.433	7.12	0.433	7.12	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
19.41	0.412	13.00	0.438	7.23	0.426	7.42	0.426	7.42	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
20.00	0.358	13.46	0.488	7.42	0.409	7.62	0.409	7.62	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
20.54	0.329	14.00	0.365	7.62	0.481	7.81	0.481	7.81	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
21.11	0.277	14.31	0.276	7.81	0.491	7.91	0.491	7.91	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
21.42	0.260	14.78	0.292	7.91	0.491	8.01	0.491	8.01	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
21.68	0.216	15.53	0.318	8.01	0.460	8.18	0.460	8.18	0.701	4.0	0.701	11.13	0.1346	11.13	0.1346	12.0	0.737	12.0	0.737	13.0	0.696	13.0	0.696	14.0	0.664	14.0	0.664	15.0	0.631	15.0	0.631
23.08	0.178	15.84	0.375	8.03	0.412	10.0	0.791	10.0	0.791	4.0	0.459	11.0	0.791	11.0	0.791	12.0	0.400	12.0	0.400	13.0	0.354	13.0	0.354	14.0	0.338	14.0	0.338	15.0	0.322	15.0	0.322
24.00	0.161	16.27	0.731	8.17	0.395	11.0	0.791	11.0	0.791	4.0	0.400	12.0	0.776	12.0	0.776	13.0	0.375	13.0	0.375	14.0	0.338	14.0	0.338	15.0	0.322	15.0	0.322				
24.67	0.056	16.49	0.707	8.26	0.417	12.0	0.776	12.0	0.776	4.0	0.400	13.0	0.776	13.0	0.776	14.0	0.375	14.0	0.375	15.0	0.338	15.0	0.338	16.0	0.311	16.0	0.311				
3.35	0.039	17.30	0.484	9.42	0.509	13.0	0.749	13.0	0.749	4.0	0.400	14.0	0.727	14.0	0.727	15.0	0.322	15.0	0.322	16.0	0.300	16.0	0.300	17.0	0.294	17.0	0.294				
4.31	0.029	17.65	0.510	9.93	0.637	14.0	0.694	14.0	0.694	4.0	0.400	15.0	0.694	15.0	0.694	16.0	0.322	16.0	0.322	17.0	0.300	17.0	0.300	18.0	0.294	18.0	0.294				
6.05	0.029	23.41	0.430	2.00	0.1436	2.11	0.1436	2.11	0.659	4.0	0.659	3.5	0.652	3.5	0.652	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
6.51	0.034	23.41	0.217	2.00	0.1015	2.65	0.0655	2.65	0.659	4.0	0.659	3.07	0.0771	3.07	0.0771	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
6.68	0.071	22.67	0.251	2.00	0.1015	2.85	0.0771	2.85	0.659	4.0	0.659	3.07	0.0730	3.07	0.0730	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
6.96	0.132	22.67	0.251	2.00	0.1015	3.07	0.0730	3.07	0.659	4.0	0.659	3.07	0.0730	3.07	0.0730	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
7.25	0.116	23.41	0.217	2.00	0.1015	3.76	0.0631	3.76	0.659	4.0	0.659	3.76	0.0631	3.76	0.0631	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
7.46	0.116	24.00	0.202	2.00	0.1015	4.39	0.0591	4.39	0.659	4.0	0.659	4.39	0.0591	4.39	0.0591	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
7.58	0.138	2.00	0.123	2.00	0.0591	4.86	0.056	4.86	0.659	4.0	0.659	4.86	0.056	4.86	0.056	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
7.74	0.147	2.28	0.105	2.00	0.0591	5.05	0.0580	5.05	0.659	4.0	0.659	5.05	0.0580	5.05	0.0580	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
8.09	0.116	2.67	0.088	2.00	0.0591	5.49	0.0643	5.49	0.659	4.0	0.659	5.49	0.0643	5.49	0.0643	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
8.33	0.125	3.12	0.074	2.00	0.0591	5.76	0.0643	5.76	0.659	4.0	0.659	5.76	0.0643	5.76	0.0643	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
8.73	0.266	3.76	0.064	2.00	0.0591	6.05	0.0775	6.05	0.659	4.0	0.659	6.05	0.0775	6.05	0.0775	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
9.01	0.394	4.07	0.059	2.00	0.0591	6.55	0.0775	6.55	0.659	4.0	0.659	6.55	0.0775	6.55	0.0775	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
9.16	0.305	5.13	0.059	2.00	0.0591	6.86	0.0775	6.86	0.659	4.0	0.659	6.86	0.0775	6.86	0.0775	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659
9.54	0.168	5.29	0.066	2.00	0.0591	7.05	0.0791	7.05	0.659	4.0	0.659	7.05	0.0791	7.05	0.0791	4.0	0.659	4.0	0.659	5.0	0.659	5.0	0.659	6.0	0.659	6.0	0.659	7.0	0.659	7.0	0.659

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ ; μm ; TEMPERATURE, T ; K; EMITTANCE, ϵ)

λ	ϵ	CURVE 15(CONT.)			CURVE 17(CONT.)			CURVE 19(CONT.)			CURVE 21(CONT.)			CURVE 23(CONT.)			CURVE 25 $T = 333.$		
16.0	0.368	11.0	0.605	5.0	0.796	11.0	0.591	5.0	0.736	5.0	0.736	5.0	0.736	3.00	0.009	0.009			
18.0	0.329	12.0	0.565	7.0	0.812	12.0	0.527	6.0	0.746	6.0	0.746	4.66	0.009	0.009	0.009	0.013	0.013		
20.0	0.304	13.0	0.526	9.0	0.820	13.0	0.484	7.0	0.741	6.0	0.722	5.49	0.024	0.024	0.024	0.024	0.024		
22.0	0.290	14.0	0.493	9.0	0.820	14.0	0.449	6.0	0.722	5.0	0.684	5.0	0.684	5.0	0.684	5.0	0.684		
24.0	0.278	14.7	0.493	10.0	0.808	15.0	0.414	9.0	0.684	9.0	0.639	6.16	0.021	0.021	0.021	0.021	0.021		
26.0	0.269			11.0	0.776	16.0	0.393	10.0	0.639	10.0	0.607	6.39	0.023	0.023	0.023	0.023	0.023		
28.0	0.260			12.0	0.737	16.0	0.356	11.0	0.575	12.0	0.54	6.54	0.031	0.031	0.031	0.031	0.031		
30.0	0.254			13.0	0.700	20.0	0.326	12.0	0.575	11.0	0.54	6.62	0.036	0.036	0.036	0.036	0.036		
32.0	0.244			14.0	0.664	22.0	0.303	11.0	0.548	11.0	0.517	6.70	0.056	0.056	0.056	0.056	0.056		
34.0	0.238	3.0	0.713	15.0	0.623	24.0	0.278	14.0	0.534	14.0	0.517	6.84	0.088	0.088	0.088	0.088	0.088		
34.8	0.238	4.0	0.744			26.0	0.264					6.92	0.105						
		5.0	0.773			28.0	0.249					6.98	0.112						
		6.0	0.795			30.0	0.238					7.15	0.103						
		7.0	0.770			32.0	0.229					7.25	0.100						
		8.0	0.566			34.0	0.225					7.33	0.100						
		9.0	0.491			35.0	0.225					7.44	0.106						
		10.0	0.415									7.55	0.117						
		11.0	0.344									7.64	0.126						
		12.0	0.311									7.72	0.130						
		13.0	0.284									7.80	0.130						
		14.0	0.264									7.89	0.130						
		15.0	0.253									7.98	0.130						
		16.0	0.241									8.06	0.130						
		17.0	0.225									8.14	0.130						
		18.0	0.225									8.22	0.130						
		19.0	0.214									8.30	0.130						
		20.0	0.203									8.38	0.130						
		22.0	0.199									8.46	0.130						
		24.0	0.199									8.54	0.130						
		26.0	0.195									8.62	0.130						
		28.0	0.195									8.70	0.130						
		30.0	0.194									8.78	0.130						
		32.0	0.194									8.86	0.130						
		34.0	0.194									8.94	0.130						
		35.0	0.194									9.02	0.130						
												9.10	0.130						
												9.18	0.130						
												9.26	0.130						
												9.34	0.130						
												9.42	0.130						
												9.50	0.130						
												9.58	0.130						
												9.66	0.130						
												9.74	0.130						
												9.82	0.130						
												9.90	0.130						
												9.98	0.130						
												10.06	0.130						
												10.14	0.130						
												10.21	0.130						
												10.28	0.130						
												10.35	0.130						
												10.42	0.130						
												10.49	0.130						
												10.57	0.130						
												10.64	0.130						
												10.71	0.130						
												10.78	0.130						
												10.85	0.130						
												10.92	0.130						
												10.99	0.130						
												11.06	0.130						
												11.13	0.130						
												11.20	0.130						
												11.27	0.130						
												11.34	0.130						
												11.41	0.130						
												11.48	0.130						
												11.55	0.130						
												11.62	0.130						
												11.69	0.130						
												11.76	0.130						
												11.83	0.130						
												11.90	0.130						
												11.97	0.130						
												12.04	0.130						
												12.11	0.130						
												12.18	0.130						
												12.25	0.130						
												12.32	0.130						
												12.39	0.130						
												12.46	0.130						
												12.53	0.130						
												12.60	0.130						
												12.67	0.130						
												12.74	0.130						
												12.81	0.130						
												12.88	0.130						
												12.95	0.130						
												13.02	0.130						
												13.09	0.130						
												13.16	0.130						
												13.23	0.130						
												13.30	0.130						
												13.37	0.130						
												13.44	0.130						
												13.51	0.130						
												13.58	0.130						
												13.65	0.130						
												13.72	0.130						
												13.79	0.130						
												13.86	0.130						
												13.93	0.130						
												14.00	0.130						
												14.07	0.130						
												14.14	0.130						
												14.21	0.130						
												14.28	0.130						
												14.35	0.130						
												14.42	0.130						

TABLE I2-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)
(WAVELLENGTH, λ , μm ; WAVELENGTH DEPENDENCE, CURVE 26 (CONT.) (CONTINUED))

λ	ϵ	CURVE 25 (CONT.)			CURVE 26 (CONT.)			CURVE 26 (CONT.)			CURVE 27 (CONT.)			CURVE 27 (CONT.)			CURVE 28 (CONT.)		
		λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ		
10.00	0.234	6.53	0.045	11.05	0.409	6.35	0.024	11.13	0.437	6.30	0.028	10.00	0.234	6.54	0.034	11.24	0.444	6.44	0.032
10.16	0.272	6.75	0.071	11.16	0.421	6.54	0.034	11.24	0.444	6.50	0.032	10.16	0.272	6.76	0.045	11.35	0.445	6.59	0.044
10.28	0.300	6.86	0.097	11.26	0.424	6.63	0.045	11.35	0.445	6.59	0.044	10.28	0.300	6.87	0.071	11.51	0.427	6.67	0.056
10.31	0.606	6.91	0.113	11.37	0.421	6.75	0.071	11.61	0.376	6.87	0.113	10.31	0.606	6.92	0.117	11.81	0.376	6.99	0.131
10.37	0.310	6.98	0.117	11.47	0.395	6.86	0.097	11.93	0.376	7.00	0.127	10.39	0.310	7.03	0.127	12.03	0.398	7.10	0.129
10.49	0.305	7.14	0.108	11.81	0.356	6.94	0.119	11.99	0.376	7.01	0.127	10.59	0.305	7.16	0.131	12.11	0.425	7.22	0.116
10.59	0.309	7.23	0.103	11.97	0.363	7.11	0.116	12.11	0.425	7.23	0.111	10.64	0.309	7.28	0.116	12.24	0.436	7.34	0.116
10.64	0.313	7.34	0.103	11.97	0.363	7.11	0.116	12.11	0.425	7.33	0.111	10.70	0.314	7.38	0.119	12.34	0.425	7.57	0.139
10.99	0.383	7.46	0.113	12.13	0.421	7.23	0.111	12.24	0.425	7.33	0.111	11.26	0.383	7.56	0.120	12.56	0.449	7.77	0.149
11.09	0.407	7.59	0.127	12.21	0.429	7.33	0.111	12.34	0.425	7.57	0.135	11.26	0.407	7.60	0.149	12.66	0.449	7.80	0.149
11.26	0.419	7.66	0.132	12.29	0.425	7.57	0.135	12.36	0.425	7.69	0.142	11.39	0.419	7.74	0.149	12.66	0.449	7.90	0.136
11.39	0.411	7.79	0.132	12.32	0.410	7.69	0.142	12.57	0.421	7.79	0.142	11.76	0.411	7.84	0.149	12.73	0.448	8.04	0.120
11.76	0.354	7.88	0.126	12.41	0.401	7.79	0.142	12.73	0.448	7.87	0.132	11.86	0.354	7.93	0.149	12.88	0.448	8.18	0.120
11.86	0.348	7.98	0.112	12.51	0.401	7.87	0.132	12.98	0.464	7.99	0.117	11.97	0.348	8.03	0.149	13.19	0.475	8.31	0.131
11.97	0.359	8.11	0.103	12.61	0.420	7.99	0.117	12.98	0.464	8.14	0.114	12.07	0.360	8.16	0.149	13.35	0.477	8.48	0.175
12.07	0.380	8.22	0.112	12.70	0.437	8.14	0.121	13.19	0.477	8.27	0.121	12.16	0.380	8.28	0.149	13.55	0.477	8.68	0.175
12.16	0.405	8.31	0.124	12.86	0.445	8.27	0.121	13.55	0.477	8.37	0.144	12.21	0.405	8.36	0.149	13.66	0.487	8.84	0.175
12.21	0.410	8.41	0.146	13.11	0.454	8.37	0.144	13.46	0.487	8.50	0.160	12.21	0.410	8.46	0.149	13.86	0.487	9.04	0.175
12.25	0.405	8.53	0.179	13.33	0.467	8.50	0.160	13.56	0.506	8.72	0.180	12.33	0.405	8.61	0.160	14.01	0.487	9.22	0.175
12.33	0.393	8.61	0.220	13.38	0.473	8.60	0.231	13.70	0.468	8.72	0.315	12.42	0.393	8.66	0.231	14.01	0.483	9.43	0.175
12.42	0.388	8.72	0.315	13.46	0.480	8.72	0.315	13.86	0.483	8.91	0.522	12.50	0.388	8.81	0.315	14.19	0.486	9.63	0.175
12.50	0.391	8.91	0.522	13.50	0.485	8.91	0.522	14.19	0.486	9.00	0.620	12.77	0.391	8.96	0.522	14.46	0.487	9.84	0.175
12.77	0.425	8.98	0.617	13.59	0.489	9.00	0.620	14.28	0.219	9.10	0.634	12.77	0.425	9.05	0.620	14.59	0.214	9.39	0.175
12.89	0.432	9.35	0.626	13.61	0.428	9.08	0.634	14.39	0.214	9.17	0.621	13.19	0.449	9.44	0.634	14.68	0.218	9.57	0.175
13.19	0.449	9.11	0.619	14.00	0.332	9.15	0.626	14.48	0.218	9.27	0.437	13.36	0.464	9.54	0.634	14.78	0.218	9.87	0.175
13.36	0.464	9.14	0.585	14.16	0.256	9.22	0.470	15.00	0.259	9.35	0.311	13.47	0.464	9.64	0.256	15.00	0.259	9.93	0.175
13.47	0.479	9.29	0.320	14.33	0.235	9.35	0.311	15.00	0.207	9.54	0.197	13.50	0.479	9.74	0.311	15.00	0.207	9.94	0.175
13.50	0.462	9.34	0.245	14.60	0.230	9.47	0.207	15.00	0.207	9.54	0.197	13.50	0.462	9.74	0.311	15.00	0.207	9.94	0.175
13.53	0.402	9.37	0.252	14.79	0.233	9.57	0.174	15.00	0.191	9.71	0.191	13.53	0.402	9.81	0.174	15.00	0.191	9.94	0.175
CURVE 26 $T = 353^\circ\text{K}$		9.51	0.171	CURVE 27			9.89	0.224	10.04	0.015	10.09	0.015	CURVE 28 $T = 393^\circ\text{K}$			10.21	0.324	10.28	0.324
3.00	0.009	9.75	0.181	10.22	0.317	3.00	0.015	10.37	0.346	3.00	0.015	4.66	0.009	4.66	0.015	5.00	0.015	5.00	0.015
4.66	0.009	9.97	0.236	10.29	0.329	4.66	0.016	10.56	0.339	4.66	0.016	5.99	0.013	5.99	0.016	6.35	0.016	6.35	0.016
5.09	0.013	10.16	0.270	10.36	0.334	5.09	0.016	10.72	0.365	5.09	0.016	6.13	0.025	6.13	0.016	6.50	0.016	6.50	0.016
5.86	0.024	10.26	0.307	10.47	0.334	5.86	0.016	10.86	0.398	5.86	0.016	6.53	0.024	6.53	0.016	7.11	0.024	7.11	0.016
5.90	0.025	10.35	0.315	10.69	0.351	5.90	0.016	11.12	0.444	5.90	0.016	6.13	0.025	6.13	0.016	6.50	0.025	6.50	0.016
6.13	0.022	10.44	0.315	10.84	0.345	6.13	0.016	11.23	0.453	6.13	0.016	6.35	0.024	6.35	0.016	6.71	0.024	6.71	0.016
6.35	0.024	10.56	0.311	10.86	0.361	6.35	0.016	11.36	0.453	6.35	0.016	6.54	0.024	6.54	0.016	6.91	0.024	6.91	0.016
6.54	0.034	10.83	0.363	11.13	0.322	6.54	0.026	11.52	0.460	6.54	0.026	6.91	0.026	6.91	0.026	7.28	0.324	7.28	0.324

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH, λ ; μm ; TEMPERATURE, T ; κ : EMITTANCE, ϵ)
(WAVELENGTH, λ ; μm ; TEMPERATURE, T ; κ : EMITTANCE, ϵ) (CONTINUED)

λ	ϵ	CURVE 28 (CONT.)			CURVE 29 (CONT.)			CURVE 30 (CONT.)			CURVE 30 (CONT.)			CURVE 31 $T = 313.$			
11.61	0.424	6.09	0.028	11.17	0.470	3.33	0.019	10.32	0.370	3.00	0.029	3.00	0.029	3.00	0.029	3.00	0.029
11.72	0.400	6.30	0.028	11.24	0.476	3.43	0.014	10.39	0.376	3.99	0.322	3.99	0.322	3.99	0.322	3.99	0.322
11.83	0.399	6.44	0.032	11.35	0.477	4.99	0.014	10.46	0.376	4.94	0.017	4.94	0.017	4.94	0.017	4.94	0.017
11.93	0.399	6.59	0.044	11.59	0.467	5.22	0.016	10.53	0.373	5.20	0.016	5.20	0.016	5.20	0.016	5.20	0.016
11.99	0.402	6.67	0.056	11.05	0.441	5.54	0.017	10.63	0.376	5.80	0.018	5.80	0.018	5.80	0.018	5.80	0.018
12.11	0.435	6.87	0.113	11.76	0.420	5.84	0.030	10.83	0.404	5.94	0.021	5.94	0.021	5.94	0.021	5.94	0.021
12.21	0.454	6.93	0.137	11.96	0.415	6.09	0.028	11.09	0.464	6.39	0.021	6.39	0.021	6.39	0.021	6.39	0.021
12.31	0.446	6.98	0.141	12.97	0.435	6.30	0.026	11.17	0.476	6.58	0.031	6.58	0.031	6.58	0.031	6.58	0.031
12.35	0.433	7.07	0.141	12.14	0.467	6.44	0.032	11.29	0.481	6.69	0.042	6.69	0.042	6.69	0.042	6.69	0.042
12.41	0.427	7.18	0.126	12.19	0.473	6.59	0.044	11.37	0.481	6.76	0.060	6.76	0.060	6.76	0.060	6.76	0.060
12.53	0.434	7.33	0.124	12.27	0.474	6.67	0.056	11.54	0.469	6.90	0.075	6.90	0.075	6.90	0.075	6.90	0.075
12.63	0.447	7.49	0.137	12.38	0.467	6.86	0.122	11.63	0.460	7.03	0.086	7.03	0.086	7.03	0.086	7.03	0.086
12.68	0.476	7.63	0.152	12.50	0.467	6.91	0.141	11.76	0.431	7.11	0.086	7.11	0.086	7.11	0.086	7.11	0.086
12.73	0.481	7.76	0.158	12.60	0.475	7.00	0.149	11.83	0.420	7.32	0.081	7.32	0.081	7.32	0.081	7.32	0.081
13.05	0.481	7.99	0.134	12.68	0.485	7.11	0.143	11.96	0.427	7.45	0.090	7.45	0.090	7.45	0.090	7.45	0.090
13.16	0.483	8.09	0.127	12.74	0.502	7.22	0.134	12.10	0.469	7.62	0.105	7.62	0.105	7.62	0.105	7.62	0.105
13.37	0.494	8.25	0.127	12.85	0.506	7.32	0.130	12.14	0.476	7.68	0.105	7.68	0.105	7.68	0.105	7.68	0.105
13.49	0.538	8.34	0.150	13.05	0.506	7.56	0.150	12.26	0.479	7.83	0.086	7.83	0.086	7.83	0.086	7.83	0.086
13.57	0.515	8.46	0.196	13.17	0.515	7.65	0.163	12.34	0.476	7.95	0.079	7.95	0.079	7.95	0.079	7.95	0.079
13.66	0.494	8.54	0.220	13.39	0.523	7.76	0.165	12.54	0.478	8.10	0.079	8.10	0.079	8.10	0.079	8.10	0.079
13.90	0.403	8.62	0.246	13.45	0.537	7.85	0.161	12.62	0.494	8.21	0.083	8.21	0.083	8.21	0.083	8.21	0.083
14.09	0.310	8.72	0.315	13.53	0.549	8.03	0.139	12.70	0.502	8.34	0.099	8.34	0.099	8.34	0.099	8.34	0.099
14.19	0.270	8.98	0.481	13.59	0.549	8.14	0.135	12.82	0.509	8.53	0.136	8.53	0.136	8.53	0.136	8.53	0.136
14.32	0.257	9.06	0.635	13.69	0.531	8.27	0.142	13.02	0.510	8.66	0.100	8.66	0.100	8.66	0.100	8.66	0.100
14.48	0.254	9.01	0.642	13.68	0.474	8.62	0.253	13.37	0.526	8.75	0.226	8.75	0.226	8.75	0.226	8.75	0.226
14.80	0.262	9.07	0.642	14.00	0.397	8.72	0.315	13.45	0.537	8.96	0.331	8.96	0.331	8.96	0.331	8.96	0.331
15.00	0.264	9.14	0.628	14.09	0.323	8.88	0.481	13.54	0.554	9.01	0.382	9.01	0.382	9.01	0.382	9.01	0.382
9.30	0.393	14.13	0.295	9.94	0.597	13.59	0.557	9.66	0.400	9.66	0.400	9.66	0.400	9.66	0.400	9.66	0.400
9.45	0.246	14.23	0.274	9.00	0.627	13.66	0.548	9.13	0.362	9.13	0.362	9.13	0.362	9.13	0.362	9.13	0.362
9.55	0.219	14.43	0.261	9.09	0.634	13.91	0.474	9.25	0.376	9.25	0.376	9.25	0.376	9.25	0.376	9.25	0.376
9.60	0.205	14.58	0.267	9.17	0.625	13.98	0.436	9.31	0.147	9.31	0.147	9.31	0.147	9.31	0.147	9.31	0.147
9.70	0.210	14.96	0.270	9.25	0.509	14.06	0.349	9.43	0.119	9.43	0.119	9.43	0.119	9.43	0.119	9.43	0.119
9.85	0.237	15.03	0.276	9.34	0.393	14.14	0.303	9.51	0.119	9.51	0.119	9.51	0.119	9.51	0.119	9.51	0.119
10.01	0.280	9.46	0.266	9.46	0.266	14.26	0.278	9.69	0.227	9.69	0.227	9.69	0.227	9.69	0.227	9.69	0.227
10.13	0.313	9.51	0.234	14.38	0.269	14.46	0.269	10.19	0.232	10.19	0.232	10.19	0.232	10.19	0.232	10.19	0.232
10.28	0.356	9.58	0.219	10.46	0.368	9.69	0.222	14.60	0.279	14.60	0.279	14.60	0.279	14.60	0.279	14.60	0.279
10.40	0.014	10.40	0.368	9.83	0.222	14.74	0.287	10.35	0.256	10.35	0.256	10.35	0.256	10.35	0.256	10.35	0.256
10.49	0.015	10.49	0.368	9.83	0.242	14.74	0.287	10.41	0.256	10.41	0.256	10.41	0.256	10.41	0.256	10.41	0.256
10.62	0.317	10.62	0.364	10.06	0.360	14.82	0.296	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300
10.75	0.030	10.75	0.376	10.21	0.351	15.00	0.300	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300
3.00	0.915	9.67	0.210	14.96	0.270	9.25	0.509	14.06	0.349	9.43	0.119	9.43	0.119	9.43	0.119	9.43	0.119
3.16	0.015	9.85	0.237	15.03	0.276	9.34	0.393	14.14	0.303	9.51	0.119	9.51	0.119	9.51	0.119	9.51	0.119
3.23	0.018	10.01	0.280	9.46	0.266	14.26	0.278	9.69	0.227	9.69	0.227	9.69	0.227	9.69	0.227	9.69	0.227
3.33	0.318	10.13	0.313	9.51	0.234	14.38	0.269	10.19	0.232	10.19	0.232	10.19	0.232	10.19	0.232	10.19	0.232
3.43	0.014	10.28	0.356	10.46	0.368	9.69	0.222	14.60	0.279	14.60	0.279	14.60	0.279	14.60	0.279	14.60	0.279
4.99	0.014	10.40	0.368	9.83	0.222	14.74	0.287	10.35	0.256	10.35	0.256	10.35	0.256	10.35	0.256	10.35	0.256
5.22	0.015	10.49	0.368	9.83	0.242	14.74	0.287	10.41	0.256	10.41	0.256	10.41	0.256	10.41	0.256	10.41	0.256
5.54	0.317	10.62	0.364	10.06	0.360	14.82	0.296	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300
5.84	0.030	10.75	0.376	10.21	0.351	15.00	0.300	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300	10.55	0.300

CURVE 29
 $T = 413.$

CURVE 30
 $T = 431.$

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF VARIED PURITY SILICON (WAVELLENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMMITTANCE, ϵ)

λ	ϵ	CURVE 34 (CONT.)			CURVE 35 (CONT.)			CURVE 36 (CONT.)			CURVE 37 (CONT.)		
λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
11.02	0.369	7.06	0.091	12.18	0.338	7.71	0.124	12.25	0.369	7.76	0.131		
11.92	0.363	7.16	0.085	12.23	0.329	7.81	0.117	12.34	0.355	6.03	0.100		
12.11	0.401	7.32	0.085	12.34	0.296	7.97	0.094	12.44	0.349	6.14	0.100		
12.21	0.412	7.50	0.094	12.49	0.311	6.03	0.089	12.77	0.376	6.25	0.112		
12.27	0.418	7.61	0.105	12.61	0.327	8.18	0.089	12.97	0.386	6.38	0.138		
12.35	0.418	7.72	0.105	12.77	0.344	8.32	0.111	13.17	0.404	6.53	0.173		
12.53	0.405	7.82	0.090	12.93	0.357	8.50	0.147	13.32	0.426	6.68	0.214		
12.62	0.410	8.00	0.079	13.13	0.368	8.63	0.185	13.41	0.416	6.80	0.264		
12.81	0.450	8.17	0.079	13.39	0.397	8.75	0.227	13.47	0.428	6.89	0.323		
12.91	0.459	8.35	0.093	13.52	0.397	8.95	0.268	13.52	0.433	6.96	0.380		
13.02	0.461	8.50	0.124	13.58	0.390	8.94	0.346	13.59	0.433	6.97	0.399		
13.13	0.461	8.63	0.158	13.73	0.353	9.32	0.386	13.67	0.412	9.07	0.407		
13.23	0.458	8.74	0.218	13.97	0.243	9.09	0.398	13.90	0.288	9.15	0.397		
13.33	0.458	8.94	0.314	14.67	0.199	9.15	0.372	14.17	0.181	9.19	0.379		
13.43	0.466	9.05	0.379	14.14	0.161	9.21	0.304	14.23	0.172	9.22	0.319		
13.54	0.486	9.09	0.398	14.17	0.157	9.25	0.258	14.40	0.176	9.26	0.279		
13.62	0.486	9.13	0.379	14.22	0.149	9.30	0.222	14.56	0.172	9.34	0.228		
13.69	0.471	9.18	0.290	14.33	0.141	9.41	0.171	14.80	0.181	9.45	0.186		
13.95	0.384	9.27	0.176	14.45	0.141	9.50	0.146	15.00	0.186	9.52	0.170		
14.06	0.333	9.31	0.154	15.00	0.160	9.59	0.139			9.58	0.159		
14.15	0.284	9.38	0.129			9.69	0.146			9.66	0.159		
14.22	0.239	9.42	0.123			10.95	0.192			9.79	0.169		
14.46	0.212	9.50	0.118			10.95	0.238			10.08	0.227		
14.82	0.187	9.62	0.125			10.21	0.252			10.32	0.295		
14.89	0.187	9.66	0.156			10.24	0.273			10.43	0.302		
15.00	0.194	10.05	0.198			10.35	0.283			10.52	0.298		
		10.13	0.222			10.43	0.283			10.61	0.298		
		10.29	0.250			10.51	0.275			10.72	0.307		
		10.36	0.258			10.60	0.275			10.80	0.329		
		10.44	0.256			10.80	0.305			10.91	0.365		
		10.54	0.254			10.92	0.029			11.18	0.403		
		10.55	0.260			6.26	0.029			6.24	0.030		
		10.97	0.315			6.43	0.032			6.41	0.032		
		11.09	0.336			6.61	0.034			6.55	0.040		
		11.21	0.342			6.79	0.064			6.66	0.052		
		11.33	0.331			6.95	0.099			6.83	0.089		
		11.60	0.280			7.04	0.109			6.95	0.112		
		11.94	0.293			7.25	0.098			7.04	0.121		
		12.07	0.312			7.36	0.095			7.21	0.105		
		12.15	0.330			7.47	0.104			7.36	0.105		
										7.65	0.131		
										7.65	0.131		

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ϵ	CURVE 37 (CONT.)		CURVE 38 (CONT.)		CURVE 39 (CONT.)		CURVE 40 (CONT.)		CURVE 41	
λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
12.46	0.383	7.01	0.133	12.61	5.409	1.837	0.0536	13.00	0.596	0.672	0.596
12.60	0.383	7.10	0.133	12.72	6.431	2.291	0.0530	14.00	0.631	0.675	0.631
12.68	0.396	7.26	0.113	12.60	6.451	2.509	0.0560	1.16	0.675	0.675	0.569
12.73	0.414	7.35	0.113	12.49	6.459	3.724	0.0620	1.21	0.659	0.631	0.631
12.80	0.422	7.69	0.144	13.14	6.459	5.117	0.0680	1.23	0.631	0.672	0.506
12.99	0.426	7.79	0.144	13.30	6.456	5.975	0.0750	1.26	0.675	0.675	0.525
13.14	0.423	7.96	0.126	13.36	6.460	6.291	0.0660	1.29	0.361	0.473	0.580
13.28	0.436	8.13	0.112	13.54	6.487	6.531	0.0960	1.34	0.272	0.473	0.525
13.41	0.453	8.26	0.126	13.60	6.493	6.699	0.154	1.39	0.207	0.473	0.580
13.51	0.473	8.44	0.160	13.66	6.490	6.823	0.260	1.45	0.163	0.528	0.601
13.57	0.481	8.62	0.214	13.68	6.401	6.982	0.205	1.60	0.132	0.610	0.625
13.66	0.471	8.70	0.235	14.00	6.355	7.129	0.205	1.72	0.119	0.601	0.637
13.83	0.400	9.88	0.331	14.07	6.306	7.195	0.190	1.86	0.112	0.620	0.655
13.95	0.359	8.96	0.402	14.22	6.246	7.499	0.179	2.14	0.112	0.929	0.672
14.03	0.284	9.05	0.414	14.33	6.224	7.638	0.201	2.31	0.116	1.06	0.675
14.14	0.234	9.14	0.409	14.47	6.211	7.962	0.179	2.90	0.130	1.21	0.674
14.21	0.214	9.20	0.393	14.64	6.202	8.260	0.154	3.61	0.146	1.25	0.657
14.34	0.190	9.33	0.274	14.83	6.188	8.511	0.185	4.56	0.166	1.26	0.632
14.46	0.190	9.49	0.206	15.00	0.135	8.730	0.324	5.05	0.179	1.28	0.594
14.50	0.207	9.61	0.180	14.53	6.224	8.974	0.434	5.55	0.199	1.30	0.427
14.64	0.217	9.69	0.180	14.64	6.211	9.141	0.454	6.03	0.224	1.33	0.348
14.77	0.223	9.80	0.195	14.83	6.188	9.376	0.364	6.37	0.246	1.37	0.278
15.00	0.225	10.08	0.255	10.08	0.135	9.376	0.329	6.56	0.270	1.41	0.229
10.24	0.296	10.24	0.296	10.24	0.525	9.816	0.293	6.71	0.269	1.44	0.202
10.34	0.319	10.34	0.473	10.54	0.580	10.00	0.314	6.79	0.307	1.66	0.186
10.54	0.319	10.54	0.529	10.70	0.601	11.00	0.430	6.89	0.319	1.88	0.186
10.70	0.332	10.70	0.625	10.81	0.611	12.00	0.449	7.03	0.319	2.00	0.195
10.81	0.346	10.81	0.637	10.81	0.637	13.00	0.498	7.26	0.305	3.04	0.256
10.95	0.379	10.95	0.823	10.95	0.655	14.00	0.558	7.83	0.356	3.67	0.300
11.04	0.400	11.04	0.929	11.04	0.672	15.00	0.460	8.00	0.356	5.05	0.378
11.23	0.425	11.23	1.127	11.23	0.672	11.27	0.672	8.34	0.391	6.11	0.435
11.32	0.425	11.32	1.175	11.32	1.669	11.69	0.629	8.61	0.441	6.11	0.529
11.50	0.416	11.50	1.208	11.50	0.629	11.86	0.629	8.97	0.507	6.91	0.563
11.66	0.031	11.66	0.365	11.66	0.353	12.62	0.253	9.14	0.521	9.00	0.564
11.70	0.031	11.70	0.368	11.70	0.350	1.309	0.258	9.31	0.508	10.00	0.597
12.22	0.041	12.22	0.415	12.22	0.415	1.337	0.178	9.51	0.467	11.63	0.647
12.26	0.041	12.26	0.419	12.26	0.419	1.330	0.130	9.73	0.454	12.00	0.680
12.37	0.041	12.37	0.419	12.37	0.419	1.459	0.693	10.00	0.476	13.00	0.712
12.46	0.046	12.46	0.406	12.46	0.406	1.549	0.610	10.00	0.549	14.00	0.712
12.56	0.042	12.56	0.402	12.56	0.402	1.656	0.670	12.00	0.655	15.00	0.712

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

CURVE 42 $T = 74.3^\circ$		CURVE 43 (CONT.)		CURVE 44 (CONT.)		CURVE 45 (CONT.)		CURVE 46 (CONT.)		CURVE 47 (CONT.)		CURVE 48 (CONT.)		CURVE 49 (CONT.)		CURVE 50 $T = 54.3^\circ$	
λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
0.398	0.525	0.443	0.546	0.494	0.567	0.501	0.714	6.18	0.717	10.23	0.748	3.01	0.677	11.14	0.756	11.33	0.747
0.473	0.580	0.479	0.569	0.535	0.589	4.88	0.716	7.05	0.730	12.33	0.761	0.601	0.608	6.00	0.716	9.12	0.758
0.526	0.601	0.530	0.591	0.601	0.608	5.00	0.716	6.00	0.716	10.16	0.766	0.611	0.638	0.615	0.631	7.00	0.716
0.610	0.625	0.592	0.611	0.622	0.655	0.638	0.733	0.631	0.731	10.16	0.766	0.613	0.647	0.655	0.650	0.700	0.716
0.681	0.637	0.620	0.655	0.613	0.647	0.655	0.733	0.650	0.731	11.14	0.782	0.620	0.687	0.656	0.664	0.700	0.716
0.929	0.929	0.672	1.04	0.673	1.22	1.22	0.677	10.00	0.716	12.33	0.789	1.00	0.664	1.00	0.664	1.00	0.716
1.04	0.675	1.20	0.676	1.20	0.676	1.69	0.693	11.00	0.716	13.33	0.794	1.20	0.676	1.20	0.676	1.20	0.716
1.21	0.674	1.25	0.670	1.25	0.670	2.24	0.706	12.00	0.716	14.22	0.798	1.25	0.661	1.31	0.652	1.30	0.713
1.29	0.641	1.35	0.622	1.35	0.622	4.88	0.716	14.00	0.712	2.26	0.684	1.29	0.687	1.35	0.687	1.35	0.713
1.31	0.616	1.37	0.549	1.37	0.549	5.00	0.716	15.00	0.710	3.01	0.686	1.31	0.616	1.37	0.616	1.31	0.713
1.32	0.484	1.39	0.479	1.39	0.479	6.00	0.716	2.98	0.686	5.01	0.699	1.32	0.484	1.39	0.484	1.32	0.713
1.34	0.416	1.43	0.442	1.43	0.442	7.00	0.716	3.55	0.689	5.98	0.719	1.34	0.416	1.43	0.416	1.34	0.713
1.37	0.372	1.52	0.429	1.52	0.429	8.00	0.716	4.11	0.694	4.15	0.730	1.37	0.372	1.52	0.372	1.37	0.713
1.42	0.350	1.73	0.451	1.73	0.451	9.00	0.716	4.58	0.688	4.97	0.737	1.42	0.350	1.73	0.350	1.42	0.713
1.51	0.339	2.15	0.517	2.15	0.517	10.00	0.716	5.14	0.697	5.01	0.747	1.51	0.339	2.15	0.339	1.51	0.713
1.58	0.342	2.54	0.558	2.54	0.558	11.00	0.716	5.55	0.689	6.28	0.755	1.58	0.342	2.54	0.342	1.58	0.713
2.13	0.396	2.94	0.594	2.94	0.594	12.00	0.716	4.11	0.694	7.13	0.767	2.13	0.396	2.94	0.396	2.13	0.713
2.64	0.452	3.37	0.622	3.37	0.622	13.60	0.713	4.56	0.702	8.22	0.781	2.64	0.452	3.37	0.452	2.64	0.713
3.48	0.498	4.06	0.653	4.06	0.653	14.00	0.712	5.02	0.708	9.27	0.783	3.48	0.498	4.06	0.498	3.48	0.713
4.30	0.553	4.70	0.675	4.70	0.675	15.00	0.710	6.05	0.722	10.23	0.803	4.30	0.553	4.70	0.553	4.30	0.713
4.97	0.594	5.47	0.695	5.47	0.695	6.00	0.735	6.99	0.735	11.14	0.766	4.97	0.594	5.47	0.594	4.97	0.713
5.66	0.627	6.47	0.710	6.47	0.710	7.28	0.717	7.05	0.749	12.33	0.777	5.66	0.627	6.47	0.627	5.66	0.713
6.37	0.651	7.00	0.716	7.00	0.716	7.00	0.716	9.12	0.762	13.34	0.781	6.37	0.651	7.00	0.651	6.37	0.713
7.23	0.678	8.00	0.716	8.00	0.716	10.14	0.771	10.14	0.771	14.22	0.784	7.23	0.678	8.00	0.678	7.23	0.713
8.38	0.698	9.00	0.716	9.00	0.716	9.398	0.763	11.14	0.786	2.44	0.665	8.38	0.698	9.00	0.698	8.38	0.713
9.25	0.708	10.00	0.716	10.00	0.716	9.433	0.508	12.33	0.795	3.01	0.669	9.25	0.708	10.00	0.708	9.25	0.713
10.00	0.712	11.00	0.716	11.00	0.716	9.463	0.533	13.34	0.802	4.06	0.677	10.00	0.712	11.00	0.712	10.00	0.713
11.00	0.716	12.00	0.716	12.00	0.716	9.496	0.558	14.22	0.805	5.01	0.688	11.00	0.716	12.00	0.716	11.00	0.713
12.00	0.716	13.00	0.713	13.00	0.713	9.542	0.580	9.597	0.597	5.98	0.662	12.00	0.716	13.00	0.716	12.00	0.713
13.00	0.713	14.00	0.712	14.00	0.712	9.592	0.615	10.00	0.697	7.11	0.709	13.00	0.713	14.00	0.713	13.00	0.713
14.00	0.712	15.00	0.710	15.00	0.710	9.638	0.638	10.00	0.733	9.34	0.717	14.00	0.712	15.00	0.712	14.00	0.713
15.00	0.710					9.693	0.631	9.693	0.631	4.69	0.678	15.00	0.710	15.00	0.710	15.00	0.713
						1.055	0.650	2.98	0.683	5.27	0.686		1.055	1.055	1.055	1.055	1.055
						1.00	0.664	3.55	0.686	6.38	0.703		1.00	1.00	1.00	1.00	1.00
						1.22	0.677	4.11	0.691	7.13	0.713		1.22	1.22	1.22	1.22	1.22
						1.30	0.693	4.60	0.697	9.34	0.727		1.30	1.30	1.30	1.30	1.30
						1.40	0.540	2.24	0.684	5.07	0.739		1.40	1.40	1.40	1.40	1.40
						0.398	0.500	0.454	0.540	0.706	0.749		0.398	0.398	0.398	0.398	0.398

b. Normal Spectral Emittance (Temperature Dependence)

Only five papers have reported the normal spectral emittance of high purity silicon at higher than room temperatures. Only three of the five have reported measurements in the 1-15 μm range. The available experimental data, covering a temperature range from 300-1075 K, are shown in Figure 12-5 and Table 12-6. The data of curves 5 through 18 were obtained by reading points from the spectral curves of Section 12.4.a at the selected wavelengths of 2.8, 3.8, 5.0, and 10.6 μm .

The recommended values shown in Table 12-4 and Figure 12-4 are based on the data of Sato [T41640] (curves 11-14) at temperatures above 550 K and on the data of Stierwalt [T16961] (curves 5-10) and Stierwalt and Potter [T32537] (curves 15-18) below 550 K. The samples used by Stierwalt and Stierwalt and Potter were high resistivity, 2.03 mm thick (n-type) and 1.68 mm thick (p-type) single crystals, while Sato's sample was a 1.77 mm thick, n-type single crystal. The tabulated values for the selected wavelengths were obtained by drawing an average curve through the data for the 2.03 and 1.68 mm thick samples in the 300-550 K range and smoothly joining it to the higher temperature data for the 1.77 mm thick sample. Consequently, at the lower temperatures, the tabulated values are applicable only to samples about 2 mm thick. However, at temperatures above about 800 K, silicon of ordinary purity becomes opaque to radiation in the 2-15 μm range and the normal spectral emittance no longer depends on the thickness of the sample. Above about 800 K, therefore, the tabulated values are applicable to polished high resistivity, single crystals of any thickness. In this temperature region, the emittance converges to a value of about 0.710 for all wavelengths in the 2-15 μm region. Sato's measurements show that this value does not vary significantly with increasing temperature in the 900-1100 K range. Assuming that this trend continues, the constant-valued curves have been extended, provisionally, to 1600 K.

The 0.710 value of the emittance for opaque specimens gives a value of 0.290 for the single surface reflectance. As mentioned in the previous section, a variety of experimental evidence confirms a value of 0.30 for the single surface reflectance of polished relatively pure silicon at room temperature for 2-15 μm radiation. This supports the high temperature emittance values, if the single surface reflectance does not vary greatly with temperature. Measurements of the absorption coefficient and refractive index at high temperatures indicate that the single surface reflectance does indeed maintain a value near 0.30 at high temperatures.

The tabulated values for 2.8, 3.8, and 5.0 μm in the 300-700 K range must be considered typical only. Their percentage uncertainty is high (as great as 80-90%) both

because of the method used to generate them and because the emittance is very small in this range. The uncertainty of the values for 10.6 μm radiation should not exceed $\pm 15\%$ in the 300-700 K range. From 800-1100 K, the uncertainty of the values for all wavelengths is believed to be no greater than $\pm 8\%$. From 1100-1600 K, the values are extrapolated, but should be accurate to within 30%.

TABLE 12-4. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T	ϵ	SINGLE CRYSTAL 2 MM THICK $\lambda = 2.8$			SINGLE CRYSTAL 2 MM THICK $\lambda = 3.6$			SINGLE CRYSTAL 2 MM THICK $\lambda = 5.0$			SINGLE CRYSTAL 2 MM THICK $\lambda = 10.6$		
		T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ
300.	0.0288†	300.	0.0128†	300.	1.0118†	300.	0.265	300.	0.0118†	300.	0.265	300.	0.265
350.	0.0328	350.	0.0178	350.	0.0153	350.	0.289	350.	0.0153	325.	0.289	325.	0.289
400.	0.0378	400.	0.0218	400.	0.0198	400.	0.296	400.	0.0218	350.	0.296	350.	0.296
425.	0.0398	425.	0.0238	425.	0.0218	425.	0.313	425.	0.0248	375.	0.313	375.	0.313
450.	0.0418	450.	0.0258	450.	0.0248	450.	0.330	450.	0.0279	400.	0.330	400.	0.330
475.	0.0428	475.	0.0269	475.	0.0279	475.	0.346	475.	0.0378	425.	0.346	425.	0.346
500.	0.0458	500.	0.0369	500.	0.0378	500.	0.364	500.	0.0498	450.	0.364	450.	0.364
520.	0.0498	520.	0.0458	520.	0.0498	520.	0.382	520.	0.0658	475.	0.382	475.	0.382
540.	0.0568	540.	0.0598	540.	0.0658	540.	0.400	540.	0.085A	500.	0.400	500.	0.400
560.	0.069A	560.	0.074A	560.	0.085A	560.	0.419	560.	0.109A	525.	0.419	525.	0.419
580.	0.087A	580.	0.092A	580.	0.109A	580.	0.440	580.	0.138A	550.	0.440	550.	0.440
600.	0.106A	600.	0.114A	600.	0.138	600.	0.464	600.	0.173	575.	0.464	575.	0.464
620.	0.126	620.	0.126	620.	0.169	620.	0.490	620.	0.217	600.	0.490	600.	0.490
640.	0.151	640.	0.169	640.	0.206	640.	0.517	640.	0.270	620.	0.517	620.	0.517
660.	0.181	660.	0.206	660.	0.253	660.	0.538	660.	0.333	640.	0.538	640.	0.538
680.	0.213	680.	0.262	680.	0.314	680.	0.563	680.	0.404	660.	0.563	660.	0.563
700.	0.262	700.	0.344	700.	0.393	700.	0.609	700.	0.490	690.	0.609	690.	0.609
720.	0.344	720.	0.431	720.	0.467	720.	0.630	720.	0.581	700.	0.630	700.	0.630
740.	0.431	740.	0.499	740.	0.560	740.	0.652	740.	0.634	710.	0.652	710.	0.652
760.	0.499	760.	0.559	760.	0.610	760.	0.672	760.	0.664	720.	0.672	720.	0.672
780.	0.559	780.	0.608	780.	0.649	780.	0.699	780.	0.685	730.	0.699	730.	0.699
800.	0.608	800.	0.647	800.	0.678	800.	0.700	800.	0.699	740.	0.700	740.	0.700
820.	0.647	820.	0.682	820.	0.698	820.	0.735	820.	0.716	750.	0.735	750.	0.735
840.	0.682	840.	0.705	840.	0.711	840.	0.750	840.	0.716	800.	0.750	800.	0.750
860.	0.705	860.	0.712	860.	0.714	860.	0.776	860.	0.716	850.	0.776	850.	0.776
880.	0.712	880.	0.712	880.	0.714	880.	0.800	880.	0.716	870.	0.800	870.	0.800
900.	0.712	900.	0.712	900.	0.714	900.	0.825	900.	0.716	900.	0.825	900.	0.825
950.	0.712	950.	0.712	950.	0.714	950.	0.875	950.	0.716	950.	0.875	950.	0.875
1000.	0.712	1000.	0.712	1000.	0.714	1000.	1.000	1000.	0.716	1000.	1.000	1000.	1.000
1050.	0.712	1050.	0.712	1050.	0.714	1050.	1.050	1050.	0.716	1050.	1.050	1050.	1.050
1075.	0.712	1075.	0.712	1075.	0.714	1075.	1.075	1075.	0.716	1075.	1.075	1075.	1.075
1400.	0.712A	1400.	0.714A	1400.	0.714A	1400.	1.400	1400.	0.716A	1400.	1.400	1400.	1.400
1600.	0.712A	1600.	0.714A	1600.	0.714A	1600.	1.600	1600.	0.716A	1600.	1.600	1600.	1.600

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL AND BY A "g" IS TYPICAL.




FIGURE 12-4. RECOMMENDED NORMAL SPECTRAL EMMITTANCE OF HIGH-RESISTIVITY SILICON
(TEMPERATURE DEPENDENCE)




FIGURE 12-5. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON
(TEMPERATURE DEPENDENCE)

TABLE 12-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMISSIVITY OF SILICON (Temperature Dependence)

Cur. Ref. No.	Author(s) No.	Year No.	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1*T8677	Allen, F.G.	1957	0.65	1000-1688		Single crystal; long thin-walled cylinder 1 in. long × 0.5 in. O.D. × 0.020 in. wall; etched; vacuum of 10^{-7} to 10^{-9} mm Hg; Worthing thin-walled cylinder technique; geometry gave as much as 5% less than ideal black body conditions; values may be high, particularly at lower temperatures; reported error $\pm 10\%$.
2*T8677	Allen, F.C.	1957	0.65	1000-1688		Similar to the above specimen except specimen sandblasted and measured in open air; rough indication only; extracted from smoothed curve.
3*T74059	Baum, B.A., Shvarev, K.M., and Gelt, P.V.	1971	0.72			Values obtained by comparing spectral intensities from the liquid specimen and from simulated graphite black body.
4*T74089	Baum, B.A., et al.	1971	0.66	1373, 1973		Similar to the above specimen.
5 T16961	Stierwalt, D.L.	1961	3.8	333-433	n-type, single crystal; 2.03 mm thick; both surfaces ground and polished; measured in vacuum using modified Beckman IR-3 spectrophotometer; resistivity 30-60 ohm-cm; data extracted from spectral curves roughly.	
6 T16961	Stierwalt, D.L.	1961	5.0	333-433	The above specimen.	
7 T16961	Stierwalt, D.L.	1961	10.6	333-433	The above specimen.	
8 T16961	Stierwalt, D.L.	1961	3.8	313-433	p-type, single crystal; 1.68 mm thick; ground and polished on both surfaces; measured in vacuum using modified Beckman IR-3 spectrophotometer; data extracted from spectral curves roughly.	
9 T16961	Stierwalt, D.L.	1961	5.0	313-433	The above specimen.	
10 T16961	Stierwalt, D.L.	1961	10.6	313-433	The above specimen.	
11 T41640	Sato, T.	1967	2.8	543-1073	n-type, phosphorous doped, single crystal disk with 26 mm diameter and 1.77 mm thickness; resistivity 15 ohm-cm; ground and polished plane parallel using metallographic and optical techniques; measured under 10^{-4} mm Hg to preclude oxidation; data extracted from spectral curves.	
12 T41640	Sato, T.	1967	5.0	543-1073	The above specimen.	
13 T41640	Sato, T.	1967	3.8	543-1073	The above specimen.	
14 T41640	Sato, T.	1967	10.6	543-1073	The above specimen.	
15 T32337	Stierwalt, D.L. and Potter, R.F.	1962	2.8	323-473	p-type, single crystal; 1.68 mm thick; resistivity 30 ohm-cm; cut to size with ultrasonic tool; optical surfaces prepared using standard lapping and polishing techniques; not etched; data extracted from spectral curves.	
16 T32337	Stierwalt, D.L. and Potter, R.F.	1962	3.8	323-473	The above specimen.	
17 T32337	Stierwalt, D.L. and Potter, R.F.	1962	5.0	323-473	The above specimen.	
18 T32337	Stierwalt, D.L. and Potter, R.F.	1962	10.6	323-473	The above specimen.	

* Not shown in figure.

TABLE 12-6. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMMITTANCE, ϵ)

T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ
CURVE 1 $\lambda = 0.65$		CURVE 3 $\lambda = 0.72$		CURVE 7 (CONT.)		CURVE 12 $\lambda = 5.0$		CURVE 16 (CONT.)	
1900.	0.64	1623.	0.664	413.	0.365	563.	0.067	373.	0.026
1100.	0.62	1677.	0.684	433.	0.376	623.	0.179	423.	0.028
1200.	0.60	1680.	0.245	CURVE 8 $\lambda = 3.8$		693.	0.376	473.	0.033
1300.	0.57	1687.	0.235			743.	0.593	CURVE 17 $\lambda = 5.0$	
1400.	0.54	1846.	0.235			793.	0.600		
1500.	0.50	CURVE 4 $\lambda = 0.66$		313.	0.023	673.	0.716	323.	0.016
1600.	0.48			353.	0.024	1073.	0.716	373.	0.022
1686.	0.46			393.	0.026			423.	0.022
CURVE 2 $\lambda = 0.65$		1373.	0.69	CURVE 9 $\lambda = 5.0$		CURVE 13 $\lambda = 3.8$		473.	0.030
1000.	0.759	CURVE 5 $\lambda = 3.8$							
1025.	0.759			313.	0.017	623.	0.144	CURVE 18 $\lambda = 10.6$	
1050.	0.759			353.	0.021	693.	0.294		
1075.	0.759	333.	0.009	393.	0.022	743.	0.504	323.	0.238
1100.	0.756	353.	0.009	433.	0.024	793.	0.634	373.	0.254
1125.	0.755	373.	0.007			873.	0.714	423.	0.205
1150.	0.755	393.	0.014	CURVE 10 $\lambda = 10.6$		1073.	0.714	473.	0.315
1175.	0.755	413.	0.014						
1200.	0.755	433.	0.014						
1225.	0.755			313.	0.259				
1250.	0.755	CURVE 6 $\lambda = 5.0$		353.	0.279	693.	0.627		
1275.	0.753			393.	0.298	743.	0.716		
1300.	0.751			433.	0.324	793.	0.716		
1325.	0.751	333.	0.011	CURVE 11 $\lambda = 2.8$		873.	0.716		
1350.	0.751	353.	0.011			1073.	0.716		
1375.	0.750	373.	0.011						
1400.	0.750	393.	0.012						
1425.	0.750	413.	0.012	543.	0.057	CURVE 15 $\lambda = 2.8$			
1450.	0.750	433.	0.012	623.	0.128				
1475.	0.750			693.	0.243	373.	0.329		
1500.	0.749	CURVE 7 $\lambda = 10.6$		743.	0.453	423.	0.466		
1525.	0.749			793.	0.501	473.	0.052		
1550.	0.747	333.	0.310	873.	0.712	CURVE 16 $\lambda = 3.8$			
1575.	0.747	353.	0.322	1073.	0.712				
1600.	0.747	373.	0.333						
		393.	0.349					323.	0.022

c. Normal Spectral Reflectance (Wavelength Dependence)

Twenty-four experimental data sets for the wavelength dependence ($1\text{-}14 \mu\text{m}$) of the normal spectral reflectance of silicon are shown in Table 12-9 and Figure 12-7. All of the measurements were made at room temperature for single crystal specimens. Of the 24 data sets, 8 sets are for specimens of relatively high purity.

The recommended values for 330 K shown in Table 12-7 and Figure 12-6 were calculated from the recommended values for the normal spectral emittance at 330 K by use of the McMahon [T20468] relations (Eq. 2.6-10 to 2.6-12). Equation 2.6-12 for the normal spectral emittance, ϵ , can be rearranged to yield

$$ad = \ln \left(\frac{1 - R - R\epsilon}{1 - \epsilon - R} \right) \quad (4.12-1)$$

where a is the absorption coefficient, d is the thickness, and R is the single surface reflectance of a plane-parallel specimen. As discussed in the previous sections, the single surface reflectance (i.e., the reflectance of an opaque specimen) of silicon near room temperature is 0.30 in the $2\text{-}15 \mu\text{m}$ range. Using this value, and the recommended emittance values, ad was calculated from Eq. 4.12-1 and used in the McMahon relation (Eq. 2.6-11) to determine the normal spectral reflectance. The 330 K values are applicable to a 2 mm thick, silicon single crystal of relatively high purity and resistivity.

In the $1.5\text{-}8 \mu\text{m}$ wavelength range, the 330 K recommended values agree with the data of Vasilev, et al. [T49418] (curve 24) and Fray, et al. [T41607] (curves 20, 21) to within 5% and with the data of Sato [T41640] (curve 22) to within 10%. These investigators did not specify the thickness of their samples. In this wavelength range, the normal spectral emittance is quite low and the normal spectral reflectance approaches the 0.46 value predicted by the McMahon relations for negligible absorption and emission. It is worthwhile to note that the 0.46 value is accurate to within 15% for any specimen whose emittance is 0.20 or less. According to measurements by Stierwalt [T32537] (curves 8, 9 of Section 4.12.a), this criteria is satisfied in the $2\text{-}6.5 \mu\text{m}$ range by specimens as thick as 13 mm, so the recommended values are applicable to a rather wide range of thicknesses in the $2\text{-}6.5 \mu\text{m}$ range. In the $1.5\text{-}8 \mu\text{m}$ range, the uncertainty of the 330 K recommended values should not exceed $\pm 10\%$. In the $8\text{-}14 \mu\text{m}$ wavelength range, there is no experimental reflectance data which can be meaningfully compared with the recommended values. However, the uncertainty of the values in this range is believed to be no greater than $\pm 15\%$. The uncertainty may be greater in the $9 \mu\text{m}$ region due to differences between crystals in the bulk oxygen content.

The 1075 K recommended values were obtained from the normal spectral emittance data of Sato [T41640] (curve 45 of Section 4.12.a). Silicon of ordinary purity is opaque in the 2-15 μm region at this high temperature, because of absorption due to free carriers, and the sum of the normal spectral emittance and the normal spectral reflectance is unity. The values are applicable to plane-parallel, polished, silicon single crystals of relatively high purity and of any thickness. The uncertainty of the 1075 K recommended values is believed to be within $\pm 10\%$ in the 2-15 μm wavelength range.

For applications as infra-red optical components, silicon is often coated with other materials designed to reduce reflection losses in specified wavelength ranges. The thermal radiative properties of these systems of silicon plus anti-reflection coatings may be markedly different from those of silicon alone. Surface oxide layers produced by high temperature atmospheric heating of silicon also alter the reflectance properties, as shown by curves 22 and 23 by Sato [T41640].

The reflectance of silicon may change greatly when it is strongly excited by laser radiation. Bobrova, et al. [T76806] measured the reflectance at 10.6 μm of a high resistivity silicon specimen under excitation by a ruby laser (0.6943 μm). They found that the reflectance first decreased from 0.30 to 0.19, and then increased to 0.50 as the excitation intensity was increased. The minimum reflectance occurred at an excitation intensity of about $10^{24} \text{ kW cm}^{-2} \text{ s}^{-1}$. Birnbaum and Stocker [A000029] found that the reflectance at around 0.5 μm (argon-ion laser) of a silicon specimen under excitation by a ruby laser increased by as much as 60%. Other investigators [A000031, T77096, T36227, T35800, T36304] have observed similar changes in silicon and other semiconductors. Gauster and Bushnell [T37021] and Reintjes and McGroddy [T77510] have observed related increases in the absorption of silicon when excited by laser radiation. These effects have been attributed both to the presence of a thin metallic surface layer produced by melting and to the presence of a high concentration of non-equilibrium charge carriers generated by the laser radiation.

TABLE 12-7. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
SINGLE CRYSTAL 2.0 MM THICK $T = 330$											
1.00	0.3558†	8.20	0.426	12.10	0.343	1.00	0.336A†				
1.10	0.4208	9.30	0.422	12.20	0.339	1.50	0.313A				
1.20	0.4468	8.49	0.412	12.30	0.331	2.00	0.301A				
1.30	0.453	8.50	0.401A†	12.40	0.343	2.80	0.288				
1.40	0.456	8.60	0.369A	12.50	0.342	3.00	0.286				
1.50	0.457	8.70	0.371A	12.60	0.340	3.80	0.286				
1.60	0.457	8.80	0.368A	12.70	0.336	4.00	0.285				
1.70	0.457	8.90	0.332A	12.80	0.334	4.50	0.285				
1.80	0.458	9.00	0.325A	12.90	0.333	5.00	0.284				
1.90	0.458	9.10	0.325A	13.00	0.332	6.00	0.284				
2.00	0.458	9.20	0.336A	13.10	0.331	7.00	0.284				
2.20	0.458	9.30	0.360A	13.20	0.329	6.00	0.284				
2.40	0.458	9.40	0.399	13.30	0.327	9.00	0.284				
2.60	0.458	9.50	0.406	13.40	0.325	10.00	0.284				
2.80	0.458	9.60	0.408	13.50	0.323	10.60	0.284				
3.00	0.458	9.70	0.405	13.60	0.324	11.00	0.284				
3.80	0.458	9.80	0.398	13.70	0.330	12.00	0.284				
4.00	0.458	9.90	0.392	13.80	0.337	13.00	0.287				
5.00	0.458	10.00	0.385	13.90	0.348	14.00	0.288				
5.50	0.457	10.10	0.377	14.00	0.363	15.00	0.290				
5.85	0.453	10.20	0.370								
6.00	0.454	10.30	0.364								
6.20	0.454	10.40	0.363								
6.40	0.453	10.50	0.364								
6.60	0.446	10.60	0.364								
6.80	0.433	10.70	0.356								
6.90	0.425	10.80	0.353								
7.00	0.423	10.90	0.347								
7.10	0.426	11.00	0.342								
7.20	0.427	11.10	0.339								
7.30	0.427	11.20	0.336								
7.40	0.426	11.30	0.336								
7.50	0.422	11.40	0.338								
7.60	0.419	11.50	0.342								
7.70	0.417	11.60	0.346								
7.80	0.420	11.70	0.350								
7.90	0.423	11.80	0.352								
8.00	0.426	11.90	0.352								
8.10	0.427	12.00	0.348								

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL AND BY A "gen" IS TYPICAL.




FIGURE 12-6. RECOMMENDED NORMAL SPECTRAL REFLECTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)




FIGURE 12-7. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON OF VARIED PURITY (WAVELENGTH DEPENDENCE).

TABLE 12-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T20100	McCarthy, D.E.	1963	2-50	293		1 cm thick; both surfaces ground and polished to flatness of one fringe; measured with Beckman specular reflectance attachment with Beckman IR-5A in the 2-16 μm region and with Beckman IR-7 in the 12.5-50 μm region; compared to aluminum mirror; measurement temperature not stated explicitly; assumed to be 293 K; data extracted from smooth curve.
2 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-10.5	293	Doped with antimony; carrier concentration $4.47 \times 10^{18} \text{ cm}^{-3}$; measured with a Perkin-Elmer Model 1112 spectrometer; comparative standard a front surfaced aluminum mirror; data corrected for the reference mirror; measurement temperature not stated explicitly; assumed to be 293 K; data presented in figure; reproducibility: 0.5%.	
3 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-15	293	Similar to the above specimen except doped with antimony to a carrier concentration of $1.65 \times 10^{18} \text{ cm}^{-3}$.	
4 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-20	293	Similar to the above specimen except doped with antimony to a carrier concentration of $0.632 \times 10^{18} \text{ cm}^{-3}$.	
5 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-8	293	Similar to the above specimen except doped with arsenic to a carrier concentration of $9.03 \times 10^{18} \text{ cm}^{-3}$.	
6 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-8	293	Similar to the above specimen except doped with arsenic to a carrier concentration of $7.32 \times 10^{18} \text{ cm}^{-3}$.	
7 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-10	293	Similar to the above specimen except doped with arsenic to a carrier concentration of $6.37 \times 10^{18} \text{ cm}^{-3}$.	
8 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-11	293	Similar to the above specimen except doped with arsenic to a carrier concentration of $5.05 \times 10^{18} \text{ cm}^{-3}$.	
9 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-14	293	Similar to the above specimen except doped with arsenic to a carrier concentration of $3.48 \times 10^{18} \text{ cm}^{-3}$.	
10 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-14	293	Similar to the above specimen except doped with arsenic to a carrier concentration of $2.84 \times 10^{18} \text{ cm}^{-3}$.	
11 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-14	293	Similar to the above specimen except doped with arsenic to a carrier concentration of $0.877 \times 10^{18} \text{ cm}^{-3}$.	
12 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-20	293	Similar to the above specimen except doped with phosphorus to a carrier concentration of $16.7 \times 10^{18} \text{ cm}^{-3}$.	
13 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-7	293	Similar to the above specimen except doped with phosphorus to a carrier concentration of $10.22 \times 10^{18} \text{ cm}^{-3}$.	
14 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-12	293	Similar to the above specimen except doped with phosphorus to a carrier concentration of $4.39 \times 10^{18} \text{ cm}^{-3}$.	
15 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-15	293	Similar to the above specimen except doped with phosphorus to a carrier concentration of $2.05 \times 10^{18} \text{ cm}^{-3}$.	
16 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-20	293	Similar to the above specimen except doped with phosphorus to a carrier concentration of $1.27 \times 10^{18} \text{ cm}^{-3}$.	
17 T29605	Howard, L.E. and Gilbert, J.F.	1963	2-20	293	Similar to the above specimen except doped with phosphorus to a carrier concentration of $0.74 \times 10^{18} \text{ cm}^{-3}$.	

TABLE 12-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
18 T22741	Coblentz, W.W.	1911	0.5-9.5	293	b	Specimen from Kahlbaum; quite homogeneous; polished using fine grade of emery paper covered with mixture of tin oxide and graphitic; measured using fluorite prism, mirror spectrometer, and vacuum bolometer; compared with silvered glass mirror; crystal of a bluish color; data presented in figure; measurement temperature not stated explicitly; assumed to be 293 K; reported error 1-3%.
19 T22741	Coblentz, W.W.	1911	0.6-8.8	293	a	Specimen from Carborundum Co.; less homogeneous, more porous, poorer polish, harder than the above specimen; polishing and measurement techniques similar to those of the above specimen.
20 T41607	Fray, S.J., Goodwin, A.R., Johnson, F.A., and Quarlington, J.E.	1963	1.886, 2.119	293		Pure, plane parallel specimen; special apparatus measured reflectance and transmittance simultaneously; absorption negligible; optical constants calculated; precision better than 1%; each point represents separate measurement.
21 T41607	Fray, S.J., et al.	1963	1.886, 2.119	293		Calculated from known refractive index data.
22 T41640	Sato, T.	1966	4.4-10.3	293		n-type, phosphor doped single crystal; optically polished and plane parallel; source radiation split into reference and test beams; aluminized mirror of known reflectivity used as standard; incident beam chopped at 10 cycle per sec; measured under 10^{-4} mm Hg to prevent oxidation; measurement temperature not stated explicitly; assumed to be 293 K; $\theta = 4^\circ$.
23 T41640	Sato, T.	1966	4.4-10.3	293		The above specimen measured after heating in atmosphere; oxidation shown by Resatraklen of Si-O at 9 μm .
24 T42418	Vasil'ev, A.M., Golovnor, T.M., Landsman, A.P., and Lidoronko, N.S.	1967		293		Undoped disc specimen cut from rod with free carrier concentration of 10^{15} cm^{-3} ; polished on both sides; measured with IKS-14 spectrometer with reflection attachment; measurement temperature not stated explicitly; assumed to be 293 K.

TABLE 12-3. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF VARIED PURITY SILICON (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 293.$	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 4 $T = 293.$	λ	ρ	CURVE 5 $T = 293.$	λ	ρ	CURVE 6 $T = 293.$	λ	ρ	CURVE 7 $T = 293.$	λ	ρ	CURVE 8 $T = 293.$	λ	ρ	CURVE 9 $T = 293.$	λ	ρ	CURVE 10 (CONT.)	λ	ρ	CURVE 11 $T = 293.$
2.0	0.350	4.21	0.253	1.3	0.215	1.3	0.39	0.215	2.0	0.03	0.276	7.47	0.164	5.51	0.241	5.51	0.231	5.97	0.196	12.97	0.196	13.46	0.196	14.00	0.193	14.50	0.193	15.00	0.195	15.50	0.195	
3.3	0.354	4.51	0.244	4.49	0.239	4.49	0.224	4.49	2.49	0.265	6.51	0.254	6.51	0.254	6.51	0.220	6.51	0.220	6.99	0.211	7.49	0.198	8.51	0.178	9.07	0.175	9.51	0.171	10.00	0.171	10.50	0.170
4.2	0.372	5.46	0.209	5.46	0.209	5.46	0.209	5.46	2.97	0.258	6.99	0.320	10.01	0.448	10.01	0.448	10.01	0.448	11.02	0.536	11.02	0.536	11.52	0.51	12.00	0.51	12.50	0.51	13.00	0.51		
5.0	0.387	6.06	0.187	6.06	0.187	6.06	0.187	6.06	3.50	0.235	11.02	0.536	11.02	0.536	11.02	0.536	11.02	0.536	11.52	0.51	12.00	0.51	12.50	0.51	13.00	0.51	13.50	0.51				
5.9	0.397	6.49	0.170	6.49	0.170	6.49	0.170	6.49	4.00	0.449	11.02	0.536	11.02	0.536	11.02	0.536	11.02	0.536	11.52	0.51	12.00	0.51	12.50	0.51	13.00	0.51	13.50	0.51				
6.5	0.358	7.30	0.150	7.30	0.150	7.30	0.150	7.30	2.60	0.295	4.49	0.194	4.49	0.194	4.49	0.194	4.49	0.194	5.00	0.97	5.00	0.97	5.50	0.97	6.00	0.97	6.50	0.97	7.00	0.97		
7.1	0.313	7.49	0.143	7.49	0.143	7.49	0.143	7.49	3.00	0.288	4.99	0.174	4.99	0.174	4.99	0.174	4.99	0.174	5.50	0.160	5.50	0.160	6.00	0.160	6.50	0.160	7.00	0.160	7.50	0.160		
6.1	0.335	8.30	0.145	8.30	0.145	8.30	0.145	8.30	4.01	0.284	5.50	0.160	5.50	0.160	5.50	0.160	5.50	0.160	6.00	0.288	6.00	0.288	6.50	0.288	7.00	0.288	7.50	0.288	8.00	0.288		
6.8	0.303	8.56	0.160	8.56	0.160	8.56	0.160	8.56	5.50	0.278	6.51	0.186	6.51	0.186	6.51	0.186	6.51	0.186	7.00	0.261	7.00	0.261	7.50	0.261	8.00	0.261	8.50	0.261	9.00	0.261		
9.3	0.324	9.03	0.233	9.03	0.233	9.03	0.233	9.03	5.99	0.272	7.01	0.261	7.01	0.261	7.01	0.261	7.01	0.261	7.50	0.261	7.50	0.261	8.00	0.261	8.50	0.261	9.00	0.261	9.50	0.261		
9.9	0.324	10.00	0.402	10.00	0.402	10.00	0.402	10.00	6.99	0.265	8.00	0.255	8.00	0.255	8.00	0.255	8.00	0.255	8.50	0.255	8.50	0.255	9.00	0.255	9.50	0.255	10.00	0.255	10.50	0.255		
10.7	0.293	10.53	0.477	10.53	0.477	10.53	0.477	10.53	3.00	0.255	4.99	0.245	4.99	0.245	4.99	0.245	4.99	0.245	5.50	0.265	5.50	0.265	6.00	0.265	6.50	0.265	7.00	0.265	7.50	0.265		
11.7	0.298	12.7	0.309	12.7	0.309	12.7	0.309	12.7	10.61	0.236	12.31	0.222	12.31	0.222	12.31	0.222	12.31	0.222	12.80	0.239	12.80	0.239	13.30	0.239	13.80	0.239	14.30	0.239	14.80	0.239		
13.6	0.325	14.9	0.347	14.9	0.347	14.9	0.347	14.9	13.30	0.203	13.30	0.203	13.30	0.203	13.30	0.203	13.30	0.203	13.80	0.258	13.80	0.258	14.30	0.258	14.80	0.258	15.30	0.258	15.80	0.258		
17.4	0.363	2.00	0.290	2.00	0.290	2.00	0.290	2.00	13.97	0.188	13.97	0.188	13.97	0.188	13.97	0.188	13.97	0.188	14.49	0.214	14.49	0.214	15.00	0.214	15.50	0.214	16.00	0.214	16.50	0.214		
22.5	0.363	2.99	0.263	2.99	0.263	2.99	0.263	2.99	3.51	0.275	14.97	0.183	14.97	0.183	14.97	0.183	14.97	0.183	15.49	0.193	15.49	0.193	16.00	0.193	16.50	0.193	17.00	0.193	17.50	0.193		
24.3	0.371	4.01	0.271	4.01	0.271	4.01	0.271	4.01	15.96	0.175	15.96	0.175	15.96	0.175	15.96	0.175	15.96	0.175	16.47	0.174	16.47	0.174	17.00	0.174	17.50	0.174	18.00	0.174	18.50	0.174		
26.9	0.371	5.53	0.267	5.53	0.267	5.53	0.267	5.53	16.45	0.179	16.45	0.179	16.45	0.179	16.45	0.179	16.45	0.179	16.97	0.178	16.97	0.178	17.50	0.178	18.00	0.178	18.50	0.178	19.00	0.178		
31.4	0.344	6.32	0.254	6.32	0.254	6.32	0.254	6.32	16.95	0.182	16.95	0.182	16.95	0.182	16.95	0.182	16.95	0.182	17.47	0.176	17.47	0.176	18.00	0.176	18.50	0.176	19.00	0.176	19.50	0.176		
35.5	0.342	7.98	0.254	7.98	0.254	7.98	0.254	7.98	17.97	0.196	17.97	0.196	17.97	0.196	17.97	0.196	17.97	0.196	18.49	0.219	18.49	0.219	19.00	0.219	19.50	0.219	20.00	0.219	20.50	0.219		
36.8	0.346	8.49	0.258	8.49	0.258	8.49	0.258	8.49	19.39	0.217	19.39	0.217	19.39	0.217	19.39	0.217	19.39	0.217	19.91	0.217	19.91	0.217	20.50	0.217	21.00	0.217	21.50	0.217	22.00	0.217		
42.3	0.356	5.96	0.253	5.96	0.253	5.96	0.253	5.96	20.00	0.244	20.00	0.244	20.00	0.244	20.00	0.244	20.00	0.244	20.50	0.244	20.50	0.244	21.00	0.244	21.50	0.244	22.00	0.244	22.50	0.244		
43.7	0.354	6.46	0.244	6.46	0.244	6.46	0.244	6.46	20.70	0.235	20.70	0.235	20.70	0.235	20.70	0.235	20.70	0.235	21.22	0.235	21.22	0.235	21.70	0.235	22.20	0.235	22.70	0.235	23.20	0.235		
44.6	0.370	7.00	0.229	7.00	0.229	7.00	0.229	7.00	21.00	0.229	21.00	0.229	21.00	0.229	21.00	0.229	21.00	0.229	21.50	0.229	21.50	0.229	22.00	0.229	22.50	0.229	23.00	0.229	23.50	0.229		
47.1	0.416	7.98	0.219	7.98	0.219	7.98	0.219	7.98	21.50	0.221	21.50	0.221	21.50	0.221	21.50	0.221	21.50	0.221	22.00	0.221	22.00	0.221	22.50	0.221	23.00	0.221	23.50	0.221	24.00	0.221		
46.0	0.435	8.51	0.211	8.51	0.211	8.51	0.211	8.51	22.00	0.223	22.00	0.223	22.00	0.223	22.00	0.223	22.00	0.223	22.50	0.223	22.50	0.223	23.00	0.223	23.50	0.223	24.00	0.223	24.50	0.223		
48.6	0.416	9.46	0.211	9.46	0.211	9.46	0.211	9.46	22.52	0.263	22.52	0.263	22.52	0.263	22.52	0.263	22.52	0.263	23.00	0.275	23.00	0.275	23.50	0.275	24.00	0.275	24.50	0.275	25.00	0.275		
50.0	0.416	9.97	0.195	9.97	0.195	9.97	0.195	9.97	23.00	0.243	23.00	0.243	23.00	0.243	23.00	0.243	23.00	0.243	23.50	0.221	23.50	0.221	24.00	0.221	24.50	0.221	25.00	0.221	25.50	0.221		
CURVE 2 $T = 293.$		10.50	0.174	10.50	0.174	10.50	0.174	10.50	24.50	0.265	24.50	0.265	24.50	0.265	24.50	0.265	24.50	0.265	25.00	0.249	25.00	0.249	25.50	0.249	26.00	0.249	26.50	0.249	27.00	0.249		
CURVE 3 $T = 293.$		10.94	0.163	10.94	0.163	10.94	0.163	10.94	25.00	0.200	25.00	0.200	25.00	0.200	25.00	0.200	25.00	0.200	25.50	0.194	25.50	0.194	26.00	0.194	26.50	0.194	27.00	0.194	27.50	0.194		
CURVE 4 $T = 293.$		11.48	0.161	11.48	0.161	11.48	0.161	11.48	25.50	0.200	25.50	0.200	25.50	0.200	25.50	0.200	25.50	0.200	26.00	0.194	26.00	0.194	26.50	0.194	27.00	0.194	27.50	0.194	28.00	0.194		
CURVE 5 $T = 293.$		8.97	0.203	8.97	0.203	8.97	0.203	8.97	26.00	0.275	26.00	0.275	26.00	0.275	26.00	0.275	26.00	0.275	26.50	0.255	26.50	0.255	27.00	0.255	27.50	0.255	28.00	0.255	28.50	0.255		
CURVE 6 $T = 293.$		9.97	0.163	9.97	0.163	9.97	0.163	9.97	26.50	0.258	26.50	0.258	26.50	0.258	26.50	0.258	26.50	0.258	27.00	0.243	27.00	0.243	27.50	0.243	28.00	0.243	28.50	0.243	29.00	0.243		
CURVE 7 $T = 293.$		10.40	0.156	10.40	0.156	10.40	0.156	10.40	27.00	0.235	27.00	0.235	27.00	0.235	27.00	0.235	27.00	0.235	27.50	0.221	27.50	0.221	28.00	0.221	28.50	0.221	29.00	0.221	29.50	0.221		
CUR																																

TABLE 12-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF VARIFIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)

d. Normal Spectral Absorptance (Wavelength Dependence)

No experimental data for the normal spectral absorptance of silicon have been reported as such. However, Kirchhoff's law, stating that the absorptance of a specimen is equal to its emittance, is valid for normal spectral properties. Consequently, the values recommended for the normal spectral emittance of silicon in Section 4.12.a are repeated in Table 12-10 and Figure 12-8. The 330 K recommended values apply to a 2 mm thick, n-type single crystal of relatively high purity and resistivity. The 1075 K recommended values are applicable to relatively pure, high resistivity, single crystal silicon of any thickness. The uncertainties of the tabulated values were discussed in Section 4.12.a.

TABLE 12-16. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

λ	α	λ	α	λ	α	λ	α	λ	α
SINGLE CRYSTAL 2.0 MM THICK $T = 330$									
SINGLE CRYSTAL 2.0 MM THICK $T = 330$ (CONT.)									
1.00	0.665	6.20	0.104	12.10	0.390	1.00	0.664		
1.10	0.575	6.30	0.114	12.20	0.410	1.50	0.667		
1.20	0.2298†	6.40	0.146	12.30	0.397	2.00	0.703		
1.30	0.0248	6.50	0.1793†	12.40	0.369	2.50	0.712		
1.40	0.3178	6.60	0.2201	12.50	0.391	3.00	0.714		
1.50	0.0148	6.70	0.2808	12.60	0.403	3.50	0.714		
1.60	0.0138	6.80	0.3669	12.70	0.417	4.00	0.714		
1.70	0.312A	6.90	0.4358	12.80	0.427	4.50	0.715		
1.80	0.011A	9.00	0.4728	12.90	0.433	5.00	0.716		
1.90	0.911A	9.10	0.4708	13.00	0.439	6.00	0.716		
2.00	0.010A	9.20	0.4208	13.10	0.443	7.00	0.716		
2.20	0.010A	9.30	0.3208	13.20	0.451	8.00	0.716		
2.40	0.009A	9.40	0.1688	13.30	0.460	9.00	0.716		
2.60	0.009A	9.50	0.165	13.40	0.470	10.00	0.716		
2.80	0.109A	9.60	0.158	13.50	0.482	10.60	0.716		
3.00	0.009A	9.70	0.169	13.60	0.478	11.00	0.716		
3.80	0.009A	9.85	0.190	13.70	0.446	12.00	0.716		
4.00	0.009A	9.90	0.210	13.80	0.414	13.00	0.713		
5.00	0.019A	10.00	0.237	13.90	0.367	14.00	0.712		
5.50	0.013A	10.10	0.260	14.00	0.310	15.00	0.710		
5.85	0.024	10.20	0.284						
6.00	0.022	10.30	0.305						
6.20	0.021	10.40	0.309						
6.40	0.023	10.50	0.306						
6.60	0.030	10.60	0.308						
6.80	0.083	10.70	0.329						
6.90	0.105	10.80	0.350						
7.00	0.112	10.90	0.373						
7.10	0.104	11.00	0.394						
7.20	0.100	11.10	0.410						
7.30	0.100	11.20	0.417						
7.40	0.104	11.30	0.417						
7.50	0.116	11.40	0.409						
7.60	0.125	11.50	0.392						
7.70	0.130	11.60	0.375						
7.80	0.122	11.70	0.358						
7.90	0.113	11.80	0.350						
8.00	0.103	11.90	0.350						
8.10	0.100	12.00	0.368						

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL AND BY A "B" IS TYPICAL.




FIGURE 12-8. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)

e. Normal Spectral Absorptance (Temperature Dependence)

No experimental data for the temperature dependence of the normal spectral absorptance of silicon have been reported as such. However Kirchhoff's law, stating that the absorptance of a specimen is equal to its emittance, is valid for normal spectral properties. Consequently, the values recommended for the normal spectral emittance of silicon in Section 4.12.b are repeated in Table 12-11 and Figure 12-9. As discussed in Section 4.12.b, the tabulated values are applicable only to samples about 2 mm thick, at the lower temperatures. Above about 800 K, however, the values are applicable to polished, high resistivity, single crystals of any thickness because of silicon's high temperature opacity. The values above 1100 K are extrapolated. The uncertainties of the tabulated values were discussed in Section 4.12.b.

TABLE 12-11. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)
 [WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

T	α	SINGLE CRYSTAL 2 MM THICK		SINGLE CRYSTAL 2 MM THICK		SINGLE CRYSTAL 2 MM THICK		SINGLE CRYSTAL $\lambda = 10.6$	
		$\lambda = 2.8$	$\lambda = 3.0$	$\lambda = 5.0$	$\lambda = 5.0$	$\lambda = 10.6$	$\lambda = 10.6$	$\lambda = 10.6$	$\lambda = 10.6$
300.	0.3288†	330.	0.6128†	300.	0.0111†	300.	0.265		
350.	0.0328	350.	0.0178	350.	0.0159	325.	0.280		
400.	0.0378	400.	0.0218	400.	0.0193	350.	0.296		
425.	0.0398	425.	0.0239	425.	0.0219	375.	0.313		
450.	0.0418	450.	0.0259	450.	0.0248	400.	0.330		
475.	0.0428	475.	0.0269	475.	0.0278	425.	0.346		
500.	0.0458	500.	0.0368	500.	0.0373	450.	0.364		
520.	0.0498	520.	0.0458	520.	0.0498	475.	0.382		
540.	0.0568	540.	0.0598	540.	0.0658	500.	0.400		
560.	0.069A	560.	0.074A	560.	0.085A	525.	0.419		
580.	0.087A	580.	0.092A	580.	0.109A	550.	0.440		
600.	0.106A	600.	0.114A	600.	0.138A	575.	0.464		
620.	0.126	620.	0.138	620.	0.173	600.	0.490		
640.	0.151	640.	0.169	640.	0.217	620.	0.513		
660.	0.181	660.	0.206	660.	0.273	640.	0.536		
680.	0.213	680.	0.253	680.	0.333	660.	0.560		
700.	0.262	700.	0.314	700.	0.404	680.	0.590		
720.	0.344	720.	0.393	720.	0.490	690.	0.630		
740.	0.431	740.	0.487	740.	0.581	700.	0.652		
760.	0.499	760.	0.560	760.	0.634	710.	0.672		
780.	0.559	780.	0.610	780.	0.664	720.	0.689		
800.	0.608	800.	0.649	800.	0.685	730.	0.700		
820.	0.647	820.	0.678	820.	0.699	740.	0.710		
840.	0.682	840.	0.698	840.	0.709	750.	0.714		
860.	0.705	860.	0.711	860.	0.715	800.	0.716		
880.	0.712	880.	0.714	880.	0.716	850.	0.716		
900.	0.712	900.	0.714	900.	0.716	900.	0.716		
950.	0.712	950.	0.714	950.	0.716	950.	0.716		
1000.	0.712	1000.	0.714	1000.	0.716	1000.	0.716		
1050.	0.712	1050.	0.714	1050.	0.716	1050.	0.716		
1075.	0.712	1075.	0.714	1075.	0.716	1075.	0.716		
1400.	0.712A	1400.	0.714A	1400.	0.716A	1400.	0.716A		
1600.	0.712A	1600.	0.714A	1600.	0.716A	1600.	0.716A		

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL AND BY A "9" IS TYPICAL.




FIGURE 12-9. RECOMMENDED NORMAL SPECTRAL ABSORBTANCE OF HIGH-RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)

f. Normal Spectral Transmittance (Wavelength Dependence)

Thirty-one experimental data sets for the wavelength dependence of the normal spectral transmittance of silicon covering the temperature range 20-673 K are shown in Table 12-14 and Figure 12-11. Of the 31 data sets, 27 sets are for specimens of relatively high purity.

The recommended values for 330 K shown in Table 12-12 and Figure 12-10 were calculated from the recommended values for the normal spectral emittance at 330 K by use of the McMahon [T20468] relations (Eq. 2.6-10 to 2.6-12). Equation 2.6-12 for the normal spectral emittance, ϵ , can be rearranged to yield

$$ad = \ln \left(\frac{1 - R - R\epsilon}{1 - \epsilon - R} \right) \quad (4.12-1)$$

where a is the absorption coefficient, d is the thickness, and R is the single surface reflectance of a plane-parallel specimen. As discussed in previous sections, the single surface reflectance of silicon is 0.30 in the 2-15 μm range. Using this value, and the recommended emittance values, the product ad was calculated from Eq. 4.12-1 and used in the McMahon relation (Eq. 2.6-10) to determine the normal spectral transmittance. The recommended values are applicable to a 2 mm thick, silicon single crystal of relatively high purity and resistivity.

In the 1.5-6.5 μm wavelength range, the normal spectral emittance of a 2 mm thick sample is quite low, and the normal spectral transmittance approaches the 0.54 value predicted by the McMahon relations for negligible absorption and emission and a single surface reflectance of 0.30. It is worthwhile to note that the 0.54 value is accurate to within 15% for any specimen whose emittance is 0.13 or less. According to measurements by Stierwalt [T32537] (curves 8, 9 of Section 4.12.a), this criteria is satisfied in the 2-6.5 μm range by specimens as thick as 13 mm, so the recommended values are applicable to a rather wide range of thicknesses in the 2-6.5 μm range. In the 1.5-6.5 μm range, the recommended values agree to within $\pm 5\%$ with the data of Labaw, et al. [T27345] (curve 7) for a 6.4 mm thick specimen; Cox, et al. [T46843] (curve 9) for a 1.5 mm specimen; Kraushaar [T10703] (curve 11) for a 4.16 mm specimen; Fray, et al. [T41607] (curves 15, 16); Sherman and Coleman [T64446] (curve 28); and Vasilev, et al. [T49418] (curve 30). They agree to within $\pm 10\%$ with the data of Gillespie, et al. [T20810] (curves 2, 3) for a 2.79 mm thick specimen; Kraushaar [T10703] (curve 10) for a 0.66 mm specimen; DeWaard and Weiner [T36371] (curve 19) for an 11 mm specimen; Meyer [E58966] (curve 29); and Beam, et al. [T28949] (curve 31). The uncertainty of the 330 K recommended values is believed to be within $\pm 10\%$ in the 1.5-6.5 μm wavelength range.

In the 6.5-15 μm range, absorption is no longer negligible, and the transmittance depends more strongly on the thickness of the specimen. In this region, the data of Gillespie, et al. [T20810] (curve 2) for a 2.79 mm thick specimen agrees with the recommended values to within $\pm 10\%$, as does the data of Salzberg and Villa [E3900] (curve 32). The uncertainties of the 330 K recommended values should be within $\pm 15\%$ in the 6.5-15 μm range. As mentioned previously, the values reported in the 9 μm region should be considered typical only because of large differences in the amount of oxygen occluded in the process of growing single crystals by different techniques.

TABLE 12-12. RECOMMENDED NOMINAL SPECTRAL TRANSMITTANCE OF HIGH RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T ; K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ
SINGLE CRYSTAL 2.0 MM THICK $T = 330$	0.008†	SINGLE CRYSTAL 2.0 MM THICK $T = 330$ (CONT.)	0.20	SINGLE CRYSTAL 2.0 MM THICK $T = 330$ (CONT.)	0.470	SINGLE CRYSTAL 2.0 MM THICK $T = 330$ (CONT.)	0.267
1.00	0.008†	1.10	0.30	1.20	0.464	1.30	0.252
1.20	0.3348	1.30	0.40	1.40	0.442	1.50	0.262
1.30	0.523	1.40	0.50	1.50	0.420	1.60	0.269
1.40	0.527	1.50	0.63	1.60	0.3918†	1.70	0.267
1.50	0.529	1.60	0.70	1.70	0.3498	1.80	0.257
1.60	0.533	1.70	0.80	1.80	0.2863	1.90	0.247
1.70	0.531	1.80	0.90	1.90	0.2339	2.00	0.239
1.80	0.531	1.90	0.90	2.00	0.2039	2.10	0.234
1.90	0.531	2.00	0.90	2.10	0.2059	2.20	0.229
2.00	0.532	2.10	0.90	2.20	0.2448	2.30	0.226
2.20	0.532	2.30	0.90	2.40	0.3209	2.50	0.220
2.40	0.533	2.50	0.90	2.60	0.4139	2.70	0.213
2.60	0.533	2.70	0.90	2.80	0.429	2.90	0.205
2.80	0.531	2.90	0.90	3.00	0.434	3.10	0.195
3.00	0.533	3.10	0.90	3.20	0.426	3.30	0.198
3.20	0.533	3.30	0.90	3.40	0.412	3.50	0.224
4.00	0.533	4.10	0.90	4.20	0.398	4.30	0.249
5.00	0.532	5.10	0.90	5.20	0.381	5.30	0.265
5.50	0.530	5.60	0.90	5.70	0.363	5.80	0.327
5.85	0.523	5.90	0.90	6.00	0.346	6.10	14.00
6.00	0.524	6.10	0.90	6.20	0.331		
6.20	0.525	6.30	0.90	6.40	0.326		
6.40	0.523	6.50	0.90	6.60	0.330		
6.60	0.514	6.70	0.90	6.80	0.328		
6.80	0.484	6.90	0.90	7.00	0.313		
7.00	0.470	7.10	0.90	7.20	0.298		
7.20	0.465	7.30	0.90	7.40	0.280		
7.40	0.470	7.50	0.90	7.60	0.264		
7.60	0.462	7.70	0.90	7.80	0.252		
7.80	0.473	7.90	0.90	8.00	0.247		
8.00	0.473	8.10	0.90	8.20	0.247		
8.20	0.453	8.30	0.90	8.40	0.253		
8.40	0.458	8.50	0.90	8.60	0.266		
8.60	0.464	8.70	0.90	8.80	0.279		
8.80	0.471	8.90	0.90	9.00	0.292		
9.00	0.473	9.10	0.90	9.20	0.298		
9.20		9.30	0.90	9.40	0.298		
9.40		9.50	0.90	9.60	0.284		

† VALUE FOLLOWED BY A "9" IS TYPICAL.




FIGURE 12-10. RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF HIGH-RESISTIVITY SILICON (WAVELENGTH DEPENDENCE)




FIGURE 12-11. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON OF VARIED PURITY (WAVELENGTH DEPENDENCE).

TABLE 12-13. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T33154	Lord, R.C.	1952	12-40	293		2 mm thick; optically polished; uncorrected for reflection losses; measurement temperature not stated explicitly; assumed to be 293 K.
2 T20810	Gillespie, D.T., Olsen, A.L., and Nichols, L.W.	1964	1-12	298	N-type single crystal; 6 ppb boron and 20 ppb phosphorous; resistivity 5 ohm-cm; diameter by 0.110 in.; thickness tolerance of ± 0.0001 in.; provided with flatness tolerance of ± 0.0001 in.; measured using Perkin-Elmer Model 21 spectrophotometer; not corrected for reflection losses; data extracted from smoothed curve.	
3 T20810	Gillespie, D.T., et al.	1964	1-12	373	The above specimen measured at 100 C; edge of sample disk about 1 C hotter than the center.	
4 T20810	Gillespie, D.T., et al.	1964	1-12	473	The above specimen measured at 200 C.	
5 T20810	Gillespie, D.T., et al.	1964	1.3-12	573	The above specimen measured at 300 C.	
6 T20510	Gillespie, D.T., et al.	1964	1.3-12	673	The above specimen measured at 400 C; edge of sample disk about 6 C hotter than the center.	
7 T27345	Labaw, K.B., Olsen, A.L., and Nichols, L.W.	1963	2-15	293	Single crystal; approx. 6 ppb boron and 20 ppb phosphorous; disk about 0.25 in. thick and 1 in. diameter; crystal supplied by Knipac Electro-Physics, Inc. and prepared by John H. Ransom Laboratories; faces pols' d optically flat within 5 green mercury fringes; plane parallel, with wedge angle of 0.00028 radians; measurement temperature not stated explicitly, assumed to be 293 K; data presented in figure.	
8 T30100	McCarthy, U.E.	1963	2-50	293	1 cm thick; both surfaces ground and polished to flatness of one fringe; measured with Beckman IR-5A in 2-16 μm range; measurement temperature not stated explicitly, assumed to be 293 K; data extracted from smooth curve.	
9 T46843	Cox, J.T., Jass, G., and Jacobus, G.F.	1961	1-14	293	High purity plate of 1.5 mm thickness; measured at room temperature; data extracted from smooth curve.	
10 T10703	Kraushaar, R.	1958	1-15	293	Single crystal; 0.66 mm thick; data extracted from smooth curve; measurement temperature not stated explicitly, assumed to be 293 K.	
11 T10703	Kraushaar, R.	1958	1-8.5	298	Single crystal silicon; 4.16 mm thick; data extracted from smooth curve.	
12 T10703	Kraushaar, R.	1958	1-8.5	573	The above specimen measured at 300 C.	
13 T10703	Kraushaar, R.	1958	1-8.5	623	The above specimen measured at 350 C.	
14 T10702	Kraushaar, R.	1958	1-8.3	673	The above specimen measured at 400 C.	
15 T1697	Frey, S.J., Goorwin, A.R., and Johnson, F.A., and Quarrington, J.E.	1963	1.886, 2.119	293	Pure, plane parallel specimen; absorption negligible; $\tau + \rho = 0.99$; optical constants calculated; precision better than 1% each point represents separate measurement.	
16 T1607	Frey, S.J., et al.	1963	1.886, 2.119	293	Values calculated from known refractive index data.	
17 T36371	DeWaard, R. and Weiner, S.	1967	5-35	293	Uncalibrated, high purity; 1 mm thick.	
18 T36371	DeWaard, R. and Weiner, S.	1967	5-35	293	Uncalibrated, high purity; 5 mm thick.	

TABLE 12-13. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
19 T36371	DeWard, R. and Weiner, S.	1967	5-35	293	Uncoated, high purity; 11 mm thick.	
20 T35846	Linstead, G. F.	1965	1-15	50	1.02 mm thick and 1.27 cm in diameter; Perkin-Elmer Model 221 spectrophotometer with NaCl optics used; measurement temperature is approximate.	
21 T71403	Morgan, H. T.	1972	1-14	20	Sample L-1 Be doped, p-type, single crystal specimen from Langley Research Center, NASA; resistivity 0.46 $\Omega\text{-cm}$; 0.5 to 4 mm thick and 2.2 to 2.6 cm in diameter; plane-parallel and polished to mirror finish using yellow rouge compound; measured with dual beam Perkin-Elmer Model 13 spectrometer; measurement temperature approximate.	
22 T71403	Morgan, H. T.	1972	1.2-14.2	20	Similar to the above specimen but with a resistivity of 0.35 $\Omega\text{-cm}$.	
23 T71403	Morgan, H. T.	1972	1.2-14.2	20	Similar to the above specimen but with a resistivity of 0.40 $\Omega\text{-cm}$.	
24 T71403	Morgan, H. T.	1972	1-15	290	Single crystal, slightly p-type; resistivity 10, 6.0 $\Omega\text{-cm}$; 0.5 to 4 mm thick and 2.2 to 2.6 cm in diameter; boule produced by float zone technique obtained from Monturito Co.; plane parallel and polished to mirror finish with yellow rouge compound; measured with dual beam Perkin-Elmer Model 13 spectrometer; measurement temperature approximate.	
25 T71402	Morgan, H. T.	1972	2-32	290	Similar to the above specimen but p-type with a resistivity of 500 $\Omega\text{-cm}$.	
26 T23974	Cox, J. J.	1961	2-6	293	Uncoated silicon plate.	
27 T23974	Cox, J. J.	1961	2-6	293	Silicon plate vacuum coated with $\text{MgF}_2 + \text{ZnS}$ on both sides with the ZnS layer on the outside.	
28 T64446	Sherman, G. H. and Coleman, P.D.	1971	2.5-50	293	Optically polished specimen 10 mil thick; resistivity 3 $\Omega\text{-cm}$; Beckman IR-12 spectrometer in double beam mode used; measurement temperature not stated explicitly, assumed to be 295 K.	
29 E58966	Meyer, M.D.	1965	1-14	293	n-type, undeformed, annealed specimen; 1 $\Omega\text{-cm}$ resistivity; optically polished and plane parallel; measured in air at room temperature using Beckman IR-IV spectrophotometer.	
30 T49418	Vasilev, A.M., Golovner, T.M., Landman, A.P., and Litserko, N.S.	1967		293	Undoped, disc specimen cut from rod with free carrier concentration of 10^{14} cm^{-3} ; polished on both sides; measured with an 1KS-14 spectrometer; measurement temperature not stated explicitly, assumed to be 293 K.	
31 T25949	Beam, K.E., Fahrig, R.H., Mccaff, W.E., Powderly, J.E., and Roderique, J.S.	1962	2.5-15	293	Uncoated silicon; measurement temperature not stated explicitly, assumed to be 293 K.	

TABLE 12-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	
CURVE 1 $T = 293.$		1.14	0.38	10.61	0.310	8.45	0.414	1.41	0.468	10.55	0.254									
12.5	0.25	1.25	0.463	11.7	0.293	8.62	0.380	1.54	0.475	10.79	0.254									
12.8	0.22	1.28	0.472	11.05	0.271	8.72	0.359	2.01	0.490	10.98	0.236									
13.2	0.19	1.35	0.479	11.18	0.259	8.82	0.321	2.98	0.497	11.17	0.204									
13.5	0.16	1.59	0.487	11.49	0.256	8.87	0.283	3.97	0.505	11.48	0.193									
13.6	0.19	1.98	0.495	11.56	0.261	8.91	0.205	4.99	0.502	11.64	0.193									
13.9	0.25	3.71	0.504	11.67	0.289	8.98	0.129	5.99	0.494	11.75	0.203									
14.3	0.36	4.35	0.504	12.0	0.314	9.04	0.121	6.63	0.494	12.03	0.214									
14.7	0.32	6.61	0.502			9.13	0.135	6.73	0.468											
15.2	0.30	6.69	0.492			9.21	0.204	6.85	0.474											
15.6	0.27	6.78	0.463			9.27	0.261	6.92	0.400											
16.1	0.05	6.90	0.473			9.32	0.302	6.96	0.394											
16.4	0.03	6.96	0.433			9.62	0.349	7.00	0.394											
16.7	0.05	7.12	0.467			9.44	0.374	7.07	0.405											
17.2	0.18	7.47	0.447			9.57	0.387	7.16	0.414											
17.9	-1.17	7.58	0.439			9.66	0.393	7.53	0.414											
18.5	0.20	7.67	0.431			9.80	0.393	7.62	0.399											
19.2	0.29	7.80	0.430			9.90	0.387	7.67	0.387											
19.4	0.24	7.97	0.447			10.00	0.369	7.77	0.377											
20.0	0.25	8.14	0.454			10.20	0.339	7.84	0.377											
20.6	0.28	8.25	0.454			10.59	0.295	7.96	0.393											
21.7	0.37	8.39	0.446			10.71	0.295	8.16	0.412											
22.7	0.36	8.55	0.424			10.80	0.287	8.31	0.412											
23.8	0.36	8.69	0.398			10.98	0.256	8.40	0.397											
25.6	0.36	8.75	0.372			11.10	0.235	8.75	0.326											
26.3	0.37	9.03	0.165			11.22	0.223	8.88	0.277											
27.6	0.37	9.08	0.161			11.50	0.223	9.00	0.173											
29.4	0.37	9.16	0.203			11.60	0.229	9.09	0.135											
31.3	0.37	9.24	0.304			5.81	0.450	11.68	0.240											
33.3	0.38	9.28	0.341			6.85	0.434	11.76	0.252											
34.5	0.39	9.33	0.371			6.88	0.415	12.00	0.264											
35.7	0.39	9.38	0.392			6.95	0.410	9.43	0.271											
37.0	0.37	9.47	0.405			7.10	0.432	9.48	0.303											
38.5	0.36	9.56	0.421			7.49	0.432	9.55	0.327											
		9.77	0.421			7.60	0.421	9.63	0.340											
CURVE 2 $T = 298.$		9.89	0.409			7.69	0.412	9.73	0.347											
1.09	0.000	10.27	0.335			7.97	0.428	10.37	0.327											
1.13	0.010	10.49	0.325			8.10	0.439	10.21	0.295											
		10.03	0.365			8.32	0.436	1.36	0.456											

CURVE 5.
 $T = 573.$ CURVE 4.
 $T = 473.$

TABLE 12-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	τ	CURVE 5(CONT.)	λ	τ	CURVE 6(CONT.)	λ	τ	CURVE 7(CONT.)	λ	τ	CURVE 7(CONT.)	λ	τ	CURVE 8(CONT.)	λ	τ	CURVE 9 $T = 293.$
7.09	0.297	2.55	0.344	5.63	0.543	11.24	0.147	8.2	0.335	0.67	0.000	1.30	0.166	41.0	0.166	10.41	0.438
8.02	0.337	2.73	0.338	7.67	0.543	11.48	0.144	6.6	0.373	0.77	0.025	0.34	0.132	43.7	0.132	10.65	0.423
8.17	0.320	3.34	0.317	5.31	0.549	11.57	0.151	6.6	0.000	1.07	0.497	0.52	0.102	45.1	0.102	11.25	0.383
8.37	0.320	3.49	0.294	5.92	0.555	11.68	0.171	9.2	0.000	1.33	0.525	0.54	0.097	47.3	0.097	11.59	0.423
8.62	0.269	3.84	0.281	6.64	0.555	11.78	0.199	9.2	0.271	1.22	0.525	0.57	0.063	50.0	0.063	12.02	0.423
8.76	0.242	4.21	0.268	6.78	0.488	11.91	0.208	9.6	0.268	1.33	0.537	0.61	0.282	51.5	0.282	12.15	0.423
8.88	0.215	4.43	0.248	6.95	0.402	12.04	0.209	10.0	0.273	1.60	0.548	0.65	0.282	52.7	0.282	12.37	0.398
9.03	0.141	4.62	0.239	7.14	0.446	12.16	0.176	10.2	0.171	2.56	0.550	0.71	0.282	53.9	0.282	12.69	0.414
9.10	0.115	4.88	0.223	7.24	0.446	12.22	0.164	10.3	0.125	6.62	0.550	0.78	0.282	55.0	0.282	12.93	0.414
9.19	0.397	5.33	0.206	7.63	0.419	12.37	0.164	10.5	0.075	6.78	0.539	0.83	0.282	56.1	0.282	13.15	0.414
9.27	0.097	5.99	0.172	7.71	0.407	12.49	0.189	11.1	0.059	6.95	0.509	0.91	0.282	57.2	0.282	13.37	0.414
9.33	0.114	6.35	0.156	7.79	0.407	12.57	0.189	11.6	0.106	7.12	0.522	1.01	0.282	58.3	0.282	13.57	0.414
9.42	0.154	6.57	0.153	7.98	0.446	12.72	0.171	12.2	0.054	7.23	0.526	1.18	0.282	59.4	0.282	13.77	0.414
9.53	0.206	6.78	0.136	8.10	0.454	13.00	0.164	12.6	0.054	7.44	0.526	1.35	0.282	60.5	0.282	13.97	0.414
9.60	0.229	6.97	0.111	8.27	0.454	13.27	0.153	13.0	0.074	7.66	0.510	1.52	0.282	61.6	0.282	14.17	0.414
9.72	0.242	7.14	0.100	8.35	0.449	13.43	0.136	13.6	0.056	7.88	0.510	1.71	0.282	62.7	0.282	14.37	0.414
9.81	0.246	7.55	0.094	9.45	0.409	13.57	0.112	14.0	0.163	8.12	0.522	1.90	0.282	63.8	0.282	14.57	0.414
9.98	0.247	7.97	0.078	9.64	0.364	13.72	0.112	14.5	0.182	8.29	0.522	2.09	0.282	64.9	0.282	14.77	0.414
10.32	0.204	8.59	0.072	9.72	0.345	13.85	0.127	15.3	0.156	8.51	0.514	2.38	0.282	66.0	0.282	14.97	0.414
10.48	0.187	8.99	0.044	9.79	0.310	13.91	0.142	15.7	0.073	6.70	0.496	2.57	0.282	67.1	0.282	15.17	0.414
10.63	0.176	9.24	0.026	8.86	0.203	13.97	0.161	16.4	0.038	8.86	0.470	2.76	0.282	68.2	0.282	15.37	0.414
10.92	0.171	9.99	0.041	9.98	0.077	14.03	0.194	17.1	0.057	8.97	0.438	2.95	0.282	69.3	0.282	15.57	0.414
11.04	0.162	10.10	0.036	9.06	0.063	14.09	0.242	17.7	0.057	9.04	0.399	3.14	0.282	70.4	0.282	15.77	0.414
11.20	0.137	10.25	0.036	9.16	0.080	14.14	0.270	18.3	0.079	9.14	0.364	3.33	0.282	71.5	0.282	15.97	0.400
11.51	0.121	10.49	0.031	9.31	0.257	14.20	0.292	19.0	0.057	9.26	0.400	3.52	0.282	72.6	0.282	16.17	0.414
11.69	0.121	10.85	0.031	9.36	0.313	14.29	0.304	21.2	0.136	9.31	0.442	3.71	0.282	73.7	0.282	16.37	0.414
12.03	0.129	11.98	0.025	9.40	0.344	14.46	0.304	22.6	0.161	9.36	0.468	3.90	0.282	74.8	0.282	16.57	0.414
12.00	0.130	11.52	0.022	9.47	0.363	14.60	0.289	23.7	0.07	9.47	0.489	4.09	0.282	75.9	0.282	16.77	0.414
12.00	0.130	12.00	0.021	9.51	0.378	14.72	0.283	26.0	0.230	9.62	0.496	4.28	0.282	77.0	0.282	16.97	0.414
CURVE 6 $T = 673.$		CURVE 7 $T = 293.$		9.56	0.386	15.00	0.283	33.9	0.230	9.83	0.496	4.47	0.282	78.1	0.282	17.17	0.414
1.30	0.000	9.71	0.366	9.62	0.373	36.5	0.209	10.13	0.475	10.41	0.438	4.66	0.282	79.2	0.282	17.37	0.414
1.34	0.019	2.00	0.542	10.30	0.326	41.0	0.166	10.65	0.423	10.65	0.423	4.85	0.282	80.3	0.282	17.57	0.414
1.43	0.367	2.52	0.547	10.17	0.271	43.7	0.132	10.86	0.423	10.86	0.423	5.04	0.282	81.4	0.282	17.77	0.414
1.46	0.368	2.56	0.554	10.33	0.227	45.1	0.102	11.06	0.423	11.06	0.423	5.23	0.282	82.5	0.282	17.97	0.414
1.52	0.395	2.67	0.554	10.45	0.223	47.3	0.087	11.59	0.423	11.59	0.423	5.42	0.282	83.6	0.282	18.17	0.414
1.78	0.395	2.75	0.548	10.74	0.223	49.1	0.411	12.02	0.423	12.02	0.423	5.61	0.282	84.7	0.282	18.37	0.414
1.85	0.382	4.39	0.559	10.93	0.211	49.5	0.359	12.15	0.423	12.15	0.423	5.80	0.282	85.8	0.282	18.57	0.414
2.05	0.382	5.76	0.562	11.06	0.162	51.6	0.282	12.69	0.414	12.69	0.414	6.00	0.282	86.9	0.282	18.77	0.414

TABLE 12-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 9 (CONT.)	CURVE 10 (CONT.)	CURVE 11 (CONT.)	CURVE 12 (CONT.)	CURVE 13 (CONT.)	CURVE 14 (CONT.)
13.11	0.450	9.96	0.526	9.43	0.483	5.50	0.343
13.42	0.371	10.00	0.520	10.50	0.462	5.63	0.320
13.64	0.355	10.40	0.507	10.74	0.517	5.83	0.302
13.85	0.372	10.50	0.509	10.87	0.510	6.00	0.286
13.98	0.398	10.77	0.509	10.00	0.531	6.11	0.274
14.13	0.430	11.50	0.492	11.17	0.543	6.34	0.253
14.29	0.449	11.15	0.493	11.19	0.543	6.50	0.237
14.39	0.459	11.34	0.483	11.50	0.538	6.61	0.172
14.55	0.470	11.50	0.492	11.63	0.512	6.70	0.147
CURVE 10		11.76	1.513	11.79	1.447	6.78	0.134
$T = 293.$		12.00	1.487	12.06	1.426	6.87	0.119
1.00	0.016	12.44	0.487	12.47	0.437	6.92	0.119
1.00	0.447	12.50	0.487	12.51	0.455	7.00	0.119
1.07	0.513	13.00	0.476	13.50	0.466	7.22	0.119
1.17	0.539	13.72	0.473	13.76	0.431	7.59	0.119
1.50	0.554	14.00	0.509	14.07	0.440	7.69	0.119
2.00	0.360	14.12	0.520	14.00	0.459	7.79	0.119
2.34	0.572	14.50	0.512	14.18	0.474	8.00	0.119
2.50	0.572	14.76	0.516	14.32	0.468	8.29	0.119
3.00	0.572	15.00	0.507	14.38	0.454	8.33	0.119
3.50	0.567			14.50	0.416	8.41	0.119
4.00	0.564			15.00	0.267	8.50	0.119
4.50	0.559					8.50	0.119
5.00	0.555	1.06	0.000	5.73.		8.50	0.119
6.00	0.555	1.10	0.025			8.50	0.119
6.50	0.558	1.19	0.462			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	5.73.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	6.23.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	6.73.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	7.23.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	7.73.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	8.23.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	8.73.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119
5.00	0.555	1.14	0.000	9.23.		8.50	0.119
6.00	0.555	1.19	0.028			8.50	0.119
6.50	0.558	1.21	0.372			8.50	0.119
7.00	0.552	1.21	0.498			8.50	0.119
7.50	0.550	1.27	0.520			8.50	0.119
8.00	0.540	1.32	0.531			8.50	0.119
8.26	0.534	1.50	0.536			8.50	0.119
8.50	0.530	2.00	0.536			8.50	0.119
8.75	0.509	2.50	0.536			8.50	0.119
8.87	0.481	3.00	0.533			8.50	0.119
9.00	0.406	3.50	0.532			8.50	0.119
9.24	0.453	4.00	0.536			8.50	0.119
9.50	0.497	4.50	0.543			8.50	0.119
9.63	0.526	5.00	0.542			8.50	0.119

TABLE 12-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELLENGTH DEPENDENCE) (CONTINUED)

TABLE 12-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	τ	CURVE 22(CONT.)	CURVE 22(CONT.)	CURVE 22(CONT.)	CURVE 23	CURVE 23 (CONT.)	CURVE 23 (CONT.)	CURVE 24 (CONT.)
1.05	0.000	9.63	0.172	11.61	0.231	9.55	0.236	6.92
2.02	0.009	6.91	0.167	11.64	0.235	9.60	0.210	7.04
2.28	0.000	6.96	0.167	11.72	0.241	6.14	0.210	6.437
2.51	0.033	9.36	0.146	11.81	0.241	6.29	0.210	6.437
2.75	0.000	9.13	0.156	11.87	0.253	6.39	0.251	6.04
3.01	0.000	9.16	0.169	11.93	0.253	6.60	0.216	6.443
3.30	0.000	9.23	0.183	11.98	0.247	6.72	0.021	6.72
3.50	0.003	9.28	0.190	12.03	0.241	6.90	0.033	6.91
3.77	0.000	9.33	0.146	12.06	0.236	6.93	0.018	10.02
4.02	0.000	9.37	0.125	12.20	0.232	7.00	0.061	10.02
4.28	0.000	9.44	0.167	12.28	0.236	7.05	0.053	10.26
4.52	0.000	9.46	0.211	12.33	0.236	7.14	0.085	10.30
4.74	0.000	9.51	0.232	12.41	0.246	7.25	0.106	10.38
5.02	0.000	9.59	0.211	12.47	0.251	7.37	0.111	10.01
5.28	0.000	9.65	0.236	12.52	0.246	7.52	0.121	10.16
5.51	0.000	9.72	0.242	12.55	0.242	7.62	0.126	10.31
5.76	0.000	9.80	0.241	12.64	0.242	7.74	0.134	10.75
5.99	0.000	9.85	0.237	12.71	0.236	7.87	0.136	10.80
6.27	0.000	9.92	0.231	12.80	0.237	7.96	0.136	10.99
6.37	0.007	10.00	0.231	12.90	0.237	8.10	0.146	11.16
6.51	0.012	10.08	0.231	12.94	0.237	8.23	0.155	11.25
6.69	0.000	10.16	0.226	13.01	0.241	8.32	0.160	11.33
6.82	0.029	10.21	0.222	13.09	0.242	8.40	0.165	11.59
7.00	0.063	10.33	0.222	13.17	0.242	8.55	0.170	11.79
7.10	0.058	10.38	0.226	13.25	0.241	8.65	0.170	11.87
7.13	0.196	10.44	0.232	13.32	0.237	8.76	0.170	12.10
7.25	0.108	10.52	0.232	13.37	0.233	8.85	0.176	12.21
7.38	0.116	10.60	0.232	13.46	0.223	8.91	0.162	12.41
7.50	0.124	10.68	0.227	13.51	0.216	8.99	0.166	12.57
7.62	0.129	10.76	0.227	13.56	0.216	9.03	0.168	12.72
7.73	0.133	10.81	0.222	13.61	0.221	9.06	0.134	12.83
7.87	0.139	10.89	0.216	13.71	0.225	9.11	0.146	13.48
8.00	0.145	10.97	0.216	13.76	0.231	9.14	0.176	14.05
8.11	0.150	11.07	0.216	13.88	0.236	9.20	0.196	13.79
8.23	0.155	11.11	0.211	13.94	0.242	9.24	0.180	13.91
8.33	0.159	11.20	0.216	13.96	0.248	9.30	0.195	6.02
8.43	0.166	11.25	0.222	14.00	0.257	9.32	0.167	6.18
8.55	0.166	11.33	0.222	14.07	0.265	9.36	0.112	6.55
8.67	0.172	11.44	0.222	14.16	0.265	9.42	0.157	6.73
8.72	0.172	11.50	0.226	9.46	0.216	9.48	0.216	6.81

CURVE 24.

 $T = 290^\circ$.

TABLE 12-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VARIED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 12-14. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF VAPED PURITY SILICON (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μ ; TEMPERATURE, T ; K; TRANSMITTANCE, τ)

λ	τ	CURVE 29(CONT.)	λ	τ	CURVE 31(CONT.)									
11.03	0.155	3.10	0.506	6.67	0.566	9.86	0.512	14.59	0.453					
11.13	0.147	3.14	0.527	6.69	0.536	9.99	0.485	14.66	0.467					
11.36	0.147	3.20	0.521	6.74	0.549	10.14	0.485	14.81	0.462					
11.50	0.154	3.26	0.543	6.80	0.545	10.14	0.457	14.89	0.478					
11.79	0.205	3.27	0.528	6.81	0.530	10.38	0.456	14.99	0.467					
11.92	0.209	3.54	0.532	7.00	0.523	10.47	0.478	15.00	0.464					
12.04	0.191	3.61	0.526	7.09	0.541	10.45	0.457							
12.17	0.152	3.65	0.551	7.13	0.522	10.50	0.475							
12.26	0.152	3.69	0.535	7.20	0.547	10.50	0.457							
12.48	0.192	3.72	0.548	7.52	0.547	10.79	0.457							
12.60	0.155	3.76	0.527	7.57	0.527	10.79	0.429							
13.15	0.130	3.83	0.545	7.67	0.527	10.88	0.437							
13.38	0.106	3.87	0.526	7.74	0.549	11.12	0.398							
13.51	0.064	3.95	0.551	7.78	0.536	11.19	0.416							
13.64	0.091	4.00	0.541	7.89	0.541	11.24	0.400							
13.83	0.115	4.18	0.541	7.97	0.552	11.35	0.419							
14.00	0.141	4.25	0.556	8.17	0.535	11.43	0.419							
		4.28	0.541	8.20	0.508	11.60	0.436							
		4.33	0.541	8.29	0.533	11.60	0.455							
		4.39	0.554	8.47	0.506	11.99	0.455							
		4.48	0.537	8.57	0.517	12.06	0.419							
		4.56	0.563	8.63	0.506	12.12	0.418							
		4.62	0.556	8.72	0.508	12.16	0.437							
		5.16	0.556	8.72	0.492	12.16	0.406							
		5.21	0.570	8.78	0.492	12.24	0.437							
		5.24	0.552	8.82	0.476	12.24	0.416							
		5.42	0.564	8.95	0.497	12.47	0.456							
		5.51	0.554	9.00	0.476	12.47	0.433							
		5.58	0.574	9.19	0.521	12.83	0.426							
		5.70	0.560	9.31	0.511	12.88	0.407							
		5.80	0.554	9.44	0.540	13.09	0.407							
		5.88	0.567	9.44	0.523	13.17	0.417							
		5.96	0.564	9.50	0.523	13.55	0.359							
		6.13	0.564	9.60	0.535	13.69	0.397							
		6.20	0.575	9.62	0.506	13.71	0.374							
		6.30	0.553	9.62	0.521	13.77	0.403							
		6.34	0.562	9.69	0.532	14.00	0.444							
		6.43	0.567	9.74	0.522	14.15	0.484							
		6.49	0.553	9.74	0.499	14.30	0.488							
		6.61	0.574	9.81	0.499	14.57	0.469							

CURVE 31
T = 293°

g. Normal Spectral Transmittance (Temperature Dependence)

The available experimental data for the temperature dependence of the normal spectral transmittance of silicon are shown in Table 12-17 and Figure 12-13. Only Gillespie, et al. [T20810] (curves 1-4) and Kraushaar [T10703] (curves 5-7) have reported the normal spectral transmittance above room temperature. The data of these curves were obtained by reading points from the spectral curves of Section 12.4.f at selected wavelengths of 2.8, 3.8, 5.0, and 10.6 μm .

In the 300-700 K temperature range, the recommended values shown in Table 12-15 and Figure 12-12 were calculated from the recommended values for the normal spectral emittance given in Section 4.12.b by use of Eq. 4.12-1 and the McMahon relation (Eq. 2.6-10), in a manner similar to that described in the preceding section. Refractive index and absorption coefficient measurements indicate that the single surface reflectance does not vary greatly with temperature, and the room temperature value of 0.30 was assumed to hold at higher temperatures. The recommended values are subject to the same restrictions as discussed in Section 4.12.b; they apply only to polished, plane-parallel, relatively pure single crystals which are about 2 mm thick.

Both the experimental data and the calculations from emittance data show that the transmittance of relatively pure silicon drops rapidly toward zero above about 600 K, for the wavelengths of interest. Above about 800 K, the 2 mm thick specimens are completely opaque. This rapid drop in transmittance with increasing temperature is the result of the thermal excitation of electrons to the conduction band, with consequent absorption due to free carriers. The experimental data exhibit a sharper drop to zero transmittance than do the calculations from emittance recommendations. The more rapid drop of the experimental data was followed in generating recommended values in the 600-800 K range.

In the 300-600 K temperature range, the uncertainty of the recommended values is believed to lie within $\pm 15\%$. At greater temperatures, the high slope of the curves as the transmittance drops rapidly to zero results in larger uncertainties.

Above 600 K, the general trend of the transmittance to zero can be accepted without reservation, but the tabulated values should be considered typical only.

TABLE 12-15. RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, T)

T	T	T	T	T	T	T	T	T	T
SINGLE CRYSTAL 2 MM THICK $\lambda = 10.6$									
SINGLE CRYSTAL 2 MM THICK $\lambda = 5.0$									
300..	0.359	300..	0.531	300..	0.531	300..	0.531	300..	0.520
350..	0.337	350..	0.529	350..	0.527	350..	0.518	350..	0.518
400..	0.312	400..	0.526	400..	0.525	400..	0.514	400..	0.514
425..	0.300	425..	0.525	425..	0.524	425..	0.513	425..	0.513
450..	0.287	450..	0.523	450..	0.522	450..	0.512	450..	0.512
475..	0.273	475..	0.521	475..	0.520	475..	0.511	475..	0.511
500..	0.260	500..	0.514	500..	0.515	500..	0.509	500..	0.509
525..	0.245	520..	0.507	520..	0.509	520..	0.507	520..	0.507
550..	0.229	540..	0.496	540..	0.500	540..	0.502	540..	0.502
575..	0.210	560..	0.483	560..	0.490	560..	0.493	560..	0.493
600..	0.189	580..	0.467	580..	0.476	580..	0.482	580..	0.482
625..	0.170	600..	0.447	600..	0.464	600..	0.469	600..	0.469
640..	0.149	620..	0.424	620..	0.447	620..	0.456	620..	0.456
660..	0.123	640..	0.393	640..	0.426	640..	0.439	640..	0.439
680..	0.086B†	660..	0.356	660..	0.401	b60..	0.419B†	b60..	0.419B†
690..	0.0360B	680..	0.310B†	680..	0.365B†	680..	0.396B	680..	0.396B
700..	0.030B	700..	0.257B	700..	0.324B	700..	0.362B	700..	0.362B
706..	0.000B	720..	0.153B	720..	0.265B	720..	0.302B	720..	0.302B
		740..	0.000B	740..	0.150B	740..	0.236B	740..	0.236B
			0.000B	756..	0.000B	760..	0.120B	760..	0.120B
						775..	0.000B		

† VALUE FOLLOWED BY A "B" IS TYPICAL.




FIGURE 12-12. RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF HIGH-RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)




FIGURE 12-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON
(TEMPERATURE DEPENDENCE)

TABLE 12-16. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON (Temperature Dependence)¹

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T20810	Gillespie, D. T., Olsen, A. I., and Nichols, L. W.	1964	2.8	298-673			n-type single crystal; 6 ppb boron and 20 ppb phosphorous; resistivity 5 ohm-cm; disk 0.110 in. thick and 1.240 in. in diameter; parallelism tolerance of $\pm 2.5 \mu\text{m}$; polished faces; provided by Kippic Electro-Physics, Inc.; measured using Perkin- Elmer 21 spectrophotometer; not corrected for reflection losses; data extracted from spectral curves.
2 T20810	Gillespie, D. T., et al.	1964	3.8	298-673			The above specimen.
3 T20810	Gillespie, D. T., et al.	1964	5.0	298-673			The above specimen.
4 T20810	Gillespie, D. T., et al.	1964	10.6	298-673			The above specimen.
5 T10703	Kraushaar, R.	1958	2.8	293-673			Single crystal silicon; 4.16 mm thick; data extracted from spectral curves.
6 T10703	Kraushaar, R.	1958	3.8	293-673			The above specimen.
7 T10703	Kraushaar, R.	1958	5.0	293-673			The above specimen.

TABLE 12-17. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF HIGH RESISTIVITY SILICON (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

T	τ	T	τ	T	τ	T	τ
CURVE 1 $\lambda = 2.6$		CURVE 5 (CONT.)		CURVE 6 $\lambda = 3.6$			
298.	0.500	673.	0.274				
373.	0.499						
473.	0.495						
573.	0.471						
673.	0.332	298.	0.534				
CURVE 2 $\lambda = 3.6$		573.	0.498				
298.	0.503	623.	0.386				
373.	0.502	673.	0.200				
473.	0.502						
573.	0.464						
673.	0.261	298.	0.541				
CURVE 3 $\lambda = 5.0$		573.	0.467				
298.	0.503	623.	0.341				
373.	0.502	673.	0.130				
473.	0.501						
573.	0.451						
673.	0.217						
CURVE 4 $\lambda = 10.6$							
298.	0.322						
373.	0.294						
473.	0.253						
573.	0.177						
673.	0.030						
CURVE 5 $\lambda = 2.6$							
298.	0.533						
573.	0.507						
623.	0.431						

4.13. Silicon Carbide

Silicon carbide is usually fabricated by heating carbon and silica sand in an oven. The material is a bluish-black iridescent crystal with hexagonal or cubic structure. The molecular weight is 40.10. The theoretical density is 3.217 g cm^{-3} . It sublimates by decomposition at $>2400\text{ K}$. It is one of the hardest substances in existence, measuring about 9 on Mohs scale hardness. Its fiber has a tensile strength of 3,000,000 psi. The thermal conductivity of a very pure and very dense silicon carbide specimen is comparable to that of metals in the neighborhood of room temperature. The coefficient of linear thermal expansion is about $4 \times 10^{-6} \text{ K}^{-1}$. This substance is soluble in fused alkalies, but is insoluble in water or alcohol.

Silicon carbide is widely used as high refractory material. Its high purity single crystals are used as semiconductors, especially at high temperature applications. Its fibers are used as reinforcement material with plastics.

Industries manufacture various forms of silicon carbide. One of them is carborundum. Optically, carborundum crystallites in various sizes appear from transparent to opaque, and from colorless to deep blue-black. The density ranges from 3.06 to 3.20 g cm^{-3} . It oxidizes slowly above 1273 K. It is commonly used for grinding and polishing. Globar is another form of silicon carbide which is widely used as a source of infrared energy. Its working temperature is up to 1783 K, and may be extended to 1922 K for a short period of time. The coefficient of thermal expansion is low. The structure is not affected by quick heating or abrupt cooling. Its electrical resistivity remains almost constant at above 755 K. It is an excellent material for resistors and heating elements.

a. Normal Spectral Emittance (Wavelength Dependence)

A total of 23 sets of data are available. Most of them were measured in the range of about $1 \mu\text{m}$ to $15 \mu\text{m}$. Measuring temperature ranges from 755 K to 2500 K.

All the data sets show a deep minimum at about $12.6 \mu\text{m}$, and all except the data of Blau and Jasperse [T32045] (Figure 13-2, curves 3-6) have a shallow minimum at about $9.2 \mu\text{m}$. A rather small peak is located around $10.4 \mu\text{m}$. No obvious reason is conceived to account for this difference. For many data sets the values tapered off below $3 \mu\text{m}$. This behavior was probably caused by the oxidation of the specimens and by the error in matching the temperature of the specimen and the blackbody standard [T20946]. The specimen was as thin as $100 \mu\text{m}$ (Figure 13-2, curves 16-18), but the data show no apparent differences compared to that of the thick specimens.

One curve is recommended for the Globar from Carborundum Company. The curve conforms to the data of Mitchell [T25673] (Figure 13-2, curve 9), except between 2 and 6 μm , where the curve follows the shape of Silverman's data [T00758] (Figure 13-2, curve 1) corrected by Morris [T20946]. A shallow minimum around 4 μm is interpreted as caused by a slight oxidation of the specimen in normal circumstances, i.e., the specimen has never been heated in air at elevated temperature over an extended period. The values are recommended for the specimen temperature of 1400 K. Two parallel curves were generated for room temperature and 2400 K. The values at 1400 K are believed to be accurate to within 5% of the true values. For other temperatures, the same set of values are believed to have an uncertainty of 5 to 10% above 700 K, and 10 to 15% below 700 K.

One more curve is presented as provisional for a roughly polished bulk specimen. The curve follows the data of Stewart and Richman [T08277, T40798] (Figure 13-2, curves 11-14 and 19-22). Since the specimens are not well-defined, the values cannot be applied accurately to any polished specimen. The provisional values are applicable to averagely polished specimens at 1000 K, and two parallel curves were generated for room temperature and 2400 K. The uncertainty of these values may be up to 20 to 30% for some specimens.

For thin films with thickness in the order of $10^{-1} \mu\text{m}$ or thinner, they have very low emittance values between 1 and 15 μm . No recommendation is made due to lack of data.

The recommended and the provisional curves are shown in Figure 13-1 and the experimental curves are shown in Figure 13-2. The recommended values, the experimental measurement information, and the experimental data are tabulated in Tables 13-1, 13-2, and 13-3, respectively.

TABLE 13-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	GLOBAR, BULK OXIDIZED $T = 293$ (CONT.)			GLOBAR, BULK OXIDIZED $T = 1400$ (CONT.)			GLOBAR, BULK OXIDIZED $T = 2400$			GLOBAR, BULK OXIDIZED $T = 2400$ (CONT.)		
1.0	0.901	10.6	0.872	1.0	0.926	10.6	0.899	1.0	0.951	10.6	0.922		
1.2	0.898	10.8	0.869	1.2	0.925	10.8	0.896	1.2	0.946	10.8	0.919		
1.5	0.893	11.0	0.862	1.5	0.920	11.0	0.889	1.5	0.943	11.0	0.912		
1.8	0.887	11.2	0.855	1.8	0.914	11.2	0.882	1.8	0.937	11.2	0.905		
2.0	0.882	11.5	0.841	2.0	0.909	11.5	0.866	2.0	0.932	11.5	0.891		
2.2	0.876	11.8	0.826	2.2	0.903	11.8	0.853	2.2	0.926	11.8	0.876		
2.5	0.866	12.0	0.815	2.5	0.895	12.0	0.842	2.5	0.916	12.0	0.865		
2.8	0.862	12.2	0.806	2.8	0.889	12.2	0.833	2.8	0.912	12.2	0.856		
3.0	0.859	12.5	0.795	3.0	0.866	12.5	0.822	3.0	0.909	12.5	0.845		
3.2	0.856	12.6	0.793	3.2	0.863	12.6	0.820	3.2	0.906	12.6	0.843		
3.5	0.855	13.0	0.796	3.5	0.862	13.0	0.825	3.5	0.905	13.0	0.848		
3.8	0.855	13.2	0.804	3.8	0.862	13.2	0.831	3.8	0.905	13.2	0.854		
4.0	0.859	13.5	0.813	4.0	0.866	13.5	0.840	4.0	0.909	13.5	0.863		
4.2	0.863	13.8	0.821	4.2	0.870	13.6	0.848	4.2	0.913	13.6	0.871		
4.5	0.870	14.0	0.825	4.5	0.897	14.0	0.852	4.5	0.920	14.0	0.875		
4.8	0.876	14.2	0.829	4.8	0.903	14.2	0.856	4.8	0.926	14.2	0.879		
5.0	0.879	14.5	0.831	5.0	0.906	14.5	0.858	5.0	0.929	14.5	0.881		
5.2	0.881	14.8	0.833	5.2	0.908	14.8	0.860	5.2	0.931	14.8	0.883		
5.5	0.880	15.0	0.833	5.5	0.907	15.0	0.860	5.5	0.930	15.0	0.883		
5.8	0.879			5.8	0.906			5.8	0.929				
6.0	0.878			6.0	0.905			6.0	0.928				
6.2	0.877			6.2	0.904			6.2	0.927				
6.5	0.877			6.5	0.904			6.5	0.927				
6.8	0.878			6.8	0.905			6.8	0.928				
7.0	0.876			7.0	0.905			7.0	0.928				
7.2	0.875			7.2	0.905			7.2	0.928				
7.5	0.877			7.5	0.904			7.5	0.927				
7.8	0.876			7.8	0.903			7.8	0.926				
8.0	0.875			8.0	0.902			8.0	0.925				
8.2	0.873			8.2	0.900			8.2	0.923				
8.5	0.871			8.5	0.898			8.5	0.921				
8.8	0.869			8.8	0.896			8.8	0.919				
9.0	0.867			9.0	0.894			9.0	0.917				
9.2	0.865			9.2	0.892			9.2	0.915				
9.5	0.864			9.5	0.891			9.5	0.914				
9.8	0.866			9.8	0.893			9.8	0.916				
10.0	0.869			10.0	0.896			10.0	0.919				
10.2	0.871			10.2	0.898			10.2	0.921				
10.5	0.873			10.5	0.900			10.5	0.923				

TABLE 13-1. RECOMMENDED NORMAL SPECTRAL EMISSANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE, T, K; EMISSANCE, ε)

(WAVELENGTH, λ, μm; TEMPERATURE, T, K; EMISSANCE, ε)

λ	ε	BULK POLISHED T = 293				BULK POLISHED T = 1000 (CONT.)				BULK POLISHED T = 2400 (CONT.)				BULK POLISHED T = 2400 (CONT.)			
		λ	ε	λ	ε	λ	ε	λ	ε	λ	ε	λ	ε	λ	ε	λ	ε
1.0	0.597A†	10.6	0.791A†	1.0	0.614A†	10.6	0.798A†	1.0	0.647A†	10.6	0.831A†	1.0	0.663A	10.6	0.826A	10.6	0.815A
1.2	0.613A	10.8	0.776A	1.2	0.630A	10.8	0.793A	1.2	0.663A	10.8	0.826A	1.2	0.686A	11.0	0.799A	11.0	0.771A
1.5	0.636A	11.0	0.765A	1.5	0.653A	11.0	0.782A	1.5	0.686A	11.0	0.799A	1.5	0.722A	11.5	0.771A	11.5	0.743A
1.8	0.658A	11.2	0.749A	1.8	0.675A	11.2	0.766A	1.8	0.738A	11.2	0.771A	1.8	0.736A	11.8	0.771A	11.8	0.725A
2.0	0.672A	11.5	0.721A	2.0	0.685A	11.5	0.780A	2.0	0.710A	11.5	0.775A	2.0	0.755A	12.1	0.775A	12.1	0.725A
2.2	0.686A	11.8	0.693A	2.2	0.703A	11.8	0.722A	2.2	0.692A	11.8	0.775A	2.2	0.788A	12.5	0.788A	12.5	0.687A
2.5	0.705A	12.0	0.675A	2.5	0.722A	12.0	0.692A	2.5	0.674A	12.0	0.775A	2.5	0.781A	12.6	0.781A	12.6	0.688A
2.8	0.721A	12.2	0.657A	2.8	0.738A	12.2	0.674A	2.8	0.655A	12.2	0.775A	2.8	0.788A	13.0	0.788A	13.0	0.687A
3.0	0.731A	12.5	0.638A	3.0	0.748A	12.5	0.690A	3.0	0.654A	12.5	0.775A	3.0	0.798A	13.2	0.798A	13.2	0.688A
3.2	0.738A	12.6	0.637A	3.2	0.755A	12.6	0.695A	3.2	0.662A	12.6	0.775A	3.2	0.804A	13.4	0.804A	13.4	0.695A
3.5	0.748A	12.8	0.645A	3.5	0.765A	12.8	0.692A	3.5	0.679A	12.8	0.775A	3.5	0.809A	13.6	0.809A	13.6	0.712A
3.8	0.754A	13.0	0.662A	3.8	0.771A	13.0	0.679A	3.8	0.699A	13.0	0.775A	3.8	0.806A	13.8	0.806A	13.8	0.732A
4.0	0.756A	13.2	0.682A	4.0	0.773A	13.2	0.707A	4.0	0.707A	13.2	0.775A	4.0	0.808A	14.0	0.808A	14.0	0.740A
4.2	0.758A	13.3	0.690A	4.2	0.775A	13.3	0.715A	4.2	0.715A	13.3	0.775A	4.2	0.809A	14.2	0.809A	14.2	0.746A
4.5	0.759A	13.5	0.698A	4.5	0.776A	13.5	0.726A	4.5	0.726A	13.5	0.775A	4.5	0.809A	14.5	0.809A	14.5	0.750A
4.8	0.759A	13.8	0.700A	4.8	0.776A	13.8	0.736A	4.8	0.736A	13.8	0.775A	4.8	0.809A	14.8	0.809A	14.8	0.749A
5.0	0.759A	14.0	0.701A	5.0	0.776A	14.0	0.740A	5.0	0.740A	14.0	0.775A	5.0	0.809A	15.0	0.809A	15.0	0.748A
5.2	0.759A	14.2	0.701A	5.2	0.776A	14.2	0.742A	5.2	0.742A	14.2	0.775A	5.2	0.809A	15.2	0.809A	15.2	0.751A
5.5	0.758A	14.5	0.700A	5.5	0.775A	14.5	0.745A	5.5	0.745A	14.5	0.775A	5.5	0.808A	15.5	0.808A	15.5	0.750A
5.8	0.757A	14.8	0.699A	5.8	0.774A	14.8	0.748A	5.8	0.748A	14.8	0.775A	5.8	0.807A	15.8	0.807A	15.8	0.749A
6.0	0.756A	15.0	0.698A	6.0	0.773A	15.0	0.750A	6.0	0.750A	15.0	0.775A	6.0	0.806A	16.0	0.806A	16.0	0.748A
6.2	0.754A	16.2	0.704A	6.2	0.771A	16.2	0.752A	6.2	0.752A	16.2	0.775A	6.2	0.804A	16.2	0.804A	16.2	0.751A
6.5	0.752A	16.5	0.704A	6.5	0.769A	16.5	0.767A	6.5	0.767A	16.5	0.775A	6.5	0.802A	16.5	0.802A	16.5	0.750A
6.8	0.750A	16.8	0.704A	6.8	0.767A	16.8	0.775A	6.8	0.775A	16.8	0.775A	6.8	0.800A	16.8	0.800A	16.8	0.750A
7.0	0.748A	17.0	0.704A	7.0	0.765A	17.0	0.774A	7.0	0.774A	17.0	0.775A	7.0	0.798A	17.0	0.798A	17.0	0.750A
7.2	0.747A	17.2	0.704A	7.2	0.764A	17.2	0.773A	7.2	0.773A	17.2	0.775A	7.2	0.797A	17.2	0.797A	17.2	0.750A
7.5	0.745A	17.5	0.704A	7.5	0.762A	17.5	0.772A	7.5	0.772A	17.5	0.775A	7.5	0.795A	17.5	0.795A	17.5	0.750A
7.8	0.743A	17.8	0.704A	7.8	0.757A	17.8	0.771A	7.8	0.771A	17.8	0.775A	7.8	0.790A	17.8	0.790A	17.8	0.750A
8.0	0.737A	18.0	0.704A	8.0	0.754A	18.0	0.769A	8.0	0.769A	18.0	0.775A	8.0	0.787A	18.0	0.787A	18.0	0.750A
8.2	0.734A	18.2	0.704A	8.2	0.751A	18.2	0.766A	8.2	0.766A	18.2	0.775A	8.2	0.784A	18.2	0.784A	18.2	0.750A
8.5	0.726A	18.5	0.704A	8.5	0.743A	18.5	0.764A	8.5	0.764A	18.5	0.775A	8.5	0.776A	18.5	0.776A	18.5	0.750A
8.8	0.716A	18.8	0.704A	8.8	0.733A	18.8	0.753A	8.8	0.753A	18.8	0.775A	8.8	0.766A	18.8	0.766A	18.8	0.750A
9.0	0.708A	19.0	0.704A	9.0	0.725A	19.0	0.745A	9.0	0.745A	19.0	0.775A	9.0	0.756A	19.0	0.756A	19.0	0.750A
9.2	0.706A	19.2	0.704A	9.2	0.723A	19.2	0.743A	9.2	0.743A	19.2	0.775A	9.2	0.768A	19.2	0.768A	19.2	0.750A
9.5	0.718A	19.5	0.704A	9.5	0.735A	19.5	0.753A	9.5	0.753A	19.5	0.775A	9.5	0.776A	19.5	0.776A	19.5	0.750A
9.8	0.741A	19.8	0.704A	9.8	0.758A	19.8	0.778A	9.8	0.778A	19.8	0.775A	9.8	0.791A	19.8	0.791A	19.8	0.750A
10.0	0.760A	20.0	0.704A	10.0	0.777A	20.0	0.797A	10.0	0.797A	20.0	0.775A	10.0	0.810A	20.0	0.810A	20.0	0.750A
10.2	0.774A	20.2	0.704A	10.2	0.791A	20.2	0.811A	10.2	0.811A	20.2	0.775A	10.2	0.824A	20.2	0.824A	20.2	0.750A
10.5	0.782A	20.5	0.704A	10.5	0.795A	20.5	0.815A	10.5	0.815A	20.5	0.775A	10.5	0.832A	20.5	0.832A	20.5	0.750A

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL.




FIGURE 13-1. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).




FIGURE 13-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).

TABLE 13-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMISSANCE OF SILICON MONOCARBIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year 1948	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T00758	Silverman, S.	1948	1.7-15.0	1375	Globar from the Carborundum Co.; data extracted from smooth curve; $\theta^* = \sim 0^\circ$.	
2 T10461	Blau, H. H., Jr., Chaffee, E., and Jasperse, J.R.	1960	2.24-13.9	1296	Norton Co. Crystalon-R; flat and smooth surface obtained by diamond wheel cutting; oxidized by heating in air at 1400 K for 1 hr; measured in argon-hydrogen atm; data extracted from smooth curve; $\theta^* = \sim 0^\circ$.	
3 T32045	Blau, H. H., Jr. and Jasperse, J.R.	1964	2.00-13.9	873	Bonded Norton RC 4237; 80% pure SiC, nitride bonded; ultrasonically machined; measured in air; $\theta^* = 0^\circ$; reported error $\leq 4\%$.	
4 T32045	Blau, H. H., Jr. and Jasperse, J.R.	1964	0.91-13.9	1293	Above specimen and conditions.	
5 T32045	Blau, H. H., Jr. and Jasperse, J.R.	1964	1.92-13.9	873	Norton Crystalon R; 99% pure; ultrasonically machined; measured in air; $\theta^* = 0^\circ$; reported error $\leq 4\%$.	
6 T32045	Blau, H. H., Jr. and Jasperse, J.R.	1964	0.92-13.9	1298	Above specimen and conditions.	
7 T22272	Schatz, E. A., Goldberg, D. M., Pearson, E. G., and Burks, T. L.	1963	1.00-15.0	1023	Sample No. 102 Density 2.32 g cm ⁻³ ; theoretical density 3.21 g cm ⁻³ ; data extracted from smooth curve; $\theta^* = \sim 0^\circ$.	
8 T22272	Schatz, E. A., et al.	1963	1.00-15.0	1023	Sample No. 103 Sintered at 2170 K for 1 hr (settler material SiC); density 1.49 g cm ⁻³ ; theoretical density 3.21 g cm ⁻³ ; data extracted from smooth curve; $\theta^* = \sim 0^\circ$.	
9 T25673	Mitchell, C.A.	1962	0.65-14.9	1358	Globar from Carborundum Co.; $\theta^* = \sim 0^\circ$.	
10 T02147	Brügel, W.	1950	0.66-15	1243	Rod specimen electrically heated.	
11 T40798	Stewart, J.E. and Richmond, J.C.	1957	2.5-15	755	Recrystallized; measured with a Perkin-Elmer spectrophotometer.	
12 T40798	Stewart, J.E. and Richmond, J.C.	1957	1.3-15	922	The above specimen.	
13 T40798	Stewart, J.E. and Richmond, J.C.	1957	1.3-15	1089	The above specimen.	
14 T40798	Stewart, J.E. and Richmond, J.C.	1957	1.3-15	1255	The above specimen.	
15 T36117	Schatz, E. A.	1962	1.0-15	1273	Supplied by Carborundum Co.; sintered; density 2.32 g cm ⁻³ .	
16 T62012	Dubrovskii, G.B.	1969	0.49-4.7	2000	α -phase 6H type single crystal; 100 μ thick plate specimen with surface perpendicular to c _z -axis; values calculated from absorption coefficient measurement; data taken from smooth curve.	
17 T62012	Dubrovskii, G.B.	1969	0.49-4.7	2200	The above specimen.	
18 T62013	Dubrovskii, G.B.	1969	0.19-4.7	2500	The above specimen.	
19 T09277	Richmond, J.C. and Stewart, J.E.	1959	2.5-15	755	Recrystallized rod specimen.	
20 T09277	Richmond, J. C. and Stewart, J.E.	1959	1.3-15	922	The above specimen.	
21 T03277	Richmond, J.C. and Stewart, J.E.	1959	1.3-15	1089	The above specimen.	

TABLE 13-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON MONOCARBIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
22 T08277	Richmond, J.C. and Stewart, J.E.	1959	1.3-15	1255		The above specimen.
23 T16606	Blau, H.H., Jr., March, J.B., Martin, W.S., Jasperse, J.R., and Chaffee, E.	1960	2.0-14	1073		The same specimen as for curve No. 5.

TABLE 13-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ ; μm ; TEMPERATURE, T , K; EMITTANCE, ϵ]

λ	ϵ	CURVE 1 $T = 1375.$			CURVE 2 (CONT.)			CURVE 4 (CONT.)			CURVE 6 (CONT.)			CURVE 8 (CONT.)		
1.7	0.73	9.47	0.832	10.9	0.848	1.00	0.945	12.3	0.738	7.56	0.938	7.56	0.945	7.87	0.945	
2.0	0.74	10.0	0.910	11.9	0.761	1.26	0.898	12.4	0.719	7.87	0.945	7.94	0.932	7.94	0.932	
3.0	0.77	10.3	0.931	12.3	0.744	1.49	0.885	12.6	0.728	8.03	0.951	8.11	0.951	8.11	0.951	
4.0	0.79	10.6	0.899	14.0	0.806	1.88	0.930	13.0	0.722	8.25	0.907	8.42	0.907	8.42	0.907	
5.0	0.84	11.8	0.700	12.6	0.617	2.06	0.969	13.5	0.817	8.42	0.841	8.51	0.841	8.51	0.841	
6.0	0.85	12.8	0.644	13.1	0.711	2.34	0.984	14.0	0.841	8.51	0.852	8.63	0.852	8.63	0.852	
7.0	0.84	13.4	0.767	14.0	0.803	1.92	0.897	14.5	0.852	8.73	0.880	8.91	0.880	8.91	0.880	
9.0	0.85	9.0	0.856	9.5	0.855	2.93	0.923	3.32	1.000	9.03	0.920	9.16	0.920	9.16	0.920	
10.0	0.86	10.0	0.866	11.0	0.855	3.95	0.943	3.99	0.995	9.16	0.920	9.22	0.920	9.22	0.920	
11.0	0.85	12.0	0.880	12.5	0.777	4.94	0.934	4.20	0.972	9.22	0.934	9.42	0.934	9.42	0.934	
13.0	0.78	13.0	0.86	14.0	0.855	5.95	0.954	4.44	0.964	9.22	0.912	9.42	0.912	9.42	0.912	
14.0	0.81	14.0	0.85	15.0	0.800	6.95	0.942	4.66	0.973	1.00	0.950	1.16	0.950	1.16	0.950	
15.0	0.79	12.5	0.77	13.0	0.781	7.91	0.944	5.20	0.963	9.79	0.920	10.1	0.939	10.1	0.939	
16.0	0.81	13.0	0.86	14.0	0.864	8.93	0.960	5.29	0.974	1.25	0.865	1.49	0.865	1.49	0.865	
17.0	0.81	14.0	0.85	15.0	0.800	9.86	0.971	5.42	0.962	1.49	0.839	1.77	0.839	1.77	0.839	
18.0	0.79	15.0	0.85	16.0	0.853	10.9	0.723	5.75	0.962	1.77	0.849	2.00	0.849	2.00	0.849	
20.0	0.77	12.5	0.77	13.0	0.781	11.9	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
21.0	0.76	13.0	0.86	14.0	0.864	12.8	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
22.0	0.78	14.0	0.85	15.0	0.800	13.7	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
23.0	0.78	15.0	0.85	16.0	0.853	14.6	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
24.0	0.77	12.5	0.77	13.0	0.781	15.5	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
25.0	0.76	13.0	0.86	14.0	0.864	16.4	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
26.0	0.78	14.0	0.85	15.0	0.800	17.3	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
27.0	0.78	15.0	0.85	16.0	0.853	18.2	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
28.0	0.77	12.5	0.77	13.0	0.781	19.1	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
29.0	0.76	13.0	0.86	14.0	0.864	20.0	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
30.0	0.78	14.0	0.85	15.0	0.800	20.9	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
31.0	0.78	15.0	0.85	16.0	0.853	21.8	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
32.0	0.77	12.5	0.77	13.0	0.781	22.7	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
33.0	0.76	13.0	0.86	14.0	0.864	23.6	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
34.0	0.78	14.0	0.85	15.0	0.800	24.5	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
35.0	0.78	15.0	0.85	16.0	0.853	25.4	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
36.0	0.77	12.5	0.77	13.0	0.781	26.3	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
37.0	0.76	13.0	0.86	14.0	0.864	27.2	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
38.0	0.78	14.0	0.85	15.0	0.800	28.1	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
39.0	0.78	15.0	0.85	16.0	0.853	29.0	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
40.0	0.77	12.5	0.77	13.0	0.781	29.9	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
41.0	0.76	13.0	0.86	14.0	0.864	30.8	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
42.0	0.78	14.0	0.85	15.0	0.800	31.7	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
43.0	0.78	15.0	0.85	16.0	0.853	32.6	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
44.0	0.77	12.5	0.77	13.0	0.781	33.5	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
45.0	0.76	13.0	0.86	14.0	0.864	34.4	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
46.0	0.78	14.0	0.85	15.0	0.800	35.3	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
47.0	0.77	15.0	0.85	16.0	0.853	36.2	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
48.0	0.76	12.5	0.77	13.0	0.781	37.1	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
49.0	0.75	13.0	0.86	14.0	0.864	38.0	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
50.0	0.77	14.0	0.85	15.0	0.800	38.9	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
51.0	0.77	15.0	0.85	16.0	0.853	39.8	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
52.0	0.76	12.5	0.77	13.0	0.781	40.7	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
53.0	0.75	13.0	0.86	14.0	0.864	41.6	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
54.0	0.77	14.0	0.85	15.0	0.800	42.5	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
55.0	0.77	15.0	0.85	16.0	0.853	43.4	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
56.0	0.76	12.5	0.77	13.0	0.781	44.3	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
57.0	0.75	13.0	0.86	14.0	0.864	45.2	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
58.0	0.77	14.0	0.85	15.0	0.800	46.1	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
59.0	0.77	15.0	0.85	16.0	0.853	47.0	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
60.0	0.76	12.5	0.77	13.0	0.781	47.9	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
61.0	0.75	13.0	0.86	14.0	0.864	48.8	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
62.0	0.77	14.0	0.85	15.0	0.800	49.7	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
63.0	0.77	15.0	0.85	16.0	0.853	50.6	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
64.0	0.76	12.5	0.77	13.0	0.781	51.5	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
65.0	0.75	13.0	0.86	14.0	0.864	52.4	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
66.0	0.77	14.0	0.85	15.0	0.800	53.3	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
67.0	0.77	15.0	0.85	16.0	0.853	54.2	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
68.0	0.76	12.5	0.77	13.0	0.781	55.1	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
69.0	0.75	13.0	0.86	14.0	0.864	56.0	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
70.0	0.77	14.0	0.85	15.0	0.800	56.9	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
71.0	0.77	15.0	0.85	16.0	0.853	57.8	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
72.0	0.76	12.5	0.77	13.0	0.781	58.7	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
73.0	0.75	13.0	0.86	14.0	0.864	59.6	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
74.0	0.77	14.0	0.85	15.0	0.800	60.5	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
75.0	0.77	15.0	0.85	16.0	0.853	61.4	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
76.0	0.76	12.5	0.77	13.0	0.781	62.3	0.604	5.85	0.951	1.99	0.891	2.50	0.891	2.50	0.891	
77.0	0.75	13.0	0.86	14.0	0.864	63.2	0.605	5.97	0.955	2.00	0.899	2.72	0.899	2.72	0.899	
78.0	0.77	14.0	0.85	15.0	0.800	64.1	0.807	6.07	0.956	2.00	0.893	2.83	0.893	2.83	0.893	
79.0	0.77	15.0	0.85	16.0	0.853	65.0	0.667	6.50	0.960	2.00	0.884	11.5	0.884	11.5	0.884	
80.0	0.76	12.5	0.77	13.0	0.781	65.9	0.604	5.85	0.951	1.99	0.891	2.5				

TABLE 13-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	CURVE 9 (CONT.)			CURVE 11 (CONT.)			CURVE 12 (CONT.)			CURVE 13 (CONT.)			CURVE 13 (CONT.)		
0.80	0.93	2.80	0.647	12.76	0.690	7.77	0.762	2.26	0.708	12.46	0.658	2.46	0.721	12.69	0.647	12.94	0.672	
0.90	0.95	3.00	0.731	12.97	0.712	7.99	0.756	2.48	0.721	12.69	0.647	2.99	0.748	12.94	0.672	13.19	0.703	
1.00	0.92	3.27	0.728	13.22	0.734	8.23	0.747	2.99	0.748	12.94	0.672	3.23	0.753	13.50	0.714	13.50	0.714	
1.30	0.92	3.52	0.772	13.47	0.742	8.48	0.737	3.23	0.753	13.19	0.703	3.49	0.776	13.72	0.714	13.72	0.714	
1.50	0.92	3.76	0.839	13.74	0.761	8.74	0.728	3.49	0.776	13.50	0.714	3.49	0.776	13.97	0.714	14.21	0.714	
2.80	0.87	4.01	0.775	13.97	0.756	8.96	0.718	3.75	0.762	13.72	0.714	4.25	0.776	14.47	0.725	14.47	0.725	
3.3	0.84	4.27	0.804	14.23	0.760	9.23	0.708	3.96	0.772	13.97	0.714	4.47	0.774	14.69	0.717	14.69	0.717	
4.9	0.82	4.50	0.775	14.43	0.766	9.47	0.744	4.25	0.776	14.21	0.714	4.71	0.774	15.00	0.722	15.00	0.722	
5.6	0.90	4.78	0.796	14.69	0.759	9.71	0.768	4.47	0.771	14.47	0.725	5.00	0.772	14.93	0.722	14.93	0.722	
6.2	0.90	4.99	0.781	14.97	0.740	9.93	0.789	4.75	0.767	14.69	0.717	5.24	0.778	CURVE 14 $T = 1255.$				
6.4	0.90	5.28	0.791	15.22	0.740	10.23	0.813	5.00	0.772	14.93	0.722	5.50	0.778	CURVE 14 $T = 1255.$				
9.5	0.89	5.49	0.788	5.80	0.768	10.44	0.813	5.24	0.778	CURVE 14 $T = 1255.$			CURVE 14 $T = 1255.$					
10.7	0.90	6.00	0.780	10.97	0.797	10.72	0.817	5.50	0.778	CURVE 14 $T = 1255.$			CURVE 14 $T = 1255.$					
13.9	0.85	6.29	0.774	11.21	0.776	5.74	0.776	CURVE 14 $T = 1255.$			CURVE 14 $T = 1255.$			CURVE 14 $T = 1255.$				
14.9	0.86	6.53	0.760	1.30	0.616	11.49	0.749	6.24	0.775	1.26	0.620	1.49	0.770	1.54	0.646	1.77	0.670	
CURVE 10 $T = 1243.$			6.78	0.769	1.49	0.616	11.72	0.720	6.49	0.770	1.54	0.646	1.74	0.770	1.77	0.670	2.01	0.700
0.66	0.739	7.53	0.763	2.05	0.673	11.96	0.707	6.74	0.770	1.77	0.670	1.96	0.770	2.01	0.725	2.26	0.725	
0.95	0.726	7.79	0.766	2.29	0.715	12.44	0.663	7.26	0.767	2.48	0.758	2.53	0.758	2.48	0.758	2.78	0.785	
2.00	0.749	8.00	0.766	2.49	0.711	12.57	0.645	7.53	0.767	2.78	0.785	2.79	0.768	3.01	0.776	3.01	0.776	
2.93	0.790	8.23	0.759	2.77	0.739	12.70	0.653	7.76	0.768	3.27	0.776	3.27	0.776	3.49	0.817	3.49	0.817	
3.97	0.793	8.49	0.750	3.05	0.750	12.90	0.690	7.99	0.756	3.59	0.776	3.59	0.776	3.78	0.817	3.78	0.817	
4.97	0.833	8.75	0.743	3.29	0.740	13.22	0.719	8.27	0.751	4.02	0.775	4.27	0.775	4.47	0.817	4.47	0.817	
5.99	0.831	9.00	0.736	4.02	0.766	13.43	0.741	8.47	0.744	4.75	0.775	5.02	0.775	5.28	0.775	5.28	0.775	
6.99	0.853	9.25	0.710	4.26	0.789	13.76	0.745	8.73	0.734	5.37	0.775	5.63	0.775	5.96	0.794	5.96	0.794	
8.02	0.876	9.51	0.751	4.50	0.768	14.20	0.754	9.25	0.717	6.02	0.803	6.23	0.803	6.47	0.817	6.47	0.817	
8.93	0.850	9.74	0.789	4.78	0.781	14.45	0.760	9.47	0.734	6.49	0.803	6.76	0.803	7.00	0.817	7.00	0.817	
10.06	0.854	9.99	0.798	5.01	0.781	14.75	0.745	9.69	0.757	7.00	0.775	7.26	0.775	7.50	0.775	7.50	0.775	
11.05	0.832	10.20	0.853	5.28	0.774	14.98	0.745	9.96	0.775	7.75	0.775	8.02	0.775	8.28	0.775	8.28	0.775	
12.00	0.780	10.48	0.637	5.49	0.765	15.21	0.737	10.16	0.783	8.02	0.775	8.37	0.775	8.63	0.775	8.63	0.775	
12.93	0.754	10.71	0.840	5.75	0.774	10.97	0.788	10.49	0.800	8.63	0.775	8.83	0.775	9.00	0.775	9.00	0.775	
14.00	0.783	11.23	0.764	6.26	0.767	11.49	0.749	10.70	0.797	9.75	0.775	10.00	0.797	10.26	0.775	10.26	0.775	
15.30	0.767	11.49	0.726	6.49	0.777	12.66	0.767	11.22	0.765	10.69	0.784	11.46	0.766	11.52	0.761	11.52	0.761	
CURVE 11 $T = 755.$			11.71	0.726	6.73	0.767	12.96	0.762	11.68	0.763	11.68	0.764	12.19	0.673	12.45	0.661	12.45	0.661
2.52	0.697	12.19	0.666	7.26	0.766	12.45	0.749	7.49	0.766	12.45	0.693	7.49	0.766	7.49	0.766	7.49	0.766	

TABLE 13-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ																				
CURVE 14 (CONT.)				CURVE 15 (CONT.)				CURVE 16 (CONT.)															
7.49	0.753	1.63	0.459	5.62	0.771	8.79	0.682	12.40	0.754	4.69	0.81	7.78	0.747	12.47	0.767	12.40	0.754	4.69	0.81				
7.78	0.747	1.78	0.459	5.66	0.754	8.82	0.697	12.47	0.767	4.70	0.81	7.93	0.745	12.53	0.753	12.53	0.753	4.70	0.81				
7.98	0.747	1.80	0.475	5.79	0.754	8.87	0.676	12.53	0.753	4.71	0.81	8.20	0.501	9.02	0.663	12.69	0.758	12.69	0.758				
8.44	0.736	1.90	0.501	5.96	0.756	9.08	0.651	12.73	0.777	4.72	0.81	8.72	0.543	6.03	0.777	9.53	0.651	12.85	0.753				
9.19	0.710	2.35	0.598	6.12	0.757	9.66	0.687	13.02	0.773	4.73	0.81	9.45	0.724	6.16	0.767	13.22	0.773	13.22	0.773				
9.45	0.724	2.49	0.615	6.16	0.767	9.77	0.687	13.22	0.773	4.74	0.81	9.72	0.742	6.33	0.773	13.44	0.777	13.44	0.777				
9.95	0.766	2.62	0.633	6.31	0.773	9.89	0.709	13.44	0.777	4.75	0.81	10.20	0.779	6.34	0.767	9.94	0.724	13.50	0.793				
10.20	0.779	2.75	0.647	6.37	0.782	9.99	0.711	13.57	0.783	4.76	0.81	10.44	0.799	6.43	0.764	10.08	0.711	13.62	0.793				
10.69	0.799	2.97	0.696	6.49	0.772	10.14	0.726	13.73	0.787	4.77	0.81	11.07	0.794	6.52	0.779	10.20	0.729	13.77	0.779				
11.20	0.775	3.12	0.693	6.63	0.779	10.20	0.729	13.77	0.779	4.78	0.81	11.46	0.753	6.68	0.771	10.24	0.746	14.05	0.783				
11.46	0.753	3.17	0.684	6.68	0.771	10.31	0.734	14.35	0.788	4.79	0.81	11.69	0.732	6.86	0.782	10.39	0.734	14.41	0.781				
11.99	0.712	3.41	0.700	7.06	0.774	10.51	0.746	14.72	0.793	4.80	0.81	12.20	0.696	7.12	0.784	10.72	0.739	14.55	0.785				
12.46	0.679	3.58	0.703	7.18	0.773	10.77	0.728	14.72	0.797	4.81	0.81	12.71	0.662	7.32	0.777	10.81	0.751	14.77	0.806				
12.93	0.674	3.67	0.727	7.36	0.790	10.87	0.724	14.83	0.800	4.82	0.81	13.19	0.702	7.50	0.792	10.98	0.748	14.87	0.789				
13.44	0.732	4.02	0.717	7.55	0.776	11.06	0.725	14.93	0.801	4.83	0.81	13.72	0.726	7.63	0.782	11.19	0.729	14.96	0.819				
13.93	0.726	4.15	0.728	7.83	0.782	11.25	0.744	15.00	0.827	4.84	0.81	14.21	0.721	8.04	0.777	11.31	0.735	15.22	0.821				
14.46	0.721	4.47	0.722	8.12	0.767	11.35	0.740	15.22	0.821	4.85	0.81	14.67	0.721	8.15	0.736	11.69	0.740	15.55	0.821				
14.67	0.721	4.53	0.736	8.20	0.750	11.73	0.755	15.55	0.827	4.86	0.81	14.95	0.724	8.24	0.724	11.80	0.740	15.87	0.827				
CURVE 15				4.61	0.739	8.29	0.737	11.86	0.748	4.87	0.81	CURVE 15				4.90	0.83	16.00	0.83				
$T = 1273$.				5.11	0.745	8.35	0.705	11.93	0.741	4.88	0.81	$T = 1273$.				5.46	0.73	16.14	0.81				
5.17	0.757	8.40	0.721	11.97	0.752	11.97	0.638	0.27	0.614	0.36	0.82	5.23	0.746	8.46	0.721	2.46	0.694	16.24	0.81				
5.23	0.746	8.46	0.721	12.01	0.744	12.01	0.674	0.23	0.638	0.36	0.82	5.49	0.754	8.51	0.703	2.71	0.646	16.42	0.81				
5.27	0.754	8.51	0.724	12.06	0.756	12.14	0.749	1.21	0.723	0.25	0.82	5.49	0.769	8.65	0.703	2.92	0.724	16.59	0.81				
5.49	0.754	8.65	0.724	12.14	0.749	12.22	0.755	1.21	0.721	0.25	0.82	5.49	0.769	8.70	0.681	3.21	0.722	16.76	0.81				
5.49	0.766	8.70	0.724	12.22	0.777	12.27	0.744	1.21	0.721	0.25	0.82	5.58	0.756	8.75	0.747	3.44	0.728	16.93	0.81				

TABLE 13-3. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMISSANCE, ϵ)

λ	ϵ	CURVE 19(CONT.)			CURVE 19(CONT.)			CURVE 20(CONT.)			CURVE 21(CONT.)			CURVE 21(CONT.)			CURVE 22(CONT.)						
3.96	0.773	13.68	0.755	0.727	3.78	0.774	13.50	0.716	0.52	0.736	11.40	0.771	13.50	0.716	0.52	0.736	10.21	0.798	14.23	0.757	0.716	0.731	
4.21	0.798	14.23	0.757	0.716	3.77	0.764	13.75	0.716	0.78	0.731	11.93	0.686	0.766	13.95	0.716	0.78	0.731	4.45	0.774	14.39	0.761	0.716	0.723
4.45	0.774	14.39	0.761	0.719	3.99	0.769	13.98	0.713	9.01	0.723	12.13	0.665	0.760	14.49	0.727	9.25	0.708	4.76	0.792	14.73	0.755	0.723	0.723
4.88	0.775	16.90	0.734	0.747	4.27	0.773	14.23	0.711	9.49	0.724	12.39	0.648	0.761	14.51	0.724	9.49	0.720	5.17	0.785	15.21	0.737	0.715	0.741
5.42	0.783	15.21	0.737	0.787	4.49	0.766	14.51	0.724	14.73	0.720	12.67	0.686	0.763	14.76	0.724	9.77	0.742	5.69	0.781	16.46	0.813	0.715	0.765
5.92	0.775	16.18	0.768	0.717	4.70	0.773	14.78	0.722	10.26	0.779	12.92	0.752	0.773	14.98	0.722	9.97	0.765	6.18	0.768	16.95	0.798	0.716	0.779
6.41	0.752	1.26	0.619	0.798	5.02	0.773	15.52	0.716	10.52	0.800	12.55	0.752	0.773	15.52	0.716	10.52	0.800	6.68	0.766	1.41	0.611	0.775	10.95
6.68	0.751	1.26	0.619	0.798	5.27	0.773	15.71	0.716	10.76	0.801	12.55	0.752	0.773	15.71	0.716	10.76	0.801	6.94	0.751	1.41	0.611	0.775	11.19
7.18	0.762	1.91	0.673	0.798	5.52	0.765	16.50	0.647	11.01	0.793	12.55	0.752	0.773	16.50	0.647	11.01	0.793	7.40	0.760	2.18	0.710	0.775	11.49
7.69	0.760	2.18	0.710	0.798	5.76	0.764	16.76	0.647	11.51	0.754	12.55	0.752	0.773	16.76	0.647	11.51	0.754	7.92	0.764	2.42	0.707	0.775	12.04
8.15	0.755	2.93	0.735	0.798	6.02	0.765	17.04	0.647	11.72	0.734	12.55	0.752	0.773	17.04	0.647	11.72	0.734	8.43	0.755	3.15	0.757	0.775	12.44
8.70	0.739	3.41	0.739	0.798	6.27	0.764	17.30	0.647	12.04	0.712	12.55	0.752	0.773	17.30	0.647	12.04	0.712	8.95	0.736	3.70	0.772	0.775	12.24
9.18	0.707	3.92	0.765	0.798	6.52	0.764	17.55	0.647	12.55	0.693	12.55	0.752	0.773	17.55	0.647	12.55	0.693	9.18	0.707	4.67	0.735	0.775	12.50
9.44	0.744	4.18	0.785	0.798	6.77	0.760	17.76	0.647	12.76	0.659	12.55	0.752	0.773	17.76	0.647	12.76	0.659	9.69	0.780	4.44	0.765	0.775	12.97
9.91	0.792	4.70	0.779	0.798	7.02	0.764	18.01	0.647	13.25	0.670	12.55	0.752	0.773	18.01	0.647	13.25	0.670	10.17	0.846	5.94	0.779	0.775	13.46
10.43	0.833	5.18	0.770	0.798	7.27	0.766	18.26	0.647	13.25	0.670	12.55	0.752	0.773	18.26	0.647	13.25	0.670	10.66	0.835	5.43	0.766	0.775	13.74
10.90	0.786	5.71	0.771	0.798	7.52	0.766	18.51	0.647	13.74	0.676	12.55	0.752	0.773	18.51	0.647	13.74	0.676	11.12	0.761	5.96	0.771	0.775	14.00
11.40	0.747	6.20	0.764	0.798	7.77	0.764	18.76	0.647	14.00	0.771	12.55	0.752	0.773	18.76	0.647	14.00	0.771	11.65	0.724	6.44	0.773	0.775	14.25
11.93	0.686	6.68	0.766	0.798	8.02	0.764	19.01	0.647	14.25	0.770	12.55	0.752	0.773	19.01	0.647	14.25	0.770	12.13	0.665	6.95	0.760	0.775	14.50
12.39	0.648	7.21	0.761	0.798	8.27	0.764	19.26	0.647	14.50	0.770	12.55	0.752	0.773	19.26	0.647	14.50	0.770	12.67	0.686	7.45	0.763	0.775	14.75
12.92	0.704	7.72	0.760	0.798	8.52	0.764	19.51	0.647	14.75	0.770	12.55	0.752	0.773	19.51	0.647	14.75	0.770	13.18	0.733	7.98	0.756	0.775	14.98
13.40	0.738	8.23	0.744	0.798	8.77	0.764	19.76	0.647	15.24	0.770	12.55	0.752	0.773	19.76	0.647	15.24	0.770	13.67	0.757	8.49	0.735	0.775	15.26
CURVE 21 T = 1069.																							
CURVE 21 T = 1069.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							
CURVE 23 T = 1073.																							

TABLE 13-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ]

λ	ϵ
CURVE 23 (CONT.)	
10.00	0.929
11.00	0.796
12.00	0.708
13.00	0.726
14.00	0.833

b. Normal Spectral Emissittance (Temperature Dependence)

A total of 11 sets of data are available. Five sets of the data were measured below 1 μm . The remaining data were measured between 2 and 12 μm at temperatures ranging from 1000 to 1800 K.

The data measured between 2 and 12 μm show a positive but weak dependence on temperature. This fact is supported by Dubrovskii's measurements [T62013] (Figure 13-2, curves 16-18) at higher temperatures for a single crystal and by Morris' values [T20946] at 395 K for Globar. The temperature dependence is assumed linear for simplicity. The slope is determined by the data of Brügel [T02147] (Figure 13-4, curves 3-6 and 9) and Dubrovskii. Using this slope value, four curves were generated as recommended for Globar at 2.8, 3.8, 5.0, and 10.6 μm from room temperature to 2400 K. The uncertainty is believed to be 5 to 10% below 800 K, 5% from 800 to 1800 K, and 10% above 1800 K. For polished bulk material, four similar curves were generated as provisional. The uncertainty is believed to be as high as 30% for some specimens.

The recommended curves are shown in Figure 13-3 and the experimental curves are shown in Figure 13-4. The recommended values, the experimental measurement information, and the experimental data are tabulated in Tables 13-4, 13-5, and 13-6, respectively.

TABLE 13-4. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE)
 (WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T	ϵ	GLOBAR, BULK OXIDIZED $\lambda = 2.6$	T	ϵ	GLOBAR, BULK OXIDIZED $\lambda = 3.0$	T	ϵ	GLOBAR, BULK OXIDIZED $\lambda = 5.0$	T	ϵ	GLOBAR, BULK OXIDIZED $\lambda = 10.6$	T	ϵ	GLOBAR, BULK OXIDIZED $\lambda = 20.6$	T	ϵ	BULK POLISHED $\lambda = 3.6$	T	ϵ	BULK POLISHED $\lambda = 2.6$	T	ϵ	BULK POLISHED $\lambda = 3.6$			
293.	0.862	293.	0.855	293.	0.855	300.	0.855	300.	0.857	400.	0.857	400.	0.857	400.	0.857	400.	0.857	500.	0.857	500.	0.857	500.	0.857	500.	0.857	500.
300.	0.862	300.	0.855	300.	0.855	400.	0.857	400.	0.860	500.	0.867	500.	0.884	500.	0.877	500.	0.874	600.	0.880	600.	0.887	600.	0.880	600.	0.874	600.
400.	0.864	400.	0.857	400.	0.857	500.	0.867	500.	0.863	600.	0.875	600.	0.887	600.	0.880	600.	0.880	700.	0.889	700.	0.882	700.	0.882	700.	0.874	700.
500.	0.867	500.	0.867	500.	0.867	600.	0.870	600.	0.863	700.	0.872	700.	0.865	700.	0.865	700.	0.867	800.	0.891	800.	0.884	800.	0.884	800.	0.876	800.
600.	0.870	600.	0.870	600.	0.870	700.	0.872	700.	0.872	800.	0.874	800.	0.874	800.	0.874	800.	0.877	900.	0.894	900.	0.887	900.	0.887	900.	0.879	900.
700.	0.872	700.	0.872	700.	0.872	800.	0.874	800.	0.874	900.	0.877	900.	0.877	900.	0.877	900.	0.886	1000.	0.896	1000.	0.889	1000.	0.889	1000.	0.879	1000.
800.	0.874	800.	0.874	800.	0.874	900.	0.877	900.	0.877	1000.	0.880	1000.	0.880	1000.	0.880	1000.	0.882	1100.	0.892	1100.	0.892	1100.	0.892	1100.	0.874	1100.
900.	0.877	900.	0.877	900.	0.877	1000.	0.879	1000.	0.879	1100.	0.882	1100.	0.882	1100.	0.882	1100.	0.885	1200.	0.894	1200.	0.894	1200.	0.894	1200.	0.876	1200.
1000.	0.879	1000.	0.879	1000.	0.879	1100.	0.882	1100.	0.882	1200.	0.885	1200.	0.885	1200.	0.885	1200.	0.888	1300.	0.896	1300.	0.896	1300.	0.896	1300.	0.878	1300.
1100.	0.882	1100.	0.882	1100.	0.882	1200.	0.884	1200.	0.884	1300.	0.887	1300.	0.887	1300.	0.887	1300.	0.890	1400.	0.896	1400.	0.896	1400.	0.896	1400.	0.878	1400.
1200.	0.884	1200.	0.884	1200.	0.884	1300.	0.886	1300.	0.886	1400.	0.889	1400.	0.889	1400.	0.889	1400.	0.893	1500.	0.906	1500.	0.906	1500.	0.906	1500.	0.878	1500.
1300.	0.886	1300.	0.886	1300.	0.886	1400.	0.889	1400.	0.889	1500.	0.892	1500.	0.892	1500.	0.892	1500.	0.896	1600.	0.911	1600.	0.911	1600.	0.911	1600.	0.878	1600.
1400.	0.889	1400.	0.889	1400.	0.889	1500.	0.892	1500.	0.892	1600.	0.895	1600.	0.895	1600.	0.895	1600.	0.904	1700.	0.913	1700.	0.913	1700.	0.913	1700.	0.878	1700.
1500.	0.891	1500.	0.891	1500.	0.891	1600.	0.894	1600.	0.894	1700.	0.897	1700.	0.897	1700.	0.897	1700.	0.906	1800.	0.915	1800.	0.915	1800.	0.915	1800.	0.878	1800.
1600.	0.894	1600.	0.894	1600.	0.894	1700.	0.896	1700.	0.896	1800.	0.898	1800.	0.898	1800.	0.898	1800.	0.906	1900.	0.917	1900.	0.917	1900.	0.917	1900.	0.878	1900.
1700.	0.896	1700.	0.896	1700.	0.896	1800.	0.898	1800.	0.898	1900.	0.901	1900.	0.901	1900.	0.901	1900.	0.913	2000.	0.920	2000.	0.920	2000.	0.920	2000.	0.878	2000.
1800.	0.898	1800.	0.898	1800.	0.898	1900.	0.901	1900.	0.901	2000.	0.904	2000.	0.904	2000.	0.904	2000.	0.916	2100.	0.923	2100.	0.923	2100.	0.923	2100.	0.878	2100.
1900.	0.901	1900.	0.901	1900.	0.901	2000.	0.904	2000.	0.904	2100.	0.907	2100.	0.907	2100.	0.907	2100.	0.918	2200.	0.925	2200.	0.925	2200.	0.925	2200.	0.878	2200.
2000.	0.903	2000.	0.903	2000.	0.903	2100.	0.906	2100.	0.906	2200.	0.909	2200.	0.909	2200.	0.909	2200.	0.920	2300.	0.933	2300.	0.933	2300.	0.933	2300.	0.878	2300.
2100.	0.906	2100.	0.906	2100.	0.906	2200.	0.909	2200.	0.909	2300.	0.913	2300.	0.913	2300.	0.913	2300.	0.927	2400.	0.935	2400.	0.935	2400.	0.935	2400.	0.878	2400.
2200.	0.908	2200.	0.908	2200.	0.908	2300.	0.913	2300.	0.913	2400.	0.921	2400.	0.921	2400.	0.921	2400.	0.932	2500.	0.943	2500.	0.943	2500.	0.943	2500.	0.878	2500.
2300.	0.913	2300.	0.913	2300.	0.913	2400.	0.921	2400.	0.921	2500.	0.932	2500.	0.932	2500.	0.932	2500.	0.943	2600.	0.954	2600.	0.954	2600.	0.954	2600.	0.878	2600.

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL.

TABLE 13-4. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; EMITTANCE, ϵ)

T	ϵ	T	ϵ
BULK POLISHED $\lambda = 5.0$	BULK POLISHED $\lambda = 10.6$		
293.	0.749A [†]	293.	0.771A†
300.	0.749A	300.	0.771A
400.	0.751A	400.	0.773A
500.	0.754A	500.	0.776A
600.	0.757A	600.	0.779A
700.	0.759A	700.	0.781A
800.	0.761A	1000.	0.783A
900.	0.764A	900.	0.786A
1000.	0.765A	1000.	0.788A
1100.	0.769A	1100.	0.791A
1200.	0.771A	1200.	0.793A
1300.	0.773A	1300.	0.795A
1400.	0.776A	1400.	0.798A
1500.	0.778A	1500.	0.800A
1600.	0.781A	1600.	0.803A
1700.	0.783A	1700.	0.805A
1800.	0.785A	1800.	0.807A
1900.	0.787A	1900.	0.809A
2000.	0.790A	2000.	0.812A
2100.	0.793A	2100.	0.815A
2200.	0.795A	2200.	0.817A
2300.	0.797A	2300.	0.819A
2400.	0.799A	2400.	0.821A

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL.




FIGURE 13-3. RECOMMENDED NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE
(TEMPERATURE DEPENDENCE).




FIGURE 13-4. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE).

TABLE 13-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON MONOCARBIDE (Temperature Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T10060	Olsen, O.H. and Morris, J.C.	1959	0.665	1050-1736	Cycle 1; $\theta = \sim 0^\circ$.	Above specimen and conditions; cycle 2.
2 T10060	Olsen, O.H. and Morris, J.C.	1959	0.665	1169-1446	Rod specimen electrically heated.	The above specimen.
3 T02147	Brügel, W.	1950	0.665	1068-1752	The above specimen.	The above specimen.
4 T02147	Brügel, W.	1950	2	1028-1755	The above specimen.	The above specimen.
5 T02147	Brügel, W.	1950	4	1051-1764	The above specimen.	The above specimen.
6 T02147	Brügel, W.	1950	6	1057-1764	The above specimen.	The above specimen.
7 TC2147	Brügel, W.	1950	8	1059-1764	The above specimen.	The above specimen.
8 T02147	Brügel, W.	1950	10	1045-1764	The above specimen.	The above specimen.
9 T02147	Brügel, W.	1950	12	1017-1768	The above specimen.	Cylindrical specimen 0.25 in. in diameter and 0.5 in. long with a hole 1/16 in. in diameter and 0.25 in. deep in one end; hot-pressed; density 3.1405 g cm^{-3} .
10 T61239	Ko, Y.C.	1969	0.665	1528-1983	Polycrystalline; sintered; density 3 to 3.05 g cm^{-3} ; electrical resistivity 0.1 to 0.4 $\Omega \text{ cm}$ at 293 K and 0.03 to 0.06 $\Omega \text{ cm}$ at 1273 K.	
11 T74177	Frantsevich, I.N., Gresin, G.G., Dyban, Yu.P., Gaiduchenko, A.K., Osorovitski, E.L., and Ostrovskiy, V.I.	1972	0.65	1593-2723		

TABLE 13-6. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON CARBIDE (TEMPERATURE DEPENDENCE)

T	ϵ	T	ϵ	T	ϵ	T	ϵ
CURVE 1 $\lambda = 0.665$		CURVE 4 (CONT.)		CURVE 8 (CONT.)			
1050.	0.769	1612.	0.755	1242.	0.851		
1326.	0.771	1755.	0.773	1313.	0.867		
1480.	0.664	CURVE 5 $\lambda = 4.$		1405.	0.867		
1485.	0.711			1507.	0.893		
1640.	0.714			1616.	0.917		
1736.	0.762	1051.	0.770	1764.	0.927		
CURVE 2 $\lambda = 0.665$		1208.	0.791	CURVE 9 $\lambda = 12.$			
1169.	0.790	1244.	0.802				
1326.	0.685	1382.	0.775				
1446.	0.699	1512.	0.795	1017.	0.760		
CURVE 3 $\lambda = 0.665$		1607.	0.785	1243.	0.781		
1068.	0.730	1764.	0.805	1364.	0.785		
1163.	0.743	CURVE 6 $\lambda = 6.$		1506.	0.787		
1238.	0.736	1057.	0.830	1630.	0.795		
1257.	0.749	1244.	0.831	1768.	0.796		
1328.	0.732	1314.	0.853	CURVE 10 $\lambda = 0.665$			
1393.	0.706	1456.	0.835	1528.	0.656		
1448.	0.757	1557.	0.849	1683.	0.616		
1517.	0.759	1661.	0.840	1745.	0.630		
1534.	0.759	CURVE 7 $\lambda = 8.$		0.857	0.577		
1566.	0.755			1795.	0.577		
1645.	0.757	1059.	0.851	1849.	0.552		
1725.	0.748	1242.	0.875	CURVE 11 $\lambda = 0.65$			
1752.	0.763	1328.	0.898				
CURVE 4 $\lambda = 2.$		1488.	0.896				
1028.	0.750	1559.	0.909	1593.	0.857		
1141.	0.762	1665.	0.906	2373.	0.644		
1241.	0.752	1764.	0.915	2723.	0.610		
1312.	0.774						
1465.	0.773	1045.	0.835				

c. Normal Spectral Reflectance (Wavelength Dependence)

A total of 38 sets of data are available. Fourteen sets were measured on single crystals, two on thin films, and seventeen on compact powder specimens.

Only three sets of data were measured for polycrystalline specimens, and two of them were measured at below 2.7 μm (Figure 13-6, curves 2 and 3). Chang's data [T42979] (Figure 13-6, curve 7) were measured at room temperature from 2 to 30 μm . The specimen was supplied by Carborundum Company, but without any detailed description. The behavior of this set of data is not consistent with any of the emittance data. Thus no recommendation was generated based on the experimental reflectance data. Provisional values were derived from the recommended curves of emittance, assuming the transmittance is negligible, for polished bulk material at 293 K and 2400 K. The error is estimated to be 20 to 30%. A pair of curves were generated the same way for Globar. Since the absolute values of the derived reflectance of Globar are small, they can only be considered as typical.

Provisional values at 293 K were generated in accordance with the data of Spitzer, et al. [T32822] (Figure 13-6, curve 25) for a thin film 0.06 μm thick. The uncertainty is estimated to be 15 to 30%.

The provisional and typical curves are shown in Figure 13-5 and the experimental curves are shown in Figure 13-6. The provisional and typical values, the experimental measurement information, and the experimental data are tabulated in Tables 13-7, 13-8, and 13-9, respectively.

TABLE 13-7. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

BULK POLISHED $T = 293$						BULK POLISHED $T = 293$ (CONT.)						BULK POLISHED $T = 2400$ (CONT.)						GLOBAR, BULK OXIDIZED $T = 293$ (CONT.)					
λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ				
1.0	0.403	10.6	0.219	1.0	0.353	10.6	0.169	1.0	0.0998†	10.6	0.1288†	10.6	0.1028	10.6	0.1318	10.6	0.1308	11.0	0.1308				
1.2	0.387	10.8	0.224	1.2	0.337	10.8	0.174	1.2	0.1028	10.8	0.1288	10.8	0.1078	11.0	0.1308	11.0	0.1308	11.2	0.1458				
1.5	0.364	11.0	0.235	1.5	0.314	11.0	0.165	1.5	0.1078	11.0	0.1288	11.0	0.1138	11.2	0.1308	11.2	0.1308	11.5	0.1598				
1.6	0.342	11.2	0.251	1.6	0.292	11.2	0.201	1.6	0.1138	11.2	0.1288	11.2	0.1248	11.5	0.1748	11.6	0.1748	12.0	0.1658				
2.0	0.328	11.5	0.279	2.0	0.278	11.5	0.229	2.0	0.1248	11.5	0.1288	11.5	0.1328	12.0	0.1758	12.0	0.1758	12.2	0.1948				
2.2	0.314	11.8	0.307	2.2	0.264	11.8	0.257	2.2	0.1328	11.8	0.1288	11.8	0.1388	12.2	0.1948	12.2	0.1948	12.5	0.2058				
2.5	0.295	12.0	0.325	2.5	0.245	12.0	0.275	2.5	0.1418	12.0	0.1288	12.0	0.1418	12.5	0.2058	12.5	0.2058	12.8	0.2078				
2.8	0.279	12.2	0.343	2.8	0.229	12.2	0.293	2.8	0.1418	12.2	0.1288	12.2	0.1418	12.5	0.2058	12.5	0.2058	12.8	0.2078				
3.0	0.269	12.5	0.362	3.0	0.219	12.5	0.312	3.0	0.1418	12.5	0.1288	12.5	0.1418	12.8	0.2058	12.8	0.2058	13.0	0.2078				
3.2	0.262	12.6	0.363	3.2	0.212	12.6	0.313	3.2	0.1448	12.6	0.1288	12.6	0.1458	13.0	0.2058	13.0	0.2058	13.2	0.2078				
3.5	0.252	12.8	0.355	3.5	0.202	12.8	0.305	3.5	0.1458	12.8	0.1288	12.8	0.1458	13.2	0.2058	13.2	0.2058	13.5	0.2078				
3.8	0.246	13.0	0.336	3.8	0.196	13.0	0.286	3.8	0.1458	13.0	0.1288	13.0	0.1458	13.5	0.2058	13.5	0.2058	13.8	0.2078				
4.0	0.244	13.2	0.318	4.0	0.194	13.2	0.268	4.0	0.1418	13.2	0.1288	13.2	0.1418	13.5	0.2058	13.5	0.2058	13.8	0.2078				
4.2	0.242	13.3	0.310	4.2	0.192	13.3	0.260	4.2	0.1378	13.3	0.1288	13.3	0.1378	13.6	0.2058	13.6	0.2058	13.8	0.2078				
4.5	0.241	13.5	0.302	4.5	0.191	13.5	0.252	4.5	0.1308	13.5	0.1288	13.5	0.1308	13.8	0.2058	13.8	0.2058	14.0	0.2078				
4.8	0.241	13.8	0.300	4.8	0.191	13.8	0.250	4.8	0.1248	13.8	0.1288	13.8	0.1248	14.2	0.2058	14.2	0.2058	14.5	0.2078				
5.0	0.241	14.0	0.299	5.0	0.191	14.0	0.249	5.0	0.1218	14.0	0.1288	14.0	0.1218	14.5	0.2058	14.5	0.2058	14.8	0.2078				
5.2	0.241	14.2	0.299	5.2	0.191	14.2	0.249	5.2	0.1198	14.2	0.1288	14.2	0.1198	14.5	0.2058	14.5	0.2058	14.8	0.2078				
5.5	0.242	14.5	0.305	5.5	0.192	14.5	0.250	5.5	0.1208	14.5	0.1288	14.5	0.1208	14.8	0.2058	14.8	0.2058	15.0	0.2078				
5.8	0.243	14.6	0.301	5.8	0.193	14.6	0.251	5.8	0.1218	14.6	0.1288	14.6	0.1218	14.8	0.2058	14.8	0.2058	15.0	0.2078				
6.0	0.244	15.0	0.332	6.0	0.194	15.0	0.252	6.0	0.1228	15.0	0.1288	15.0	0.1228	15.2	0.2058	15.2	0.2058	15.4	0.2078				
6.2	0.246	15.2	0.299	6.2	0.196	15.2	0.252	6.2	0.1238	15.2	0.1288	15.2	0.1238	15.4	0.2058	15.4	0.2058	15.6	0.2078				
6.5	0.248	15.5	0.300	6.5	0.198	15.5	0.255	6.5	0.1248	15.5	0.1288	15.5	0.1248	15.8	0.2058	15.8	0.2058	16.0	0.2078				
6.8	0.250	15.8	0.299	6.8	0.200	15.8	0.256	6.8	0.1258	15.8	0.1288	15.8	0.1258	16.0	0.2058	16.0	0.2058	16.2	0.2078				
7.0	0.252	16.0	0.299	7.0	0.202	16.0	0.257	7.0	0.1258	16.0	0.1288	16.0	0.1258	16.2	0.2058	16.2	0.2058	16.4	0.2078				
7.2	0.253	16.2	0.299	7.2	0.203	16.2	0.258	7.2	0.1258	16.2	0.1288	16.2	0.1258	16.4	0.2058	16.4	0.2058	16.6	0.2078				
7.5	0.255	16.5	0.299	7.5	0.205	16.5	0.259	7.5	0.1258	16.5	0.1288	16.5	0.1258	16.8	0.2058	16.8	0.2058	17.0	0.2078				
7.8	0.260	16.8	0.299	7.8	0.210	16.8	0.260	7.8	0.1268	16.8	0.1288	16.8	0.1268	17.0	0.2058	17.0	0.2058	17.2	0.2078				
8.0	0.263	17.0	0.299	8.0	0.213	17.0	0.262	8.0	0.1278	17.0	0.1288	17.0	0.1278	17.2	0.2058	17.2	0.2058	17.4	0.2078				
8.2	0.266	17.2	0.299	8.2	0.216	17.2	0.264	8.2	0.1278	17.2	0.1288	17.2	0.1278	17.4	0.2058	17.4	0.2058	17.6	0.2078				
8.5	0.274	17.5	0.299	8.5	0.224	17.5	0.265	8.5	0.1298	17.5	0.1288	17.5	0.1298	17.8	0.2058	17.8	0.2058	18.0	0.2078				
8.8	0.284	17.8	0.299	8.8	0.234	17.8	0.266	8.8	0.1318	17.8	0.1288	17.8	0.1318	18.0	0.2058	18.0	0.2058	18.2	0.2078				
9.0	0.292	18.0	0.299	9.0	0.242	18.0	0.267	9.0	0.1338	18.0	0.1288	18.0	0.1338	18.2	0.2058	18.2	0.2058	18.4	0.2078				
9.2	0.294	18.2	0.299	9.2	0.244	18.2	0.268	9.2	0.1358	18.2	0.1288	18.2	0.1358	18.4	0.2058	18.4	0.2058	18.6	0.2078				
9.5	0.282	18.5	0.299	9.5	0.232	18.5	0.269	9.5	0.1368	18.5	0.1288	18.5	0.1368	18.6	0.2058	18.6	0.2058	18.8	0.2078				
9.8	0.259	18.8	0.299	9.8	0.209	18.8	0.270	9.8	0.1348	18.8	0.1288	18.8	0.1348	19.0	0.2058	19.0	0.2058	19.2	0.2078				
10.0	0.240	19.0	0.299	10.0	0.190	19.0	0.271	10.0	0.1318	19.0	0.1288	19.0	0.1318	19.2	0.2058	19.2	0.2058	19.4	0.2078				
10.2	0.226	19.2	0.299	10.2	0.176	19.2	0.272	10.2	0.1298	19.2	0.1288	19.2	0.1298	19.4	0.2058	19.4	0.2058	19.6	0.2078				
10.5	0.216	19.5	0.299	10.5	0.168	19.5	0.273	10.5	0.1278	19.5	0.1288	19.5	0.1278	19.6	0.2058	19.6	0.2058	19.8	0.2078				

† VALUE FOLLOWED BY A "g" IS TYPICAL.

TABLE 13-7. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
GLOBAR, BULK OXIDIZED $T = 2400$											
1.0	0.0498 [†]	10.6	0.0788 [†]	1.0	0.447	9.0	0.016	14.5	0.083		
1.2	0.0528	10.8	0.0818	1.1	0.415	10.0	0.016	14.6	0.076		
1.5	0.0578	11.0	0.0888	1.2	0.387	10.2	0.016	15.0	0.076		
1.6	0.0638	11.2	0.0958	1.3	0.361	10.5	0.017				
2.0	0.0688	11.5	0.1093	1.4	0.336	10.6	0.016				
2.2	0.0748	11.8	0.1248	1.5	0.316	10.8	0.019				
2.5	0.0828	12.0	0.1358	1.6	0.298	11.0	0.022				
2.8	0.0888	12.2	0.1448	1.8	0.262	11.2	0.028				
3.0	0.0918	12.5	0.1553	2.0	0.232	11.4	0.040				
3.2	0.0948	12.8	0.1578	2.2	0.206	11.5	0.049				
3.5	0.0958	13.0	0.1528	2.5	0.174	11.6	0.059				
3.8	0.0958	13.2	0.1468	2.8	0.149	11.7	0.073				
4.0	0.0918	13.5	0.1378	3.0	0.136	11.8	0.091				
4.2	0.0878	13.8	0.1298	3.2	0.125	11.9	0.122				
4.5	0.0808	14.0	0.1253	3.5	0.111	12.0	0.190				
4.8	0.0748	14.2	0.1218	3.8	0.099	12.1	0.298				
5.0	0.0718	14.5	0.1198	4.0	0.092	12.2	0.427				
5.2	0.0698	14.8	0.1178	4.2	0.086	12.3	0.576				
5.5	0.0718	15.0	0.1178	4.5	0.078	12.35	0.653				
5.8	0.0718			4.8	0.072	12.38	0.667				
6.0	0.0728			5.0	0.068	12.40	0.675				
6.2	0.0738			5.2	0.065	12.42	0.678				
6.5	0.0738			5.5	0.061	12.46	0.661				
6.8	0.0728			5.8	0.057	12.5	0.682				
7.0	0.0728			6.0	0.055	12.54	0.681				
7.2	0.0728			7.2	0.047	12.9	0.435				
7.5	0.0738			7.5	0.046	13.0	0.360				
7.8	0.0748			7.8	0.044	13.1	0.289				
8.0	0.0758			8.0	0.044	13.2	0.227				
9.2	0.0858			8.2	0.043	13.3	0.189				
9.5	0.0868			8.5	0.038	13.5	0.147				
9.8	0.0848			8.8	0.032	13.7	0.121				
10.0	0.0818			9.0	0.027	13.8	0.112				
10.2	0.0798			9.2	0.023	14.0	0.100				
10.5	0.0778			9.5	0.017	14.2	0.092				

[†] VALUE FOLLOWED BY A "0" IS TYPICAL.




FIGURE 13-5. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).




FIGURE 13-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE
(WAVELENGTH DEPENDENCE).

TABLE 13-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON MONOCARBIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T10060	Olson, O.H. and Morris, J.C.	1959	0.316-2.70	298		Magnesium carbonate reference standard; $\theta = 9^\circ$, $\omega' = 2\pi$; reported error 4%.
2 T22272	Schatz, E.A., Goldberg, D.M., Pearson, E.G., and Burks, T.L.	1963	0.230-2.64	298	Sample No. 102	Commercially sintered sample from Carborundum; density 2.32 g cm^{-3} ; theoretical density 3.21 g cm^{-3} ; MgO reference standard; data extracted from smooth curve; $\theta = \sim 0^\circ$, $\omega' = 2\pi$.
3 T22272	Schatz, E.A., et al.	1963	0.230-2.65	298	Sample No. 103	Sintered at 2173 K for 1 hr (scatter material SiC); density 1.49 g cm^{-3} ; theoretical density 3.21 g cm^{-3} ; MgO reference standard; data extracted from smooth curve; $\theta = \sim 0^\circ$, $\omega' = 2\pi$.
4 T40308	Imai, A.	1966	15.1-30.1	300	B-166	n-type; single crystal of hexagonal plate; grown in a Ley's type furnace from commercial grade or purified SiC; carrier density at 300 K 1.4×10^{18} cm^{-3} ; measured in argon-nitrogen, incident beam perpendicular to the c-plane; $\theta = \sim 0^\circ$, $\omega' = \sim 0^\circ$. Similar to the above specimen and conditions except carrier density at 300 K 3.9 $\times 10^{17}$ cm^{-3} .
5 T40308	Imai, A.	1966	14.5-32.5	300	B-93	Similar to the above specimen and conditions except carrier density at 300 K 3.9 $\times 10^{17}$ cm^{-3} .
6 T40308	Imai, A.	1966	14.0-31.1	300	B-97	Similar to the above specimen and conditions except carrier density at 300 K 1.2×10^{18} cm^{-3} .
7 T42279	Chang, L.	1965	2.00-29.9	~298		Poly crystalline (Carborundum Co.); $\theta = \sim 0^\circ$, $\omega' = \sim 0^\circ$.
8 T35840	Schatz, E.A., Alvarez, G.H., Counts, C.R., and Hopple, M.A.	1965	0.230-2.65	~298		Black powder from Norton Co.; 98 pure; compacted at 70,500 psi; data extracted from smooth curve; MgO reference standard; $\theta = 0^\circ$, $\omega' = 2\pi$.
9 T35840	Schatz, E.A., et al.	1965	0.230-2.65	~298		Similar to the above specimen and conditions except compacted at 35,250 psi.
10 T35840	Schatz, E.A., et al.	1965	0.230-2.65	~298		Similar to the above specimen and conditions except compacted at 11,750 psi.
11 T35840	Schatz, E.A., et al.	1965	0.230-2.65	~298		Green powder from Norton Co.; 99.4 pure; compacted at 70,500 psi; data extracted from smooth curve; MgO reference standard; $\theta = 0^\circ$, $\omega' = 2\pi$.
12 T35840	Schatz, E.A., et al.	1965	0.230-2.65	~298		Similar to the above specimen and conditions except compacted at 35,250 psi.
13 T35840	Schatz, E.A., et al.	1965	0.230-2.65	~298		Similar to the above specimen and conditions except compacted at 11,750 psi.
14 T37398	Schatz, E.A., Counts, C.R., III, and Burks, T.L.	1964	1.00-15.0	~298		98.1 pure powder from Fisher Scientific Co.; mesh size 320; compacted at 1400 psi with highly polished stainless steel ram; data extracted from smooth curve; converted from reflectance factor; $\theta = 0^\circ$, $\omega' = 2\pi$.
15 T37398	Schatz, E.A., et al.	1964	1.00-15.0	~298		Similar to the above specimen and conditions except compacted at 7000 psi; $\theta = \sim 0^\circ$.
16 T37398	Schatz, E.A., et al.	1964	1.00-15.0	~298		Similar to the above specimen and conditions except compacted at 28,000 psi.
17 T37398	Schatz, E.A., et al.	1964	0.230-2.65	~298		96.1 pure powder (regular crystolon, Norton Co.); particle size 7 μm ; compacted at 23,500 psi with highly polished stainless steel ram; data extracted from smooth curve; MgO reference standard; $\theta = 0^\circ$, $\omega' = 2\pi$.
18 T37398	Schatz, E.A., et al.	1964	0.230-2.65	~298		Similar to the above specimen and conditions except particle size 30 μm ; $\theta = \sim 0^\circ$.
19 T37398	Schatz, E.A., et al.	1964	0.230-2.65	~298		Similar to the above specimen and conditions except particle size 70 μm .
20 T37398	Schatz, E.A., et al.	1964	0.230-2.65	~298		Similar to the above specimen and conditions except particle size 100 μm .
21 T37398	Schatz, E.A., et al.	1964	1.00-15.0	~298		98.1 pure powder (regular crystolon, Norton Co.); particle size 7 μm ; compacted at 42,000 psi with highly polished stainless steel ram; data extracted from smooth curve; converted from reflectance factor; $\theta = 0^\circ$, $\omega' = 2\pi$.

TABLE 13-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON MONOCARBIDE (Wavelength Dependence) (continued)

Cur. Ref. No. No.	Author(s) Counts, C.R., III, and Barks, T.L.	Year 1964	Wavelength Range, μm 1.00-15.0	Temperature Range, K ~298	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
22 T37398	Schatz, E.A., Counts, C.R., III, and Barks, T.L.	1964	1.00-15.0	~298		Similar to the above specimen and conditions except particle size 30 μm ; $\theta = \sim 0^\circ$.
23 T37398	Schitz, E.A., et al.	1964	1.00-15.0	~298		Similar to the above specimen and conditions except particle size 70 μm .
24 T37398	Schitz, E.A., et al.	1964	0.230-2.65	~298		98.1 pure powder. Norton Co.; mesh size 400; compacted with highly polished stainless steel ram; data extracted from smooth curve; MgO reference standard; $\theta = 0^\circ$, $\omega = 2^\circ$.
25 T32222	Spitzer, W.G., E17420 Kleemann, D.A., and Frosch, C.J.	1959	0.95-14	293		β -phase polycrystalline cubic SiC film, 0.05 μm thick; measured by comparing reflected energy from the specimen with that from a good-quality front-surface aluminum mirror; $\theta = 0^\circ$.
26 T32222	Spitzer, W.G., E17420 et al.	1959	11-14	293		Similar to the above except specimen thickness 0.12 μm .
27 T22521	Spitzer, W.G., E17420 Kleemann, D., and Walsh, D.	1959	8.0-15	293		α -II hexagonal, about 3 mm high and larger than 25 mm^2 in basal area; supplied by Exxon Corp.; surface polished, oxidized at 1273 K for 2 hr, then washed by HF; measured for extraordinary ray with electric vector polarized parallel to optic axis (lying in surface); $\theta = \sim 0^\circ$.
28 T32221	Spitzer, W.G., E17420 et al.	1959	2.0-22	293		The above specimen measured for ordinary ray with electric vector polarized perpendicular to optic axis.
29 E3607	Lely, J.A. and Kruger, F.A.	1958	1.0-15	293		Hexagonal; colorless; single crystal; measured with unpolarized light normal to a plane perpendicular to c-axis; data taken from smooth curve; $\theta = 0^\circ$.
30 E17415	Lipson, H.G.	1960	2.77-3.5	293		α -II hexagonal; values calculated from measured transmittance.
31 E17419	Philip, H.R. and Taft, E.A.	1960	0.11-1.2	300		Type 6H hexagonal; data measured by using a vacuum grating monochrometer.
32 T22517	Coblentz, W.W.	1906	0.90-14	293	Carborundum	No details reported.
33 T43162	Wheeler, B.E.	1966	0.096-0.41	293		6H hexagonal single crystal; data taken from smooth curve
34 T43162	Wheeler, B.E.	1966	0.096-0.41	293		β -phase cubic single crystal; data taken from smooth curve.
35 T72208	Purtseidze, I.M. and Khavasi, L.G.	1971	0.18-2.5	300		Type 27R; α -phase; nitrogen doped; 150 to 200 μ thick; mechanically ground and polished; difference between donor and acceptor concentrations $N_D - N_A = 2 \times 10^{17}$ cm^{-3} .
36 T64949	Il'in, M.A., Kucharski, A.A., Rashetskaya, E.P., and Suhashiev, V.K.	1971	6.1-44	293	1	6H hexagonal single crystal; prepared by recrystallization; electrical conductivity 20 to $25 \Omega^{-1} \text{cm}^{-4}$; carrier concentration $1.1 \times 10^{17} \text{ cm}^{-3}$.
37 T64949	Il'in, M.A., et al.	1971	6.0-44	293	4	Similar to the above specimen except electrical conductivity 66 to $71 \Omega^{-1} \text{cm}^{-4}$ and carrier concentration $6.8 \times 10^{18} \text{ cm}^{-3}$.
38 T64949	Il'in, M.A., et al.	1971	6.0-44	293	6	Similar to the above specimen except electrical conductivity 133 to $105 \Omega^{-1} \text{cm}^{-4}$ and carrier concentration $1.36 \times 10^{19} \text{ cm}^{-3}$.

TABLE 13-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 298.$	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 4 (CONT.)*	λ	ρ	CURVE 5 (CONT.)*	λ	ρ	CURVE 7 (CONT.)	λ	ρ	CURVE 8 (CONT.)	λ	ρ	
0.316	0.147	2.45	0.100	22.0	0.405	28.0	0.304	3.10	0.134	0.796	0.171									
0.397	0.149	2.55	0.103	23.0	0.412	28.5	0.300	3.50	0.221	0.964	0.154									
0.600	0.130	2.65	0.103	24.0	0.431	29.0	0.293	3.10	0.279	1.25	0.138									
0.921	0.109			25.0	0.450	29.5	0.291	5.10	0.345	1.76	0.118									
1.33	0.132			26.0	0.445	30.0	0.292	6.00	0.374	2.14	0.111									
1.22	0.102			27.0	0.443	30.5	0.291	7.10	0.375	2.65	0.110									
1.35	0.108			28.0	0.466	31.0	0.291	6.10	0.375											
1.70	0.097			29.1	0.466	31.5	0.291	9.10	0.359											
1.89	0.093			30.1	0.466	32.0	0.291	10.0	0.295											
2.20	0.085			0.270	0.117			32.5	0.291	10.3	0.266									
2.41	0.093			0.290	0.106					10.6	0.536									
2.51	0.089			0.310	0.100					11.0	0.739									
2.71	0.068			0.320	0.094	14.5	0.400			11.5	0.786									
				0.340	0.094	15.0	0.380	14.0	0.440	12.0	0.750									
				0.350	0.095	15.5	0.375	14.5	0.400	13.0	0.631									
				0.379	0.126	16.0	0.347	15.0	0.390	14.0	0.562									
				0.425	0.209	16.5	0.342	15.5	0.375	14.0	0.550									
				0.460	0.220	17.0	0.332	16.0	0.361	15.0	0.530									
				0.648	0.198	17.6	0.326	17.0	0.338	16.0	0.520									
				0.848	0.185	18.0	0.320	18.0	0.333	18.0	0.497									
				0.179	0.179	19.5	0.317	19.0	0.327	19.9	0.486									
				1.25	0.176	19.0	0.313	20.0	0.332	22.0	0.488									
				1.45	0.173	19.4	0.311	21.0	0.332	24.0	0.488									
				1.65	0.169	20.0	0.310	22.0	0.327	26.0	0.488									
				1.85	0.167	20.5	0.306	23.0	0.327	27.9	0.489									
				2.15	0.166	21.6	0.303	24.0	0.327	29.9	0.491									
				2.55	0.170	21.5	0.300	25.0	0.327											
				2.65	0.178	22.0	0.295	26.0	0.327											
				0.104	0.166	22.5	0.300	27.0	0.333											
				0.105	0.166	23.0	0.294	28.0	0.342											
				0.111	0.170	23.5	0.292	29.0	0.336	0.230	0.101									
				0.148	0.170	24.0	0.292	30.0	0.332	0.261	0.086									
				0.152	0.178	22.5	0.300	27.0	0.329	0.280	0.083									
				0.150	0.178	23.0	0.294	28.0	0.342	0.328	0.084									
				0.150	0.178	23.5	0.292	29.0	0.336	0.350	0.093									
				0.134	0.178	24.0	0.292	30.0	0.332	0.253	0.092									
				0.121	0.178	24.5	0.295	31.1	0.334	0.288	0.089									
				0.119	0.178	25.0	0.293			0.323	0.093									
				0.115	0.178	25.5	0.294													
				0.115	0.178	17.1	0.397													
				0.114	0.178	16.0	0.397													
				0.108	0.178	16.0	0.396													
				0.104	0.178	19.0	0.396													
				0.102	0.178	20.1	0.396	27.0	0.293	2.00	0.169									
				0.100	0.178	21.0	0.397	27.5	0.298	2.50	0.145									
				0.150	0.178	23.0	0.294	28.0	0.342	0.230	0.101									
				0.134	0.178	23.5	0.292	29.0	0.336	0.261	0.086									
				0.121	0.178	24.0	0.292	30.0	0.332	0.280	0.083									
				0.119	0.178	24.5	0.295	31.1	0.334	0.328	0.084									
				0.115	0.178	16.0	0.397													
				0.115	0.178	17.1	0.397													
				0.114	0.178	17.1	0.397													
				0.108	0.178	16.0	0.396													
				0.104	0.178	19.0	0.396													
				0.102	0.178	20.1	0.396	27.0	0.293	2.00	0.169									
				0.100	0.178	21.0	0.397	27.5	0.298	2.50	0.145									
				0.150	0.178	23.0	0.294	28.0	0.342	0.230	0.101									
				0.134	0.178	23.5	0.292	29.0	0.336	0.261	0.086									
				0.121	0.178	24.0	0.292	30.0	0.332	0.280	0.083									
				0.119	0.178	24.5	0.295	31.1	0.334	0.328	0.084									
				0.115	0.178	16.0	0.397													
				0.115	0.178	17.1	0.397													
				0.114	0.178	17.1	0.397													
				0.108	0.178	16.0	0.396													
				0.104	0.178	19.0	0.396													
				0.102	0.178	20.1	0.396	27.0	0.293	2.00	0.169									
				0.100	0.178	21.0	0.397	27.5	0.298	2.50	0.145									

* NOT SHOWN IN FIGURE.

CURVE 9
 $T = 298.$

CURVE 10
 $T = 298.$

CURVE 8
 $T = 298.$

CURVE 7
 $T = 298.$

CURVE 6
 $T = 298.$

TABLE 13-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ								
CURVE 10 (CONT.)		CURVE 12 (CONT.)		CURVE 13 (CONT.)		CURVE 14 (CONT.)		CURVE 15 (CONT.)		CURVE 16		CURVE 17 (CONT.)	
1.03	0.108	0.240	0.115	0.356	0.122	0.67	0.442	1.34	0.585	0.327	0.109		
1.31	0.100	0.249	0.105	0.380	0.141	10.1	0.447	13.6	0.575	0.336	0.113		
1.74	0.093	0.268	0.099	0.416	0.232	10.2	0.468	14.5	0.569	0.338	0.119		
2.65	0.086	0.294	0.097	0.438	0.263	10.6	0.560	15.0	0.565	0.349	0.119		
CURVE 11		0.319	0.101	0.495	0.300	11.9	0.718			0.350	0.154		
T = 298.		0.337	0.110	0.532	0.309	12.3	0.745			0.391	0.202		
		0.348	0.117	0.565	0.309	12.5	0.738			0.399	0.228		
		0.353	0.130	0.649	0.299	12.7	0.700			0.444	0.228		
		0.378	0.160	0.733	0.285	12.9	0.655			0.606	0.164		
		0.408	0.231	0.899	0.241	13.1	0.627			0.912	0.154		
		0.432	0.271	1.01	0.270	13.4	0.608			1.01	0.154		
		0.471	0.300	1.04	0.274	13.5	0.602			1.12	0.154		
		0.515	0.314	1.07	0.274	15.0	0.597			1.26	0.132		
		0.561	0.317	1.10	0.279					1.58	0.119		
		0.643	0.307	1.21	0.279					1.81	0.111		
		0.716	0.309	1.34	0.267					2.18	0.107		
		0.910	0.264	1.58	0.248					2.65	0.109		
		1.00	0.290	1.63	0.242	1.00	0.104	10.1	0.317				
		1.10	0.297	1.90	0.234	1.57	0.104	10.2	0.317				
		1.21	0.299	2.19	0.220	2.50	0.147	10.5	0.431				
		1.35	0.282	2.39	0.212	3.48	0.195	10.9	0.482				
		1.46	0.279	2.59	0.208	3.78	0.209	11.5	0.582				
		1.60	0.263	2.65	0.201	4.48	0.267	11.9	0.605				
		1.83	0.253			5.39	0.316	12.6	0.623				
		2.00	0.246			6.18	0.327	12.7	0.593				
		2.23	0.231			6.92	0.368	13.0	0.545				
		2.44	0.224			7.73	0.386	13.2	0.519				
		2.65	0.219	1.00	0.107	8.12	0.386	13.6	0.488				
				1.97	0.107	8.50	0.405	15.0	0.484				
				2.33	0.142	9.51	0.399			0.472	0.182		
				3.30	0.193	10.2	0.422			0.624	0.155		
				3.75	0.213	10.3	0.443			0.687	0.153		
				4.60	0.299	10.4	0.460			0.750	0.141		
				4.98	0.326	10.6	0.530			0.881	0.126		
				5.82	0.349	11.2	0.628			1.04	0.118		
				6.32	0.361	12.1	0.732			1.17	0.116		
				6.64	0.400	12.4	0.735			1.25	0.111		
				7.42	0.424	12.7	0.714			1.33	0.111		
				8.12	0.429	13.0	0.635			1.40	0.107		
				8.62	0.436	13.2	0.604			1.65	0.102		

CURVE 16
 $T = 298.$

CURVE 17
 $T = 298.$

CURVE 18
 $T = 298.$

CURVE 19
 $T = 298.$

CURVE 20
 $T = 298.$

CURVE 21
 $T = 298.$

CURVE 22
 $T = 298.$

CURVE 23
 $T = 298.$

TABLE 13-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 13-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ρ	CURVE 26 $T = 293.$		CURVE 27 (CONT.)		CURVE 28 (CONT.)		CURVE 29 (CONT.)		CURVE 30 $T = 293.$		CURVE 31 (CONT.)*		CURVE 31 (CONT.)*	
9.6	0.022	9.6	0.0	9.96	0.0	8.98	0.0	10.1	0.037	0.121	0.393	0.413	0.219	0.413	0.219
10.59	0.034	10.07	0.0	9.49	0.053	10.2	0.085	10.3	0.123	0.393	0.443	0.215	0.443	0.215	
10.78	0.038	10.19	0.031	9.99	0.011	10.3	0.619	10.4	0.126	0.399	0.475	0.213	0.475	0.213	
10.98	0.045	10.30	0.231	10.09	0.024	10.4	0.786	10.5	0.129	0.404	0.514	0.209	0.514	0.209	
11.08	0.060	10.41	0.716	10.14	0.095	10.5	0.886	10.5	0.131	0.409	0.564	0.207	0.564	0.207	
11.18	0.073	10.52	0.839	10.31	0.533	10.6	0.925	10.6	0.134	0.415	0.620	0.202	0.620	0.202	
11.27	0.083	10.69	0.895	10.38	0.825	10.8	0.956	10.8	0.136	0.422	0.713	0.202	0.713	0.202	
11.39	0.108	11.09	0.925	10.53	0.887	11.2	0.975	11.2	0.140	0.432	0.838	0.199	0.838	0.199	
11.49	0.128	11.19	0.919	11.04	0.914	11.4	0.991	11.4	0.144	0.450	0.984	0.199	0.984	0.199	
11.58	0.168	11.31	0.885	10.97	0.953	12.0	1.000	12.0	0.147	0.473	1.24	0.199	1.24	0.199	
11.78	0.210	11.38	0.940	11.26	0.970	12.4	0.966	12.4	0.150	0.505	1.53	0.202	1.53	0.202	
11.88	0.248	11.51	0.946	11.62	0.976	12.6	0.936	12.6	0.152	0.522	1.73	0.202	1.73	0.202	
11.99	0.327	11.61	0.959	12.04	0.978	12.7	0.781	12.7	0.154	0.531	2.02	0.202	2.02	0.202	
12.09	0.419	11.72	0.961	12.40	0.975	12.8	0.706	12.8	0.156	0.536	2.32	0.202	2.32	0.202	
12.19	0.507	11.93	0.964	12.62	0.912	12.9	0.651	12.9	0.158	0.540	2.62	0.202	2.62	0.202	
12.29	0.623	12.13	0.964	12.66	0.758	13.0	0.619	13.0	0.160	0.541	2.77	0.202	2.77	0.202	
12.38	0.712	12.32	0.964	12.82	0.664	13.1	0.576	13.1	0.162	0.541	2.37	0.173	2.37	0.173	
12.49	0.742	12.51	0.961	13.04	0.580	13.2	0.529	13.2	0.166	0.535	2.22	0.173	2.22	0.173	
12.54	0.741	12.63	0.949	13.51	0.489	13.4	0.500	13.4	0.172	0.526	2.93	0.169	2.93	0.169	
12.59	0.730	12.70	0.891	13.96	0.446	13.6	0.466	13.6	0.176	0.515	5.24	0.181	5.24	0.181	
12.63	0.727	12.80	0.802	14.48	0.415	14.0	0.428	14.0	0.181	0.495	5.78	0.189	5.78	0.189	
12.68	0.721	12.89	0.692	16.00	0.358	14.3	0.386	14.3	0.187	0.470	6.31	0.189	6.31	0.189	
12.78	0.700	13.08	0.607	19.01	0.324	15.0	0.322	15.0	0.193	0.442	7.17	0.187	7.17	0.187	
12.88	0.642	13.21	0.578	22.00	0.303	15.4	0.271	15.4	0.199	0.417	8.03	0.180	8.03	0.180	
12.98	0.571	13.30	0.561	23.00	0.303	15.8	0.271	15.8	0.207	0.389	8.68	0.180	8.68	0.180	
13.09	0.512	13.74	0.482	24.00	0.303	16.2	0.271	16.2	0.213	0.360	9.00	0.178	9.00	0.178	
13.19	0.445	14.47	0.401	25.00	0.379	17.0	0.219	17.0	0.336	0.336	9.36	0.168	9.36	0.168	
13.29	0.403	14.50	0.379	26.00	0.379	17.0	0.229	17.0	0.316	0.316	9.67	0.114	9.67	0.114	
13.38	0.366	14.51	0.366	27.00	0.379	17.0	0.238	17.0	0.299	0.299	9.91	0.082	9.91	0.082	
13.49	0.302	14.52	0.366	28.00	0.379	17.0	0.248	17.0	0.257	0.276	10.21	0.067	10.21	0.067	
13.78	0.248	14.53	0.366	29.00	0.379	17.0	0.268	17.0	0.257	0.276	10.34	0.036	10.34	0.036	
13.99	0.218	14.54	0.366	30.00	0.379	17.0	0.281	17.0	0.259	0.281	10.63	0.021	10.63	0.021	
14.00	0.000	14.55	0.366	31.00	0.379	17.0	0.294	17.0	0.253	0.294	10.75	0.011	10.75	0.011	
14.49	0.047	14.56	0.366	32.00	0.379	17.0	0.310	17.0	0.245	0.310	11.15	0.003	11.15	0.003	
14.50	0.000	14.57	0.366	33.00	0.379	17.0	0.325	17.0	0.235	0.325	11.49	0.000	11.49	0.000	
14.51	0.000	14.58	0.366	34.00	0.379	17.0	0.340	17.0	0.226	0.340	11.71	0.000	11.71	0.000	
14.52	0.000	14.59	0.366	35.00	0.379	17.0	0.356	17.0	0.216	0.356	12.00	0.000	12.00	0.000	
14.53	0.000	14.60	0.366	36.00	0.379	17.0	0.371	17.0	0.206	0.371	12.24	0.000	12.24	0.000	

* NOT SHOWN IN FIGURE.

TABLE 13-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	ρ	CURVE 32 (CONT.)			CURVE 33 (CONT.)*			CURVE 34 (CONT.)*			CURVE 35 (CONT.)*			CURVE 36 (CONT.)		
12.45	0.912	0.182	0.722	0.142	0.392	0.40	0.200	9.5	0.056	38.0	0.259	0.044	40.1	0.260	0.260	0.260
12.75	0.786	0.185	0.722	0.147	0.461	0.49	0.186	9.6	0.044	40.1	0.259	0.035	42.1	0.260	0.260	0.260
12.96	0.629	0.190	0.716	0.148	0.482	0.58	0.171	9.7	0.035	42.1	0.259	0.024	44.1	0.260	0.260	0.260
13.23	0.578	0.197	0.684	0.149	0.510	0.69	0.148	9.8	0.024	44.1	0.259	0.012	44.1	0.260	0.260	0.260
13.41	0.564	0.206	0.640	0.152	0.536	0.80	0.133	9.9	0.012	44.1	0.259	0.003	44.1	0.260	0.260	0.260
13.84	0.551	0.215	0.609	0.155	0.553	0.91	0.113	10.1	0.003	44.1	0.259	0.065	44.1	0.260	0.260	0.260
14.34	0.534	0.223	0.597	0.158	0.572	0.99	0.095	10.2	0.0589	44.1	0.259	0.192	44.1	0.260	0.260	0.260
14.77	0.525	0.225	0.589	0.160	0.589	0.99	0.0779	10.4	0.0779	44.1	0.259	0.133	44.1	0.260	0.260	0.260
15.17	0.517	0.231	0.577	0.162	0.583	1.02	0.0440	10.4	0.037	44.1	0.259	0.092	44.1	0.260	0.260	0.260
15.57	0.501	0.236	0.557	0.163	0.563	1.03	0.0702	10.5	0.0873	44.1	0.259	0.065	44.1	0.260	0.260	0.260
15.97	0.493	0.243	0.543	0.165	0.553	1.06	0.0821	10.7	0.0911	44.1	0.259	0.035	44.1	0.260	0.260	0.260
16.37	0.485	0.252	0.532	0.168	0.542	1.06	0.0883	10.9	0.0935	44.1	0.259	0.095	44.1	0.260	0.260	0.260
16.77	0.477	0.261	0.526	0.172	0.537	1.10	0.0914	11.0	0.0945	44.1	0.259	0.035	44.1	0.260	0.260	0.260
17.17	0.469	0.270	0.520	0.175	0.533	1.14	0.0914	11.2	0.0954	44.1	0.259	0.065	44.1	0.260	0.260	0.260
17.57	0.461	0.276	0.520	0.178	0.525	1.19	0.0825	11.4	0.0960	44.1	0.259	0.035	44.1	0.260	0.260	0.260
17.97	0.453	0.284	0.508	0.186	0.496	1.19	0.0714	11.6	0.0960	44.1	0.259	0.065	44.1	0.260	0.260	0.260
18.37	0.445	0.301	0.501	0.198	0.457	1.23	0.0619	11.8	0.0964	44.1	0.259	0.035	44.1	0.260	0.260	0.260
18.77	0.437	0.331	0.488	0.204	0.448	1.29	0.0529	12.0	0.0964	44.1	0.259	0.065	44.1	0.260	0.260	0.260
19.17	0.429	0.369	0.478	0.207	0.451	1.45	0.0411	12.2	0.0964	44.1	0.259	0.035	44.1	0.260	0.260	0.260
19.57	0.421	0.466	0.469	0.209	0.451	1.56	0.0360	12.5	0.0940	44.1	0.259	0.065	44.1	0.260	0.260	0.260
19.97	0.413	0.413	0.469	0.213	0.439	1.66	0.0329	12.6	0.0914	44.1	0.259	0.035	44.1	0.260	0.260	0.260
20.37	0.405	0.673	0.673	0.217	0.417	1.93	0.0308	12.8	0.0663	44.1	0.259	0.065	44.1	0.260	0.260	0.260
20.77	0.397	0.129	0.668	0.220	0.400	2.06	0.0308	13.0	0.0542	44.1	0.259	0.035	44.1	0.260	0.260	0.260
21.17	0.389	0.132	0.668	0.225	0.380	2.14	0.0308	13.2	0.0485	44.1	0.259	0.065	44.1	0.260	0.260	0.260
21.57	0.381	0.656	0.656	0.232	0.361	2.22	0.0308	13.4	0.0450	44.1	0.259	0.035	44.1	0.260	0.260	0.260
21.97	0.373	0.135	0.642	0.233	0.338	2.28	0.0308	13.6	0.0427	44.1	0.259	0.065	44.1	0.260	0.260	0.260
22.37	0.365	0.138	0.642	0.240	0.338	2.36	0.0316	13.8	0.0412	44.1	0.259	0.035	44.1	0.260	0.260	0.260
22.77	0.357	0.141	0.648	0.248	0.324	2.45	0.0316	14.0	0.0395	44.1	0.259	0.065	44.1	0.260	0.260	0.260
23.17	0.349	0.143	0.659	0.257	0.313	2.52	0.0304	14.2	0.0395	44.1	0.259	0.035	44.1	0.260	0.260	0.260
23.57	0.341	0.674	0.674	0.270	0.313	2.67	0.0304	14.4	0.0350	44.1	0.259	0.065	44.1	0.260	0.260	0.260
23.97	0.333	0.145	0.674	0.277	0.305	2.82	0.0305	14.6	0.0350	44.1	0.259	0.035	44.1	0.260	0.260	0.260
24.37	0.325	0.147	0.701	0.120	0.377	2.98	0.0305	14.8	0.0350	44.1	0.259	0.065	44.1	0.260	0.260	0.260
24.77	0.317	0.149	0.723	0.123	0.396	3.02	0.0304	15.0	0.0350	44.1	0.259	0.035	44.1	0.260	0.260	0.260
25.17	0.309	0.152	0.746	0.126	0.411	3.04	0.0304	15.2	0.0350	44.1	0.259	0.065	44.1	0.260	0.260	0.260
25.57	0.301	0.156	0.773	0.128	0.411	3.17	0.0304	15.4	0.0350	44.1	0.259	0.035	44.1	0.260	0.260	0.260
25.97	0.293	0.159	0.795	0.130	0.405	3.27	0.0304	15.6	0.0350	44.1	0.259	0.065	44.1	0.260	0.260	0.260
26.37	0.285	0.162	0.789	0.132	0.394	3.37	0.0304	15.8	0.0350	44.1	0.259	0.035	44.1	0.260	0.260	0.260
26.77	0.277	0.164	0.770	0.134	0.380	3.46	0.0304	16.0	0.0350	44.1	0.259	0.065	44.1	0.260	0.260	0.260
27.17	0.270	0.166	0.742	0.135	0.358	3.43	0.0267	16.2	0.0262	44.1	0.259	0.035	44.1	0.260	0.260	0.260
27.57	0.262	0.170	0.710	0.137	0.343	3.43	0.0267	16.4	0.0262	44.1	0.259	0.065	44.1	0.260	0.260	0.260
27.97	0.255	0.175	0.723	0.139	0.343	3.43	0.0267	16.6	0.0262	44.1	0.259	0.035	44.1	0.260	0.260	0.260
28.37	0.248	0.178	0.713	0.215	0.354	3.43	0.0267	16.8	0.0262	44.1	0.259	0.035	44.1	0.260	0.260	0.260

* NOT SHOWN IN FIGURE 6

TABLE 13-9. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ
CURVE 37 (CONT.)			
18.9	0.286	11.2	0.799
20.1	0.288	11.4	0.830
22.0	0.298	11.6	0.872
23.9	0.303	11.7	0.890
26.1	0.316	11.8	0.904
28.3	0.327	11.9	0.913
30.2	0.346	12.0	0.929
32.1	0.363	12.1	0.942
34.1	0.380	12.3	0.955
36.2	0.398	12.4	0.960
38.0	0.419	12.5	0.966
40.1	0.441	12.7	0.693
42.0	0.460	12.8	0.616
43.9	0.475	13.0	0.530
CURVE 38 (CONT.)			
$T = 293^\circ\text{K}$			
6.0	0.116	13.4	0.438
6.4	0.113	13.6	0.409
6.8	0.104	13.8	0.386
7.2	0.100	15.0	0.367
7.4	0.099	15.9	0.345
7.6	0.100	17.0	0.327
7.8	0.099	18.1	0.300
8.2	0.096	20.0	0.297
8.4	0.096	22.1	0.322
8.6	0.099	24.1	0.352
8.8	0.099	26.1	0.377
9.0	0.109	28.1	0.409
9.2	0.127	30.1	0.432
9.4	0.163	32.1	0.457
9.6	0.201	34.1	0.483
9.8	0.255	36.0	0.513
10.0	0.319	38.1	0.529
10.2	0.406	40.0	0.550
10.4	0.523	41.9	0.562
10.6	0.656	44.1	0.579
10.8	0.715		
11.0	0.759		

d. Normal Spectral Absorptance (Wavelength Dependence)

Only four sets of data are available. Three of them were measured below 1 μm . The remaining one [T32388] was measured between 0.4 and 2.6 μm for Globar without any detailed description about the specimen.

It is impossible to generate recommended curves from the meager experimental data. However, it is adequate to apply Kirchhoff's law on the Globar and the averagely polished silicon carbide. Hence, the recommended values presented in subsection (a) are repeated here as recommended values for the normal spectral absorptance. The uncertainty of each curve is believed to be the same as that of the emittance.

The recommended and the provisional curves are shown in Figure 13-7 and the experimental curves are shown in Figure 13-8. The recommended and the provisional values, the experimental measurement information, and the experimental data are tabulated in Tables 13-10, 13-11, and 13-12, respectively.

TABLE 13-10. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α
GLOBAR,BULK OXIDIZED $T = 293$																			
1.0	0.901	10.6	0.872	1.0	0.928	10.6	0.899	1.0	0.951	10.6	0.922								
1.2	0.893	10.8	0.869	1.2	0.925	10.8	0.896	1.2	0.948	10.8	0.919								
1.5	0.893	11.0	0.862	1.5	0.920	11.0	0.889	1.5	0.943	11.0	0.912								
1.8	0.887	11.2	0.855	1.8	0.914	11.2	0.882	1.8	0.937	11.2	0.905								
2.0	0.882	11.5	0.841	2.0	0.909	11.5	0.868	2.0	0.932	11.5	0.891								
2.2	0.876	11.8	0.826	2.2	0.903	11.8	0.853	2.2	0.926	11.8	0.876								
2.5	0.868	12.0	0.815	2.5	0.895	12.0	0.842	2.5	0.918	12.0	0.865								
2.8	0.862	12.2	0.806	2.8	0.889	12.2	0.833	2.8	0.912	12.2	0.856								
3.0	0.859	12.5	0.795	3.0	0.886	12.5	0.822	3.0	0.909	12.5	0.845								
3.2	0.856	12.6	0.793	3.2	0.883	12.8	0.823	3.2	0.906	12.8	0.843								
3.5	0.855	13.0	0.798	3.5	0.882	13.0	0.825	3.5	0.905	13.0	0.848								
3.6	0.855	13.2	0.804	3.6	0.882	13.2	0.831	3.6	0.905	13.2	0.854								
4.0	0.859	13.5	0.813	4.0	0.886	13.5	0.840	4.0	0.909	13.5	0.863								
4.2	0.863	13.8	0.821	4.2	0.890	13.8	0.848	4.2	0.913	13.8	0.871								
4.5	0.870	14.0	0.825	4.5	0.897	14.0	0.852	4.5	0.920	14.0	0.875								
4.8	0.876	14.2	0.829	4.8	0.903	14.2	0.856	4.8	0.926	14.2	0.879								
5.0	0.879	14.5	0.831	5.0	0.906	14.5	0.858	5.0	0.929	14.5	0.881								
5.2	0.881	14.8	0.833	5.2	0.908	14.8	0.860	5.2	0.931	14.8	0.883								
5.5	0.880	15.0	0.833	5.5	0.907	15.0	0.860	5.5	0.930	15.0	0.883								
5.8	0.879	15.0		5.8	0.906			5.8	0.929										
6.0	0.878			6.0	0.905			6.0	0.928										
6.2	0.877			6.2	0.904			6.2	0.927										
6.5	0.877			6.5	0.904			6.5	0.927										
6.8	0.878			6.8	0.905			6.8	0.928										
7.0	0.878			7.0	0.905			7.0	0.928										
7.2	0.878			7.2	0.905			7.2	0.928										
7.5	0.877			7.5	0.904			7.5	0.927										
7.8	0.876			7.8	0.903			7.8	0.926										
8.0	0.875			8.0	0.902			8.0	0.925										
8.2	0.873			8.2	0.900			8.2	0.923										
8.5	0.871			8.5	0.898			8.5	0.921										
8.8	0.869			8.8	0.896			8.8	0.919										
9.0	0.867			9.0	0.894			9.0	0.917										
9.2	0.865			9.2	0.892			9.2	0.915										
9.5	0.864			9.5	0.891			9.5	0.914										
9.8	0.866			9.8	0.893			9.8	0.916										
10.0	0.869			10.0	0.896			10.0	0.919										
10.2	0.871			10.2	0.898			10.2	0.921										
10.5	0.873			10.5	0.900			10.5	0.923										

GLOBAR,BULK
OXIDIZED
 $T = 293$ (CONT.)

GLOBAR,BULK
OXIDIZED
 $T = 1400$ (CONT.)

GLOBAR,BULK
OXIDIZED
 $T = 2400$

GLOBAR,BULK
OXIDIZED
 $T = 2400$ (CONT.)

GLOBAR,BULK
OXIDIZED
 $T = 2400$

TABLE 13-10. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α]

λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α	λ	α		
BULK POLISHED $T = 293$																					
		BULK POLISHED $T = 293$ (CONT.)				BULK POLISHED $T = 1000$				BULK POLISHED $T = 1000$ (CONT.)				BULK POLISHED $T = 2400$				BULK POLISHED $T = 2400$ (CONT.)			
1.0	0.597A†	10.6	0.781A†	1.0	0.614A†	10.6	0.798A†	1.0	0.647A†	10.6	0.831A†	10.6	0.826A	10.6	0.826A	10.6	0.826A	10.6	0.826A		
1.2	0.613A	10.8	0.776A	1.2	0.630A	10.8	0.793A	1.2	0.663A	10.8	0.826A	10.8	0.826A	10.8	0.826A	10.8	0.826A	10.8	0.826A		
1.5	0.636A	11.0	0.765A	1.5	0.653A	11.0	0.782A	1.5	0.686A	11.0	0.815A	11.0	0.815A	11.0	0.815A	11.0	0.815A	11.0	0.815A		
1.8	0.658A	11.2	0.749A	1.8	0.675A	11.2	0.766A	1.8	0.708A	11.2	0.799A	11.2	0.799A	11.2	0.799A	11.2	0.799A	11.2	0.799A		
2.0	0.672A	11.5	0.721A	2.0	0.689A	11.5	0.738A	2.0	0.722A	11.5	0.771A	11.5	0.771A	11.5	0.771A	11.5	0.771A	11.5	0.771A		
2.2	0.686A	11.8	0.693A	2.2	0.703A	11.8	0.710A	2.2	0.736A	11.8	0.743A	11.8	0.743A	11.8	0.743A	11.8	0.743A	11.8	0.743A		
2.5	0.705A	12.0	0.675A	2.5	0.722A	12.0	0.692A	2.5	0.755A	12.0	0.725A	12.0	0.725A	12.0	0.725A	12.0	0.725A	12.0	0.725A		
2.8	0.721A	12.2	0.657A	2.8	0.738A	12.2	0.674A	2.8	0.771A	12.2	0.707A	12.2	0.707A	12.2	0.707A	12.2	0.707A	12.2	0.707A		
3.0	0.731A	12.5	0.638A	3.0	0.748A	12.5	0.655A	3.0	0.781A	12.5	0.688A	12.5	0.688A	12.5	0.688A	12.5	0.688A	12.5	0.688A		
3.2	0.738A	12.6	0.637A	3.2	0.755A	12.6	0.654A	3.2	0.788A	12.6	0.687A	12.6	0.687A	12.6	0.687A	12.6	0.687A	12.6	0.687A		
3.5	0.748A	12.8	0.645A	3.5	0.765A	12.8	0.662A	3.5	0.798A	12.8	0.695A	12.8	0.695A	12.8	0.695A	12.8	0.695A	12.8	0.695A		
3.8	0.754A	13.0	0.662A	3.8	0.771A	13.0	0.679A	3.8	0.804A	13.0	0.712A	13.0	0.712A	13.0	0.712A	13.0	0.712A	13.0	0.712A		
4.0	0.756A	13.2	0.682A	4.0	0.773A	13.2	0.699A	4.0	0.806A	13.2	0.732A	13.2	0.732A	13.2	0.732A	13.2	0.732A	13.2	0.732A		
4.2	0.758A	13.3	0.691A	4.2	0.775A	13.3	0.707A	4.2	0.808A	13.3	0.740A	13.3	0.740A	13.3	0.740A	13.3	0.740A	13.3	0.740A		
4.5	0.759A	13.5	0.698A	4.5	0.776A	13.5	0.715A	4.5	0.809A	13.5	0.745A	13.5	0.745A	13.5	0.745A	13.5	0.745A	13.5	0.745A		
4.8	0.759A	13.6	0.700A	4.8	0.776A	13.6	0.717A	4.8	0.809A	13.6	0.750A	13.6	0.750A	13.6	0.750A	13.6	0.750A	13.6	0.750A		
5.0	0.759A	14.0	0.701A	5.0	0.776A	14.0	0.718A	5.0	0.809A	14.0	0.751A	14.0	0.751A	14.0	0.751A	14.0	0.751A	14.0	0.751A		
5.2	0.759A	14.2	0.701A	5.2	0.776A	14.2	0.718A	5.2	0.809A	14.2	0.751A	14.2	0.751A	14.2	0.751A	14.2	0.751A	14.2	0.751A		
5.5	0.758A	14.5	0.700A	5.5	0.775A	14.5	0.717A	5.5	0.808A	14.5	0.750A	14.5	0.750A	14.5	0.750A	14.5	0.750A	14.5	0.750A		
5.8	0.757A	14.8	0.699A	5.8	0.774A	14.8	0.716A	5.8	0.807A	14.8	0.745A	14.8	0.745A	14.8	0.745A	14.8	0.745A	14.8	0.745A		
6.0	0.756A	15.0	0.698A	6.0	0.773A	15.0	0.715A	6.0	0.806A	15.0	0.746A	15.0	0.746A	15.0	0.746A	15.0	0.746A	15.0	0.746A		
6.2	0.755A			6.2	0.771A			6.2	0.804A			6.2	0.804A			6.2	0.804A				
6.5	0.752A			6.5	0.769A			6.5	0.802A			6.5	0.802A			6.5	0.802A				
6.8	0.750A			6.8	0.767A			6.8	0.800A			6.8	0.800A			6.8	0.800A				
7.0	0.748A			7.0	0.765A			7.0	0.798A			7.0	0.798A			7.0	0.798A				
7.2	0.747A			7.2	0.764A			7.2	0.797A			7.2	0.797A			7.2	0.797A				
7.5	0.745A			7.5	0.762A			7.5	0.795A			7.5	0.795A			7.5	0.795A				
7.8	0.740A			7.8	0.757A			7.8	0.790A			7.8	0.790A			7.8	0.790A				
8.0	0.737A			8.0	0.754A			8.0	0.787A			8.0	0.787A			8.0	0.787A				
8.2	0.734A			8.2	0.751A			8.2	0.784A			8.2	0.784A			8.2	0.784A				
8.5	0.726A			8.5	0.747A			8.5	0.776A			8.5	0.776A			8.5	0.776A				
8.8	0.716A			8.8	0.733A			8.8	0.766A			8.8	0.766A			8.8	0.766A				
9.0	0.709A			9.0	0.725A			9.0	0.758A			9.0	0.758A			9.0	0.758A				
9.2	0.706A			9.2	0.723A			9.2	0.758A			9.2	0.758A			9.2	0.758A				
9.5	0.718A			9.5	0.735A			9.5	0.768A			9.5	0.768A			9.5	0.768A				
9.8	0.714A			9.8	0.740A			9.8	0.758A			9.8	0.758A			9.8	0.758A				
10.0	0.760A			10.0	0.777A			10.0	0.810A			10.0	0.810A			10.0	0.810A				
10.2	0.774A			10.2	0.791A			10.2	0.824A			10.2	0.824A			10.2	0.824A				
10.5	0.792A			10.5	0.799A			10.5	0.832A			10.5	0.832A			10.5	0.832A				

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL.




FIGURE 13-7. RECOMMENDED NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).




FIGURE 13-8. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE
(WAVELENGTH DEPENDENCE).

TABLE 13-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTION OF SILICON MONOCARBIDE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T32388	Byrne, R. F. and Manchall, L. N.	1954	0.40-2.60	~298	A	Globar; data extracted from smooth curve; $\theta \approx 0^\circ$.	
2 T57246	Burton, G. V.	1970	0.39-0.80	293	B	Film specimen 0.3 μm thick; deposited on glass at 300 K; electrical resistivity 446, 378, 357, 312, 292, 269, 237, 202, 179, and 163 Ω cm at 295, 303, 308, 315, 322, 328, 337, 346, and 353 K, respectively.	
3 T57246	Burton, G. V.	1970	0.39-0.80	293	C	Film specimen 0.3 μm thick; deposited on glass at 315 K; electrical resistivity 115, 100, 91.2, 83.9, 74.3, 66.7, 63.3, 55.3, 51.3, 42.9, 43.7, 40.5, 37.6, 34.4, 32.6, and 30.8 Ω cm at 294, 300, 303, 310, 314, 320, 323, 328, 333, 335, 342, 349, 354, 358, 362, and 367 K, respectively.	
4 T57246	Burton, G. V.	1970	0.39-0.80	293	D	Film specimen 0.5 μm thick; deposited on glass at 550 K; electrical resistivity 2800, 2180, 1880, 1730, 1570, 1380, 1250, 1150, 1040, 938, 857, 794, 736, 698, 638, and 601 Ω cm at 294, 308, 314, 319, 324, 328, 334, 338, 343, 349, 353, 359, 362, 365, 371, and 376 K, respectively.	

TABLE 13-12. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

	λ	α		λ	α		λ	α
CURVE 1 $T = 298.$	0.400	0.900		0.404	0.994		0.422	0.994
	0.630	0.923		0.452	0.993		0.471	0.988
	0.803	0.921		0.502	0.973		0.523	0.963
	1.01	0.906		0.554	0.924		0.572	0.896
	1.15	0.906		0.603	0.853		0.624	0.796
	1.23	0.922		0.651	0.733		0.674	0.724
	1.33	0.921		0.702	0.686		0.721	0.620
	1.64	0.950		0.755	0.518		0.772	0.503
	1.80	0.950		0.804	0.450			
CURVE 2 $T = 293.$	0.386	0.987		0.386	0.998		0.404	0.998
	0.404	0.987		0.422	0.998		0.442	0.998
	0.422	0.987		0.452	0.998		0.471	0.998
	0.452	0.976		0.498	0.998		0.523	0.995
	0.481	0.957		0.523	0.998		0.554	0.963
	0.504	0.935		0.452	0.998		0.572	0.948
	0.524	0.909		0.471	0.998		0.603	0.722
	0.550	0.867		0.502	0.990		0.624	0.501
	0.571	0.833		0.523	0.985		0.653	0.392
	0.604	0.790		0.554	0.963		0.673	0.840
	0.622	0.754		0.572	0.948		0.707	0.796
	0.651	0.688		0.603	0.722		0.730	0.756
	0.671	0.652		0.624	0.501		0.755	0.708
	0.701	0.572		0.653	0.392		0.776	0.688
	0.724	0.515		0.673	0.668		0.805	0.668
	0.752	0.451		0.707	0.394			
	0.798	0.403						
CURVE 3 $T = 293.$	0.386	0.994						

e. Normal Spectral Transmittance (Wavelength Dependence)

A total of 61 sets of data are available at room temperature. Thirty-one sets were measured below 1 μm and six sets above 15 μm .

Most of the data measured between 1 and 15 μm were for thin specimens with thickness ranging from several μm to over 300 μm and colored from colorless to dark green. A recommended curve applicable to colorless specimen with thickness ranging from 100 to 200 μm is generated following the data of Lipson [E17415] (Figure 13-10, curve 30). The values are typical above 5 μm where a series of peaks and valleys occur. Below 5 μm , the uncertainty is believed to be 10%.

Four sets of data were measured for thin films about 0.1 μm thick or thinner. One curve was generated following the data of Schatz, et al. [T22272] (Figure 13-10, curve 2) for a specimen 0.06 μm thick. The recommended values below 10 μm have an uncertainty of 5%. The values above 10 μm are typical.

The recommended and the typical curves are shown in Figure 13-9 and the experimental curves are shown in Figure 13-10. The recommended and the typical values, the experimental measurement information, and the experimental data are tabulated in Tables 13-13, 13-14, and 13-15, respectively.

TABLE 13-13. RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELLENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ]

λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
THIN, COLORLESS 100-200 μm THICK $T = 293$											
1.0	0.641	6.82	0.4928†	10.8	0.0000†	1.0	0.548	11.5	0.9148†		
1.2	0.643	6.86	0.5328			1.2	0.604	11.6	0.8938		
1.5	0.647	6.95	0.4008			1.5	0.675	11.8	0.8258		
1.8	0.650	7.0	0.1408			1.8	0.734	11.9	0.7628		
2.0	0.653	7.04	0.1018			2.0	0.765	12.0	0.6838		
2.2	0.655	7.1	0.0808			2.2	0.791	12.1	0.5728		
2.5	0.658	7.2	0.0598			2.5	0.822	12.2	0.4458		
2.8	0.660	7.4	0.0298			2.8	0.846	12.3	0.2728		
3.0	0.661	7.5	0.0178			3.0	0.859	12.4	0.1208		
3.2	0.662	7.64	0.0004			3.2	0.871	12.5	0.0558		
3.5	0.662	7.76	0.0004			3.5	0.888	12.5	0.0398		
3.8	0.663	7.8	0.0148			3.8	0.902	12.55	0.0268		
4.0	0.658	7.9	0.0678			4.0	0.909	12.6	0.0428		
4.2	0.655A†	8.0	0.0968			4.2	0.915	12.65	0.0868		
4.5	0.646A	8.05	0.1038			4.5	0.923	12.7	0.1768		
4.8	0.631A	8.1	0.1058			4.8	0.929	12.75	0.2968		
5.0	0.6158	8.2	0.1038			5.0	0.932	12.8	0.3768		
5.2	0.5928	8.3	0.0928			5.2	0.934	12.9	0.4908		
5.4	0.5558	8.5	0.0808			5.5	0.938	13.0	0.5768		
5.5	0.5288	8.6	0.0618			5.6	0.940	13.1	0.6358		
5.6	0.4628	8.9	0.0588			6.0	0.942	13.3	0.7168		
5.8	0.4388	9.0	0.0578			6.2	0.942	13.5	0.7748		
5.8	0.3838	9.1	0.0568			6.5	0.944	13.6	0.8338		
5.7	0.3428	9.2	0.0568			6.6	0.944	14.0	0.862A		
5.75	0.2368	9.3	0.0578			7.0	0.945	14.2	0.881A		
5.8	0.1308	9.4	0.0608			7.5	0.945	14.4	0.893A		
5.82	0.1058	9.5	0.0658			8.0	0.945	14.5	0.897A		
5.36	0.0708	9.58	0.0708			8.5	0.945	14.6	0.899A		
5.9	0.0498	9.62	0.0718			8.8	0.944	14.6	0.903A		
6.0	0.0148	9.64	0.0718			9.0	0.944	15.0	0.902A		
6.2	0.0004	9.68	0.0698			9.5	0.944				
6.26	0.0708	9.75	0.0618			9.8	0.945				
6.32	0.1408	9.8	0.0518			10.0	0.945				
6.39	0.0004	9.86	0.0408			10.5	0.945A†				
6.52	0.0004	9.9	0.0328			10.6	0.945A				
6.6	0.1758	10.0	0.0258			10.8	0.944A				
6.7	0.3408	10.1	0.0118			11.0	0.943A				
6.75	0.4118	10.2	0.0058			11.2	0.938A				
6.8	0.4688	10.6	0.0028			11.4	0.9278				

† VALUE FOLLOWED BY AN "A" IS PROVISIONAL AND BY A "B" IS TYPICAL.




FIGURE 13-9. RECOMMENDED NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE).




FIGURE 13-10. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE
(WAVELENGTH DEPENDENCE).

TABLE 13-14. MEASUREMENT INFORMATION ON THE SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	T32822	Spitzer, W.G., Kleinman, D.A., and Froesch, C.J., et al.	1959	11-14	293		β -phase polycrystalline cubic SiC film 0.04 μm thick; measured by a conventional sample in-sample out technique with a double-pass Perkin Elmer spectrometer; $\theta_1 = \theta_0$.
2	T32822	Spitzer, W.G., et al.	1959	0.95-15	293		Similar to the above except specimen thickness 0.06 μm.
3	T32822	Spitzer, W.G., et al.	1959	11-14	293		Similar to the above except specimen thickness 0.12 μm.
4	E02863	Namba, M.	1957	0.3-1.0	293		p-type colorless single crystal; electrical resistivity $10^4 \Omega$ cm.
5	E02863	Namba, M.	1957	0.4-1.0	293		n-type green single crystal; electrical resistivity $10^2 \Omega$ cm.
6	E02863	Namba, M.	1957	0.4-1.0	293		p-type black single crystal; electrical resistivity 0.1 Ω cm.
7	E03607	Lely, J.A. and Kröger, F.A.	1958	0.38-0.57	293		Hexagonal colorless crystal; 200 μm in thickness; prepared by sublimation at ~2773 K in a stream of pure argon; data taken from smooth curve.
8	E03607	Lely, J.A. and Kröger, F.A.	1958	0.42-0.62	293		From the same batch as the above specimen except surface covered by a thin layer of yellow cubic SiC.
9	E03607	Lely, J.A. and Kröger, F.A.	1958	0.39-0.43	77		Hexagonal; prepared by sublimation in argon; data taken from smooth curve.
10	E03607	Lely, J.A. and Kröger, F.A.	1958	0.40-0.45	292.5		The above specimen.
11	E03607	Lely, J.A. and Kröger, F.A.	1958	0.40-0.45	384		The above specimen.
12	E03607	Lely, J.A. and Kröger, F.A.	1958	0.41-0.46	461		The above specimen.
13	E03607	Lely, J.A. and Kröger, F.A.	1958	0.41-0.47	5.4		The above specimen.
14	E03607	Lely, J.A. and Kröger, F.A.	1958	0.42-0.47	585		The above specimen.
15	E03607	Lely, J.A. and Kröger, F.A.	1958	0.43-0.48	744		The above specimen.
16	E03607	Lely, J.A. and Kröger, F.A.	1958	0.44-0.49	800		The above specimen.
17	E03607	Lely, J.A. and Kröger, F.A.	1956	0.45-0.50	948		The above specimen.
18	E03607	Lely, J.A. and Kröger, F.A.	1958	0.46-0.51	1036		The above specimen.
19	E03607	Lely, J.A. and Kröger, F.A.	1958	0.40-2.4	293	101	$1.5 \times 10^{10} N$; hexagonal; dark green; 135 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 10% N ₂ atm; data taken from smooth curve.
20	E03607	Lely, J.A. and Kröger, F.A.	1958	0.39-6.0	293	103	$2.7 \times 10^{10} N$; hexagonal; green; 97 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 0.1% N ₂ atm; data taken from smooth curve.
21	E03607	Lely, J.A. and Kröger, F.A.	1958	0.39-9.9	293	131	Hexagonal; colorless; ~270 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 0.01% N ₂ atm; data taken from smooth curve.

TABLE 13-14. MEASUREMENT INFORMATION ON THE SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s) No.	Year 1958	Wavelength Range, μm	Temperature K.	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
22 E03607	Lely, J. A. and Kröger, F. A.	1958	0.39-9.9	293	130	Hexagonal; colorless; 230 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 0.001% N ₂ atm; data taken from smooth curve.
23 E03607	Lely, J. A. and Kröger, F. A.	1958	0.39-9.9	293	132	Hexagonal; colorless; 215 μm in thickness; prepared by sublimation at ~2773 K in pure argon; data taken from smooth curve.
24 E03607	Lely, J. A. and Kröger, F. A.	1958	0.36-9.9	293	96	10 ¹⁵ Al; hexagonal; blue; 107 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 0.51% AlCl ₃ atm; data taken from smooth curve.
25 E03607	Lely, J. A. and Kröger, F. A.	1958	0.37-5.8	293	201	5.7 × 10 ¹⁸ Al; hexagonal; blue; 66 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 0.51% AlCl ₃ atm; data taken from smooth curve.
26 E03607	Lely, J. A. and Kröger, F. A.	1958	0.38-9.9	293	98	~10 ¹⁸ Al; hexagonal; light blue; 200 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 0.008% AlCl ₃ atm; data taken from smooth curve.
27 E03607	Lely, J. A. and Kröger, F. A.	1958	0.38-9.9	293	115	Hexagonal; colorless; prepared by sublimation at ~2773 K in pure argon; data taken from smooth curve.
28 E03607	Lely, J. A. and Kröger, F. A.	1958	1.0-10	293	188	~2 × 10 ¹⁸ Al; hexagonal; light blue; 155 μm in thickness; prepared by sublimation at ~2773 K in an Ar + 0.076% AlCl ₃ atm; data taken from smooth curve.
29 E03607	Lely, J. A. and Kröger, F. A.	1958	10-14	293		Cubic; yellow; data taken from smooth curve.
30 E17415	Lipson, H. G.	1960	1.0-25	293	S-25	α-II hexagonal crystal 0.155 mm thick; obtained from General Electric Co.; as grown; measured by the conventional in-out technique; data taken from smooth curve.
31 E17415	Lipson, H. G.	1960	1.0-24	293	S-25	Similar to the above except specimen 0.11 mm thick.
32 E17415	Lipson, H. G.	1960	14-24	293	S-25	Similar to the above except specimen 0.105 mm thick and surface polished.
33 E17415	Lipson, H. G.	1960	14-24	293	S-25	Similar to the above except specimen 0.145 mm thick.
34 E17415	Lipson, H. G.	1960	1.0-5.7	293	R-256	α-II hexagonal crystal 0.27 mm thick; obtained from Westinghouse Research Lab.; measured by the conventional in-out technique; data taken from smooth curve.
35 E17415	Lipson, H. G.	1960	1.0-10	293	R-278	Similar to the above except specimen 0.07 mm thick.
36 E17415	Lipson, H. G.	1960	1.0-11	293		α-II hexagonal; light green crystal 0.007 mm thick; obtained from Norton Co.; measured by the conventional in-out technique; data taken from smooth curve.
37 T35131	Dalven, R.	1965	0.44-0.76	295		β-phase n-type cubic single crystal; <10 ¹⁷ cm ⁻³ each of Al, B, Ca, Fe, and Ni; about 2 mm in diameter and 0.114 mm thick; grown as extension of Kendall's method; polished; measured by the conventional in-out technique with unpolarized light normal to the polished surface 17° to <111> direction.
38 T35131	Dalven, R.	1965	0.44-0.76	351		The above specimen.
39 T35131	Dalven, R.	1965	0.45-0.76	400		The above specimen.
40 T35131	Dalven, R.	1965	0.46-0.76	450		The above specimen.
41 T35131	Dalven, R.	1965	0.46-0.76	499		The above specimen.
42 T35131	Dalven, R.	1965	0.47-0.76	550		The above specimen.
43 T35131	Dalven, R.	1965	0.47-0.76	601		The above specimen.
44 T35131	Dalven, R.	1965	0.48-0.76	652		The above specimen.
45 T35131	Dalven, R.	1965	0.48-0.76	700		The above specimen.

TABLE 13-14. MEASUREMENT INFORMATION ON THE SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
46 T60470	Brame, E. G., Jr., Margrave, J. L., and Meloche, V. W.	1957	2.0-16	293		High-purity; 12 mm diameter × 1 mm thick; measured by KBr disk method; data taken from smooth curve.
47 T32121	Pichugin, I. G. and Pikhkin, A. N.	1966	0.14-0.19	293		6H single crystal; pure; grown at 2723 K; data taken from smooth curve.
48 T32121	Pichugin, I. G. and Pikhkin, A. N.	1966	0.14-0.19	293	171	Similar to the above specimen except 0.0025 B-doped; acceptor concentration $N_A = 2.70 \times 10^{14} \text{ cm}^{-3}$; donor concentration $N_D = 8.1 \times 10^{12} \text{ cm}^{-3}$.
49 T32121	Pichugin, I. G. and Pikhkin, A. N.	1966	0.14-0.19	293	172	Similar to the above specimen except 0.0033 B-doped; N_A and N_D not given.
50 T32121	Pichugin, I. G. and Pikhkin, A. N.	1966	0.14-0.19	293	173	Similar to the above specimen except 0.0037 B-doped; $N_A = 4.40 \times 10^{14} \text{ cm}^{-3}$; $N_D = 4.4 \times 10^{12} \text{ cm}^{-3}$.
51 T32121	Pichugin, I. G. and Pikhkin, A. N.	1966	0.14-0.18	293	175	Similar to the above specimen except 0.001 B-doped; N_A and N_D not given.
52 T65652	Il'lin, M. A., Kosayanova, M. G., Solomin, V. N., Barinov, Yu. V., and Bulynkov, Yu. V.	1971	0.40-1.4	293	D-2-353 P1	6H α-phase p-type single crystal; B-doped; 460 μm thick; obtained by evaporating β-SiC; electrical resistivity $625 \Omega \text{ cm}$; carrier concentration $2.1 \times 10^{14} \text{ cm}^{-3}$.
53 T65652	Il'lin, M. A., et al.	1971	0.46-1.3	293		The above specimen neutron-irradiated by a dose of $3.9 \times 10^{15} \text{ cm}^{-2}$; electrical resistivity $10^3 \Omega \text{ cm}$.
54 T65652	Il'lin, M. A., et al.	1971	0.43-1.4	293	D-2-336 P2	6H α-phase p-type single crystal; B-doped; 310 μm thick; obtained by evaporating β-SiC; electrical resistivity $3C2 \Omega \text{ cm}$; carrier concentration $5.2 \times 10^{14} \text{ cm}^{-3}$.
55 T65652	Il'lin, M. A., et al.	1971	0.45-1.3	293		The above specimen neutron-irradiated by a dose of $2.7 \times 10^{15} \text{ cm}^{-2}$; electrical resistivity $1.2 \times 10^4 \Omega \text{ cm}$; carrier concentration $0.7 \times 10^{14} \text{ cm}^{-3}$.
56 T65652	Il'lin, M. A., et al.	1971	0.40-1.0	293	S-3-273 PM4	6H α-phase p-type single crystal; B-doped; 400 μm thick; obtained by evaporating pure silicon and graphite; electrical resistivity $200 \Omega \text{ cm}$; carrier concentration $4 \times 10^{14} \text{ cm}^{-3}$; data taken from smooth curve.
57 T65652	Il'lin, M. A., et al.	1971	0.40-1.0	293		The above specimen α-irradiated by a dose of $3.6 \times 10^{13} \text{ cm}^{-2}$; electrical resistivity $642 \Omega \text{ cm}$; carrier concentration $2.36 \times 10^{14} \text{ cm}^{-3}$.
58 T63770	Il'lin, M. A., Rashkowskaya, E. P., and Buras, E. M.	1971	15-21	293		6H α-phase n-type single crystal; light polarized parallel to c-axis; data taken from smooth curve.
59 T62770	Il'lin, M. A., et al.	1971	15-21	293		Similar to the above specimen except light polarized perpendicular to c-axis.
60 T63770	Il'lin, M. A., et al.	1971	15-21	293		6H α-phase p-type single crystal; light polarized parallel to c-axis.
61 T63770	Il'lin, M. A., et al.	1971	15-21	293		Similar to the above specimen except light polarized perpendicular to c-axis.

TABLE 13-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, T]

* NOT SHOWN IN FIGURE.

TABLE 13-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 11* $T = 394.$	CURVE 14* $T = 585.$	CURVE 17* $T = 946.$	CURVE 19 (CONT.)	CURVE 20 (CONT.)	CURVE 21 (CONT.)
0.402	0.0	0.417	0.0	0.447	0.0	0.593	0.336
0.406	0.062	0.422	0.046	0.451	0.030	0.603	0.302
0.410	0.149	0.427	0.130	0.456	0.072	0.624	0.291
0.417	0.374	0.430	0.226	0.461	0.163	0.641	0.310
0.425	0.625	0.438	0.560	0.477	0.628	0.705	0.384
0.429	0.721	0.442	0.677	0.483	0.754	0.726	0.393
0.432	0.762	0.447	0.742	0.487	0.816	0.865	0.379
0.437	0.809	0.452	0.794	0.491	0.862	0.973	0.353
0.442	0.843	0.460	0.843	0.494	0.890	1.05	0.326
0.450	0.876	0.471	0.891	0.498	0.914	1.14	0.279
CURVE 12* $T = 461.$		CURVE 15* $T = 744.$		CURVE 18* $T = 1036.$		CURVE 21. $T = 293.$	
0.406	0.0	0.429	0.0	0.457	0.0	1.26	0.198
0.409	0.045	0.433	0.036	0.463	0.038	1.61	0.031
0.414	0.099	0.438	0.096	0.466	0.085	1.95	0.015
0.417	0.181	0.443	0.240	0.471	0.157	2.40	0.0
0.426	0.469	0.454	0.607	0.489	0.644		
0.433	0.667	0.460	0.737	0.492	0.717		
0.437	0.747	0.465	0.807	0.496	0.789		
0.441	0.791	0.470	0.857	0.500	0.844		
0.451	0.861	0.475	0.884	0.512	0.921		
0.460	0.892	0.481	0.911				
CURVE 13* $T = 514.$		CURVE 16* $T = 800.$		CURVE 19 $T = 293.$		CURVE 22. $T = 293.$	
0.410	0.0	0.435	0.0	0.397	0.0	0.407	0.123
0.414	0.042	0.440	0.032	0.420	0.017	0.478	0.036
0.418	0.104	0.444	0.085	0.437	0.033	0.416	0.056
0.423	0.224	0.449	0.191	0.450	0.134	0.489	0.074
0.431	0.496	0.464	0.659	0.461	0.297	0.536	0.574
0.437	0.651	0.469	0.777	0.472	0.382	0.599	0.555
0.441	0.739	0.473	0.822	0.484	0.440	0.646	0.537
0.449	0.806	0.477	0.856	0.500	0.478	0.702	0.535
0.457	0.854	0.481	0.879	0.529	0.495	0.795	0.568
0.467	0.896	0.466	0.903	0.551	0.435	0.836	0.575
						0.887	0.575
						0.566	0.419
						0.973	0.536
						0.562	0.237
						0.973	0.352

* NOT SHOWN IN FIGURE.

TABLE 13-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)

TABLE 13-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 27 (CONT.)		CURVE 28 (CONT.)		CURVE 29 (CONT.)		CURVE 30 (CONT.)		CURVE 31 (CONT.)		CURVE 32*		CURVE 33*	
λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T
5.74	0.2224	5.9	0.266	11.9	0.703	7.52	0.013	5.31	0.614	17.55	0.395	1.0	0.405
5.84	0.141	6.2	0.000	12.1	0.734	7.67	0.0	5.50	0.503	16.18	0.421	1.6	0.036
5.92	0.064	6.3	0.162	12.3	0.786	7.81	0.019	5.64	0.535	16.91	0.435	1.9	0.016
5.99	0.039	6.5	0.000	12.5	0.828	8.07	0.107	5.77	0.441	19.78	0.450	2.5	0.074
6.15	0.0348	6.7	0.153	12.8	0.869	8.77	0.061	5.93	0.132	21.04	0.462	3.0	0.039
6.34	0.011	6.8	0.314	12.9	0.876	9.41	0.056	5.98	0.039	22.58	0.474	3.6	0.000
6.44	0.011	6.9	0.600	13.1	0.899	9.67	0.070	6.07	0.0	24.33	0.480	4.1	0.000
6.50	0.034	7.1	0.410	13.5	0.899	9.88	0.034	6.26	0.0	0.0	0.0	4.6	0.000
6.69	0.445	7.3	0.208	13.7	0.927	10.17	0.015	6.32	0.137	T = 293.	T = 293.	5.0	0.000
6.73	0.455	7.4	0.172	13.8	0.944	10.75	0.0	6.38	0.016	0.0	0.0	5.6	0.000
6.78	0.444	7.6	0.160	14.0	0.953	13.39	0.0	6.53	0.0	0.0	0.0	6.2	0.000
7.00	0.070	7.7	0.111	14.38	0.038	6.86	0.661	14.00	0.074	0.0	0.0	7.0	0.000
7.13	0.029	7.8	0.124	14.84	0.078	6.98	0.303	14.95	0.222	0.0	0.0	7.5	0.000
7.26	0.012	8.0	0.300	14.84	0.139	7.06	0.201	15.31	0.272	0.0	0.0	8.0	0.000
7.48	0.021	8.3	0.417	15.23	0.186	7.13	0.139	15.59	0.307	0.0	0.0	8.5	0.000
7.73	0.016	8.5	0.417	15.60	0.223	7.31	0.170	16.05	0.342	0.0	0.0	9.0	0.000
8.04	0.035	8.6	0.393	16.00	0.255	7.41	0.109	16.28	0.359	0.0	0.0	9.5	0.000
8.34	0.042	8.8	0.368	16.62	0.294	7.50	0.053	16.82	0.380	0.0	0.0	10.0	0.000
8.73	0.034	9.0	0.362	17.25	0.323	7.62	0.026	17.59	0.411	0.0	0.0	10.5	0.000
9.04	0.023	9.2	0.378	17.63	0.344	7.80	0.026	18.18	0.426	0.0	0.0	11.0	0.000
9.36	0.031	9.4	0.395	18.22	0.358	8.05	0.211	18.96	0.439	0.0	0.0	11.5	0.000
9.57	0.031	9.7	0.422	19.02	0.366	8.26	0.193	20.15	0.451	0.0	0.0	12.0	0.000
9.93	0.0	9.8	0.394	20.16	0.374	8.62	0.179	21.75	0.461	0.0	0.0	12.5	0.000
9.9	0.023	9.9	0.301	4.62	0.643	8.74	0.147	22.34	0.462	0.0	0.0	13.0	0.000
10.0	0.185	10.0	0.100	4.85	0.603	8.95	0.131	23.28	0.466	0.0	0.0	13.5	0.000
10.1	0.000	10.3	0.000	4.99	0.616	9.12	0.152	24.12	0.467	0.0	0.0	14.0	0.000
1.0	0.637	1.3	0.699	5.64	0.541	9.49	0.167	0.0	0.0	0.0	0.0	1.6	0.000
1.6	0.554	1.6	0.554	5.73	0.306	9.80	0.123	0.0	0.0	0.0	0.0	2.2	0.000
1.9	0.458	2.5	0.357	10.0	0.964	1.00	0.646	9.90	0.036	0.0	0.0	2.8	0.000
3.0	0.314	10.2	0.964	5.82	0.105	1.03	0.652	10.07	0.016	0.0	0.0	3.4	0.000
3.3	0.281	10.3	0.946	5.95	0.043	2.06	0.655	10.75	0.0	0.0	0.0	4.0	0.000
3.6	0.281	10.5	0.899	6.71	0.349	4.13	0.651	14.29	0.122	0.0	0.0	4.6	0.000
4.1	0.329	10.7	0.863	6.89	0.525	4.33	0.625	14.73	0.191	0.0	0.0	5.1	0.000
5.2	0.434	10.9	0.877	6.99	0.204	4.46	0.647	15.19	0.258	0.0	0.0	5.7	0.000
5.5	0.463	11.0	0.861	7.02	0.074	4.61	0.660	15.63	0.291	0.0	0.0	6.2	0.000
5.7	0.463	11.5	0.742	7.15	0.066	4.90	0.642	16.22	0.333	0.0	0.0	6.8	0.000
5.8	0.432	11.7	0.730	5.06	0.077	5.30	0.644	16.73	0.369	0.0	0.0	7.4	0.000

*NOT SHOWN IN FIGURE.

TABLE 13-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : TRANSMITTANCE, τ)

λ	τ	CURVE 33 (CONT.)*	λ	τ	CURVE 35 (CONT.)	λ	τ	CURVE 36 (CONT.)	λ	τ	CURVE 38 (CONT.)*	λ	τ	CURVE 39 (CONT.)*
19.39	0.414	2.81	0.612	8.00	0.281	8.94	0.102	0.456	0.037	0.642	0.577			
19.98	0.420	3.19	0.607	8.20	0.320	9.54	0.099	0.463	0.058	0.664	0.581			
20.52	0.429	3.54	0.603	8.33	0.299	9.95	0.089	0.470	0.096	0.690	0.592			
21.97	0.439	3.96	0.607	8.68	0.255	10.15	0.063	0.478	0.148	0.721	0.592			
22.97	0.446	4.21	0.604	8.94	0.241	10.30	0.024	0.486	0.217	0.758	0.585			
24.05	0.453	4.29	0.599	9.39	0.268	10.92	0.012	0.495	0.311					
CURVE 34 $T = 293.$		4.43	0.603	9.65	0.301	11.43	0.0	0.505	0.420					
4.56		0.607	9.75	0.262				0.515	0.497					
4.70		0.596	9.82	0.199				0.528	0.533					
5.01		0.599	9.90	0.124				0.543	0.556					
5.21		0.584	9.99	0.055				0.555	0.563					
5.45		0.550	10.15	0.022				0.570	0.570					
5.65		0.499	10.34	0.0				0.585	0.572					
5.73		0.401						0.602	0.581					
5.68		0.302						0.620	0.586					
CURVE 36 $T = 293.$								0.456	0.052					
3.73		0.647	5.96	0.224				0.463	0.086					
3.94		0.647	6.03	0.101				0.470	0.131					
4.06		0.636	6.09	0.046				0.478	0.191					
4.21		0.613	6.15	0.017				0.496	0.274					
4.29		0.565	6.23	0.072				0.496	0.371					
4.30		0.565	6.24	0.168				0.596	0.371					
4.39		0.511	6.29	0.223				0.499	0.469					
4.39		0.549	6.33	0.132				0.404	0.515					
4.39		0.612	6.37	0.039				0.299	0.527					
4.51		0.626	6.37	0.00				0.226	0.540					
4.63		0.612	6.45	0.019				0.00	0.551					
4.74		0.580	6.56	0.037				4.67	0.556					
4.83		0.559	6.62	0.192				0.182	0.567					
4.93		0.578	6.70	0.394				0.167	0.585					
5.10		0.557	6.73	0.543				0.148	0.602					
5.39		0.473	6.79	0.596				0.161	0.621					
5.56		0.417	6.88	0.510				0.137	0.642					
5.70		0.359	6.98	0.399				0.094	0.664					
CURVE 35 $T = 293.$		7.03	0.291	6.34	0.109	6.34	0.109	0.721	0.618					
7.15		0.220	6.49	0.008				0.757	0.627					
7.29		0.247	6.68	0.109				0.757	0.627					
7.40		0.186	6.96	0.113				0.747	0.102					
7.51		0.099	7.67	0.096				0.702	0.102					
7.63		0.069	7.67	0.096				0.795	0.106					
7.64		0.103	7.95	0.106				0.444	0.007					
7.92		0.196	8.43	0.106				0.450	0.018					
CURVE 40* $T = 450.$														
CURVE 41* $T = 499.$														
CURVE 38* $T = 351.$														
CURVE 39* $T = 400.$														

* NOT SHOWN IN FIGURE.

TABLE 13-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T
CURVE 41 (CONT.)*																			
0.621	0.534	0.621	0.535	0.621	0.541	0.621	0.546	0.721	0.541	0.692	0.546	0.641	0.546	0.663	0.549	0.758	0.459	0.758	0.459
0.641	0.535	0.641	0.535	0.641	0.541	0.641	0.546	0.721	0.541	0.692	0.546	0.641	0.546	0.663	0.549	0.758	0.459	0.758	0.459
0.664	0.535	0.664	0.535	0.664	0.541	0.664	0.546	0.721	0.541	0.692	0.546	0.641	0.546	0.663	0.549	0.758	0.459	0.758	0.459
0.692	0.535	0.692	0.535	0.692	0.541	0.692	0.546	0.721	0.541	0.692	0.546	0.641	0.546	0.663	0.549	0.758	0.459	0.758	0.459
0.721	0.535	0.721	0.535	0.721	0.541	0.721	0.546	0.721	0.541	0.723	0.546	0.723	0.546	0.759	0.498	0.759	0.498	0.759	0.498
CURVE 42*		T = 499.		CURVE 43 (CONT.)*		CURVE 43 (CONT.)*		CURVE 44*		CURVE 44*		CURVE 45 (CONT.)*		CURVE 45 (CONT.)*		CURVE 46 (CONT.)*		CURVE 46 (CONT.)*	
0.470	0.020	0.470	0.020	0.478	0.035	0.486	0.064	0.495	0.120	0.495	0.192	0.495	0.222	0.495	0.311	0.520	0.502	0.570	0.502
0.478	0.020	0.478	0.020	0.486	0.035	0.495	0.064	0.495	0.120	0.495	0.192	0.495	0.222	0.495	0.311	0.520	0.502	0.570	0.502
0.486	0.020	0.486	0.020	0.495	0.035	0.495	0.064	0.495	0.120	0.495	0.192	0.495	0.222	0.495	0.311	0.520	0.502	0.570	0.502
0.495	0.020	0.495	0.020	0.504	0.035	0.504	0.064	0.515	0.120	0.504	0.192	0.504	0.222	0.504	0.311	0.520	0.502	0.570	0.502
0.504	0.020	0.504	0.020	0.515	0.035	0.515	0.064	0.524	0.120	0.515	0.192	0.515	0.222	0.515	0.311	0.520	0.502	0.570	0.502
0.527	0.020	0.527	0.020	0.536	0.035	0.536	0.064	0.545	0.120	0.536	0.192	0.536	0.222	0.536	0.311	0.520	0.502	0.570	0.502
0.544	0.020	0.544	0.020	0.553	0.035	0.553	0.064	0.562	0.120	0.553	0.192	0.553	0.222	0.553	0.311	0.520	0.502	0.570	0.502
0.555	0.020	0.555	0.020	0.563	0.035	0.563	0.064	0.572	0.120	0.563	0.192	0.563	0.222	0.563	0.311	0.520	0.502	0.570	0.502
0.570	0.020	0.570	0.020	0.579	0.035	0.579	0.064	0.588	0.120	0.579	0.192	0.579	0.222	0.579	0.311	0.520	0.502	0.570	0.502
0.582	0.020	0.582	0.020	0.591	0.035	0.591	0.064	0.599	0.120	0.591	0.192	0.591	0.222	0.591	0.311	0.520	0.502	0.570	0.502
0.593	0.020	0.593	0.020	0.599	0.035	0.599	0.064	0.604	0.120	0.599	0.192	0.599	0.222	0.599	0.311	0.520	0.502	0.570	0.502
0.604	0.020	0.604	0.020	0.613	0.035	0.613	0.064	0.621	0.120	0.613	0.192	0.613	0.222	0.613	0.311	0.520	0.502	0.570	0.502
0.621	0.020	0.621	0.020	0.630	0.035	0.630	0.064	0.639	0.120	0.630	0.192	0.630	0.222	0.630	0.311	0.520	0.502	0.570	0.502
0.641	0.020	0.641	0.020	0.650	0.035	0.650	0.064	0.659	0.120	0.650	0.192	0.650	0.222	0.650	0.311	0.520	0.502	0.570	0.502
0.663	0.020	0.663	0.020	0.672	0.035	0.672	0.064	0.681	0.120	0.672	0.192	0.672	0.222	0.672	0.311	0.520	0.502	0.570	0.502
0.692	0.020	0.692	0.020	0.701	0.035	0.701	0.064	0.710	0.120	0.701	0.192	0.701	0.222	0.701	0.311	0.520	0.502	0.570	0.502
0.722	0.020	0.722	0.020	0.731	0.035	0.731	0.064	0.740	0.120	0.731	0.192	0.731	0.222	0.731	0.311	0.520	0.502	0.570	0.502
0.756	0.020	0.756	0.020	0.765	0.035	0.765	0.064	0.774	0.120	0.765	0.192	0.765	0.222	0.765	0.311	0.520	0.502	0.570	0.502
CURVE 43*		T = 601.		CURVE 44*		CURVE 45 (CONT.)*		CURVE 45 (CONT.)*		CURVE 46 (CONT.)*		CURVE 46 (CONT.)*		CURVE 47*		CURVE 47*		CURVE 48*	
0.470	0.009	0.470	0.009	0.478	0.021	0.486	0.038	0.495	0.077	0.495	0.134	0.505	0.141	0.486	0.026	0.486	0.026	0.486	0.026
0.478	0.009	0.478	0.009	0.486	0.021	0.495	0.038	0.505	0.077	0.505	0.134	0.515	0.141	0.495	0.027	0.495	0.027	0.495	0.027
0.495	0.009	0.495	0.009	0.505	0.021	0.515	0.038	0.525	0.077	0.525	0.134	0.535	0.141	0.515	0.027	0.515	0.027	0.515	0.027
0.505	0.009	0.505	0.009	0.515	0.021	0.525	0.038	0.535	0.077	0.535	0.134	0.545	0.141	0.525	0.027	0.525	0.027	0.525	0.027
0.515	0.009	0.515	0.009	0.525	0.021	0.535	0.038	0.545	0.077	0.545	0.134	0.555	0.141	0.535	0.027	0.535	0.027	0.535	0.027
0.527	0.009	0.527	0.009	0.537	0.021	0.547	0.038	0.557	0.077	0.557	0.134	0.567	0.141	0.547	0.027	0.547	0.027	0.547	0.027
0.544	0.009	0.544	0.009	0.554	0.021	0.564	0.038	0.574	0.077	0.574	0.134	0.584	0.141	0.564	0.027	0.564	0.027	0.564	0.027
0.562	0.009	0.562	0.009	0.572	0.021	0.582	0.038	0.592	0.077	0.592	0.134	0.602	0.141	0.582	0.027	0.582	0.027	0.582	0.027
0.582	0.009	0.582	0.009	0.592	0.021	0.602	0.038	0.612	0.077	0.612	0.134	0.622	0.141	0.602	0.027	0.602	0.027	0.602	0.027
0.602	0.009	0.602	0.009	0.612	0.021	0.622	0.038	0.632	0.077	0.632	0.134	0.642	0.141	0.622	0.027	0.622	0.027	0.622	0.027
0.622	0.009	0.622	0.009	0.632	0.021	0.642	0.038	0.652	0.077	0.652	0.134	0.662	0.141	0.642	0.027	0.642	0.027	0.642	0.027
0.642	0.009	0.642	0.009	0.652	0.021	0.662	0.038	0.672	0.077	0.672	0.134	0.682	0.141	0.662	0.027	0.662	0.027	0.662	0.027
0.662	0.009	0.662	0.009	0.672	0.021	0.682	0.038	0.692	0.077	0.692	0.134	0.702	0.141	0.682	0.027	0.682	0.027	0.682	0.027
0.682	0.009	0.682	0.009	0.692	0.021	0.702	0.038	0.712	0.077	0.712	0.134	0.722	0.141	0.702	0.027	0.702	0.027	0.702	0.027
0.702	0.009	0.702	0.009	0.712	0.021	0.722	0.038	0.732	0.077	0.732	0.134	0.742	0.141	0.722	0.027	0.722	0.027	0.722	0.027
0.722	0.009	0.722	0.009	0.732	0.021	0.742	0.038	0.752	0.077	0.752	0.134	0.762	0.141	0.742	0.027	0.742	0.027	0.742	0.027
0.742	0.009	0.742	0.009	0.752	0.021	0.762	0.038	0.772	0.077	0.772	0.134	0.782	0.141	0.762	0.027	0.762	0.027	0.762	0.027
0.762	0.009	0.762	0.009	0.772	0.021	0.782	0.038	0.792	0.077	0.792	0.134	0.802	0.141	0.782	0.027	0.782	0.027	0.782	0.027
0.782	0.009	0.782	0.009	0.792	0.021	0.802	0.038	0.812	0.077	0.812	0.134	0.822	0.141	0.802	0.027	0.802	0.027	0.802	0.027
0.802	0.009	0.802	0.009	0.812	0.021	0.822	0.038	0.832	0.077	0.832	0.134	0.842	0.141	0.822	0.027	0.822	0.027	0.822	0.027
0.822	0.009	0.822	0.009	0.832	0.021	0.842	0.038	0.852	0.077	0.852	0.134	0.862	0.141	0.842	0.027	0.842	0.027	0.842	0.027
0.842	0.009	0.842	0.009	0.852	0.021	0.862	0.038	0.872	0.077	0.872	0.134	0.882	0.141	0.862	0.027	0.862	0.027	0.862	0.027
0.862	0.009	0.862	0.009	0.872	0.021	0.882	0.038	0.892	0.077	0.892	0.134	0.902	0.141	0.882	0.027	0.882	0.027	0.882	0.027
0.882	0.009	0.882	0.009	0.892	0.021	0.902	0.038	0.912	0.077	0.912	0.134	0.922	0.141	0.902	0.027	0.902	0.027	0.902	0.027
0.902	0.009	0.902	0.009	0.912	0.021	0.922	0.038	0.932	0.077	0.932	0.134	0.942	0.141	0.922	0.027	0.922	0.027	0.922	0.027
0.922	0.009	0.922	0.009	0.932	0.021	0.942	0.038	0.952	0.077	0.952	0.134	0.962	0.141	0.942	0.027	0.942	0.027	0.942	0.027
0.942	0.009	0.942	0.009	0.952	0.021	0.962	0.038	0.972	0.077	0.972	0.134	0.982	0.141	0.962	0.027	0.962	0.027	0.962	0.027
0.962	0.009	0.962	0.009	0.972	0.021	0.982	0.038	0.992	0.077	0.992	0.134	1.002	0.141	0.982	0.027	0.982	0.027	0.982	0.027
1.002	0.009	1.002	0.009	0.992	0.021	0.982	0.038	0.972	0.077	0.972	0.134	0.962	0.141	0.982	0.027	0.982	0.027	0.982	0.027
0.470	0.009	0.470	0.009	0.478	0.021	0.486	0.038	0.495	0.077	0.495	0.134	0.505	0.141	0.486	0.027	0.486	0.027	0.486	0.027
0.478	0.009	0.478	0.009	0.4															

* NOT SHOWN IN FIGURE 1

TABLE 13-15. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON CARBIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
CURVE 55 $T = 293.$									
0.452	0.123	0.449	0.167	0.449	0.093	19.9	0.257	19.7	0.257
0.499	0.210	0.508	0.167	0.508	0.382	20.0	0.246	19.8	0.246
0.606	0.311	0.556	0.160	0.616	0.399	20.2	0.267	19.9	0.267
0.741	0.351	0.616	0.156	0.722	0.413	20.5	0.402	20.2	0.402
0.803	0.360	0.808	0.152	0.859	0.421	20.6	0.429	20.3	0.429
0.849	0.382	0.859	0.157	0.906	0.425	21.3	0.425	20.5	0.439
0.933	0.407	0.936	0.169	CURVE 59 $T = 293.$		CURVE 61 $T = 293.$			
0.956	0.439	0.965	0.195	0.984	0.206	14.8	0.201	15.1	0.341
1.014	0.465	0.984	0.206	0.999	0.219	15.3	0.212	15.8	0.376
1.345	0.513	1.014	0.237	1.014	0.240	15.8	0.240	16.3	0.406
CURVE 56* $T = 293.$									
0.430	0.0	CURVE 58 $T = 293.$		15.1	0.219	17.0	0.260	17.0	0.433
0.400	0.144	0.408	0.170	15.1	0.219	18.0	0.269	17.7	0.442
0.418	0.186	0.418	0.186	15.2	0.236	18.8	0.274	18.3	0.448
0.430	0.194	0.430	0.194	15.4	0.278	19.5	0.278	19.0	0.458
0.449	0.194	0.449	0.194	15.6	0.319	20.0	0.285	20.0	0.461
0.479	0.189	0.479	0.189	15.7	0.329	CURVE 60 $T = 293.$			
0.528	0.165	0.528	0.165	15.8	0.326	15.4	0.307	15.8	0.323
0.580	0.154	0.580	0.154	15.9	0.322	16.6	0.366	15.5	0.344
0.645	0.141	0.645	0.141	16.4	0.349	17.2	0.395	15.7	0.344
0.703	0.131	0.703	0.131	16.6	0.366	17.8	0.408	16.0	0.339
0.756	0.125	0.756	0.125	16.7	0.366	18.1	0.414	16.2	0.347
0.833	0.125	0.833	0.125	16.9	0.381	18.5	0.414	16.3	0.365
0.880	0.132	0.880	0.132	17.2	0.395	18.8	0.426	16.5	0.386
0.929	0.142	0.929	0.142	17.8	0.408	19.0	0.436	16.7	0.389
0.973	0.150	0.973	0.150	18.1	0.414	19.5	0.445	17.0	0.408
0.996	0.161	0.996	0.161	18.5	0.414	19.7	0.449	17.4	0.424
1.022	0.177	1.022	0.177	18.8	0.406	20.0	0.444	19.1	0.444
CURVE 57* $T = 293.$									
0.399	0.0	19.2	0.384	19.5	0.359	17.0	0.424	17.9	0.436
0.399	0.138	19.6	0.306	19.6	0.245	18.4	0.445	18.4	0.449
0.414	0.153	19.7	0.95	19.7	0.72	19.1	0.449	19.2	0.444

* NOT SHOWN IN FIGURE.

4.14. Silicon Nitride

Bulk silicon nitride is manufactured by standard metallurgical techniques based on reacting silicon powder with nitrogen at elevated temperatures (above 1573 K). It is used as a hard refractory material in high temperature ceramic applications with a useful service temperature of about 1500 K. It dissociates at about 2200 K. It has been reported that there are two types of crystal structure of silicon nitride, $\alpha\text{-Si}_3\text{N}_4$ and $\beta\text{-Si}_3\text{N}_4$, both of which are hexagonal but with different lattice constants in the c-axis [T52257]. Four types of crystructure of Si_3N_4 have also been reported [T29667]. Silicon nitride is a good electrical insulator with reported resistivity of 10^{12} ohm-cm at room temperature and 10^6 ohm-cm at 1300 K. Its thermal expansion coefficient is $2.5 \times 10^{-6} \text{ K}^{-1}$ over the range of 300-1300 K. As a result of this low thermal expansion, its thermal shock resistance is very good so that this bulk material can be used as a high temperature radome material.

Dense silicon nitride is produced by hot pressing and sintering silicon powder compact in a nitrogen atmosphere at high pressure and at a temperature near the melting point of silicon (1687 K). Using this technique, laboratory preparations have resulted in samples of 98% purity.

There is a considerable increase of interest in silicon nitride thin films for microelectronic applications in the recent years. Silicon nitride films can be prepared by several different deposition techniques:

- a) Direct nitridation
- b) Evaporation
- c) Glow discharge (dc and rf)
- d) Sputtering (dc, rf, and reactive)
- e) Pyrolytic (chemical vapor deposition)

The reactive sputtering and pyrolysis methods have been most frequently utilized. In each of these deposition methods, several parameters can be varied: temperature, flow rate, plasma density, pressure or degree of vacuum, ratio of reactants, or electric field. Prior to deposition, the substrates are usually given a mechanical lap followed by a mechanical or chemical polish. Heat treatment of the film is also utilized.

a. Normal Spectral Emittance (Wavelength Dependence)

There is only one set of data on the normal spectral emittance of Si_3N_4 available. Schatz, Goldberg, Pearson, and Burks [T22272] have measured the emittance for the

sintered specimen with density 1.82 g cm^{-3} at 1023 K. Compared with the theoretical density of 3.43 g cm^{-3} , their specimen has very high porosity. Therefore, based on this measurement only provisional values of normal spectral emittance were reported here which are listed in Table 14-1 and shown in Figure 14-1, and they are slightly lower than the experimental results. The estimated uncertainty of the normal spectral emittance is about $\pm 30\%$.

TABLE I-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ	$T = 1023$	$T = 1023$ (CONT.)
SINTERED	SINTERED				
1.03	0.740	11.5	0.604		
1.25	0.692	11.8	0.604		
1.39	0.687	12.0	0.815		
1.81	0.721	12.2	0.633		
2.30	0.776	12.5	0.833		
2.25	0.789	12.6	0.836		
3.00	0.309	12.9	0.632		
3.46	0.839	13.0	0.633		
3.60	0.835	13.5	0.641		
3.83	0.847	14.0	0.841		
4.10	0.853	14.3	0.847		
4.16	0.851	14.5	0.841		
4.25	0.929	14.8	0.844		
4.50	0.335	15.0	0.864		
5.00	0.356				
5.32	0.966				
5.91	0.865				
6.00	0.359				
6.24	0.355				
6.34	0.855				
6.53	0.872				
7.00	0.863				
7.50	0.890				
7.68	0.896				
8.00	0.896				
8.17	0.854				
8.55	0.873				
8.71	0.363				
9.00	0.343				
9.25	0.825				
9.50	0.808				
9.76	0.305				
10.0	0.914				
10.3	0.809				
10.5	0.793				
10.6	0.810				
10.9	0.797				
11.0	0.799				
11.3	0.793				




FIGURE 14-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).




FIGURE 14-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).

TABLE 14-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICON NITRIDE (Wavelength Dependence)

Cur. Ref. No.	Authc(s) No.	Year	Wavelength Range, μm.	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T22272	Schatz, E.A., Goldberg, D.M., Pearson, E.A., and Burks, T.L.	1963	1-1.5	1023		Sintered at 1673 K for 2 hr (settler material Si ₃ N ₄), density 1.82 g cm ⁻³ ; θ°~θ°.

TABLE 14-3. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMMITTANCE, ϵ)

λ	ϵ	CURVE 1 $T = 1023$	λ	ϵ	CURVE 1 (CONT.)
1.00	0.820		11.4	0.877	
1.25	0.772		11.5	0.894	
1.39	0.763		11.6	0.894	
1.81	0.801		12.0	0.905	
2.08	0.864		12.2	0.923	
2.25	0.876		12.5	0.923	
2.98	0.899		12.6	0.929	
3.46	0.929		12.9	0.925	
3.60	0.925		13.5	0.934	
3.73	0.935		14.0	0.934	
4.16	0.946		14.3	0.941	
4.25	0.921		14.5	0.934	
4.49	0.928		14.8	0.933	
5.32	0.962		15.0	0.960	
5.91	0.964				
6.60	0.953				
6.21	0.962				
6.34	0.950				
6.50	0.969				
7.01	0.975				
7.50	0.978				
7.68	0.984				
8.00	0.984				
6.17	0.949				
8.55	0.970				
8.64	0.960				
8.71	0.970				
9.51	0.896				
9.72	0.895				
9.95	0.904				
10.0	0.923				
10.3	0.899				
10.4	0.905				
10.5	0.829				
10.6	0.911				
10.9	0.865				
11.1	0.887				
11.2	0.878				
11.3	0.886				

b. Normal Spectral Reflectance (Wavelength Dependence)

There are ten sets of experimental data available for the wavelength dependence of the normal spectral reflectance of silicon nitride as listed in Table 14-6 and shown in Figure 14-4. Specimen characterization and measurement information for the data are given in Table 14-5. Schatz, Goldberg, Pearson, and Burks [T22272] measured the normal spectral reflectance for sintered samples in the 0.23-2.65 μm wavelength region while Schatz [T34908] and Schatz, Alvarez, Counts, and Hepplu [T35840] measured the normal spectral reflectance of compacted powder specimen with compaction pressure from 2350 psi to 70 500 psi in the 0.23-2.65 μm region. Schatz, Alvarez, Burkes, Counts, and Dunkerley [T33974] measured the reflectance for the specimen pressed at 21 000 psi in the 1.0-15 μm wavelength region at 373 K. It is observed that for the sintered specimen, the reflectance data values were lower than those of the pressed samples. One possible explanation is that it has lower density (1.82 g cm^{-3}), hence a lower reflectance value. Since all the measurements were made by the same research group, only one set of data is available for the longer wavelength region. As a consequence, only provisional values are justified. The provisional values are for the pressed specimen at 373 K which are listed in Table 14-4 and shown in Figure 14-3. The estimated uncertainty for the provisional values is within $\pm 30\%$.

TABLE I4-4. PREVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ]

λ	ρ	λ	ρ
COMPACTED POWDER $T = 373$		COMPACTED POWDER $T = 373$ (CONT.)	
0.23	0.225	13.50	0.301
0.30	0.324	14.00	0.301
0.40	0.353	14.50	0.301
0.50	0.368	15.00	0.296
0.60	0.393		
0.75	0.418		
0.80	0.425		
0.87	0.441		
1.00	0.429		
1.25	0.405		
1.50	0.379		
1.75	0.347		
2.00	0.315		
2.50	0.293		
2.55	0.272		
2.80	0.243		
3.00	0.241		
3.25	0.241		
3.50	0.237		
3.80	0.233		
4.00	0.231		
4.50	0.225		
5.00	0.200		
5.50	0.183		
6.00	0.192		
6.50	0.195		
7.00	0.203		
7.50	0.200		
8.00	0.195		
8.50	0.204		
9.00	0.254		
9.50	0.279		
10.00	0.297		
10.50	0.310		
11.00	0.309		
11.50	0.303		
12.00	0.307		
12.50	0.302		
13.00	0.306		




FIGURE 14-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).




FIGURE 14-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).

TABLE 14-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s) No.	Year 1963	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T22272	Schatz, E.A.; Goldberg, D.M., Pearson, F.G., and Burks, T.L.	1963	0.23-2.65	293	No. 106	Sintered at 1673 K for 2 hr; density 1.82 g cm^{-3} ; MgO reference standard; data extracted from smooth curve; $\theta=0^\circ$, $\omega=2\pi$.
2 T34908	Schatz, E.A.	1966	0.23-2.65	293		Compacted Si_3N_4 powder; compaction pressure 2350 psi; measurements will be performed on a Beckman DK-2A Spectrorereflectometer U.S. MgO standards; $\theta=0^\circ$, $\omega=2\pi$.
3 T34906	Schatz, E.A.	1966	0.23-2.65	293		Similar to the above specimen except compaction pressure 11800 psi.
4 T34908	Schatz, E.A.	1966	0.23-2.65	293		Similar to the above specimen except compaction pressure 15500 psi.
5 T34906	Schatz, E.A.	1966	0.23-2.65	293		Similar to the above specimen except compaction pressure 70500 psi.
6 T35840	Schatz, E.A., Alvarez, G.H., Counts, C.H., III, and McPeople, M.A.	1965	0.23-2.65	298		Specimen was Si_3N_4 powders compacted into stainless steel circular sample holder under compaction pressure 2350 psi; measurements U.S. MgO standard; $\theta=0^\circ$, $\omega=2\pi$.
7 T35840	Schatz, E.A., et al.	1965	0.23-2.65	298		Similar to the above specimen except compaction pressure 11750 psi.
8 T35840	Schatz, E.A., et al.	1965	0.23-2.65	298		Similar to the above specimen except compaction pressure 35250 psi.
9 T35840	Schatz, E.A., et al.	1965	0.23-2.65	298		Similar to the above specimen except compaction pressure 70500 psi.
10 T33974	Schatz, E.A., Alvarez, G.H., Burks, T.L., Counts, C.R., III, and Durberley, F.J.	1964	1-15	373		Pressed Si_3N_4 powder specimen; pressed at 21000 psi; the absolute spectral reflectance are measured by using a blackbody reflectometer apparatus; $\theta=0^\circ$, $\omega=2\pi$.

TABLE 14-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ]

λ	ρ	CURVE 1 $T = 298.$	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 6 (CONT.)	λ	ρ	CURVE 7 (CONT.)	λ	ρ	CURVE 9 (CONT.)	λ	ρ
0.230	0.200	0.404	0.357	0.275	0.313	0.242	0.239	1.05	0.423	0.262	0.279	0.230	0.257	1.33	0.384	0.278	0.310	0.234	0.278
0.240	0.209	0.486	0.381	0.287	0.327	0.250	0.257	1.33	0.384	0.257	0.278	0.243	0.284	1.62	0.351	0.293	0.324	0.251	0.284
0.250	0.220	0.646	1.407	0.302	0.330	0.260	0.284	1.62	0.351	0.351	0.351	0.349	0.334	0.302	1.91	0.322	0.308	0.331	0.349
0.266	0.249	0.874	0.442	0.450	0.365	0.280	0.316	2.15	0.300	0.300	0.318	0.442	0.326	0.283	2.42	0.350	0.341	0.360	0.381
0.280	0.265	1.14	0.429	0.651	0.396	0.290	0.326	2.42	0.283	0.283	0.350	0.411	0.411	0.411	2.65	0.262	0.361	0.381	0.381
0.290	0.274	1.64	0.367	0.748	0.419	0.309	0.332	2.65	0.262	0.262	0.483	0.483	0.483	0.483	2.98.	0.262	0.360	0.381	0.381
0.306	0.276	1.87	0.347	0.691	0.422	0.330	0.336	3.01	0.300	0.300	0.483	0.483	0.483	0.483	3.24.	0.262	0.360	0.381	0.381
0.321	0.276	2.15	0.324	1.04	0.419	0.350	0.337	3.24.	0.300	0.300	0.568	0.568	0.568	0.568	3.49.	0.262	0.360	0.381	0.381
0.331	0.275	2.41	0.311	1.24	0.390	0.399	0.344	3.49.	0.300	0.300	0.721	0.721	0.721	0.721	3.73.	0.262	0.360	0.381	0.381
0.350	0.275	2.59	0.311	1.64	0.345	0.464	0.376	3.73.	0.300	0.300	0.815	0.815	0.815	0.815	4.00.	0.262	0.360	0.381	0.381
0.370	0.268	2.65	0.312	2.03	0.306	0.580	0.378	4.00.	0.300	0.300	0.899	0.899	0.899	0.899	4.24.	0.262	0.360	0.381	0.381
0.449	0.330	0.333	0.333	2.26	0.290	0.714	0.403	4.24.	0.300	0.300	1.04	1.04	1.04	1.04	4.49.	0.262	0.360	0.381	0.381
0.550	0.330	0.651	0.315	2.41	0.280	0.893	0.411	4.49.	0.300	0.300	2.51	2.51	2.51	2.51	4.75.	0.262	0.360	0.381	0.381
0.849	3.288	0.259	0.259	2.65	0.281	0.912	0.411	4.75.	0.300	0.300	2.79	2.79	2.79	2.79	5.00.	0.262	0.360	0.381	0.381
1.04	0.259	0.230	0.219	2.65	0.281	1.05	0.403	5.00.	0.300	0.300	2.86	2.86	2.86	2.86	5.24.	0.262	0.360	0.381	0.381
1.24	0.234	0.243	0.231	2.65	0.281	1.57	0.334	5.24.	0.300	0.300	2.93	2.93	2.93	2.93	5.49.	0.262	0.360	0.381	0.381
1.44	0.209	0.266	0.275	2.65	0.281	2.01	0.287	5.49.	0.300	0.300	3.08	3.08	3.08	3.08	5.75.	0.262	0.360	0.381	0.381
1.54	0.201	0.279	0.312	2.65	0.281	2.43	0.262	5.75.	0.300	0.300	3.18	3.18	3.18	3.18	6.00.	0.262	0.360	0.381	0.381
1.64	0.192	0.313	0.335	2.65	0.281	2.65	0.254	6.00.	0.300	0.300	3.41	3.41	3.41	3.41	6.24.	0.262	0.360	0.381	0.381
1.74	0.192	0.349	0.337	2.65	0.281	3.00	0.242	6.24.	0.300	0.300	4.11	4.11	4.11	4.11	6.49.	0.262	0.360	0.381	0.381
1.85	0.182	0.439	0.362	2.65	0.281	3.55	0.250	6.49.	0.300	0.300	4.83	4.83	4.83	4.83	6.75.	0.262	0.360	0.381	0.381
2.04	0.180	0.547	0.410	2.65	0.281	4.00	0.243	6.75.	0.300	0.300	5.56	5.56	5.56	5.56	7.00.	0.262	0.360	0.381	0.381
2.14	0.177	0.821	0.438	2.65	0.281	4.50	0.242	7.00.	0.300	0.300	6.15	6.15	6.15	6.15	7.24.	0.262	0.360	0.381	0.381
2.35	0.177	1.03	0.434	2.65	0.281	5.00	0.235	7.24.	0.300	0.300	6.90	6.90	6.90	6.90	7.49.	0.262	0.360	0.381	0.381
2.54	0.177	1.19	0.412	2.65	0.281	5.57	0.235	7.49.	0.300	0.300	7.62	7.62	7.62	7.62	7.75.	0.262	0.360	0.381	0.381
2.61	0.181	1.64	0.355	2.65	0.281	6.04	0.235	7.75.	0.300	0.300	8.32	8.32	8.32	8.32	8.50.	0.262	0.360	0.381	0.381
2.65	0.180	1.84	0.340	2.65	0.281	6.42	0.235	8.00.	0.300	0.300	9.09	9.09	9.09	9.09	8.24.	0.262	0.360	0.381	0.381
2.65	0.180	2.15	0.312	2.65	0.281	6.80	0.235	8.24.	0.300	0.300	9.37	9.37	9.37	9.37	8.50.	0.262	0.360	0.381	0.381
2.54	0.177	2.28	0.301	2.65	0.281	7.33	0.235	8.50.	0.300	0.300	9.70	9.70	9.70	9.70	8.75.	0.262	0.360	0.381	0.381
2.54	0.177	2.54	0.298	2.65	0.281	7.74	0.235	8.75.	0.300	0.300	10.14	10.14	10.14	10.14	9.00.	0.262	0.360	0.381	0.381
2.65	0.180	3.00	0.280	2.65	0.281	8.08	0.235	9.00.	0.300	0.300	10.50	10.50	10.50	10.50	9.24.	0.262	0.360	0.381	0.381
2.30	0.226	0.226	0.226	2.65	0.281	8.49	0.235	9.24.	0.300	0.300	10.75	10.75	10.75	10.75	9.50.	0.262	0.360	0.381	0.381
2.42	0.226	0.261	0.261	2.65	0.281	8.84	0.235	9.50.	0.300	0.300	11.00	11.00	11.00	11.00	9.75.	0.262	0.360	0.381	0.381
2.55	0.261	0.324	0.324	2.65	0.281	9.19	0.235	9.75.	0.300	0.300	11.25	11.25	11.25	11.25	10.00.	0.262	0.360	0.381	0.381
2.66	0.261	0.335	0.335	2.65	0.281	9.54	0.235	10.00.	0.300	0.300	11.50	11.50	11.50	11.50	10.24.	0.262	0.360	0.381	0.381
2.55	0.255	0.343	0.343	2.65	0.281	9.84	0.235	10.24.	0.300	0.300	11.75	11.75	11.75	11.75	10.50.	0.262	0.360	0.381	0.381
2.55	0.255	0.349	0.349	2.65	0.281	10.14	0.235	10.50.	0.300	0.300	12.00	12.00	12.00	12.00	10.75.	0.262	0.360	0.381	0.381
2.30	0.230	0.231	0.231	2.65	0.281	10.44	0.235	10.75.	0.300	0.300	12.25	12.25	12.25	12.25	11.00.	0.262	0.360	0.381	0.381
2.43	0.243	0.241	0.241	2.65	0.281	10.74	0.235	11.00.	0.300	0.300	12.50	12.50	12.50	12.50	11.25.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	11.04	0.235	11.25.	0.300	0.300	12.75	12.75	12.75	12.75	11.50.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	11.34	0.235	11.50.	0.300	0.300	13.00	13.00	13.00	13.00	11.75.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	11.64	0.235	11.75.	0.300	0.300	13.25	13.25	13.25	13.25	12.00.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	11.94	0.235	12.00.	0.300	0.300	13.50	13.50	13.50	13.50	12.25.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	12.24	0.235	12.25.	0.300	0.300	13.75	13.75	13.75	13.75	12.50.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	12.54	0.235	12.50.	0.300	0.300	14.00	14.00	14.00	14.00	12.75.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	12.84	0.235	13.00.	0.300	0.300	14.25	14.25	14.25	14.25	13.00.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	13.14	0.235	13.25.	0.300	0.300	14.50	14.50	14.50	14.50	13.25.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	13.44	0.235	13.50.	0.300	0.300	14.75	14.75	14.75	14.75	13.50.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	13.74	0.235	13.75.	0.300	0.300	15.00	15.00	15.00	15.00	13.75.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	14.04	0.235	14.00.	0.300	0.300	15.25	15.25	15.25	15.25	14.00.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	14.34	0.235	14.25.	0.300	0.300	15.50	15.50	15.50	15.50	14.25.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	14.64	0.235	14.50.	0.300	0.300	15.75	15.75	15.75	15.75	14.50.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	14.94	0.235	14.75.	0.300	0.300	16.00	16.00	16.00	16.00	14.75.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	15.24	0.235	15.00.	0.300	0.300	16.25	16.25	16.25	16.25	15.00.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	15.54	0.235	15.25.	0.300	0.300	16.50	16.50	16.50	16.50	15.25.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	15.84	0.235	15.50.	0.300	0.300	16.75	16.75	16.75	16.75	15.50.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	16.14	0.235	15.75.	0.300	0.300	17.00	17.00	17.00	17.00	15.75.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	16.44	0.235	16.00.	0.300	0.300	17.25	17.25	17.25	17.25	16.00.	0.262	0.360	0.381	0.381
2.55	0.255	0.275	0.275	2.65	0.281	16.74	0.235	16.25.	0.300	0.300	17.50	17.50	17.50	17					

TABLE 14-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ]

λ ρ
 CURVE 10 (CONT.)

5.61	0.191
5.94	0.191
6.16	0.195
6.49	0.195
6.77	0.203
7.39	0.206
7.82	0.200
8.03	0.195
8.33	0.195
8.55	0.204
8.69	0.228
8.79	0.243
8.94	0.254
9.20	0.266
9.48	0.278
9.70	0.287
10.00	0.297
10.19	0.301
10.40	0.309
10.62	0.312
10.92	0.312
11.15	0.308
11.38	0.308
11.92	0.312
11.98	0.307
12.41	0.302
12.84	0.302
12.95	0.306
13.16	0.306
13.31	0.301
14.15	0.301
14.38	0.304
14.51	0.301
14.87	0.302
15.00	0.296

c. Normal Spectral Absorptance (Wavelength Dependence)

There are four sets of experimental data available for the wavelength dependence of the normal spectral absorptance of silicon nitride as listed in Table 14-9 and shown in Figure 14-5. Specimen characterization and measurement information for the data are given in Table 14-8. Three sets of data are for the thin film specimen coating on silicon substrate and one set of data is for the powder specimen. All the measurements were performed at room temperature. They all show a broad peak of absorption with the maximum near the 10-12 μm region. However, there is no information on the thickness of the sample and substrate which is essentially for the absorptance value. Therefore, we cannot make any recommended values for the absorptance on coating specimens. According to Kirchhoff's law, the absorptance is equal to the emittance, $\alpha = \epsilon$. Therefore, the provisional values on the normal spectral absorptance for sintered specimens at 1023 K were obtained which are listed in Table 14-7 and shown in Figure 14-6. The estimated uncertainty is about $\pm 30\%$.

TABLE 14-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	λ	α	λ	α	λ	α
SINTERED		SINTERED		SINTERED		SINTERED	
$T = 1023$		$T = 1023$ (CONT.)		$T = 1023$		$T = 1023$	
1.00	0.740	11.5	0.804	1.00	0.740	11.5	0.804
1.25	0.592	11.3	0.804	1.25	0.592	11.3	0.804
1.39	0.687	12.0	0.815	1.39	0.687	12.0	0.815
1.81	0.721	12.2	0.833	1.81	0.721	12.2	0.833
2.00	0.778	12.5	0.833	2.00	0.778	12.5	0.833
2.25	0.789	12.6	0.836	2.25	0.789	12.6	0.836
3.20	0.805	12.9	0.832	3.20	0.805	12.9	0.832
3.46	0.839	13.3	0.833	3.46	0.839	13.3	0.833
3.60	0.835	13.5	0.841	3.60	0.835	13.5	0.841
3.83	0.847	14.3	0.841	3.83	0.847	14.3	0.841
4.00	0.850	14.3	0.847	4.00	0.850	14.3	0.847
4.16	0.851	14.5	0.841	4.16	0.851	14.5	0.841
4.25	0.829	14.6	0.844	4.25	0.829	14.6	0.844
4.50	0.835	15.0	0.864	4.50	0.835	15.0	0.864
5.00	0.850			5.00	0.850		
5.32	0.865			5.32	0.865		
5.91	0.966			5.91	0.966		
6.30	0.853			6.30	0.853		
6.21	0.866			6.21	0.866		
6.34	0.355			6.34	0.355		
6.50	0.872			6.50	0.872		
7.00	0.868			7.00	0.868		
7.50	0.390			7.50	0.390		
7.68	0.396			7.68	0.396		
8.00	0.896			8.00	0.896		
8.17	0.854			8.17	0.854		
8.55	0.873			8.55	0.873		
8.71	0.363			8.71	0.363		
9.00	0.343			9.00	0.343		
9.25	0.925			9.25	0.925		
9.50	0.805			9.50	0.805		
9.76	0.805			9.76	0.805		
10.0	0.814			10.0	0.814		
10.3	0.809			10.3	0.809		
10.5	0.793			10.5	0.793		
10.6	0.840			10.6	0.840		
10.9	0.797			10.9	0.797		
11.0	0.799			11.0	0.799		
11.3	0.798			11.3	0.798		




FIGURE 14-5. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE).




FIGURE 14-6. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE
(WAVELENGTH DEPENDENCE).

TABLE 14-6. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (Wavelength Dependence)

Cur. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	E 46853	Bartnicki, I.N., Ayunoo, B.M., and Kuryliva, R.G.	1970	6-25	~293	Si_3N_4 on Si	Silicon nitride film was deposited on silicon by electrolysis in liquid ammonia with a constant voltage applied to the cell; the film resistivity was of the order of 10^9 $\Omega\cdot\text{cm}$; a UR-10 spectrophotograph was used to obtain the absorption spectra.
2	E 3-318	Badcock, F.R., Lamb, D.R., and Wood, S.S.	1967	8.5-14.5	~293	Silicon nitride film was deposited on silicon substrate by reacting together ammonia and silane or trichlorosilane vapor; data were extracted from the smooth curve; $\theta \sim 0^\circ$.	
3	E 2A316	Badcock, F.R., et al.	1967	8.5-14.5	~293	Silicon nitride crystalline film was grown thermally at 1300 C in ammonia at atm pressure; data were extracted from the smooth curve; $\theta \sim 0^\circ$.	
4	E 3-318	Badcock, F.R., et al.	1967	8.5-14.5	~293	Silicon nitride powder; data were extracted from the smooth curve; $\theta \sim 0^\circ$.	

TABLE 14-9. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)

λ	α	CURVE 1 (CONT.)	λ	α	CURVE 2 $T = 293.$	λ	α	CURVE 3 (CONT.)	λ	α	CURVE 3 (CONT.)	λ	α	CURVE 4 (CONT.)
6.11	0.429	13.09	0.213	13.21	0.176	8.45	0.262	9.16	0.353	14.12	0.257	10.46	0.570	
6.35	0.497	13.32	0.122	6.61	0.277	9.32	0.374	14.37	0.255	10.56	0.569			
6.44	0.493	13.44	0.083	8.73	0.289	9.41	0.403	14.58	0.255	10.66	0.587			
5.55	0.400	13.55	0.064	8.93	0.303	9.55	0.413	14.77	0.252	10.75	0.587			
6.67	0.414	13.74	0.052	9.07	0.318	9.78	0.413	10.83	0.256	11.14	0.576			
6.74	0.414	14.10	0.052	9.22	0.336	9.78	0.413	10.98	0.256	11.07	0.557			
6.64	0.408	14.31	0.035	9.36	0.355	9.91	0.400	11.07	0.257	11.14	0.535			
7.15	0.498	14.60	0.025	9.43	0.375	10.06	0.389	0.07	0.099	11.12	0.255			
7.39	0.415	14.64	0.020	9.60	0.395	10.12	0.403	0.12	0.099	11.22	0.255			
7.64	0.425	15.64	0.030	9.69	0.409	10.31	0.417	8.18	0.110	11.27	0.259			
7.84	0.452	15.20	0.065	9.78	0.431	10.46	0.447	8.26	0.110	11.34	0.492			
8.13	0.489	15.31	0.225	9.88	0.455	10.53	0.455	8.31	0.120	11.38	0.460			
9.33	0.521	15.41	0.303	9.99	0.475	10.63	0.479	8.38	0.125	11.48	0.466			
6.53	0.549	15.60	0.405	10.08	0.503	10.66	0.497	8.44	0.142	11.66	0.446			
8.83	0.368	15.75	0.442	10.25	0.540	10.71	0.511	8.50	0.148	11.72	0.455			
8.92	0.602	16.00	0.468	10.37	0.570	10.78	0.519	8.55	0.160	11.78	0.458			
9.16	0.663	16.16	0.323	10.52	0.596	10.85	0.519	8.67	0.168	11.81	0.441			
9.26	0.663	16.29	0.223	10.66	0.618	11.01	0.511	8.85	0.206	11.86	0.420			
9.36	0.543	16.31	0.157	10.81	0.631	11.19	0.527	8.90	0.228	12.00	0.393			
9.56	0.581	16.45	0.114	10.95	0.641	11.31	0.527	8.94	0.234	12.03	0.364			
9.63	0.502	16.61	0.082	11.17	0.652	11.48	0.506	9.03	0.270	12.30	0.317			
9.77	0.439	16.92	0.064	11.35	0.657	11.63	0.511	9.11	0.301	12.39	0.292			
9.84	0.497	17.36	0.064	11.76	0.657	11.63	0.521	9.15	0.326	12.61	0.266			
9.99	0.396	17.86	0.032	11.98	0.640	11.72	0.532	9.23	0.366	12.94	0.237			
10.20	0.409	18.49	0.006	12.08	0.626	11.75	0.565	9.30	0.380	13.14	0.220			
10.41	0.428	19.16	0.011	12.33	0.574	11.82	0.553	9.37	0.410	13.30	0.203			
10.63	0.428	20.28	0.045	12.77	0.492	11.92	0.499	9.63	0.445	13.37	0.188			
10.87	0.417	21.65	0.109	13.04	0.425	12.00	0.441	9.69	0.445	13.44	0.178			
10.99	0.398	22.62	0.109	13.39	0.367	12.17	0.409	9.74	0.428	13.59	0.162			
11.12	0.365	23.31	0.095	13.83	0.314	12.21	0.392	9.78	0.398	13.67	0.155			
11.29	0.315	23.81	0.060			12.36	0.369	9.63	0.398	14.18	0.134			
11.42	0.292	24.27	0.026			12.41	0.353	9.89	0.423	14.49	0.121			
11.88	0.265	24.81	0.012			12.53	0.321	9.95	0.453			0.113		
12.14	0.285	25.38	0.051			12.64	0.307	10.07	0.473					
12.39	0.274	25.77	0.104			12.60	0.298	10.10	0.496					
12.53	0.273	25.97	0.181			13.07	0.292	10.17	0.506					
12.58	0.263					13.14	0.285	10.22	0.519					
12.72	0.237					13.51	0.280	10.29	0.535					
13.00	0.229					13.91	0.278	10.37	0.543					

d. Normal Spectral Transmittance (Wavelength Dependence)

There are 33 sets of experimental data available for the wavelength dependence of the normal spectral transmittance of silicon nitride as listed in Table 14-12 and shown in Figure 14-8 for the thin film coatings and Figure 14-9 for the powder specimens. Specimen characterization and measurement information are given in Table 14-11. All the measurements were performed at room temperature (~ 293 K) and a broad absorption peak due to Si-N has a maximum near $11.4 \mu\text{m}$.

Silicon, germanium, molybdenum, graphite, gallium arsenide, graphite, and potassium chloride were used as the coating substrate. Fifteen sets of experimental data were measured for the transmittance of thin Si_3N_4 film coating on silicon substrates. However, few authors have reported the thickness of the film and substrate. The various deposition techniques for preparation of the thin films also affect the transmittance. The silicon nitride film was also used as an antireflection coating for silicon and the maximum of transmission was dependent on the thickness of the coating by the well-known square-root condition for quarter-wave films as follows:

$$4n_1 d\lambda_0^{-1} = 2m + 1; m = 0, 1, 2, 3, \dots \quad (14-1)$$

$$R_{\min} \approx \left(\frac{n_2 - n_1^2}{n_2 + n_1^2} \right) \ll 1 \text{ for } n_1^2 \approx n_2 \quad (14-2)$$

where d is the coating thickness, λ_0 the free space wavelength, R_{\min} the minimum intensity reflectance, and n_1 and n_2 are the refractive indices of the coating and substrate, respectively. Therefore, as a consequence of these difficulties, only the provisional values for a $0.5 \mu\text{m}$ thick silicon nitride film deposited on both sides of a $250 \mu\text{m}$ thick silicon substrate by the reactive sputtering technique at room temperature are presented. The estimated uncertainty is within $\pm 30\%$.

TABLE 14-10. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	COATING SI SUBSTRATE $T = 293$	λ	COATING SI SUBSTRATE $T = 293$ (CONT.)
1.06	0.259	7.50	0.592
1.38	0.446	8.00	0.557
1.16	0.750	8.50	0.413
1.19	0.854	9.00	0.282
1.24	0.951	9.73	0.241
1.26	0.976	10.00	0.172
1.30	0.993	10.50	0.128
1.34	0.973	11.00	0.110
1.40	0.925	11.40	0.097
1.44	0.945	11.60	0.098
1.50	0.757	12.00	0.098
1.57	0.563	12.35	0.109
1.62	0.625	13.03	0.116
1.66	0.594	13.50	0.133
1.73	0.565	14.00	0.180
1.78	0.546	14.50	0.210
1.87	0.535	15.00	0.243
1.93	0.536		
2.05	0.542		
2.10	0.562		
2.29	0.614		
2.39	0.645		
2.57	0.723		
2.80	0.835		
3.00	0.897		
3.20	0.923		
3.50	0.986		
3.65	0.954		
3.83	0.993		
4.30	0.981		
4.25	0.962		
4.50	0.933		
4.75	0.395		
5.00	0.856		
5.25	0.223		
5.50	0.771		
5.70	0.722		
6.40	0.665		
7.00	0.612		




FIGURE 14-7. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE COATINGS (WAVELENGTH DEPENDENCE).




FIGURE 14-8. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE COATINGS (WAVELENGTH DEPENDENCE).




FIGURE 14-9. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE POWDERS (WAVELENGTH DEPENDENCE).

TABLE 14-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T45177	Bean, K.E., Glein, P.S., Yeakly, R.L., and Runyan, W.R.	1967	0.2-0.4	293	Si_3N_4 film was deposited on fused silica substrate; index of refraction 2.0; no absorption band between 0.4 and 8 μ ; $\theta \sim 0^\circ$.	
2 T45177	Bean, K.E., et al.	1967	8-24	293	Similar to the above specimen.	
3 T45954	Seki, H. and Moriyama, K.	1967	2.5-16	293	Si_3N_4 film was deposited on GaAs substrate by reacting SiCl_4 and NH_3 in N_2 atm at 823 K; $\theta \sim 0^\circ$.	
4 T45954	Seki, H. and Moriyama, K.	1967	2.5-16	293	Similar to the above specimen except deposited on Si substrate by reacting SiCl_4 and NH_3 in N_2 atm at 823 K.	
5 T45954	Seki, H. and Moriyama, K.	1967	2.5-16	293	Similar to the above specimen except at 723 K.	
6 T48136	Sugano, T., Hirai, K., Kurokawa, K., and Itoh, K.	1968	7-12	293	Si_3N_4 film was deposited on Si substrate by gas phase reaction of SiH_4 and NH_3 , using N_2 as carrier gas at 1123 K; $\theta \sim 0^\circ$.	
7 T72572	Nuttall, R., Bowbrougham, C., and Eastwood, E.	1967	3-15	293	1 μm thickness Si_3N_4 films were deposited on 10 Ω cm N-type Si substrate at 1273 K by thermal reaction of NH_3 with SiH_4 , SiCl_4 , or SiBr_4 ; $\theta \sim 0^\circ$.	
8 T61411	Laff, R.A.	1971	1.8-2.6	293	0.245 μm film of silicon nitride was coated on both sides of Ge window (3840 μm thickness) by rf-diode reactive sputtering technique; $\theta \sim 0^\circ$.	
9 T61411	Laff, R.A.	1971	1.0-2.2	293	Similar to the above specimen except 0.140 μm film of silicon nitride was coated on both side of Si window (750 μm thickness).	
10 T61411	Laff, R.A.	1971	0.9-2.3	293	Similar to the above specimen except 0.220 μm film of silicon nitride was coated on both side of GaAs window (190 μm thickness).	
11 T61411	Laff, R.A.	1971	1-15	293	Similar to the above specimen except 0.505 μm film of silicon nitride was coated on both side of Si window (250 μm thickness).	
12 T65344	Kamchata, M.I., and Ormont, B.F.	1971	6.67-20	293	Poly-crystalline Si_3N_4 was coated on p-type Si single crystal substrate by reaction of ammonia with the silicon substrate at 1623 K for 18 min; $\theta \sim 0^\circ$.	
13 T65344	Kamchata, M.I., and Ormont, B.F.	1971	6.67-20	293	Similar to the above specimen except it was prepared for 60 min.	
14 T65344	Kamchata, M.I., and Ormont, B.F.	1971	6.67-20	293	Similar to the above specimen except it was prepared for 180 min.	
15 T74942	Berg, D., Lewis, D.W., Dakin, T.W., and Pappoito, J.N.	1966	2.5-50	293	Si_3N_4 film was deposited on graphite substrate by pyrolysis of SiF_4 and 2NH_3 ; $\theta \sim 0^\circ$.	
16 T74942	Berg, D., et al.	1966	2.5-50	293	Similar to the above specimen except amorphous Si_3N_4 film was deposited on graphite substrate by pyrolysis of SiH_4 and NH_3 .	
17 T70779	Kijima, K., Steraka, N., Ishii, M., and Tanaka, H.	1973	2.5-25	293	α - Si_3N_4 Polycrystalline Si_3N_4 film was deposited on Si substrate in 15 min at 1473 K; $\theta \sim 0^\circ$.	

TABLE 14-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s) and Co., C.M.	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
18 T70731	Mazdiyasi, K.S. and Cooke, C.M.	1973	2.5-50	293	$\alpha\text{-Si}_3\text{N}_4$	Si_3N_4 powder prepared by ammonolysis of SiCl_4 and calcined at 1573 K for 2 hr in vacuum; a 1 mg of the nitride was dispersed in 400 mg of anhydrous spectrographic grade CsI Powder and pressed into disks for infrared studies; $\theta\sim 0^\circ$. Similar to the above specimen except it was calcined at 1563 K for 2 hr in vacuum.
19 T70731	Mazdiyasi, K.S. and Cooke, C.M.	1973	7.4-50	293	$\alpha\text{-Si}_3\text{N}_4$	Si_3N_4 film was sputtering on KCl substrate by pyrolysis of SiH_4 and NH_3 at 823 K. Similar to the above specimen.
20 T71496	Buck, J.	1973	2-15	293	$\alpha\text{-Si}_3\text{N}_4$	Similar to the above specimen.
21 T71496	Buck, J.	1973	2-15	293	$\alpha\text{-Si}_3\text{N}_4$	Similar to the above specimen.
22 T71498	Buck, J.	1973	2-15	293	$\alpha\text{-Si}_3\text{N}_4$	Similar to the above specimen.
23 E9770	Kaiser, W. and Thurmond, C.D.	1959	3.5-15	~293	$\alpha\text{-Si}_3\text{N}_4$ powder was contained in KBr pellet; data were extracted from the smooth figure.	A morphous silicon nitride film was applied to the mechanically polished p-type silicon wafer by means of reaction between silane and ammonia at 1000 C, and then was tempered in dry nitrogen for 10 min at 1200 C; data were extracted from the smooth curve; $\theta\sim 0^\circ$.
24 F42663	Franz, I. and Langbeinrich, W.	1965	9-14	~293	$\alpha\text{-Si}_3\text{N}_4$	Silicon nitride coating was deposited on Mo substrate by pyrolysis of silane and ammonia at reduced pressure; infrared spectra (Nujol) was extracted from the figure; $\theta\sim 0^\circ$.
25 E27385	Lewis, D.W., Epsto, J.N., Dakin, T.W., and Berg, D.	1966	2.5-15	~293	Sample 104-114	Similar to the above specimen.
26 F27955	Lewis, D.W., et al.	1966	2.5-15	~293	Sample 104-112	Similar to the above specimen except large area of well crystallized $\alpha\text{-Si}_3\text{N}_4$ plus some amorphous were formed.
27 E27953	Lewis, D.W., et al.	1966	2.5-4.0	~293	Sample 118-140	Similar to the above specimen.
28 T32764	Kuwano, Yukinov'	1968	7.7-15	~293	$\alpha\text{-Si}_3\text{N}_4$	Silicon nitride film was deposited on 10 $\Omega\text{-cm}$ N-type silicon wafer by the glow discharge reaction of SiH_4 and NH_3 ; data were extracted from the smooth curve; $\theta\sim 0^\circ$.
29 F32764	Kuwano, Yukinov'	1968	7.7-15	~293	$\alpha\text{-Si}_3\text{N}_4$	Silicon nitride film was deposited on 10 $\Omega\text{-cm}$ N-type silicon wafer by the glow discharge reaction of SiH_4 and N_2 ; data were extracted from the smooth curve; $\theta\sim 0^\circ$.
30 E27192	Doo, V.Y., Nichols, D.R., and Silvey, G.A.	1966	2.5-30	~293	$\alpha\text{-Si}_3\text{N}_4$	Silicon nitride film was deposited on silicon substrate by pyrolytic process by react silane and ammonia in the pressure of excess hydrogen; data were extracted from the smooth curve; $\theta\sim 0^\circ$.
31 E27192	Doo, V.Y., et al.	1966	2.5-30	~293	$\alpha\text{-Si}_3\text{N}_4$	Similar to the above specimen except it was annealed at 1160 C for 3 hr in N_2 atm.
32 E27192	Doo, V.Y., et al.	1966	2.5-30	~293	$\alpha\text{-Si}_3\text{N}_4$	Similar to the above specimen.

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELLENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, T]

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	T	CURVE 5 (CONT.)	CURVE 10 $T = 293.$	CURVE 11 (CONT.)	CURVE 11 (CONT.)	CURVE 12 (CONT.)	CURVE 13 $T = 293.$
2.035	0.930	1.000	0.912	1.6596	0.5940	11.6145	0.560
2.062	0.930	0.560	0.921	1.7250	0.5660	12.2462	0.556
2.095	0.929	0.721	0.312	1.7824	0.5400	12.8529	0.443
2.153	0.916	0.933	0.525	1.8664	0.5360	13.5519	0.453
2.216	0.902	1.112	0.689	1.9323	0.5360	13.8995	0.458
2.267	0.888	1.208	0.771	2.0277	0.5450	15.4170	0.472
2.323	0.879	1.299	0.850	2.1038	0.5620	16.0694	0.475
2.371	0.866	1.339	0.874	2.2083	0.5960	17.0216	0.478
2.428	0.856	1.379	0.901	2.2900	0.6110	18.0717	0.478
2.504	0.841	1.413	0.920	2.3933	0.6450	20.3704	0.487
1.453	0.941	2.5704	0.7230	2.7925	0.8650	10.73	0.485
1.502	0.959	2.9648	0.8600	3.0903	0.7000	10.98	0.486
1.550	0.970	1.606	0.976	3.2137	0.9290	7.05	0.486
1.700	0.978	3.3113	0.9490	7.09	0.581	11.22	0.485
1.762	0.972	3.4190	0.9680	7.14	0.574	11.31	0.485
1.819	0.961	3.5075	0.9800	7.23	0.569	11.36	0.486
1.899	0.946	3.6475	0.9930	7.35	0.566	11.56	0.487
1.960	0.930	2.036	0.912	3.8107	0.9930	7.40	0.487
2.150	0.882	2.150	0.882	4.0551	0.9810	7.46	0.486
2.284	0.843	2.284	0.843	4.2756	0.9620	7.63	0.486
1.003	0.000	1.003	0.000	4.5186	0.9370	7.76	0.486
1.048	0.560	1.762	0.972	4.7373	0.8950	7.80	0.486
1.054	0.721	1.819	0.961	5.2461	0.8230	7.87	0.486
1.063	0.796	1.899	0.946	6.0395	0.7220	7.99	0.486
1.074	0.847	1.960	0.930	6.3660	0.6750	8.08	0.486
1.087	0.874	2.036	0.912	6.9343	0.5310	8.20	0.486
1.097	0.890	2.150	0.882	8.0107	0.9930	8.40	0.486
1.113	0.919	2.284	0.843	8.4551	0.9160	8.53	0.486
1.130	0.934	2.338	0.934	8.7370	0.8730	8.67	0.486
1.144	0.943	2.406	0.943	9.0950	0.8250	8.80	0.486
1.160	0.951	2.481	0.951	9.4516	0.7750	8.93	0.486
1.184	0.951	2.560	0.951	9.8166	0.7250	9.07	0.486
1.220	0.934	2.640	0.934	10.1816	0.6750	9.20	0.486
1.266	0.912	2.720	0.912	10.5566	0.6350	9.33	0.486
1.324	0.885	2.800	0.885	10.9316	0.5950	9.47	0.486
1.393	0.860	2.880	0.860	11.3066	0.5560	9.60	0.486
1.494	0.822	2.965	0.8540	11.6805	0.4620	9.73	0.486
1.565	0.794	3.048	0.9280	12.0545	0.4070	9.87	0.486
1.694	0.754	3.238	0.9560	12.4286	0.2650	10.00	0.486
1.839	0.710	3.618	0.9760	12.7926	0.1400	10.14	0.486
1.983	0.674	3.972	1.0000	13.1566	0.0920	10.28	0.486
2.142	0.631	4.348	0.9730	13.5206	0.2050	10.42	0.486
1.4380	0.8660	1.3964	0.9260	13.8946	0.0925	10.56	0.486
1.4962	0.7570	1.4380	0.8460	14.2686	0.1400	10.70	0.486
1.5740	0.6630	1.4962	0.7570	14.6426	0.1280	10.84	0.486

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ]

λ	τ	CURVE 13(CONT.)		CURVE 14(CONT.)		CURVE 14(CONT.)		CURVE 15(CONT.)		CURVE 15(CONT.)		CURVE 16 $T = 293.$	
11.74	0.366	6.06	0.420	12.74	0.322	3.60	0.354	7.79	0.441	2.50	0.218		
11.92	0.351	6.19	0.418	12.90	0.350	3.62	0.377	6.01	0.414	2.61	0.229		
12.08	0.403	6.28	0.421	13.00	0.368	3.64	0.390	6.44	0.325	2.70	0.244		
12.21	0.437	6.28	0.419	13.09	0.364	3.67	0.363	6.68	0.270	2.95	0.280		
12.36	0.464	6.49	0.416	13.25	0.381	3.70	0.385	6.83	0.270	3.05	0.280		
12.53	0.473	6.56	0.406	13.46	0.383	3.75	0.385	9.29	0.227	3.11	0.293		
12.71	0.483	6.63	0.414	13.59	0.393	3.85	0.440	9.51	0.232	3.16	0.297		
13.02	0.483	6.66	0.409	13.83	0.387	3.92	0.474	9.79	0.220	3.22	0.307		
13.30	0.478	6.75	0.406	13.97	0.390	4.01	0.511	10.15	0.215	3.28	0.308		
13.51	0.471	6.80	0.411	14.10	0.363	4.07	0.525	10.30	0.200	3.31	0.289		
13.61	0.464	6.89	0.395	14.18	0.394	4.19	0.525	10.72	0.200	3.34	0.265		
14.68	0.460	6.94	0.404	14.18	0.387	4.24	0.548	11.10	0.215	3.37	0.151		
14.16	0.450	6.98	0.402	14.45	0.390	4.37	0.548	11.42	0.230	3.38	0.026		
14.33	0.446	9.35	0.394	14.58	0.372	4.69	0.599	11.71	0.230	3.44	0.020		
14.41	0.434	9.43	0.395	14.71	0.360	5.00	0.642	12.72	0.290	3.52	0.031		
14.66	0.424	9.47	0.389	14.79	0.356	5.28	0.667	13.30	0.323	3.55	0.031		
		9.62	0.389	14.90	0.342	5.44	0.682	13.87	0.284	3.52	0.031		
		9.81	0.382	15.06	0.338	5.54	0.693	14.04	0.368	3.54	0.020		
		10.00	0.368	15.22	0.340	5.70	0.706	14.20	0.426	3.55	0.020		
		10.28	0.347	15.38	0.337	5.74	0.695	14.95	0.480	3.58	0.350		
		10.40	0.326			5.79	0.710	15.27	0.480	3.60	0.376		
		10.60	0.313			6.15	0.724	16.26	0.529	3.62	0.394		
		10.67	0.286			6.44	0.724	16.26	0.546	3.65	0.204		
		10.82	0.281			6.55	0.704	16.56	0.541	3.69	0.387		
		7.13	0.398			6.63	0.681	17.48	0.579	3.72	0.402		
		7.16	0.407			6.69	0.624	16.59	0.579	3.76	0.402		
		7.19	0.412			6.80	0.034	19.01	0.548	3.80	0.417		
		7.21	0.410			6.85	0.015	19.96	0.455	4.06	0.473		
		7.24	0.413	11.01	0.231	2.50	0.354	6.93	0.058	21.55	0.434		
		7.27	0.409	11.11	0.232	2.50	0.354	6.93	0.058	23.36	0.487		
		7.32	0.416	11.30	0.216	2.54	0.364	7.01	0.498	26.18	0.536		
		7.38	0.509	11.43	0.198	2.65	0.367	7.12	0.581	27.03	0.529		
		7.42	0.420	11.56	0.192	2.68	0.375	7.17	0.560	27.93	0.563		
		7.46	0.412	11.64	0.220	2.76	0.387	7.28	0.073	28.90	0.601		
		7.56	0.413	11.70	0.211	2.82	0.401	7.30	0.205	31.95	0.640		
		7.56	0.419	11.78	0.216	3.09	0.401	7.34	0.215	34.36	0.640		
		7.63	0.418	11.83	0.180	3.15	0.376	7.36	0.370	35.71	0.616		
		7.67	0.421	11.99	0.173	3.20	0.381	7.46	0.410	40.09	0.544		
		7.72	0.417	12.14	0.185	3.26	0.370	7.52	0.470	6.32	0.679		
		7.76	0.426	12.20	0.215	3.30	0.326	7.54	0.221	6.08	0.670		
		7.81	0.418	12.33	0.221	3.33	0.245	7.58	0.370	6.22	0.679		
		7.83	0.424	12.33	0.243	3.37	0.000	7.55	0.470	6.38	0.687		
		7.85	0.420	12.41	0.261	3.52	0.000	7.68	0.435	6.59	0.687		
		7.99	0.417	12.50	0.291	3.57	0.224						

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 16 (CONT.)		CURVE 16 (CONT.)		CURVE 17 (CONT.)		CURVE 17 (CONT.)		CURVE 18 (CONT.)		λ	
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
6.65	0.676	13.30	0.377	3.11	0.568	19.96	0.651	6.28	0.398	9.25	0.256	11.67	0.163
6.70	0.660	13.64	0.420	3.28	0.567	20.75	0.642	6.43	0.404	9.37	0.207	11.96	0.171
6.73	0.630	13.95	0.433	3.36	0.574	21.74	0.638	6.54	0.413	9.61	0.153	12.25	0.199
6.78	0.543	14.06	0.484	3.42	0.566	23.70	0.603	6.62	0.413	9.71	0.156	12.50	0.230
6.83	0.246	14.35	0.524	3.51	0.577	25.00	0.613	6.65	0.421	9.62	0.150	12.77	0.270
6.36	0.223	14.66	0.533	3.81	0.576	2.50	0.264	6.83	0.432	9.98	0.125	12.99	0.303
6.90	0.250	14.66	0.546	3.91	0.585	2.59	0.266	6.94	0.432	10.27	0.128	13.36	0.554
6.93	0.364	15.50	0.590	4.12	0.573	2.60	0.270	6.97	0.437	10.52	0.137	13.66	0.556
6.95	0.591	17.06	0.621	4.33	0.592	2.67	0.270	7.00	0.441	10.62	0.132	13.88	0.558
7.03	6.677	18.12	0.621	4.72	0.592	2.70	0.279	7.01	0.441	10.71	0.118	14.00	0.560
7.12	0.700	18.73	0.606	4.85	0.587	2.89	0.279	7.04	0.444	10.76	0.154	14.12	0.562
7.16	0.633	19.38	0.579	5.10	0.587	2.91	0.286	7.05	0.446	10.83	0.165	14.24	0.564
7.19	0.669	20.12	0.545	5.19	0.600	2.96	0.286	7.08	0.467	10.86	0.199	14.36	0.566
7.24	0.479	20.53	0.545	5.59	0.600	2.98	0.300	7.13	0.469	10.86	0.199	14.48	0.568
7.26	0.359	21.23	0.561	5.75	0.600	3.06	0.302	7.17	0.473	10.89	0.205	14.60	0.570
7.30	0.518	22.37	0.606	5.93	0.612	2.91	0.286	7.21	0.481	11.01	0.150	14.72	0.572
7.34	0.532	23.58	0.647	6.62	0.618	2.96	0.286	7.24	0.481	11.05	0.221	14.84	0.574
7.36	0.616	24.75	0.681	7.13	0.622	2.98	0.300	7.28	0.481	11.11	0.161	14.96	0.576
7.51	0.666	25.45	0.695	7.35	0.633	3.06	0.302	7.32	0.484	11.17	0.144	15.18	0.578
7.57	0.675	26.84	0.695	7.50	0.632	3.08	0.309	7.36	0.489	11.26	0.168	15.30	0.580
7.68	0.660	26.67	0.679	7.69	0.629	3.12	0.309	7.40	0.497	11.33	0.352	15.42	0.582
7.79	0.665	26.95	0.688	7.84	0.637	3.16	0.312	7.44	0.491	11.42	0.212	15.54	0.584
7.89	0.644	26.95	0.729	8.14	0.635	3.19	0.318	7.48	0.501	11.52	0.270	15.66	0.586
8.08	0.593	28.25	0.751	8.67	0.640	3.23	0.316	7.52	0.504	11.70	0.155	15.78	0.588
8.32	0.526	29.33	0.757	8.93	0.629	3.26	0.325	7.56	0.515	11.79	0.357	15.90	0.590
8.45	0.505	31.85	0.757	9.64	0.651	3.35	0.331	7.62	0.517	11.85	0.433	16.02	0.592
8.78	0.402	33.56	0.745	9.95	0.640	3.41	0.331	7.66	0.523	11.88	0.492	16.14	0.594
9.07	0.291	35.09	0.717	1.022	0.630	3.44	0.337	7.70	0.526	12.00	0.550	16.26	0.662
9.31	0.232	36.36	0.693	1.056	0.629	3.47	0.337	7.74	0.528	12.11	0.586	16.38	0.664
9.57	0.184	38.31	0.597	1.095	0.609	3.49	0.344	7.41	0.540	12.41	0.622	16.50	0.666
9.90	0.160	40.00	0.590	1.152	0.563	3.54	0.344	7.69	0.545	12.76	0.650	16.62	0.668
10.35	0.141	CURVE 17		1.209	0.512	3.56	0.351	8.05	0.545	13.35	0.635	16.74	0.674
10.85	0.141	1.277	0.151	1.377	0.573	3.71	0.357	8.47	0.532	14.43	0.635	16.86	0.676
11.67	0.163	1.513	0.657	3.84	0.370	8.73	0.517	14.47	0.512	17.00	0.672	16.99	0.674
11.96	0.171	2.50	0.554	15.67	0.654	3.89	0.369	8.82	0.501	14.51	0.603	17.18	0.676
12.25	0.199	2.66	0.556	16.04	0.661	3.99	0.361	8.91	0.479	14.60	0.634	17.30	0.678
12.50	0.230	2.69	0.550	17.36	0.661	4.05	0.361	8.97	0.453	14.66	0.610	17.42	0.680
12.77	0.270	2.73	0.559	18.02	0.673	4.07	0.361	9.07	0.363	14.77	0.672	17.54	0.682
12.99	0.303	2.86	0.563	18.55	0.662	4.19	0.360	9.16	0.366	14.93	0.674	17.66	0.684

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)

[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ]

λ	T	CURVE 18(CONT.)	λ	T	CURVE 18(CONT.)	λ	T	CURVE 19(CONT.)	λ	T	CURVE 19(CONT.)	λ	T	CURVE 19(CONT.)
15.24	0.696	27.70	0.605	7.96	0.516	11.93	0.240	21.51	0.607	40.82	0.727			
15.60	0.699	27.93	0.716	6.08	0.512	12.02	0.322	21.83	0.433	41.67	0.734			
15.80	0.730	28.33	0.734	8.22	0.502	12.12	0.400	21.98	0.701	42.92	0.727			
15.90	0.726	30.21	0.741	6.32	0.495	12.25	0.455	22.32	0.719	43.67	0.688			
16.26	0.726	39.77	0.732	6.46	0.487	12.47	0.525	22.37	0.693	44.44	0.717			
16.50	0.593	31.75	0.735	6.43	0.490	12.67	0.504	22.62	0.695	45.45	0.724			
16.56	0.710	32.57	0.656	8.45	0.478	12.94	0.615	23.15	0.695	45.45	0.724			
16.69	0.731	33.00	0.721	5.54	0.467	13.18	0.536	23.70	0.708	46.08	0.726			
17.61	0.735	33.44	0.743	6.64	0.452	13.46	0.652	24.10	0.686	50.00	0.713			
17.95	0.745	33.78	0.790	8.73	0.426	13.70	0.663	24.51	0.399					
18.60	0.759	34.13	0.754	8.82	0.401	14.10	0.672	24.94	0.502	2.12	0.735			
19.16	0.742	34.36	0.792	8.89	0.362	14.43	0.663	25.19	0.688	2.39	0.755			
19.26	0.467	35.09	0.751	8.98	0.319	14.53	0.602	25.64	0.710	2.67	0.790			
19.53	0.601	35.46	0.762	9.07	0.244	14.64	0.463	26.04	0.698	2.81	0.790			
19.76	0.385	35.59	0.737	9.17	0.193	14.73	0.590	26.46	0.687	2.92	0.769			
20.00	0.346	35.59	0.767	9.24	0.157	14.77	0.567	27.03	0.302	2.99	0.781			
20.24	0.698	36.50	0.780	9.30	0.128	14.86	0.629	27.17	0.650	2.33	0.804			
20.45	0.730	37.04	0.751	9.47	0.109	14.95	0.651	27.47	0.688	3.25	0.814			
20.62	0.750	37.31	0.766	9.49	0.099	15.20	0.678	27.62	0.670	3.55	0.816			
21.19	0.750	38.31	0.777	9.69	0.092	15.58	0.684	27.86	0.699	3.66	0.825			
21.41	0.493	38.76	0.813	9.76	0.097	15.90	0.689	28.33	0.469	3.99	0.838			
21.55	0.722	39.06	0.737	9.85	0.090	16.29	0.689	28.57	0.703	4.50	0.819			
21.74	0.754	39.37	0.813	9.95	0.080	16.56	0.678	29.50	0.712	4.74	0.829			
22.22	0.754	39.37	0.784	10.09	0.068	16.72	0.486	31.06	0.712	4.93	0.846			
22.47	0.749	40.32	0.767	10.58	0.068	16.81	0.633	31.65	0.720	4.09	0.826			
22.99	0.754	42.37	0.779	10.78	0.058	16.86	0.675	31.95	0.711	4.18	0.838			
23.47	0.746	43.10	0.806	10.89	0.081	17.01	0.691	32.79	0.711	5.75	0.867			
23.70	0.732	44.05	0.781	10.98	0.107	17.42	0.676	33.11	0.506	6.36	0.882			
24.16	0.457	47.17	0.787	11.06	0.077	18.05	0.700	33.11	0.662	6.65	0.864			
24.27	0.628	50.00	0.784	11.14	0.110	18.76	0.704	33.78	0.522	5.32	0.855			
24.69	0.636			11.19	0.082	19.12	0.694	34.13	0.682	6.36	0.873			
24.69	0.724			11.26	0.071	19.38	0.677	34.48	0.706	5.85	0.861			
25.13	0.744			11.33	0.082	19.69	0.332	35.34	0.706	5.92	0.874			
25.64	0.733			11.39	0.202	19.88	0.467	35.71	0.642	6.05	0.864			
25.91	0.703			11.44	0.171	20.04	0.259	36.10	0.699	6.24	0.878			
26.39	0.468			11.47	0.113	20.24	0.211	36.50	0.711	6.36	0.882			
26.53	0.703			11.50	0.137	20.45	0.252	37.31	0.711	6.54	0.884			
26.74	0.725			11.67	0.109	20.66	0.603	37.45	0.744	6.79	0.895			
26.95	0.714			11.74	0.072	20.88	0.664	38.31	0.737	6.94	0.893			
27.25	0.727			11.81	0.097	21.32	0.693	39.53	0.742					

CURVE 19
 $T = 293.$

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELLENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 20 (CONT.)				CURVE 21 (CONT.)				CURVE 22 (CONT.)				CURVE 23 (CONT.)				CURVE 24 (CONT.)			
λ	τ	λ	τ																		
7.24	0.693	3.18	0.792	14.79	0.612	6.91	0.576	10.09	0.317	15.22	0.664	9.22	0.694	15.72	0.664	9.22	0.694	15.72	0.664		
7.39	0.899	3.31	0.799	14.90	0.629	9.19	0.495	10.52	0.269	15.52	0.652	9.42	0.799	10.84	0.304	9.54	0.788	15.02	0.622		
7.59	0.899	3.42	0.799	15.02	0.622	9.67	0.409	10.84	0.304	15.17	0.629	10.03	0.371	11.25	0.523	CURVE 25					
7.79	0.890	3.54	0.788	15.17	0.629	10.33	0.317	11.43	0.594	T = 293.		10.33	0.317	11.43	0.594	CURVE 25					
8.21	0.828	3.94	0.770	4.20	0.761	10.54	0.267	11.64	0.636			10.54	0.267	11.64	0.636	CURVE 25					
8.31	0.743	5.743	0.743	4.45	0.761	10.99	0.260	11.86	0.684			10.99	0.260	11.86	0.684	CURVE 25					
9.22	0.694	9.69	0.768	4.69	0.768	11.48	0.238	12.19	0.721			11.48	0.238	12.19	0.721	CURVE 25					
9.85	0.586	10.19	0.523	4.76	0.780	1.98	0.835	12.06	0.246			1.98	0.835	12.06	0.246	CURVE 25					
10.19	0.549	10.47	0.523	5.01	0.780	2.13	0.825	12.43	0.257			2.13	0.825	12.43	0.257	CURVE 25					
10.47	0.523	10.73	0.507	5.62	0.815	2.13	0.809	13.61	0.622			2.13	0.809	13.61	0.622	CURVE 25					
11.34	0.507	11.34	0.522	6.05	0.838	2.29	0.804	12.70	0.290			2.29	0.804	12.70	0.290	CURVE 25					
11.44	0.522	11.44	0.547	6.22	0.842	2.49	0.767	13.27	0.375			2.49	0.767	13.27	0.375	CURVE 25					
11.34	0.547	12.21	0.593	6.39	0.860	2.78	0.727	13.65	0.453			2.78	0.727	13.65	0.453	CURVE 25					
12.51	0.626	6.72	0.870	7.14	0.881	3.00	0.686	14.14	0.499			7.14	0.881	14.14	0.499	CURVE 25					
12.81	0.683	7.36	0.888	7.58	0.888	3.14	0.676	14.90	0.583			7.58	0.888	14.90	0.583	CURVE 25					
13.28	0.724	7.75	0.874	7.75	0.874	3.27	0.702	14.98	0.572			7.75	0.874	14.98	0.572	CURVE 25					
14.01	0.790	7.75	0.874	7.84	0.874	3.57	0.702	15.06	0.584			7.84	0.874	15.06	0.584	CURVE 25					
14.26	0.816	8.16	0.815	8.29	0.774	3.95	0.709	14.14	0.499			8.16	0.815	14.14	0.499	CURVE 25					
14.69	0.829	8.29	0.774	8.43	0.743	4.37	0.716	14.51	0.544			8.29	0.774	14.51	0.544	CURVE 25					
14.85	0.847	8.56	0.743	8.60	0.743	4.60	0.721	14.90	0.583			8.56	0.743	14.90	0.583	CURVE 25					
14.93	0.832	8.56	0.743	8.74	0.743	4.69	0.739	14.98	0.572			8.74	0.743	14.98	0.572	CURVE 25					
15.34	0.849	8.56	0.726	8.84	0.874	3.95	0.709	14.51	0.544			8.84	0.874	14.51	0.544	CURVE 25					
15.38	0.854	8.65	0.716	9.05	0.760	5.12	0.760	14.90	0.583			9.05	0.760	14.90	0.583	CURVE 25					
15.44	0.848	8.63	0.669	9.05	0.793	5.66	0.793	11.20	0.302			9.05	0.793	11.20	0.302	CURVE 25					
15.55	0.863	8.93	0.635	9.14	0.803	6.34	0.820	11.63	0.302			9.14	0.803	11.63	0.302	CURVE 25					
15.34	0.849	8.56	0.726	9.14	0.859	6.71	0.859	11.90	0.310			9.14	0.859	11.90	0.310	CURVE 25					
15.38	0.854	8.65	0.716	9.44	0.539	7.13	0.869	12.12	0.333			9.44	0.539	7.13	0.869	CURVE 25					
15.44	0.848	9.74	0.501	10.13	0.469	7.21	0.864	12.36	0.357			9.74	0.501	10.13	0.469	CURVE 25					
15.55	0.863	10.79	0.422	10.79	0.422	7.32	0.877	12.56	0.386			10.79	0.422	12.56	0.386	CURVE 25					
15.34	0.849	11.06	0.413	11.28	0.413	7.99	0.835	13.00	0.466			11.28	0.413	7.99	0.835	CURVE 25					
15.38	0.854	11.06	0.413	11.69	0.396	8.13	0.801	12.56	0.386			11.69	0.396	12.56	0.386	CURVE 25					
15.44	0.848	12.27	0.405	12.27	0.405	8.63	0.875	13.59	0.575			12.27	0.405	13.59	0.575	CURVE 25					
15.55	0.863	12.63	0.424	12.63	0.424	9.29	0.760	13.79	0.604			12.63	0.424	13.79	0.604	CURVE 25					
15.34	0.846	13.08	0.462	13.08	0.462	8.29	0.736	13.97	0.621			13.08	0.462	13.97	0.621	CURVE 25					
15.44	0.852	13.64	0.517	13.64	0.517	8.60	0.701	14.16	0.636			13.64	0.517	14.16	0.636	CURVE 25					
15.55	0.810	14.27	0.575	14.27	0.575	9.73	0.701	14.45	0.650			14.27	0.575	14.45	0.650	CURVE 25					

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 25 (CONT.)		CURVE 25 (CONT.)		CURVE 26 (CONT.)		CURVE 26 (CONT.)		CURVE 27 (CONT.)		CURVE 27 (CONT.)	
		λ	τ										
5.41	0.919	7.47	0.833	3.33	0.737	7.93	0.891	2.99	0.839	4.31	0.769	4.34	0.765
5.60	0.934	7.58	0.851	3.44	0.726	8.10	0.863	3.05	0.876	4.62	0.809	4.62	0.809
5.89	0.920	7.64	0.866	3.49	0.602	8.16	0.838	3.12	0.920	4.72	0.826	4.72	0.826
5.92	0.948	7.78	0.834	3.51	0.298	8.23	0.828	3.16	0.927	4.75	0.841	4.75	0.841
5.95	0.913	7.90	0.819	3.56	0.251	8.37	0.754	3.19	0.951	4.81	0.841	4.81	0.841
6.03	0.936	8.02	0.759	3.61	0.401	8.50	0.686	3.20	0.976	4.91	0.961	4.91	0.961
6.06	0.914	8.21	0.560	3.63	0.355	8.71	0.628	3.21	0.954	4.96	0.861	4.96	0.861
6.12	0.904	8.48	0.249	3.68	0.703	9.00	0.583	3.22	0.963	5.03	0.871	5.03	0.871
6.15	0.927	8.59	0.190	3.71	0.757	9.15	0.552	3.25	0.969	5.14	0.873	5.14	0.873
6.19	0.899	8.72	0.164	3.76	0.794	9.53	0.512	3.29	0.961	5.16	0.883	5.16	0.883
6.21	0.921	8.88	0.151	3.82	0.789	9.81	0.488	3.31	0.938	5.27	0.888	5.27	0.888
6.24	0.901	9.11	0.129	3.97	0.805	9.87	0.474	3.32	0.896	5.41	0.907	5.41	0.907
6.30	0.919	9.50	0.108	4.06	0.833	10.09	0.468	3.35	0.704	5.73	0.924	5.73	0.924
6.42	0.939	9.69	0.091	4.34	0.855	10.33	0.453	3.38	0.201	5.80	0.924	5.80	0.924
6.46	0.939	10.10	0.091	4.43	0.850	10.71	0.438	3.39	0.153	5.90	0.935	5.90	0.935
6.48	0.932	10.52	0.076	4.46	0.861	11.15	0.438	3.40	0.148	5.97	0.936	5.97	0.936
6.50	0.949	11.33	0.076	4.87	0.889	11.64	0.458	3.43	0.101	6.03	0.931	6.03	0.931
6.53	0.921	11.95	0.084	5.34	0.917	12.18	0.472	3.45	0.152	6.18	0.948	6.18	0.948
6.57	0.948	12.34	0.092	6.01	0.926	12.48	0.499	3.47	0.299	6.45	0.948	6.45	0.948
6.61	0.923	12.74	0.129	6.35	0.926	13.01	0.558	3.48	0.319	6.60	0.948	6.60	0.948
6.65	0.941	12.89	0.129	6.69	0.938	13.36	0.590	3.49	0.256	6.69	0.932	6.69	0.932
6.69	0.925	13.36	0.157	6.82	0.919	13.48	0.600	3.51	0.221	6.73	0.902	6.73	0.902
6.72	0.940	13.59	0.162	6.89	0.849	13.63	0.600	3.54	0.697	6.77	0.813	6.77	0.813
6.74	0.901	13.74	0.173	6.92	0.671	13.77	0.620	3.55	1.000	6.84	0.363	6.84	0.363
9.76	0.922	13.99	0.192	6.96	0.634	13.88	0.621	3.58	1.000	6.86	0.370	6.86	0.370
6.81	0.904	14.16	0.228	6.99	0.656	14.24	0.684	3.58	0.551	6.89	0.389	6.89	0.389
6.85	0.845	14.42	0.248	7.03	0.780	14.41	0.697	3.60	0.580	6.92	0.503	6.92	0.503
6.89	0.740	14.62	0.261	7.11	0.897	14.71	0.721	3.63	0.591	7.02	0.876	7.02	0.876
6.92	0.498	14.84	0.262	7.20	0.926	14.83	0.736	3.68	0.584	7.06	0.905	7.06	0.905
6.94	0.416	15.00	0.263	7.27	0.919	15.00	0.754	3.71	0.600	7.09	0.916	7.09	0.916
7.09	0.600	7.33	0.803	7.37	0.740	7.39	0.804	3.87	0.646	7.13	0.926	7.13	0.926
7.11	0.835	7.39	0.804	7.43	0.827	7.43	0.827	4.00	0.695	7.28	0.526	7.28	0.526
7.13	0.863	7.43	0.827	7.46	0.874	7.46	0.874	4.02	0.695	7.32	0.714	7.32	0.714
7.16	0.676	7.50	0.642	7.53	0.703	7.51	0.885	4.04	0.711	7.35	0.721	7.35	0.721
7.21	0.905	7.54	0.664	7.59	0.885	7.72	0.767	4.06	0.696	7.42	0.802	7.42	0.802
7.26	0.890	7.66	0.698	7.63	0.900	7.82	0.792	4.10	0.717	7.44	0.833	7.44	0.833
7.36	0.596	7.86	0.729	7.67	0.901	7.89	0.806	4.21	0.733	7.57	0.884	7.57	0.884
7.39	0.731	7.25	0.729	7.76	0.891	7.96	0.821	4.26	0.759	7.70	0.876	7.70	0.876
7.43	0.747	7.31	0.724	7.31	0.821	7.31	0.821	4.26	0.759	7.70	0.876	7.70	0.876

CURVE 27
 $T = 293.$

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 27 (CONT.)		CURVE 28 (CONT.)		CURVE 29 (CONT.)		CURVE 30 (CONT.)		CURVE 31 (CONT.)	
λ	T								
7.78	0.874	16.84	0.124	8.42	0.581	12.22	0.236	11.98	0.190
7.84	0.874	17.79	0.297	8.76	0.581	12.44	0.273	12.17	0.190
7.99	0.562	18.69	0.502	9.02	0.559	12.61	0.319	12.45	0.220
8.19	0.822	19.01	0.550	9.38	0.516	12.80	0.380	12.69	0.273
8.40	0.753	19.34	0.564	9.78	0.474	13.07	0.443	13.05	0.346
8.55	0.666	19.57	0.536	10.20	0.433	13.35	0.512	13.35	0.421
8.79	0.534	19.80	0.358	10.70	0.397	13.59	0.554	13.76	0.518
8.84	0.520	20.08	0.351	11.16	0.367	13.83	0.594	14.01	0.558
9.09	0.343	20.62	0.152	11.53	0.367	14.08	0.624	14.37	0.591
9.23	0.234	21.14	0.286	11.78	0.388	14.41	0.661	14.41	0.333
9.29	0.188	21.55	0.230	12.11	0.426	14.66	0.682	14.66	0.272
9.43	0.164	21.98	0.141	12.42	0.473	14.99	0.705	14.99	0.394
9.63	0.157	22.57	0.199	12.66	0.521	15.41	0.720	15.41	0.27
9.80	0.135	24.27	0.445	12.99	0.580	15.80	0.720	15.80	0.592
9.91	0.135	24.63	0.316	13.40	0.654	16.10	0.706	16.10	0.638
10.24	0.393	25.13	0.361	13.89	0.705	16.37	0.665	16.37	0.652
10.56	0.064	25.58	0.573	14.25	0.735	16.56	0.638	16.56	0.670
10.70	0.062	25.97	0.614	14.66	0.765	16.84	0.607	16.84	0.722
10.78	0.075	26.46	0.589	14.95	0.776	17.09	0.619	17.09	0.729
11.03	0.101	27.03	0.305	15.43	0.791	17.36	0.637	17.36	0.937
11.15	0.095	28.17	0.727						
11.24	0.099	28.65	0.634	28.99	0.755	17.09	0.637	17.09	0.937
11.35	0.091	29.76	0.834	29.76	0.834	17.36	0.680	17.36	0.937
11.48	0.116	30.58	0.860	30.58	0.860	17.93	0.680	17.93	0.937
11.82	0.535	32.68	0.892	8.14	0.671	7.95	0.667	7.95	0.667
12.38	0.133	34.13	0.806	8.34	0.662	8.08	0.650	8.08	0.650
12.82	0.165	34.72	0.860	8.61	0.635	8.22	0.620	8.22	0.620
13.18	0.189	35.59	0.881	8.85	0.609	8.45	0.585	8.45	0.677
13.62	0.202	36.50	0.881	9.10	0.576	8.76	0.532	8.76	0.677
14.37	0.232	36.90	0.996	9.44	0.537	8.90	0.498	8.90	0.701
14.56	0.197	39.06	0.927	9.79	0.487	9.06	0.475	9.06	0.702
14.73	0.165	39.06	1.000	10.11	0.440	9.23	0.457	9.23	0.664
14.95	0.165	39.06	1.000	10.37	0.409	9.51	0.447	9.51	0.650
15.15	0.168	39.06	1.000	10.63	0.371	9.77	0.431	9.77	0.631
15.52	0.152	39.06	1.000	10.98	0.327	10.07	0.386	10.07	0.609
15.65	0.152	39.06	1.000	11.39	0.277	10.40	0.338	10.40	0.581
16.00	0.134	39.06	1.000	11.61	0.242	10.82	0.288	10.82	0.572
16.09	0.152	39.06	1.000	11.85	0.224	11.25	0.246	11.25	0.485
16.45	0.131	39.06	1.000	12.09	0.224	11.64	0.214	11.64	0.596
16.69	0.134	39.06	1.000						
CURVE 28		CURVE 29		CURVE 30		CURVE 31		CURVE 32	
λ	T								

TABLE 14-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON NITRIDE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ
CURVE 32 $T = 293$.		CURVE 32 (CONT.)		CURVE 33 (CONT.)		CURVE 33 (CONT.)	
2.50	0.453	10.18	0.030	4.61	0.558		
2.63	0.479	11.22	0.008	4.79	0.540		
2.71	0.507	12.35	0.009	4.96	0.509		
2.79	0.533	12.90	0.035	5.13	0.506		
2.86	0.533	13.32	0.110	5.29	0.480		
2.91	0.514	13.91	0.194	5.53	0.459		
2.95	0.489	14.62	0.266	5.81	0.436		
3.04	0.450	14.99	0.279	6.31	0.435		
3.17	0.442	15.62	0.297	6.63	0.446		
3.33	0.429	16.05	0.309	6.97	0.463		
3.61	0.429	16.67	0.296	7.28	0.489		
3.65	0.451	17.36	0.333	7.50	0.501		
3.77	0.484	18.42	0.321	7.65	0.502		
3.91	0.509	18.55	0.309	7.89	0.480		
4.03	0.527	20.08	0.230	8.03	0.454		
4.20	0.553	20.70	0.223	8.25	0.372		
4.54	0.573	21.83	0.258	8.50	0.265		
4.69	0.572	23.96	0.323	8.68	0.230		
4.81	0.554	25.84	0.369	9.04	0.136		
5.00	0.531	27.62	0.399	9.31	0.086		
5.15	0.509	32.79	0.417	9.68	0.059		
5.33	0.498			10.18	0.030		
5.50	0.476			11.22	0.008		
5.62	0.467			12.35	0.009		
5.74	0.446	2.50	0.453	12.90	0.035		
6.61	0.447	2.58	0.463	13.32	0.110		
6.97	0.463	2.66	0.468	13.91	0.194		
7.26	0.489	2.77	0.507	15.95	0.296		
7.50	0.501	2.86	0.507	16.58	0.287		
7.44	0.504	2.93	0.480	17.33	0.324		
7.76	0.502	3.00	0.452	18.55	0.309		
7.97	0.478	3.16	0.438	20.70	0.214		
8.12	0.435	3.32	0.427	23.20	0.293		
8.25	0.372	3.49	0.422	25.91	0.363		
8.50	0.285	3.64	0.438	29.05	0.383		
8.68	0.230	3.77	0.453				
9.04	0.138	3.87	0.481				
9.31	0.086	4.04	0.518				
9.68	0.059	4.45	0.558				



4.15. Acrylic Resins

The four major categories of acrylic resins include polymethacrylate, polyacrylate, poly(methyl methacrylate), and copolymer of acrylonitrile. The list of esters range from methyl to lauryl, C₁-C₁₅. Because of the many combinations possible, there are at least 40 varieties of acrylic resins commercially available. Lucite is a trade name of DuPont for poly(methyl methacrylate) which will be described in the next subsection. Other trade names for the various acrylic resins include Acryloid, Acrysol, Acryrin, Hycar PA, Acrilan, Creslan, Dynel, Orlon, Plexiglass, Vernonite, etc. These materials are manufactured in a wide range of colors and are in demand where aesthetic considerations predominate. They possess low specific gravity, low water absorption, good weather ability, and tensile strengths but only moderate heat resistance and low hardness. They soften from 250 to 400 K and are more easily scratched than glass.

According to the Reference [A00025], the softening points of acrylics are as follows:

<u>Acrylics</u>	<u>Softening Point (K)</u>
Polymethylacrylate (PMA)	277
Polyethylacrylate (PEA)	248
Polymethylmethacrylate (PMMA)	397
Polyethylmethacrylate (PEMA)	339
Poly n-butyl methacrylate (PBMA)	303
Polyacrylonitrile	511

The polymerization of acrylate and methacrylate esters is carried out in water suspension with peroxide catalyst. The resulting polymer is washed, dried, and blended with plasticizers and colorants before pelletizing for use as molding powders.



Acrylic resins are soluble in aromatic and most chlorinated hydrocarbons (toluene, ethylene dichloride, chloroform), esters (ethyl acetate), ketones, tetrahydrofuran; 80/20 toluene/methanol gives low-viscosity solutions. Polymers of butyl and higher esters are

soluble in aliphatic hydrocarbons (e.g., white spirit, also in molten waxes). Cross-linked polymers are insoluble but swell in chlorinated hydrocarbons. Acrylic resins can also be swollen by alcohols, phenols, ether, and carbon tetrachloride. They are decomposable by conc. oxidizing acids (HNO_3 , H_2SO_4 , H_2CrO_4), alcoholic alkalis.

Acrylic resins have a density of about $1.02\text{-}1.22 \text{ g cm}^{-3}$. Their refractive index is about $1.47\text{-}1.49$. The ultraviolet cut off is below 2800 \AA , it transmits about 85% in the visible region, and the infrared cut off is about 23000 \AA ($2.3 \mu\text{m}$).

a. Normal Spectral Emittance (Wavelength Dependence)

There are four sets of experimental data available for the wavelength dependence of the normal spectral emittance of acrylic resins as listed in Table 15-3 and shown in Figure 15-2. Specimen characterization and measurement information for the data are given in Table 15-2. All the data are for the paint coatings with green, blue/black, or white color. In the wavelength region above $\lambda = 6 \mu\text{m}$, there are small differences among the values of emittance for the different paints. In the shorter wavelength region the white paint has lowest emittance value. Since the data are limited, as a consequence, only provisional values were reported here. The provisional values listed in Table 15-1 and shown in Figure 15-1 are for the "white acrylic paint" on stainless steel substrate. The estimated uncertainty is within $\pm 30\%$.

TABLE 15-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	λ	ϵ
WHITE PAINT ON S. STEEL $T = 293$			
0.32	0.953	0.32	0.934
0.36	0.935	0.40	0.944
0.37	0.799	0.48	0.952
0.40	0.503	0.56	0.958
0.45	0.372	0.63	0.962
0.50	0.264	0.70	0.956
0.65	0.275	0.80	0.944
0.80	0.275	0.90	0.928
1.00	0.320	1.10	0.900
1.50	0.463		
2.00	0.555		
2.50	0.643		
3.00	0.795		
3.20	0.893		
3.50	0.930		
3.60	0.943		
3.73	0.942		
3.90	0.880		
4.00	0.795		
4.40	0.686		
4.80	0.665		
5.00	0.665		
5.50	0.688		
5.70	0.760		
5.80	0.914		
5.90	0.926		
6.00	0.862		
6.50	0.809		
6.75	0.765		
6.80	0.976		
6.90	0.923		
7.00	0.890		
7.50	0.921		
8.00	0.942		
8.30	0.765		
8.50	0.923		
9.00	0.930		
9.50	0.925		
9.60	0.884		
10.00	0.880		
10.60	0.925		




FIGURE 15-1. PROVISIONAL NORMAL SPECTRAL EMMITTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).




FIGURE 15-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN COATINGS
(WAVELENGTH DEPENDENCE).

TABLE 15-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ACRYLIC RESIN COATING (Wavelength Dependence)

Cur. Ref. No.	Ref. Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T63130	Faulkner, D., Horvath, R., Ulrich, J. P., and Worts, E.	1971	3.3-14	293	MIL-L-19538B Paint (Field Green ANA-627)	aluminum substrate, MIL-C-5541 surface preparation, MIL-P-7962 primer; Field Infrared Spectro-Radiometer was used; data were extracted from the figure; $\theta' \sim 3^\circ$.
2 T63130	Faulkner, D., et al.	1971	3.3-14	293	MIL-L-19538B Blue/Black (15042)	Similar to the above specimen.
3 T63130	Faulkner, D., et al.	1971	3.3-14	293	Glossy Acrylic O.D. (X34087)	Similar to the above specimen.
4 T52784	Shirkle, F.J.	1961	0.3-40	~300	Flat White Acrylic Paint	7/16 in. disc stainless steel No. 301 substrate; the paint was obtained from Sherwin Williams; one coat over one coat pre-treatment wash coating; formula No. E90CC22, MIL-C-153284; $\theta' \sim 0^\circ$.

TABLE 15-3. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMMITTANCE, ϵ .]

λ	ϵ	CURVE 1 $T = 293$.	CURVE 1 (CONT.)	λ	ϵ	CURVE 3 (CONT.)	λ	ϵ	CURVE 4 $T = 300$.	λ	ϵ	CURVE 4 (CONT.)	λ	ϵ	CURVE 4 (CONT.)
3.19	0.931	13.67	0.980	3.42	0.929	0.316	0.951	4.797	0.666	17.219	0.880				
3.84	0.825	13.78	0.973	3.56	0.903	1.329	0.953	4.989	0.666	17.906	0.571				
4.30	0.764		CURVE 2 $T = 293$.	3.76	0.873	0.365	0.953	5.152	0.675	20.941	0.607				
4.45	0.749			3.89	0.855	0.348	0.953	5.152	0.687	21.281	0.759				
4.50	0.745			4.14	0.832	0.352	0.936	5.272	0.687	21.281	0.719				
4.78	0.749			4.36	0.809	0.365	0.837	5.408	0.679	21.878	0.710				
5.00	0.753			4.57	0.799	0.373	0.798	5.546	0.690	22.439	0.723				
5.21	0.777			4.78	0.799	0.393	0.655	5.720	0.762	22.439	0.757				
5.45	0.823			5.05	0.808	0.402	0.596	5.814	0.914	23.383	0.777				
5.61	0.843			5.65	0.618	0.414	0.524	5.861	0.928	24.322	0.791				
5.61	0.934			5.47	0.824	0.443	0.421	5.957	0.922	25.644	0.762				
5.78	0.984			5.53	0.848	0.444	0.385	5.957	0.869	25.122	0.706				
5.97	0.977			5.64	0.872	0.516	0.281	6.209	0.323	27.164	0.635				
5.15	0.966			5.72	0.908	0.532	0.267	6.577	0.805	28.104	0.793				
6.26	0.952			5.96	0.856	0.652	0.275	6.745	0.750	29.183	0.771				
6.44	0.929			6.26	0.866	0.819	0.275	6.776	0.875	29.242	0.772				
6.46	0.997			5.45	0.677	0.940	0.290	7.515	0.923	33.729	0.781				
6.57	0.892			5.70	0.897	0.923	0.392	6.291	0.954	37.356	0.766				
6.59	0.867			5.95	0.925	5.96	0.886	6.577	0.805	28.104	0.793				
6.66	0.923			5.37	0.952	7.43	0.909	6.652	0.275	6.745	0.750				
6.70	0.968			6.53	0.959	6.04	0.925	6.819	0.275	6.776	0.875				
6.82	0.975			7.01	0.964	9.25	0.935	6.940	0.290	7.515	0.923				
7.10	0.983			7.52	0.971	9.43	0.942	7.233	0.392	6.291	0.954				
7.68	0.937			8.30	0.971	9.53	0.949	1.407	0.429	6.356	0.887				
6.37	0.937			6.70	0.964	9.25	0.942	6.652	0.275	6.745	0.750				
9.47	0.982			7.01	0.968	9.43	0.947	1.407	0.429	6.745	0.875				
9.77	0.959			7.52	0.971	9.53	0.937	1.637	0.481	7.516	0.923				
10.34	0.963			8.30	0.971	9.62	0.952	1.637	0.481	7.516	0.923				
10.60	0.975			9.92	0.966	9.75	0.952	1.675	0.503	7.516	0.923				
11.35	0.987			10.40	0.964	9.86	0.933	1.706	0.526	8.291	0.954				
11.72	0.981			11.12	0.967	10.41	0.860	2.512	0.669	9.290	0.921				
12.47	0.983			12.38	0.967	10.19	0.882	2.812	0.744	9.683	0.941				
12.74	0.972			12.40	0.975	10.26	0.900	2.00	0.557	8.576	0.922				
12.33	0.970			12.57	0.981	10.55	0.911	3.006	0.852	9.750	0.950				
12.79	0.976			13.59	0.976	11.25	0.935	2.076	0.579	9.531	0.672				
13.24	0.982			13.96	0.973	11.66	0.942	3.257	0.879	11.220	0.943				
13.42	0.933			13.96	0.972	12.38	0.946	3.483	0.885	12.331	0.959				
13.56	0.982			13.33	0.970	13.11	0.946	3.524	0.937	13.032	0.965				
12.79	0.976			13.45	0.945	13.45	0.946	3.589	0.947	13.740	0.954				
13.24	0.982			14.00	0.936	13.79	0.940	3.673	0.940	14.825	0.920				
13.42	0.933			13.23	0.979	4.122	0.732	4.416	0.586	15.366	0.893				
13.56	0.982			13.31	0.953	3.31	0.953	4.416	0.586	15.922	0.884				

b. Normal Spectral Reflectance (Wavelength Dependence)

There are thirteen sets of experimental data available for the wavelength dependence of the normal spectral reflectance of acrylic resin coatings as listed in Table 15-6 and shown in Figure 15-4. Specimen characterization and measurement information for the data are given in Table 15-5. There are seven different kinds of acrylic resins used for measurements. The normal spectral reflectance values for flat black acrylic were the lowest. White paint (Sherwin Williams) has the highest reflectance value. Only Brandenberg [T52153] and Afonaseva, et al. [T56239] measured the normal spectral reflectance in the wavelength region above 2.6 μm . Because the range of reflectance for acrylic was wide, only provisional values were reported here which are listed in Table 15-4 and shown in Figure 15-3. The provisional values are for the flat white acrylic paint (Sherwin Williams) coatings at 310 K. The estimated uncertainty is within $\pm 30\%$.

TABLE 15-•. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T, K; REFLECTANCE, ρ]

λ	ρ	λ	ρ
ACRYLIC PAINT WHITE T = 310			
2.35	0.14	3.14	0.06
2.49	0.49	4.49	0.06
2.53	0.99	5.00	0.06
2.64	0.89	5.99	0.05
2.80	0.36	6.00	0.10
2.95	0.77	6.44	0.11
3.00	0.69	6.66	
3.25	0.45		
2.75	0.29		
3.00	0.13		
3.50	0.12		
3.50	0.09		
3.75	0.23		
3.80	0.24		
3.80	0.24		
4.00	0.28		
4.40	0.33		
4.84	0.35		
5.20	0.34		
5.50	0.29		
5.70	0.12		
5.80	0.12		
6.00	0.09		
6.13	0.20		
6.33	0.25		
6.46	0.23		
6.80	0.13		
6.90	0.08		
7.20	0.19		
7.26	0.19		
7.30	0.19		
7.67	0.09		
8.00	0.07		
8.23	0.07		
9.00	0.07		
9.30	0.08		
10.00	0.10		
10.62	0.22		
11.70	0.03		
12.00	0.37		

10.00
10.62
11.70
12.00




FIGURE 15-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).




FIGURE 15-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).

TABLE 15-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN COATING (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T64206	Pennigton, C. W. and Moore, G. L.	1971	0.4-2.6	~293	Acrylic Panel	Reflective type acrylic panel; reflectance spectra was measured by using a DK-2 spectrophotometer; data were extracted from figure; $\theta \sim 0^\circ$.
2 T62587	Gilligan, J. E. and Brzuskievicz,	1971	0.2-2.6	~293	DuPont Elvacite 6011 (methyl-methacrylate)	0.015 in. thick sprayed film; Beckman DK-2 spectrometer was used; data were extracted from figure; $\theta \sim 0^\circ$.
3 T62587	Gilligan, J. E. and Brzuskievicz,	1971	0.2-2.6	~293	DuPont Elvacite 6011 (methyl-methacrylate)	Similar to the above specimen except 0.032 in. thick.
4 T62587	Gilligan, J. E. and Brzuskievicz,	1971	0.2-2.6	~293	DuPont Elvacite 6011 (methyl-methacrylate)	Similar to the above specimen except 0.054 in. thick.
5 T62587	Gilligan, J. E. and Brzuskievicz,	1971	0.2-2.6	~293	DuPont Elvacite 6011 (methyl-methacrylate)	Similar to the above specimen except 0.035 in. thick film by a doctor's blade technique.
6 T56229	Afanaseva, G. O., Vinogradova, L. M., Illyasov, S. G., Fridzon, M. B., and Tyurin, B. F.	1969	0.25-15	~293	AS-81	Acrylic white enamals; data were extracted from figure; $\theta \sim 0^\circ$.
7 T56229	Afanaseva, G. O., et al.	1969	0.25-15	~293	AS-20P (R)	Similar to the above specimen.
9 T53498	Shirkle, F. J.	1961	0.38-38	338	Flat Black Acrylic Paint	A heavy coat of paint had been sprayed on 5/16 in. diameter disc of 0.012 in. thick stainless steel; a Perkin-Elmer Model 13 double beam spectrometer was used; data were extracted from figure; $\theta \sim 0^\circ$.
9 T35754	Anderson, R. B.	1965	0.38-1.9	~293	(Sherwin Williams) White Paint	3 mil spray coating of W. P. Fuller Co. 171W-360 Acrylic Vehicle glass white paint on a white substrate; a Gier-Dankel reflectometer and a Cary reflectometer were used; data were extracted from figure; $\theta \sim 0^\circ$.
10 T39754	Anderson, R. B.	1965	0.38-1.9	~293	White Paint (DMS 1765)	2.6 mil spray coating of DMS 1765 white paint on aluminum; other specifications similar to above.
11 T39754	Anderson, R. B.	1965	0.38-1.9	~293	White Paint (NASA-S-13)	8.5 mil spray coating of NASA-S-13 white paint on aluminum; other specifications similar to above.
12 139754	Anderson, R. B.	1965	0.38-1.9	~293	White Paint (MIL-C22750)	2.2 mil spray coating of MIL-C22750 white paint on aluminum; other specifications similar to above.
13 T52153	Bradenberg, W. M.	1961	0.3-25	310.8	Flat White Acrylic Paint	Two coats of Sherwin Williams Flat White acrylic paint over one coat of Sherwin Williams Pre-treatment Wash coating were coated on vehicle; Perkin-Elmer Model 13 double beam meter was used; data were extracted from figure; $\theta \sim 0^\circ$.

TABLE 15-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T ; κ : REFLECTANCE, ρ)

λ	ρ	CURVE 1 (CONT.)	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 5 (CONT.)
CURVE 1 $T = 293.$			1.996	0.106	2.220	0.254	2.218	0.069	1.919	0.302	1.615	0.156		
0.406	0.628	2.056	0.099	2.242	0.241	2.260	0.063	1.961	0.302	1.653	0.150			
0.140	0.628	2.080	0.075	2.266	0.241	2.293	0.063	2.002	0.294	1.695	0.150			
0.500	0.630	2.109	0.062	2.293	0.253	2.335	0.074	2.038	0.284	1.776	0.160			
0.530	0.624	2.219	0.053	2.310	0.261	2.367	0.074	2.071	0.267	1.898	0.169			
0.750	0.624	2.559	0.053	2.342	0.269	2.408	0.060	2.142	0.238	2.016	0.169			
0.811	0.610			2.378	0.261	2.452	0.060	2.185	0.214	2.086	0.162			
0.847	0.596			2.405	0.256	2.490	0.070	2.222	0.204	2.151	0.149			
3.071	0.566			2.428	0.256	2.538	0.085	2.197	0.197	2.1976	0.133			
0.919	0.524			2.470	0.263	2.600	0.104	2.273	0.197	2.227	0.117			
0.996	0.431			0.186	0.491	2.526	0.271	2.295	0.211	2.267	0.067			
1.055	0.364			0.215	0.544	2.600	0.286	2.317	0.222	2.298	0.055			
1.094	0.335			0.236	0.570			2.333	0.228	2.312	0.339			
1.104	0.316			0.250	0.582			2.352	0.228	2.338	0.333			
1.13	0.316			0.269	0.589			2.393	0.217	2.405	0.37			
1.159	0.316			0.289	0.589			2.427	0.217	2.470	0.45			
1.189	0.361			0.328	0.575			2.459	0.223	2.531	0.53			
1.205	0.383			0.426	0.549			2.562	0.228	2.600	0.62			
1.228	0.407			0.493	0.532			2.572	0.228					
1.253	0.416			0.575	0.513			2.590	0.236					
1.288	0.416			0.663	0.494			2.557	0.249					
1.309	0.398			0.771	0.473			2.523	0.222					
1.328	0.301			0.671	0.454			2.519	0.228					
1.334	0.254			0.973	0.437			2.515	0.228					
1.365	0.243			1.103	0.418			2.513	0.228					
1.397	0.212			1.214	0.402			2.511	0.228					
1.439	0.200			1.331	0.382			2.509	0.228					
1.486	0.218			1.447	0.363			2.507	0.228					
1.507	0.268			1.511	0.351			2.505	0.228					
1.538	0.301			1.581	0.339			2.503	0.228					
1.574	0.314			1.641	0.330			2.501	0.228					
1.622	0.264			1.707	0.324			2.499	0.228					
1.664	0.144			1.755	0.321			2.497	0.228					
1.702	0.103			1.856	0.321			2.495	0.228					
1.787	0.900			1.902	0.322			2.493	0.228					
1.820	0.102			2.002	0.322			2.491	0.228					
1.862	0.114			2.060	0.316			2.489	0.228					
1.919	0.105			2.118	0.307			2.487	0.228					
1.947	0.087			2.158	0.293			2.485	0.228					
1.986	0.996			2.194	0.277			2.483	0.228					

TABLE 15-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)						(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)									
λ	ρ	CURVE 6 (CONT.)	λ	ρ	CURVE 6 (CONT.)	λ	ρ	CURVE 7 (CONT.)	λ	ρ	CURVE 7 (CONT.)	λ	ρ	CURVE 8 (CONT.)	
2.06	0.710	6.60	0.137	0.45	0.831	4.35	0.436	9.47	0.072	0.819	0.063	6.65	0.063	0.063	
2.14	0.676	6.65	0.084	0.53	0.859	4.45	0.460	9.66	0.069	0.935	0.063	6.70	0.064	0.064	
2.17	0.626	6.79	0.095	0.62	0.833	4.61	0.470	10.01	0.069	1.042	0.058	6.74	0.064	0.064	
2.23	0.429	7.01	0.066	0.84	0.783	4.71	0.458	10.21	0.060	1.104	0.051	7.05	0.061	0.061	
2.30	0.376	7.35	0.066	0.89	0.759	4.83	0.418	10.38	0.063	1.449	0.061	7.38	0.061	0.061	
2.47	0.393	7.56	0.077	1.05	0.739	4.92	0.418	10.57	0.056	1.538	0.064	7.58	0.064	0.064	
2.58	0.424	7.74	0.060	1.25	0.739	4.96	0.451	10.70	0.065	1.693	0.064	7.74	0.064	0.064	
2.68	0.324	7.88	0.060	1.40	0.706	5.04	0.490	10.91	0.065	1.995	0.062	7.92	0.062	0.062	
2.82	0.194	8.04	0.080	1.55	0.697	5.21	0.480	11.06	0.053	2.366	0.065	8.04	0.065	0.065	
2.88	0.136	8.28	0.080	1.62	0.666	5.38	0.469	11.24	0.053	2.730	0.069	8.28	0.069	0.069	
3.05	0.123	8.50	0.075	1.69	0.644	5.46	0.447	11.72	0.047	3.034	0.075	8.50	0.075	0.075	
3.29	0.114	8.74	0.097	1.78	0.664	5.53	0.406	12.23	0.018	4.246	0.075	8.74	0.075	0.075	
3.46	0.097	9.03	0.097	1.87	0.664	5.58	0.287	12.77	0.018	5.000	0.079	9.03	0.079	0.079	
3.53	0.125	9.17	0.067	1.98	0.678	5.60	0.175	12.90	0.036	5.943	0.076	9.17	0.076	0.076	
3.57	0.189	9.84	0.090	2.19	0.622	5.67	0.124	13.19	0.071	7.261	0.074	9.84	0.074	0.074	
3.90	0.253	10.15	0.055	2.23	0.422	5.75	0.100	13.53	0.070	8.146	0.060	10.15	0.060	0.060	
3.95	0.302	10.37	0.065	2.30	0.373	5.85	0.085	13.77	0.081	8.851	0.070	10.37	0.070	0.070	
4.16	0.249	10.58	0.057	2.37	0.359	5.89	0.098	13.97	0.103	9.351	0.093	10.58	0.093	0.093	
4.25	0.220	10.72	0.064	2.45	0.398	5.93	0.136	14.07	0.096	9.683	0.124	10.72	0.124	0.124	
4.29	0.232	11.21	0.043	2.53	0.460	6.07	0.125	14.11	0.116	9.795	0.151	11.21	0.151	0.151	
4.36	0.313	11.84	0.035	2.62	0.499	6.16	0.136	14.18	0.127	10.35	0.119	11.84	0.119	0.119	
4.43	0.351	12.17	0.023	2.70	0.373	6.31	0.098	14.35	0.127	10.81	0.190	12.17	0.190	0.190	
4.71	0.363	12.62	0.037	2.81	0.211	6.50	0.124	14.41	0.156	11.25	0.117	12.62	0.117	0.117	
4.96	0.366	13.26	0.044	2.88	0.124	6.61	0.136	14.49	0.192	13.03	0.117	13.26	0.117	0.117	
5.04	0.431	13.49	0.052	2.97	0.112	6.66	0.101	14.54	0.192	13.37	0.125	13.49	0.125	0.125	
5.15	0.431	13.76	0.083	3.06	0.126	6.79	0.113	14.64	0.182	13.37	0.144	13.76	0.144	0.144	
5.30	0.406	13.96	0.108	3.16	0.180	6.91	0.061	14.79	0.220	13.65	0.149	13.96	0.149	0.149	
5.44	0.373	14.11	0.091	3.23	0.157	7.13	0.066	14.89	0.253	14.16	0.130	14.11	0.130	0.130	
5.51	0.307	14.31	0.082	3.31	0.105	7.51	0.066	14.97	0.198	14.16	0.089	14.31	0.089	0.089	
5.57	0.270	14.44	0.092	3.43	0.093	7.98	0.052	15.06	0.178	14.52	0.080	14.44	0.080	0.080	
5.63	0.149	14.51	0.093	3.51	0.123	8.07	0.063	15.06	0.178	14.79	0.091	14.51	0.091	0.091	
5.70	0.113	14.79	0.125	3.61	0.212	8.16	0.063	15.06	0.178	14.93	0.116	14.79	0.116	0.116	
5.82	0.112	14.91	0.148	3.70	0.270	8.29	0.054	15.06	0.178	15.32	0.124	14.91	0.124	0.124	
5.93	0.133	15.05	0.179	3.75	0.311	8.49	0.054	15.06	0.178	16.00	0.117	15.05	0.117	0.117	
6.03	0.148	0.148	3.89	0.317	8.66	0.077	16.79	0.127	16.79	0.127	16.79	0.127	16.79	0.127	0.127
6.22	0.118	0.350	8.84	0.077	16.86	0.026	17.66	0.177	17.66	0.177	17.66	0.177	17.66	0.177	0.177
6.34	0.094	0.07	8.96	0.082	16.75	0.014	18.75	0.213	18.75	0.213	18.75	0.213	18.75	0.213	0.213
6.40	0.111	0.380	9.05	0.076	19.23	0.022	20.14	0.221	20.14	0.221	20.14	0.221	20.14	0.221	0.221
6.45	0.143	0.472	9.17	0.081	20.14	0.042	22.44	0.170	22.44	0.170	22.44	0.170	22.44	0.170	0.170
6.52	0.153	0.656	9.28	0.372	20.14	0.055	22.44	0.170	22.44	0.170	22.44	0.170	22.44	0.170	0.170

CURVE 7
 $T = 293^\circ$

CURVE 8
 $T = 338^\circ$

TABLE 15-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ]

λ	ρ	CURVE 8 (CONT.)	λ	ρ	CURVE 9 (CONT.)	λ	ρ	CURVE 10 (CONT.)	λ	ρ	CURVE 11 (CONT.)	λ	ρ	CURVE 12 (CONT.)
24.55	0.143	1.503	0.831	0.784	0.906	1.733	0.588	1.234	0.739	1.127	0.804			
26.36	0.156	1.569	0.831	0.826	0.898	1.740	0.572	1.292	0.711	1.177	0.797			
27.23	0.187	1.601	0.624	0.903	0.890	1.746	0.594	1.335	0.689	1.259	0.787			
27.86	0.230	1.625	0.813	0.963	0.886	1.751	0.624	1.370	0.675	1.325	0.778			
26.38	0.266	1.641	0.794	1.011	0.879	1.757	0.636	1.419	0.661	1.358	0.774			
28.71	0.349	1.652	0.761	1.083	0.861	1.759	0.657	1.475	0.642	1.420	0.772			
29.17	0.357	1.661	0.733	1.142	0.844	1.764	0.661	1.521	0.623	1.462	0.769			
30.69	0.343	1.679	0.715	1.167	0.834	1.770	0.659	1.549	0.607	1.503	0.767			
31.55	0.385	1.692	0.715	1.175	0.822	1.778	0.651	1.595	0.575	1.530	0.765			
32.36	0.376	1.713	0.732	1.179	0.795	1.784	0.665	1.624	0.556	1.549	0.764			
33.04	0.363	1.736	0.755	1.182	0.794	1.800	0.680	1.648	0.544	1.565	0.759			
34.51	0.384	1.769	0.776	1.192	0.831	1.661	0.532	1.589	0.750	1.615	0.742			
37.27	0.384	1.797	0.795	1.195	0.840	1.669	0.514	1.669	0.514	1.650	0.730			
		1.817	0.804	1.202	0.842	1.671	0.500	1.671	0.500	1.639	0.730			
		1.841	0.804	1.229	0.834	1.684	0.494	1.684	0.494	1.650	0.724			
		1.867	0.789	1.278	0.820	1.704	0.484	1.704	0.484	1.658	0.711			
		1.881	0.773	1.323	0.803	1.733	0.474	1.733	0.474	1.659	0.696			
		1.900	0.773	1.353	0.795	1.753	0.462	1.753	0.462	1.667	0.687			
		0.380	0.000	1.367	0.785	1.783	0.452	1.783	0.452	1.672	0.676			
		0.399	0.498	1.382	0.774	1.795	0.443	1.795	0.443	1.685	0.666			
		0.405	0.670	1.412	0.825	1.440	0.430	1.805	0.411	1.642	0.657			
		0.412	0.825	1.425	0.768	1.440	0.440	1.808	0.418	1.753	0.657			
		0.422	0.677	0.386	0.500	1.502	0.765	1.458	0.909	1.711	0.652			
		0.423	0.902	0.389	0.610	1.527	0.762	1.476	0.915	1.724	0.649			
		0.436	0.920	0.396	0.724	1.548	0.755	1.505	0.918	1.730	0.649			
		0.466	0.937	0.400	0.737	1.566	0.754	1.550	0.908	1.740	0.653			
		0.500	0.941	0.405	0.821	1.602	0.741	1.597	0.905	1.742	0.667			
		0.565	0.943	0.410	0.858	1.627	0.728	1.658	0.905	1.749	0.671			
		0.616	0.951	0.417	0.892	1.644	0.720	1.704	0.897	1.763	0.673			
		0.700	0.952	0.421	0.908	1.660	0.711	1.779	0.881	1.507	0.681			
		0.783	0.949	0.427	0.924	1.674	0.703	1.848	0.866	1.524	0.881			
		0.840	0.945	0.436	0.937	1.679	0.695	1.902	0.848	1.646	0.873			
		0.903	0.935	0.448	0.945	1.682	0.683	1.952	0.835	1.667	0.878			
		0.987	0.924	0.464	0.950	1.698	0.595	2.004	0.823	1.702	0.871			
		1.057	0.910	0.497	0.950	1.705	0.611	2.060	0.805	1.796	0.853			
		1.140	0.897	0.523	0.945	1.705	0.642	1.081	0.799	1.862	0.837			
		1.200	0.884	0.549	0.937	1.709	0.650	1.103	0.788	1.902	0.826			
		1.263	0.875	0.592	0.931	1.712	0.671	1.127	0.776	1.928	0.823			
		1.346	0.849	0.663	0.931	1.718	0.667	1.148	0.770	1.964	0.819			
		1.388	0.839	0.689	0.929	1.720	0.638	1.180	0.764	1.943	0.816			
		1.441	0.833	0.725	0.922	1.725	0.614	1.204	0.755	1.966	0.812			
		1.200	0.884	0.549	0.937	1.709	0.650	1.103	0.788	1.902	0.826			
		1.263	0.875	0.592	0.931	1.712	0.671	1.127	0.776	1.928	0.823			
		1.346	0.849	0.663	0.931	1.718	0.667	1.148	0.770	1.964	0.819			
		1.388	0.839	0.689	0.929	1.720	0.638	1.180	0.764	1.943	0.816			
		1.441	0.833	0.725	0.922	1.725	0.614	1.204	0.755	1.966	0.812			

CURVE 13
 $T = 293$.

TABLE 15-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ]

CURVE 13 (CONT.)		CURVE 13 (CONT.)		CURVE 13 (CONT.)	
λ	ρ	λ	ρ	λ	ρ
0.401	0.327	5.715	0.123	19.634	0.143
0.406	0.507	5.808	0.069	19.953	0.183
0.427	0.757	5.984	0.093	20.701	0.215
0.433	0.812	6.095	0.197	21.528	0.236
0.444	0.839	6.283	0.248	22.856	0.248
0.460	0.859	6.412	0.278	24.210	0.235
0.493	0.863	6.577	0.257	25.941	0.209
0.542	0.868	6.776	0.086	100.00	0.200
0.624	0.856	6.902	0.080		
0.738	0.832	7.195	0.097		
0.912	0.798	7.345	0.106		
1.189	0.743	7.674	0.079		
1.531	0.676	8.184	0.068		
1.653	0.644	8.650	0.068		
1.879	0.532	5.984	0.093		
2.065	0.525	6.095	0.197		
2.291	0.440	6.281	0.248		
2.404	0.387	6.412	0.278		
2.455	0.401	6.577	0.257		
2.518	0.409	6.776	0.086		
2.565	0.396	6.902	0.080		
2.735	0.278	7.195	0.097		
2.871	0.165	7.345	0.106		
2.904	0.142	7.674	0.079		
3.013	0.130	8.185	0.068		
3.177	0.141	8.650	0.068		
3.304	0.118	9.311	0.078		
3.327	0.091	10.023	0.104		
3.404	0.084	16.617	0.104		
3.516	0.093	11.695	0.077		
3.593	0.123	12.473	0.064		
3.664	0.182	13.305	0.064		
3.715	0.216	13.396	0.081		
3.899	0.266	14.555	0.105		
4.102	0.300	15.066	0.116		
4.406	0.332	15.922	0.105		
4.842	0.352	16.673	0.095		
5.200	0.343	17.418	0.095		
5.458	0.317	18.537	0.107		
5.598	0.289	19.187	0.127		

c. Normal Spectral Absorptance (Wavelength Dependence)

There are five sets of experimental data available for the wavelength dependence of the normal spectral absorptance of acrylic resin coatings as listed in Table 15-9 and shown in Figure 15-6. Specimen characterization and measurement information for the data are given in Table 15-8. Four of the data sets each contains a single point ($10.6 \mu\text{m}$). Therefore, as a consequence of the limited data, only provisional values of normal spectral emittance are presented here as listed in Table 15-7 and shown in Figure 15-5. The provisional values are for the "white acrylic paint" on stainless steel substrate. The estimated uncertainty is within $\pm 30\%$.

TABLE 15-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN (WAVELLENGTH DEPENDENCE)

(WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	λ	α
WHITE PAINT S. STEEL SUBSTR $T = 293$			
0.32	0.953	11.30	0.934
0.36	0.936	11.50	0.944
0.37	0.793	12.00	0.952
0.40	0.538	12.50	0.955
0.45	0.372	13.00	0.962
0.50	0.264	13.50	0.956
0.65	0.275	14.00	0.944
0.30	0.275	14.50	0.928
1.00	0.320	15.00	0.900
1.50	0.465		
2.00	0.555		
2.50	0.643		
3.00	0.795		
3.20	0.883		
3.50	0.930		
3.60	0.948		
3.70	0.940		
3.80	0.390		
4.00	0.795		
4.40	0.696		
4.80	0.665		
5.00	0.655		
5.50	0.683		
5.70	0.760		
5.80	0.317		
5.90	0.926		
6.00	0.352		
6.50	0.503		
6.75	0.765		
6.80	0.876		
7.00	0.390		
7.50	0.321		
8.00	0.342		
8.50	0.323		
9.00	0.930		
9.50	0.925		
9.80	0.387		
10.00	0.888		
10.60	0.925		

**WHITE PAINT
S. STEEL SUBSTR
 $T = 293$ (CONT.)**




FIGURE 15-5. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).




FIGURE 15-6. EXPERIMENTAL INFRARED SPECTRAL ABSORBTION OF ACRYLIC RESIN COATINGS (WAVELENGTH DEPENDENCE).

TABLE 15-8. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN COATING (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	T39754	Anderson, R. B.	1965	0.38-2.0	~293	White Paint	3 mil spray coating of W. P. Fuller Co. 171W-560 Acrylic Vehicle gloss white paint on a white substrate; data were extracted from figure; $\theta \sim 0^\circ$. Acrylic-Mil-L-1953B-black; Mil-P-7968 0.7 mil thick primer; 3.0 mil thick top coat; an IR-9 Beckman spectrometer was used for measurements.
2	A00004	Firsdon, R.	1968	10.6	300	Acrylic (black)	The above specimen; a calorimeter was used for measurements.
3	A00004	Firsdon, R.	1968	10.6	300	Acrylic (black)	Acrylic-Mil-C-81352-white; Mil-P-23377-0.5 mil thick primer; 1.7 mil thick top coat; an IR-9 Beckman spectrometer was used.
4	A00004	Firsdon, R.	1969	10.6	300	Acrylic (white)	The above specimen; a calorimeter was used for measurements.
5	A00004	Firsdon, R.	1968	10.6	300	Acrylic (white)	The above specimen; a calorimeter was used for measurements.

TABLE 15-9. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	CURVE 1 $T = 293.$	λ	α	CURVE 4 $T = 300.$
0.400	0.732		10.6	0.97	
0.404	0.453				
0.409	0.338				
0.415	0.239				
0.420	0.176				
0.432	0.139		13.6	0.94	
0.446	0.112				
0.459	0.199				
0.495	0.394				
0.592	0.394				
0.704	0.037				
0.800	0.101				
0.903	0.105				
1.000	0.113				
1.086	0.124				
1.155	0.140				
1.229	0.161				
1.298	0.181				
1.399	0.213				
1.482	0.242				
1.571	0.273				
1.684	0.313				
1.804	0.356				
1.902	0.395				
2.000	0.440				

CURVE 2
 $T = 305.$

10.6 0.95

CURVE 3
 $T = 300.$

10.5 0.96

d. Normal Spectral Absorptance (Temperature Dependence)

There is no experimental data available for the temperature dependence of the normal spectral absorptance of acrylic resins. However, Frisdon [A00004] measured the absorptance of acrylic paints as a function of the incident power of CO₂ laser. His results show that there is very small decreasing or no change in the absorptance value for the incident power of CO₂ laser up to 130 watts. As the incident power equals to 60 watts or higher, there is instantaneous surface charring happening at the point of incidence. Probably this charring occurs at the decomposing temperature. Therefore, we can roughly say that the absorptance of acrylic paints at wavelength 10.6 μm is independent of temperature in the temperature region from 293 K to 400 K (decomposing temperature). Figure 15-7 shows the provisional value for the normal spectral absorptance of acrylic white and black paints as a function of temperature.

The absorptance is 0.97 for white paint and 0.95 for black paint. The estimated uncertainty is within $\pm 20\%$.




FIGURE 15-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ACRYLIC RESIN COATING
(TEMPERATURE DEPENDENCE)

e. Normal Spectral Transmittance (Wavelength Dependence)

There are 30 sets of experimental data available for the wavelength dependence of the normal spectral transmittance of acrylic resins as listed in Table 15-12 and shown in Figure 15-8 (bulk materials) and Figure 15-9 (thin films). Specimen characterization and measurement information for the data are given in Table 15-11. There were 20 different kinds of acrylic resins used for measurement; their transmittance values were quite different. Therefore, only provisional values are reported here as listed in Table 15-10 and shown in Figure 15-7. The provisional values are for the acrylic sheet with thickness 6.3 mm at 293 K. The estimated uncertainty is within $\pm 30\%$.

TABLE 15-1C. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ
ACRYLIC SHEET 6.3MM THICK $T = 293$ (CONT.)							
0.42	0.82	0.42	1.50	0.42	0.61	0.42	0.61
0.43	0.81	0.43	1.54	0.43	0.61	0.43	0.61
0.45	0.81	0.45	1.59	0.45	0.60	0.45	0.60
0.47	0.80	0.47	1.62	0.47	0.59	0.47	0.59
0.49	0.81	0.49	1.64	0.49	0.59	0.49	0.59
0.50	0.83	0.50	1.70	0.50	0.54	0.50	0.54
0.51	0.83	0.51	1.74	0.51	0.56	0.51	0.56
0.52	0.83	0.52	1.76	0.52	0.48	0.52	0.48
0.54	0.84	0.54	1.79	0.54	0.46	0.54	0.46
0.55	0.85	0.55	1.81	0.55	0.45	0.55	0.45
0.56	0.86	0.56	1.84	0.56	0.45	0.56	0.45
0.58	0.88	0.58	1.85	0.58	0.49	0.58	0.49
0.69	0.90	0.69	1.87	0.69	0.47	0.69	0.47
0.71	0.92	0.71	1.88	0.71	0.49	0.71	0.49
0.72	0.92	0.72	1.89	0.72	0.51	0.72	0.51
0.75	0.92	0.75	1.91	0.75	0.53	0.75	0.53
0.77	0.92	0.77	1.92	0.77	0.57	0.77	0.57
0.82	0.91	0.82	1.94	0.82	0.63	0.82	0.63
0.84	0.91	0.84	1.95	0.84	0.66	0.84	0.66
0.88	0.89	0.88	1.96	0.88	0.71	0.88	0.71
0.91	0.88	0.91	1.97	0.91	0.72	0.91	0.72
0.94	0.88	0.94	1.98	0.94	0.76	0.94	0.76
0.98	0.89	0.98	2.00	0.98	0.77	0.98	0.77
1.03	0.89	1.03	2.01	1.03	0.79	1.03	0.79
1.07	0.91	1.07	2.03	1.07	0.82	1.07	0.82
1.10	0.90	1.10	2.05	1.10	0.86	1.10	0.86
1.13	0.89	1.13	2.09	1.13	0.81	1.13	0.81
1.17	0.89	1.17	2.16	1.17	0.82	1.17	0.82
1.20	0.88	1.20	2.31	1.20	0.82	1.20	0.82
1.22	0.87	1.22	2.51	1.22	0.83	1.22	0.83
1.24	0.86	1.24	2.62	1.24	0.82	1.24	0.82
1.26	0.84	1.26	2.64	1.26	0.81	1.26	0.81
1.29	0.82	1.29	2.66	1.29	0.81	1.29	0.81
1.32	0.75	1.32	2.75	1.32	0.75	1.32	0.75
1.35	0.71	1.35	2.83	1.35	0.71	1.35	0.71
1.38	0.66	1.38	2.88	1.38	0.66	1.38	0.66
1.41	0.64	1.41	2.91	1.41	0.64	1.41	0.64
1.43	0.53	1.43	2.93	1.43	0.53	1.43	0.53
1.45	0.62	1.45	2.95	1.45	0.62	1.45	0.62




FIGURE 15-8. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE).




FIGURE 15-9. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELLENGTH DEPENDENCE).




FIGURE 15-10. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC THIN FILMS (WAVELENGTH DEPENDENCE).

TABLE I5-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESINS (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T40338	Acitelli, M.A., Gumby, W.L., and Naujokas, A.A.	1966	0.2-2.2	298	Poly (Allyl-Methacrylate)	7.13 mm thickness; measurements were determined by Cary Spectrophotometer Model 14; the sample used was disc approx. 50 mm in diameter.
2 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	298	Poly (Allyl-Methacrylate)	The above specimen; after 100 standard fade hours of solarization.
3 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	298	Poly (Isobutyl Methacrylate)	6.67 mm thickness; measurements were determined by Cary Spectrophotometer Model 14; the sample used was disc approx. 50 mm in diameter.
4 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	298	Poly (Isobutyl Methacrylate)	The above specimen; after 100 standard fade hours of solarization.
5 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	298	Poly (ethylene glycol dimethacrylate)	6.95 mm thick disc approx. 50 mm in diameter; Cary Spectrophotometer Model 14 was employed.
6 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	298	Poly (cyclohexyl methacrylate)	6.75 mm thick disc specimen approx. 50 mm in diameter; Cary Spectrophotometer was employed.
7 TI9914	Moore, L.E., Prastein, M., Tourpkins, E.H., and Van Ostenburg, D.O.	1958	2-15.0	293	Poly-n-butyl methacrylate	Refractive index 1.48 at $\lambda = 5893 \text{ \AA}$; unknown thickness.
8 T34840	Boyer-Kawenold, F.	1966	2.5-6.5	293	Polyacrylic Acid	Specimen was obtained by making pellets with KBr and measured by Perkin-Elmer spectrometer; unfractionated polymer with molecular weight 25 000 determined by viscosimetric technique.
9 T47094	Holland, W.R.	1967	0.2-2.6	293	Acrylic Sheets	0.25 in. thick sheets; Perkin-Elmer Model 99 monochromator was used.
10 T47094	Holland, W.R.	1967	0.2-2.6	293	Acrylic Sheets	Similar to the above specimen.
11 T49135	Hirai, T. and Nakada, O.	1968	2.5-16	~293	Polyacrylonitrile (PAN)	Thin film was formed on a rock salt crystal plate (30 mm diameter and 2 mm thick); infrared spectra was measured by using a Hitachi E.P.-2 infrared spectrometer; data were extracted from figure; $\theta \sim 0^\circ$.
12 T64206	Pemington, C.W. and Moore, G.L.	1971	0.4-2.6	~293	Acrylic Panel	Reflective type acrylic panel; transmittance spectra was obtained by using a DR-2 spectrometer; data were extracted from figure; $\theta \sim 0^\circ$.
13 T62597	Gilligan, J.E. and Brzuskiwicz, J.	1971	0.2-2.6	~293	DuPont Evacite 6011 (methyl-methacrylate)	0.015 in. thick sprayed film; Beckman DK-2 spectrometer was used; data were extracted from figure
14 T62597	Gilligan, J.E. and Brzuskiwicz, J.	1971	0.2-2.6	~293	DuPont Evacite 6011 (methyl-methacrylate)	Similar to the above specimen except 0.032 in. thick.
15 T62597	Gilligan, J.E. and Brzuskiwicz, J.	1971	0.2-2.6	~293	DuPont Evacite 6011 (methyl-methacrylate)	Similar to the above specimen except 0.054 in. thick.
16 T62597	Gilligan, J.E. and Brzuskiwicz, J.	1971	0.2-2.6	~293	DuPont Evacite 6011 (methyl-methacrylate)	0.035 in. thick film was obtained by a doctor blade technique; Beckman DK-2 spectrometer was used; data were extracted from figure.
17 T76612	Kagarise, R.E. and Weinberger, L.A.	1954	2-15	~293	Hypalon P-4	The specimen was obtained from DuPont Co.; dissolved in C_6H_6 and the resulting viscous solution was spread uniformly over a rock salt on KBr plate; the solvent was removed by heating in vacuum on normal evaporation at room temperature; a Perkin-Elmer Model 21 double beam spectrophotometer was used; data were extracted from figure.

TABLE 15-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESINS (Wavelength Decendence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
18 T32490	Cobble, M. H., Fang, P. C., and Lumsdaine, E.	1966	0.3-1.6	~293	Methyl Methacrylate	The transmission spectra of the 2.5 in. slab of methyl methacrylate plastic is determined using a Beckman spectrometer; data were corrected for surface reflectance; data were extracted from figure; $\theta \sim 0^\circ$.	
19 T76795	Stimler, S. S., and Kagarise, R. E.	1966	2.5-25	~293	Zerlon-150 (Methyl methacrylate- styrene copolymer)	Film specimen was obtained from Dow Chemical; a Beckman IR-12 spectrophotometer was used to obtain spectra; data were extracted from figure; $\theta \sim 0^\circ$.	
20 T76795	Stimler, S. S., and Kagarise, R. E.	1966	2.5-25	~293	Bavick 11-X-1 (Methyl methacrylate- or methylstyrene copolymer)	Film specimen was obtained from J. T. Baker Chemical Co.; other specifications similar to the above.	
21 T76795	Stimler, S. S., and Kagarise, R. E.	1966	2.5-25	~293	Implax	Film specimen was obtained from Rohm and Haas Co.; other specifications similar to the above.	
22 T66740	Janardhanan, K. K., Ramasubramanian, P. K., Rao, H. N. V., Subramanian, V., and Suryanarayana, C. V.	1972	1.0-2.8	~293	Persepex in methyl methacrylate	The transmission was studied by using a Carl Zeiss SPM-2 monochromator; $\theta \sim 0^\circ$.	
23 T76798	Lara, M. O.	1967	2.5-25	~293	Acrylic, Lacquer Erolite MIL-L-61352 (Andrew Brown Co.)	The specimen was condensed pyrolysis on potassium bromide on sodium chloride; a Beckman IR-9 double beam, prism-grating infrared spectrophotometer was used to obtain the spectra; data were extracted from figure; $\theta \sim 0^\circ$.	
24 T76798	Lara, M. O.	1967	2.5-25	~293	Acrylic LATEX Spred House Paint (The Glidden Co.)	Similar to the above specimen.	
25 T76798	Lara, M. O.	1967	2.5-25	~293	Orion (Polyacrylonitrile)	Similar to the above specimen.	
26 T76798	Lara, M. O.	1967	2.5-25	~293	Orion (Polyacrylonitrile)	Similar to the above specimen.	
27 T77043	Bactoniu, P.	1969	2.5-15	~293	Orion 42 (Polyacrylonitrile)	No details given; data were extracted from figure; $\theta \sim 0^\circ$.	
28 T77043	Bactoniu, P.	1969	2.5-15	~293	(Polyacrylonitrile)	Similar to the above specimen.	
29 T77043	Bactoniu, P.	1969	2.5-15	~293	Creslan MMA	Similar to the above specimen.	
30 E26638	Carbajal, B. G. III	1966	2.5-25	~293	Methylmethacrylate; data were extracted from the figure; $\theta \sim 0^\circ$.		

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 1 $T = 293$.		CURVE 1 (CONT.)		CURVE 2 (CONT.)										
0.394	0.200	1.567	0.292	0.695	0.912	1.329	0.797	1.870	0.332	0.366	0.721	0.378	0.770	0.378	0.770	
0.400	0.207	1.596	0.308	0.803	0.928	1.352	0.610	1.631	0.303	0.303	0.593	0.387	0.593	0.387	0.593	
0.406	0.207	1.641	0.300	0.842	0.928	1.361	0.605	1.894	0.197	0.197	0.827	0.395	0.827	0.395	0.827	
0.412	0.207	1.648	0.264	0.657	0.917	1.365	0.524	1.902	0.105	0.105	0.242	0.410	0.242	0.410	0.242	
0.417	0.211	1.675	0.238	0.869	0.869	1.374	0.524	1.913	0.214	0.214	0.410	0.410	0.410	0.410	0.410	
0.419	0.211	1.675	0.238	0.869	0.869	1.387	0.544	1.919	0.257	0.257	0.435	0.435	0.435	0.435	0.435	
0.515	0.211	1.702	0.122	0.687	0.899	1.398	0.528	1.925	0.267	0.267	0.474	0.474	0.474	0.474	0.474	
0.537	0.208	1.738	0.069	0.901	0.891	1.405	0.569	1.932	0.257	0.257	0.534	0.534	0.534	0.534	0.534	
0.573	0.209	1.765	0.041	0.919	0.901	1.415	0.553	1.944	0.212	0.212	0.673	0.673	0.673	0.673	0.673	
0.627	0.217	1.795	0.032	0.936	0.911	1.416	0.553	1.954	0.217	0.217	0.557	0.557	0.557	0.557	0.557	
0.665	0.223	1.823	0.045	0.963	0.915	1.426	0.583	1.963	0.267	0.267	0.649	0.649	0.649	0.649	0.649	
0.745	0.236	1.845	0.079	1.004	0.895	1.435	0.583	1.963	0.267	0.267	0.745	0.745	0.745	0.745	0.745	
0.766	0.253	1.871	0.100	1.036	0.895	1.453	0.663	1.972	0.288	0.288	0.797	0.797	0.797	0.797	0.797	
0.780	0.262	1.891	0.117	1.058	0.907	1.467	0.712	1.978	0.302	0.302	0.895	0.895	0.895	0.895	0.895	
0.504	0.270	1.928	0.109	1.080	0.907	1.486	0.764	1.988	0.239	0.239	0.841	0.841	0.841	0.841	0.841	
0.830	0.269	1.941	0.005	1.091	0.833	1.509	0.793	1.995	0.237	0.237	0.657	0.657	0.657	0.657	0.657	
0.873	0.281	1.991	0.100	1.100	0.886	1.524	0.808	2.004	0.211	0.211	0.665	0.665	0.665	0.665	0.665	
0.914	0.281	1.992	0.135	1.113	0.795	1.540	0.808	2.014	0.223	0.223	0.880	0.880	0.880	0.880	0.880	
0.949	0.290	2.051	0.145	1.116	0.818	1.559	0.784	2.022	0.204	0.204	0.895	0.895	0.895	0.895	0.895	
0.986	0.295	2.075	0.123	1.136	0.603	1.563	0.745	2.032	0.191	0.191	0.909	0.909	0.909	0.909	0.909	
1.021	0.338	2.143	0.359	1.140	0.594	1.577	0.751	2.047	0.215	0.215	0.926	0.926	0.926	0.926	0.926	
1.043	0.293	2.188	0.020	1.143	0.594	1.594	0.705	2.056	0.219	0.219	0.959	0.959	0.959	0.959	0.959	
1.059	0.259	2.245	0.200	0.600	1.153	0.532	1.601	0.652	2.069	0.172	0.172	0.955	0.955	0.955	0.955	0.955
1.079	0.194	2.059	0.292	0.600	1.159	0.646	1.621	0.669	2.081	0.151	0.151	0.979	0.979	0.979	0.979	0.979
1.109	0.153	1.161	0.394	0.594	1.171	0.598	1.626	0.645	2.098	0.000	0.000	0.936	0.936	0.936	0.936	0.936
1.127	0.169	1.169	0.316	0.644	1.176	0.590	1.629	0.665	2.114	0.000	0.000	0.833	0.833	0.833	0.833	0.833
1.148	0.225	1.225	0.326	0.684	1.186	0.614	1.640	0.270	2.124	0.019	0.019	1.059	1.059	1.059	1.059	1.059
1.167	0.263	1.263	0.336	0.149	1.197	0.674	1.648	0.300	2.140	0.019	0.019	1.075	1.075	1.075	1.075	1.075
1.189	0.303	1.303	0.346	0.644	1.223	0.640	1.665	0.040	2.150	0.022	0.022	1.080	1.080	1.080	1.080	1.080
1.205	0.312	1.305	0.316	0.720	1.235	0.866	1.674	0.015	2.165	0.017	0.017	1.086	1.086	1.086	1.086	1.086
1.225	0.318	1.318	0.367	0.307	1.249	0.875	1.699	0.051	2.172	0.042	0.042	1.107	1.107	1.107	1.107	1.107
1.250	0.318	1.318	0.377	0.832	1.263	0.892	1.720	0.051	2.180	0.042	0.042	1.114	1.114	1.114	1.114	1.114
1.263	0.303	1.303	0.396	0.854	1.267	0.869	1.728	0.041	2.194	0.049	0.049	1.124	1.124	1.124	1.124	1.124
1.283	0.260	1.305	0.403	0.674	1.274	0.869	1.744	0.049	2.206	0.049	0.049	1.133	1.133	1.133	1.133	1.133
1.365	0.164	0.413	0.884	1.279	0.849	1.755	0.116	2.214	0.043	0.043	1.147	1.147	1.147	1.147	1.147	
1.410	0.132	0.444	0.694	1.284	0.857	1.771	0.170	2.220	0.060	0.060	1.155	1.155	1.155	1.155	1.155	
1.446	0.117	0.539	0.901	1.288	0.877	1.793	0.220	2.220	0.291	0.291	1.163	1.163	1.163	1.163	1.163	
1.436	0.143	0.549	0.894	1.304	0.877	1.807	0.245	2.220	0.302	0.302	1.170	1.170	1.170	1.170	1.170	
1.521	0.183	0.558	0.921	1.312	0.865	1.831	0.292	2.220	0.322	0.322	1.184	1.184	1.184	1.184	1.184	
1.564	0.264	0.617	0.901	1.325	0.784	1.846	0.332	2.220	0.356	0.356	1.203	1.203	1.203	1.203	1.203	

CURVE 2
 $T = 296$.

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

CURVE 2(CONT.)	λ	τ	CURVE 2(CONT.)			CURVE 2(CONT.)			CURVE 3(CONT.)			CURVE 3(CONT.)			CURVE 3(CONT.)		
			λ	τ	CURVE 2(CONT.)	λ	τ	CURVE 3(CONT.)									
1.216	0.793	1.644	0.245	2.396	0.000	0.932	0.884	1.602	0.737	2.140	0.055	1.226	0.931	1.644	0.710	2.151	0.075
1.220	0.931	1.650	0.223	2.110	0.000	0.951	0.883	1.611	0.707	2.158	0.061	1.229	0.953	1.650	0.624	2.173	0.091
1.229	0.953	1.661	0.043	2.122	0.021	0.952	0.869	1.641	0.620	2.173	0.064	1.252	0.353	1.673	0.021	2.148	0.200
1.252	0.353	1.673	0.021	2.137	0.013	0.970	0.826	1.664	0.185	2.173	0.064	1.259	0.324	1.680	0.021	2.158	0.230
1.259	0.324	1.680	0.017	2.148	0.021	1.503	0.857	1.670	0.169	2.173	0.064	1.262	0.362	1.689	0.012	2.158	0.230
1.262	0.362	1.689	0.012	2.158	0.015	1.052	0.670	1.572	0.169	2.173	0.064	1.269	0.355	1.697	0.022	2.167	0.230
1.277	0.843	1.705	0.250	2.167	0.029	1.082	0.883	1.678	0.036	2.173	0.230	1.285	0.868	1.714	0.039	2.156	0.230
1.285	0.868	1.714	0.050	2.173	0.041	1.121	0.850	1.701	0.011	2.192	0.230	1.303	0.858	1.726	0.041	2.156	0.230
1.299	0.358	1.726	0.542	2.183	0.053	1.138	0.755	1.711	0.026	2.192	0.230	1.313	0.756	1.736	0.053	2.174	0.230
1.303	0.853	1.736	0.533	2.192	0.053	1.144	0.671	1.722	0.026	2.192	0.230	1.319	0.773	1.750	0.053	2.174	0.230
1.313	0.805	1.756	0.136	2.192	0.053	1.155	0.650	1.729	0.021	2.192	0.230	1.319	0.773	1.772	0.053	2.174	0.230
1.319	0.773	1.772	0.183	2.192	0.053	1.183	0.376	1.748	0.059	2.192	0.230	1.325	0.793	1.787	0.053	2.174	0.230
1.325	0.793	1.787	0.215	2.192	0.053	1.209	0.691	1.763	0.054	2.192	0.230	1.325	0.793	1.793	0.053	2.174	0.230
1.347	0.599	1.807	0.250	2.192	0.053	1.218	0.727	1.774	0.162	2.192	0.230	1.356	0.599	1.826	0.275	2.174	0.230
1.356	0.599	1.826	0.292	2.192	0.053	1.223	0.787	1.781	0.183	2.192	0.230	1.356	0.599	1.835	0.292	2.174	0.230
1.352	0.532	1.835	0.314	2.192	0.053	1.241	0.829	1.796	0.169	2.192	0.230	1.352	0.532	1.854	0.314	2.174	0.230
1.350	0.521	1.848	0.324	2.192	0.053	1.321	0.643	1.828	0.233	2.192	0.230	1.350	0.521	1.868	0.324	2.174	0.230
1.379	0.532	1.853	0.324	2.192	0.053	1.332	0.722	1.837	0.309	2.192	0.230	1.379	0.532	1.871	0.324	2.174	0.230
1.393	0.532	1.871	0.313	2.192	0.053	1.347	0.766	1.855	0.343	2.192	0.230	1.393	0.532	1.889	0.343	2.174	0.230
1.401	0.555	1.889	0.211	2.192	0.053	1.355	0.795	1.883	0.314	2.192	0.230	1.401	0.548	1.908	0.355	2.174	0.230
1.409	0.548	1.908	0.198	2.192	0.053	1.362	0.826	1.894	0.260	2.192	0.230	1.409	0.548	1.923	0.362	2.174	0.230
1.416	0.573	1.925	0.196	2.192	0.053	1.375	0.846	1.903	0.247	2.192	0.230	1.416	0.573	1.943	0.375	2.174	0.230
1.416	0.573	1.925	0.216	2.192	0.053	1.382	0.851	1.922	0.227	2.192	0.230	1.416	0.573	1.943	0.382	2.174	0.230
1.427	0.533	1.933	0.227	2.192	0.053	1.391	0.861	1.931	0.227	2.192	0.230	1.427	0.533	1.951	0.391	2.174	0.230
1.448	0.659	1.946	0.255	2.192	0.053	1.407	0.873	1.949	0.227	2.192	0.230	1.448	0.659	1.961	0.395	2.174	0.230
1.456	0.693	1.954	0.243	2.192	0.053	1.424	0.886	1.962	0.227	2.192	0.230	1.456	0.693	1.971	0.395	2.174	0.230
1.471	0.731	1.974	0.219	2.192	0.053	1.434	0.896	1.971	0.227	2.192	0.230	1.471	0.731	1.984	0.395	2.174	0.230
1.483	0.765	1.986	0.216	2.192	0.053	1.444	0.906	1.971	0.227	2.192	0.230	1.483	0.765	1.996	0.395	2.174	0.230
1.511	0.792	2.014	0.223	2.192	0.053	1.454	0.916	1.981	0.227	2.192	0.230	1.511	0.792	2.034	0.395	2.174	0.230
1.535	0.792	2.014	0.223	2.192	0.053	1.464	0.926	1.981	0.227	2.192	0.230	1.535	0.792	2.034	0.395	2.174	0.230
1.560	0.739	2.043	0.219	2.192	0.053	1.474	0.936	1.981	0.227	2.192	0.230	1.560	0.739	2.054	0.395	2.174	0.230
1.618	0.101	2.054	0.223	2.192	0.053	1.484	0.946	1.981	0.227	2.192	0.230	1.618	0.101	2.073	0.395	2.174	0.230
1.622	0.103	2.055	0.176	2.192	0.053	1.494	0.954	1.981	0.227	2.192	0.230	1.622	0.103	2.073	0.395	2.174	0.230
1.633	0.303	2.075	0.155	2.192	0.053	1.504	0.962	1.981	0.227	2.192	0.230	1.633	0.303	2.085	0.395	2.174	0.230
1.640	0.322	2.089	0.056	2.192	0.053	1.514	0.972	1.981	0.227	2.192	0.230	1.640	0.322	2.101	0.395	2.174	0.230

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 4 (CONT.)	CURVE 4 (CONT.)			CURVE 5 (CONT.)			CURVE 5 (CONT.)			CURVE 5 (CONT.)			CURVE 6 (CONT.)		
			λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	
0.923	0.854	1.527	0.789	0.200	0.000	1.369	0.497	2.209	0.059	1.209	0.708	1.216	0.754	1.216	0.754		
0.946	0.864	1.538	0.789	0.300	0.000	1.388	0.445	1.228	0.512	1.394	0.445	1.243	0.559	1.243	0.559		
0.955	0.847	1.552	0.776	0.317	0.011	1.425	0.393	1.265	0.891	1.425	0.425	1.265	0.891	1.265	0.891		
0.970	0.860	1.572	0.745	0.329	0.011	1.451	0.497	1.470	0.538	1.470	0.538	1.470	0.538	1.470	0.538		
0.991	0.845	1.599	0.712	0.363	0.011	1.497	0.497	1.528	0.692	1.528	0.692	1.528	0.692	1.528	0.692		
1.025	0.834	1.617	0.679	0.381	0.590	1.557	0.637	1.577	0.637	1.577	0.637	1.577	0.637	1.577	0.637		
1.026	0.845	1.614	0.597	0.412	0.723	1.598	0.677	1.598	0.677	1.598	0.677	1.598	0.677	1.598	0.677		
1.056	0.847	1.667	0.156	0.432	0.775	1.643	0.857	1.643	0.857	1.643	0.857	1.643	0.857	1.643	0.857		
1.071	0.858	1.683	0.022	0.861	0.852	1.647	0.852	1.647	0.852	1.647	0.852	1.647	0.852	1.647	0.852		
1.093	0.859	1.696	0.014	0.471	0.819	1.610	0.664	1.610	0.664	1.610	0.664	1.610	0.664	1.610	0.664		
1.114	0.846	1.708	0.029	0.498	0.837	1.620	0.613	1.620	0.613	1.620	0.613	1.620	0.613	1.620	0.613		
1.125	0.807	1.722	0.025	0.559	0.850	1.631	0.623	1.631	0.623	1.631	0.623	1.631	0.623	1.631	0.623		
1.144	0.552	1.731	0.024	0.822	0.857	1.643	0.858	1.643	0.858	1.643	0.858	1.643	0.858	1.643	0.858		
1.154	0.515	1.750	0.059	0.861	0.852	1.647	0.527	1.647	0.527	1.647	0.527	1.647	0.527	1.647	0.527		
1.164	0.504	1.759	0.059	0.882	0.843	1.658	0.476	1.658	0.476	1.658	0.476	1.658	0.476	1.658	0.476		
1.175	0.465	1.771	0.119	0.906	0.813	1.673	0.388	1.673	0.388	1.673	0.388	1.673	0.388	1.673	0.388		
1.183	0.363	1.790	0.179	0.939	0.815	1.689	0.073	1.689	0.073	1.689	0.073	1.689	0.073	1.689	0.073		
1.192	0.465	1.793	0.169	0.954	0.827	1.694	0.073	1.694	0.073	1.694	0.073	1.694	0.073	1.694	0.073		
1.205	0.653	1.823	0.243	0.962	0.913	1.696	0.042	1.696	0.042	1.696	0.042	1.696	0.042	1.696	0.042		
1.222	0.770	1.827	0.319	0.972	0.829	1.723	0.014	1.723	0.014	1.723	0.014	1.723	0.014	1.723	0.014		
1.233	0.323	1.850	0.414	1.018	0.866	1.744	0.035	1.744	0.035	1.744	0.035	1.744	0.035	1.744	0.035		
1.261	0.327	1.876	0.329	1.051	0.916	1.768	0.075	1.768	0.075	1.768	0.075	1.768	0.075	1.768	0.075		
1.266	0.447	1.888	0.292	1.094	0.818	1.738	0.045	1.738	0.045	1.738	0.045	1.738	0.045	1.738	0.045		
1.286	0.835	1.899	0.258	1.105	0.818	1.855	0.205	1.855	0.205	1.855	0.205	1.855	0.205	1.855	0.205		
1.312	0.833	1.905	0.253	1.120	0.798	1.868	0.221	1.868	0.221	1.868	0.221	1.868	0.221	1.868	0.221		
1.325	0.804	1.922	0.296	1.134	0.742	1.885	0.188	1.885	0.188	1.885	0.188	1.885	0.188	1.885	0.188		
1.347	0.657	1.947	0.235	1.146	0.696	1.902	0.032	1.902	0.032	1.902	0.032	1.902	0.032	1.902	0.032		
1.352	0.537	1.967	0.293	1.173	0.500	1.994	0.075	1.994	0.075	1.994	0.075	1.994	0.075	1.994	0.075		
1.359	0.456	1.983	0.258	1.184	0.490	1.931	0.125	1.931	0.125	1.931	0.125	1.931	0.125	1.931	0.125		
1.366	0.433	2.015	0.337	1.203	0.524	1.949	0.120	1.949	0.120	1.949	0.120	1.949	0.120	1.949	0.120		
1.375	0.448	2.026	0.352	1.222	0.535	1.980	0.213	1.980	0.213	1.980	0.213	1.980	0.213	1.980	0.213		
1.384	0.430	2.033	0.337	1.233	0.629	1.994	0.225	1.994	0.225	1.994	0.225	1.994	0.225	1.994	0.225		
1.391	0.483	2.067	0.249	1.248	0.713	2.012	0.225	2.012	0.225	2.012	0.225	2.012	0.225	2.012	0.225		
1.392	0.494	2.083	0.253	1.256	0.751	2.050	0.250	2.050	0.250	2.050	0.250	2.050	0.250	2.050	0.250		
1.401	0.455	2.100	0.130	1.250	0.790	2.077	0.180	2.077	0.180	2.077	0.180	2.077	0.180	2.077	0.180		
1.414	0.523	2.130	0.046	1.279	0.800	2.093	0.159	2.093	0.159	2.093	0.159	2.093	0.159	2.093	0.159		
1.422	0.533	2.151	0.073	1.306	0.300	2.111	0.069	2.111	0.069	2.111	0.069	2.111	0.069	2.111	0.069		
1.467	0.586	2.163	0.337	1.321	0.791	2.139	0.036	2.139	0.036	2.139	0.036	2.139	0.036	2.139	0.036		
1.484	0.591	2.175	0.091	1.335	0.740	2.162	0.070	2.162	0.070	2.162	0.070	2.162	0.070	2.162	0.070		
1.516	0.770	2.202	0.073	1.366	0.534	2.196	0.073	2.196	0.073	2.196	0.073	2.196	0.073	2.196	0.073		

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RÉSIN (AVELENGTH DEPENDENCE) (CONTINUED)

[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ]

CURVE 6 (CONT.)	λ	T	λ	T	CURVE 7 (CONT.)	λ	T	CURVE 7 (CONT.)	λ	T	CURVE 8	λ	T	CURVE 8	λ	T	CURVE 9	λ	T	CURVE 9	λ	T	CURVE 9 (CONT.)	
1.823	0.204	4.11	0.879	9.19	0.632	2.50	0.354	0.417	0.824	0.611	1.498	0.451	0.607	1.541	0.607	1.541	0.589	0.603	1.589	0.603	0.603	1.622	0.595	
1.834	0.235	4.43	0.905	9.28	0.619	2.68	0.354	0.429	0.813	0.607	1.541	0.451	0.607	1.589	0.607	1.589	0.603	0.603	1.589	0.603	0.603	1.622	0.595	
1.845	0.259	5.30	0.905	9.28	0.517	2.74	0.333	0.446	0.808	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
1.861	0.259	5.47	0.882	9.40	0.459	2.73	0.291	0.475	0.805	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
1.885	0.221	5.56	0.767	9.45	0.536	2.83	0.240	0.487	0.812	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
1.902	0.234	5.67	0.388	9.50	0.732	2.92	0.219	0.499	0.828	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
1.922	0.234	5.77	0.099	9.60	0.808	2.92	0.219	0.499	0.828	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
1.949	0.216	5.82	0.194	9.65	0.780	3.01	0.224	0.513	0.834	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
1.992	0.296	5.82	0.627	9.71	0.703	3.15	0.224	0.619	0.834	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
1.996	0.318	5.90	0.782	9.79	0.691	3.25	0.232	0.635	0.839	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.013	0.326	5.98	0.852	9.84	0.759	3.39	0.242	0.645	0.846	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.029	0.293	6.19	0.884	9.93	0.759	3.49	0.282	0.661	0.862	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.045	0.302	6.39	0.634	10.03	0.663	3.58	0.316	0.675	0.875	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.063	0.255	6.54	0.845	10.12	0.747	3.69	0.331	0.694	0.891	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.075	0.171	6.62	0.731	10.23	0.747	3.84	0.335	0.710	0.916	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.119	0.105	6.69	0.611	10.27	0.690	3.94	0.363	0.724	0.923	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.131	0.055	6.79	0.376	10.33	0.553	4.04	0.397	0.754	0.923	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.163	0.132	6.87	0.449	10.46	0.632	4.13	0.435	0.774	0.917	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.185	0.150	6.90	0.632	10.58	0.593	4.21	0.436	0.807	0.907	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.200	0.137	7.02	0.760	10.67	0.649	4.33	0.474	0.841	0.897	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
2.200	0.137	7.23	0.606	10.75	0.740	4.46	0.485	0.878	0.889	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
7.22	0.667	10.91	0.818	10.91	0.818	4.57	0.485	0.912	0.883	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
7.37	0.727	11.10	0.646	11.10	0.646	4.64	0.475	0.933	0.942	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
7.53	0.743	11.20	0.877	11.20	0.877	5.06	0.456	0.980	0.687	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
7.76	0.583	11.41	0.816	11.41	0.816	5.23	0.442	1.034	0.894	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
7.82	0.355	11.66	0.816	11.66	0.816	5.32	0.426	1.070	0.897	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
9.33	0.283	11.87	0.760	11.87	0.760	5.39	0.406	1.105	0.897	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.08	0.231	12.24	0.850	12.24	0.850	5.47	0.356	1.133	0.894	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.16	0.401	12.93	0.856	12.93	0.856	5.56	0.323	1.169	0.868	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.23	0.523	13.11	0.938	13.11	0.938	5.62	0.295	1.195	0.831	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.28	0.369	13.27	0.749	13.27	0.749	5.67	0.193	1.219	0.873	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.34	0.309	13.37	0.652	13.37	0.652	5.77	0.162	1.242	0.861	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.43	0.123	13.64	0.782	13.64	0.782	5.86	0.203	1.262	0.844	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.45	0.093	13.91	0.836	13.91	0.836	5.90	0.261	1.286	0.816	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.59	0.093	14.16	0.812	14.16	0.812	6.02	0.317	1.322	0.751	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.69	0.076	14.50	0.812	14.50	0.812	6.15	0.398	1.349	0.73	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.76	0.255	14.63	0.819	14.63	0.819	6.21	0.442	1.361	0.665	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.83	0.394	14.79	0.802	14.79	0.802	6.24	0.466	1.406	0.644	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
8.96	0.467	15.03	0.824	15.03	0.824	6.31	0.481	1.430	0.629	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	
9.01	0.566	15.03	0.849	15.03	0.849	6.43	0.493	1.463	0.698	0.607	1.498	0.451	0.607	1.541	0.607	1.541	0.603	0.603	1.541	0.603	0.603	1.622	0.595	

CURVE 10

$T = 293$.

TABLE 15-12. EXPERIMENTAL ACRYLIC SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 10 (CONT.)			CURVE 10 (CONT.)			CURVE 11 (CONT.)			CURVE 11 (CONT.)			CURVE 12 $T = 293^\circ$			CURVE 12 $T = 293^\circ$		
0.516	0.898	1.350	0.606	2.68	0.903	3.95	0.769	0.394	0.200	1.536	0.306	1.641	0.330	1.702	0.122	1.702	0.122		
0.554	0.898	1.385	0.590	2.95	0.876	6.01	0.730	0.400	0.207	1.648	0.264	1.675	0.236	1.675	0.236	1.675	0.236		
0.566	0.901	1.404	0.582	2.98	0.834	6.11	0.695	0.470	0.207	1.675	0.236	1.702	0.122	1.702	0.122	1.702	0.122		
0.593	0.913	1.422	0.577	3.07	0.834	6.25	0.765	0.515	0.211	1.738	0.069	1.756	0.041	1.756	0.041	1.756	0.041		
0.614	0.917	1.446	0.573	3.11	0.878	6.34	0.785	0.490	0.211	1.799	0.211	1.819	0.132	1.819	0.132	1.819	0.132		
0.629	0.917	1.476	0.565	3.22	0.879	6.60	0.799	0.515	0.211	1.798	0.211	1.838	0.132	1.838	0.132	1.838	0.132		
0.545	0.912	1.511	0.562	3.32	0.853	6.65	0.919	0.537	0.238	1.795	0.032	1.795	0.032	1.795	0.032	1.795	0.032		
0.672	0.903	1.573	0.549	3.33	0.796	6.72	0.820	0.570	0.239	1.795	0.032	1.795	0.032	1.795	0.032	1.795	0.032		
0.596	0.862	1.595	0.541	3.38	0.751	6.80	0.787	0.627	0.217	1.820	0.645	1.820	0.645	1.820	0.645	1.820	0.645		
0.707	0.879	1.614	0.533	3.42	0.698	6.81	0.733	0.665	0.223	1.845	0.079	1.871	0.100	1.871	0.100	1.871	0.100		
0.725	0.879	1.645	0.521	3.42	0.755	6.84	0.676	0.745	0.236	1.901	0.117	1.901	0.117	1.901	0.117	1.901	0.117		
0.737	0.883	1.682	0.502	3.47	0.815	6.90	0.552	0.766	0.253	1.928	0.109	1.928	0.109	1.928	0.109	1.928	0.109		
0.748	0.869	1.722	0.473	3.54	0.886	6.94	0.675	0.760	0.262	1.941	0.109	1.941	0.109	1.941	0.109	1.941	0.109		
0.757	0.909	1.758	0.456	3.62	0.901	6.97	0.721	0.804	0.270	1.951	0.109	1.951	0.109	1.951	0.109	1.951	0.109		
0.765	0.924	1.783	0.446	3.62	0.909	7.05	0.752	0.830	0.209	1.991	0.100	1.991	0.100	1.991	0.100	1.991	0.100		
0.775	0.931	1.816	0.436	3.94	0.914	7.17	0.766	0.973	0.281	1.991	0.135	1.991	0.135	1.991	0.135	1.991	0.135		
0.783	0.937	1.841	0.393	4.18	0.926	7.28	0.747	0.914	0.281	2.051	0.145	2.051	0.145	2.051	0.145	2.051	0.145		
0.796	0.942	1.867	0.352	4.33	0.908	7.42	0.773	0.949	0.290	2.075	0.123	2.075	0.123	2.075	0.123	2.075	0.123		
0.857	0.969	1.958	0.456	3.91	0.929	7.59	0.762	0.886	0.295	2.143	0.039	2.143	0.039	2.143	0.039	2.143	0.039		
0.832	0.945	1.932	0.233	4.40	0.772	7.94	0.775	0.793	0.293	2.189	0.020	2.189	0.020	2.189	0.020	2.189	0.020		
0.851	0.945	1.969	0.146	4.40	0.772	7.94	0.775	0.793	0.293	2.275	0.000	2.275	0.000	2.275	0.000	2.275	0.000		
0.870	0.931	1.986	0.109	4.52	0.762	8.40	0.822	0.859	0.246	2.317	0.427	2.317	0.427	2.317	0.427	2.317	0.427		
0.884	0.922	1.996	0.092	4.53	0.807	8.64	0.815	0.979	0.161	2.343	0.427	2.343	0.427	2.343	0.427	2.343	0.427		
0.905	0.907	2.010	0.077	4.64	0.880	8.67	0.814	1.109	0.153	2.383	0.427	2.383	0.427	2.383	0.427	2.383	0.427		
0.922	0.903	2.023	0.066	4.74	0.905	9.03	0.802	1.127	0.169	2.423	0.427	2.423	0.427	2.423	0.427	2.423	0.427		
0.942	0.893	2.043	0.060	4.90	0.884	9.23	0.812	1.148	0.225	2.464	0.427	2.464	0.427	2.464	0.427	2.464	0.427		
0.969	0.885	2.066	0.054	4.94	0.851	9.39	0.840	1.170	0.283	2.503	0.427	2.503	0.427	2.503	0.427	2.503	0.427		
0.997	0.899	2.097	0.049	4.90	0.819	9.88	0.840	1.199	0.393	2.543	0.427	2.543	0.427	2.543	0.427	2.543	0.427		
1.030	0.875	2.130	0.043	4.88	0.790	10.37	0.822	1.205	0.312	2.589	0.365	2.589	0.365	2.589	0.365	2.589	0.365		
1.087	0.869	2.172	0.037	4.90	0.772	10.73	0.847	1.225	0.313	2.606	0.415	2.606	0.415	2.606	0.415	2.606	0.415		
1.191	0.869	2.245	0.031	4.94	0.693	11.35	0.847	1.250	0.316	2.616	0.415	2.616	0.415	2.616	0.415	2.616	0.415		
1.212	0.864	2.322	0.027	4.96	0.638	11.31	0.872	1.268	0.303	2.636	0.415	2.636	0.415	2.636	0.415	2.636	0.415		
1.232	0.859	2.500	0.028	5.00	0.682	11.95	0.872	1.283	0.260	2.668	0.415	2.668	0.415	2.668	0.415	2.668	0.415		
1.245	0.851	2.500	0.028	5.02	0.854	12.66	0.851	1.365	0.164	2.706	0.509	2.706	0.509	2.706	0.509	2.706	0.509		
1.254	0.839	2.500	0.028	5.05	0.689	13.37	0.839	1.410	0.132	2.746	0.575	2.746	0.575	2.746	0.575	2.746	0.575		
1.274	0.793	2.500	0.028	5.14	0.507	14.41	0.846	1.446	0.117	2.786	0.646	2.786	0.646	2.786	0.646	2.786	0.646		
1.290	0.713	2.500	0.028	5.27	0.923	15.60	0.821	1.466	0.140	2.820	0.709	2.820	0.709	2.820	0.709	2.820	0.709		
1.311	0.670	2.50	0.926	5.71	0.923	15.60	0.140	1.521	0.188	2.851	0.714	2.851	0.714	2.851	0.714	2.851	0.714		
1.333	0.638	2.74	0.924	5.87	0.671	15.60	0.264	1.542	0.264	2.857	0.714	2.857	0.714	2.857	0.714	2.857	0.714		
1.345	0.618	2.76	0.902	5.94	0.831	15.60	0.292	1.567	0.292	2.887	0.710	2.887	0.710	2.887	0.710	2.887	0.710		

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 13 (CONT.)			CURVE 14 (CONT.)			CURVE 15 (CONT.)			CURVE 16 (CONT.)			CURVE 17 (CONT.)		
2.184	0.705	2.294	0.481	2.393	0.663	2.035	0.732	5.18	0.898	7.73	0.552	5.35	0.361	7.84	0.346	7.88
2.197	0.693	2.309	0.512	2.415	0.653	2.104	0.741	5.35	0.361	7.92	0.294	5.54	0.860	7.92	0.333	7.97
2.237	0.591	2.327	0.542	2.511	0.706	2.180	0.741	5.58	0.838	7.97	0.346	5.61	0.778	7.97	0.441	7.97
2.262	0.524	2.339	0.583	2.600	0.756	2.234	0.735	5.65	0.744	8.02	0.233	5.65	0.686	8.02	0.632	8.02
2.275	0.511	2.353	0.598	2.375	0.581	2.254	0.725	5.68	0.686	8.06	0.243	5.68	0.595	8.06	0.484	8.06
2.287	0.522	2.367	0.567	2.415	0.557	2.260	0.725	5.74	0.486	8.11	0.335	5.74	0.124	8.14	0.382	8.14
2.308	0.567	2.381	0.567	2.446	0.584	2.281	0.482	5.77	0.042	8.16	0.202	5.77	0.079	8.20	0.520	8.20
2.325	0.503	2.393	0.533	2.533	0.647	2.299	0.541	5.80	0.557	8.23	0.551	5.80	0.557	8.23	0.551	8.23
2.346	0.538	2.407	0.547	2.600	0.700	2.325	0.126	5.84	0.595	8.27	0.27	5.84	0.726	8.27	0.339	8.27
2.352	0.547	2.413	0.612	2.413	0.605	2.339	0.126	5.91	0.760	8.33	0.202	5.91	0.816	8.33	0.39	8.33
2.363	0.637	2.413	0.613	2.434	0.613	2.229	0.198	5.95	0.635	8.39	0.121	5.95	0.952	8.39	0.45	8.39
2.401	0.612	2.413	0.605	2.434	0.613	2.229	0.198	5.97	0.697	8.47	0.121	5.97	0.867	8.47	0.45	8.47
2.413	0.605	2.413	0.613	2.434	0.613	2.229	0.198	6.01	0.720	8.53	0.121	6.01	0.876	8.53	0.45	8.53
2.434	0.613	2.413	0.605	2.434	0.613	2.229	0.198	6.05	0.726	8.59	0.121	6.05	0.884	8.59	0.45	8.59
2.467	0.657	2.413	0.657	2.434	0.657	2.229	0.198	6.11	0.726	8.64	0.121	6.11	0.889	8.64	0.45	8.64
2.557	0.711	2.413	0.657	2.434	0.657	2.229	0.198	6.15	0.726	8.70	0.121	6.15	0.893	8.70	0.45	8.70
2.600	0.749	2.413	0.657	2.434	0.657	2.229	0.198	6.19	0.726	8.74	0.121	6.19	0.897	8.74	0.45	8.74
2.612	0.612	2.413	0.605	2.434	0.613	2.229	0.198	6.23	0.726	8.78	0.121	6.23	0.899	8.78	0.45	8.78
2.613	0.613	2.413	0.605	2.434	0.613	2.229	0.198	6.27	0.726	8.82	0.121	6.27	0.903	8.82	0.45	8.82
2.617	0.657	2.413	0.657	2.434	0.657	2.229	0.198	6.31	0.726	8.86	0.121	6.31	0.907	8.86	0.45	8.86
2.637	0.637	2.413	0.657	2.434	0.657	2.229	0.198	6.35	0.726	8.90	0.121	6.35	0.911	8.90	0.45	8.90
2.641	0.612	2.413	0.605	2.434	0.613	2.229	0.198	6.39	0.726	8.94	0.121	6.39	0.915	8.94	0.45	8.94
2.643	0.613	2.413	0.605	2.434	0.613	2.229	0.198	6.43	0.726	8.98	0.121	6.43	0.919	8.98	0.45	8.98
2.657	0.657	2.413	0.657	2.434	0.657	2.229	0.198	6.47	0.726	9.02	0.121	6.47	0.923	9.02	0.45	9.02
2.671	0.711	2.413	0.657	2.434	0.657	2.229	0.198	6.51	0.726	9.06	0.121	6.51	0.927	9.06	0.45	9.06
2.687	0.697	2.413	0.657	2.434	0.657	2.229	0.198	6.55	0.726	9.10	0.121	6.55	0.931	9.10	0.45	9.10
2.706	0.504	2.413	0.657	2.434	0.657	2.229	0.198	6.59	0.726	9.14	0.121	6.59	0.935	9.14	0.45	9.14
2.716	0.386	2.413	0.657	2.434	0.657	2.229	0.198	6.63	0.726	9.18	0.121	6.63	0.939	9.18	0.45	9.18
2.739	0.399	2.413	0.657	2.434	0.657	2.229	0.198	6.67	0.726	9.22	0.121	6.67	0.943	9.22	0.45	9.22
2.742	0.452	2.413	0.657	2.434	0.657	2.229	0.198	6.71	0.726	9.26	0.121	6.71	0.947	9.26	0.45	9.26
2.755	0.695	2.413	0.657	2.434	0.657	2.229	0.198	6.75	0.726	9.30	0.121	6.75	0.951	9.30	0.45	9.30
2.777	0.472	2.413	0.657	2.434	0.657	2.229	0.198	6.79	0.726	9.34	0.121	6.79	0.955	9.34	0.45	9.34
2.791	0.675	2.413	0.657	2.434	0.657	2.229	0.198	6.83	0.726	9.38	0.121	6.83	0.959	9.38	0.45	9.38
2.804	0.634	2.413	0.657	2.434	0.657	2.229	0.198	6.87	0.726	9.42	0.121	6.87	0.963	9.42	0.45	9.42
2.818	0.621	2.413	0.657	2.434	0.657	2.229	0.198	6.91	0.726	9.46	0.121	6.91	0.967	9.46	0.45	9.46
2.832	0.620	2.413	0.657	2.434	0.657	2.229	0.198	6.95	0.726	9.50	0.121	6.95	0.971	9.50	0.45	9.50
2.846	0.649	2.413	0.657	2.434	0.657	2.229	0.198	6.99	0.726	9.54	0.121	6.99	0.975	9.54	0.45	9.54
2.859	0.649	2.413	0.657	2.434	0.657	2.229	0.198	7.03	0.726	9.58	0.121	7.03	0.979	9.58	0.45	9.58
2.873	0.664	2.413	0.657	2.434	0.657	2.229	0.198	7.07	0.726	9.62	0.121	7.07	0.983	9.62	0.45	9.62
2.887	0.683	2.413	0.657	2.434	0.657	2.229	0.198	7.11	0.726	9.66	0.121	7.11	0.987	9.66	0.45	9.66
2.901	0.695	2.413	0.657	2.434	0.657	2.229	0.198	7.15	0.726	9.70	0.121	7.15	0.991	9.70	0.45	9.70
2.915	0.695	2.413	0.657	2.434	0.657	2.229	0.198	7.19	0.726	9.74	0.121	7.19	0.995	9.74	0.45	9.74
2.929	0.666	2.413	0.657	2.434	0.657	2.229	0.198	7.23	0.726	9.78	0.121	7.23	0.999	9.78	0.45	9.78
2.943	0.634	2.413	0.657	2.434	0.657	2.229	0.198	7.27	0.726	9.82	0.121	7.27	1.003	9.82	0.45	9.82
2.957	0.649	2.413	0.657	2.434	0.657	2.229	0.198	7.31	0.726	9.86	0.121	7.31	1.007	9.86	0.45	9.86
2.971	0.649	2.413	0.657	2.434	0.657	2.229	0.198	7.35	0.726	9.90	0.121	7.35	1.011	9.90	0.45	9.90
2.985	0.664	2.413	0.657	2.434	0.657	2.229	0.198	7.39	0.726	9.94	0.121	7.39	1.015	9.94	0.45	9.94
2.999	0.683	2.413	0.657	2.434	0.657	2.229	0.198	7.43	0.726	1.000	0.121	7.43	1.019	1.000	0.45	1.000

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 17 (CONT.)		CURVE 17 (CONT.)		CURVE 18 (CONT.)		CURVE 19 (CONT.)		CURVE 19 (CONT.)	
λ	τ								
9.80	0.705	13.43	0.656	0.91	0.924	2.84	0.947	6.18	0.932
9.82	0.685	13.53	0.707	0.92	0.992	2.87	0.947	6.23	0.905
9.85	0.711	13.58	0.723	0.93	0.941	2.91	0.934	6.26	0.845
9.89	0.752	13.65	0.758	0.95	0.829	2.98	0.950	6.28	0.926
9.92	0.771	13.69	0.798	0.97	0.706	3.20	0.947	6.33	0.917
9.95	0.798	13.77	0.817	1.01	0.785	3.22	0.920	6.37	0.941
10.02	0.797	13.85	0.829	1.04	0.940	3.24	0.867	6.49	0.941
10.05	0.689	14.00	0.829	1.06	0.763	3.27	0.243	6.61	0.930
10.08	0.713	14.13	0.831	1.09	0.251	3.28	0.953	6.66	0.900
10.13	0.746	14.24	0.786	1.10	0.932	3.31	0.716	6.68	0.692
10.15	0.774	14.35	0.802	1.13	0.000	3.32	0.747	6.72	0.739
10.21	0.740	14.39	0.812	1.15	0.136	3.34	0.627	6.76	0.658
10.33	0.595	14.48	0.612	1.16	0.298	3.36	0.722	6.84	0.627
10.38	0.559	14.66	0.798	1.18	0.456	3.39	0.460	6.86	0.495
10.42	0.572	15.00	0.798	1.19	0.654	3.47	0.804	6.93	0.571
10.45	0.603	15.05	0.583	1.20	0.745	3.49	0.855	6.96	0.555
10.55	0.568	15.59	0.568	1.21	0.765	3.52	0.836	7.03	0.357
10.64	0.512	15.64	0.512	1.23	0.783	3.54	0.923	7.07	0.901
10.83	0.768	15.83	0.768	1.26	0.756	3.58	0.946	7.13	0.672
10.92	0.912	16.00	0.455	1.27	0.491	3.63	0.956	7.17	0.733
11.04	0.846	16.04	0.595	1.29	0.217	4.48	0.962	7.20	0.693
11.08	0.933	16.10	0.34	1.30	0.000	5.00	0.953	7.28	0.820
11.15	0.833	16.15	0.36	1.41	0.000	5.11	0.946	7.43	0.937
11.19	0.643	16.43	0.38	1.42	0.134	5.23	0.958	7.56	0.837
11.25	0.349	16.49	0.43	1.45	0.236	5.35	0.953	7.67	0.320
11.34	0.312	16.50	0.50	1.47	0.354	5.49	0.962	7.69	0.798
11.40	0.793	16.57	0.57	1.49	0.386	5.56	0.933	7.77	0.757
11.45	0.833	16.64	0.36	1.51	0.339	5.62	0.933	7.83	0.625
11.49	0.643	16.76	0.32	1.53	0.299	5.67	0.901	7.95	0.661
11.59	0.795	16.80	0.68	0.979	1.55	0.130	5.71	0.821	8.08
11.60	0.773	16.81	0.70	0.969	1.58	0.000	5.73	0.401	8.18
11.36	0.751	16.82	0.72	0.554	5.75	0.104	5.75	0.429	8.25
12.36	0.783	16.83	0.73	0.567	5.77	0.376	8.32	0.341	8.25
12.09	0.314	16.90	0.74	0.936	6.74	0.393	5.79	0.424	8.42
12.22	0.940	16.95	0.75	0.981	5.87	0.602	5.85	0.443	17.54
12.89	0.840	17.00	0.30	0.981	2.50	0.947	5.89	0.424	16.28
13.04	0.824	17.04	0.81	0.558	2.72	0.946	5.93	0.288	20.37
13.15	0.796	17.05	0.83	0.794	2.75	0.946	5.96	0.667	0.869
13.22	0.765	17.07	0.87	0.617	2.78	0.945	5.98	0.786	21.41
13.37	0.627	17.08	0.89	0.941	2.82	0.932	9.00	0.97	0.855

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; TRANSMITTANCE, τ)

CURVE 19(CONT.)				CURVE 20(CONT.)				CURVE 20 (CONT.)				CURVE 21(CONT.)				CURVE 21 (CONT.)			
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ		
CURVE 20 T = 293.	23.58	0.935	5.37	0.951	8.01	0.280	14.31	0.947	3.61	0.921	7.78	0.677	7.81	0.536	7.65	0.499	7.91	0.536	
	24.21	0.911	5.55	0.915	8.13	0.431	14.64	0.980	3.74	0.935	7.81	0.536	7.65	0.499	7.91	0.536	7.57	0.501	
	25.00	0.776	5.63	0.683	8.19	0.412	15.65	0.975	4.18	0.943	7.65	0.499	7.91	0.536	7.57	0.501	7.91	0.536	
			5.73	0.394	8.31	0.182	15.21	0.963	5.00	0.945	7.65	0.499	7.91	0.536	7.57	0.501	7.91	0.536	
			5.72	0.053	8.39	0.230	15.53	0.906	5.13	0.943	7.65	0.499	7.91	0.536	7.57	0.501	7.91	0.536	
			5.77	0.029	8.53	0.216	15.92	0.906	5.26	0.952	8.04	0.415	8.20	0.642	8.20	0.642	8.20	0.642	
			5.84	0.595	8.67	0.142	20.53	0.872	5.38	0.952	8.20	0.642	8.20	0.642	8.20	0.642	8.20	0.642	
	2.50	0.915	5.83	0.769	8.75	0.201	20.88	0.925	5.48	0.940	8.26	0.597	8.26	0.597	8.26	0.597	8.26	0.597	
	2.66	0.922	5.95	0.662	8.98	0.594	22.03	0.930	5.59	0.917	8.35	0.318	8.35	0.318	8.35	0.318	8.35	0.318	
	2.69	0.927	6.32	0.902	9.67	0.697	23.31	0.911	6.65	0.896	8.44	0.369	8.44	0.369	8.44	0.369	8.44	0.369	
CURVE 21 T = 293.	2.75	0.934	6.18	0.902	9.14	0.737	23.31	0.879	6.73	0.798	8.54	0.350	8.54	0.350	8.54	0.350	8.54	0.350	
	2.78	0.913	6.21	0.686	9.32	0.748	23.92	0.872	6.72	0.425	8.67	0.198	8.67	0.198	8.67	0.198	8.67	0.198	
	2.82	0.943	6.24	0.823	9.43	0.770	25.50	0.826	7.75	0.698	8.83	0.502	8.83	0.502	8.83	0.502	8.83	0.502	
	2.84	0.324	6.27	0.907	9.53	0.876	5.76	0.671	6.92	0.671	8.92	0.542	8.92	0.542	8.92	0.542	8.92	0.542	
	2.87	0.324	6.32	0.897	9.59	0.952	5.79	0.793	7.13	0.793	9.14	0.774	9.14	0.774	9.14	0.774	9.14	0.774	
	2.90	0.396	5.37	0.918	9.65	0.803	5.88	0.713	9.26	0.713	9.26	0.776	9.26	0.776	9.26	0.776	9.26	0.776	
	2.94	0.927	5.52	0.911	9.69	0.885	5.93	0.690	9.43	0.690	9.43	0.749	9.43	0.749	9.43	0.749	9.43	0.749	
	3.19	0.327	6.55	0.691	9.77	0.902	2.56	0.914	6.11	0.796	9.52	0.625	9.52	0.625	9.52	0.625	9.52	0.625	
	3.22	0.394	6.66	0.793	9.86	0.878	2.63	0.915	6.14	0.851	9.71	0.539	9.71	0.539	9.71	0.539	9.71	0.539	
	3.24	0.350	6.64	0.784	9.78	0.672	2.72	0.919	6.24	0.871	9.86	0.850	9.86	0.850	9.86	0.850	9.86	0.850	
CURVE 21 T = 293.	3.26	0.374	6.69	0.515	6.613	2.77	3.93	6.29	0.963	6.47	10.03	6.47	10.03	6.47	10.03	6.47	10.03	6.47	10.03
	3.27	0.507	6.72	0.481	10.17	0.724	2.84	0.892	6.37	0.910	7.93	0.793	7.93	0.793	7.93	0.793	7.93	0.793	
	3.29	0.792	6.80	0.472	10.28	0.676	2.89	0.883	6.51	0.910	10.37	0.624	10.37	0.624	10.37	0.624	10.37	0.624	
	3.32	0.593	6.83	0.394	10.53	0.332	2.92	0.874	6.62	0.889	10.46	0.753	10.46	0.753	10.46	0.753	10.46	0.753	
	3.34	0.446	6.86	0.329	10.65	0.957	2.96	0.866	6.68	0.843	10.60	0.835	10.60	0.835	10.60	0.835	10.60	0.835	
	3.36	0.531	6.90	0.397	10.87	0.835	3.03	0.897	6.70	0.698	10.76	0.863	10.76	0.863	10.76	0.863	10.76	0.863	
	3.40	0.323	6.94	0.387	11.03	0.992	3.23	0.905	6.73	0.625	10.95	0.624	10.95	0.624	10.95	0.624	10.95	0.624	
	3.43	0.598	7.31	0.795	11.22	0.916	3.26	0.874	6.79	0.651	11.15	0.653	11.15	0.653	11.15	0.653	11.15	0.653	
	3.49	0.339	7.06	0.821	11.44	0.899	3.29	0.839	6.84	0.600	11.29	0.694	11.29	0.694	11.29	0.694	11.29	0.694	
	3.52	0.399	7.11	0.796	11.81	0.773	3.32	0.709	6.88	0.479	11.35	0.903	11.35	0.903	11.35	0.903	11.35	0.903	
	3.54	0.915	7.12	0.694	11.92	0.861	3.34	0.600	6.91	0.507	11.56	0.884	11.56	0.884	11.56	0.884	11.56	0.884	
CURVE 21 T = 293.	3.59	0.323	7.19	0.556	12.11	0.697	3.36	0.671	6.96	0.494	11.67	0.663	11.67	0.663	11.67	0.663	11.67	0.663	
	3.63	0.344	7.23	0.7C9	12.30	0.691	3.39	0.591	7.33	0.768	11.79	0.647	11.79	0.647	11.79	0.647	11.79	0.647	
	3.69	0.954	7.30	0.723	12.53	0.922	3.39	0.470	7.37	0.782	11.92	0.522	11.92	0.522	11.92	0.522	11.92	0.522	
	4.00	0.946	7.37	0.787	12.71	0.896	3.41	0.527	7.42	0.765	12.02	0.634	12.02	0.634	12.02	0.634	12.02	0.634	
	4.23	0.948	7.47	0.801	13.09	0.584	3.43	0.527	7.42	0.637	12.11	0.659	12.11	0.659	12.11	0.659	12.11	0.659	
	4.57	0.965	7.59	0.787	12.60	0.924	3.46	0.702	7.27	0.736	12.25	0.878	12.25	0.878	12.25	0.878	12.25	0.878	
	4.98	0.942	7.68	0.724	13.62	0.955	3.48	0.784	7.46	0.802	12.39	0.665	12.39	0.665	12.39	0.665	12.39	0.665	
	5.10	0.927	7.96	0.396	13.99	0.714	3.52	0.735	7.59	0.802	12.59	0.889	12.59	0.889	12.59	0.889	12.59	0.889	
	5.21	0.951	7.93	0.386	14.12	0.534	3.56	0.902	7.70	0.768	12.85	0.883	12.85	0.883	12.85	0.883	12.85	0.883	

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELLENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	τ	CURVE 22(CONT.)		CURVE 23(CONT.)		CURVE 23(CONT.)		CURVE 24(CONT.)	
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
12.59	0.889	2.699	0.910	4.17	0.923	6.81	0.500	11.11	0.822
12.85	0.883	2.800	0.827	4.23	0.954	6.67	0.462	11.44	0.858
13.07	0.840	4.35	0.937	6.96	0.505	11.71	0.819	2.85	0.865
13.35	0.745	4.47	0.948	7.03	0.692	11.98	0.842	2.91	0.824
13.42	0.457	4.75	0.937	7.13	0.683	12.18	0.797	2.95	0.830
13.95	0.876	5.00	0.934	7.23	0.520	12.35	0.856	3.06	0.830
14.14	0.863	5.13	0.927	7.29	0.552	12.55	0.825	3.16	0.850
14.29	0.732	5.28	0.927	7.34	0.632	12.80	0.825	3.22	0.850
14.49	0.880	5.41	0.906	7.41	0.666	13.02	0.809	3.29	0.797
15.87	0.689	5.47	0.889	7.47	0.632	13.19	0.699	3.32	0.725
17.64	0.862	5.53	0.774	7.52	0.569	13.48	0.676	3.37	0.417
18.80	0.853	5.58	0.746	7.58	0.552	13.74	0.644	3.40	0.326
19.83	0.632	5.64	0.594	7.67	0.404	14.06	0.808	3.41	0.238
20.49	0.924	5.68	0.524	7.70	0.314	14.29	0.750	3.43	0.266
20.92	0.796	5.72	0.225	7.73	0.256	14.43	0.685	3.47	0.475
21.51	0.816	5.74	0.106	7.79	0.244	14.97	0.920	3.51	0.414
22.62	0.803	5.76	0.087	7.90	0.287	15.29	0.899	3.53	0.711
23.64	0.794	5.80	0.122	8.04	0.392	15.43	0.917	3.56	0.612
25.00	0.737	5.86	0.396	8.14	0.424	15.65	0.930	3.61	0.876
		5.93	0.547	8.36	0.336	16.45	0.906	3.66	0.877
		5.96	0.602	8.45	0.336	17.42	0.914	3.77	0.910
		6.00	0.657	8.63	0.286	17.70	0.898	3.87	0.910
		6.05	0.664	8.83	0.386	18.12	0.909	4.18	0.940
		6.08	0.658	8.90	0.390	18.45	0.891	4.23	0.924
		6.12	0.673	9.02	0.591	19.31	0.907	4.27	0.937
		6.16	0.771	9.15	0.642	19.72	0.889	4.32	0.930
		6.21	0.794	9.21	0.593	20.33	0.888	4.38	0.946
		6.24	0.772	9.25	0.505	20.53	0.669	4.62	0.954
		6.27	0.820	9.32	0.482	21.46	0.669	5.00	0.954
		6.31	0.807	9.41	0.649	22.57	0.823	5.13	0.956
		6.36	0.842	9.49	0.664	23.53	0.789	5.27	0.953
		6.40	0.824	9.59	0.596	24.33	0.718	5.28	0.944
		6.44	0.824	9.70	0.566	25.03	0.718	5.32	0.953
		6.49	0.811	9.80	0.577	5.37	0.942		
		6.56	0.827	9.92	0.723	5.39	0.831		
		6.61	0.798	10.21	0.755	5.42	0.910		
		6.65	0.737	10.46	0.700	5.45	0.928		
		6.68	0.744	10.60	0.746	5.49	0.884		
		6.73	0.697	10.76	0.608	5.56	0.782		
		6.78	0.577	10.89	0.793	5.58	0.626		

CURVE 24
 $T = 293.$

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 24 (CONT.)		CURVE 24 (CONT.)		CURVE 25 (CONT.)							
λ	T										
5.61	0.654	7.47	0.628	16.10	0.919	3.52	0.787	6.30	0.727	12.17	0.611
5.63	0.521	7.65	0.516	16.89	0.902	3.57	0.849	6.44	0.773	12.66	0.841
5.65	0.551	7.75	0.484	18.28	0.902	3.68	0.869	6.54	0.793	12.74	0.776
5.68	0.511	7.88	0.423	18.76	0.854	3.87	0.874	6.68	0.768	12.95	0.787
5.71	0.257	7.96	0.350	19.08	0.884	3.90	0.896	6.76	0.699	13.21	0.773
5.75	0.128	8.14	0.419	19.96	0.892	3.96	0.871	6.87	0.303	13.42	0.628
5.81	0.211	8.29	0.362	21.51	0.892	4.05	0.895	6.96	0.391	13.76	0.859
5.83	0.434	8.48	0.300	23.09	0.849	4.10	0.888	7.01	0.363	14.03	0.896
5.92	0.604	8.61	0.314	23.53	0.808	4.16	0.888	7.06	0.466	14.27	0.685
5.97	0.696	8.67	0.335	24.27	0.786	4.21	0.906	7.12	0.483	14.51	0.897
6.02	0.744	8.98	0.383	25.00	0.769	4.28	0.875	7.12	0.634	15.36	0.871
6.03	0.744	9.03	0.389	25.00	0.769	4.35	0.875	7.37	0.612	16.03	0.858
6.11	3.733	9.15	0.457	24.97	0.786	4.39	0.798	7.49	0.639	16.64	0.882
6.17	0.753	9.18	0.497	24.97	0.786	4.44	0.331	7.69	0.639	17.36	0.809
6.22	3.741	9.31	0.529	24.97	0.786	4.46	0.534	7.85	0.590	17.92	0.835
6.25	0.757	9.46	0.561	2.50	0.908	4.50	0.499	7.92	0.626	18.42	0.798
6.27	0.723	9.63	0.516	2.64	0.922	4.52	0.612	8.03	0.626	19.12	0.844
5.32	0.790	9.76	0.534	2.78	0.905	4.56	0.768	8.17	0.576	21.28	0.917
5.37	0.646	9.82	0.615	2.84	0.905	4.60	0.894	8.31	0.585	22.99	0.876
6.41	0.656	9.97	0.664	2.86	0.880	4.69	0.922	8.40	0.629	23.53	0.837
6.44	0.669	10.19	0.719	2.89	0.813	4.76	0.909	8.51	0.591	25.00	0.837
6.53	0.684	10.33	0.700	2.91	0.834	4.87	0.926	8.67	0.704		
6.57	0.664	10.54	0.707	2.95	0.744	4.93	0.916	8.83	0.756		
6.61	0.503	10.81	0.757	2.96	0.726	5.00	0.922	8.92	0.734		
6.67	0.525	11.12	0.660	2.98	0.735	5.07	0.921	9.03	0.754		
6.72	0.757	11.25	0.727	2.99	0.772	5.15	0.894	9.16	0.734		
6.76	0.693	11.44	0.760	3.02	0.806	5.26	0.881	9.31	0.712		
6.80	0.504	11.68	0.750	3.06	0.776	5.35	0.917	9.45	0.728		
6.81	0.451	11.83	0.783	3.09	0.791	5.55	0.914	9.58	0.704		
6.85	0.437	12.24	0.801	3.13	0.791	5.63	0.877	9.67	0.741		
6.89	0.458	12.42	0.833	3.17	0.811	5.68	0.842	9.72	0.768		
6.89	0.486	12.67	0.833	3.21	0.751	5.74	0.538	10.05	0.768		
6.98	0.539	13.02	0.805	3.24	0.786	5.77	0.446	10.16	0.738		
7.02	0.651	13.18	0.795	3.26	0.739	5.82	0.642	10.31	0.437		
7.09	0.674	13.57	0.843	3.31	0.735	5.88	0.689	10.44	0.399		
7.15	0.566	13.93	0.659	3.33	0.647	5.96	0.659	10.71	0.701		
7.25	0.501	14.16	0.861	3.40	0.443	6.03	0.685	10.89	0.795		
7.41	0.535	14.60	0.893	3.42	0.496	6.08	0.595	11.19	0.831		
7.41	0.535	15.04	0.919	3.44	0.645	6.15	0.562	11.61	0.857		
7.41	0.604	15.62	0.911	3.46	0.677	6.23	0.677	11.98	0.714		

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T; K; TRANSMITTANCE, τ)

λ	T	λ	T	CURVE 26(CONT.)		CURVE 26(CONT.)		CURVE 26(CONT.)		CURVE 27(CONT.)		CURVE 27(CONT.)	
3.20	0.763	5.30	0.911	7.87	0.511	14.16	0.897	4.65	0.839	10.64	0.903	4.65	0.839
3.22	0.765	5.36	0.937	7.92	0.672	14.41	0.866	5.21	0.854	11.75	0.904	5.21	0.854
3.25	0.767	5.41	0.957	8.01	0.550	14.79	0.875	5.57	0.824	12.52	0.885	5.57	0.824
3.29	0.770	5.50	0.957	8.03	0.670	15.22	0.653	5.68	0.690	13.55	0.912	5.68	0.690
3.32	0.773	5.53	0.935	8.16	0.514	15.72	0.825	5.70	0.553	13.45	0.902	5.70	0.553
3.35	0.551	5.59	0.956	8.27	0.654	16.31	0.827	5.75	0.478	13.73	0.943	5.75	0.478
3.38	0.413	5.69	0.938	8.35	0.704	16.64	0.659	5.82	0.596	13.97	0.936	5.82	0.596
3.40	0.349	5.76	0.879	8.45	0.721	17.21	0.774	5.87	0.654	14.15	0.936	5.87	0.654
3.44	0.529	5.81	0.666	8.54	0.721	17.67	0.735	5.89	0.792	14.50	0.902	5.89	0.792
3.46	0.522	5.89	0.845	8.63	0.750	18.21	0.754	6.02	0.661	15.00	0.895	6.02	0.661
3.49	0.513	5.97	0.784	8.70	0.798	18.59	0.699	6.14	0.798	15.00	0.895	6.14	0.798
3.65	0.754	6.24	0.759	8.87	0.757	18.93	0.713	6.30	0.822	15.00	0.895	6.30	0.822
3.57	0.323	6.08	0.654	8.93	0.711	19.42	0.746	6.38	0.639	15.00	0.895	6.38	0.639
3.64	0.834	6.10	0.561	9.15	0.722	19.60	0.805	6.60	0.809	15.00	0.895	6.60	0.809
3.72	0.294	6.13	0.561	9.39	0.674	20.12	0.861	6.77	0.704	15.00	0.895	6.77	0.704
3.77	0.895	6.17	0.508	9.49	0.687	20.83	0.948	6.81	0.548	15.00	0.895	6.81	0.548
3.53	0.372	6.19	0.619	9.52	0.654	21.55	0.897	7.03	0.459	15.00	0.895	7.03	0.459
3.37	0.894	6.25	0.693	9.72	0.705	22.27	0.858	7.00	0.762	15.00	0.895	7.00	0.762
3.91	0.394	6.32	0.761	9.81	0.735	23.20	0.893	7.09	0.807	15.00	0.895	7.09	0.807
3.97	0.311	6.38	0.744	9.87	0.716	23.20	0.854	7.18	0.784	15.00	0.895	7.18	0.784
3.93	0.393	6.44	0.804	10.03	0.739	24.04	0.831	7.26	0.677	15.00	0.895	7.26	0.677
4.06	0.903	6.51	0.846	10.17	0.687	24.51	0.756	7.36	0.558	15.00	0.895	7.36	0.558
4.19	0.908	6.65	0.801	10.33	0.353	25.00	0.769	7.48	0.672	15.00	0.895	7.48	0.672
4.25	0.862	6.70	0.771	10.47	0.222	7.55	0.733	7.55	0.733	15.00	0.895	7.55	0.733
4.35	0.876	6.73	0.721	10.73	0.623	7.67	0.733	7.67	0.733	15.00	0.895	7.67	0.733
4.40	0.839	6.77	0.796	10.85	0.703	7.84	0.672	7.84	0.672	15.00	0.895	7.84	0.672
4.47	0.162	6.85	0.556	10.92	0.755	8.01	0.630	8.01	0.630	15.00	0.895	8.01	0.630
4.48	0.410	6.89	0.435	11.09	0.742	8.18	0.703	8.31	0.633	15.00	0.895	8.31	0.633
4.50	0.345	6.93	0.260	11.33	0.767	8.22	0.732	8.45	0.664	15.00	0.895	8.45	0.664
4.52	0.784	6.97	0.297	11.56	0.750	8.29	0.696	8.58	0.655	15.00	0.895	8.58	0.655
4.57	0.732	7.53	0.204	11.64	0.804	8.31	0.732	8.67	0.708	15.00	0.895	8.67	0.708
4.51	0.971	7.37	0.353	11.82	0.779	8.28	0.706	8.72	0.820	15.00	0.895	8.72	0.820
4.61	0.924	7.19	0.339	12.05	0.731	8.45	0.611	8.80	0.852	15.00	0.895	8.80	0.852
4.71	0.343	7.19	0.642	12.14	0.783	8.53	0.771	9.01	0.777	15.00	0.895	9.01	0.777
4.31	0.954	7.39	0.975	12.36	0.811	8.83	0.809	9.28	0.798	15.00	0.895	9.28	0.798
4.43	0.929	7.45	0.619	12.64	0.764	9.18	0.816	9.35	0.708	15.00	0.895	9.35	0.708
5.00	0.357	7.53	0.632	13.21	0.697	9.33	0.630	9.47	0.747	15.00	0.895	9.47	0.747
5.37	0.965	7.53	0.632	13.51	0.770	9.43	0.751	9.63	0.747	15.00	0.895	9.63	0.747
5.44	0.937	7.71	0.647	13.77	0.786	9.50	0.552	9.77	0.828	15.00	0.895	9.77	0.828
5.22	0.874	7.75	0.627	13.93	0.862	9.59	0.801	9.87	0.877	15.00	0.895	9.87	0.877

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

CURVE 23(CONT.)			CURVE 28(CONT.)			CURVE 29(CONT.)			CURVE 30			CURVE 30(CONT.)		
λ	T	τ	λ	T	τ	λ	T	τ	λ	T	τ	λ	T	τ
4.59	0.915	0.558	9.38	0.558	0.573	0.527	0.591	0.573	3.68	0.738	0.41	0.723	3.71	0.794
4.69	0.944	0.695	9.59	0.695	0.537	0.51	0.539	0.591	3.71	0.794	0.45	0.762	3.78	0.800
4.99	0.954	0.750	9.69	0.750	0.539	0.51	0.445	0.822	3.57	0.796	0.46	0.748	3.61	0.776
5.63	0.954	0.817	9.76	0.817	0.445	0.61	0.445	0.822	3.61	0.822	0.50	0.690	3.65	0.776
5.73	0.922	0.885	10.02	0.885	0.445	0.66	0.833	0.833	3.84	0.785	0.59	0.537	3.84	0.785
5.88	0.916	0.894	10.23	0.894	0.487	0.70	0.827	0.827	3.88	0.769	0.66	0.338	3.92	0.769
6.15	0.944	0.911	10.70	0.911	0.499	0.72	0.839	0.839	3.91	0.793	0.71	0.154	3.95	0.793
6.24	0.944	0.698	11.11	0.698	0.409	0.75	0.831	0.831	3.95	0.745	0.72	0.067	3.98	0.745
6.29	0.959	0.299	6.54	0.917	0.415	7.26	0.299	0.299	4.00	0.792	0.77	0.064	4.04	0.792
6.57	0.987	0.415	6.73	0.756	0.485	7.38	0.415	0.415	4.09	0.792	0.87	0.054	4.13	0.792
6.73	0.756	0.394	6.79	0.79	0.419	7.54	0.485	0.485	4.13	0.800	0.90	0.032	4.18	0.800
6.79	0.471	0.490	7.48	0.490	0.254	7.94	0.394	0.394	4.26	0.781	0.95	0.141	4.31	0.781
6.85	0.114	0.457	7.66	0.457	0.189	8.00	0.189	0.189	4.33	0.791	0.91	0.247	4.37	0.791
6.92	0.429	0.358	7.73	0.358	0.351	8.18	0.351	0.351	4.38	0.732	0.55	0.373	4.42	0.732
6.97	0.653	0.319	7.64	0.319	0.419	8.20	0.419	0.419	4.41	0.802	0.08	0.198	4.46	0.802
7.01	0.773	0.364	7.98	0.364	0.522	8.31	0.522	0.522	4.53	0.810	0.10	0.059	4.57	0.810
7.37	0.809	0.424	7.10	0.424	0.548	7.94	0.254	0.254	4.55	0.823	0.11	0.000	4.59	0.823
7.47	0.710	0.394	7.22	0.394	0.607	8.09	0.607	0.607	4.59	0.732	0.55	0.373	4.63	0.732
7.26	0.579	0.279	7.34	0.279	0.469	8.08	0.469	0.469	4.62	0.797	0.22	0.438	4.67	0.797
7.27	0.482	0.423	7.44	0.423	0.364	9.31	0.364	0.364	4.66	0.752	0.24	0.198	4.71	0.752
7.35	0.455	0.528	7.53	0.528	0.580	9.53	0.580	0.580	4.70	0.761	0.28	0.059	4.75	0.761
7.46	0.526	0.555	7.85	0.555	0.548	8.47	0.548	0.548	4.73	0.751	0.32	0.32	4.79	0.751
7.51	0.615	0.555	6.19	0.555	0.623	8.09	0.623	0.623	4.74	0.773	0.35	0.32	4.83	0.773
7.65	0.615	0.427	6.27	0.427	0.469	8.08	0.469	0.469	4.77	0.797	0.42	0.517	4.88	0.797
7.76	0.541	0.293	7.49	0.293	0.511	9.92	0.619	0.619	4.81	0.761	0.44	0.605	4.89	0.761
7.92	0.792	0.534	7.53	0.534	0.650	10.29	0.650	0.650	4.88	0.805	0.52	0.522	4.93	0.805
7.93	0.535	0.534	7.35	0.534	0.534	10.74	0.679	0.679	4.91	0.796	0.56	0.44	4.97	0.796
7.99	0.546	0.445	7.45	0.445	0.599	11.21	0.735	0.735	4.95	0.682	0.60	0.541	5.01	0.682
8.36	0.585	0.453	7.53	0.453	0.627	11.46	0.753	0.753	4.99	0.698	0.55	0.527	5.05	0.698
8.21	0.617	0.355	7.95	0.355	0.607	11.91	0.673	0.673	5.01	0.761	0.58	0.493	5.09	0.761
8.37	0.792	0.515	8.07	0.515	0.607	12.21	0.712	0.712	5.04	0.745	0.61	0.415	5.13	0.745
8.45	0.735	0.534	7.35	0.534	0.597	12.40	0.742	0.742	5.06	0.666	0.62	0.256	5.17	0.666
8.93	0.546	0.447	7.72	0.546	0.599	13.90	0.621	0.621	5.07	0.727	0.76	0.192	5.21	0.727
9.03	0.515	0.57	6.97	0.57	0.532	13.06	0.681	0.681	5.07	0.298	0.12	0.126	5.25	0.298
9.18	0.568	0.66	6.62	0.629	0.222	13.35	0.690	0.690	5.11	0.478	0.71	0.061	5.31	0.478
9.23	0.495	0.483	6.13	0.483	0.396	13.57	0.621	0.621	5.13	0.293	0.73	0.015	5.37	0.293

TABLE 15-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF ACRYLIC RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 39 (CONT.)				CURVE 30 (CONT.)				CURVE 30 (CONT.)			
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
7.00	0.051	10.05	0.146	15.39	0.265	21.87	0.678	7.36	0.155	10.09	0.231
7.10	0.171	15.15	0.133	15.64	0.531	22.11	0.673	7.14	0.072	10.13	0.103
7.14	0.274	12.25	0.335	15.75	0.673	22.28	0.667	7.20	0.286	12.30	0.347
7.24	0.176	10.35	0.329	16.03	0.704	22.41	0.652	7.24	0.072	10.13	0.103
7.24	0.033	12.75	0.333	15.84	0.725	23.06	0.624	7.31	0.274	12.25	0.335
7.31	0.373	15.59	0.697	15.94	0.750	23.19	0.604	7.32	0.329	10.79	0.938
7.32	0.329	10.59	0.606	16.03	0.755	23.48	0.596	7.33	0.324	10.66	0.693
7.33	0.324	12.66	0.603	16.31	0.718	23.98	0.586	7.34	0.346	10.82	0.629
7.34	0.234	12.79	0.633	16.44	0.718	24.06	0.563	7.35	0.373	10.59	0.697
7.35	0.373	10.79	0.629	16.55	0.664	24.08	0.563	7.36	0.324	10.59	0.606
7.36	0.324	12.79	0.633	16.61	0.359	24.39	0.532	7.37	0.373	10.59	0.697
7.37	0.373	10.92	0.691	16.66	0.347	24.56	0.516	7.38	0.324	10.66	0.693
7.38	0.324	12.82	0.629	16.72	0.359	24.56	0.495	7.39	0.324	10.79	0.633
7.39	0.324	10.92	0.691	16.78	0.476	24.65	0.485	7.40	0.373	10.59	0.606
7.40	0.373	12.82	0.629	16.85	0.415	24.81	0.468	7.41	0.324	10.66	0.693
7.41	0.324	11.64	0.633	16.93	0.402			7.42	0.373	10.79	0.697
7.42	0.373	11.39	0.581	16.96	0.421			7.43	0.324	10.59	0.606
7.43	0.324	11.22	0.725	16.96	0.545			7.44	0.373	10.79	0.697
7.44	0.373	11.38	0.741	17.05	0.625			7.45	0.324	10.59	0.606
7.45	0.324	11.57	0.741	17.21	0.755			7.46	0.373	10.79	0.697
7.46	0.373	11.86	0.668	17.33	0.780			7.47	0.324	10.59	0.606
7.47	0.324	11.95	0.228	17.55	0.783			7.48	0.373	10.79	0.697
7.48	0.373	11.38	0.662	17.70	0.785			7.49	0.324	10.59	0.606
7.49	0.324	11.57	0.741	18.09	0.768			7.50	0.373	10.79	0.697
7.50	0.373	11.86	0.668	18.45	0.780			7.51	0.324	10.59	0.606
7.51	0.324	11.95	0.228	18.68	0.783			7.52	0.373	10.79	0.697
7.52	0.373	11.38	0.662	18.91	0.765			7.53	0.324	10.59	0.606
7.53	0.324	11.57	0.741	19.13	0.735			7.54	0.373	10.79	0.697
7.54	0.373	11.86	0.668	19.31	0.696			7.55	0.324	10.59	0.606
7.55	0.324	11.95	0.228	19.50	0.583			7.56	0.373	10.79	0.697
7.56	0.373	11.38	0.662	19.65	0.464			7.57	0.324	10.59	0.606
7.57	0.324	11.57	0.741	19.74	0.443			7.58	0.373	10.79	0.697
7.58	0.373	11.86	0.668	19.82	0.425			7.59	0.324	10.59	0.606
7.59	0.324	11.95	0.228	20.00	0.405			7.60	0.373	10.79	0.697
7.60	0.373	11.38	0.662	20.16	0.385			7.61	0.324	10.59	0.606
7.61	0.324	11.57	0.741	20.31	0.365			7.62	0.373	10.79	0.697
7.62	0.373	11.86	0.668	20.48	0.345			7.63	0.324	10.59	0.606
7.63	0.324	11.95	0.228	20.64	0.325			7.64	0.373	10.79	0.697
7.64	0.373	11.38	0.662	20.80	0.305			7.65	0.324	10.59	0.606
7.65	0.324	11.57	0.741	20.97	0.285			7.66	0.373	10.79	0.697
7.66	0.373	11.86	0.668	21.13	0.265			7.67	0.324	10.59	0.606
7.67	0.324	11.95	0.228	21.30	0.245			7.68	0.373	10.79	0.697
7.68	0.373	11.38	0.662	21.46	0.225			7.69	0.324	10.59	0.606
7.69	0.324	11.57	0.741	21.62	0.205			7.70	0.373	10.79	0.697
7.70	0.373	11.86	0.668	21.78	0.185			7.71	0.324	10.59	0.606
7.71	0.324	11.95	0.228	21.94	0.165			7.72	0.373	10.79	0.697
7.72	0.373	11.38	0.662	22.10	0.145			7.73	0.324	10.59	0.606
7.73	0.324	11.57	0.741	22.26	0.125			7.74	0.373	10.79	0.697
7.74	0.373	11.86	0.668	22.42	0.105			7.75	0.324	10.59	0.606
7.75	0.324	11.95	0.228	22.58	0.085			7.76	0.373	10.79	0.697
7.76	0.373	11.38	0.662	22.74	0.065			7.77	0.324	10.59	0.606
7.77	0.324	11.57	0.741	22.90	0.045			7.78	0.373	10.79	0.697
7.78	0.373	11.86	0.668	23.06	0.025			7.79	0.324	10.59	0.606
7.79	0.324	11.95	0.228	23.22	0.005			7.80	0.373	10.79	0.697
7.80	0.373	11.38	0.662	23.38	-0.145			7.81	0.324	10.59	0.606
7.81	0.324	11.57	0.741	23.54	-0.165			7.82	0.373	10.79	0.697
7.82	0.373	11.86	0.668	23.70	-0.185			7.83	0.324	10.59	0.606
7.83	0.324	11.95	0.228	23.86	-0.205			7.84	0.373	10.79	0.697
7.84	0.373	11.38	0.662	24.02	-0.225			7.85	0.324	10.59	0.606
7.85	0.324	11.57	0.741	24.18	-0.245			7.86	0.373	10.79	0.697
7.86	0.373	11.86	0.668	24.34	-0.265			7.87	0.324	10.59	0.606
7.87	0.324	11.95	0.228	24.50	-0.285			7.88	0.373	10.79	0.697
7.88	0.373	11.38	0.662	24.66	-0.305			7.89	0.324	10.59	0.606
7.89	0.324	11.57	0.741	24.82	-0.325			7.90	0.373	10.79	0.697
7.90	0.373	11.86	0.668	24.98	-0.345			7.91	0.324	10.59	0.606
7.91	0.324	11.95	0.228	25.14	-0.365			7.92	0.373	10.79	0.697
7.92	0.373	11.38	0.662	25.30	-0.385			7.93	0.324	10.59	0.606
7.93	0.324	11.57	0.741	25.46	-0.405			7.94	0.373	10.79	0.697
7.94	0.373	11.86	0.668	25.62	-0.425			7.95	0.324	10.59	0.606
7.95	0.324	11.95	0.228	25.78	-0.445			7.96	0.373	10.79	0.697
7.96	0.373	11.38	0.662	25.94	-0.465			7.97	0.324	10.59	0.606
7.97	0.324	11.57	0.741	26.10	-0.485			7.98	0.373	10.79	0.697
7.98	0.373	11.86	0.668	26.26	-0.505			7.99	0.324	10.59	0.606
7.99	0.324	11.95	0.228	26.42	-0.525			8.00	0.373	10.79	0.697
8.00	0.373	11.38	0.662	26.58	-0.545			8.01	0.324	10.59	0.606
8.01	0.324	11.57	0.741	26.74	-0.565			8.02	0.373	10.79	0.697
8.02	0.373	11.86	0.668	26.90	-0.585			8.03	0.324	10.59	0.606
8.03	0.324	11.95	0.228	27.06	-0.605			8.04	0.373	10.79	0.697
8.04	0.373	11.38	0.662	27.22	-0.625			8.05	0.324	10.59	0.606
8.05	0.324	11.57	0.741	27.38	-0.645			8.06	0.373	10.79	0.697
8.06	0.373	11.86	0.668	27.54	-0.665			8.07	0.324	10.59	0.606
8.07	0.324	11.95	0.228	27.70	-0.685			8.08	0.373	10.79	0.697
8.08	0.373	11.38	0.662	27.86	-0.705			8.09	0.324	10.59	0.606
8.09	0.324	11.57	0.741	28.02	-0.725			8.10	0.373	10.79	0.697
8.10	0.373	11.86	0.668	28.18	-0.745			8.11	0.324	10.59	0.606
8.11	0.324	11.95	0.228	28.34	-0.765			8.12	0.373	10.79	0.697
8.12	0.373	11.38	0.662	28.50	-0.785			8.13	0.324	10.59	0.606
8.13	0.324	11.57	0.741	28.66	-0.805			8.14	0.373	10.79	0.697
8.14	0.373	11.86	0.668	28.82	-0.825			8.15	0.324	10.59	0.606
8.15	0.324	11.95	0.228	28.98	-0.845			8.16	0.373	10.79	0.697
8.16	0.373	11.38	0.662	29.14	-0.865			8.17	0.324	10.59	0.606
8.17	0.324	11.57	0.741	29.30	-0.885			8.18	0.373	10.79	0.697
8.18	0.373	11.86	0.668	29.46	-0.905			8.19	0.324	10.59	0.606
8.19	0.324	11.95	0.228	29.62	-0.925			8.20	0.373	10.79	0.697
8.20	0.373	11.38	0.662	29.78	-0.945			8.21	0.324	10.59	0.606
8.21	0.324	11.57	0.741	29.94	-0.965			8.22	0.373	10.79	0.697
8.22	0.373	11.86	0.668	30.10	-0.985			8.23	0.324	10.59	0.606
8.23	0.324	11.95	0.228	30.26	-1.005			8.24	0.373	10.79	0.697
8.24	0.373	11.38	0.662	30.42	-1.025			8.25	0.324	10.59	0.606
8.25	0.324	11.57	0.741	30.58	-1.045			8.26	0.373	10.79	0.697
8.26	0.373	11.86	0.668	30.74	-1.065			8.27	0.324	10.59	0.606
8.27	0.324	11.95	0.228	30.90	-1.085			8.28	0.373	10.79	0.697
8.28	0.373	11.38	0.662	31.06	-1.105			8.29	0.324	10.59	0.606
8.29	0.324	11.57	0.741	31.22	-1.125			8.30	0.373	10.79	0.697
8.30	0.373	11.86	0.668	31.38	-1.145			8.31	0.324		


4.16 Lucite

Lucite is a proprietary acrylic resin, poly(methyl methacrylate), manufactured by DuPont Co. "Plexiglas" and "Perspex" are essentially the same material manufactured by Rohm and Haas Co. and Imperical Chemical Industrial Chemicals Ltd. respectively.

Lucite is a rigid, crystal-clear thermoplastic material with excellent mechanical and chemical properties. It has the best resistance to the effects of sunlight and outdoor weathering among all the transparent plastics. Industrial uses include optical applications such as in TV screens, automobile taillights, and lenses for cameras and slide viewers.

Lucite acrylic resins can be easily processed by all fabricating techniques currently practiced in the industry. They can be injection molded, blow molded, compression molded, and extruded. It also can be machined, drilled, threaded, and routed with standard wood and metal-working equipment.

The polymerization of Lucite is carried out in water suspension with peroxide catalyst. The resulting polymer is washed, dried and blended with plasticizer and colorants before pelletizing for use as molding powders.



The molecular weight of Lucite is of the order of 5×10^5 to over 10^6 (degree of polymerisation approximately 5000-10000). According to x-ray data, Lucite is substantially amorphous materials. It is soluble in aromatic and most chlorinated hydrocarbons (toluene, ethylene, dichloride, chloroform), esters (ethyl acetate), leetones, tetrahydrofuran. It will be swollen by alcohols, phenols, ether and carbon tetrachloride. It can be decomposed by conc. oxidizing acids (HNO_3 , H_2SO_4 , H_2CrO_4) and alcoholic alkalis.

Lucite has density $1.18-1.19 \text{ gm cm}^{-3}$, has the second order (glass) transition temperature at about 378 K, softens above 397 K and decomposes around 520 K. The maximum service temperature is 350 K. Its dielectric constants are 2.7-3.9 over the range 50-10⁵ Hz. Its resistivity is about $10^{14}-10^{15} \text{ ohm-cm}$. Its dielectric strength is about 16 KV/mm for 3 mm sheet.

Lucite has specific heat 0.35, thermal conductivity $0.00188 \text{ W cm}^{-1} \text{ K}^{-1}$, and thermal expansion coefficient $0.75 \times 10^{-4} \text{ K}^{-1}$ at 293 K ($1.05 \times 10^{-4}/\text{K}$ at 350 K). It shrinks 0.2-0.7% when molding.

a. Normal Spectral Emittance (Wavelength Dependence)

There is no data on the normal spectral emittance of Lucite available. However, Pregelhof, Francy, and Haas [T77125] used a one-dimensional model, assuming uniform properties, and gave the emittance $\epsilon(\lambda)$, the absorptance $\alpha(\lambda)$, the transmittance $\tau(\lambda)$, and the reflectance $\rho(\lambda)$ of a polymer sheet in the following expressions:

$$\epsilon(\lambda) = \alpha(\lambda) = \frac{(1-R) [(1+R) \sinh ad + (1-R) (\cosh ad - 1)]}{(1+R^2) \sinh ad + (1-R^2) \cosh ad} \quad (4.16-1)$$

$$\tau(\lambda) = \frac{(1-R)^2}{(1+R^2) \sinh ad + (1-R^2) \cosh ad} \quad (4.16-2)$$

$$\rho(\lambda) = \frac{2R [R \sinh ad + (1-R) \cosh ad]}{(1+R^2) \sinh ad + (1-R^2) \cosh ad} \quad (4.16-3)$$

where $R = (n - 1/n + 1)^2$ and n is the refractive index, d is the thickness of the sample, and a is the absorption coefficient.

For the Lucite bulk material, it can be assumed that

$$e^{ad} \gg R e^{-ad} \quad (4.16-4)$$

which enables eqs. (4.16-1, 4.16-2, and 4.16-3) to become the following:

$$\epsilon(\lambda) = \alpha(\lambda) \cong (1-R) [1 - (1-R) e^{-ad} - R e^{-2ad}] \quad (4.16-5)$$

$$\tau(\lambda) \cong (1-R)^2 e^{-ad} \quad (4.16-6)$$

$$\rho(\lambda) \cong R [1 + (1-2R) e^{-2ad}] \quad (4.16-7)$$

By using these equations together with the experimental data of transmittance and reflectance, the emittance can be calculated. Here we used $d = 3.2$ mm for calculation. The calculated results of the normal spectral emittance for Lucite sample with thickness 3.2 mm at 293 K are shown in Table 16-1 and Fig. 16-1 with an estimated uncertainty of about $\pm 20\%$.

TABLE I-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T; K; EMITTANCE, ϵ]

λ	ϵ	THICKNESS 3.2MM	THICKNESS 3.2MM	THICKNESS 3.2MM
λ	ϵ	T = 293 (CONT.)	T = 293 (CONT.)	T = 293 (CONT.)
6.240	0.919	1.92	0.430	9.00
6.259	0.931	1.95	0.430	9.50
6.270	0.919	2.06	0.371	10.50
6.284	0.932	2.09	0.699	10.50
6.299	0.939	2.13	0.511	11.00
6.314	0.950	2.22	0.950	11.60
6.330	0.959	2.43	0.964	12.00
6.347	0.972	2.53	0.931	12.72
6.364	0.972	2.58	0.926	13.00
6.381	0.975	2.63	0.927	13.50
6.397	0.975	2.66	0.972	14.00
6.414	0.972	2.80	0.965	14.50
6.430	0.972	3.00	0.965	15.00
6.447	0.972	3.07	0.974	0.964
6.464	0.972	3.12	0.963	0.966
6.481	0.972	3.25	0.972	0.952
6.497	0.972	3.42	0.968	0.957
6.514	0.972	3.54	0.968	0.964
6.530	0.972	3.59	0.970	0.967
6.547	0.972	3.74	0.974	0.968
6.564	0.972	3.87	0.974	0.972
6.581	0.972	3.95	0.974	0.971
6.597	0.972	4.22	0.963	0.974
6.614	0.972	4.46	0.967	0.976
6.630	0.972	4.60	0.968	0.964
6.647	0.972	4.73	0.972	0.958
6.664	0.972	5.05	0.971	0.972
6.681	0.972	5.23	0.974	0.970
6.697	0.972	5.62	0.976	0.964
6.714	0.972	5.78	0.978	0.958
6.730	0.972	6.02	0.978	0.959
6.747	0.972	6.25	0.975	0.958
6.763	0.972	6.50	0.973	0.972
6.779	0.972	6.67	0.973	0.970
6.795	0.972	6.83	0.973	0.971
6.811	0.972	7.00	0.973	0.972
6.827	0.972	7.16	0.973	0.971
6.843	0.972	7.33	0.973	0.972
6.859	0.972	7.50	0.973	0.970
6.875	0.972	7.67	0.973	0.971
6.891	0.972	7.83	0.973	0.972
6.907	0.972	8.00	0.973	0.971
6.923	0.972	8.16	0.973	0.972
6.939	0.972	8.33	0.973	0.971
6.955	0.972	8.50	0.973	0.972
6.971	0.972	8.67	0.973	0.970
6.987	0.972	8.83	0.973	0.971
7.003	0.972	9.00	0.973	0.972
7.019	0.972	9.16	0.973	0.971
7.035	0.972	9.33	0.973	0.972
7.051	0.972	9.50	0.973	0.971
7.067	0.972	9.67	0.973	0.972
7.083	0.972	9.83	0.973	0.971
7.099	0.972	10.00	0.973	0.972




FIGURE 16-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE).

b. Normal Spectral Reflectance (Wavelength Dependence)

Only Byrne and Mancinilli [T32388] have measured the normal spectral reflectance for a 3.2 mm thick specimen in the 0.24 to 2.6 μm region. Grim, Linford, Dillow, Spinak, and Mills [A00001] measured the angular spectral reflectance for a 290 mil thick disk of Plexiglas in the 2-15 μm region with the incident angle of 15° and 45°. The reflectance value increases slightly with the increase of the incident angle.

Pregelhof, Francy, and Haas [T77125] calculated the absorption coefficient $a = 20 \text{ cm}^{-1}$ or larger in the wavelength region $\lambda > 4 \mu\text{m}$. Then, Eq. (4.16-7) becomes

$$\rho(\lambda) \approx R = (n - 1)^2 / (n + 1)^2 \quad (4.16-8)$$

which is independent of the thickness of the sample and depends only on index of refraction. However, the data of index of refraction is not available in the wavelength region above 1 μm . Thus, Eq. (4.16-8) is not applicable in this case.

Based on the three sets of experimental data and Eq. (4.16-7), the provisional values of normal spectral reflectance are presented in Table 16-2 and Figure 16-2 with an estimated uncertainty of about $\pm 30\%$.

TABLE 16-2. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELLENGTH DEPENDENCE)
 (WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ
T = 293	PLEXIGLAS	T = 293 (CONT.)	PLEXIGLAS	T = 293 (CONT.)	PLEXIGLAS
0.24	0.081	3.25	0.030	14.3	0.037
0.39	0.092	3.41	0.035	15.9	0.037
0.51	0.079	3.54	0.032		
0.80	0.075	3.68	0.036		
0.94	0.072	3.80	0.031		
1.30	0.074	3.84	0.029		
1.33	0.070	3.95	0.023		
1.19	0.063	4.00	0.022		
1.27	0.069	4.16	0.033		
1.33	0.060	4.68	0.032		
1.46	0.067	4.78	0.025		
1.54	0.073	5.00	0.023		
1.60	0.069	5.29	0.026		
1.65	0.047	5.62	0.022		
1.79	0.061	5.78	0.039		
1.82	0.066	6.03	0.032		
1.89	0.049	6.58	0.022		
1.96	0.260	6.75	0.028		
2.09	0.047	7.00	0.030		
2.13	0.046	7.30	0.027		
2.21	0.050	7.50	0.023		
2.43	0.036	7.75	0.025		
2.53	0.035	8.00	0.027		
2.58	0.024	8.50	0.038		
2.63	0.022	8.75	0.043		
2.66	0.036	9.20	0.036		
2.69	0.033	9.50	0.033		
2.70	0.036	9.73	0.031		
2.73	0.023	10.00	0.033		
2.76	0.022	10.50	0.031		
2.80	0.035	11.0	0.033		
2.84	0.029	11.5	0.029		
2.93	0.033	12.0	0.032		
2.96	0.026	12.4	0.035		
3.00	0.035	12.7	0.033		
3.07	0.025	13.0	0.032		
3.12	0.037	13.5	0.030		
3.17	0.030	13.8	0.030		
3.23	0.034	14.0	0.033		




FIGURE 16-2. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).




FIGURE 16-3. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).

TABLE 16-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF LUCITE (Wavelength Dependence)

Cur. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T3298	Byrd, R. F. and Mancinilli, L. N.	1954	0.24-2.6	293	Lucite	Approx. 1/8 in. thick; General Electric Spectrometer, Heckman Spectrometer, and Perkin-Elmer Spectrometer were used; data extracted from the smooth curve; $\theta=0^\circ$, $\omega=2\pi$; reported error $\leq 5\%$

TABLE 16-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF LUCITE (WAVELLENGTH DEPENDENCE)

(WAVELLENGTH, λ , μm ; TEMPERATURE, T ; K; REFLECTANCE, ρ)

λ	ρ
CURVE 1 $T = 293.$	
0.241	0.382
0.279	0.062
0.326	0.079
0.326	0.079
0.376	0.094
0.461	0.084
0.636	0.075
0.861	0.075
1.043	0.065
1.399	0.067
1.476	0.073
1.601	0.081
1.734	0.070
1.538	0.074
1.956	0.071
2.082	0.071
2.193	0.061
2.269	0.061
2.396	0.065
2.561	0.066
2.626	0.062
2.672	0.058
2.689	0.051

c. Angular Spectral Reflectance (Wavelength Dependence)

Only Grim, Linfored, Dillow, Spinak, and Mills [A00001] have measured the angular spectral reflectance for a 290 mil thick disk of Plexiglas in the 2-15 μm region with the incident angle of 15° and 45°, as shown in Table 16-6 and Figure 16-5. The reflectance values increase slightly with the increasing of incident angle. The provisional values are for Plexiglas at 293 K and are listed in Table 16-5 and shown in Figure 16-4. The estimated uncertainty is about $\pm 30\%$.

TABLE 16-5. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ
PLEXIGLAS							
$\theta=15^\circ$		$\theta=15^\circ$		$\theta=15^\circ$		$\theta=15^\circ$	
$T = 293$		$T = 293$	(CONT.)	$T = 293$	(CONT.)	$T = 293$	(CONT.)
0.24	0.081	0.25	0.030	14.3	0.037		
0.39	0.032	0.41	0.035	15.0	0.037		
0.51	0.079	0.54	0.032				
0.60	0.075	0.65	0.036				
0.64	0.072	0.80	0.036				
1.03	0.075	3.84	0.029				
1.08	0.072	3.95	0.033				
1.19	0.063	4.00	0.032				
1.27	0.059	4.16	0.033				
1.33	0.050	4.68	0.032				
1.46	0.067	4.73	0.028				
1.54	0.073	5.00	0.029				
1.63	0.059	5.29	0.026				
1.65	0.047	5.62	0.022				
1.79	0.062	5.78	0.023				
1.92	0.065	6.00	0.032				
1.89	0.049	6.59	0.022				
1.96	0.060	5.75	0.026				
2.05	0.047	7.00	0.030				
2.13	0.046	7.30	0.027				
2.20	0.050	7.52	0.023				
2.43	0.036	7.75	0.025				
2.53	0.035	8.00	0.027				
2.59	0.030	9.50	0.033				
2.58	0.028	5.50	0.038				
2.63	0.022	6.75	0.043				
2.55	0.036	9.35	0.036				
2.53	0.035	2.00	0.027				
2.59	0.030	9.50	0.033				
2.73	0.032	5.72	0.031				
2.73	0.029	10.00	0.033				
2.76	0.025	10.50	0.031				
2.83	0.035	11.0	0.033				
2.84	0.029	11.8	0.029				
2.93	0.036	12.9	0.032				
2.96	0.026	12.4	0.035				
3.03	0.036	12.7	0.032				
3.07	0.026	13.0	0.032				
3.12	0.037	13.5	0.030				
3.17	0.031	13.9	0.030				
3.20	0.034	14.0	0.033				




FIGURE 16-4. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).




FIGURE 16-5. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE).

TABLE 16-6. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF LUCITE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	Grimm, T.C., Linford, R.M.F., Dillow, C.F., Spivak, S., and Mills, J.P.	1972	2-15	293	Plexiglas 55 Sample M-1	Spectral hemispherical reflectance was measured by utilizing a Dune Associate ellipsoidal-mirror reflectometer; one in. diameter disc sample was used; data were extracted from the smooth curve; $\theta=15^\circ$, $\omega=2\pi$.	
2	Grimm, T.C., et al.	1972	2-15	293	Plexiglas 55 Sample M-1	The above specimen except the incident angle $\theta=45^\circ$ and data were extracted from the table.	

TABLE 16-7. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF LUCITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 293^\circ$	λ	ρ	CURVE 1 (CONT.)		λ	ρ	CURVE 1 (CONT.)		λ	ρ	CURVE 2 (CONT.)		
					CURVE 1 (CONT.)	CURVE 1 (CONT.)			CURVE 1 (CONT.)	CURVE 1 (CONT.)			CURVE 2 (CONT.)	CURVE 2 (CONT.)	
2.00	0.017	3.12	0.038	7.08	0.027	3.6	0.04								
2.01	0.033	3.17	0.030	7.24	0.027	5.0	0.04								
2.05	0.024	3.20	0.034	7.31	0.028	10.6	0.05								
2.09	0.073	3.25	0.030	7.58	0.023										
2.39	0.629	3.36	0.033	7.67	0.023										
2.11	0.047	3.41	0.036	7.77	0.025										
2.15	0.054	3.48	0.037	7.86	0.026										
2.16	0.059	3.54	0.033	7.95	0.027										
2.19	0.051	3.63	0.034	8.13	0.027										
2.21	0.062	3.68	0.037	8.25	0.028										
2.24	0.050	3.73	0.034	8.35	0.032										
2.27	0.347	3.78	0.033	8.47	0.037										
2.29	0.021	3.84	0.029	8.58	0.043										
2.30	0.043	3.95	0.031	8.75	0.044										
2.32	0.030	3.98	0.034	8.89	0.043										
2.34	0.043	4.04	0.032	9.07	0.037										
2.37	0.031	4.09	0.030	9.34	0.036										
2.39	0.060	4.16	0.034	9.50	0.033										
2.43	0.023	4.23	0.031	9.73	0.031										
2.45	0.039	4.30	0.034	10.10	0.034										
2.45	0.024	4.42	0.031	10.35	0.033										
2.47	0.040	4.57	0.031	10.54	0.031										
2.49	0.035	4.68	0.032	10.88	0.031										
2.51	0.046	4.78	0.028	11.24	0.034										
2.53	0.036	4.94	0.028	11.45	0.032										
2.55	0.039	5.04	0.030	11.82	0.029										
2.57	0.029	5.21	0.029	12.18	0.034										
2.63	0.022	5.29	0.026	12.39	0.036										
2.66	0.037	5.40	0.027	12.71	0.034										
2.69	0.030	5.62	0.022	13.01	0.032										
2.70	0.036	5.76	0.040	13.60	0.030										
2.73	0.029	5.96	0.032	13.87	0.030										
2.76	0.025	6.05	0.032	14.02	0.033										
2.79	0.036	6.15	0.029	14.29	0.037										
2.84	0.029	6.33	0.029	14.67	0.037										
2.90	0.039	6.58	0.022	2.6	0.05										
2.96	0.026	6.75	0.028												
3.00	0.037	6.89	0.030												
3.07	0.026	7.01	0.030												

CURVE 2
 $T = 293^\circ$

2.6 0.05

d. Normal Spectral Absorptance (Wavelength Dependence)

Byrne and Mancinelli [T32388] measured the absorptance of a 3.2 mm thick specimen in the 0.2 to 2.7 μm region. Pilipetskii, Raizer, and Upadyshov [E37991] used a ruby laser $\lambda = 0.69 \mu\text{m}$ with incident power of 0.5-1.1 joules to obtain the absorptance for specimens 43 mm long. According to Eq. (4.16-5), $\alpha(\lambda) \approx (1-R) [1 - (1-R)e^{-ad} - Re^{-2ad}]$ which is strongly dependent on the thickness of thin films. However, for the bulk materials in the wavelength region $\lambda > 3 \mu\text{m}$

$$\alpha(\lambda) \approx (1-R) \quad (4.16-9)$$

which is independent of the thickness, and the material becomes opaque. From Kirchhoff's law $\alpha(\lambda) = \epsilon(\lambda)$, the absorptance is equal to emittance. The calculated values are shown in Table 16-8 and in Figure 16-6 together with the experimental results.

The estimated uncertainty is about $\pm 20\%$.

TABLE 16-6. FRCVISIONAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : ABSORPTANCE, α)

λ	α	λ	α	λ	α	λ	α
THICKNESS 3.2MM							
T = 293 (CONT.)							
6.240	0.915	1.92	0.430	9.33	0.964		
6.259	0.901	1.95	0.400	9.53	0.967		
6.296	0.919	2.00	0.371	10.00	0.957		
6.356	0.910	2.09	0.699	10.50	0.969		
6.364	0.902	2.13	0.811	11.00	0.967		
6.369	0.592	2.20	0.950	11.83	0.971		
6.374	0.355	2.43	0.964	12.00	0.968		
6.376	0.772	2.53	0.961	12.70	0.977		
6.389	0.145	2.58	0.926	13.00	0.964		
6.396	0.120	2.63	0.927	13.50	0.970		
6.463	0.646	2.66	0.922	14.00	0.967		
6.422	0.012	2.60	0.565	14.50	0.963		
6.510	0.312	3.00	0.964	15.00	0.963		
6.760	0.312	3.07	0.274				
6.741	0.253	3.12	0.963				
6.763	0.837	3.20	0.966				
6.768	0.097	3.25	0.970				
6.815	0.095	3.41	0.955				
6.844	0.220	3.54	0.968				
6.359	0.256	3.65	0.964				
6.336	0.054	3.80	0.970				
1.181	0.253	3.84	0.971				
1.214	0.114	3.95	0.967				
1.270	0.039	4.22	0.960				
1.313	0.374	4.15	0.957				
1.347	0.250	4.58	0.968				
1.367	0.311	4.73	0.972				
1.406	0.253	5.00	0.971				
1.360	0.381	5.29	0.974				
1.607	0.148	5.62	0.978				
1.764	0.660	5.78	0.961				
1.677	0.845	6.00	0.963				
1.753	0.778	6.30	0.978				
1.727	0.732	6.75	0.972				
1.764	0.512	7.00	0.973				
1.826	0.342	7.53	0.977				
1.377	0.365	8.00	0.973				
1.890	0.517	8.50	0.962				
1.900	0.700	8.75	0.957				




FIGURE 16-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE).




FIGURE 16-7. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE).

TABLE 16-9. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF LUCITE (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	T32388	Byrne, R. T. and Mancinelli, L. N.	1954	0.2-2.7	~293	Lucite	Approx. 1/8 in. thick specimen; Beckman Spectrometer, General Electric Spectrometer and Perkin-Elmer Spectrometer were employed; data were extracted from the smooth curve; $\theta \sim 0^\circ$, reported error 5%.
2	E37931	Filipetskil, N. F.* Raizer, Yu. P., and Upadyshev, V. A.	1968	0.69	~293	PMA	Polymethylmeth acrylate sample of dimension 43 x 9 x 9 mm; ruby laser with incident power about 0.5-1.1 Joules was used; $\theta \sim 0^\circ$, reported error 9%.

TABLE 16-10. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF LUCITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	CURVE $T = 293.$	α	λ	CURVE 1 (CONT.)	α
0.260	0.934		1.860	0.428	
0.285	0.922		1.930	0.396	
0.296	0.914		1.956	0.433	
0.298	0.279		1.992	0.378	
0.309	0.126		2.024	0.390	
0.316	0.099		2.069	0.442	
0.326	0.067		2.094	0.545	
0.337	0.045		2.094	0.721	
0.375	0.022		2.123	0.777	
0.418	0.000		2.157	0.837	
0.843	0.009		2.182	0.904	
0.899	0.022		2.252	0.917	
0.959	0.022		2.298	0.924	
1.027	0.017		2.362	0.924	
1.073	0.025		2.408	0.916	
1.098	0.037		2.431	0.903	
1.112	0.066		2.464	0.884	
1.156	0.156		2.504	0.876	
1.196	0.161		2.564	0.876	
1.230	0.154		2.608	0.887	
1.264	0.399		2.682	0.928	
1.290	0.067				
1.315	0.085				
1.345	0.195				
1.376	0.225				
1.406	0.233				
1.441	0.170				
1.456	0.132				
1.491	0.100				
1.539	0.124				
1.628	0.200				
1.657	0.335				
1.682	0.612				
1.688	0.687				
1.705	0.704				
1.712	0.646				
1.737	0.512				
1.755	0.473				
2.811	0.439				

CURVE 2
 $T = 293.$

0.69 0.46

e. Normal Spectral Transmittance (Wavelength Dependence)

There are 20 sets of experimental data available for the transmittance of Lucite as listed in Table 16-13. Of these, 12 sets measured on thin film samples are shown in Figure 16-10. They represent reasonably consistent results with each other. Major absorption peaks near $\lambda = 3.4, 5.8, 6.9, 7.2, 8.0, 8.7$, and $13.4 \mu\text{m}$ are observed.

As we have mentioned in d., the bulk Lucite materials become opaque above $\lambda = 3 \mu\text{m}$. At the visible and near infrared region it transmits about 90%. According to Eq. (4.16-6), $\tau(\lambda) = (1-R)^2 e^{-ad}$, the transmittance becomes very strongly dependent on the thickness of the sample where absorption coefficient a is not small. Therefore, the provisional values of transmittance for a sample with thickness of 3.2 mm at 293 K are derived, based on the works of Byrne and Mancinelli [T32388], Acitelli, Gumby, and Naujobas [T40338], Turner and Keller [T77381], and duPont Co. [E62601]. The values are shown in Table 16-11 and in Figure 16-8 with the experimental data.

The provisional values are estimated with an uncertainty of about $\pm 30\%$.

TABLE 16-11. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	λ	τ	λ	τ
THICKNESS 3.2MM				THICKNESS 3.2MM			
$T = 293$				$T = 293$ (CONT.)			
0.250	0.300	1.928	0.600	11.50	0.00		
0.259	0.313	1.877	0.585	12.00	0.00		
0.261	0.304	1.846	0.333	12.50	0.00		
0.262	0.318	1.899	0.253	13.00	0.00		
0.264	0.313	1.809	0.274	13.50	0.00		
0.266	0.300	1.999	0.319	14.00	0.00		
0.357	0.010	1.914	0.339	14.50	0.00		
0.364	0.015	1.916	0.456	15.00	0.00		
0.369	0.030	1.924	0.470				
0.374	0.069	1.928	0.502				
0.376	0.146	1.950	0.444				
0.389	0.775	2.030	0.582				
0.290	0.817	2.09	0.251				
0.403	0.630	2.13	0.141				
0.422	0.503	2.20	0.000				
0.510	0.908	2.49	0.000				
0.700	0.912	2.53	0.033				
0.741	0.916	2.58	0.043				
0.765	0.543	2.61	0.060				
0.783	0.913	2.63	0.051				
0.815	0.323	2.65	0.042				
0.344	0.932	2.68	0.050				
0.890	0.874	3.03	0.003				
1.003	0.396	3.80	0.001				
1.182	0.594	4.00	0.005				
1.214	0.325	4.50	0.004				
1.259	0.392	5.00	0.00				
1.316	0.366	5.50	0.00				
1.347	0.592	6.00	0.00				
1.367	0.629	6.50	0.00				
1.400	0.679	7.00	0.00				
1.500	0.349	7.50	0.00				
1.507	0.763	8.00	0.00				
1.662	0.352	8.50	0.00				
1.670	0.134	9.00	0.00				
1.677	0.104	9.50	0.00				
1.709	0.170	10.00	0.00				
1.727	0.209	10.50	0.00				
1.784	0.429	11.00	0.00				




FIGURE 16-8. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE).




FIGURE 16-9. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE).




FIGURE 16-10. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE THIN FILMS
(WAVELENGTH DEPENDENCE).

TABLE 16-12. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T40591	Wells, A.J.	1940	3.3-25	293	Lucite	Films were made from the powder of DuPont Co. by mercury and dip method; film thickness 25 μ ; data were extracted from the figure; $\theta \sim 0^\circ$.
2 T40591	Wells, A.J.	1940	3.3-25	293	Plexiglas	5 μ thickness sheet was obtained from the Röhm and Haas Co.; films were made by mercury method; data were extracted from the figure; $\theta \sim 0^\circ$.
3 T40591	Wells, A.J.	1940	3.3-25	293	Plexiglas	The above specimen except 7 μ thickness.
4 T24947	Armour Research Foundation	1961	2-15	293	Lucite	0.01 in. thickness sample was deposited on the surface of sodium chloride discs, it transmit well in the 2-6 μ and 9.5-15 μ spectral region; in the visible region, its refractive index is 1.49; curing temperature = 54 C; data were extracted from the figure; $\theta \sim 0^\circ$.
5 T19814	Moore, L.E., Prastein, M., Tompkins, E.H., and VanOsterburg, D.O.	1958	2-15	293	Lucite	Refractive index = 1.49 at $\lambda = 5893 \text{ \AA}$; unknown thickness; data were extracted from the figure; $\theta \sim 0^\circ$.
6 T40338	Acitelli, M.A., Gumbay, W.L., and Naujokas, A.A.	1966	0.3-2.2	296	Poly(methyl methacrylate)	7.46 mm thickness disc about 50 mm in diameter; Cary Spectrophotometer model 14 was employed; data were extracted from the figure; $\theta \sim 0^\circ$.
7 T40338	Acitelli, M.A., et al.	1966	0.3-2.2	296	Poly(methyl methacrylate)	The above specimen after 100 standard fade hr in solarization.
8 T47094	Holland, W.R.	1967	0.2-2.6	296	Cross linked methacrylate	1/4 in. thick; the transmittance was measured by using a Perkin-Elmer model 99 mono-chromator; data were extracted from the figure; $\theta \sim 0^\circ$.
9 T47094	Holland, W.R.	1967	0.2-2.6	296	Cross linked methacrylate	The above specimen except it was indicated by simulated sunlight for 14 days, 30 days, 60 days and 90 days respectively.
10 T76795	Stimler, S.S. and Kaganise, R.E.	1966	2.5-25	~293	Lucite 763497	A Beckman model IR-112 spectrophotometer was used to obtain the spectra of film sample; specimen was obtained from DuPont; data were extracted from the figure; $\theta \sim 0^\circ$.
11 T51594	Story, J.G.	1961	2-15	296	Polymethyl methacrylate	No thickness has been given; the absorption peak at 3.37 μ indicating absence of long chains of CH_2 groups; strong absorption at 5.77 μ due to the C-O bond and strong absorption at 8 to 9 μ region, probably due to C-O-C stretching mode; data were extracted from the figure.
12 T32288	Byrne, R.F. and Mancinelli, L.N.	1954	0.2-2.7	293	Lucite	Approx. 1/8 in. thick; for the ultraviolet region Beckman Model DC Spectrometer was used; for the visible and near infrared region a General Electric Recording Spectrometer was used; for the measurement above 1 μm , a Perkin-Elmer Infrared Spectrometer was employed; data were extracted from the figure.
13 T76793	Lara, M.O.	1967	2.5-25	~293	Lucite	The specimen was condensed pyrolyzate on potassium bromide or sodium chloride; a Beckman IR-9 double beam, prism-grating infrared spectrophotometer was used to obtain the spectra; data were extracted from the figure; $\theta \sim 0^\circ$.
14 T76793	Lara, M.O.	1967	2.5-25	~293	Plexiglass	Similar to the above specimen.
15 T35117	Hass, M. and O'Hara, M.	1965	2.86-100	~293	DP Polymethyl methacrylate grating	0.051 μm thickness specimen was obtained from diffraction products; a Perkin-Elmer model and a Cary Spectrometer were used for measurements; data were extracted from the figure; $\theta \sim 0^\circ$.

TABLE 16-12. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (Wavelength Dependence) (continued)

Cur. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
16 T76512	Kagarike, R. E. and Weinberger, L. A.	1954	2-15	~293	Plexiglas B	The specimen was obtained from Rohm and Haas Co.; the specimen was dissolved in methyl ethyl ketone and the resulting viscous solution spread uniformly over a rock salt or KBr plate, the solvent was removed by heating under vacuum or normal evaporation at room temperature; a Perkin-Elmer model 21 spectrometer was used; data were extracted from the figure; $\theta \sim 0^\circ$.
17 E26638	Cartajal, B. G., III.	1966	2.5-25	~293	GDP MMA	Glow discharge polymerized methyl methacrylate; data were extracted from the smooth curve.
18 T77381	Turner, H. C. and Keller, F. E.	1959	0.185-2.0	~293	Plexiglas	Beckman DK-2 spectrorereflectometer was used for measurement; data were extracted from the figure; $\theta \sim 0^\circ$.
19 E62501	du Pont Co.	1968	0.20-2.30	~293	Lucite 129, 130, 140, 147, 148	3.2 mm thickness; index of refraction = 1.491; dispersion = 5%; data were extracted from the figure.
20 E52601	du Pont Co.	1968	0.2-0.7	~293	Lucite 140 T	3.2 mm thickness; data were extracted from the figure.
21 E16981	Imperial Chemical Industries, Ltd.	1962	0.25-0.7	~293	"Dakota" MG	0.125 in. thickness; disc specimen; data were extracted from the figure.

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	τ	CURVE 1 $T = 293.$	λ	τ	CURVE 2 (CONT.)	λ	τ	CURVE 3 (CONT.)	λ	τ	CURVE 4 (CONT.)	λ	τ	CURVE 4 (CONT.)	λ	τ	CURVE 5 $T = 293.$		
			3.45	0.862		3.85	0.896		3.06	0.908		7.46	0.799		12.74	0.878			
3.35	0.762	3.57	0.865	4.00	0.907	3.21	0.878	7.57	0.799	12.85	0.878	3.45	0.751	4.17	0.907	3.28	0.752	7.78	0.693
3.45	0.751	3.70	0.904	4.17	0.907	3.35	0.914	3.35	0.680	7.84	0.575	3.57	0.802	4.00	0.907	3.36	1.36	13.36	0.665
3.55	0.802	3.85	0.923	4.35	0.904	3.36	0.904	3.36	0.532	7.84	0.403	3.70	0.857	4.07	0.907	3.61	0.805	13.61	0.843
3.70	0.857	4.00	0.907	4.55	0.894	3.43	0.849	3.43	0.622	7.93	0.476	3.85	0.914	4.17	0.907	3.77	0.843	14.10	0.843
3.85	0.914	4.17	0.907	4.76	0.894	3.47	0.849	3.47	0.723	8.02	0.349	4.00	0.860	4.35	0.907	3.84	1.10	14.26	0.810
4.00	0.860	4.35	0.914	5.00	0.894	3.53	0.827	3.53	0.806	8.13	0.588	4.17	0.889	4.55	0.907	3.98	1.65	14.65	0.810
4.17	0.880	4.55	0.904	4.76	0.870	3.56	0.826	3.60	0.868	8.25	0.398	4.35	0.889	5.00	0.907	3.98	1.77	14.77	0.797
4.35	0.889	5.00	0.870	5.00	0.870	3.68	0.680	3.78	0.895	8.33	0.228	4.76	0.926	5.26	0.907	4.00	1.96	14.96	0.810
4.55	0.341	5.00	0.870	5.26	0.869	6.25	0.762	6.20	0.895	8.43	0.289	4.76	0.926	5.56	0.907	4.25	2.00	15.00	0.810
4.76	0.792	5.26	0.869	5.68	0.846	6.67	0.700	6.41	0.907	8.56	0.172	5.00	0.870	5.88	0.907	4.76	2.09	15.26	0.810
5.00	0.787	5.56	0.846	5.33	0.728	7.14	0.667	4.58	0.898	8.62	0.111	5.26	0.765	5.57	0.870	4.98	2.18	15.56	0.810
5.26	0.765	5.33	0.728	6.25	0.821	7.69	0.560	4.96	0.918	8.73	0.153	5.56	0.700	6.33	0.870	5.07	2.27	15.86	0.810
5.56	0.700	6.25	0.821	6.57	0.766	8.33	0.332	5.07	0.901	8.73	0.299	6.00	0.744	6.76	0.870	5.33	2.36	16.16	0.810
5.88	0.564	6.57	0.766	7.14	0.760	9.09	0.579	5.43	0.869	8.77	0.474	6.25	0.705	7.61	0.870	5.77	2.45	16.46	0.810
6.25	3.605	7.14	0.760	7.63	0.671	10.00	0.702	5.54	0.847	8.83	0.575	6.67	0.765	8.00	0.870	6.00	2.54	16.76	0.810
6.67	0.464	7.63	0.671	8.33	0.468	10.87	0.835	5.65	0.602	8.89	0.676	7.14	0.765	8.28	0.870	6.53	2.63	17.06	0.810
7.14	0.450	8.33	0.468	9.09	0.697	11.11	0.835	5.70	0.346	8.98	0.739	7.69	0.765	8.53	0.870	6.88	2.72	17.36	0.810
7.69	0.328	9.09	0.697	10.00	0.806	11.76	0.823	5.74	0.097	9.17	0.765	8.00	0.765	8.73	0.870	6.98	2.81	17.66	0.810
8.33	0.105	10.00	0.806	10.87	0.671	12.50	0.853	5.81	0.286	9.30	0.713	9.09	0.765	9.00	0.870	7.07	2.90	17.96	0.810
9.09	0.346	10.87	0.671	11.11	0.871	13.33	0.835	5.83	0.651	9.42	0.743	9.67	0.765	9.67	0.870	7.27	2.99	18.27	0.810
9.38	0.336	11.11	0.871	11.76	0.865	14.29	0.840	5.93	0.703	9.44	0.636	9.98	0.765	9.98	0.870	7.46	3.08	18.57	0.810
10.00	0.503	11.76	0.865	12.50	0.879	15.38	0.863	5.93	0.832	9.52	0.688	10.36	0.765	10.36	0.870	7.65	3.17	18.86	0.810
10.87	0.682	12.50	0.879	13.33	0.856	16.67	0.863	6.08	0.868	9.66	0.921	11.11	0.765	11.11	0.870	7.84	3.26	19.16	0.810
11.11	0.724	13.33	0.856	14.29	0.851	18.18	0.861	6.29	0.860	9.83	0.890	11.67	0.765	11.67	0.870	8.03	3.35	19.46	0.810
11.76	1.653	14.29	0.851	15.38	0.890	20.00	0.835	6.42	0.860	9.95	0.783	12.33	0.765	12.33	0.870	8.22	3.44	19.76	0.810
12.50	0.745	15.38	0.890	16.67	0.879	22.22	0.891	6.47	0.888	10.00	0.683	13.33	0.765	13.33	0.870	8.41	3.53	20.03	0.810
13.33	0.692	16.67	0.879	18.18	0.879	25.00	0.871	6.56	0.888	10.04	0.658	14.29	0.765	14.29	0.870	8.60	3.62	20.33	0.810
14.29	0.666	18.18	0.879	20.00	0.870	22.00	0.922	6.61	0.817	10.12	0.681	15.38	0.765	15.38	0.870	8.79	3.71	20.63	0.810
15.38	0.835	20.00	0.870	22.00	0.922	25.00	0.916	6.64	0.572	10.22	0.731	16.57	0.765	16.57	0.870	9.03	3.80	20.93	0.810
16.67	0.844	22.00	0.922	25.00	0.916	25.00	0.906	6.74	0.572	10.32	0.690	17.82	0.765	17.82	0.870	9.23	3.89	21.22	0.810
18.18	0.835	25.00	0.916	25.00	0.906	25.00	0.906	6.85	0.446	10.43	0.792	19.00	0.765	19.00	0.870	9.42	3.98	21.52	0.810
20.00	0.799	25.00	0.906	25.00	0.906	25.00	0.906	6.97	0.520	10.70	0.843	20.78	0.765	20.78	0.870	9.61	4.07	21.82	0.810
22.02	0.858	25.00	0.906	25.00	0.906	25.00	0.906	7.02	0.793	11.36	0.923	22.33	0.765	22.33	0.870	9.81	4.16	22.63	0.810
25.00	0.848	25.00	0.906	25.00	0.906	25.00	0.906	7.14	0.793	11.78	0.779	23.00	0.765	23.00	0.870	10.00	4.25	23.33	0.810
CURVE 2 $T = 293.$	3.35	3.45	3.57	3.68	3.80	3.90	3.99	4.00	4.06	4.14	4.24	4.35	4.45	4.55	4.65	4.75	4.85	4.95	5.05
CURVE 3 $T = 293.$	3.45	3.57	3.68	3.80	3.90	3.99	4.00	4.06	4.14	4.24	4.35	4.45	4.55	4.65	4.75	4.85	4.95	5.05	5.15
CURVE 4 $T = 293.$	3.57	3.68	3.80	3.90	3.99	4.00	4.06	4.14	4.24	4.35	4.45	4.55	4.65	4.75	4.85	4.95	5.05	5.15	5.25
3.35	0.862	3.70	0.889	4.00	0.906	4.35	0.922	4.76	0.938	5.14	0.954	5.57	0.970	5.93	0.986	6.31	0.996	6.68	0.996

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE) (CONTINUED)
WAVELENGTH, λ , μm ; TEMPERATURE, T ; K ; TRANSMITTANCE, τ

λ	τ	CURVE 5 (CONT.)	λ	τ	CURVE 6 (CONT.)	λ	τ	CURVE 6 (CONT.)	λ	τ	CURVE 6 (CONT.)
5.97	0.755	9.21	0.742	0.349	0.841	1.202	0.766	1.696	0.022	2.177	0.137
6.02	0.815	9.32	0.742	0.355	0.868	1.207	0.617	1.705	0.027	2.185	0.076
6.12	0.855	9.46	0.699	0.368	0.885	1.216	0.850	1.717	0.027	2.200	0.019
6.25	0.838	9.53	0.768	0.384	0.899	1.234	0.881	1.733	0.052		
6.47	0.848	9.56	0.845	0.415	0.909	1.253	0.895	1.749	0.121		
6.54	0.863	9.65	0.899	0.537	0.911	1.261	0.911	1.759	0.170		
6.69	0.615	10.00	0.838	0.544	0.908	1.268	0.889	1.766	0.170	0.200	0.000
6.71	0.639	10.08	0.665	0.554	0.911	1.277	0.896	1.775	0.153	0.336	0.000
6.71	0.515	10.17	0.617	0.628	0.911	1.291	0.896	1.782	0.169	0.345	0.018
6.84	0.229	10.33	0.722	0.696	0.919	1.308	0.883	1.810	0.320		
6.94	0.426	10.45	0.668	0.734	0.919	1.318	0.855	1.819	0.330	0.364	0.500
6.99	0.527	10.57	0.781	0.748	0.925	1.335	0.580	1.831	0.330	0.376	0.642
7.02	0.654	10.77	0.830	0.772	0.925	1.338	0.509	1.840	0.321	0.399	0.854
7.10	0.757	10.96	0.830	0.793	0.933	1.348	0.474	1.847	0.286	0.410	0.878
7.16	0.733	11.10	0.760	0.832	0.935	1.354	0.462	1.856	0.274	0.426	0.894
7.16	0.656	11.30	0.873	0.871	0.927	1.359	0.408	1.866	0.295	0.456	0.905
7.21	0.620	11.54	0.873	0.864	0.917	1.366	0.388	1.876	0.267	0.538	0.909
7.29	0.663	11.62	0.775	0.876	0.899	1.374	0.405	1.883	0.061	0.549	0.907
7.37	0.649	11.95	0.746	0.866	0.877	1.383	0.490	1.899	0.050	0.558	0.915
7.46	0.760	12.23	0.846	0.893	0.877	1.393	0.460	1.908	0.063	0.685	0.919
7.64	0.760	12.37	0.799	0.904	0.895	1.401	0.475	1.918	0.167	0.768	0.926
7.77	0.714	12.61	0.850	0.925	0.916	1.412	0.468	1.927	0.206	0.813	0.933
7.85	0.592	13.05	0.811	0.940	0.916	1.420	0.487	1.934	0.184	0.838	0.933
7.88	0.363	13.32	0.710	0.948	0.913	1.449	0.658	1.942	0.158	0.859	0.926
7.98	0.641	13.43	0.629	0.962	0.913	1.462	0.705	1.950	0.174	0.873	0.912
8.01	0.338	13.50	0.696	0.970	0.899	1.481	0.760	1.957	0.251	0.883	0.893
8.03	0.293	13.55	0.776	0.986	0.895	1.496	0.790	1.968	0.317	0.889	0.888
8.23	0.557	13.69	0.810	0.999	0.882	1.514	0.816	1.982	0.330	0.898	0.880
8.30	0.381	14.00	0.823	1.012	0.895	1.533	0.816	1.992	0.330	0.911	0.905
8.35	0.327	14.47	0.803	1.026	0.895	1.562	0.781	2.004	0.316	0.924	0.916
8.45	0.188	15.00	0.766	1.050	0.911	1.587	0.726	2.020	0.314	0.964	0.916
8.51	0.271					1.601	0.658	2.051	0.244	0.974	0.901
8.57	0.271					1.614	0.577	2.065	0.226	0.984	0.901
8.65	0.173					1.625	0.524	2.077	0.179	0.993	0.868
8.77	0.109					1.635	0.479	2.106	0.024	1.004	0.888
8.84	0.267					1.645	0.306	2.118	0.024	1.015	0.895
8.84	0.431					1.653	0.070	2.132	0.000	1.029	0.895
8.89	0.546					1.660	0.031	2.152	0.024	1.053	0.915
9.01	0.659					1.673	0.000	2.171	0.023	1.074	0.915
						1.673	0.486	2.171	0.023	1.080	0.905

CURVE 6
 $T = 296.$

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 10 (CONT.)		CURVE 10 (CONT.)		CURVE 10 (CONT.)		CURVE 11 (CONT.)		CURVE 11 (CONT.)	
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
3.11	0.963	6.14	0.928	9.15	0.766	17.79	0.951	5.74	0.197	6.42	0.216
3.16	0.955	6.27	0.934	9.26	0.750	16.59	0.951	5.78	0.072	6.45	0.267
3.25	0.939	6.45	0.934	9.35	0.710	19.06	0.915	5.83	0.174	6.51	0.296
3.28	0.895	6.55	0.918	9.40	0.754	19.84	0.988	5.85	0.429	6.60	0.211
3.33	0.529	6.61	0.886	9.47	0.897	20.45	0.857	5.89	0.563	6.72	0.119
3.35	0.667	6.64	0.854	9.57	0.936	20.83	0.893	5.94	0.703	6.81	0.315
3.38	0.424	6.69	0.527	9.69	0.947	21.74	0.906	5.98	0.808	6.84	0.496
3.40	0.608	6.72	0.516	9.79	0.938	22.78	0.893	6.02	0.846	6.90	0.611
3.43	0.659	6.78	0.559	9.87	0.892	23.81	0.836	6.12	0.574	6.97	0.696
3.46	0.813	6.80	0.523	9.98	0.636	25.00	0.776	6.25	0.459	6.99	0.737
3.48	0.876	6.81	0.440	10.06	0.627			6.50	0.877	9.18	0.761
3.52	0.833	6.87	0.416	10.15	0.703			6.62	0.857	9.26	0.761
3.53	0.923	6.90	0.442	10.28	0.671			6.66	0.618	9.43	0.723
3.57	0.957	6.95	0.433	10.44	0.793			6.70	0.668	9.52	0.877
3.68	0.971	7.02	0.796	10.56	0.843	2.00		6.70	0.567	9.60	0.922
3.78	0.971	7.06	0.827	10.67	0.856	2.21		6.73	0.539	9.92	0.869
3.86	0.964	7.11	0.778	10.86	0.832	2.32		6.82	0.552	10.00	0.717
3.92	0.973	7.13	0.714	11.05	0.903	2.45		6.93	0.439	10.11	0.645
4.09	0.976	7.16	0.641	11.20	0.921	2.55		7.00	0.605	10.23	0.706
4.15	0.965	7.23	0.749	11.36	0.917	2.66		7.08	0.662	10.31	0.734
4.27	0.976	7.26	0.764	11.63	0.848	2.83		7.08	0.779	10.39	0.691
4.57	0.976	7.30	0.764	11.79	0.765	3.23		7.14	0.755	10.51	0.804
4.67	0.957	7.35	0.804	11.89	0.862	3.28		7.18	0.648	10.71	0.844
5.00	0.972	7.46	0.625	12.02	0.851	3.36		7.26	0.685	10.84	0.856
5.10	0.967	7.50	0.806	12.09	0.895	3.43		7.33	0.674	11.05	0.804
5.28	0.992	7.66	0.770	12.24	0.864	3.49		7.39	0.721	11.27	0.895
5.40	0.976	7.72	0.694	12.44	0.922	3.54		7.44	0.760	11.47	0.896
5.50	0.958	7.82	0.396	12.56	0.931	3.62		7.50	0.777	11.64	0.857
5.58	0.934	7.93	0.425	12.77	0.911	3.73		7.61	0.777	11.85	0.779
5.62	0.899	8.03	0.322	13.05	0.811	4.55		7.74	0.736	11.98	0.791
5.67	0.844	8.14	0.543	13.25	0.691	4.97		7.81	0.638	12.10	0.848
5.70	0.499	8.19	0.574	13.37	0.895	5.04		7.86	0.469	12.19	0.871
5.72	0.102	8.29	0.399	13.64	0.938	5.18		7.98	0.393	12.33	0.840
5.75	0.046	8.35	0.230	13.87	0.954	5.25		7.96	0.456	12.60	0.878
5.80	0.079	8.45	0.290	14.12	0.941	5.34		8.06	0.323	12.88	0.869
5.84	0.591	8.55	0.263	14.43	0.965	5.47		8.09	0.372	12.96	0.840
5.86	0.771	8.65	0.143	15.08	0.974	5.56		8.15	0.527	13.15	0.789
5.93	0.805	8.91	0.593	15.43	0.966	5.61		8.31	0.575	13.29	0.735
5.97	0.901	9.01	0.695	16.18	0.973	5.65		8.34	0.366	13.38	0.671
6.03	0.914	9.08	0.745	17.18		5.71		8.35	0.264	13.45	0.704

CURVE 11
T = 296.

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 11 (CONT.)		CURVE 12 (CONT.)		CURVE 13 (CONT.)		CURVE 13 (CONT.)		CURVE 13 (CONT.)	
		λ	τ								
13.43	0.783	1.558	0.801	2.67	0.819	4.32	0.875	6.20	0.872	6.09	0.773
13.59	0.840	1.591	0.767	2.71	0.862	4.41	0.900	6.36	0.886	8.18	0.550
13.75	0.855	1.617	0.645	2.74	0.856	4.46	0.900	6.40	0.862	8.24	0.306
14.08	0.855	1.670	0.259	2.74	0.833	4.49	0.912	6.40	0.795	8.30	0.216
14.99	0.816	1.685	0.240	2.78	0.860	4.60	0.877	6.43	0.868	8.37	0.255
CURVE 12 $T = 293$.		1.700	0.254	2.82	0.860	4.65	0.895	6.48	0.880	8.43	0.349
		1.714	0.342	2.83	0.880	4.73	0.883	6.51	0.852	8.50	0.092
		1.747	0.456	2.87	0.880	4.84	0.906	6.57	0.798	8.55	0.072
		1.763	0.490	2.89	0.867	4.93	0.890	6.61	0.842	8.61	0.106
0.275	0.003	1.834	0.501	2.92	0.880	5.00	0.901	6.63	0.793	8.68	0.604
0.303	0.547	1.912	0.526	3.02	0.880	5.04	0.906	6.68	0.869	8.75	0.898
0.313	0.747	1.968	0.554	3.06	0.880	5.11	0.920	6.72	0.826	8.82	0.857
0.327	0.612	1.989	0.562	3.08	0.888	5.14	0.909	6.74	0.791	9.00	0.884
0.336	0.845	2.021	0.544	3.13	0.865	5.17	0.923	6.80	0.642	9.15	0.897
0.351	0.878	2.038	0.486	3.16	0.883	5.20	0.897	6.80	0.569	9.42	0.897
0.369	0.904	2.050	0.310	3.18	0.874	5.24	0.912	6.84	0.589	9.51	0.910
0.391	0.918	2.066	0.198	3.21	0.835	5.29	0.888	6.88	0.590	9.66	0.762
0.419	0.926	2.122	0.114	3.25	0.868	5.32	0.897	6.93	0.564	9.76	0.721
0.567	0.926	2.156	0.060	3.28	0.813	5.35	0.879	6.98	0.741	9.84	0.779
0.609	0.933	2.195	0.023	3.29	0.750	5.36	0.911	7.01	0.792	9.91	0.836
0.838	0.933	2.259	0.012	3.31	0.704	5.40	0.920	7.03	0.749	10.12	0.889
0.900	0.914	2.350	0.012	3.34	0.641	5.42	0.906	7.07	0.770	10.24	0.919
0.943	0.914	2.418	0.026	3.35	0.652	5.49	0.906	7.11	0.758	10.46	0.700
1.002	0.925	2.476	0.055	3.36	0.536	5.56	0.860	7.17	0.782	10.58	0.537
1.068	0.904	2.516	0.066	3.40	0.710	5.59	0.882	7.20	0.803	10.81	0.801
1.119	0.853	2.572	0.067	3.43	0.784	5.61	0.862	7.26	0.818	10.88	0.916
1.155	0.795	2.635	0.048	3.47	0.835	5.67	0.403	7.26	0.642	11.07	0.938
1.197	0.765	2.668	0.019	3.51	0.806	5.69	0.130	7.34	0.864	11.51	0.938
1.226	0.792	3.54	0.865	5.71	0.094	7.37	0.889	11.74	0.916		
1.271	0.859	3.60	0.879	5.75	0.145	7.42	0.555	11.95	0.812		
1.289	0.867	3.67	0.888	5.79	0.605	7.45	0.381	12.03	0.753		
1.312	0.857	3.81	0.886	5.84	0.806	7.50	0.361	12.22	0.729		
1.344	0.765	2.50	0.879	3.83	0.898	5.85	0.790	7.56	0.412	12.30	0.668
1.364	0.701	2.56	0.878	3.93	0.898	5.93	0.614	7.61	0.389	12.39	0.886
1.391	0.633	2.56	0.834	3.96	0.885	5.97	0.852	7.68	0.461	12.47	0.936
1.422	0.718	2.58	0.858	4.01	0.902	6.02	0.827	7.73	0.699	12.76	0.959
1.437	0.778	2.60	0.829	4.06	0.902	6.04	0.657	7.79	0.437	13.04	0.944
1.457	0.820	2.62	0.858	4.16	0.902	6.06	0.710	7.86	0.845	13.66	0.966
1.488	0.836	2.65	0.880	4.19	0.870	6.11	0.691	7.91	0.869	14.39	0.942
1.526	0.823	2.66	0.856	4.23	0.815	6.14	0.808	8.03	0.822	15.08	0.874

CURVE 13
 $T = 293$.

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 13 (CONT.)		CURVE 14 (CONT.)		CURVE 15 (CONT.)		CURVE 16 (CONT.)	
15.36	0.889	3.39	0.563	6.21	0.861	10.72	0.834
15.50	0.920	3.41	0.589	6.30	0.876	10.85	0.846
15.95	0.952	3.44	0.546	6.54	0.883	11.10	0.842
16.72	0.914	3.45	0.601	6.59	0.859	11.45	0.861
17.39	0.958	3.47	0.725	6.65	0.869	11.76	0.845
18.69	0.958	3.50	0.747	6.71	0.834	12.14	0.842
19.76	0.913	3.52	0.664	6.78	0.703	12.25	0.825
20.53	0.929	3.54	0.801	6.81	0.625	12.39	0.868
21.26	0.922	3.57	0.839	6.89	0.598	12.82	0.897
22.12	0.877	3.63	0.851	6.96	0.558	13.00	0.870
22.57	0.831	3.72	0.860	7.00	0.762	13.39	0.828
23.29	0.810	3.98	0.865	7.07	0.799	13.53	0.871
23.56	0.727	4.01	0.890	7.15	0.776	13.55	0.913
25.00	0.694	4.04	0.861	7.18	0.725	13.93	0.905
4.12	0.875	4.12	0.875	7.26	0.714	14.01	0.933
4.26	0.875	4.36	0.861	7.32	0.749	14.45	0.927
4.55	0.886	4.55	0.886	7.39	0.768	14.81	0.939
4.78	0.881	4.78	0.881	7.43	0.750	15.22	0.921
2.50	0.837	2.58	0.840	7.58	0.702	15.48	0.935
2.67	0.848	2.76	0.848	7.68	0.643	16.29	0.930
2.61	0.839	2.83	0.826	7.84	0.572	19.27	0.930
2.83	0.839	2.88	0.839	8.05	0.512	19.61	0.923
2.91	0.823	2.94	0.837	8.07	0.595	21.05	0.923
2.96	0.837	3.04	0.826	8.27	0.527	21.51	0.914
2.80	0.837	2.83	0.839	8.33	0.502	22.27	0.933
2.91	0.823	2.94	0.837	8.37	0.394	24.10	0.871
2.96	0.837	3.04	0.826	8.43	0.448	24.63	0.826
2.80	0.837	2.83	0.839	8.67	0.377	25.00	0.808
2.91	0.823	2.94	0.837	8.81	0.547		
2.96	0.837	3.04	0.826	8.95	0.597		
2.80	0.839	2.83	0.837	9.05	0.661		
2.91	0.823	2.94	0.837	9.20	0.671	CURVE 15 T = 293.	
2.96	0.837	3.04	0.826	9.40	0.745		
2.80	0.839	2.83	0.837	9.58	0.774		
2.91	0.823	2.94	0.837	9.77	0.734		
2.96	0.837	3.04	0.826	9.82	0.773		
2.80	0.839	2.83	0.837	9.96	0.769		
2.91	0.823	2.94	0.837	10.11	0.753		
2.96	0.837	3.04	0.826	10.22	0.774		
2.80	0.839	2.83	0.837	10.32	0.798		
2.91	0.823	2.94	0.837	10.52	0.785		
2.96	0.837	3.04	0.826	10.64	0.815		

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELLENGTH DEPENDENCE) (CONTINUED)

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T, K; TRANSMITTANCE, τ)

λ	τ	CURVE 17 (CONT.)		CURVE 17 (CONT.)		CURVE 17 (CONT.)		CURVE 18 (CONT.)		λ		τ	CURVE 19 (CONT.)	
7.40	0.448	11.06	0.454	14.54	0.590	19.16	0.583	0.341	0.404	0.259	0.018			
7.43	0.444	11.12	0.450	14.64	0.581	19.28	0.600	0.350	0.432	0.261	0.041			
7.47	0.450	11.18	0.449	14.77	0.596	19.38	0.600	0.356	0.400	0.262	0.016			
7.49	0.445	11.25	0.457	14.83	0.581	19.42	0.585	0.365	0.461	0.261	0.018			
7.54	0.445	11.32	0.452	15.02	0.589	19.55	0.581	0.404	0.444	0.268	0.001			
7.56	0.438	11.39	0.461	15.16	0.581	19.76	0.594	0.452	0.901	0.357	0.000			
7.59	0.439	11.49	0.458	15.21	0.597	20.01	0.581	0.603	0.913	0.364	0.015			
7.62	0.428	11.62	0.465	15.28	0.598	20.08	0.592	0.751	0.931	0.369	0.030			
7.65	0.428	11.67	0.479	15.36	0.583	20.24	0.600	0.908	0.931	0.372	0.046			
7.69	0.417	11.75	0.468	15.46	0.589	20.39	0.588	1.064	0.936	0.374	0.069			
7.73	0.417	11.84	0.484	15.55	0.602	20.50	0.588	1.220	0.928	0.376	0.146			
7.76	0.401	11.91	0.475	15.67	0.586	20.65	0.597	1.249	0.930	0.389	0.775			
7.79	0.401	11.99	0.484	15.73	0.536	20.68	0.600	1.341	0.929	0.390	0.817			
7.82	0.384	12.07	0.478	15.80	0.603	20.88	0.593	1.405	0.893	0.393	0.842			
7.85	0.381	12.15	0.492	15.86	0.600	20.95	0.588	1.436	0.891	0.397	0.863			
7.93	0.356	12.27	0.478	15.95	0.573	21.15	0.596	1.460	0.895	0.403	0.895			
7.97	0.345	12.34	0.492	16.10	0.573	21.28	0.598	1.502	0.915	0.411	0.895			
8.02	0.358	12.42	0.481	16.16	0.558	21.57	0.591	1.554	0.922	0.422	0.904			
8.09	0.360	12.49	0.495	16.26	0.536	21.67	0.599	1.600	0.917	0.700	0.906			
8.12	0.357	12.60	0.468	16.43	0.536	21.77	0.599	1.631	0.891	0.700	0.912			
8.16	0.360	12.78	0.500	16.53	0.527	22.03	0.591	1.672	0.854	0.715	0.912			
8.20	0.353	12.84	0.516	16.66	0.535	22.21	0.598	1.702	0.854	0.741	0.920			
8.23	0.357	12.98	0.517	16.77	0.560	22.59	0.592	1.725	0.852	0.763	0.916			
8.26	0.344	13.05	0.526	17.04	0.584	22.78	0.599	1.758	0.656	0.788	0.918			
8.29	0.344	13.17	0.518	17.10	0.591	23.28	0.594	1.794	0.886	0.815	0.923			
8.38	0.372	13.25	0.536	17.16	0.579	23.49	0.599	1.828	0.878	0.890	0.874			
8.50	0.361	13.34	0.526	17.29	0.584	23.60	0.593	1.852	0.858	0.915	0.873			
8.70	0.361	13.43	0.554	17.34	0.598	23.05	0.594	1.872	0.834	0.941	0.889			
8.81	0.347	13.50	0.537	17.40	0.606	23.86	0.596	1.894	0.813	0.960	0.869			
9.05	0.335	13.57	0.537	17.46	0.598	1.913	0.813	1.003	0.876	1.130	0.835			
9.09	0.322	13.64	0.553	17.53	0.579	1.938	0.827	1.030	0.863	1.141	0.797			
9.26	0.322	13.75	0.537	18.11	0.600	1.970	0.850	1.060	0.896	1.161	0.726			
9.50	0.346	13.80	0.546	18.27	0.581	2.000	0.847	1.182	0.684	1.172	0.692			
9.64	0.373	13.95	0.569	18.37	0.588	2.01	0.440	1.190	0.440	1.190	0.440			
9.83	0.380	13.96	0.556	18.49	0.603	2.034	0.596	1.204	0.596	1.204	0.596			
9.95	0.400	14.07	0.564	18.65	0.589	2.038	0.662	1.218	0.662	1.218	0.662			
10.21	0.426	14.17	0.567	18.76	0.589	2.032	0.689	1.232	0.689	1.232	0.689			
10.56	0.463	14.27	0.591	18.89	0.599	2.039	0.726	1.250	0.726	1.250	0.726			
10.98	0.463	14.42	0.581	18.99	0.588	2.039	0.764	1.257	0.764	1.257	0.764			

CURVE 19
 $T = 293.$

TABLE 16-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF LUCITE (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T; K; TRANSMITTANCE, τ)

λ	T	λ	T	CURVE 19 (CONT.)	CURVE 19 (CONT.)	CURVE 20 (CONT.)	CURVE 20 (CONT.)	CURVE 21 (CONT.)	CURVE 21 (CONT.)
1.191	0.730	1.877	0.585	0.250	0.000	0.552	0.926	0.552	0.926
1.214	0.625	1.879	0.554	0.254	0.009	0.600	0.931	0.600	0.931
1.236	0.367	1.886	0.415	0.257	0.020	0.647	0.933	0.647	0.933
1.259	0.892	1.886	0.333	0.259	0.044	0.668	0.933	0.668	0.933
1.273	0.873	1.891	0.268	0.279	0.415	0.700	0.935	0.700	0.935
1.288	0.283	1.899	0.253	0.284	0.531				
1.318	0.866	1.909	0.271	0.290	0.612				
1.347	0.692	1.909	0.319	0.297	0.684				
1.367	0.629	1.914	0.339	0.302	0.714				
1.377	0.657	1.914	0.362	0.308	0.753				
1.383	0.646	1.916	0.417	0.316	0.789				
1.388	0.566	1.916	0.456	0.323	0.813				
1.401	0.679	1.924	0.470	0.333	0.840				
1.501	0.695	1.928	0.502	0.344	0.860				
1.421	0.695	1.946	0.444	0.353	0.873				
1.470	0.807	1.953	0.467	0.361	0.881				
1.500	0.849	1.963	0.483	0.369	0.889				
1.550	0.849	1.976	0.559	0.375	0.893				
1.584	0.818	1.991	0.591	0.389	0.900				
1.607	0.783	2.028	0.576	0.700	0.900				
1.608	0.763	2.051	0.504						
1.613	0.737	2.064	0.473						
1.643	0.645	2.079	0.353						
1.654	0.508	2.093	0.253						
1.662	0.355	2.108	0.262	0.250	0.006				
1.570	0.134	2.115	0.211	0.265	0.199				
1.677	0.104	2.120	0.147	0.277	0.400				
1.686	0.123	2.127	0.133	0.289	0.598				
1.685	0.151	2.139	0.153	0.294	0.655				
1.696	0.183	2.148	0.173	0.303	0.713				
1.709	0.170	2.148	0.203	0.310	0.757				
1.727	0.209	2.165	0.215	0.320	0.800				
1.741	0.300	2.181	0.031	0.327	0.830				
1.769	0.420	2.193	0.000	0.339	0.857				
1.769	0.447	2.226	0.000	0.351	0.883				
1.784	0.429			0.366	0.900				
1.509	0.558			0.378	0.909				
1.615	0.584			0.400	0.913				
1.526	0.600			0.450	0.913				
1.650	0.550			0.500	0.920				

CURVE 21
 $T = 293.$

CURVE 20
 $T = 293.$


0.200 0.000

4.17. Polycarbonate Plastics

Polycarbonates are transparent, faintly amber-colored, thermoplastic materials showing good dimensional stability, thermal resistance, and electrical properties, as well as good tensile and impact strength. Their unique hardness properties allow polycarbonates to substitute for metals in some applications, as in plastic rivets and bolts.

Trade names of polycarbonates are "Lexan" for General Electric, "Merlon" for Mobay, "Lexel" (fibre), "Makrolon", and "Panlite". The softening point of Lexan is 428 K and that of Merlon is 410 K. The heat distortion temperature and mold temperature is 406-411 K and 561-589 K, respectively.

Polycarbonates are formed by the condensation of polyphenols (usually Bis-phenol A) with phosgene. The resulting thermoplastic polymer can be considered an ester of carbonic acid and bisphenol A.



The molecular weight of commercial polycarbonate plastics is up to 30000 (degree of polymerization c. 120), beyond which increasing viscosity limits practical processing. The commonest polycarbonate unit cell contains 4 chains and 8 fundamental units; identity period 21.5 Å. It can be dissolved by certain chlorinated hydrocarbons (dichloroform, methylene chloride, di-, tri-, and tetrachloroethane, hot chlorobenzene), pyridine, dioxan, cyclohexanone, and hot phenols. It will be swollen by acetone, benzene, and carbon tetrachloride. It can be decomposed by hot alcoholic alkalis, amines, and other organic bases, and its surface attack by aq. alkalis.

Polycarbonate has density 1.20 g cm^{-3} , has the second order (glass) transition temperature at about 420 K, softens above 430 K, decomposes around 580 K, and is serviceable up to 410 K. Its tensile strength halves at 400 K. Its dielectric constants are 2.7-3.1 over the range $50-10^{10} \text{ Hz}$. Its resistivity is about $10^{16} \Omega \text{ cm}$ at room temperature and $10^{14} \Omega \text{ cm}$ at 400 K. Dielectric strength of very thin films is 120 KV/mm and 100 KV/mm for 0.05-0.125 mm films. Its electrical properties show little dependence

on frequency, and are not greatly changed by heating to 410 K or by long immersion in water.

Polycarbonate has specific heat 0.28-0.30, thermal conductivity 0.00192 W cm⁻¹ K⁻¹, and thermal expansion coefficient 0.6-0.7 x 10⁻⁴ K⁻¹ (0.76 x 10⁻⁸ K⁻¹ at 30-410 K). It shrinks 0.5~0.7% when molding and it is self-extinguishing by the ASTM D-635 test.

a. Normal Spectral Emittance (Wavelength Dependence)

There is no data on emittance of polycarbonate plastics available. However, Pregelhof, Franey, and Haas [T77125] used a one-dimensional model, assuming uniform properties, and gave the emittance $\epsilon(\lambda)$, the absorptance $\alpha(\lambda)$, the transmittance $\tau(\lambda)$, and the reflectance $\rho(\lambda)$ of a polymer sheet in the following expressions:

$$\epsilon(\lambda) = \alpha(\lambda) = \frac{(1-R) [(1+R) \sinh ad + (1-R) (\cosh ad - 1)]}{(1+R^2) \sinh ad + (1-R^2) \cosh ad} \quad (4.17-1)$$

$$\tau(\lambda) = \frac{(1-R)^2}{(1+R^2) \sinh ad + (1-R^2) \cosh ad} \quad (4.17-2)$$

$$\rho(\lambda) = \frac{2R [R \sinh ad + (1-R) \cosh ad]}{(1+R^2) \sinh ad + (1-R^2) \cosh ad} \quad (4.17-3)$$

where $R = (n - 1/n+1)^2$ and n is the refractive index, d is the thickness of the sample, and a is the absorption coefficient. Therefore, the absorptance can be calculated from the above equations.

For the polycarbonate plastic bulk materials, it can be assumed that

$$e^{ad} \gg Re^{-ad} \quad (4.17-4)$$

which enables Eqs. (4.17-1, 4.17-2, and 4.17-3) to become the following:

$$\epsilon(\lambda) = \alpha(\lambda) \cong (1-R) [1 - (1-R) e^{-ad} - Re^{-2ad}] \quad (4.17-5)$$

$$\tau(\lambda) \cong (1-R)^2 e^{-ad} \quad (4.17-6)$$

$$\rho(\lambda) \cong R [1 + (1-R) e^{-2ad}] \quad (4.17-7)$$

By using these equations together with the experimental data of transmittance and reflectance, the emittance can be calculated. Here we used $d = 4$ mm for the

calculation. The calculated results of emittance for bulk polycarbonate plastic samples with thickness 4 mm at 293K are shown in Table 17-1 and Figure 17-1 with an estimated uncertainty of about $\pm 20\%$.

TABLE 17-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ]

λ	ϵ	λ	ϵ	THICKNESS 4 MM $T = 293$	THICKNESS 4 MM $T = 293$ (CONT.)
6.6	0.12	12.5	0.940		
6.75	0.05	13.0	0.931		
6.92	0.05	13.5	0.926		
7.00	0.05	14.0	0.949		
7.19	0.05	14.5	0.969		
7.34	0.10	15.0	0.943		
7.75	0.16				
7.77	0.07				
7.83	0.09				
7.95	0.77				
8.69	0.72				
9.75	0.33				
10.75	0.37				
11.67	0.33				
11.95	0.46				
12.95	0.52				
13.00	0.41				
20.59	0.34				
20.69	0.35				
20.80	0.92				
20.85	0.953				
20.90	0.961				
20.95	0.960				
21.00	0.62				
21.21	0.355				
21.60	0.253				
21.65	0.967				
21.95	0.953				
22.05	0.972				
22.25	0.358				
22.56	0.914				
22.59	0.935				
22.50	0.944				
23.00	0.939				
23.60	0.945				
24.00	0.953				
24.50	0.947				
24.90	0.951				
24.56	0.951				




FIGURE 17-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).

b. Normal Spectral Reflectance (Wavelength Dependence)

Only Vinokanova, Cherkusov, and Kisilitsu [T71819] have measured the normal spectral reflectance in the 0.05-0.25 μm wavelength region. We can only roughly estimate the normal spectral reflectance by the results of angular reflectance. The provisional normal spectral reflectance values are slightly lower than that of the angular reflectance and are shown in Table 17-2 and Figure 17-2 with an uncertainty of about $\pm 30\%$.

TABLE 17-2. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T ; K; REFLECTANCE, ρ)

λ	ρ	λ	ρ		
LEXAN			LEXAN		
T = 293		T = 293 (CONT.)			
6.06	0.07	11.60	0.047		
6.18	0.11	11.50	0.053		
6.25	0.13	12.30	0.049		
6.50	0.11	12.50	0.057		
6.75	0.17	13.30	0.061		
6.92	0.146	13.50	0.060		
7.09	0.150	14.00	0.051		
7.19	0.190	14.50	0.051		
7.34	0.170	15.00	0.057		
7.39	0.165				
7.47	0.155				
7.53	0.128				
7.55	0.170				
7.75	0.200				
7.78	0.364				
7.83	0.655				
7.87	0.330				
7.98	0.030				
8.30	0.330				
8.30	0.958				
8.35	0.052				
8.39	0.347				
8.92	0.221				
8.92	0.034				
8.93	0.346				
9.00	0.039				
9.50	0.346				
9.95	0.033				
9.95	0.235				
9.95	0.641				
9.95	0.333				
7.82	0.237				
7.82	0.228				
8.20	0.262				
8.50	0.386				
9.00	0.064				
9.50	0.050				
10.00	0.061				
10.60	0.254				




FIGURE 17-2. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).




FIGURE 17-3. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).

TABLE 17-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 TT1613, TT2331	Vinokurova, L. N., Charkasov, Yu. A., and Kisilitsa, P. P.	1973	0.05-0.25	293	Polycarbonate	Polymer film with thickness about several μm was deposited from solution on a polished glass face plate; a VMR-2 vacuum monochromator at a resolution of 1.6 mm was used and a glow discharge in hydrogen and technical helium was used as radiation source; data were extracted from figure; $\theta \sim 0^\circ$.

TABLE 17-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE ϵ)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ
CURVE 1 $T = 293.$	
0.0554	0.071
0.0592	0.377
0.0833	0.112
0.0996	0.116
0.0977	0.111
0.1064	0.105
0.1254	0.102
0.1219	0.101
0.1296	0.093
0.1408	0.076
0.1485	0.057
0.1566	0.044
0.1605	0.037
0.1662	0.034
0.1730	0.034
0.1756	0.054
0.1797	0.382
0.1798	0.398
0.1879	0.145
0.1933	0.185
0.1985	0.189
0.2048	0.166
0.2119	0.169
0.2176	0.162
0.2242	0.158
0.2315	0.151
0.2356	0.139
0.2454	0.136
0.2511	0.129

c. Angular Spectral Reflectance (Wavelength Dependence)

Only Grimm, Linfored, Dillow, Spinak, and Mills [A00001] have measured the angular spectral reflectance for a 290 mm thick disk of Lexan in the 2-15 μm region with the incident angle of 15° and 45°, respectively for curves 1 and 2. The reflectance values increase slightly with the increasing of incident angle.

Pregelhof, Francy, and Haas [T77125] calculated the absorption coefficient $a = 50 \text{ cm}^{-1}$ or larger in the wavelength region $\lambda > 4 \mu\text{m}$. Therefore, Eq. (4.17-7) becomes

$$\rho(\lambda) \cong R = (n - 1/n + 1)^2 \quad (4.17-8)$$

which is independent of the thickness of the sample and depends only on index of refraction. However, the data of index of refraction are not available in the wavelength region above 1 μm . Thus, Eq. (4.17-8) is not applicable here.

For the wavelength region below 2 μm , with the aid of the transmittance data, the reflectance can be calculated. Together with the experimental data of Grimm, et al., which is shown in Table 17-3, the provisional values of angular reflectance are shown in Table 17-2 and Figure 17-4 with an estimated uncertainty of about $\pm 30\%$.

TABLE 17-5. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)

λ	ρ	λ	ρ
LEXAN $\theta=15^\circ$ $T = 293$		LEXAN $\theta=15^\circ$ $T = 293$ (CONT.)	
0.36	0.371	11.00	0.648
0.40	0.115	11.50	0.054
0.25	0.135	12.09	0.050
0.60	0.115	12.50	0.058
0.74	0.170	13.00	0.061
0.75	0.173	13.50	0.061
0.92	0.149	14.00	0.052
1.03	0.150	14.50	0.052
1.19	0.195	15.30	0.058
1.34	0.174		
1.39	0.163		
1.47	0.169		
1.53	0.130		
1.65	0.174		
1.75	0.208		
1.73	0.365		
1.83	0.397		
1.97	0.331		
1.93	0.332		
2.30	0.381		
2.39	0.351		
2.53	0.351		
2.92	0.332		
3.60	0.335		
3.32	0.341		
4.03	0.340		
4.50	0.341		
5.00	0.339		
5.50	0.336		
6.00	0.342		
6.50	0.334		
7.36	0.338		
7.53	0.229		
8.32	0.363		
8.50	0.387		
9.00	0.065		
9.30	0.357		
10.00	0.362		
10.50	0.355		




FIGURE 17-4. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).




FIGURE 17-5. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).

TABLE 17-6. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (Wavelength Dependent)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1	Grimm, T.C., Linsford, R.M.F., Dillow, C.F., Spink, S., and Mills, J.P.	1972	2-15	293	Lexan Sample N-1	One in. diameter disc sample with thickness 290 mil.; reflectance was measured by utilizing a Dune Associate ellipsoidal-mirror reflectometer; $\theta=15^\circ$.	
2	Grimm, T.C., et al.	1972	2-15	293	Lexan Sample N-1	The above specimen except $\theta=45^\circ$.	

TABLE 17-7. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

CURVE 1 $T = 293^\circ\text{K}$	λ	ρ	CURVE 1 (CONT.)		CURVE 1 (CONT.)		CURVE 2 (CONT.)	
			λ	ρ	λ	ρ	λ	ρ
2.06	0.913	3.38	0.041	7.98	0.040	10.6	0.07	
2.03	0.263	3.44	0.046	8.08	0.063			
2.07	0.013	3.46	0.044	8.15	0.083			
2.07	0.062	3.49	0.046	8.32	0.089			
2.10	0.051	3.55	0.043	8.52	0.087			
2.11	0.088	3.61	0.044	8.62	0.088			
2.13	0.059	3.69	0.043	8.72	0.085			
2.16	0.035	3.75	0.043	8.81	0.079			
2.19	0.019	3.83	0.040	8.99	0.065			
2.23	0.063	3.89	0.043	9.10	0.060			
2.29	0.935	4.00	0.040	9.22	0.058			
2.30	0.059	4.09	0.044	9.51	0.057			
2.35	0.024	4.21	0.041	9.69	0.056			
2.37	0.050	4.29	0.044	10.03	0.062			
2.39	0.064	4.40	0.041	10.22	0.058			
2.42	0.032	4.55	0.041	10.46	0.056			
2.46	0.162	4.72	0.039	10.75	0.054			
2.47	0.040	4.83	0.046	10.99	0.048			
2.50	0.051	4.95	0.039	11.19	0.055			
2.52	0.038	5.63	0.039	11.54	0.054			
2.55	0.051	5.11	0.042	11.68	0.050			
2.55	0.033	5.19	0.038	11.83	0.048			
2.59	0.051	5.28	0.037	12.03	0.050			
2.62	0.040	5.43	0.036	12.24	0.053			
2.67	0.055	5.51	0.036	12.42	0.057			
2.68	0.051	5.62	0.033	12.71	0.059			
2.71	0.035	5.70	0.045	12.99	0.062			
2.75	0.043	5.73	0.050	13.23	0.062			
2.81	0.046	5.81	0.050	13.47	0.061			
2.83	0.044	5.89	0.043	13.68	0.056			
2.90	0.041	6.08	0.042	13.88	0.052			
2.93	0.032	6.28	0.038	14.56	0.052			
2.97	0.047	6.42	0.036	14.68	0.054			
3.00	0.035	6.52	0.032					
3.06	0.051	6.67	0.043					
3.13	0.043	6.81	0.044					
3.17	0.048	7.02	0.038					
3.25	0.041	7.32	0.036	2.8	0.05			
3.34	0.048	7.75	0.021	3.6	0.05			
		7.91	0.024	5.0	0.05			
						CURVE 2 $T = 293^\circ\text{K}$		

d. Normal Spectral Absorptance (Wavelength Dependence)

There is no data of absorptance available for bulk polycarbonate plastics. Only Fujikura and Ishikawa [T77102] have measured the absorptive power of thin films with thickness of 18 μm and 118 μm at 300 K. The absorptance data was obtained by dividing the absorptive power with the black body radiation power. According to Eq. (4.17-5), the absorptance is strongly dependent on the thickness of the sample for thin films. However, for the bulk materials, in the wavelength region $\lambda > 4 \mu\text{m}$,

$$\alpha(\lambda) \cong (1-R) \quad (4.17-9)$$

which is independent of the thickness, and the material becomes opaque. By using Eqs. (4.17-5, 4.17-6, and 4.17-7), the absorptance can be calculated as equal to the emittance. The calculated results are for a sample with thickness 4 mm at 293 K which are shown in Table 17-8 and Figure 17-6 together with the experimental data of thin films. The estimated uncertainty is about $\pm 20\%$.

TABLE 17-3. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

λ	α	λ	α		
THICKNESS 4MM			THICKNESS 4MM		
$T = 293$			$T = 293$ (CONT.)		
6.60	0.42		12.50	0.940	
6.75	0.55		12.00	0.931	
6.92	0.65		13.50	0.940	
7.10	0.65		14.00	0.949	
7.19	0.55		14.50	0.969	
7.34	0.10		15.00	0.943	
7.39	0.16				
7.47	0.37				
7.63	0.60				
7.65	0.77				
7.69	0.72				
7.75	0.33				
7.78	0.37				
7.83	0.43				
7.87	0.46				
7.98	0.32				
8.03	0.41				
8.53	0.94				
8.60	0.95				
8.90	0.95				
9.00	0.92				
9.65	0.953				
9.72	0.962				
9.95	0.965				
10.00	0.959				
10.50	0.957				
10.60	0.933				
11.00	0.914				
11.50	0.936				
11.50	0.944				
12.00	0.951				
12.50	0.951				




FIGURE 17-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).




FIGURE 17-7. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).

TABLE 17-9. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	T77102	Fujikura, Y. and Ishikawa, K.	1968	2.5-50	300		Polycarbonate film; thickness 18 μm; absorptive power data were extracted from the figure; 0-0°.
2	T77102	Fujikura, Y. and Ishikawa, K.	1968	2.5-50	300		Polycarbonate film; thickness 118 μm; absorptive power data were extracted from the figure; 0-0°.

TABLE 17-10. EXPERIMENTAL SPECTRAL ABSORPTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

λ	α	CURVE 1 $T = 300^\circ$		CURVE 1 (CONT.) $T = 300^\circ$		CURVE 2 $T = 300^\circ$		CURVE 2 (CONT.)	
		λ	α	λ	α	λ	α	λ	α
3.09	0.00	10.50	0.16	11.00	0.15	3.00	0.000	11.40	0.91
3.50	0.00	11.00	0.51	11.50	0.25	3.50	0.00	11.60	0.72
3.90	0.03	11.50	0.67	11.90	0.72	3.90	0.00	11.80	0.89
4.40	0.19	11.90	12.10	12.40	4.39	0.19	12.10	0.65	
4.69	0.08	12.10	0.72	12.40	4.40	0.37	12.40	0.90	
4.70	0.16	12.40	0.69	12.50	4.50	0.09	12.60	0.71	
4.90	0.10	12.50	0.29	12.50	5.00	0.38	12.00	0.91	
5.10	0.16	12.50	0.12	12.50	5.20	0.69	13.40	0.79	
5.20	0.26	13.00	0.52	13.20	5.40	0.70	13.70	0.67	
5.30	0.19	13.20	0.32	13.50	5.50	1.00	14.00	0.76	
5.60	0.59	13.50	0.22	13.50	5.70	1.00	14.70	0.31	
5.76	3.27	13.60	0.25	14.00	5.70	0.91	15.30	0.20	
6.10	0.18	14.00	0.27	14.40	5.90	0.80	15.70	0.37	
6.10	0.32	14.40	0.69	14.90	6.00	0.57	16.00	0.25	
6.49	0.23	14.90	0.67	15.20	6.30	0.90	16.50	0.44	
6.70	0.52	15.20	0.07	15.40	6.40	0.66	16.90	0.67	
6.90	0.27	15.40	0.05	15.60	6.60	0.85	17.50	0.91	
7.10	0.46	15.60	0.05	16.00	6.90	0.95	18.20	0.94	
7.20	0.40	16.00	0.00	16.40	7.00	0.82	18.60	0.81	
7.30	0.49	16.40	0.00	16.80	7.20	0.93	18.90	0.55	
7.45	0.26	16.80	0.10	17.10	7.40	0.90	19.40	0.52	
7.60	0.45	17.10	0.24	17.50	7.60	0.82	20.50	0.51	
7.70	0.67	17.50	0.36	17.80	7.80	0.98	21.10	0.37	
7.90	0.74	17.80	0.60	18.10	8.30	0.96	21.90	0.24	
8.10	0.77	18.10	0.65	18.50	8.60	0.93	22.40	0.25	
8.50	0.78	18.50	0.35	19.30	9.10	0.95	23.00	0.40	
8.50	0.80	19.30	0.15	19.80	9.40	0.96	23.40	0.49	
8.80	0.75	19.80	0.12	20.00	9.50	0.94	24.00	0.55	
8.90	0.41	20.00	0.04	21.00	9.60	0.68	24.50	0.70	
9.10	0.52	21.00	0.05	22.40	10.40	0.50	25.00	0.74	
9.30	0.14	22.40	0.10	23.40	9.90	0.84	26.70	0.65	
9.50	0.23	23.40	0.11	24.30	10.30	0.90	28.30	0.56	
9.70	0.24	24.30	0.16	24.90	10.20	0.54	29.50	0.48	
9.80	0.46	24.90	0.24	25.00	10.40	0.50	31.00	0.41	
10.00	0.56	25.00	0.33	26.00	10.40	0.55	32.00	0.45	
10.10	0.08	26.00	0.33	29.10	10.60	0.59	32.80	0.34	
10.20	0.05	29.10	0.33		10.70	0.56	35.00	0.39	
10.30	0.09				10.60	0.55	36.60	0.25	
10.50	0.12				11.00	0.59	37.40	0.27	
							39.30	0.38	

e. Normal Spectral Transmittance (Wavelength Dependence)

There are 16 sets of experimental data available for the transmittance of polycarbonate plastics as listed in Table 17-13. Of these, 5 sets were measured on thin film samples which are shown in Figure 17-5. They represent reasonably consistent results with each other. The major absorption peaks near $\lambda = 3.4, 5.6, 6.6, 8.1, 8.2, 8.6, 9.8$, and $12 \mu\text{m}$ are observed.

As we have mentioned in d., the bulk polycarbonate materials become opaque above $\lambda = 4 \mu\text{m}$. At the visible and near infrared region it transmits about 80-90%. Above $1.7 \mu\text{m}$ the transmittance becomes very strongly dependent on the thickness of the sample. Therefore, the recommended values of transmittance for a sample with thickness of 4 mm at 293 K were derived based on the works of Cloud [T54891, curve 4], Acitelli [T40338, curve 7], and Progelhof, et al. [T77125, curve 16]. The values are shown in Table 17-11 and in Figure 17-8 with the experimental data.

The recommended values which are for polished samples are estimated with an uncertainty of about $\pm 20\%$.

TABLE 17-11. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ		
THICKNESS 4 MM			THICKNESS 4 MM $T = 293$ (CONT.)		
0.35	0.35	0.35	2.60	0.07	
0.37	0.57	0.57	2.62	0.08	
0.36	0.57	0.57	2.65	0.06	
0.49	0.66	0.66	2.70	0.00	
0.50	0.73	0.73	2.80	0.00	
0.60	0.77	0.77	2.84	0.00	
0.70	0.84	0.84	2.96	0.05	
0.75	0.78	0.78	2.92	0.06	
0.80	0.89	0.89	3.03	0.04	
0.90	0.37	0.37	3.22	0.00	
0.92	0.90	0.90	3.50	0.007	
1.36	0.84	0.84	3.63	0.030	
1.49	0.76	0.76	3.92	0.002	
1.20	0.81	0.81	3.93	0.013	
1.34	0.73	0.73	4.03	0.015	
1.37	0.66	0.66	4.12	0.013	
1.39	0.57	0.57	4.10	0.0	
1.46	0.72	0.72	5.0	0.0	
1.47	0.76	0.76	6.0	0.0	
1.50	0.80	0.80	7.0	0.0	
1.53	0.80	0.80	8.0	0.0	
1.55	0.79	0.79	9.0	0.0	
1.59	0.73	0.73	10.0	0.0	
1.62	0.55	0.55	10.6	0.0	
1.65	0.06	0.06	11.0	0.0	
1.69	0.21	0.21	12.0	0.0	
1.74	0.36	0.36	13.0	0.0	
1.75	0.43	0.43	14.0	0.0	
1.78	0.57	0.57	15.0	0.0	
1.83	0.56	0.56			
1.87	0.54	0.54			
1.90	0.48	0.48			
1.95	0.50	0.50			
1.98	0.63	0.63			
2.00	0.56	0.56			
2.13	0.37	0.37			
2.21	0.17	0.17			
2.39	0.21	0.21			
2.50	0.01	0.01			




FIGURE 17-8. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).




FIGURE 17-9. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE).




FIGURE 17-10. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS THIN FILMS (WAVELENGTH DEPENDENCE).

TABLE 17-12. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T29424	Mobay Chemical Co.	1962	0.2-2.5	293	"Merlon" 100 ASTM D1003-55T	5 mil. thickness film; refractive index 1.587; it absorbs essentially all light in the ultraviolet region (up to 2750 Å), it transmits between 80-90% in the visible region (4000 to 7500 Å) and 90% in the infrared wavelength range (5500-1100 Å); the slight absorption of light in 3600 to 5000 Å range gives natural Merlon the light straw-colored hue.
2 T57541	Cloud, G.	1970	0.3-2.3	293	Merlon	9.5 mm thickness unannealed sample; Perkin-Elmer model 137-BT spectrometer and Bausch and Lomb Petronic is colorimeter was utilized to measure the transmission spectra; reported error 5%.
3 T57541	Cloud, G.	1970	0.3-0.9	293	Merlon	9.4 mm thickness annealed sample (at 154°C for 100 hr); Perkin-Elmer model 137-BT spectrometer and Bausch and Lomb Petronic is colorimeter was utilized to measure the transmission spectra; reported error 5%.
4 T57541	Cloud, G.	1970	0.8-2.3	293	Lexan	4.27 mm thickness sample; Perkin-Elmer model 137-BT spectrometer and Bausch and Lomb Petronic is colorimeter was utilized to measure the transmission spectra; reported error 5%.
5 T40338	Acitelli, M.A., and Cumby, W.L., and Nijckas, A.A.	1966	0.2-2.2	296	Poly(allyl diglycol carbonate)	7.2 mm thickness disc, approx. 50 mm in diameter; Cary Spectrophoton model 14 was used in measurements.
6 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	296	Poly(allyl diglycol carbonate)	The above specimen after 100 standard fade hr in solarization.
7 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	296	Polycarbonate "Lexan"	6.15 mm thickness disc approximately 50 mm in diameter; Cary Spectrophotometer was used in measurements.
8 T40338	Acitelli, M.A., et al.	1966	0.2-2.2	296	Polycarbonate "Lexan"	The above specimen after 100 standard fade hr in solarization.
9 T76795	Stimler, S.S., and Kagrisse, R.E.	1966	2.5-25	~293	K-1 Resin	Film specimen was obtained from Eastman Chemical Products; a Beckman IR-12 model spectrophotometer was used to obtain the spectra; data were extracted from the figure; $\theta \sim 0^\circ$.
10 T76795	Stimler, S.S., and Kagrisse, R.E.	1966	2.5-25	~293	Merlon M-50	Film specimen was obtained from Mobay Chemical Co.; other specifications similar to the above specimen.
11 T76795	Lara, M.O.	1967	2.5-25	~293	Lexan	The specimen was condensed pyrolyzate on potassium bromide or sodium chloride; a Beckman IR-9 double beam infrared spectrophotometer was used to obtain the spectra; data were extracted from the figure; $\theta \sim 0^\circ$.
12 T77102	Fujikura, Y., and Ishikawa, K.	1968	3-35	300	Polycarbonate film; thickness 1.6 μm ; penetrating power data were extracted from the figure.	
13 T77102	Fujikura, Y., and Ishikawa, K.	1968	3-35	300	Polycarbonate film; thickness 1.6 μm ; penetrating power data were extracted from the figure.	
14 T77125	Progelhof, R.C., and Franey, J., and Haas, T.W.	1971	2-15	~293	Polycarbonate film was obtained from General Electrical Co.; thickness, 40 μm ; data were extracted from the figure.	
15 T77125	Progelhof, R.C., et al.	1971	2.5-4.19	~293	Cast sheet, thickness 0.0825 in.; data were extracted from the figure; $\theta \sim 0^\circ$.	
16 T77125	Progelhof, R.C., et al.	1971	2.48-4.09	~293	Cast sheet, thickness 0.1258 in.; data were extracted from the figure; $\theta \sim 0^\circ$.	

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ_1)

λ	τ	CURVE 1 $T = 293^\circ\text{K}$	λ	τ	CURVE 1 (CONT.)	λ	τ	CURVE 2 (CONT.)	λ	τ	CURVE 3 (CONT.)	λ	τ	CURVE 3 (CONT.)
0.286	0.000	1.662	0.819	2.078	0.754	0.842	0.874	0.651	0.804	1.346	0.631	1.358	0.566	1.358
0.286	0.695	1.673	0.014	2.500	0.751	0.855	0.857	0.662	0.814	1.358	0.566	1.369	0.506	1.369
0.292	0.739	1.686	0.828	0.844	0.864	0.864	0.857	0.683	0.846	1.398	0.513	1.398	0.513	1.398
0.302	0.771	1.710	0.846	0.872	0.866	0.884	0.874	0.708	0.868	1.408	0.602	1.408	0.602	1.408
0.314	0.799	1.719	0.841	0.873	0.857	0.891	0.868	0.719	0.872	1.413	0.628	1.413	0.628	1.413
0.335	0.816	1.737	0.657	0.353	0.496	0.898	0.873	0.747	0.873	1.421	0.628	1.421	0.628	1.421
0.348	0.826	1.751	0.651	0.356	0.440	0.904	0.868	0.756	0.883	1.441	0.672	1.441	0.672	1.441
0.375	0.843	1.768	0.862	0.363	0.495	0.914	0.868	0.784	0.884	1.464	0.683	1.464	0.683	1.464
0.490	0.852	1.871	0.862	0.373	0.559	0.925	0.869	0.796	0.872	1.474	0.716	1.474	0.716	1.474
0.444	0.864	1.888	0.856	0.390	0.626	0.949	0.901	0.802	0.802	1.492	0.765	1.492	0.765	1.492
0.455	0.876	1.902	0.666	0.402	0.673	0.957	0.893	0.812	0.882	1.517	0.797	1.517	0.797	1.517
0.535	0.884	1.913	0.656	0.422	0.728	0.830	0.849	0.830	0.849	1.535	0.797	1.535	0.797	1.535
0.583	0.892	1.926	0.863	0.436	0.750	0.843	0.849	0.843	0.849	1.554	0.797	1.554	0.797	1.554
0.636	0.892	2.000	0.663	0.458	0.759	0.363	0.810	0.810	0.810	1.572	0.749	1.572	0.749	1.572
0.665	0.890	2.052	0.654	0.480	0.737	0.377	0.850	0.850	0.850	1.591	0.656	1.591	0.656	1.591
0.743	0.892	2.075	0.854	0.493	0.725	0.349	0.302	0.886	0.850	1.605	0.446	1.605	0.446	1.605
0.759	0.887	2.092	0.849	0.497	0.721	0.351	0.317	0.902	0.831	1.615	0.271	1.615	0.271	1.615
0.844	0.877	2.104	0.821	0.518	0.709	0.354	0.326	0.927	0.866	1.628	0.114	1.628	0.114	1.628
0.883	0.882	2.119	0.735	0.536	0.709	0.377	0.520	0.988	0.866	1.633	0.042	1.633	0.042	1.633
0.944	0.884	2.132	0.775	0.548	0.720	0.382	0.568	1.005	0.856	1.654	0.000	1.654	0.000	1.654
0.964	0.872	2.146	0.744	0.562	0.715	0.395	0.601	1.010	0.856	1.694	0.000	1.694	0.000	1.694
1.338	0.872	2.125	0.821	0.577	0.715	0.402	0.618	1.029	0.868	1.702	0.075	1.702	0.075	1.702
1.097	0.868	2.169	0.809	0.584	0.721	0.406	0.634	1.073	0.868	1.715	0.092	1.715	0.092	1.715
1.125	0.861	2.185	0.832	0.593	0.721	0.412	0.657	1.094	0.850	1.726	0.049	1.726	0.049	1.726
1.141	0.866	2.196	0.814	0.614	0.741	0.412	0.697	1.104	0.783	1.735	0.212	1.735	0.212	1.735
1.173	0.862	2.226	0.800	0.640	0.766	0.422	0.725	1.130	0.412	1.743	0.253	1.743	0.253	1.743
1.198	0.865	2.249	0.708	0.664	0.807	0.430	0.725	1.142	0.655	1.754	0.177	1.754	0.177	1.754
1.237	0.866	2.265	0.728	0.678	0.818	0.441	0.751	1.152	0.694	1.771	0.351	1.771	0.351	1.771
1.251	0.861	2.274	0.691	0.662	0.834	0.460	0.761	1.162	0.672	1.792	0.324	1.792	0.324	1.792
1.286	0.863	2.300	0.691	0.697	0.847	0.469	0.761	1.182	0.510	1.802	0.325	1.802	0.325	1.802
1.452	0.864	2.306	0.691	0.706	0.848	0.502	0.719	1.191	0.736	1.816	0.296	1.816	0.296	1.816
1.517	0.863	2.318	0.716	0.722	0.868	0.523	0.719	1.197	0.790	1.830	0.331	1.830	0.331	1.830
1.586	0.868	2.330	0.726	0.730	0.866	0.537	0.730	1.204	0.624	1.847	0.340	1.847	0.340	1.847
1.610	0.861	2.335	0.739	0.741	0.866	0.560	0.730	1.241	0.669	1.868	0.314	1.868	0.314	1.868
1.624	0.849	2.382	0.710	0.756	0.875	0.566	0.724	1.260	0.869	1.887	0.131	1.887	0.131	1.887
1.639	0.823	2.403	0.755	0.765	0.873	0.578	0.737	1.293	0.847	1.896	0.340	1.896	0.340	1.896
1.650	0.758	2.424	0.791	0.776	0.872	0.583	0.733	1.308	0.812	1.903	0.369	1.903	0.369	1.903
1.656	0.769	2.442	0.526	0.803	0.893	0.660	0.736	1.322	0.796	1.919	0.366	1.919	0.366	1.919
1.662	0.794	2.463	0.753	0.328	0.882	0.622	0.764	1.335	0.765	1.928	0.393	1.928	0.393	1.928

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 8 (CONT.)	λ	τ	CURVE 8 (CONT.)	λ	τ	CURVE 9 (CONT.)	λ	τ	CURVE 9 (CONT.)	λ	τ	CURVE 9 (CONT.)
1.192	0.823	1.771	0.423	1.774	0.479	2.50	0.971	5.62	0.193	7.67	0.827	10.83	0.933	
1.207	0.865	1.774	0.479	1.781	0.497	2.80	0.969	5.64	0.293	7.69	0.724	10.99	0.942	
1.238	0.889	1.794	0.478	1.794	0.478	2.82	0.958	5.68	0.694	7.72	0.692	11.09	0.860	
1.261	0.889	1.812	0.478	1.823	0.449	2.93	0.966	5.71	0.859	7.78	0.732	11.19	0.806	
1.268	0.939	1.830	0.471	1.830	0.471	3.18	0.964	5.78	0.908	7.91	0.225	11.25	0.873	
1.274	0.893	1.837	0.501	1.843	0.487	3.21	0.951	5.92	0.951	7.94	0.125	11.35	0.866	
1.285	0.871	1.847	0.501	1.856	0.489	3.26	0.951	6.05	0.944	7.97	0.079	11.38	0.920	
1.295	0.871	1.865	0.505	1.875	0.494	3.29	0.925	6.12	0.952	8.05	0.057	11.47	0.929	
1.313	0.843	1.881	0.505	1.881	0.490	3.31	0.954	6.17	0.946	8.14	0.102	11.93	0.620	
1.333	0.831	1.887	0.505	1.893	0.494	3.33	0.929	6.20	0.932	8.23	0.320	12.05	0.740	
1.349	0.723	1.893	0.494	1.893	0.489	3.35	0.929	6.22	0.902	8.31	1.054	12.24	0.756	
1.367	0.656	1.893	0.494	1.893	0.489	3.37	0.770	6.27	0.892	8.37	0.103	12.41	0.915	
1.375	0.579	1.893	0.494	1.893	0.489	3.37	0.680	6.30	0.922	8.45	0.497	12.63	0.906	
1.385	0.057	1.902	0.458	1.902	0.527	3.39	0.856	6.30	0.945	8.54	0.114	12.90	0.806	
1.390	0.680	1.913	0.527	1.913	0.542	3.41	0.861	6.35	0.953	8.64	0.592	13.11	0.847	
1.402	0.691	1.913	0.532	1.922	0.532	3.42	0.898	6.41	0.953	8.68	0.750	13.30	0.896	
1.411	0.731	1.913	0.544	1.932	0.544	3.45	0.915	6.51	0.926	8.77	0.836	13.55	0.890	
1.424	0.720	1.942	0.567	1.942	0.567	3.48	0.895	6.55	0.884	8.85	0.859	13.76	0.907	
1.438	0.745	1.952	0.567	1.952	0.567	3.50	0.965	6.60	0.529	8.94	0.431	14.12	0.885	
1.465	0.751	1.967	0.567	1.967	0.567	3.66	0.971	6.62	0.291	8.94	0.791	14.27	0.915	
1.477	0.774	1.960	0.553	1.960	0.553	3.99	0.971	6.65	0.349	9.02	0.776	14.47	0.927	
1.513	0.811	1.961	0.553	1.961	0.545	4.19	0.964	6.69	0.763	9.04	0.849	15.38	0.932	
1.540	0.811	1.961	0.545	1.961	0.545	4.23	0.956	6.73	0.864	9.12	0.871	15.58	0.923	
1.561	0.799	2.026	0.473	2.026	0.473	4.25	0.964	6.81	0.835	9.22	0.535	16.05	0.931	
1.576	0.774	2.037	0.355	2.037	0.355	4.25	0.964	6.84	0.890	9.26	0.442	16.72	0.919	
1.590	0.716	2.048	0.340	2.048	0.340	4.36	0.968	6.91	0.892	9.30	0.909	17.27	0.885	
1.620	0.432	2.058	0.274	2.058	0.274	4.48	0.952	6.91	0.924	9.38	0.921	17.54	0.763	
1.641	0.811	2.061	0.201	2.061	0.201	4.56	0.970	6.96	0.937	9.45	0.890	18.83	0.732	
1.654	0.028	2.062	0.110	2.062	0.110	4.83	0.961	7.03	0.920	9.57	0.929	18.21	0.837	
1.665	0.300	2.118	0.031	2.118	0.031	5.00	0.962	7.08	0.302	9.65	0.922	18.48	0.870	
1.674	0.041	2.131	0.000	2.131	0.000	5.06	0.967	7.11	0.892	9.72	0.849	19.01	0.890	
1.686	0.933	2.162	0.000	2.162	0.000	5.20	0.963	7.14	0.907	9.78	0.334	19.33	0.929	
1.698	0.070	2.172	0.042	2.172	0.042	5.26	0.941	7.16	0.890	9.95	0.660	20.04	0.869	
1.704	0.204	2.185	0.025	2.185	0.025	5.29	0.952	7.20	0.841	10.05	0.877	20.37	0.886	
1.714	0.206	2.190	0.037	2.190	0.037	5.36	0.956	7.24	0.915	10.10	0.923	21.83	0.866	
1.720	0.221	2.192	0.077	2.192	0.077	5.42	0.952	7.30	0.789	10.20	0.933	22.57	0.861	
1.730	0.161	2.200	0.080	2.200	0.080	5.48	0.928	7.35	0.930	10.33	0.929	23.58	0.805	
1.744	0.353	2.261	0.698	2.261	0.698	5.54	0.851	7.46	0.930	10.44	0.936	25.00	0.749	
1.749	0.401					5.58	0.397	7.56	0.917	10.60	0.930			
1.762	0.323					5.59	0.253	7.60	0.832	10.72	0.942			

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ ; μm ; TEMPERATURE, T ; K; TRANSMITTANCE, τ)

λ	T	CURVE 10 $T = 293^\circ\text{K}$		CURVE 10 (CONT.)		CURVE 10 (CONT.)		CURVE 10 (CONT.)		CURVE 11 (CONT.)	
		λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
2.50	0.934	5.49	0.900	7.06	0.998	10.00	0.766	17.57	0.603	3.31	0.624
2.65	0.932	5.52	0.843	7.08	0.652	10.02	0.820	17.89	0.617	3.33	0.728
2.66	0.923	5.56	0.502	7.15	0.923	10.12	0.802	18.28	0.668	3.37	0.454
2.68	0.930	5.59	0.353	7.23	0.913	10.18	0.896	18.59	0.782	3.40	0.652
2.68	0.930	5.61	0.262	7.29	0.930	10.28	0.919	19.12	0.815	3.41	0.626
2.82	0.931	5.65	0.344	7.46	0.923	10.35	0.897	19.69	0.893	3.43	0.657
2.87	0.937	5.69	0.714	7.52	0.699	10.44	0.888	20.24	0.911	3.44	0.715
3.06	0.941	5.71	0.835	7.57	0.808	10.56	0.855	20.79	0.902	3.46	0.740
3.18	0.941	5.74	0.865	7.62	0.803	10.59	0.904	21.32	0.910	3.49	0.713
3.20	0.924	5.77	0.879	7.66	0.773	10.61	0.916	22.68	0.694	3.51	0.822
3.24	0.919	5.81	0.918	7.72	0.740	10.95	0.939	23.53	0.864	3.53	0.857
3.25	0.891	5.94	0.933	7.75	0.668	11.04	0.939	25.00	0.772	3.59	0.866
3.28	0.878	6.00	0.940	7.83	0.668	11.14	0.930	3.62	0.876	3.75	0.870
3.30	0.903	6.12	0.940	7.89	0.597	11.29	0.800	3.81	0.895	3.95	0.870
3.33	0.877	6.19	0.932	7.94	0.274	11.47	0.893	4.07	0.870	4.16	0.907
3.37	0.463	6.21	0.917	7.99	0.194	11.56	0.980	4.22	0.920	4.39	0.943
3.40	0.704	6.22	0.669	8.10	0.128	11.70	0.690	2.50	0.939	3.93	0.890
3.44	0.857	6.25	0.863	8.19	0.184	11.69	0.852	2.52	0.929	3.96	0.900
3.47	0.682	6.25	0.886	8.24	0.264	11.89	0.720	2.54	0.940	4.07	0.877
3.49	0.901	6.31	0.901	8.34	0.105	12.09	0.637	2.62	0.940	4.16	0.907
3.51	0.933	6.32	0.928	8.39	0.132	12.32	0.659	2.64	0.947	4.22	0.920
3.56	0.944	6.39	0.939	8.48	0.428	12.53	0.872	2.70	0.947	4.39	0.920
3.58	0.939	6.49	0.926	4.56	0.192	12.69	0.887	2.72	0.923	4.47	0.934
3.61	0.938	6.55	0.899	8.69	0.598	12.84	0.861	2.73	0.945	4.56	0.950
3.66	0.949	6.57	0.631	8.73	0.692	12.92	0.802	2.76	0.931	4.72	0.943
4.07	0.949	6.59	0.813	8.80	0.669	13.07	0.765	2.78	0.694	4.81	0.920
4.13	0.944	6.61	0.503	8.83	0.759	13.26	0.841	2.80	0.771	5.00	0.921
4.26	0.952	6.62	0.303	8.90	0.793	13.50	0.886	2.82	0.595	5.06	0.941
4.38	0.952	6.67	0.408	8.94	0.793	13.72	0.874	2.85	0.488	5.14	0.941
4.47	0.933	6.69	0.752	9.00	0.772	13.83	0.890	2.88	0.399	5.17	0.928
4.60	0.954	6.71	0.797	9.12	0.886	14.04	0.897	2.92	0.326	5.21	0.935
4.84	0.945	6.75	0.780	9.30	0.899	14.35	0.889	2.95	0.287	5.27	0.875
5.03	0.946	6.78	0.854	9.38	0.892	14.56	0.916	3.03	0.370	5.29	0.857
5.10	0.952	6.81	0.876	9.45	0.813	15.06	0.927	3.08	0.434	5.32	0.874
5.20	0.952	6.84	0.835	9.51	0.901	15.58	0.927	3.13	0.528	5.34	0.901
5.29	0.933	6.86	0.771	9.62	0.921	15.87	0.916	3.18	0.665	5.40	0.922
5.34	0.939	6.88	0.876	9.73	0.897	16.18	0.931	3.20	0.690	5.47	0.899
5.38	0.933	6.93	0.914	9.79	0.674	16.86	0.908	3.23	0.718	5.49	0.915
5.40	0.938	6.98	0.928	9.85	0.393	17.09	0.923	3.26	0.664	5.56	0.811
5.46	0.931	7.03	0.931	9.89	0.689	17.30	0.913	3.28	0.653	5.60	0.600

CURVE 11
 $T = 293^\circ\text{K}$

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE) (CONTINUED)

WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ						CURVE 11 (CONT.)						CURVE 12 (CONT.)						CURVE 13 (CONT.)					
CURVE 11 (CONT.)			CURVE 11 (CONT.)			CURVE 11 (CONT.)			CURVE 12 (CONT.)			CURVE 12 (CONT.)			CURVE 12 (CONT.)			CURVE 13					
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ		
5.63	0.469	7.79	0.240	12.66	0.759	5.00	0.80	12.40	0.39	3.93	0.90	5.63	0.440	4.40	0.40	12.70	0.90	4.40	0.69	4.60	0.45		
5.66	0.492	7.85	0.146	12.85	0.702	5.20	0.91	12.70	0.90	5.01	0.51	5.66	0.440	4.60	0.40	13.20	0.72	4.70	0.82	4.70	0.46		
5.68	0.459	7.91	0.117	13.09	0.663	5.40	0.76	13.40	0.80	5.10	0.51	5.68	0.440	4.60	0.40	13.60	0.76	5.10	0.46	5.20	0.45		
5.69	0.360	7.99	0.130	13.26	0.605	5.50	0.81	13.40	0.72	5.20	0.51	5.69	0.440	4.60	0.40	14.20	0.76	5.20	0.64	5.30	0.35		
5.72	0.324	8.11	0.102	13.46	0.694	5.80	0.46	13.60	0.80	5.30	0.51	5.72	0.440	4.60	0.40	14.70	0.76	5.30	0.35	5.40	0.43		
5.74	0.373	8.20	0.155	13.79	0.717	6.10	0.72	14.20	0.76	5.40	0.51	5.74	0.440	4.60	0.40	15.40	0.94	5.40	0.35	5.50	0.35		
5.79	0.698	8.34	0.203	14.10	0.744	6.30	0.73	14.70	0.94	5.50	0.51	5.79	0.440	4.60	0.40	15.40	0.96	5.50	0.35	5.60	0.35		
5.84	0.795	8.42	0.148	14.25	0.692	6.40	0.78	15.40	0.96	5.60	0.51	5.84	0.440	4.60	0.40	15.70	0.99	5.60	0.36	5.70	0.36		
5.94	0.823	8.58	0.236	14.43	0.698	6.50	0.62	15.90	0.99	5.70	0.51	5.94	0.440	4.60	0.40	16.20	1.00	5.80	0.36	5.90	0.36		
6.05	0.800	8.64	0.209	14.62	0.674	6.60	0.75	16.20	1.00	5.80	0.51	6.05	0.440	4.60	0.40	16.70	1.00	6.10	0.46	6.20	0.36		
6.10	0.780	8.75	0.602	14.84	0.733	6.80	0.56	16.80	0.68	6.00	0.51	6.10	0.440	4.60	0.40	17.70	1.00	6.30	0.12	6.40	0.36		
6.14	0.726	8.83	0.689	15.08	0.747	7.00	0.50	17.70	1.00	6.30	0.51	6.14	0.440	4.60	0.40	18.60	0.68	6.40	0.12	6.50	0.36		
6.19	0.432	8.90	0.711	15.87	0.703	7.20	0.72	17.60	0.65	6.40	0.51	6.19	0.440	4.60	0.40	18.60	0.65	6.50	0.12	6.60	0.36		
6.21	0.296	8.96	0.679	16.13	0.730	7.30	0.55	17.80	0.43	6.60	0.51	6.21	0.440	4.60	0.40	18.10	0.38	6.80	0.19	6.90	0.36		
6.27	0.397	9.06	0.606	16.39	0.699	7.40	0.62	18.40	0.50	6.90	0.51	6.27	0.440	4.60	0.40	18.40	0.50	6.90	0.06	7.00	0.19		
6.33	0.688	9.12	0.638	16.75	0.709	7.50	0.52	18.60	0.68	7.00	0.51	6.33	0.440	4.60	0.40	19.50	0.88	7.00	0.19	7.10	0.36		
6.36	0.764	9.17	0.749	17.27	0.669	7.70	0.72	19.50	0.88	7.10	0.51	6.36	0.440	4.60	0.40	20.10	0.99	7.20	0.17	7.30	0.36		
6.40	0.816	9.29	0.653	17.57	0.606	7.80	0.69	19.50	0.88	7.20	0.51	6.40	0.440	4.60	0.40	21.10	1.00	7.30	0.03	7.40	0.36		
6.45	0.843	9.35	0.782	17.73	0.494	7.90	0.34	19.80	0.91	7.40	0.51	6.45	0.440	4.60	0.40	21.10	1.00	7.50	0.17	7.60	0.36		
6.50	0.819	9.39	0.777	18.35	0.484	8.20	0.23	20.10	0.99	7.50	0.51	6.50	0.440	4.60	0.40	21.10	1.00	7.60	0.03	7.70	0.36		
6.53	0.751	9.43	0.816	18.45	0.587	8.40	0.22	21.10	1.00	7.60	0.51	6.53	0.440	4.60	0.40	21.60	1.00	7.70	0.03	7.80	0.36		
6.57	0.302	9.63	0.840	18.73	0.600	8.60	0.21	21.60	1.00	7.80	0.51	6.57	0.440	4.60	0.40	22.10	0.97	7.90	0.03	8.00	0.36		
6.61	0.095	9.70	0.832	19.31	0.700	8.90	0.53	23.50	0.94	8.20	0.51	6.61	0.440	4.60	0.40	23.50	0.94	8.30	0.03	8.40	0.36		
6.67	0.196	9.86	0.452	19.88	0.631	9.10	0.59	25.00	0.83	8.50	0.51	6.67	0.440	4.60	0.40	25.00	0.83	8.60	0.03	8.70	0.36		
6.74	0.563	9.97	0.760	20.24	0.686	9.20	0.49	25.00	0.83	8.70	0.51	6.74	0.440	4.60	0.40	25.00	0.83	8.80	0.03	8.90	0.36		
6.82	0.515	10.07	0.833	20.66	0.703	9.40	0.58	26.90	0.79	9.10	0.51	6.82	0.440	4.60	0.40	26.90	0.79	9.20	0.03	9.30	0.36		
6.90	0.471	10.17	0.833	20.92	0.740	9.60	0.67	26.90	0.77	9.30	0.51	6.90	0.440	4.60	0.40	27.10	0.77	9.40	0.03	9.50	0.36		
6.92	0.430	10.26	0.867	21.63	0.755	9.80	0.79	33.60	1.00	9.60	0.51	6.92	0.440	4.60	0.40	33.60	1.00	9.70	0.03	9.80	0.36		
6.95	0.415	10.42	0.823	24.04	0.720	10.00	0.78	35.00	1.00	9.80	0.51	6.95	0.440	4.60	0.40	35.00	1.00	9.90	0.03	10.10	0.36		
7.00	0.431	10.60	0.851	25.00	0.755	10.20	0.45	37.10	1.00	10.00	0.51	7.00	0.440	4.60	0.40	37.10	1.00	10.20	0.03	10.40	0.36		
7.07	0.680	10.73	0.840	10.73	0.96	10.50	0.66	39.60	0.99	10.50	0.51	7.07	0.440	4.60	0.40	39.60	0.99	10.50	0.03	10.60	0.36		
7.11	0.672	10.87	0.658	11.55	0.769	10.60	0.93	42.20	0.97	10.60	0.51	7.11	0.440	4.60	0.40	42.20	0.97	10.60	0.03	11.30	0.36		
7.14	0.714	11.07	0.791	11.55	0.759	10.73	0.92	46.00	1.00	10.73	0.51	7.14	0.440	4.60	0.40	46.00	1.00	10.80	0.03	11.50	0.36		
7.20	0.656	11.29	0.633	11.44	0.776	11.20	0.66	48.00	1.00	11.20	0.51	7.20	0.440	4.60	0.40	48.00	1.00	11.60	0.03	11.80	0.36		
7.22	0.563	11.44	0.776	11.55	0.769	11.40	0.51	50.00	1.00	11.40	0.51	7.22	0.440	4.60	0.40	50.00	1.00	11.60	0.03	11.80	0.36		
7.34	0.463	11.55	0.769	11.55	0.55	11.40	0.51	52.20	0.97	11.40	0.51	7.34	0.440	4.60	0.40	52.20	0.97	11.40	0.03	11.80	0.36		
7.38	0.531	11.70	0.759	4.10	0.94	11.60	0.76	54.00	1.00	11.60	0.51	7.38	0.440	4.60	0.40	54.00	1.00	11.80	0.03	12.00	0.36		
7.53	0.561	11.90	0.316	4.40	0.94	11.80	0.74	56.00	1.00	11.80	0.51	7.53	0.440	4.60	0.40	56.00	1.00	12.00	0.03	12.30	0.36		
7.59	0.627	12.02	0.298	4.60	0.80	12.00	0.34	58.00	1.00	12.00	0.51	7.59	0.440	4.60	0.40	58.00	1.00	12.20	0.03	12.50	0.36		
7.69	0.441	12.27	0.367	4.90	0.95	12.20	0.29	60.00	1.00	12.20	0.51	7.69	0.440	4.60	0.40	60.00	1.00	12.30	0.03	12.50	0.36		

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	λ	τ	CURVE 13 (CONT.)		CURVE 14 (CONT.)		λ	τ	CURVE 14 (CONT.)		CURVE 14 (CONT.)		λ	τ	CURVE 14 (CONT.)	
12.56	6.28	47.90	0.88	4.072	0.943	6.81	0.814	9.19	0.800	12.13	0.743	12.27	0.758	12.37	0.856	12.45	0.911
12.70	5.30	50.00	0.84	4.079	0.937	6.88	0.801	9.22	0.694	12.27	0.758	12.37	0.856	12.45	0.911	12.47	0.943
12.80	0.13			4.086	0.943	6.93	0.906	9.26	0.569	12.37	0.856	12.47	0.943	12.57	0.955	12.73	0.929
13.10	0.11			4.097	0.940	7.00	0.914	9.28	0.686	12.45	0.911	12.57	0.955	12.73	0.929	12.73	0.929
13.50	0.35			5.017	0.940	7.04	0.865	9.33	0.796	12.47	0.943	12.57	0.955	12.73	0.929	12.89	0.892
13.80	0.34			5.022	0.933	7.11	0.794	9.33	0.902	12.57	0.955	12.73	0.929	12.73	0.929	12.93	0.892
14.10	0.25			5.024	0.910	7.11	0.856	9.38	0.924	12.57	0.955	12.73	0.929	12.73	0.929	12.93	0.892
14.50	0.51			5.034	0.910	7.25	0.900	9.46	0.937	12.57	0.955	12.73	0.929	12.73	0.929	12.93	0.892
14.80	0.71			5.043	0.900	7.30	0.867	9.56	0.937	12.57	0.955	12.73	0.929	12.73	0.929	12.93	0.892
15.40	0.84			5.051	0.865	7.34	0.812	9.70	0.926	13.06	0.841	13.06	0.841	13.19	0.889	13.31	0.925
15.70	0.79			5.052	0.854	7.36	0.908	9.74	0.891	13.19	0.889	13.31	0.925	13.51	0.951	13.51	0.951
15.90	0.66			5.053	0.765	7.44	0.926	9.77	0.792	13.31	0.925	13.51	0.951	13.51	0.951	13.51	0.951
16.20	0.78			5.057	0.660	7.55	0.893	9.80	0.695	13.31	0.925	13.51	0.951	13.51	0.951	13.51	0.951
16.40	0.70			5.059	0.493	7.59	0.807	9.82	0.598	13.33	0.941	13.33	0.941	13.76	0.950	13.76	0.950
16.90	0.41			5.059	0.272	7.69	0.792	9.83	0.409	13.06	0.841	13.06	0.841	13.99	0.943	13.99	0.943
17.30	0.22			5.063	0.272	7.73	0.671	9.89	0.586	14.12	0.919	14.12	0.919	14.12	0.919	14.12	0.919
17.60	0.11			5.063	0.493	7.82	0.687	9.95	0.686	14.12	0.919	14.12	0.919	14.12	0.919	14.12	0.919
18.00	0.08			5.067	0.598	7.88	0.488	10.00	0.885	14.26	0.936	14.39	0.967	14.39	0.967	14.39	0.967
18.40	0.12			5.071	0.748	7.94	0.298	10.05	0.935	14.39	0.967	14.61	0.941	14.61	0.941	14.61	0.941
19.10	0.50			5.075	0.841	7.97	0.196	10.10	0.956	14.61	0.941	14.61	0.941	14.74	0.915	14.74	0.915
20.50	0.53			5.079	0.865	8.02	0.170	10.20	0.953	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
21.00	0.66			5.081	0.889	8.07	0.138	10.33	0.964	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
21.70	0.74			5.086	0.907	8.14	0.165	10.48	0.959	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
22.10	0.81			5.093	0.915	8.18	0.216	10.58	0.966	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
22.60	0.80			5.095	0.735	8.25	0.325	10.67	0.977	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
23.00	0.67			6.007	0.909	8.30	0.220	10.77	0.967	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
23.60	0.54			6.016	0.919	8.36	0.138	11.00	0.977	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
24.10	0.51			6.021	0.815	8.40	0.289	11.10	0.958	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
24.50	0.36			6.026	0.846	8.49	0.457	11.16	0.896	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
25.10	0.31			6.030	0.886	8.52	0.329	11.22	0.816	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
26.30	0.51			6.036	0.932	8.57	0.203	11.36	0.883	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
29.30	0.60			6.041	0.906	8.61	0.393	11.41	0.924	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
30.60	0.68			6.045	0.916	8.69	0.592	11.48	0.958	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
31.90	0.73			6.055	0.758	8.75	0.790	11.60	0.939	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
33.00	0.81			6.060	0.595	8.79	0.817	11.70	0.890	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
35.00	0.92			6.061	0.423	8.87	0.840	11.76	0.798	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
37.10	0.82			6.064	0.423	8.97	0.816	11.84	0.775	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
39.50	0.76			6.064	0.552	9.05	0.775	11.89	0.694	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
41.60	0.91			6.068	0.697	9.12	0.815	12.00	0.626	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912
45.80	0.75			6.074	0.814	9.14	0.830	12.07	0.609	14.74	0.915	14.74	0.915	15.00	0.912	15.00	0.912

CURVE 14 (CONT.)
 $T = 293.$

TABLE 17-13. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF POLYCARBONATE PLASTICS (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

CURVE 15 (CONT.)



λ	T
3.11	0.075
3.14	0.041
3.19	0.030
3.81	0.000
3.87	0.033
3.90	0.066
3.92	0.086
3.97	0.169
3.97	0.041
4.07	0.041
4.11	0.023
4.19	0.000

CURVE 16
 $T = 293^\circ\text{K}$


2.48	0.000
2.48	0.360
2.54	0.034
2.61	0.083
2.63	0.030
2.69	0.014
2.76	0.000
2.84	0.000
2.87	0.027
2.92	0.057
2.98	0.057
2.98	0.041
3.04	0.041
3.19	0.026
3.17	0.000
3.62	0.000
3.84	0.024
3.88	0.017
3.94	0.000
4.03	0.016
4.09	0.000

4.18. Poly(phenylquinoxaline), PPQ

The preparation of soluble high molecular weight poly(phenylquinoxalines), PPQ, by the condensation of aromatic bis(o-diamines) with aromatic bisbenzils was first reported in 1967.




where $\phi = \text{---}\text{C}_6\text{H}_4\text{---}$ and $\text{Ar}, \text{Ar}' = \text{aromatic}$ typically, for PPQI $\text{Ar} = \text{---}\text{C}_6\text{H}_4\text{---}\text{C}_6\text{H}_4\text{---}$ and $\text{Ar}' = \text{---}\text{C}_6\text{H}_3(\text{NO}_2)_2\text{---}$, hence PPQI is described by the formula:



UV data for homo- and copolymers exhibit a λ_{max} in the case of PPQI at $292 \mu\text{m}$. Apparently the p-phenylene moiety and the phenyl group are forced out of the plane due to steric interaction, and therefore, are unable to participate significantly in resonance, for λ_{max} to appear at shorter wavelength.

The current interest in PPQ's is due to the high thermal stability and unusual ease of formation of these polymers. Formation is a one stage quantitative process at room temperature which yields completely cyclized, soluble polymers. Reaction of 1,4-di(phenylglyoxal) benzene



in excess in air yields a crosslinked polymer compared with the usual linear polymer when the reagents are used in stoichiometric amounts.

PPQ's are faintly yellow fibrous amorphous substances readily soluble in most organic solvents. Typical molecular weights are of the order of 330,000. PPQ polymers were shown to exhibit good solubility and processability as well as excellent thermal oxidative stability. However, IR spectra of PPQ demonstrates the ease of oxidation of the methylene bridges in those polymers containing this structural feature. It starts decomposition at 780 to 830 K.

The potential of PPQ for use as functional and structural resin in high temperature environment has been demonstrated.

PPQ specimens may be cured at 644 K and 1000 psi for four hours. The thermal linear expansion of the cured material increases gradually to the instability temperature of 578 K with the expansion at this point being 1.3% [T77908]. Above the instability temperature, PPQ first contracts, then expands slightly, then finally contracts severely above 756 K where degradation occurs.

The thermal conductivity of PPQ exhibits increasing values from $0.00293 \text{ W cm}^{-1} \text{ K}^{-1}$ at 340 K to $0.00317 \text{ W cm}^{-1} \text{ K}^{-1}$ at 533 K. Typical densities fall in the range $1.196 - 1.205 \text{ g cm}^{-3}$.

PPQ carbon fiber composites have been studied as potential re-entry vehicle (REV) materials.

No information on the thermal radiative properties of this material was uncovered from the search of literature. Consequently, no tabulation or recommendation of the thermal radiative properties of this material is possible at this time.

4.19. Silicone Resin

These organo-silicon oxide polymers may be resins, rubbers, or liquids. They are characterized by resistance to heat, oxidation, and weathering; water repellency; near independence of physical properties with temperature; and resistance to electrical breakdown. Their thermal degradation temperature is about 473 to 873 K.

Industrial uses include silicone release agents, lubricants, adhesives, laminating resins, electrical insulation, molding compounds, and additives. Trade names include Silastic, Polysil, Versilube, Dow Corning Silicone, etc.

In the United States, major companies producing silicones for industrial use include Dow Corning Corporation, General Electric Company, and Union Carbide Corporation.


For the purpose of aircraft design, the application of silicone resins may be classified in the following three ways:

- (1) Silicone laminating resins - These are used primarily in bonding glass cloth to produce structural and electrical laminates. They are also used to bond asbestos paper and cloth. Silicone-glass laminates have excellent resistance to heat and heat aging.
- (2) Interlayer for laminates glass - Silastic Type K Interlayer serves as the center layer in safety glass windshield for supersonic aircraft.
- (3) Silicone molding compounds - These are thermosetting materials that can be formed by either compression or transfer molding techniques. For high-impact, glass fiber-filled silicone molding compounds, the heat distortion temperature is about 755 K. Parts molded from silicone molding compounds find use as both structural and dielectric materials in aircraft and missiles.


Several silicone resins have been considered for application in aerospace construction. Poly(dimethylsilanediol) with a melting point of 740 K has been considered for use as a matrix material for flexible windows and domes in manned spacecraft, although it has been suggested that it has insufficient tear resistance for this purpose. Polyphenyl silicone has been considered for use as a paint-like organic coating for spacecraft, designed to control emission and absorption of radiant energy. Silicone DC 808 has been considered for similar uses. Silicone XRG-2044 has been considered for use as a coating for solar cells. Owens-Illinois "Glass Resin 100" has been studied for possible use as a lightweight optical material for aerospace reconnaissance. Some elastomers

are used for oxygen hoses, space suits, and cabin seals. Silicone resins are also used as ablation shields for space ships.

Silicones consist of chains of alternate Si and O atoms. The chains are modified by various organic groups attached to Si, or by crosslinking. Silicone polymers are prepared by condensation of di- or trihydroxymethylsilanes.



Silicone rubber



Silicone resin

Uncured silicone resins are soluble in some organic liquids such as toluene, xylene, petroleum spirit, and n-butyl acetate. Cured silicone resins can be swollen by toluene and some other hydrocarbons, carbon tetrachloride, methyl chloride, acetone, methyl ethyl ketone, liquid ammonia, liquid sulphur dioxide, and glacial acetic acid. They may be decomposed by the attack of concentrated hydrochloric and sulphuric acids.

Silicone resins have density about $1.0-1.2 \text{ g cm}^{-3}$. Its refractive index is about 1.405-1.49, specific heat 0.36-0.37, thermal conductivity $0.00146 \text{ W cm}^{-1} \text{ K}^{-1}$. Silicone resins that are flexible at room temperature have a brittleness temperature of 200 K or lower. The resins soften at temperatures from 300 K to above 470 K according to the degree of cure (cross-linkage). Prolonged heating causes gradual loss of weight by breakdown of volatile products, e.g., benzene and cyclic siloxanes from methylsiloxanes at 400-500 K. Its electrical resistivity at room temperature is about $3 \cdot 10^{13} - 5 \cdot 10^{15} \Omega \text{ cm}$ and dielectric constant is 2.75-2.85 from 60-10⁶ Hz. Its dielectric strength is about 20-120 kV/mm at room temperature, 50% lower at 370 K, and 20-30% lower for wet film. The arc resistance of silicone resins is greater than that of the organic resins.

a. Normal Spectral Emittance (Wavelength Dependence)

There are six sets of experimental data available for the wavelength dependence of the normal spectral emittance of silicone resins as listed in Table 19-3 and shown in Fig. 19-2. Specimen characterization and measurement information for the data are

given in Table 19-2. Two data sets each are for "Pyrosin" heat resistant paint on aluminum plate at 473 and 673 K with brown, green, and beige color, respectively. In the wavelength region above $\lambda = 8 \mu\text{m}$, there are very small differences among the values of emittance for different paint. However, in the shorter wavelength region, i.e., $\lambda < 8 \mu\text{m}$, brown paint has the highest emittance value and beige paint has the lowest emittance value. Since the data are limited, as a consequence, only provisional values were reported here. The provisional values are listed in Table 19-1 and shown in Figure 19-1 for the green "Pyrosin" paint on aluminum plate at 473 K. The estimated uncertainty is within $\pm 30\%$.

TABLE 19-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ
PYROGIN GREEN $T = 473$	
2.70	0.67
2.90	0.74
3.00	0.81
3.20	0.84
3.40	0.82
3.60	0.74
4.00	0.73
4.60	0.76
5.00	0.96
5.20	0.90
5.80	0.91
6.00	0.72
6.50	0.93
7.00	0.93
7.50	0.94
8.00	0.94
8.50	0.35
9.00	0.36
9.60	0.94
10.00	0.94
10.20	0.94
10.50	0.94
11.00	0.96
11.80	0.96
12.00	0.96
12.50	0.97
13.00	0.97
13.50	0.97
14.00	0.96
14.50	0.96
15.00	0.96




FIGURE 19-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF SILICONE RESIN COATING (WAVELENGTH DEPENDENCE).




FIGURE 19-2. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).

TABLE 19-2. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF SILICONE RESIN COATING (Wavelength Dependence).

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T71893	Kanayama, K.	1972	1-25	673	"Pyrosin"	Heat resisting paint with brown color was coated on aluminum plate; data were extracted from figure; $\theta \sim 0^\circ$.	
2 T71893	Kanayama, K.	1972	1-25	473	"Pyrosin"	Similar to the above specimen.	
3 T71893	Kanayama, K.	1972	1-25	673	"Pyrosin"	Similar to the above specimen except paint with green color.	
4 T71893	Kanayama, K.	1972	1-25	473	"Pyrosin"	Similar to the above specimen.	
5 T71893	Kanayama, K.	1972	1-25	673	"Pyrosin"	Similar to the above specimen except paint with beige color.	
6 T71893	Kanayama, K.	1972	1-25	473	"Pyrosin"	Similar to the above specimen.	

TABLE 19-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ	CURVE 1 $T = 673.$		CURVE 2 $T = 473.$		CURVE 3 (CONT.)		CURVE 4 $T = 473.$		CURVE 4 (CONT.)		CURVE 5 (CONT.)	
		λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ	λ	ϵ
1.83	0.862	2.40	1.000	2.80	0.726	2.73	0.670	22.79	0.962	8.56	0.979	2.91	0.984
2.05	0.882	2.91	0.967	2.93	0.761	3.04	0.786	23.27	0.973	8.74	0.983	3.67	0.987
2.36	0.893	3.17	0.946	3.17	0.786	3.17	0.786	23.67	0.968	9.37	0.983	4.39	0.986
2.52	0.907	3.50	0.940	3.44	0.735	3.03	0.813	24.39	0.968	9.56	0.980	5.02	0.986
2.72	0.915	4.02	0.946	3.80	0.735	3.18	0.840	24.74	0.962	9.80	0.985	5.67	0.985
3.21	0.918	4.54	0.962	3.99	0.690	3.44	0.819	25.00	0.987	10.22	0.956	6.23	0.956
3.69	0.923	5.15	0.952	4.31	0.717	3.75	0.740	10.80	0.976	11.65	0.982	6.87	0.982
3.99	0.939	5.75	0.967	4.47	0.744	4.08	0.733	12.16	0.986	12.82	0.990	7.52	0.988
4.21	0.954	6.03	0.965	4.63	0.779	4.67	0.757	12.82	0.990	13.76	0.994	8.18	0.994
5.17	0.954	6.33	0.970	4.86	0.856	4.87	0.816	1.91	0.679	15.40	0.994	8.84	0.994
5.54	0.963	7.05	0.970	5.02	0.806	5.03	0.878	2.20	0.714	18.01	0.989	9.50	0.989
6.14	0.963	7.74	0.981	5.17	0.904	5.17	0.902	2.61	0.737	18.42	0.993	10.18	0.993
6.55	0.969	8.34	0.986	5.34	0.922	5.80	0.910	2.59	0.739	19.09	0.990	10.86	0.990
7.21	0.968	8.86	0.970	5.75	0.923	6.34	0.931	2.77	0.754	20.71	0.975	11.54	0.975
7.80	0.968	9.25	0.949	6.01	0.950	6.66	0.931	2.96	0.754	22.32	0.975	12.22	0.975
8.97	0.971	9.76	0.934	6.35	0.970	6.89	0.935	3.12	0.742	22.86	0.969	12.86	0.969
9.44	0.956	10.26	0.934	7.27	0.967	7.09	0.931	3.23	0.722	24.48	0.962	13.54	0.962
9.77	0.950	10.79	0.954	7.80	0.968	7.96	0.942	3.33	0.686	25.15	0.962	14.22	0.962
10.24	0.950	11.13	0.973	8.97	0.971	8.21	0.937	3.51	0.650	23.44	0.965	14.90	0.965
10.36	0.970	13.33	0.975	9.10	0.968	6.73	0.969	3.75	0.629	23.79	0.967	15.58	0.967
11.32	0.970	14.39	0.981	9.56	0.966	9.25	0.949	3.88	0.619	24.48	0.962	16.26	0.962
11.61	0.978	15.00	0.981	10.28	0.966	9.62	0.937	4.19	0.607	25.15	0.962	16.94	0.962
11.97	0.968	15.72	0.977	10.64	0.981	10.21	0.937	4.49	0.628	23.79	0.967	17.62	0.967
12.50	0.988	16.27	0.982	10.92	0.988	10.79	0.954	4.94	0.671	24.48	0.962	18.30	0.962
12.69	0.983	17.32	0.984	12.00	0.997	11.23	0.960	5.23	0.703	25.15	0.962	18.98	0.962
13.78	0.994	18.25	0.973	12.83	0.997	11.87	0.960	5.69	0.706	25.86	0.968	19.66	0.968
15.40	0.994	19.47	0.976	13.73	0.994	12.53	0.973	6.02	0.769	3.06	0.775	20.91	0.971
16.39	0.989	20.45	0.969	15.40	0.994	13.21	0.973	6.02	0.769	3.13	0.791	21.56	0.971
19.09	0.975	21.91	0.969	16.39	0.989	16.11	0.981	6.19	0.776	3.25	0.807	22.22	0.971
19.91	0.975	22.29	0.974	19.09	0.975	14.96	0.984	6.39	0.764	3.46	0.804	22.89	0.971
20.52	0.965	22.99	0.987	20.32	0.975	15.29	0.977	6.57	0.793	3.70	0.724	23.56	0.971
21.35	0.960	25.00	0.987	21.18	0.969	15.99	0.977	6.74	0.834	3.99	0.684	24.22	0.971
21.94	0.946	23.33	0.946	22.41	0.961	17.58	0.950	7.11	0.829	4.13	0.641	24.89	0.971
23.87	0.956	22.69	0.967	22.69	0.967	18.16	0.947	7.32	0.859	4.38	0.620	25.56	0.971
24.45	0.977	23.24	0.967	23.81	0.975	18.70	0.966	7.52	0.922	4.64	0.639	26.23	0.971
25.15	0.984	2.61	0.672	24.48	0.981	19.78	0.954	7.64	0.952	4.80	0.675	26.90	0.971
				25.11	0.989	21.38	0.962	7.84	0.969	5.18	0.711	27.56	0.972

CURVE 5
 $T = 673.$

6

T = 473.

3

4

5

6

7

8

9

10

11

12

13

14

15

16

17

18

19

20

21

22

23

24

25

26

27

28

29

30

31

32

33

34

35

36

37

38

39

40

41

42

43

44

45

46

47

48

49

50

51

52

53

54

55

56

57

58

59

60

61

62

63

64

65

66

67

68

69

70

71

72

73

74

75

76

77

78

79

80

81

82

83

84

85

86

87

88

89

90

91

92

93

94

95

96

97

98

99

100

101

102

103

104

105

106

107

108

109

110

111

112

113

114

115

116

117

118

119

120

121

122

123

124

125

126

127

128

129

130

131

132

133

134

135

136

137

138

139

140

141

142

143

144

145

146

147

148

149

150

151

152

153

154

155

156

157

158

159

160

161

TABLE 19-3. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ	CURVE 6 (CONT.)
6.04	0.760	
6.09	0.916	
6.33	0.835	
6.57	0.812	
6.81	0.838	
6.86	0.875	
7.14	0.865	
7.50	0.879	
7.66	0.943	
7.83	0.976	
8.07	0.994	
8.59	0.994	
8.88	0.985	
9.09	0.986	
9.35	0.968	
9.79	0.939	
10.29	0.939	
10.79	0.954	
11.15	0.966	
12.41	0.972	
13.92	0.972	
14.60	0.959	
15.22	0.949	
15.86	0.949	
17.09	0.954	
18.09	0.959	
18.67	0.957	
19.79	0.951	
21.32	0.959	
23.19	0.959	
23.60	0.967	
23.98	0.978	
24.91	0.978	

b. Normal Spectral Reflectance (Wavelength Dependence)

There are 21 sets of experimental data available for the wavelength dependence of the normal spectral reflectance of silicone resin coating as listed in Table 19-6 and shown in Figure 19-4. Specimen characterization and measurement information for the data are given in Table 19-5. There were 10 different kinds of silicone used for measurements. The normal spectral reflectance values for silicone black paint (Pyrolac 7G 800) were the lowest. RTV-602 silicone on aluminum substrate has the highest reflectance values. Only Wilburn and Renius [T47062] and Wetmore [T40420] measured the normal spectral reflectance in the wavelength region above 2.6 μm . Because the range of reflectance for silicone is so wide, only provisional values are reported here which are listed in Table 19-4 and shown in Figure 19-3. The provisional values are for a 0.43 mm thick Dow Corning 6510 silicone on aluminum substrate at 400 K. The estimated uncertainty is within $\pm 30\%$.

TABLE 19-2. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ
DC 5510	
$T = 403$	
1.75	0.52
2.00	0.50
2.10	0.59
2.15	0.21
2.22	0.17
2.40	0.18
2.50	0.21
2.56	0.21
2.70	0.07
2.80	0.22
3.00	0.24
3.10	0.04
3.30	0.03
3.50	0.04
3.60	0.39
3.84	0.42
4.00	0.29
4.05	0.44
4.15	0.47
4.25	0.44
4.50	0.18
4.80	0.37
5.00	0.15
5.50	0.05
7.00	0.39
7.30	0.10
8.00	0.13
8.50	0.16
9.00	0.19
9.30	0.23
9.60	0.22
10.00	0.21
11.00	0.21
11.50	0.21
12.00	0.21
12.50	0.22
13.00	0.22
13.50	0.23
14.00	0.23




FIGURE 19-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF SILICONE RESIN COATING (WAVELENGTH DEPENDENCE).




FIGURE 19-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).

TABLE 19-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICONE RESIN COATING (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T41945	Caldwell, C.R. and Nelsen, P.A.	1969	0.25-2.6	~293	RTV-602	3.8 ml RTV-602 silicone over aluminum foil; data were extracted from figure; $\theta \sim 0^\circ$. Similar to the above specimen except 2.6 ml.
2 T41945	Caldwell, C.R. and Nelsen, P.A.	1969	0.25-2.6	~293	RTV-602	Silicone coated on cotton fabric; magnesium oxide was chosen as a standard for diffuse reflector; data were extracted from figure; $\theta \sim 0^\circ$. Similar to the above specimen.
3 T47062	Wilburn, D.K. and Reinius, O.	1955	1-12	~293	Silicone coated on cotton fabric	General Electric experimental silicone resin 391-15-170 (PJ 113) was on aluminum substrate; data were extracted from figure; $\theta \sim 0^\circ$.
4 T47062	Wilburn, D.K. and Reinius, O.	1955	1-12	~293	Silicone coated on cotton fabric	Silicone black paint; a DK 2A spectrometer was used to measure the reflectance; $\theta \sim 0^\circ$.
5 T41421	Griffin, R.N. and Linder, B.	1969	0.3-2.3	~293	Silicone PJ 113 on Aluminum	White silicone coating on optical solar reflector; the spectral reflectance data were obtained using a Gier-Dunkle integrating sphere and a Gier Dunkle heated cavity directional reflectometer; data were extracted from figure; $\theta \sim 0^\circ$.
6 T35934	Faugere, J.F.	1965	0.3-2.6	~293	Pyrolac 7G800	Air dried on MKI integrating sphere; a Beckman DK 2A spectrometer was used; data were extracted from figure; $\theta \sim 0^\circ$, $\omega = 28^\circ$.
7 T53491	Marshall, K.N. and Brench, R.A.	1968	0.3-25	295	Silicone coating	Similar to the above specimen except cured at 250 C.
8 T34045	Porter, J. and Butler, E.A.W.	1965	0.3-2.6	~293	White Silicone Paint F663-2020-1/001/35	Similar to the above specimen except air dried on MKII sphere.
9 T34045	Porter, J. and Butler, E.A.W.	1965	0.3-2.6	~293	White Silicone Paint F663-2020-1/001/35	Similar to the above specimen except air dried on MKII sphere.
10 T34045	Porter, J. and Butler, E.A.W.	1965	0.3-2.6	~293	White Silicone Paint F663-2020-1/001/35	Similar to the above specimen except air dried on MKII sphere.
11 T34045	Porter, J. and Butler, E.A.W.	1965	0.3-2.6	~293	White Silicone Paint F663-2020-1/001/35	Similar to the above specimen except air dried on MKII sphere.
12 T34045	Porter, J. and Butler, E.A.W.	1965	0.3-2.6	~293	Gloss Black Silicone Paint F663-2021-1/001/35	Similar to the above specimen except air dried on MKII sphere.
13 T34045	Porter, J. and Butler, E.A.W.	1965	0.3-2.6	~293	Gloss Black Silicone Paint F663-2021-1/001/35	Similar to the above specimen except air dried on MKII sphere.
14 T41934	Slemp, W.S. and Hankinson, T.W.E.	1969	0.3-2.6	~293	H-10	Calcined (Mono 90) clay-methyl silicone (RTV-602) specimen was obtained from Hughes Aircraft Co.; data were extracted from figure; $\theta \sim 0^\circ$.
15 T29599	Carroll, W.F.	1962	0.021-0.751	298		DCS68 silicone 3 parts by wt. TBT 2 parts by wt.; polished aluminum substrate; data were extracted from figure; $\theta \sim 0^\circ$, $\omega = 27^\circ$.
16 T29599	Carroll, W.F.	1962	0.372-0.751	298		The above specimen except it was exposed to UV at about 10 runs for 22.75 hr; data were extracted from smooth curve.
17 T40420	Wetmore, R.A.	1963	0.49-3.00	300	Sample 29R	Dow Corning 6510 silicone (0.432 mm thick); aluminum substrate; data were extracted from smooth curve; $\theta = 5^\circ$, $\omega = 28^\circ$.
18 T40420	Wetmore, R.A.	1963	1.76-14.0	389	Sample 31Ra	Similar to the above specimen.
19 T40420	Wetmore, R.A.	1963	3.72-14.0	422	Sample 30Ra	Similar to the above specimen.
20 T40420	Wetmore, R.A.	1963	1.76-14.0	450	Sample 31Rb	Similar to the above specimen.

TABLE 19-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF SILICONE RESIN COATING (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
21 T-773 <i>a</i>		Turner, H.C. and Keller, E.E.	1959	0.25-2.0	~293	X5G-138	Silicone/"5" glass; a Beckman DK-2 spectroradiometer was used in measurements; data were extracted from smooth curve.

TABLE 19-5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 1		CURVE 1 (CONT.)		CURVE 2		CURVE 2 (CONT.)		CURVE 5		CURVE 5 (CONT.)		λ	ρ
		$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	$T = 293$	
0.313	0.796	1.748	0.652	0.620	0.651	2.362	0.825	0.333	0.762	0.40	0.0432	0.44	0.0423	0.57	0.0423
0.344	0.809	1.794	0.904	0.663	0.646	2.402	0.843	0.364	0.786	0.44	0.0423	0.69	0.0423	0.74	0.0423
0.368	0.812	1.817	0.915	0.714	0.635	2.455	0.858	0.391	0.798	0.57	0.0423	0.74	0.0423	0.74	0.0423
0.406	0.812	1.843	0.925	0.766	0.619	2.520	0.850	0.418	0.809	0.69	0.0451	0.74	0.0451	0.74	0.0451
0.434	0.826	1.875	0.930	0.792	0.618	2.555	0.850	0.444	0.820	0.74	0.0451	0.77	0.0424	0.77	0.0424
0.463	0.798	1.966	0.930	0.812	0.629	2.583	0.839	0.477	0.827	0.79	0.0311	0.79	0.0311	0.79	0.0311
0.503	0.603	2.005	0.926	0.845	0.663	2.600	0.817	0.477	0.827	0.85	0.0357	0.85	0.0357	0.85	0.0357
0.534	0.794	2.105	0.926	0.879	0.694	2.635	0.838	0.607	0.838	1.03	0.0323	1.03	0.0323	1.03	0.0323
0.564	0.784	2.122	0.922	0.910	0.716	2.663	0.838	0.621	0.838	1.22	0.0344	1.22	0.0344	1.22	0.0344
0.603	0.778	2.135	0.897	0.950	0.746	2.691	0.750	0.621	0.821	1.36	0.0357	1.36	0.0357	1.36	0.0357
0.642	0.755	2.165	0.694	0.978	0.761	2.720	0.778	0.787	0.816	1.50	0.0364	1.50	0.0364	1.50	0.0364
0.682	0.727	2.201	0.885	1.020	0.778	2.750	0.816	0.816	0.864	2.09	0.0364	2.09	0.0364	2.09	0.0364
0.722	0.717	2.219	0.867	1.062	0.785	2.800	0.816	0.816	0.864	2.19	0.0371	2.19	0.0371	2.19	0.0371
0.751	0.717	2.244	0.813	1.117	0.793	3.00	0.816	0.862	0.862	2.35	0.0377	2.35	0.0377	2.35	0.0377
0.780	0.733	2.282	0.740	1.174	0.816	4.41	0.816	0.904	0.904	2.47	0.0385	2.47	0.0385	2.47	0.0385
0.807	0.774	2.298	0.713	1.218	0.823	5.00	0.823	0.956	0.956	2.95	0.0385	2.95	0.0385	2.95	0.0385
0.836	0.826	2.319	0.698	1.297	0.831	6.00	0.831	1.020	0.919	3.19	0.0385	3.19	0.0385	3.19	0.0385
0.865	0.820	2.332	0.705	1.357	0.840	7.00	0.841	1.09	0.923	3.56	0.0385	3.56	0.0385	3.56	0.0385
0.893	0.811	2.356	0.737	1.402	0.850	8.00	0.850	1.156	0.933	3.93	0.0385	3.93	0.0385	3.93	0.0385
0.922	0.815	2.385	0.772	1.464	0.857	9.00	0.850	1.240	0.933	4.30	0.0385	4.30	0.0385	4.30	0.0385
0.951	0.838	2.404	0.799	1.550	0.857	10.00	0.619	1.325	0.927	4.67	0.0385	4.67	0.0385	4.67	0.0385
0.980	0.847	2.428	0.611	1.626	0.851	11.00	0.221	1.397	0.934	5.04	0.0385	5.04	0.0385	5.04	0.0385
1.009	0.820	2.456	0.623	1.679	0.841	12.00	0.063	1.514	0.934	5.41	0.0385	5.41	0.0385	5.41	0.0385
1.038	0.855	2.484	0.827	1.732	0.841	13.00	0.904	1.624	0.921	5.78	0.0385	5.78	0.0385	5.78	0.0385
1.067	0.856	2.504	0.827	1.730	0.853	14.00	0.221	1.726	0.904	6.15	0.0385	6.15	0.0385	6.15	0.0385
1.142	0.855	2.484	0.827	1.730	0.853	15.00	0.853	1.769	0.895	6.52	0.0385	6.52	0.0385	6.52	0.0385
1.183	0.861	2.539	0.827	1.781	0.874	16.00	0.874	1.811	0.895	6.89	0.0385	6.89	0.0385	6.89	0.0385
1.227	0.871	2.569	0.821	1.781	0.874	17.00	0.874	1.861	0.895	7.26	0.0385	7.26	0.0385	7.26	0.0385
1.266	0.869	2.600	0.806	1.636	0.869	18.00	0.869	1.911	0.895	7.63	0.0385	7.63	0.0385	7.63	0.0385
1.295	0.395	2.632	0.903	1.960	0.903	19.00	0.181	1.967	0.916	8.00	0.0385	8.00	0.0385	8.00	0.0385
1.347	0.394	2.651	0.903	1.960	0.903	20.00	0.328	1.956	0.916	8.37	0.0385	8.37	0.0385	8.37	0.0385
1.356	0.876	2.669	0.903	2.028	0.908	21.00	0.217	1.998	0.904	8.70	0.0385	8.70	0.0385	8.70	0.0385
1.369	0.864	2.687	0.903	2.085	0.900	22.00	0.209	2.075	0.876	9.04	0.0385	9.04	0.0385	9.04	0.0385
1.407	0.900	2.755	0.539	2.135	0.889	23.00	0.200	2.180	0.821	9.41	0.0385	9.41	0.0385	9.41	0.0385
1.432	0.901	2.96	0.554	2.166	0.877	24.00	0.102	2.217	0.821	9.78	0.0385	9.78	0.0385	9.78	0.0385
1.462	0.894	3.35	0.572	2.199	0.861	25.00	0.059	2.258	0.821	10.16	0.0385	10.16	0.0385	10.16	0.0385
1.489	0.865	3.76	0.591	2.225	0.638	26.00	0.069	2.309	0.821	10.53	0.0385	10.53	0.0385	10.53	0.0385
1.504	0.897	4.11	0.613	2.240	0.916	27.00	0.216	2.368	0.821	10.90	0.0385	10.90	0.0385	10.90	0.0385
1.515	0.906	4.34	0.628	2.254	0.805	28.00	0.430	2.430	0.821	11.27	0.0385	11.27	0.0385	11.27	0.0385
1.550	0.899	479	0.634	2.275	0.795	29.00	0.236	2.503	0.821	11.64	0.0385	11.64	0.0385	11.64	0.0385
1.666	0.873	560	0.635	2.303	0.795	30.00	0.169	2.575	0.821	12.00	0.0385	12.00	0.0385	12.00	0.0385
1.726	0.848	581	0.647	2.331	0.805	31.00	0.073	2.647	0.821	12.37	0.0385	12.37	0.0385	12.37	0.0385

CURVE 6
 $T = 293$.

CURVE 6
 $T = 293$.

TABLE 19-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELLENGTH DEPENDENCE) (CONTINUED)

λ	ρ	CURVE 7 (CONT.)		CURVE 8 (CONT.)		CURVE 9 (CONT.)		CURVE 10 (CONT.)		CURVE 11 (CONT.)		CURVE 12		CURVE 13	
λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
3.21	0.267	0.396	0.564	2.467	0.554	2.151	0.676	1.623	0.780	1.616	0.761	1.616	0.716	1.628	0.716
3.50	0.1.2	0.413	0.759	2.303	0.582	2.186	0.668	1.652	0.757	1.628	0.716	1.628	0.716	1.628	0.716
3.74	0.075	0.417	0.835	2.524	0.626	2.186	0.706	1.670	0.736	1.700	0.703	1.700	0.703	1.700	0.703
3.90	0.128	0.446	0.851			2.233	0.766	1.697	0.717	1.755	0.727	1.755	0.727	1.755	0.727
4.23	0.231	0.477	0.858			2.302	0.676	1.744	0.748	1.799	0.771	1.799	0.771	1.799	0.771
4.44	0.286	0.504	0.858			2.364	0.656	1.804	0.799	1.854	0.800	1.854	0.800	1.854	0.800
4.65	0.306	0.539	0.854			2.395	0.616	1.863	0.813	1.912	0.810	1.912	0.810	1.912	0.810
4.82	0.279	0.629	0.827	0.268	0.052	2.422	0.550	1.909	0.822	1.985	0.810	1.985	0.810	1.985	0.810
5.10	0.196	0.666	0.736	0.312	0.077	2.446	0.530	1.978	0.822	2.047	0.816	2.047	0.816	2.047	0.816
5.43	0.133	0.668	0.717	0.368	0.339	2.491	0.530	2.047	0.816	2.077	0.761	2.077	0.761	2.077	0.761
5.65	0.275	0.722	0.740	0.396	0.564	2.491	0.554	2.089	0.787	2.131	0.716	2.131	0.716	2.131	0.716
5.79	0.323	0.796	0.663	0.413	0.759	2.506	0.582	2.211	0.685	2.211	0.685	2.211	0.685	2.211	0.685
6.02	0.262	0.623	0.683	0.442	0.789	2.524	0.626								
6.18	0.154	0.882	0.686	0.466	0.816										
6.38	0.396	1.212	0.881	0.494	0.835										
6.53	0.069	1.265	0.861	0.504	0.858										
6.57	0.189	1.314	0.846	0.589	0.854										
6.97	0.144	1.369	0.843	0.629	0.827	0.325	0.038	0.325	0.036	0.349	0.034	0.349	0.034	0.349	0.034
6.35	0.096	1.540	0.840	0.666	0.738	0.372	0.049	0.405	0.299	0.425	0.047	0.425	0.047	0.425	0.047
9.35	0.69	1.583	0.826	0.688	0.717	0.405	0.299	0.422	0.762	0.513	0.039	0.513	0.039	0.513	0.039
10.27	0.051	1.607	0.807	0.722	0.740	0.422	0.762	0.461	0.793	0.599	0.034	0.599	0.034	0.599	0.034
10.92	0.043	1.633	0.740	0.796	0.868	0.422	0.799	0.508	0.815	0.835	0.034	0.835	0.034	0.835	0.034
11.89	0.043	1.658	0.715	0.823	0.863	0.457	0.824	0.550	0.826	1.154	0.039	1.154	0.039	1.154	0.039
12.46	0.050	1.739	0.822	0.882	0.886	0.513	0.839	0.595	0.843	1.563	0.042	1.563	0.042	1.563	0.042
12.58	0.057	1.778	0.853	1.212	0.881	0.595	0.843	0.647	0.832	1.954	0.043	1.954	0.043	1.954	0.043
13.70	0.072	1.877	0.887	1.265	0.861	0.647	0.832	0.684	0.757	2.226	0.038	2.226	0.038	2.226	0.038
14.49	0.112	1.959	0.694	1.314	0.846	0.684	0.757	0.718	0.726	2.500	0.034	2.500	0.034	2.500	0.034
14.94	0.136	2.031	0.879	1.369	0.840	0.718	0.726	0.745	0.742						
15.46	0.151	2.092	0.849	1.540	0.840	0.745	0.742	0.768	0.766						
16.36	0.151	2.126	0.817	1.583	0.826	0.768	0.792	0.794	0.818						
17.02	0.165	2.142	0.723	1.607	0.807	0.794	0.818	0.826	0.834						
17.93	0.179	2.157	0.699	1.633	0.740	0.826	0.834	0.896	0.846						
16.93	0.202	2.189	0.713	1.658	0.715	0.896	0.846	0.905	0.849						
2.21	0.743	2.211	0.743	1.629	0.826	0.985	0.849	1.065	0.849						
2.234	0.728	2.234	0.728	1.629	0.853	1.065	0.849	1.170	0.836						
2.250	0.701	2.250	0.701	1.694	0.869	1.170	0.836	1.243	0.824						
2.348	0.685	2.348	0.685	1.694	0.875	1.243	0.824	1.299	0.811						
2.389	0.654	2.389	0.654	2.046	0.856	1.351	0.811	1.351	0.811						
2.441	0.577	2.441	0.577	2.095	0.895	1.455	0.819	1.455	0.819						

TABLE 19-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
CURVE 14 $T = 293.$		CURVE 16 $T = 298.$		CURVE 17 (CONT.)		CURVE 18 (CONT.)		CURVE 19 $T = 422.$		CURVE 20 (CONT.)		CURVE 21 (CONT.)	
0.253	0.310	0.372	0.149	0.250	0.265	10.34	0.213	2.70	0.121	1.506	0.680		
0.351	0.697	0.399	0.224	0.57	0.259	11.63	0.212	2.80	0.218	1.575	0.693		
0.374	0.775	0.449	0.403	2.63	0.289	14.00	0.240	2.97	0.239	1.601	0.663		
0.385	0.822	0.466	0.447	2.71	0.266			3.08	0.065	1.641	0.523		
0.465	0.857	0.487	0.502	2.85	0.296			3.31	0.331	1.676	0.401		
0.443	0.885	0.500	0.522	2.90	0.273			3.58	0.045	1.701	0.445		
0.495	0.902	0.518	0.550	3.00	0.263			3.78	0.362	1.739	0.507		
0.542	0.913	0.549	0.580			3.72	0.363	3.87	0.420	1.775	0.572		
0.593	0.922	0.600	0.613			3.79	0.460	4.02	0.289	1.790	0.595		
0.709	0.922	0.649	0.637			4.18	0.529	4.13	0.471	1.898	0.629		
0.869	0.914	0.702	0.654			4.45	0.402	4.38	0.311	1.951	0.636		
1.123	0.901	0.751	0.658			4.69	0.158	4.57	0.250	2.000	0.633		
1.381	0.895	0.895				4.78	0.107	4.69	0.146				
1.743	0.889	0.57	0.567			4.94	0.075	4.88	0.112				
1.940	0.883	0.69	0.585			5.13	0.062	5.19	0.099				
2.100	0.673	0.83	0.578			6.32	0.071	6.13	0.121				
2.209	0.562	0.49	0.536			7.50	0.102	7.40	0.165				
2.312	0.653	0.57	0.567			7.72	0.099	8.38	0.218				
2.406	0.834	0.69	0.585			8.71	0.139	9.73	0.298				
2.491	0.815	0.83	0.578			9.14	0.179	12.03	0.305				
2.580	0.786	0.97	0.631			9.61	0.235	14.00	0.323				
		1.02	0.672			9.80	0.249						
		1.11	0.700			10.09	0.241						
		1.17	0.656			10.49	0.199						
		1.26	0.664			12.47	0.199						
		1.27	0.753			12.61	0.209						
		1.36	0.753			13.56	0.218						
		1.40	0.667			14.00	0.220						
		1.45	0.673										
		1.50	0.766										
		1.63	0.790										
		1.80	0.715										
		1.90	0.769										
		1.94	0.773										
		1.95	0.441										
		1.50	0.766										
		2.02	0.757										
		2.13	0.786										
		2.33	0.211										
		2.39	0.237										
		2.47	0.299										
		3.53	0.230										
		2.61	0.121										

CURVE 21
 $T = 293.$

CURVE 18
 $T = 389.$

CURVE 17
 $T = 300.$

CURVE 20

$T = 450.$

CURVE 21

$T = 450.$

c. Angular Spectral Reflectance (Wavelength Dependence)

There are seven sets of experimental data available for the wavelength dependence of the angular spectral reflectance of silicone resin coatings as listed in Table 19-9 and shown in Figure 19-6. Specimen characterization and measurement information for the data are given in Table 19-8. Only specular reflectance data were measured. All the specimens were coated over silver thin films and there is no information on the thickness of the silicone coating and silver thin film. As a consequence of these difficulties, only provisional values are reported here which are listed in Table 19-7 and shown in Figure 19-5 with the experimental data as background. The estimated uncertainty is about $\pm 30\%$.

TABLE 19-7. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE,
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ])

λ	ρ
COATING $\theta' = 9 \pm 45^\circ$ $T = 293$	8.45
4.00	0.62
4.45	0.62
4.80	0.73
5.15	0.75
5.50	0.77
5.85	0.79
6.20	0.81
6.55	0.84
6.90	0.85
7.25	0.86
7.60	0.87
7.95	0.87
8.30	0.87
8.65	0.87
9.00	0.88
9.35	0.89
9.70	0.89
10.05	0.89
10.40	0.89
10.75	0.89
11.10	0.90
11.45	0.90
11.80	0.91
12.15	0.91
12.50	0.91
12.85	0.91
13.20	0.91
13.55	0.91
13.90	0.91
14.25	0.91
14.60	0.91
14.95	0.91
15.30	0.91




FIGURE 19-5. PROVISIONAL ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN COATING (WAVELENGTH DEPENDENCE).




FIGURE 19-6. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).

TABLE 19-S. MEASUREMENT INFORMATION ON THE ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN COATING (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T33368	Beiser, R. B.; Carithers, M. D.; Britt, F. L.; Meaders, J. C.; Elsica, L. W.; Koralek, A. S.; Cooke, J. C.; and Frahm, C. P.	1962	1-14.4	~293	Ag 87 CS	Siliclad; silicone resin over coating on a silver film which is deposited on silicone resin coated 316 stainless steel substrate; silver film was applied by Brashear method; specular reflectance; data were extracted from the table; $\theta=45^\circ$, $\theta'=45^\circ$.
2 T33368	Beiser, R. B., et al.	1962	1-14.4	~293	Ag 88 CS	Similar to the above specimen.
3 T33368	Beiser, R. B., et al.	1962	1-14.4	~293	Ag 89 CS	Similar to the above specimen.
4 T33368	Beiser, R. B., et al.	1962	1-14.4	~293	Ag 90 CS	Similar to the above specimen except silver film was deposited on SY627-119 polyurethane (Febert Shorndorfer Co.), and 316 stainless steel substrates.
5 T33368	Beiser, R. B., et al.	1962	1-14.4	~293	Ag 91 CS	Similar to the above specimen.
6 T33368	Beiser, R. B., et al.	1962	1-14.4	~293	Ag 92 CS	Similar to the above specimen except silver film was deposited on Maraset 617-C epoxy resin (Marblet Co.), and 316 stainless steel substrate.
7 T33368	Beiser, R. B., et al.	1962	1-14.4	~293	Ag 93 CS	Similar to the above specimen.

TABLE 19-9. EXPERIMENTAL ANGULAR SPECTRAL REFLECTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)


λ	ρ	CURVE 1 $T = 293.$	CURVE 3 (CONT.)	CURVE 6 $T = 293.$
1.009	0.435	7.780	0.659	1.009 0.831
1.120	0.463	10.198	0.681	1.120 0.864
1.345	0.519	12.099	0.893	1.345 0.886
1.720	0.606	13.530	0.896	1.720 0.923
1.945	0.633	14.375	0.892	1.945 0.929
2.240	0.700	CURVE 4		
4.824	0.828	$T = 293.$		
7.780	0.859	7.780	0.824	7.780 0.967
10.198	0.877	1.009	0.700	1.0198 0.977
12.099	0.888	1.120	0.741	1.120 0.974
13.530	0.892	1.345	0.767	13.530 0.965
14.375	0.889	1.720	0.786	14.375 0.953
CURVE 2				
$T = 293.$				
1.009	0.706	2.240	0.827	CURVE 7 $T = 293.$
1.120	0.725	4.824	0.878	7.780 0.958
1.345	0.757	10.198	0.902	10.198 0.914
1.720	0.791	12.099	0.908	12.099 0.826
1.945	0.805	13.530	0.908	13.530 0.830
2.240	0.827	14.375	0.917	14.375 0.860
4.824	0.875	CURVE 5		
7.780	0.906	$T = 293.$		
10.198	0.909	1.009	0.577	1.0198 0.957
12.099	0.928	1.120	0.572	12.099 0.965
13.530	0.934	1.345	0.586	13.530 0.963
14.375	0.932	1.720	0.508	14.375 0.962
CURVE 3				
$T = 293.$				
1.009	0.320	2.240	0.656	7.780 0.750
1.120	0.349	4.824	0.824	10.198 0.809
1.345	0.422	12.099	0.821	12.099 0.778
1.720	0.531	13.530	0.827	13.530 0.842
1.945	0.577	14.375	0.842	14.375 0.848
2.240	0.675			
4.824	0.818			

d. Normal Spectral Transmittance (Wavelength Dependence)

There are 26 sets of experimental data available for the wavelength dependence of the normal spectral reflectance of silicone resin as listed in Table 19-9 and shown in Figure 19-6 (bulk materials) and Figure 19-7 (thin films). Specimen characterization and measurement information for the data are given in Table 19-8. There were 22 different kinds of silicone resins used for measurement; their transmittance values were quite different. Therefore, only provisional values are reported here which are listed in Table 19-7 and shown in Figure 19-5. The provisional values are for Dow Corning XR6-2044 silicone resin with thickness 0.112 mm at 293 K. The estimated uncertainty is about $\pm 30\%$.

TABLE 19-12. PROVISIONAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ
DC XR6-2044 0.112 MM THICK $T = 293$	
0.36	0.34
0.40	0.36
0.50	0.58
0.73	0.89
1.00	0.90
1.25	0.98
1.35	0.69
1.43	0.37
1.45	0.68
1.50	0.59
1.60	0.39
1.62	0.38
1.64	0.71
1.55	0.55
1.68	0.40
1.70	0.35
1.71	0.33
1.74	0.66
1.76	0.63
1.78	0.72
1.80	0.77
1.83	0.80
1.85	0.84
1.90	0.85
2.00	0.86
2.15	0.86






FIGURE 19-8. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICONE RESIN (WAVELENGTH DEPENDENCE).




FIGURE 19-9. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICONE RESIN COATINGS (WAVELENGTH DEPENDENCE).

TABLE 19-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICONE RESINS (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T19816	Wituchi, R. M., and Lewis, A. E.	1961	0.3-2.1	293	XR6-2044 Resin (Dow Corning)	0.046 in. thick with no substrate; curve not corrected for reflection losses; measurements on Dow Corning 805 and Dow Corning 4000 resins showed all to be very similar; $\theta \sim 0^\circ$.
2 T24833	Cowling, J. E., Alexander, A. V., Noonan, F. V., Kagariis, H., and Stokes, S.	1960	2-15	293	Phenyl Silicone Resin Film	Film-forming polymers in a vacuum of approx. 10^{-4} mm pressure; $\theta \sim 0^\circ$.
3 T24833	Cowling, J. E., et al.	1960	2-15	293	Phenyl Silicone Resin Film	Similar to the above specimen except film was exposed to mercury vapor lamp 80 hr (11.3 mW/cm ² at 10 cm).
4 T24833	Cowling, J. E., et al.	1960	2-15	293	Phenyl Silicone Resin Film	Similar to the above specimen except film was exposed to mercury vapor lamp 250 hr.
5 T35546	Zerlaut, G. A.	1960	5.5-14	293	Dow Corning 808	No thickness or details given; $\theta \sim 0^\circ$.
6 T40338	Acitelli, M. A., and Gamby, W. L., and Nujokas, A. A.	1966	0.2-2.2	296	Glass Resin 100	6.67 mm thick disc approx. 50 mm in diameter; specimen was obtained from Owens-Illinois; Cary spectrophotometer was used for measurements; $\theta \sim 0^\circ$.
7 T40338	Acitelli, M. A., et al.	1966	0.2-2.2	296	Glass Resin 100 "CR 39"	Similar to the above specimen except 6.76 mm thick.
8 T51317	Chukio, A. A., Pavlik, G. E., Tertykh, V. A., Chukio, E. A., Artenov, V. A., Neimark, I. E., and Tsipenyuk, E. V.	1966	2.7-5.5	295	Carboxyorganosilica	Powder specimen; $\theta \sim 0^\circ$.
9 T51594	Story, J. G.	1961	2-15	296	Silicone	No thickness was given; $\theta \sim 0^\circ$.
10 T61459	Williams, J. G., and Judd, J. H.	1971	0.23-2.5	293	Silicone 1	3.064 mm thick; 100 dimethyl silicone rubber RTV 615 part A and 10 RTV 615 part B; the specimen was cast, cured 2 hr at 71 C; $\theta \sim 0^\circ$.
11 T61459	Williams, J. G., and Judd, J. H.	1971	0.23-2.5	293	Silicone 2	2.976 mm thick; 100 dimethyl silicone rubber Sylgard 184 part A and 10 Sylgard 184 part B; the specimen was cast, cured 2 hr at 71 C; $\theta \sim 0^\circ$.
12 T76798	Lara, M. O.	1967	2.5-25	~293	Silastic 916 (Dow Corning Co.)	The specimen was condensed pyrolytate on potassium bromide or sodium chloride; a Beckman IR-9 double beamed, prism-grating infrared spectrophotometer was used to obtain the spectra; data were extracted from figure; $\theta \sim 0^\circ$.
13 T76798	Lara, M. O.	1967	2.5-25	~293	Silastic 6526 (Dow Corning Co.)	Similar to the above specimen.
14 T76798	Lara, M. O.	1967	2.5-25	~293	Silicone Rubber Heat Shrinkable (Dow Corning Co.)	Similar to the above specimen.
15 T76798	Lara, M. O.	1967	2.5-25	~293	5542 Silicone Finish Aluminum Silicone (Dutch Boy)	Similar to the above specimen.
16 T45212	Schmidt, R. N.	1967	1-10	~293	Dow Corning Silicone 901	0.014 in. thick (356 μ); not baked; data were extracted from figure; $\theta \sim 0^\circ$.

TABLE 19-11. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL TRANSMITTANCE OF SILICONE RESINS (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
17 T45212	17	Schmidt, R. N.	1967	1-10	~293	Dow Corning Silicone 991	Similar to the above specimen except it was baked at 600 F.
18 T45212	18	Schmidt, R. N.	1967	1-10	~293	General Electric Silicone PT	0.003 in. thick specimen after 600 F bake; data were extracted from figure; $\theta \sim 0^\circ$.
19 T45212	19	Schmidt, R. N.	1967	1-10	~293	General Electric Silicone 120	0.0175 in. thick specimen after 600 F bake; data were extracted from figure; $\theta \sim 0^\circ$.
20 T76812	20	Kagarise, R. E. and Weinberger, L. A.	1954	2-15	~293	Silicone Resin 4746-26A	The specimen was obtained from Linde Air Products; it was dissolved in C ₄ H ₈ and the resulting viscous solution was spread uniformly on rock salt or KBr plate; the solvent was removed by heating in vacuum or normal evaporation at room temperature; a Perkin-Elmer spectrophotometer was used in measurement; data were extracted from figure; $\theta \sim 0^\circ$.
21 T76812	21	Kagarise, R. E. and Weinberger, L. A.	1954	2-15	~293	Silicone Resin 173-8-211	Similar to the above specimen except obtained from General Electric Co.
22 T76812	22	Kagarise, R. E. and Weinberger, L. A.	1954	2-15	~293	Dow Corning 1107	Similar to the above specimen except obtained from Dow Corning Co.
23 T66915	23	Jayme, G. and Traser, G.	1972	2.5-25	~293	Silicone Resin	The transmittance spectra was obtained by using FMIR technique (multiple reflection); data were extracted from figure; $\theta \sim 0^\circ$.
24 T66915	24	Jayme, G. and Traser, G.	1972	2.5-25	~293	Silicone coated paper	Similar to the above specimen.
25 T77141	25	Tkachuk, B. V., Perova, L. V., and Kololyadkin, V. M. et al.	1971	3-12	~293	HMDS film	Hexamethylsiloxane film about 0.5-2 μm thick was prepared in a silence discharge; $\theta \sim 0^\circ$.
26 T77141	26	Tkachuk, B. V.,	1971	3-12	~293	HMDS film	Similar to the above specimen except it was irradiated by 400 Mrad dose γ -ray.

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 1 $T = 293$.	CURVE 1 (CONT.)		CURVE 2 (CONT.)		CURVE 2 (CONT.)		CURVE 3 (CONT.)		
			λ	τ	λ	τ	λ	τ	λ	τ	
0.300	0.841	1.0827	3.801	5.16	0.975	6.17	0.712	1.407	0.278	5.10	0.005
0.324	0.820	1.0843	0.819	5.23	0.902	8.32	0.490	1.424	0.114	5.19	0.818
0.367	0.860	1.0864	0.836	5.28	0.940	8.32	0.442	1.428	0.082	5.25	0.793
0.442	0.666	1.0893	0.849	5.34	0.755	8.41	0.361	1.433	0.072	5.35	0.811
0.480	0.873	1.0926	0.854	5.44	0.898	8.54	0.095	1.441	0.107	5.47	0.777
0.506	0.881	1.0957	0.859	5.48	0.932	8.63	0.045	1.452	0.501	5.54	0.777
0.537	0.890	1.0981	0.854	5.55	0.945	8.76	0.07	1.460	0.568	5.71	0.718
0.659	0.890	1.0981	0.853	5.61	0.920	9.82	0.007	1.466	0.583	5.81	0.665
0.819	0.900	1.0981	0.845	5.73	0.945	9.93	0.047	1.480	0.601	5.97	0.715
1.112	0.903	1.112	0.889	6.01	0.916	10.00	0.098	15.00	0.678	6.10	0.677
1.126	0.889	6.09	0.937	10.11	0.412	6.40	0.768	6.49	0.797	6.55	0.797
1.135	0.854	6.20	0.900	10.16	0.527	6.55	0.797	6.71	0.769	6.80	0.769
1.147	0.834	6.24	0.605	10.28	0.640	6.71	0.770	6.92	0.743	6.99	0.291
1.182	0.863	6.27	0.668	10.33	0.716	1.05	0.755	2.00	0.755	2.16	0.770
1.225	0.869	6.21	0.959	5.31	0.897	10.49	0.778	10.58	0.791	10.74	0.799
1.263	0.901	2.29	0.970	6.44	0.923	10.54	0.799	10.74	0.770	10.86	0.630
1.309	0.991	2.36	0.970	6.49	0.940	10.86	0.779	10.93	0.746	11.00	0.631
1.342	0.891	2.45	0.956	6.60	0.943	11.00	0.779	11.15	0.816	11.25	0.700
1.378	0.872	2.53	0.973	6.68	0.865	11.00	0.816	11.21	0.608	11.36	0.700
1.409	0.867	2.62	0.973	6.71	0.917	11.15	0.816	11.31	0.897	11.49	0.723
1.446	0.882	2.74	0.933	6.76	0.936	11.31	0.801	11.36	0.92	11.36	0.743
1.479	0.891	2.81	0.973	6.89	0.906	11.47	0.737	11.47	0.326	11.53	0.713
1.610	0.891	2.95	0.984	6.94	0.820	11.59	0.631	11.64	0.364	11.73	0.674
1.617	0.882	3.12	0.994	6.99	0.291	11.77	0.482	11.77	0.412	11.86	0.674
1.637	0.710	3.20	0.949	7.01	0.767	12.07	0.328	12.07	0.455	12.13	0.633
1.653	0.577	3.24	0.687	7.08	0.755	12.23	0.252	12.23	0.433	12.31	0.239
1.665	0.480	3.27	0.659	7.15	0.869	12.35	0.138	12.35	0.510	12.46	0.090
1.682	0.400	3.29	0.696	7.22	0.899	12.58	0.069	12.58	0.497	12.69	0.121
1.703	0.350	3.32	0.710	7.33	0.922	12.72	0.042	12.72	0.586	12.77	0.498
1.711	0.377	3.32	0.753	7.40	0.922	12.93	0.054	12.93	0.670	13.05	0.515
1.739	0.656	3.38	0.711	7.53	0.837	13.14	0.106	13.14	0.740	13.22	0.346
1.745	0.672	3.38	0.844	7.59	0.847	13.25	0.152	13.25	0.769	13.33	0.187
1.753	0.663	3.43	0.900	7.62	0.816	13.31	0.212	13.31	0.769	13.40	0.124
1.755	0.645	3.51	0.953	7.70	0.824	13.38	0.234	13.38	0.606	13.51	0.045
1.762	0.635	3.62	0.982	7.75	0.714	13.48	0.171	13.48	0.805	13.66	0.007
1.770	0.657	4.13	0.994	7.84	0.090	13.61	0.677	13.61	0.559	13.69	0.027
1.780	0.702	4.97	0.994	7.90	0.121	13.72	0.104	13.72	0.796	13.92	0.025
1.796	0.745	5.05	0.944	7.99	0.700	13.76	0.185	13.76	0.827	13.89	0.065
1.809	0.774	5.10	0.975	8.98	0.741	14.00	0.223	14.00	0.828	14.09	0.191

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ)

λ	τ	CURVE 3 (CONT.)	λ	τ	CURVE 4 (CONT.)	λ	τ	CURVE 4 (CONT.)	λ	τ	CURVE 5 (CONT.)	λ	τ	CURVE 5 (CONT.)
10.17	0.275	2.90	0.265	9.74	0.077	6.12	0.765	7.00	0.635	7.99	0.101			
10.26	0.305	2.95	0.251	9.99	0.112	6.12	0.714	7.04	0.663	8.08	0.104			
10.37	0.305	3.07	0.251	10.16	0.157	6.16	0.714	7.06	0.652	8.11	0.129			
10.58	0.259	3.24	0.319	10.27	0.157	6.16	0.614	7.06	0.625	8.13	0.157			
10.75	0.235	3.47	0.419	10.56	0.116	6.19	0.597	7.10	0.655	8.16	0.183			
10.96	0.235	3.57	0.474	10.70	0.104	6.20	0.426	7.15	0.668	8.18	0.228			
11.19	0.284	3.70	0.505	10.89	0.104	6.24	0.383	7.19	0.658	8.21	0.277			
11.35	0.367	4.03	0.522	11.09	0.135	6.27	0.412	7.23	0.641	8.22	0.327			
11.46	0.394	4.37	0.515	11.33	0.174	6.28	0.609	7.25	0.625	8.26	0.368			
11.56	0.394	4.74	0.468	11.49	0.208	6.28	0.630	7.26	0.605	8.26	0.491			
11.92	0.263	4.95	0.488	11.65	0.208	6.31	0.641	7.26	0.620	8.28	0.511			
12.37	0.136	5.28	0.465	11.77	0.192	6.33	0.627	7.29	0.642	8.32	0.496			
12.73	0.074	5.49	0.454	11.95	0.154	6.33	0.576	7.32	0.670	8.32	0.458			
12.83	0.057	5.80	0.378	12.31	0.150	6.39	0.586	7.36	0.650	8.34	0.457			
13.01	0.095	5.95	0.401	12.47	0.104	6.39	0.755	7.36	0.620	8.35	0.425			
13.22	0.163	6.09	0.373	12.73	0.099	6.45	0.784	7.37	0.572	8.35	0.360			
13.37	0.221	6.26	0.399	12.90	0.099	6.49	0.756	7.38	0.602	8.38	0.329			
13.50	0.196	6.26	0.417	13.04	0.119	6.50	0.602	7.41	0.627	8.39	0.268			
13.61	0.154	6.39	0.436	13.50	0.177	6.55	0.602	7.41	0.676	8.40	0.225			
13.89	0.206	5.60	0.460	13.72	0.177	6.55	0.499	7.46	0.658	8.40	0.186			
14.02	0.222	6.07	0.460	13.80	0.253	6.56	0.453	7.51	0.634	8.42	0.164			
14.20	0.245	6.96	0.445	13.95	0.268	6.56	0.189	7.55	0.613	8.47	0.193			
14.32	0.136	6.26	0.417	13.04	0.119	6.60	0.303	7.59	0.579	8.49	0.232			
14.41	0.179	7.00	0.412	14.23	0.227	6.62	0.192	7.62	0.546	8.49	0.328			
14.49	0.405	7.03	0.403	14.39	0.197	6.62	0.316	7.64	0.520	8.49	0.439			
14.54	0.465	7.19	0.453	14.50	0.247	6.67	0.316	7.66	0.466	8.51	0.457			
14.85	0.481	7.29	0.467	14.59	0.275	6.67	0.388	7.66	0.424	8.54	0.495			
14.97	0.518	7.37	0.467	14.76	0.291	6.69	0.451	7.68	0.397	8.59	0.464			
		7.47	0.479	14.94	0.301	6.70	0.502	7.70	0.381	8.62	0.435			
		7.63	0.479	15.22	0.305	6.75	0.537	7.71	0.347	8.64	0.406			
		7.73	0.451	15.22	0.305	6.80	0.516	7.74	0.381	8.68	0.378			
		7.83	0.293	15.22	0.305	6.80	0.462	7.76	0.431	8.71	0.344			
		7.91	0.292	15.22	0.305	6.84	0.433	7.78	0.481	8.71	0.316			
		8.00	0.315	15.22	0.305	6.90	0.452	7.81	0.446	8.73	0.287			
		8.06	0.263	15.22	0.305	6.94	0.545	7.84	0.399	8.73	0.243			
		8.16	0.167	15.22	0.305	6.95	0.578	7.85	0.353	8.75	0.222			
		8.31	0.129	15.22	0.305	6.97	0.835	7.87	0.256	8.80	0.212			
		8.67	0.088	15.22	0.305	6.98	0.839	7.87	0.215	8.86	0.206			
		8.99	0.062	15.22	0.305	7.00	0.821	7.90	0.183	8.93	0.210			
		9.42	0.077	15.22	0.305	7.00	0.803	7.93	0.130	8.94	0.221			
CURVE 5 $T = 293$														
1.85	0.554	7.91	0.292	15.22	0.305	6.84	0.433	7.78	0.481	8.71	0.316			
1.97	0.551	8.00	0.315	15.22	0.305	6.90	0.452	7.81	0.446	8.73	0.287			
2.05	0.540	8.06	0.263	15.22	0.305	6.94	0.545	7.84	0.399	8.73	0.243			
2.39	0.549	8.16	0.167	15.22	0.305	6.95	0.578	7.85	0.353	8.75	0.222			
2.52	0.554	8.31	0.129	15.22	0.305	6.97	0.835	7.87	0.256	8.80	0.212			
2.64	0.554	8.67	0.088	15.22	0.305	6.98	0.839	7.87	0.215	8.86	0.206			
2.72	0.512	8.99	0.062	15.22	0.305	7.00	0.821	7.90	0.183	8.93	0.210			
2.72	0.406	9.42	0.077	15.22	0.305	7.00	0.803	7.93	0.130	8.94	0.221			

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T ; K; TRANSMITTANCE, τ)

λ	τ	CURVE 5 (CONT.)	λ	τ	CURVE 5 (CONT.)	λ	τ	CURVE 6 (CONT.)	λ	τ	CURVE 6 (CONT.)	λ	τ	CURVE 6 (CONT.)
8.98	0.227	10.97	0.653	13.39	0.549	1.192	0.622	1.692	0.024	2.163	0.019			
9.05	0.233	11.08	0.670	13.45	0.514	1.232	0.622	1.702	0.099	2.177	0.030			
9.18	0.231	11.19	0.660	13.53	0.480	1.211	0.656	1.713	0.178	2.187	0.017			
9.27	0.231	11.29	0.665	13.63	0.518	1.224	0.676	1.726	0.099	2.199	0.013			
9.36	0.232	11.39	0.699	13.69	0.554	1.254	0.676	1.735	0.075					
9.43	0.220	11.47	0.688	13.73	0.592	1.262	0.667	1.744	0.103					
9.49	0.184	11.52	0.672	13.79	0.623	1.271	0.689	1.753	0.212					
9.55	0.162	11.56	0.649	13.88	0.642	1.285	0.675	1.758	0.254					
9.59	0.155	11.58	0.615	13.96	0.655	1.306	0.675	1.770	0.218					
9.67	0.172	11.63	0.584	13.99	0.655	1.324	0.688	1.776	0.297					
9.70	0.193	11.65	0.539	11.79	0.489	1.347	0.751	1.777	0.365					
9.74	0.221	11.77	0.438	11.76	0.438	1.356	0.719	1.793	0.401					
9.77	0.235	11.80	0.372	11.80	0.372	1.356	0.662	1.801	0.396					
9.75	0.256	11.84	0.294	11.84	0.294	1.368	0.654	1.808	0.410					
9.80	0.275	11.88	0.232	11.88	0.232	1.374	0.601	1.815	0.397					
9.80	0.306	11.91	0.200	11.89	0.200	1.392	0.423	1.822	0.359					
9.91	0.308	11.92	0.180	11.90	0.180	1.397	0.380	1.832	0.392					
9.92	0.308	11.96	0.165	11.95	0.165	1.397	0.384	1.837	0.355					
9.92	0.357	12.02	0.161	12.02	0.161	1.408	0.377	1.847	0.410					
9.93	0.390	12.06	0.159	12.06	0.159	1.426	0.458	1.869	0.497					
9.96	0.424	12.09	0.203	12.09	0.203	1.442	0.528	1.880	0.473					
9.99	0.443	12.12	0.238	12.12	0.238	1.452	0.543	1.893	0.456					
10.05	0.443	12.12	0.264	12.15	0.265	1.470	0.543	1.893	0.456					
10.09	0.463	12.15	0.265	12.15	0.265	1.504	0.528	1.897	0.304					
10.12	0.507	12.16	0.314	12.16	0.314	1.525	0.498	1.904	0.286					
10.14	0.538	12.16	0.345	12.16	0.345	1.546	0.527	1.919	0.370					
10.15	0.570	12.21	0.367	12.21	0.367	1.562	0.541	1.935	0.365					
10.20	0.592	12.21	0.396	12.21	0.396	1.582	0.541	1.951	0.389					
10.25	0.616	12.25	0.416	12.25	0.416	1.601	0.525	1.961	0.408					
10.30	0.637	12.29	0.421	12.29	0.421	1.614	0.467	1.973	0.405					
10.38	0.649	12.36	0.415	12.36	0.415	1.617	0.407	1.983	0.378					
10.56	0.649	12.41	0.406	12.41	0.406	1.618	0.392	1.984	0.349					
10.59	0.643	12.50	0.422	12.50	0.422	1.625	0.393	1.985	0.319					
10.63	0.634	12.57	0.453	12.57	0.453	1.632	0.386	1.991	0.304					
10.66	0.648	12.58	0.496	12.58	0.496	1.638	0.326	1.993	0.262					
10.70	0.660	12.66	0.514	12.66	0.514	1.642	0.246	2.019	0.217					
10.74	0.674	12.79	0.515	12.79	0.515	1.651	0.261	2.015	0.223					
10.79	0.663	12.91	0.506	12.91	0.506	1.662	0.262	2.016	0.223					
10.84	0.645	13.07	0.531	13.07	0.531	1.668	0.12	2.019	0.026					
10.88	0.640	13.30	0.506	13.30	0.506	1.679	0.696	2.019	0.012					

CURVE 7
 $T = 296$.CURVE 6
 $T = 296$.

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	τ	CURVE 10 (CONT.)		CURVE 10 (CONT.)		CURVE 11		CURVE 11 (CONT.)		CURVE 11 (CONT.)		CURVE 12 (CONT.)	
λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
0.689	0.915	1.652	0.764	1.652	0.240	1.040	0.940	1.712	0.604	2.64	0.932		
0.735	0.910	1.663	0.205	1.663	0.000	1.086	0.935	1.750	0.098	2.70	0.926		
0.776	0.910	1.675	0.088	1.675	0.013	1.132	0.937	1.750	0.519	2.78	0.922		
0.822	0.916	1.687	0.078	1.687	0.040	1.146	0.932	1.762	0.574	2.93	0.922		
0.857	0.920	1.694	0.096	1.694	0.050	1.153	0.846	1.786	0.452	2.95	0.934		
0.893	0.921	1.694	0.551	1.694	0.049	1.161	0.660	1.795	0.841	2.97	0.916		
0.910	0.897	1.706	0.543	1.706	0.010	1.180	0.567	1.811	0.546	3.00	0.913		
0.920	0.911	1.714	0.604	1.714	0.000	1.191	0.597	1.811	0.621	3.03	0.918		
0.940	0.922	1.750	0.519	1.750	0.013	1.205	0.880	1.841	0.560	3.17	0.918		
0.991	0.928	1.750	0.098	1.750	0.039	1.222	0.890	1.858	0.858	3.20	0.908		
1.030	0.916	1.762	0.574	1.762	0.056	1.227	0.917	1.888	0.648	3.25	0.908		
1.054	0.926	1.786	0.452	1.786	0.060	1.247	0.914	1.914	0.618	3.27	0.890		
1.081	0.933	1.795	0.841	1.795	0.050	1.274	0.935	1.932	0.810	3.30	0.900		
1.114	0.933	1.811	0.821	1.811	0.050	1.306	0.918	1.945	0.771	3.34	0.877		
1.140	0.920	1.811	0.546	1.811	0.062	1.324	0.931	1.972	0.747	3.36	0.740		
1.146	0.866	1.841	0.560	1.841	0.133	1.340	0.931	1.986	0.778	3.37	0.578		
1.153	0.848	1.658	0.858	1.658	0.251	1.349	0.913	2.004	0.768	3.39	0.735		
1.16	0.860	1.808	0.848	1.808	0.323	1.355	0.870	2.023	0.806	3.41	0.650		
1.180	0.567	1.914	0.818	1.914	0.360	1.352	0.742	2.037	0.772	3.45	0.250		
1.191	0.597	1.932	0.010	1.932	0.360	1.381	0.813	1.390	0.749	2.064	0.826		
1.205	0.863	1.945	0.771	1.945	0.370	1.403	0.841	1.403	0.638	2.109	0.792		
1.222	0.890	1.972	0.747	1.972	0.382	1.416	0.855	1.416	0.703	2.133	0.575		
1.247	0.998	1.986	0.778	1.986	0.391	1.435	0.864	1.435	0.847	2.193	0.226		
1.262	0.983	2.004	0.768	2.004	0.404	1.454	0.876	1.454	0.880	2.208	0.664		
1.285	0.382	2.023	0.806	2.023	0.417	1.476	0.882	1.476	0.872	2.223	0.037		
1.312	0.891	2.037	0.772	2.037	0.435	1.500	0.890	1.500	0.872	2.223	0.014		
1.355	0.870	2.064	0.826	2.064	0.459	1.517	0.897	1.517	0.833	2.275	0.355		
1.358	0.742	2.105	0.792	2.105	0.484	1.542	0.903	1.542	0.820	2.323	0.152		
1.390	0.741	2.133	0.575	2.133	0.512	1.563	0.904	1.563	0.652	2.366	0.082		
1.403	0.632	2.153	0.614	2.153	0.548	1.585	0.906	1.585	0.808	2.399	0.034		
1.416	0.703	2.265	0.000	2.265	0.600	1.600	0.906	1.600	0.906	2.421	0.162		
1.531	0.814	2.421	0.182	2.421	0.647	1.611	0.918	1.611	0.906	2.438	0.023		
1.563	0.852	2.436	0.023	2.436	0.684	1.618	0.912	1.675	0.088	4.32	0.938		
1.585	0.871	2.344	0.000	2.344	0.512	1.618	0.924	1.687	0.078	4.38	0.950		
1.500	0.957	2.355	0.082	2.355	0.782	1.637	0.924	1.637	0.772	2.472	0.087		
1.510	0.624	2.399	0.034	2.399	0.826	1.652	0.764	1.652	0.27	0.955	0.55		
1.531	0.814	2.421	0.182	2.421	0.904	1.663	0.925	1.663	0.205	4.63	0.948		
1.563	0.852	2.436	0.023	2.436	0.912	1.675	0.908	1.675	0.088	4.81	0.945		
1.585	0.858	2.455	0.062	2.455	0.936	1.687	0.978	1.687	0.078	5.00	0.954		
1.618	0.837	2.472	0.087	2.472	0.959	1.694	0.937	1.694	0.096	5.10	0.950		
1.637	0.777	2.472	0.007	2.472	0.907	1.703	0.543	2.59	0.938	5.19	0.945		
												CURVE 12	T = 293.

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 12 (CONT.)			CURVE 12 (CONT.)			CURVE 12 (CONT.)			CURVE 13 (CONT.)			CURVE 13 (CONT.)			CURVE 13 (CONT.)			
λ	T	λ	λ	T	λ	λ	T	λ	λ	T	λ	λ	T	λ	λ	T		
5.23	0.961	9.17	0.256	21.23	0.662	4.02	0.898	7.62	0.891	14.39	0.660	7.71	0.719	14.64	0.683	14.73	0.725	
5.30	0.954	9.33	0.291	22.68	0.728	4.07	0.904	7.71	0.719	14.64	0.683	7.79	0.546	14.73	0.725	14.73	0.725	
5.34	0.963	9.51	0.303	23.53	0.648	4.16	0.904	7.85	0.203	15.11	0.725	7.91	0.087	15.24	0.800	15.46	0.815	
5.38	0.957	9.63	0.265	25.00	0.621	4.27	0.865	7.91	0.205	15.46	0.815	8.02	0.659	15.80	0.815	15.80	0.815	
5.44	0.966	9.74	0.242	CURVE 13 $T = 293.$			4.35	0.903	7.96	0.205	15.80	0.815	8.10	0.761	16.03	0.794	16.69	0.833
5.47	0.944	9.82	0.290	CURVE 13 $T = 293.$			4.81	0.903	7.96	0.205	16.03	0.794	8.15	0.798	16.69	0.833	17.51	0.833
5.52	0.952	9.95	0.572	CURVE 13 $T = 293.$			4.89	0.891	8.02	0.659	16.03	0.794	8.25	0.813	16.69	0.833	17.51	0.833
5.66	0.352	10.16	0.742	CURVE 13 (CONT.)			4.96	0.910	8.10	0.761	16.69	0.833	8.25	0.813	16.69	0.833	17.51	0.833
5.66	0.928	10.42	0.826	CURVE 13 (CONT.)			5.00	0.899	8.15	0.798	16.69	0.833	8.25	0.813	16.69	0.833	17.51	0.833
5.92	0.940	10.62	0.842	CURVE 13 (CONT.)			5.03	0.906	8.25	0.813	16.69	0.833	8.39	0.795	16.25	0.822	16.25	0.822
6.23	0.935	11.00	0.798	CURVE 13 (CONT.)			5.07	0.900	8.39	0.669	16.25	0.822	8.57	0.669	16.25	0.822	16.25	0.822
6.26	0.913	11.15	0.759	CURVE 13 (CONT.)			5.12	0.863	8.57	0.669	16.25	0.822	8.71	0.501	20.75	0.75	20.75	0.75
6.31	0.939	11.33	0.654	CURVE 13 (CONT.)			5.19	0.903	8.71	0.501	20.75	0.75	8.71	0.501	20.75	0.75	20.75	0.75
5.41	0.979	11.43	0.696	CURVE 13 (CONT.)			2.71	0.888	5.23	0.892	8.86	0.226	21.46	0.853	21.46	0.853	21.46	0.853
6.53	0.950	11.56	0.591	CURVE 13 (CONT.)			2.74	0.895	5.27	0.904	8.97	0.128	22.22	0.828	22.22	0.828	22.22	0.828
6.67	0.940	11.75	0.614	CURVE 13 (CONT.)			2.85	0.892	5.42	0.911	9.11	0.083	23.98	0.597	23.98	0.597	23.98	0.597
6.78	0.940	11.92	0.542	CURVE 13 (CONT.)			2.95	0.886	5.56	0.898	9.23	0.983	25.00	0.534	25.00	0.534	25.00	0.534
6.94	0.902	12.08	0.298	CURVE 13 (CONT.)			3.02	0.880	5.61	0.682	9.42	0.105	9.42	0.105	9.42	0.105	9.42	0.105
7.02	0.865	12.36	0.212	CURVE 13 (CONT.)			3.09	0.880	5.72	0.882	9.63	0.105	9.63	0.105	9.63	0.105	9.63	0.105
7.06	0.831	12.52	0.334	CURVE 13 (CONT.)			3.13	0.868	5.79	0.797	9.77	0.095	9.77	0.095	9.77	0.095	9.77	0.095
7.12	0.852	12.77	0.605	CURVE 13 (CONT.)			3.16	0.877	5.94	0.799	9.91	0.179	9.91	0.179	9.91	0.179	9.91	0.179
7.15	0.900	12.92	0.666	CURVE 13 (CONT.)			3.24	0.846	5.92	0.761	10.17	0.602	10.17	0.602	10.17	0.602	10.17	0.602
7.22	0.932	12.92	0.693	CURVE 13 (CONT.)			3.26	0.818	5.97	0.845	10.35	0.713	10.35	0.713	10.35	0.713	10.35	0.713
7.37	0.949	13.14	0.735	CURVE 13 (CONT.)			3.27	0.818	6.05	0.861	10.57	0.754	10.57	0.754	10.57	0.754	10.57	0.754
7.51	0.949	13.33	0.737	CURVE 13 (CONT.)			3.30	0.835	6.13	0.869	10.61	0.754	10.61	0.754	10.61	0.754	10.61	0.754
7.64	0.922	13.50	0.702	CURVE 13 (CONT.)			3.34	0.791	6.29	0.845	10.71	0.713	10.71	0.713	10.71	0.713	10.71	0.713
7.72	0.881	13.61	0.776	CURVE 13 (CONT.)			3.36	0.598	6.36	0.836	11.21	0.650	11.21	0.650	11.21	0.650	11.21	0.650
7.76	0.819	13.79	0.794	CURVE 13 (CONT.)			3.38	0.338	6.50	0.876	11.40	0.500	11.40	0.500	11.40	0.500	11.40	0.500
7.92	0.495	14.14	0.681	CURVE 13 (CONT.)			3.40	0.643	6.67	0.876	11.64	0.426	11.64	0.426	11.64	0.426	11.64	0.426
7.98	0.283	14.35	0.780	CURVE 13 (CONT.)			3.43	0.660	6.79	0.855	11.81	0.457	11.81	0.457	11.81	0.457	11.81	0.457
7.96	0.654	14.99	0.814	CURVE 13 (CONT.)			3.45	0.882	6.94	0.799	12.11	0.166	12.11	0.166	12.11	0.166	12.11	0.166
7.99	0.796	15.04	0.869	CURVE 13 (CONT.)			3.46	0.763	6.98	0.739	12.41	0.066	12.41	0.066	12.41	0.066	12.41	0.066
8.05	0.671	15.60	0.873	CURVE 13 (CONT.)			3.52	0.793	7.03	0.774	12.53	0.091	12.53	0.091	12.53	0.091	12.53	0.091
8.18	0.908	15.82	0.860	CURVE 13 (CONT.)			3.54	0.854	7.07	0.704	12.85	0.498	12.85	0.498	12.85	0.498	12.85	0.498
8.34	0.885	16.47	0.889	CURVE 13 (CONT.)			3.60	0.873	7.14	0.733	13.09	0.615	13.09	0.615	13.09	0.615	13.09	0.615
8.49	0.813	17.76	0.889	CURVE 13 (CONT.)			3.65	0.896	7.17	0.806	13.42	0.662	13.42	0.662	13.42	0.662	13.42	0.662
8.51	0.715	18.69	0.901	CURVE 13 (CONT.)			3.68	0.876	7.26	0.832	13.62	0.594	13.62	0.594	13.62	0.594	13.62	0.594
8.73	0.595	19.27	0.866	CURVE 13 (CONT.)			3.71	0.904	7.32	0.859	13.87	0.730	13.87	0.730	13.87	0.730	13.87	0.730
8.82	0.442	19.76	0.886	CURVE 13 (CONT.)			3.77	0.881	7.42	0.859	14.08	0.598	14.08	0.598	14.08	0.598	14.08	0.598
8.93	0.299	20.24	0.836	CURVE 13 (CONT.)			3.84	0.898	7.53	0.832	14.22	0.544	14.22	0.544	14.22	0.544	14.22	0.544

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELLENGTH DEPENDENCE) (CONTINUED)

CURVE 14 (CONT.)				CURVE 14 (CONT.)				CURVE 15 (CONT.)				CURVE 15 (CONT.)			
λ	τ	λ	τ												
3.38	0.455	5.92	0.908	9.72	0.162	22.73	0.748	4.57	0.973	6.30	0.838	5.92	0.908	9.72	0.162
3.40	0.758	6.05	0.908	9.80	0.188	23.42	0.666	5.00	0.974	6.41	0.765	6.05	0.908	9.80	0.188
3.42	0.784	6.17	0.886	10.07	0.567	23.70	0.599	5.11	0.945	6.50	0.708	6.17	0.886	10.07	0.567
3.45	0.770	6.20	0.868	10.31	0.732	24.21	0.599	5.19	0.973	6.70	0.342	6.20	0.868	10.31	0.732
3.46	0.834	6.26	0.809	10.45	0.756	25.00	0.595	5.32	0.950	6.77	0.232	6.26	0.809	10.45	0.756
3.47	0.968	6.29	0.667	10.65	0.695	25.00	0.595	5.36	0.970	6.77	0.176	6.29	0.667	10.65	0.695
3.50	0.882	6.37	0.896	10.79	0.711	25.00	0.595	5.42	0.970	6.90	0.156	6.37	0.896	10.79	0.711
3.54	0.909	6.52	0.910	10.94	0.650	25.00	0.595	5.51	0.939	6.99	0.171	6.52	0.910	10.94	0.650
3.57	0.909	6.63	0.910	11.12	0.662	25.00	0.595	5.59	0.963	6.99	0.160	6.63	0.910	11.12	0.662
3.61	0.940	6.67	0.879	11.30	0.560	25.00	0.595	5.65	0.944	9.46	0.156	6.67	0.879	11.30	0.560
3.65	0.940	6.76	0.879	11.75	0.418	25.00	0.595	5.69	0.956	9.61	0.267	6.76	0.879	11.75	0.418
3.66	0.931	6.90	0.812	11.96	0.342	25.00	0.595	5.87	0.924	9.82	0.203	6.90	0.812	11.96	0.342
3.71	0.941	6.93	0.812	12.14	0.257	25.00	0.595	5.93	0.948	9.96	0.228	6.93	0.812	12.14	0.257
3.74	0.921	6.97	0.695	12.36	0.148	25.00	0.595	6.06	0.938	10.13	0.601	6.97	0.695	12.36	0.148
3.76	0.943	7.01	0.781	12.56	0.208	25.00	0.595	6.13	0.937	10.24	0.761	7.01	0.781	12.56	0.208
4.02	0.943	7.06	0.715	12.99	0.567	25.00	0.595	6.23	0.926	10.37	0.819	7.06	0.715	12.99	0.567
4.15	0.956	7.13	0.750	13.21	0.630	25.00	0.595	6.28	0.788	10.66	0.866	7.13	0.750	13.21	0.630
4.22	0.922	7.19	0.813	13.40	0.623	25.00	0.595	6.31	0.910	10.87	0.877	7.19	0.813	13.40	0.623
4.24	0.935	7.24	0.798	13.62	0.645	25.00	0.595	6.39	0.947	11.26	0.877	7.24	0.798	13.62	0.645
4.28	0.925	7.26	0.837	13.79	0.595	25.00	0.595	6.53	0.957	11.43	0.851	7.26	0.837	13.79	0.595
4.33	0.947	7.43	0.680	14.01	0.595	25.00	0.595	6.70	0.946	11.72	0.687	7.43	0.680	14.01	0.595
4.42	0.942	7.55	0.651	14.22	0.580	25.00	0.595	6.73	0.697	11.82	0.655	7.55	0.651	14.22	0.580
4.46	0.930	7.68	0.806	14.45	0.691	25.00	0.595	6.73	0.923	11.57	0.672	7.68	0.806	14.45	0.691
4.55	0.944	7.76	0.752	14.66	0.734	25.00	0.595	6.78	0.933	12.18	0.656	7.76	0.752	14.66	0.734
4.59	0.906	7.84	0.483	14.97	0.701	25.00	0.595	6.86	0.865	12.42	0.380	7.84	0.483	14.97	0.701
4.74	0.935	7.91	3.195	15.11	0.758	25.00	0.595	6.92	0.911	12.59	0.404	7.91	3.195	15.11	0.758
4.98	0.946	7.99	3.589	15.36	0.765	25.00	0.595	6.96	0.902	12.72	0.395	7.99	3.589	15.36	0.765
5.00	0.947	8.05	0.768	15.53	0.751	25.00	0.595	7.03	0.518	12.99	0.502	8.05	0.768	15.53	0.751
5.07	0.942	8.17	0.810	15.65	0.795	25.00	0.595	7.03	0.840	13.40	0.616	8.17	0.810	15.65	0.795
5.13	0.920	8.30	0.810	16.05	0.893	25.00	0.595	7.06	0.861	13.66	0.444	8.30	0.810	16.05	0.893
5.26	0.938	8.42	0.758	16.29	0.835	25.00	0.595	7.14	0.631	13.85	0.596	8.42	0.758	16.29	0.835
5.29	0.928	8.49	3.717	16.95	0.816	25.00	0.595	7.19	0.863	14.03	0.662	8.49	3.717	16.95	0.816
5.32	0.948	8.66	0.580	17.33	0.794	25.00	0.595	7.33	0.936	14.35	0.403	8.66	0.580	17.33	0.794
5.35	0.955	8.74	0.355	13.45	0.511	25.00	0.595	7.43	0.946	14.56	0.822	8.74	0.355	13.45	0.511
5.42	0.944	8.80	0.361	18.94	0.572	25.00	0.595	7.58	0.902	14.99	0.859	8.80	0.361	18.94	0.572
5.46	0.926	8.99	0.213	19.42	0.602	25.00	0.595	7.63	0.833	15.34	0.897	8.99	0.213	19.42	0.602
5.62	0.926	9.07	0.180	19.96	0.776	25.00	0.595	7.87	0.460	16.42	0.869	9.07	0.180	19.96	0.776
5.73	0.900	9.27	0.163	20.62	0.767	25.00	0.595	7.94	0.385	16.42	0.887	9.27	0.163	20.62	0.767
5.80	0.983	9.50	0.190	21.01	0.740	25.00	0.595	8.05	0.954	16.98	0.671	9.50	0.190	21.01	0.740
5.87	0.987	9.59	0.173	21.98	0.797	25.00	0.595	8.16	0.984	17.51	0.690	9.59	0.173	21.98	0.797

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

λ	τ	CURVE 15(CONT.)		CURVE 17(CONT.)		CURVE 19 $T = 293.$		CURVE 20(CONT.)		CURVE 20(CONT.)	
18.45	0.857	2.50	0.678	3.60	0.936	8.26	0.757	11.22	0.899	8.26	0.757
18.94	0.835	2.99	0.539	1.00	0.787	3.80	0.950	11.50	0.919	6.37	0.649
20.16	0.785	3.51	0.452	1.49	0.847	4.40	0.950	11.67	0.934	8.47	0.76
20.62	0.511	4.01	0.631	1.98	0.653	4.97	0.940	8.54	0.351	12.01	0.934
21.23	0.584	4.52	0.669	2.49	0.707	5.12	0.946	8.62	0.262	12.31	0.925
21.46	0.696	5.01	0.450	2.99	0.505	5.24	0.932	8.72	0.194	12.41	0.910
22.03	0.721	5.49	0.236	3.49	0.453	5.43	0.932	8.81	0.154	12.50	0.868
23.20	0.692	6.00	0.131	3.95	0.605	5.50	0.924	8.86	0.132	12.57	0.805
24.33	0.644	6.51	0.106	4.47	0.655	5.74	0.937	8.93	0.132	12.66	0.758
25.00	0.670	6.99	0.059	5.00	0.529	6.13	0.937	9.01	0.173	12.76	0.723
CURVE 16 $T = 293.$		7.48	0.094	5.51	0.198	6.35	0.930	9.14	0.265	12.89	0.687
CURVE 17 $T = 293.$		8.02	0.020	6.00	0.077	6.41	0.943	9.21	0.306	13.01	0.654
1.01	0.895	8.46	0.004	6.47	0.097	6.57	0.943	9.30	0.325	13.15	0.586
1.47	0.857	9.01	0.000	6.99	0.021	6.66	0.932	9.38	0.296	13.25	0.533
2.30	0.897	9.49	0.000	7.49	0.021	6.72	0.893	9.47	0.245	13.35	0.514
2.49	0.679	10.00	0.000	7.99	0.009	6.78	0.785	9.56	0.227	13.49	0.576
3.46	0.416	1.00	0.787	8.49	0.006	6.81	0.707	9.62	0.255	13.68	0.688
3.98	0.648	1.49	0.847	8.97	0.000	6.84	0.764	9.71	0.326	13.75	0.737
4.52	0.650	5.00	0.417	1.98	0.853	9.48	0.000	9.77	0.356	13.83	0.775
5.00	0.226	2.47	0.816	2.00	0.955	10.00	0.892	9.81	0.339	13.97	0.888
5.46	0.124	2.96	0.755	2.22	0.955	6.92	0.909	9.87	0.272	14.05	0.783
6.04	0.098	3.49	0.736	2.32	0.941	6.99	0.876	9.93	0.347	14.12	0.742
6.55	0.098	4.00	0.782	2.43	0.947	7.04	0.781	10.02	0.517	14.18	0.698
6.98	0.092	4.49	0.824	2.72	0.947	7.08	0.868	10.07	0.625	14.25	0.600
7.43	0.023	4.96	0.728	3.15	0.936	7.12	0.907	10.15	0.695	14.32	0.514
7.96	0.300	5.50	0.581	3.27	0.925	7.19	0.907	10.24	0.716	14.39	0.487
8.47	0.000	5.97	0.531	3.30	0.904	7.23	0.900	10.30	0.700	14.47	0.524
9.01	0.000	6.47	0.469	3.35	0.598	7.29	0.931	10.36	0.625	14.55	0.605
9.49	0.300	6.99	0.430	3.37	0.575	7.54	0.938	10.41	0.647	14.62	0.681
10.00	0.000	7.49	0.375	3.40	0.630	7.71	0.907	10.46	0.747	14.68	0.725
CURVE 17 $T = 293.$		7.99	0.194	3.41	0.654	7.81	0.878	10.55	0.826	14.74	0.755
CURVE 18 $T = 293.$		8.45	0.017	3.41	0.654	8.02	0.658	10.56	0.845	14.79	0.771
8.45	0.97	9.48	0.000	3.45	0.650	8.04	0.691	10.60	0.851	14.86	0.805
1.00	0.825	9.48	0.000	3.48	0.863	8.10	0.697	10.69	0.875	14.91	0.782
1.50	0.836	10.00	0.000	3.53	0.892	8.15	0.774	10.79	0.889	15.00	0.815
2.30	0.840	10.00	0.000	3.58	0.918	8.19	0.799	10.90	0.899	15.00	0.846
CURVE 20 $T = 293.$		8.97	0.000	3.45	0.650	8.02	0.658	10.56	0.845	14.91	0.815
9.48	0.000	10.00	0.000	3.48	0.863	8.10	0.697	10.72	0.877	14.91	0.782
CURVE 21 $T = 293.$		8.00	0.000	3.48	0.863	8.10	0.697	10.84	0.891	15.00	0.815
CURVE 21 $T = 293.$		8.45	0.000	3.48	0.863	8.10	0.697	11.00	0.895	15.00	0.846

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

WAVELENGTH, λ , ; TEMPERATURE, T , K; TRANSMITTANCE, τ						CURVE 21 (CONT.)						CURVE 21 (CONT.)						CURVE 22 (CONT.)					
λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T	λ	T
2.54	0.962	6.28	0.905	9.53	0.104	13.05	0.726	4.42	0.903	8.19	0.849	8.29	0.831	8.38	0.791	8.52	0.686	8.67	0.514	8.75	0.445	8.86	0.236
2.63	0.962	6.47	0.960	9.74	0.116	13.11	0.766	4.47	0.863	8.29	0.831	8.38	0.791	8.52	0.686	8.67	0.514	8.75	0.445	8.86	0.236	8.95	0.236
2.68	0.951	6.62	0.960	9.86	0.161	13.17	0.782	4.50	0.798	8.38	0.791	8.45	0.324	8.52	0.686	8.67	0.514	8.75	0.445	8.86	0.236	8.95	0.236
2.74	0.898	6.70	0.927	9.93	0.316	13.25	0.762	4.40	0.405	3.29	0.917	7.82	0.912	7.94	0.392	8.04	0.203	8.15	0.154	8.24	0.203	8.35	0.236
2.84	0.931	6.78	0.959	9.97	0.400	13.33	0.738	4.61	0.272	6.67	0.514	7.98	0.925	8.04	0.203	8.15	0.154	8.24	0.203	8.35	0.236	8.45	0.236
2.96	0.938	6.89	0.943	10.03	0.332	13.49	0.565	4.63	0.320	8.88	0.256	8.98	0.925	9.04	0.203	9.15	0.154	9.24	0.203	9.35	0.236	9.45	0.236
3.04	0.952	6.93	0.918	10.07	0.525	13.61	0.599	4.66	0.595	8.96	0.192	9.06	0.925	9.12	0.203	9.23	0.154	9.32	0.203	9.43	0.236	9.53	0.236
3.18	0.952	6.95	0.564	10.19	0.638	13.75	0.599	4.69	0.844	9.07	0.154	9.17	0.924	9.23	0.203	9.32	0.154	9.41	0.203	9.51	0.236	9.61	0.236
3.21	0.896	6.96	0.525	10.19	0.762	13.81	0.563	4.72	0.884	9.17	0.154	9.27	0.924	9.32	0.203	9.41	0.154	9.51	0.203	9.61	0.236	9.71	0.236
3.26	0.820	6.99	0.787	10.26	0.806	13.89	0.503	4.76	0.913	9.27	0.182	9.37	0.924	9.42	0.203	9.51	0.154	9.61	0.203	9.71	0.236	9.81	0.236
3.29	0.841	7.02	0.806	10.34	0.844	13.93	0.486	4.80	0.925	9.37	0.182	9.47	0.925	9.52	0.203	9.61	0.154	9.71	0.203	9.81	0.236	9.91	0.236
3.33	0.901	7.12	0.819	10.44	0.872	14.00	0.544	4.87	0.925	9.47	0.182	9.57	0.209	9.66	0.201	9.75	0.154	9.84	0.201	9.94	0.236	10.04	0.236
3.37	0.859	6.66	0.838	10.50	0.884	14.06	0.616	4.92	0.915	9.57	0.182	9.66	0.209	9.75	0.201	9.84	0.154	9.93	0.201	10.02	0.236	10.12	0.236
3.40	0.930	7.30	0.851	10.70	0.884	14.11	0.636	4.96	0.930	9.67	0.182	9.76	0.209	9.85	0.201	9.94	0.154	10.03	0.201	10.12	0.236	10.22	0.236
3.45	0.933	7.40	0.851	10.75	0.869	14.16	0.606	5.05	0.924	9.77	0.182	9.86	0.209	9.95	0.201	10.04	0.154	10.13	0.201	10.22	0.236	10.31	0.236
3.50	0.957	7.48	0.832	10.90	0.855	14.29	0.385	5.09	0.870	9.87	0.529	9.96	0.209	10.05	0.201	10.14	0.154	10.23	0.201	10.32	0.236	10.41	0.236
3.55	0.969	7.58	0.835	11.00	0.859	14.34	0.337	5.11	0.917	9.96	0.640	10.05	0.209	10.14	0.201	10.23	0.154	10.32	0.201	10.41	0.236	10.50	0.236
3.92	0.977	7.65	0.819	11.05	0.862	14.38	0.369	5.15	0.930	9.93	0.692	10.02	0.208	10.11	0.201	10.20	0.154	10.29	0.201	10.38	0.236	10.47	0.236
4.48	0.969	7.72	0.830	11.21	0.851	14.45	0.690	5.26	0.930	10.02	0.754	10.11	0.208	10.20	0.201	10.29	0.154	10.38	0.201	10.47	0.236	10.56	0.236
4.85	0.955	7.76	0.812	11.33	0.833	14.49	0.760	5.49	0.915	10.11	0.782	10.20	0.208	10.29	0.201	10.38	0.154	10.47	0.201	10.56	0.236	10.65	0.236
4.99	0.961	7.86	0.551	11.44	0.808	14.55	0.820	5.62	0.915	10.21	0.608	10.30	0.208	10.39	0.201	10.48	0.154	10.57	0.201	10.66	0.236	10.75	0.236
5.06	0.935	7.90	0.510	11.53	0.757	14.65	0.853	6.07	0.900	10.40	0.608	10.49	0.208	10.58	0.201	10.67	0.154	10.76	0.201	10.85	0.236	10.94	0.236
5.11	0.935	7.93	0.537	11.67	0.654	14.81	0.887	6.24	0.914	10.59	0.774	10.68	0.208	10.77	0.201	10.86	0.154	10.95	0.201	11.04	0.236	11.13	0.236
5.15	0.952	7.96	0.722	11.80	0.570	15.00	0.907	6.70	0.914	10.69	0.774	10.78	0.208	10.87	0.201	10.96	0.154	11.05	0.201	11.14	0.236	11.23	0.236
5.21	0.953	7.98	0.854	11.84	0.550	15.14	0.927	6.92	0.902	10.78	0.657	10.87	0.208	10.96	0.201	11.05	0.154	11.14	0.201	11.23	0.236	11.32	0.236
5.27	0.925	8.03	0.886	11.91	0.612	15.22	0.927	7.02	0.874	10.87	0.657	10.96	0.208	11.05	0.201	11.14	0.154	11.23	0.201	11.32	0.236	11.41	0.236
5.33	0.950	8.07	0.897	12.00	0.673	15.30	0.927	7.09	0.834	10.96	0.657	11.05	0.208	11.14	0.201	11.23	0.154	11.32	0.201	11.41	0.236	11.50	0.236
5.39	0.950	8.15	0.897	12.05	0.666	15.36	0.927	7.21	0.891	11.05	0.657	11.14	0.208	11.23	0.201	11.32	0.154	11.41	0.201	11.50	0.236	11.59	0.236
5.45	0.925	8.23	0.869	12.16	0.666	15.42	0.927	7.46	0.888	11.14	0.657	11.23	0.208	11.32	0.201	11.41	0.154	11.50	0.201	11.59	0.236	11.68	0.236
5.51	0.950	8.30	0.826	12.23	0.610	15.48	0.927	7.61	0.878	11.24	0.657	11.33	0.208	11.42	0.201	11.51	0.154	11.60	0.201	11.69	0.236	11.78	0.236
5.54	0.950	8.35	0.753	12.32	0.502	15.54	0.927	7.75	0.846	11.34	0.657	11.43	0.208	11.52	0.201	11.61	0.154	11.70	0.201	11.79	0.236	11.88	0.236
5.61	0.933	8.38	0.718	12.42	0.405	15.60	0.927	7.82	0.794	11.44	0.657	11.53	0.208	11.62	0.201	11.71	0.154	11.80	0.201	11.89	0.236	11.98	0.236
5.68	0.951	8.45	0.689	12.51	0.492	15.66	0.927	7.87	0.515	11.54	0.657	11.63	0.208	11.72	0.201	11.81	0.154	11.90	0.201	11.99	0.236	12.08	0.236
5.91	0.951	8.51	0.492	12.60	0.602	15.72	0.927	7.98	0.368	11.64	0.657	11.73	0.208	11.82	0.201	11.91	0.154	12.00	0.201	12.09	0.236	12.18	0.236
6.00	0.936	8.57	0.337	12.65	0.641	15.78	0.903	8.00	0.236	11.74	0.657	11.83	0.208	11.92	0.201	12.01	0.154	12.10	0.201	12.19	0.236	12.28	0.236
6.04	0.953	8.66	0.197	12.70	0.667	15.84	0.903	8.04	0.392	11.84	0.657	11.93	0.208	12.02	0.201	12.11	0.154	12.20	0.201	12.29	0.236	12.38	0.236
6.14	0.947	8.77	0.070	12.79	0.687	15.90	0.903	8.11	0.392	11.94	0.657	12.03	0.208	12.12	0.201	12.21	0.154	12.30	0.201	12.39	0.236	12.48	0.236
6.20	0.924	8.86	0.070	12.86	0.703	15.96	0.903	8.18	0.766	12.04	0.657	12.13	0.208	12.22	0.201	12.31	0.154	12.40	0.201	12.49	0.236	12.58	0.236
6.22	0.896	8.95	0.084	12.92	0.703	16.02	0.903	8.25	0.766	12.14	0.657	12.23	0.208	12.32	0.201	12.41	0.154	12.50	0.201	12.59	0.236	12.68	0.236
6.24	0.801	9.36	0.083	12.98	0.736	16.08	0.903	8.32	0.803	12.24	0.657	12.33	0.208	12.42	0.201	12.51	0.154	12.60	0.201	12.69	0.236	12.78	0.236

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)

CURVE 22 (CONT.)		CURVE 23 (CONT.)		CURVE 24 (CONT.)	
λ	τ	λ	τ	λ	τ
11.93	0.162	2.77	0.691	5.80	0.929
11.93	0.141	2.81	0.713	5.92	0.697
11.58	0.203	2.84	0.715	5.97	0.897
12.05	0.453	2.85	0.787	6.04	0.919
12.12	0.507	2.93	0.707	6.11	0.919
12.12	0.556	2.94	0.722	6.22	0.900
12.24	0.693	3.37	0.724	6.29	0.907
12.37	0.731	3.18	0.749	6.34	0.924
12.52	0.730	3.23	0.755	6.40	0.937
12.62	0.699	3.28	0.755	6.43	0.937
12.62	0.664	3.32	0.746	6.57	0.922
12.73	0.632	3.35	0.654	6.65	0.902
12.81	0.492	3.39	0.560	6.71	0.902
12.92	0.333	3.40	0.652	6.79	0.911
12.92	0.294	3.43	0.641	6.85	0.911
13.52	0.254	3.45	0.690	6.96	0.899
13.14	0.390	3.47	0.715	7.03	0.876
13.25	0.495	3.51	0.706	7.16	0.885
13.34	0.614	3.53	0.735	7.25	0.885
13.76	0.745	3.59	0.787	7.32	0.873
13.57	0.762	3.65	0.811	7.40	0.897
13.71	0.804	3.74	0.828	7.48	0.887
13.39	0.804	3.78	0.822	7.53	0.876
14.04	0.502	3.94	0.860	7.58	0.863
14.49	0.974	4.05	0.645	7.66	0.872
14.86	0.932	4.03	0.645	7.72	0.863
15.00	0.948	4.27	0.693	7.82	0.869
4.39	0.835	4.39	0.835	7.88	0.873
4.53	0.276	4.53	0.276	7.97	0.623
4.65	0.662	4.50	0.877	7.99	0.552
5.00	0.680	5.17	0.890	8.05	0.241
5.34	0.341	5.34	0.623	8.10	0.206
5.50	0.632	5.50	0.877	8.14	0.241
5.62	0.677	5.44	0.923	8.16	0.788
5.62	0.677	5.50	0.938	8.24	0.835
5.63	0.698	5.34	0.938	8.31	0.852
5.65	0.709	5.65	0.511	8.39	0.842
5.69	0.709	5.69	0.911	8.42	0.809
5.73	0.691	5.73	0.929	8.55	0.795

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; TRANSMITTANCE, τ]

λ	τ	CURVE 24 (CONT.)		CURVE 24 (CONT.)		CURVE 25		CURVE 25 (CONT.)		CURVE 26 (CONT.)	
		λ	τ	λ	τ	λ	τ	λ	τ	λ	τ
6.34	0.921	7.81	0.884	11.93	0.481	7.60	0.946	3.43	0.916	7.70	0.914
6.36	0.949	7.87	0.699	12.65	0.506	2.86	0.792	3.47	0.923	7.78	0.580
6.41	0.949	7.93	0.885	12.14	0.497	2.89	0.798	3.55	0.972	7.84	0.442
6.44	0.926	7.99	0.842	12.22	0.497	3.00	0.792	4.45	0.976	7.89	0.527
6.45	0.960	8.06	0.322	12.36	0.486	3.06	0.801	4.60	0.977	7.99	0.802
6.49	0.940	8.08	0.250	12.48	0.216	3.15	0.862	5.59	0.979	8.07	0.837
6.52	0.950	8.13	0.385	12.67	0.141	3.25	0.921	5.67	0.548	8.18	0.866
6.54	0.929	5.17	0.719	12.82	0.085	3.31	0.821	5.77	0.825	8.33	0.840
6.56	0.974	8.22	0.747	12.94	0.070	3.34	0.802	5.84	0.853	8.58	0.676
6.60	0.939	8.23	0.622	13.05	0.155	3.37	0.643	5.96	0.395	8.58	0.147
6.64	0.961	8.35	0.530	13.16	0.262	3.38	0.732	6.06	0.932	8.63	0.133
6.67	0.957	8.48	0.605	13.40	0.394	3.40	0.783	6.25	0.950	8.73	0.200
6.69	0.930	8.62	0.793	13.64	0.404	3.41	0.866	6.35	0.981	8.73	0.626
6.76	0.936	8.70	0.758	13.85	0.448	3.44	0.785	6.54	0.981	8.77	0.657
6.82	0.933	8.79	0.583	14.33	0.463	3.47	0.931	6.68	0.657	8.77	0.943
6.85	0.933	8.92	0.550	14.27	0.444	3.52	0.923	6.83	0.638	8.77	0.895
6.89	0.974	9.06	0.444	14.60	0.360	3.53	0.657	7.11	0.845	8.77	0.443
6.91	0.923	9.12	0.292	14.90	0.324	4.44	0.932	7.26	0.914	8.77	0.564
6.93	0.942	9.25	0.196	15.29	0.306	4.51	0.933	7.36	0.824	8.77	0.576
6.95	0.913	9.25	0.156	15.60	0.242	4.60	0.927	7.53	0.941	8.77	0.537
6.99	0.896	9.40	0.115	15.97	0.263	4.69	0.927	7.64	0.941	8.77	0.537
7.01	0.915	9.56	0.115	16.26	0.251	4.75	0.947	7.77	0.648	8.77	0.477
7.04	0.997	9.68	0.090	17.12	0.186	4.82	0.947	7.84	0.617	8.77	0.526
7.07	0.916	9.39	0.573	18.02	0.170	4.97	0.985	14.10	0.973	7.89	0.562
7.08	0.880	9.53	0.553	18.45	0.152	5.21	0.979	7.96	0.556	7.90	0.577
7.13	0.963	10.19	0.668	18.90	0.124	5.50	0.982	8.13	0.926	8.33	0.644
7.19	0.956	10.27	0.151	19.34	0.136	5.71	0.945	8.33	0.563	8.33	0.644
7.23	0.935	10.26	0.190	19.88	0.129	5.87	0.974	8.35	0.533	8.35	0.533
7.27	0.876	10.43	0.249	20.49	0.137	6.00	0.956	8.44	0.746	8.44	0.746
7.34	0.915	10.48	0.336	21.19	0.131	6.14	0.956	8.87	0.690	8.90	0.079
7.39	0.896	10.62	0.376	21.55	0.138	6.23	0.967	8.89	0.665	9.96	0.199
7.41	0.964	10.71	0.477	22.05	0.139	6.46	1.000	5.57	1.044	6.64	0.624
7.44	0.675	10.79	0.532	22.88	0.118	6.61	1.000	2.96	0.556	10.54	0.556
7.46	0.890	11.14	0.596	23.87	0.090	6.75	0.949	3.13	0.449	13.71	0.623
7.50	0.874	11.27	0.569	23.87	0.075	6.90	0.939	3.30	0.526	16.93	0.624
7.52	0.891	11.35	0.529	25.00	0.072	7.00	0.858	3.35	0.905	11.24	0.633
7.59	0.901	11.35	0.601	7.06	0.899	7.06	0.899	3.36	0.380	11.61	0.551
7.63	0.875	11.57	0.622	7.17	0.924	7.17	0.924	3.39	0.561	11.98	0.561
7.69	0.879	11.71	0.582	7.35	0.998	7.35	0.998	3.40	0.358	12.39	0.755
7.73	0.963	11.91	0.501	7.46	0.949	7.46	0.949	3.40	0.694	12.69	0.551

CURVE 26
 $T = 293$

TABLE 19-12. EXPERIMENTAL NORMAL SPECTRAL TRANSMITTANCE OF SILICON RESIN (WAVELENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; TRANSMITTANCE, τ)

λ	τ
CURVE 26 (CONT.)	
12.95	0.611
13.04	0.710
13.44	0.815
14.29	1.000

4.20. Aluminized Grafoil

Aluminized grafoil is made by applying thin coatings of aluminum on grafoil, a pure flexible, insulating graphite tape with highly directional properties similar to those of pyrolytic graphite.

The grafoil adds the advantage of flexibility to the thermal-insulating properties of pyrolytic graphite from the cryogenic range up to about 4000 K. Preliminary values of the ratio of the thermal conductivity perpendicular to the surface plane to that along the surface range between 0.001 to 0.006, depending upon the type of grafoil tape measured. There is no increase in thermal conductivity at high temperatures as found in conventional insulation materials. Grafoil tape and foil are normally produced in the 1.0 to 1.3 g cm⁻³ density range. It can be embossed, wrapped, rolled, pressed or otherwise formed.

Aluminized grafoil was made primarily for the purpose of providing a high-reflectivity, low thermal-conductivity material for cryogenic applications. However, advantages of this material made it a favorable material in the area of aircraft design and space vehicle construction where heat insulation plays an important role.

Experimental data on the thermal radiative properties of aluminized grafoil were not found in our literature search. This discouraging fact does not prevent us from making a reasonable estimation for the radiative properties because the thin coatings of aluminum are usually thick enough to be opaque to the radiation and are therefore considered as the sole material interacting with the incident radiation. Therefore, the generation of the most probable values on the thermal radiative properties of aluminized grafoil is based on the available data of aluminum.

Literature survey for aluminum revealed an adequate amount of data on the normal spectral emittance, reflectance and absorptance. Measurement information and experimental results obtained in this survey are given in Tables 20-1 to 20-10 and Figures 20-1 to 20-5. By careful review of the tables and figures, one will see that the magnitudes of the thermal radiative properties are very much affected by the surface conditions of the specimens. The literature abounds with examples of test surfaces shown to be very sensitive to methods of preparation, thermal history, and environmental conditions. Despite this awareness, descriptions of test surfaces are generally inadequate because of our modest understanding of the mechanisms or real surface effects and how to properly characterize a surface.




FIGURE 20-1. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE).

TABLE 20-1. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMMITTANCE OF ALUMINUM (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 T11723	Reynolds, P. M.	1961	1.8-12.5	599		99.7 Al, 0.11 Fe, 0.11 Si, 0.01 Cu, 0.01 Mg, <0.01 Mn, Ni and Zn; cylindrical tube; heated at 467 K for 15 hr; polished with Carni on Selvyt cloth; surface roughness 0.976 μm (center line average); data extracted from smooth curve; reported error ±20%.	
2 T11723	Reynolds, P. M.	1961	1.7-14.0	697		The above specimen and conditions except heated at 697 K for 20 hr before measurement.	
3 T11723	Reynolds, P. M.	1961	1.7-14.0	805		The above specimen and conditions except heated at 805 K for 15 hr before measurement.	
4 T11723	Reynolds, P. M.	1961	1.7-12.5	599		The above specimen and conditions.	
5 T11723	Reynolds, P. M.	1961	1.8-14.5	462		99.7 Al, 0.11 Fe, 0.11 Si, 0.01 Cu, 0.01 Mg, <0.01 Mn, Ni and Zn; tube; heated for 25 hr at 462 K; roughened and knurled with grade 180 silicon carbide paper; surface roughness 2.92 μm (center line average); data extracted from a smooth curve; error given over the wavelength range 2 to 10 μm, reported error ±10%.	
6 T11723	Reynolds, P. M.	1961	2.0-14.0	599		The above specimen and conditions except heated at 598 K for 22 hr before measurement.	
7 T11723	Reynolds, P. M.	1961	1.25-14.5	715		The above specimen and conditions except heated at 715 K for 27 hr before measurement.	
8 T11723	Reynolds, P. M.	1961	3.5-14.5	803		The above specimen and conditions except heated at 787 K for 17 hr before measurement.	
9 T11723	Reynolds, P. M.	1961	3.0-14.0	461		The above specimen and conditions.	

TABLE 26-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ]

λ	ϵ	CURVE 1 $T = 599.$	CURVE 2 (CONT.)	CURVE 3 (CONT.)	CURVE 4 $T = 599.$	CURVE 5 (CONT.)	CURVE 6 (CONT.)	CURVE 7 (CONT.)	λ	ϵ
1.8	0.119	7.0 0.043	11.5 0.051	3.0 0.261	7.0 0.264	11.0 0.323	11.0 0.323	11.0 0.323	1.5	0.314
2.0	0.160	7.5 0.042	12.0 0.049	3.5 0.258	7.5 0.263	11.5 0.263	11.5 0.263	11.5 0.263	1.5	0.314
2.5	0.288	8.5 0.046	12.5 0.047	4.0 0.257	8.5 0.262	12.5 0.262	12.5 0.262	12.5 0.262	1.5	0.318
3.0	0.076	9.0 0.039	13.0 0.045	4.5 0.254	9.0 0.266	12.5 0.266	12.5 0.266	12.5 0.266	1.5	0.234
3.5	0.268	9.5 0.038	13.5 0.043	5.0 0.247	9.0 0.263	13.0 0.263	13.0 0.263	13.0 0.263	1.5	0.310
4.0	0.062	10.0 0.039	14.0 0.042	5.5 0.244	9.5 0.267	13.5 0.267	13.5 0.267	13.5 0.267	1.5	0.312
4.5	0.057	10.5 0.041	14.5 0.044	6.0 0.241	10.0 0.270	13.5 0.270	13.5 0.270	13.5 0.270	1.5	0.313
5.0	0.053	11.0 0.040	15.0 0.043	6.5 0.239	10.5 0.273	13.5 0.273	13.5 0.273	13.5 0.273	1.5	0.304
5.5	0.053	11.5 0.040	15.5 0.043	7.0 0.238	11.0 0.276	13.5 0.276	13.5 0.276	13.5 0.276	1.5	0.304
6.0	0.048	12.0 0.038	16.0 0.042	7.5 0.233	11.5 0.273	13.5 0.273	13.5 0.273	13.5 0.273	1.5	0.302
6.5	0.045	12.5 0.039	16.5 0.042	8.0 0.233	12.0 0.269	12.5 0.269	12.5 0.269	12.5 0.269	1.5	0.264
7.0	0.047	13.0 0.039	17.0 0.042	8.5 0.233	12.5 0.266	12.5 0.266	12.5 0.266	12.5 0.266	1.5	0.264
7.5	0.042	13.5 0.035	17.5 0.035	9.0 0.233	13.0 0.271	13.0 0.271	13.0 0.271	13.0 0.271	1.5	0.234
8.0	0.041	14.0 0.034	18.0 0.035	9.5 0.233	13.5 0.273	13.5 0.273	13.5 0.273	13.5 0.273	1.5	0.222
8.5	0.039	14.5 0.033	18.5 0.034	10.0 0.246	13.5 0.271	13.5 0.271	13.5 0.271	13.5 0.271	1.5	0.277
9.0	0.033	15.0 0.033	19.0 0.034	10.5 0.246	14.0 0.269	14.0 0.269	14.0 0.269	14.0 0.269	1.5	0.255
9.5	0.033	15.5 0.033	19.5 0.034	11.0 0.246	14.5 0.269	14.5 0.269	14.5 0.269	14.5 0.269	1.5	0.255
10.0	0.033	16.0 0.033	20.0 0.034	11.5 0.246	15.0 0.269	15.0 0.269	15.0 0.269	15.0 0.269	1.5	0.255
10.5	0.033	16.5 0.033	20.5 0.034	12.0 0.246	15.5 0.269	15.5 0.269	15.5 0.269	15.5 0.269	1.5	0.255
11.0	0.033	17.0 0.033	21.0 0.034	12.5 0.246	16.0 0.269	16.0 0.269	16.0 0.269	16.0 0.269	1.5	0.255
11.5	0.033	17.5 0.033	21.5 0.034	13.0 0.246	16.5 0.269	16.5 0.269	16.5 0.269	16.5 0.269	1.5	0.255
12.0	0.033	18.0 0.033	22.0 0.034	13.5 0.246	17.0 0.269	17.0 0.269	17.0 0.269	17.0 0.269	1.5	0.255
12.5	0.033	18.5 0.033	22.5 0.034	14.0 0.246	17.5 0.269	17.5 0.269	17.5 0.269	17.5 0.269	1.5	0.255
13.0	0.033	19.0 0.033	23.0 0.034	14.5 0.246	18.0 0.269	18.0 0.269	18.0 0.269	18.0 0.269	1.5	0.255
13.5	0.033	19.5 0.033	23.5 0.034	15.0 0.246	18.5 0.269	18.5 0.269	18.5 0.269	18.5 0.269	1.5	0.255
14.0	0.033	20.0 0.033	24.0 0.034	15.5 0.246	19.0 0.269	19.0 0.269	19.0 0.269	19.0 0.269	1.5	0.255
14.5	0.033	20.5 0.033	24.5 0.034	16.0 0.246	19.5 0.269	19.5 0.269	19.5 0.269	19.5 0.269	1.5	0.255
15.0	0.033	21.0 0.033	25.0 0.034	16.5 0.246	20.0 0.269	20.0 0.269	20.0 0.269	20.0 0.269	1.5	0.255
15.5	0.033	21.5 0.033	25.5 0.034	17.0 0.246	20.5 0.269	20.5 0.269	20.5 0.269	20.5 0.269	1.5	0.255
16.0	0.033	22.0 0.033	26.0 0.034	17.5 0.246	21.0 0.269	21.0 0.269	21.0 0.269	21.0 0.269	1.5	0.255
16.5	0.033	22.5 0.033	26.5 0.034	18.0 0.246	21.5 0.269	21.5 0.269	21.5 0.269	21.5 0.269	1.5	0.255
17.0	0.033	23.0 0.033	27.0 0.034	18.5 0.246	22.0 0.269	22.0 0.269	22.0 0.269	22.0 0.269	1.5	0.255
17.5	0.033	23.5 0.033	27.5 0.034	19.0 0.246	22.5 0.269	22.5 0.269	22.5 0.269	22.5 0.269	1.5	0.255
18.0	0.033	24.0 0.033	28.0 0.034	19.5 0.246	23.0 0.269	23.0 0.269	23.0 0.269	23.0 0.269	1.5	0.255
18.5	0.033	24.5 0.033	28.5 0.034	20.0 0.246	23.5 0.269	23.5 0.269	23.5 0.269	23.5 0.269	1.5	0.255
19.0	0.033	25.0 0.033	29.0 0.034	20.5 0.246	24.0 0.269	24.0 0.269	24.0 0.269	24.0 0.269	1.5	0.255
19.5	0.033	25.5 0.033	29.5 0.034	21.0 0.246	24.5 0.269	24.5 0.269	24.5 0.269	24.5 0.269	1.5	0.255
20.0	0.033	26.0 0.033	30.0 0.034	21.5 0.246	25.0 0.269	25.0 0.269	25.0 0.269	25.0 0.269	1.5	0.255
20.5	0.033	26.5 0.033	30.5 0.034	22.0 0.246	25.5 0.269	25.5 0.269	25.5 0.269	25.5 0.269	1.5	0.255
21.0	0.033	27.0 0.033	31.0 0.034	22.5 0.246	26.0 0.269	26.0 0.269	26.0 0.269	26.0 0.269	1.5	0.255
21.5	0.033	27.5 0.033	31.5 0.034	23.0 0.246	26.5 0.269	26.5 0.269	26.5 0.269	26.5 0.269	1.5	0.255
22.0	0.033	28.0 0.033	32.0 0.034	23.5 0.246	27.0 0.269	27.0 0.269	27.0 0.269	27.0 0.269	1.5	0.255
22.5	0.033	28.5 0.033	32.5 0.034	24.0 0.246	27.5 0.269	27.5 0.269	27.5 0.269	27.5 0.269	1.5	0.255
23.0	0.033	29.0 0.033	33.0 0.034	24.5 0.246	28.0 0.269	28.0 0.269	28.0 0.269	28.0 0.269	1.5	0.255
23.5	0.033	29.5 0.033	33.5 0.034	25.0 0.246	28.5 0.269	28.5 0.269	28.5 0.269	28.5 0.269	1.5	0.255
24.0	0.033	30.0 0.033	34.0 0.034	25.5 0.246	29.0 0.269	29.0 0.269	29.0 0.269	29.0 0.269	1.5	0.255
24.5	0.033	30.5 0.033	34.5 0.034	26.0 0.246	29.5 0.269	29.5 0.269	29.5 0.269	29.5 0.269	1.5	0.255
25.0	0.033	31.0 0.033	35.0 0.034	26.5 0.246	30.0 0.269	30.0 0.269	30.0 0.269	30.0 0.269	1.5	0.255
25.5	0.033	31.5 0.033	35.5 0.034	27.0 0.246	30.5 0.269	30.5 0.269	30.5 0.269	30.5 0.269	1.5	0.255
26.0	0.033	32.0 0.033	36.0 0.034	27.5 0.246	31.0 0.269	31.0 0.269	31.0 0.269	31.0 0.269	1.5	0.255
26.5	0.033	32.5 0.033	36.5 0.034	28.0 0.246	31.5 0.269	31.5 0.269	31.5 0.269	31.5 0.269	1.5	0.255
27.0	0.033	33.0 0.033	37.0 0.034	28.5 0.246	32.0 0.269	32.0 0.269	32.0 0.269	32.0 0.269	1.5	0.255
27.5	0.033	33.5 0.033	37.5 0.034	29.0 0.246	32.5 0.269	32.5 0.269	32.5 0.269	32.5 0.269	1.5	0.255
28.0	0.033	34.0 0.033	38.0 0.034	29.5 0.246	33.0 0.269	33.0 0.269	33.0 0.269	33.0 0.269	1.5	0.255
28.5	0.033	34.5 0.033	38.5 0.034	30.0 0.246	33.5 0.269	33.5 0.269	33.5 0.269	33.5 0.269	1.5	0.255
29.0	0.033	35.0 0.033	39.0 0.034	30.5 0.246	34.0 0.269	34.0 0.269	34.0 0.269	34.0 0.269	1.5	0.255
29.5	0.033	35.5 0.033	39.5 0.034	31.0 0.246	34.5 0.269	34.5 0.269	34.5 0.269	34.5 0.269	1.5	0.255
30.0	0.033	36.0 0.033	40.0 0.034	31.5 0.246	35.0 0.269	35.0 0.269	35.0 0.269	35.0 0.269	1.5	0.255
30.5	0.033	36.5 0.033	40.5 0.034	32.0 0.246	35.5 0.269	35.5 0.269	35.5 0.269	35.5 0.269	1.5	0.255
31.0	0.033	37.0 0.033	41.0 0.034	32.5 0.246	36.0 0.269	36.0 0.269	36.0 0.269	36.0 0.269	1.5	0.255
31.5	0.033	37.5 0.033	41.5 0.034	33.0 0.246	36.5 0.269	36.5 0.269	36.5 0.269	36.5 0.269	1.5	0.255
32.0	0.033	38.0 0.033	42.0 0.034	33.5 0.246	37.0 0.269	37.0 0.269	37.0 0.269	37.0 0.269	1.5	0.255
32.5	0.033	38.5 0.033	42.5 0.034	34.0 0.246	37.5 0.269	37.5 0.269	37.5 0.269	37.5 0.269	1.5	0.255
33.0	0.033	39.0 0.033	43.0 0.034	34.5 0.246	38.0 0.269	38.0 0.269	38.0 0.269	38.0 0.269	1.5	0.255
33.5	0.033	39.5 0.033	43.5 0.034	35.0 0.246	38.5 0.269	38.5 0.269	38.5 0.269	38.5 0.269	1.5	0.255
34.0	0.033	40.0 0.033	44.0 0.034	35.5 0.246	39.0 0.269	39.0 0.269	39.0 0.269	39.0 0.269	1.5	0.255
34.5	0.033	40.5 0.033	44.5 0.034	36.0 0.246	39.5 0.269	39.5 0.269	39.5 0.269	39.5 0.269	1.5	0.255
35.0	0.033	41.0 0.033	45.0 0.034	36.5 0.246	40.0 0.269	40.0 0.269	40.0 0.269	40.0 0.269	1.5	0.255
35.5	0.033	41.5 0.033	45.5 0.034	37.0 0.246	40.5 0.269	40.5 0.269	40.5 0.269	40.5 0.269	1.5	0.255
36.0	0.033	42.0 0.033	46.0 0.034	37.5 0.246	41.0 0.269	41.0 0.269	41.0 0.269	41.0 0.269	1.5	0.255
36.5	0.033	42.5 0.033	46.5 0.034	38.0 0.246	41.5 0.269	41.5 0.269	41.5 0.269	41.5 0.269	1.5	0.255
37.0	0.033	43.0 0.033	47.0 0.034	38.5 0.246	42.0 0.269	42.0 0.269	42.0 0.269	42.0 0.269	1.5	0.255
37.5	0.033	43.5 0.033	47.5 0.034	39.0 0.246	42.5 0.269	42.5 0.269	42.5 0.269	42.5 0.269	1.5	0.255
38.0	0.033	44.0 0.033	48.0 0.034	39.5 0.246	43.0 0.269	43.0 0.269	43.0 0.269	43.		

TABLE 20-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (WAVELLENGTH DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ
CURVE 9 $T = 465.$	
3.0	0.275
3.5	0.267
4.0	0.253
4.5	0.252
5.0	0.246
5.5	0.242
6.0	0.240
6.5	0.233
7.0	0.230
7.5	0.230
8.0	0.235
8.5	0.232
9.0	0.239
9.4	0.237
9.7	0.240
10.0	0.249
10.5	0.245
10.8	0.237
11.0	0.245
11.5	0.280
12.0	0.310
12.5	0.312
13.0	0.320
13.5	0.314
14.0	0.316




FIGURE 20-2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM
(TEMPERATURE DEPENDENCE).

TABLE 20-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMISSANCE OF ALUMINUM (Temperature Dependence)

Cur. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	T53964	Curcio, J.V.	1968	2.0	591-887	No. 1
2	T53964	Curcio, J.V.	1968	2.5	591-887	No. 1
3	T53964	Curcio, J.V.	1966	3.0	591-887	No. 1
4	T53964	Curcio, J.V.	1968	3.5	591-887	The above specimen.
5	T53964	Curcio, J.V.	1968	4.0	591-887	The above specimen.
6	T53964	Curcio, J.V.	1968	4.5	591-887	No. 1
7	T53964	Curcio, J.V.	1968	5.0	591-887	No. 1
8	T53964	Curcio, J.V.	1968	5.5	591-887	No. 1
9	T53964	Curcio, J.V.	1968	6.0	591-887	No. 1
10	T53964	Curcio, J.V.	1968	6.5	591-887	No. 1
11	T53964	Curcio, J.V.	1968	7.0	645-887	No. 1
12	T53964	Curcio, J.V.	1968	7.5	645-887	No. 1
13	T53964	Curcio, J.V.	1968	8.0	645-887	No. 1
14	T53964	Curcio, J.V.	1968	8.5	645-887	No. 1
15	T53964	Curcio, J.V.	1968	9.0	645-887	No. 1
16	T53964	Curcio, J.V.	1968	9.5	316-887	No. 1
17	T53964	Curcio, J.V.	1968	10.0	816-887	No. 1
18	T53964	Curcio, J.V.	1968	10.5	816-887	No. 1
19	T53964	Curcio, J.V.	1968	11.0	816-887	No. 1
20	T53964	Curcio, J.V.	1968	11.5	816-887	No. 1
21	T53964	Curcio, J.V.	1968	12.0	816-887	No. 1
22	T53964	Curcio, J.V.	1968	12.5	816-887	No. 1
23	T53964	Curcio, J.V.	1968	13.0	816-887	No. 1
24	T53964	Curcio, J.V.	1968	13.5	816-887	No. 1
25	T53964	Curcio, J.V.	1968	14.0	816-887	No. 1
26	T53964	Curcio, J.V.	1968	2.0	502-888	No. 2
27	T53964	Curcio, J.V.	1968	2.5	502-888	No. 2
28	T53964	Curcio, J.V.	1968	3.0	502-888	No. 2
29	T53964	Curcio, J.V.	1968	3.5	502-888	The above specimen.
30	T53964	Curcio, J.V.	1968	4.0	502-888	The above specimen.
31	T53964	Curcio, J.V.	1968	4.5	502-888	The above specimen.
					Cut from a disk of the same batch as the above specimen; as received; reported error 3-8%.	

TABLE 20-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM (Temperature Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
32 T53964	Curcio, J. V.	1968	5.0	502-888	No. 2	The above specimen.
33 T53964	Curcio, J. V.	1968	5.5	502-888	No. 2	The above specimen.
34 T53964	Curcio, J. V.	1968	6.0	502-888	No. 2	The above specimen.
35 T53964	Curcio, J. V.	1968	6.5	502-888	No. 2	The above specimen.
36 T53964	Curcio, J. V.	1968	7.0	502-888	No. 2	The above specimen.
37 T53964	Curcio, J. V.	1968	7.5	502-888	No. 2	The above specimen.
38 T53964	Curcio, J. V.	1968	8.0	502-888	No. 2	The above specimen.
39 T53964	Curcio, J. V.	1968	8.5	502-888	No. 2	The above specimen.
40 T53964	Curcio, J. V.	1968	9.0	502-888	No. 2	The above specimen.
41 T53964	Curcio, J. V.	1968	9.5	502-888	No. 2	The above specimen.
42 T53964	Curcio, J. V.	1968	10.0	502-888	No. 2	The above specimen.
43 T53964	Curcio, J. V.	1968	2.0	617-877	No. 3	Similar to the above specimen; polished with various grades of emery paper; reported error 3-8%.
44 T53964	Curcio, J. V.	1968	2.5	483-877	No. 3	The above specimen.
45 T53964	Curcio, J. V.	1968	3.0	399-877	No. 3	The above specimen.
46 T53964	Curcio, J. V.	1968	3.5	399-877	No. 3	The above specimen.
47 T53964	Curcio, J. V.	1968	4.0	399-877	No. 3	The above specimen.
48 T53964	Curcio, J. V.	1968	4.5	399-877	No. 3	The above specimen.
49 T53964	Curcio, J. V.	1968	5.0	399-877	No. 3	The above specimen.
50 T53964	Curcio, J. V.	1968	5.5	399-877	No. 3	The above specimen.
51 T53964	Curcio, J. V.	1968	6.0	399-877	No. 3	The above specimen.
52 T53964	Curcio, J. V.	1968	6.5	399-877	No. 3	The above specimen.
53 T53964	Curcio, J. V.	1968	7.0	399-877	No. 3	The above specimen.
54 T53964	Curcio, J. V.	1968	7.5	399-877	No. 3	The above specimen.
55 T53964	Curcio, J. V.	1968	8.0	399-877	No. 3	The above specimen.
56 T53964	Curcio, J. V.	1968	8.5	399-877	No. 3	The above specimen.
57 T53964	Curcio, J. V.	1968	9.0	399-877	No. 3	The above specimen.
58 T53964	Curcio, J. V.	1968	9.5	399-877	No. 3	The above specimen.
59 T53964	Curcio, J. V.	1968	10.0	399-877	No. 3	The above specimen.
60 T53964	Curcio, J. V.	1968	10.5	399-877	No. 3	The above specimen.
61 T53964	Curcio, J. V.	1968	11.0	399-877	No. 3	The above specimen.
62 T53964	Curcio, J. V.	1968	11.5	399-877	No. 3	The above specimen.
63 T53964	Curcio, J. V.	1968	12.0	399-877	No. 3	The above specimen.
64 T53964	Curcio, J. V.	1968	12.5	399-877	No. 3	The above specimen.

TABLE 20-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM (Temperature Dependence) (continued)

Cur. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
65 T53964	Curcio, J.V.	1968	13.0	399-877	No. 3	The above specimen.
66 T53964	Curcio, J.V.	1968	13.5	399-877	No. 3	The above specimen.
67 T53964	Curcio, J.V.	1968	14.0	399-877	No. 3	The above specimen.
68 T53964	Curcio, J.V.	1968	2.0	643-914	No. 4	Similar to the above specimen; polished with various grades of emery paper and abraded with 400 alumundum for 5 min; reported error 3-8%.
69 T53964	Curcio, J.V.	1968	2.5	514-914	No. 4	The above specimen.
70 T53964	Curcio, J.V.	1968	3.0	514-914	No. 4	The above specimen.
71 T53964	Curcio, J.V.	1968	3.5	514-914	No. 4	The above specimen.
72 T53964	Curcio, J.V.	1968	4.0	514-914	No. 4	The above specimen.
73 T53964	Curcio, J.V.	1968	4.5	514-914	No. 4	The above specimen.
74 T53964	Curcio, J.V.	1968	5.0	514-914	No. 4	The above specimen.
75 T53964	Curcio, J.V.	1968	5.5	643-914	No. 4	The above specimen.
76 T53964	Curcio, J.V.	1968	6.0	643-914	No. 4	The above specimen.
77 T53964	Curcio, J.V.	1968	2.0	637-912	No. 5	Similar to the above specimen; polished with various grades of emery paper and abraded with 400 alumundum for 1 hr; reported error 3-8%.
78 T53964	Curcio, J.V.	1968	2.5	484-912	No. 5	The above specimen.
79 T53964	Curcio, J.V.	1968	3.0	479-912	No. 5	The above specimen.
80 T53964	Curcio, J.V.	1968	3.5	479-912	No. 5	The above specimen.
81 T53964	Curcio, J.V.	1968	4.0	479-912	No. 5	The above specimen.
82 T53964	Curcio, J.V.	1968	4.5	479-912	No. 5	The above specimen.
83 T53964	Curcio, J.V.	1968	5.0	479-912	No. 5	The above specimen.
84 T53964	Curcio, J.V.	1968	5.5	479-912	No. 5	The above specimen.
85 T53964	Curcio, J.V.	1968	6.0	479-912	No. 5	The above specimen.
86 T53964	Curcio, J.V.	1968	2.0	646-918	No. 6	Similar to the above specimen; polished with various grades of emery paper, abraded with 400 alumundum for 5 min; reported error 3-8%.
87 T53964	Curcio, J.V.	1968	2.5	484-918	No. 6	The above specimen.
88 T53964	Curcio, J.V.	1968	3.0	484-918	No. 6	The above specimen.
89 T53964	Curcio, J.V.	1968	3.5	484-918	No. 6	The above specimen.
90 T53964	Curcio, J.V.	1968	4.0	484-918	No. 6	The above specimen.
91 T53964	Curcio, J.V.	1968	4.5	484-918	No. 6	The above specimen.
92 T53964	Curcio, J.V.	1968	5.0	646-918	No. 6	The above specimen.
93 T53964	Curcio, J.V.	1968	5.5	646-918	No. 6	The above specimen.
94 T53964	Curcio, J.V.	1968	6.0	646-918	No. 6	The above specimen.
95 T53964	Curcio, J.V.	1968	2.0	568-833	No. 7	Similar to the above specimen; polished with various grades of emery paper, abraded with 400 alumundum for 30 min and with 600 alumundum for 15 min; reported error 3-8%.

TABLE 20-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM (Temperature Dependence) (continued)

Cur. Ref. No.	Author(s) No.	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
96	T53964	Curcio, J. V.	1963	2.5	568-833	No. 7 The above specimen.
97	T53964	Curcio, J. V.	1968	3.0	553-833	No. 7 The above specimen.
98	T53964	Curcio, J. V.	1968	3.5	553-833	No. 7 The above specimen.
99	T53964	Curcio, J. V.	1968	4.0	553-833	No. 7 The above specimen.
100	T53964	Curcio, J. V.	1968	4.5	553-833	No. 7 The above specimen.
101	T53964	Curcio, J. V.	1968	5.0	553-833	No. 7 The above specimen.
102	T53964	Curcio, J. V.	1968	5.5	553-833	No. 7 The above specimen.
103	T53964	Curcio, J. V.	1968	6.0	553-833	No. 7 The above specimen.
104	T53964	Curcio, J. V.	1968	6.5	636-833	No. 7 The above specimen.
105	T53964	Curcio, J. V.	1968	7.0	687-833	No. 7 The above specimen.
106	T53964	Curcio, J. V.	1968	7.5	687-833	No. 7 The above specimen.
107	T53964	Curcio, J. V.	1968	8.0	687-833	No. 7 The above specimen.
108	T53964	Curcio, J. V.	1968	8.5	687-833	No. 7 The above specimen.
109	T53964	Curcio, J. V.	1968	9.0	687-833	No. 7 The above specimen.
110	T53964	Curcio, J. V.	1968	9.5	833	No. 7 The above specimen.
111	T53964	Curcio, J. V.	1968	2.0	546-814	No. 8 Similar to the above specimen; polished with various grades of emery paper, abraded with 400 alumundum for 30 min and with 600 alumundum for 30 min; reported error 3-8%.
112	T53964	Curcio, J. V.	1968	2.5	472-814	No. 8 The above specimen.
113	T53964	Curcio, J. V.	1968	3.0	472-814	No. 8 The above specimen.
114	T53964	Curcio, J. V.	1968	3.5	472-814	No. 8 The above specimen.
115	T53964	Curcio, J. V.	1968	4.0	472-814	No. 8 The above specimen.
116	T53964	Curcio, J. V.	1963	4.5	472-814	No. 9 The above specimen.
117	T53964	Curcio, J. V.	1968	5.0	472-814	No. 3 The above specimen.
118	T53964	Curcio, J. V.	1968	5.5	472-814	No. 8 The above specimen.
119	T53964	Curcio, J. V.	1968	6.0	472-814	No. 8 The above specimen.
120	T53964	Curcio, J. V.	1968	6.5	472-814	No. 8 The above specimen.
121	T53964	Curcio, J. V.	1968	7.0	546-814	No. 8 The above specimen.
122	T53964	Curcio, J. V.	1968	7.5	546-814	No. 8 The above specimen.
123	T53964	Curcio, J. V.	1968	8.0	578-814	No. 8 The above specimen.
124	T53964	Curcio, J. V.	1968	8.5	578-814	No. 8 The above specimen.
125	T53964	Curcio, J. V.	1968	9.0	669-814	No. 8 The above specimen.
126	T53964	Curcio, J. V.	1968	9.5	669-814	No. 8 The above specimen.
127	T53964	Curcio, J. V.	1968	10.0	769-814	No. 8 The above specimen.
128	T53964	Curcio, J. V.	1968	10.5	769-814	No. 8 The above specimen.

TABLE 20-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM (Temperature Dependence) (continued)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
129 T53964	Curcio, J. V.	1968	11.0	769, 814	No. 8	The above specimen.
130 T53964	Curcio, J. V.	1968	11.5	769, 814	No. 8	The above specimen.
131 T53964	Curcio, J. V.	1968	12.0	769, 814	No. 8	The above specimen.
132 T53964	Curcio, J. V.	1968	12.5	769, 814	No. 8	The above specimen.
133 T53964	Curcio, J. V.	1968	13.0	769, 814	No. 8	The above specimen.
134 T53964	Curcio, J. V.	1968	13.5	769, 814	No. 8	The above specimen.
135 T53964	Curcio, J. V.	1968	14.0	769, 814	No. 8	The above specimen.
136 T53964	Curcio, J. V.	1968	2.0	603-808	No. 9	Similar to the above specimen; polished with various grades of emery paper, abraded with 400 alundum for 30 min and with 600 alundum for 30 min; reported error 3-8%.
137 T53964	Curcio, J. V.	1968	2.5	568-808	No. 9	The above specimen.
138 T53964	Curcio, J. V.	1968	3.0	470-808	No. 9	The above specimen.
139 T53964	Curcio, J. V.	1968	3.5	470-808	No. 9	The above specimen.
140 T53964	Curcio, J. V.	1968	4.0	470-808	No. 9	The above specimen.
141 T53964	Curcio, J. V.	1968	4.5	470-808	No. 9	The above specimen.
142 T53964	Curcio, J. V.	1968	5.0	470-808	No. 9	The above specimen.
143 T53964	Curcio, J. V.	1968	5.5	470-808	No. 9	The above specimen.
144 T53964	Curcio, J. V.	1968	6.0	568-808	No. 9	The above specimen.
145 T53964	Curcio, J. V.	1968	6.5	568-808	No. 9	The above specimen.
146 T53964	Curcio, J. V.	1968	7.0	568-808	No. 9	The above specimen.
147 T53964	Curcio, J. V.	1968	7.5	568-808	No. 9	The above specimen.
148 T53964	Curcio, J. V.	1968	8.0	603-808	No. 9	The above specimen.
149 T53964	Curcio, J. V.	1968	8.~	603-808	No. 9	The above specimen.
150 T53964	Curcio, J. V.	1968	9.0	681-808	No. 9	The above specimen.
151 T53964	Curcio, J. V.	1968	9.5	681-768	No. 9	The above specimen.
152 T53964	Curcio, J. V.	1968	10.0	681-768	No. 9	The above specimen.
153 T53964	Curcio, J. V.	1968	10.5	681, 768	No. 9	The above specimen.
154 T53964	Curcio, J. V.	1968	11.0	681, 768	No. 9	The above specimen.
155 T53964	Curcio, J. V.	1968	11.5	681, 768	No. 9	The above specimen.
156 T53964	Curcio, J. V.	1968	2.0	623-883	No. 10	Similar to the above specimen; polished with various grades of emery paper, and abraded with 400 alundum for 1 hr and with 600 alundum for 1 hr; reported error 3-8%.
157 T53964	Curcio, J. V.	1968	2.5	491-883	No. 10	The above specimen.
158 T53964	Curcio, J. V.	1968	3.0	491-883	No. 10	The above specimen.
159 T53964	Curcio, J. V.	1968	3.5	491-883	No. 10	The above specimen.
160 T53964	Curcio, J. V.	1968	4.0	491-883	No. 10	The above specimen.

TABLE 20-3. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL EMITTANCE OF ALUMINUM (Temperature Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
161	T53964	Curcio, J. V.	1968	4.5	513-883	No. 10	The above specimen.
162	T53964	Curcio, J. V.	1968	5.0	513-883	No. 10	The above specimen.
163	T53964	Curcio, J. V.	1968	5.5	623-883	No. 10	The above specimen.
164	T53964	Curcio, J. V.	1968	6.0	623-883	No. 10	The above specimen.
165	T53964	Curcio, J. V.	1968	6.5	644, 883	No. 10	The above specimen.
166	T53964	Curcio, J. V.	1968	7.0	644, 883	No. 10	The above specimen.
167	T53964	Curcio, J. V.	1968	7.5	644, 883	No. 10	The above specimen.
168	T53964	Curcio, J. V.	1968	8.0	644, 883	No. 10	The above specimen.

TABLE II. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF ALUMINUM (TEMPERATURE DEPENDENCE)
[WAVELENGTH, λ ; μm ; TEMPERATURE, T ; K ; EMISSANCE, ϵ]

NOT SHOWN IN FIGURE.

TABLE 20--2. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE) (CONTINUED)

* NOT SHOWN IN FIGURE.

TABLE 20--4. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T, K; EMITTANCE, ϵ)

T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ
CURVE 54*		CURVE 58*		CURVE 62*		CURVE 65*		CURVE 71*		CURVE 74*	
$\lambda = 7.5$		$\lambda = 9.5$		$\lambda = 11.5$		$\lambda = 13.5$		$\lambda = 3.5$		$\lambda = 6.0$	
399.	6.633	399.	6.535	399.	6.495	399.	6.319	514.	6.065	543.	6.420
463.	6.705	483.	6.634	463.	6.594	483.	6.473	643.	6.059	738.	6.038
617.	6.722	617.	6.659	617.	6.617	617.	6.577	735.	6.056	914.	6.057
756.	6.743	758.	6.697	758.	6.625	758.	6.592	914.	6.103		
844.	6.773	844.	6.720	844.	6.650	844.	6.620			CURVE 77*	
877.	6.795	877.	6.708	877.	6.632	877.	6.603	CURVE 72*			
CURVE 55*		CURVE 59*		CURVE 63*		CURVE 67*		$\lambda = 4.0$		$\lambda = 2.5$	
$\lambda = 8.0$		$\lambda = 10.3$		$\lambda = 12.3$		$\lambda = 14.3$					
359.	6.621	399.	6.526	399.	6.480	433.	6.447	514.	6.344	637.	6.152
463.	6.657	453.	6.616	463.	6.553	627.	6.525	643.	6.366	635.	6.156
617.	6.715	617.	6.653	617.	6.593	758.	6.572	738.	6.375	639.	6.175
755.	6.734	753.	6.717	753.	6.620	644.	6.592	914.	6.053	755.	6.202
844.	6.754	844.	6.721	844.	6.643	877.	6.616	914.	6.056	912.	
877.	6.794	877.	6.663	877.	6.624			CURVE 73*			
CURVE 56*		CURVE 60*		CURVE 64*		CURVE 68*		$\lambda = 4.5$		$\lambda = 2.5$	
$\lambda = 8.5$		$\lambda = 10.5$		$\lambda = 12.5$		$\lambda = 2.0$					
359.	6.629	399.	6.526	399.	6.430	643.	6.109	514.	6.334	634.	6.080
463.	6.670	463.	6.605	463.	6.533	738.	6.364	643.	6.070	637.	6.124
527.	6.763	617.	6.672	617.	6.574	914.	6.163	914.	6.376	639.	6.126
758.	6.724	758.	6.665	758.	6.606	CURVE 69*		CURVE 74*			
844.	6.752	844.	6.808	844.	6.634	$\lambda = 2.5$		$\lambda = 5.0$			
877.	6.792	877.	6.665	877.	6.623	514.	6.019	514.	6.019	738.	6.146
CURVE 57*		CURVE 61*		CURVE 65*		CURVE 69*		$\lambda = 5.5$		$\lambda = 3.0$	
$\lambda = 9.0$		$\lambda = 11.0$		$\lambda = 13.0$		$\lambda = 2.0$					
359.	6.666	399.	6.560	399.	6.390	643.	6.104	738.	6.045	738.	6.174
463.	6.693	483.	6.696	483.	6.504	643.	6.084	914.	6.070	637.	6.149
527.	6.732	617.	6.632	617.	6.557	738.	6.370	738.	6.376	738.	6.149
758.	6.724	758.	6.684	758.	6.603	CURVE 75*		$\lambda = 5.5$			
844.	6.752	844.	6.657	844.	6.623	$\lambda = 2.5$					
877.	6.792	877.	6.643	877.	6.615	514.	6.072	514.	6.062	CURVE 60*	
						399.	6.390	643.	6.067	$\lambda = 3.5$	
						463.	6.333	643.	6.029	912.	6.160
						527.	6.322	643.	6.042	738.	6.122
						758.	6.323	738.	6.120	914.	6.072
						844.	6.372	914.	6.120	637.	6.072
						877.	6.372	914.	6.120	639.	6.072

* NOT SHOWN IN FIGURE.

TABLE 20-4. EXPERIMENTAL NORMAL SPECTRAL EMMITTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE) (CONTINUED)

T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ
CURVE 80 (CONT.)*											
6.37*	0.106	4.73*	0.106	4.73*	0.026	4.84*	0.105	6.46*	0.066	55.3*	0.032
6.39*	0.117	4.84*	0.014	4.93*	0.060	6.54*	0.084	56.8*	0.068	63.3*	0.094
7.35*	0.116	6.37*	0.062	6.45*	0.097	7.56*	0.116	63.6*	0.074	CURVE 102*	
7.55*	0.153	6.39*	0.039	6.58*	0.113	7.69*	0.194	68.7*	0.060	$\lambda = 5.5$	
9.12*		7.33*	0.099	7.56*	0.154	9.18*	0.122	93.3*	0.096	CURVE 101 (CONT.)*	
CURVE 81*											
7.55*	0.092	7.55*	0.125	7.63*	0.190	7.91*	0.190	CURVE 93*		55.3*	0.051
$\lambda = 4.0$		9.12*	0.110	9.18*	0.110	$\lambda = 5.5$		$\lambda = 3.5$		56.8*	0.040
CURVE 82*											
$\lambda = 4.5$		CURVE 85**		$\lambda = 6.0$		6.46*	0.040	55.3*	0.050	63.6*	0.055
6.64*	0.057	6.64*	0.029	6.73*	0.011	6.84*	0.057	55.4*	0.056	63.7*	0.057
6.77*		6.73*	0.100	6.73*	0.280	6.95*	0.099	63.6*	0.075	CURVE 103*	
6.85*		6.73*	0.102	6.79*	0.045	7.02*	0.073	68.7*	0.073	$\lambda = 6.0$	
7.33*		6.79*	0.103	6.95*	0.035	7.16*	0.105	83.3*	0.105	$\lambda = 6.0$	
7.55*		7.33*	0.091	6.91*	0.196	CURVE 94*		$\lambda = 5.0$		55.3*	0.053
9.12*		7.55*	0.097	7.63*	0.134	7.69*	0.154	$\lambda = 4.0$		56.8*	0.054
$\lambda = 4.5$		9.12*	0.104	9.18*	0.152	9.18*	0.152	$\lambda = 4.0$		63.6*	0.055
CURVE 86**											
7.79*	0.261	CURVE 90**		$\lambda = 2.0$		6.46*	0.019	55.3*	0.055	63.6*	0.075
8.06*	0.257	8.06*	0.029	8.06*	0.159	8.06*	0.034	56.8*	0.058	63.7*	0.074
8.37*		8.46*	0.235	8.56*	0.057	8.56*	0.060	63.6*	0.073	CURVE 104*	
8.59*		8.56*	0.297	8.56*	0.235	8.77*	0.063	68.7*	0.085	$\lambda = 6.5$	
8.81*		8.17*	0.157	8.56*	0.243	8.77*	0.110	83.3*	0.100	$\lambda = 6.5$	
9.12*		9.12*	0.123	9.18*	0.176	9.18*	0.262	$\lambda = 2.0$		CURVE 95*	
9.12*		9.12*	0.125	9.18*	0.277	9.18*	0.017	55.3*	0.055	63.6*	0.070
CURVE 87**											
$\lambda = 5.0$		$\lambda = 2.5$		$\lambda = 2.5$		7.69*	0.130	56.8*	0.145	55.3*	0.048
7.72*	0.053	7.72*	0.128	7.72*	0.128	7.91*	0.145	63.6*	0.084	56.8*	0.052
7.72*	0.245	7.72*	0.128	7.72*	0.115	7.72*	0.057	68.7*	0.067	63.6*	0.067
7.77*		7.77*	0.195	7.77*	0.156	7.77*	0.145	83.3*	0.099	63.7*	0.055
7.79*		7.79*	0.095	7.79*	0.156	7.79*	0.007	$\lambda = 2.5$		CURVE 101*	
7.79*		7.79*	0.104	7.79*	0.194	7.79*	0.075	55.3*	0.050	$\lambda = 5.0$	
7.92*		7.92*	0.126	7.92*	0.147	7.92*	0.093	56.8*	0.095	$\lambda = 7.5$	
7.92*		7.92*	0.126	7.92*	0.240	7.92*	0.124	63.6*	0.079	68.7*	0.052
7.92*		7.92*	0.120	7.92*	0.120	7.92*	0.103	60.7*	0.047	56.8*	0.053
7.92*		7.92*	0.114	7.92*	0.129	7.92*	0.114	83.3*	0.114	63.6*	0.070

* NOT SHOWN IN FIGURE.

TABLE 2A-4. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE) (CONTINUED)

(WAVELENGTH, λ , μm ; TEMPERATURE, T; K; EMITTANCE, ϵ)

	T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ	
CURVE 107*	$\lambda = 3.0$	CURVE 113 $\lambda = 3.0$		CURVE 117* $\lambda = 5.0$		CURVE 121* $\lambda = 7.0$		CURVE 126* $\lambda = 9.5$		CURVE 133* $\lambda = 13.0$	
6.87*	0.042	472.	0.044	472.	0.053	545.	0.015	669.	0.012	769.	0.054
6.33*	0.035	565.	0.055	546.	0.057	576.	0.029	765.	0.063	814.	0.055
CURVE 108*	$\lambda = 3.5$	573.	0.075	573.	0.072	669.	0.035	814.	0.078		CURVE 134*
		669.	0.080	569.	0.077	769.	0.067			$\lambda = 13.5$	
		769.	0.095	769.	0.102	814.	0.097				CURVE 127*
		814.	0.118	814.	0.120					$\lambda = 10.0$	
CURVE 107*	$\lambda = 3.0$	CURVE 114* $\lambda = 3.5$		CURVE 118* $\lambda = 5.5$		CURVE 122* $\lambda = 7.5$		CURVE 125* $\lambda = 9.5$		769.	0.041
6.37*	0.034	472.	0.061	472.	0.060	546.	0.012	669.	0.012	614.	0.043
6.33*	0.034	546.	0.056	546.	0.061	578.	0.023	769.	0.023		CURVE 135*
		573.	0.055	573.	0.066	669.	0.030	814.	0.030	$\lambda = 14.0$	
CURVE 113*	$\lambda = 3.5$	669.	0.074	669.	0.074	769.	0.069	769.	0.019		CURVE 128*
		769.	0.096	769.	0.099	814.	0.085	814.	0.023	$\lambda = 10.5$	
CURVE 113*	$\lambda = 3.5$	814.	0.116	814.	0.108						CURVE 136*
6.33*	0.003	CURVE 115* $\lambda = 4.0$		CURVE 119* $\lambda = 6.0$		CURVE 123* $\lambda = 8.0$		CURVE 129* $\lambda = 11.0$		769.	0.075
CURVE 111*	$\lambda = 2.0$	472.	0.059	472.	0.038	546.	0.020	769.	0.075	603.	0.079
		546.	0.055	546.	0.039	573.	0.062	814.	0.078	681.	0.067
5.5*	2.014	576.	0.066	573.	0.048	669.	0.051	CURVE 130* $\lambda = 11.5$		731.	0.034
5.78*	0.053	669.	0.074	669.	0.048	769.	0.069			768.	0.087
5.5*	0.137	769.	0.101	769.	0.082	814.	0.055			803.	0.105
7.59*	0.135	814.	0.115	814.	0.090						CURVE 137*
5.24*	0.175	CURVE 116* $\lambda = 4.5$		CURVE 120* $\lambda = 6.5$		CURVE 124* $\lambda = 8.5$		CURVE 129* $\lambda = 11.5$		769.	0.076
CURVE 112*	$\lambda = 2.5$	472.	0.064	472.	0.005	546.	0.019	769.	0.069	569.	0.031
		546.	0.053	546.	0.017	573.	0.035	814.	0.071	603.	0.069
5.72*	0.031	578.	0.072	573.	0.037	669.	0.055	CURVE 131* $\lambda = 12.0$		681.	0.056
5.6*	0.059	669.	0.076	669.	0.039	769.	0.071			731.	0.077
5.79*	0.112	769.	0.116	769.	0.075	814.	0.054			768.	0.089
7.63*	0.171	814.	0.118	814.	0.093					803.	0.090
6.14*	0.143										CURVE 138*
										$\lambda = 3.0$	
										769.	0.061
										814.	0.055
											470.
											568.
											0.020
											0.042

* NOT SHOWN IN FIGURE.

TABLE 29-4. EXPERIMENTAL NORMAL SPECTRAL EMISSANCE OF ALUMINUM (TEMPERATURE DEPENDENCE) (CONTINUED)

[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMISSANCE, ϵ]

	T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ	T	ϵ
CURVE 138 (CONT.)*												
			CURVE 142*		CURVE 146*		CURVE 150 (CONT.)*		CURVE 156 (CONT.)*		CURVE 160*	
			$\lambda = 5.0$		$\lambda = 7.0$		$\lambda = 10.0$		$\lambda = 14.0$		$\lambda = 4.0$	
603.	0.062	470.	0.052	568.	0.010	731.	0.043	644.	0.113	491.	0.007	
631.	0.052	568.	0.043	603.	0.024	768.	0.060	724.	0.130	513.	0.337	
731.	0.070	603.	0.054	631.	0.047	808.	0.079	733.	0.190	623.	0.087	
768.	0.373	603.	0.054	731.	0.055			863.	0.177	644.	0.387	
808.	0.083	621.	0.061	768.	0.066					724.	0.021	
CURVE 139*												
			$\lambda = 3.5$		$\lambda = 7.0$		$\lambda = 9.5$		CURVE 157*		CURVE 161*	
									$\lambda = 2.5$		$\lambda = 4.5$	
470.	0.631	768.	0.086	808.	0.075	861.	0.033	731.	0.035	491.	0.102	
568.	0.545	808.	0.086	861.	0.056	768.	0.056	768.	0.056	513.	0.065	
631.	0.561	861.	0.082	660.	0.025			623.	0.120	644.	0.094	
731.	0.059	660.	0.034	603.	0.017	CURVE 152*		724.	0.111	513.	0.024	
768.	0.574	603.	0.043	631.	0.046	$\lambda = 10.0$		733.	0.150	623.	0.084	
808.	0.086	631.	0.060	731.	0.053	681.	0.030	863.	0.147	644.	0.085	
CURVE 149*												
			$\lambda = 4.0$		$\lambda = 7.0$		$\lambda = 9.0$		CURVE 158*		CURVE 162*	
									$\lambda = 3.0$		$\lambda = 5.0$	
470.	0.325	768.	0.277	768.	0.148*			768.	0.052	491.	0.042	
568.	0.644	808.	0.325	808.	0.144*	CURVE 144*		768.	0.049	513.	0.045	
631.	0.659	861.	0.312	660.	0.044	$\lambda = 6.0$		768.	0.049	623.	0.105	
660.	0.351	731.	0.053	681.	0.046			724.	0.049	644.	0.093	
731.	0.627	660.	0.043	768.	0.053	CURVE 154*		733.	0.129	623.	0.072	
768.	0.673	631.	0.055	808.	0.074	$\lambda = 11.0$		813.	0.125	644.	0.085	
808.	0.031	731.	0.052	861.	0.149*	CURVE 148*		768.	0.014	724.	0.038	
CURVE 141*												
			$\lambda = 4.5$		$\lambda = 8.0$		$\lambda = 8.0$		CURVE 153*		CURVE 163*	
									$\lambda = 10.5$		$\lambda = 5.5$	
470.	0.325	768.	0.076	768.	0.076	CURVE 144*		768.	0.048	491.	0.040	
568.	0.644	808.	0.076	808.	0.076	$\lambda = 6.0$		768.	0.048	513.	0.052	
631.	0.659	861.	0.076	660.	0.076			724.	0.048	623.	0.095	
660.	0.351	731.	0.076	681.	0.076	CURVE 145*		733.	0.067	644.	0.092	
731.	0.627	631.	0.076	768.	0.076	$\lambda = 11.5$		813.	0.074	724.	0.095	
768.	0.673	603.	0.076	808.	0.076			768.	0.046	724.	0.073	
808.	0.031	731.	0.056	861.	0.076	CURVE 150*		863.	0.053	733.	0.103	
CURVE 141*												
			$\lambda = 4.5$		$\lambda = 6.0$		$\lambda = 9.0$		CURVE 156*		CURVE 163*	
									$\lambda = 2.0$		$\lambda = 5.5$	
470.	0.022	768.	0.022	808.	0.033	CURVE 145*		603.	0.006	491.	0.040	
568.	0.043	631.	0.042	681.	0.042	$\lambda = 6.5$		631.	0.042	513.	0.052	
631.	0.057	731.	0.052	768.	0.052			731.	0.049	623.	0.095	
660.	0.057	660.	0.052	808.	0.052	CURVE 154*		863.	0.067	644.	0.092	
681.	0.052	631.	0.052	681.	0.052	$\lambda = 11.5$		768.	0.074	724.	0.095	
731.	0.053	621.	0.053	768.	0.053			768.	0.046	724.	0.073	
768.	0.074	731.	0.056	861.	0.056	CURVE 150*		863.	0.053	733.	0.103	
808.	0.036	768.	0.037	861.	0.037	$\lambda = 9.0$		863.	0.117	863.	0.113	

* NOT SHOWN IN FIGURE.

TABLE 20-4. EXPERIMENTAL NORMAL SPECTRAL EMITTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE) (CONTINUED)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T	ϵ
CURVE 164*	
$\lambda = 6.0$	
623.	0.034
644.	0.058
724.	0.065
733.	0.093
883.	0.107
CURVE 165*	
$\lambda = 6.5$	
644.	0.026
883.	0.097
CURVE 166*	
$\lambda = 7.0$	
644.	0.028
883.	0.107
CURVE 167*	
$\lambda = 7.5$	
644.	0.020
883.	0.105
CURVE 168*	
$\lambda = 8.0$	
644.	0.016
883.	0.107

* NOT SHOWN IN FIGURE.




FIGURE 20-3. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM
(WAVELENGTH DEPENDENCE).

TABLE 20-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM (Wavelength Dependence)

Cur. Ref. No.	Author(s) No.	Year of	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1	T27253	Wallin, D.R.	1960	0.30-2.50	298	Foil; cemented on fiberglass laminate; $\theta \sim 0^\circ$, $\omega' = 2\pi$.
2	T27424	Bennett, H.E., and Bennett, J.M., and Ashley, E.J.	1962	0.550-32	298	99.998 pure; Al film (0.065 to 0.11 μm thick), evaporated at 1×10^{-5} mm Hg, super-smooth fused quartz optical flats as substrate, no watermarks or other blemishes on the substrate surface, no shadows or streaks in the evaporated Al film; freshly prepared; measured in dry nitrogen; $\theta = 5^\circ$, $\theta' = 5^\circ$, reported error $\pm 0.1\%$.
3	T27424	Bennett, H.E., et al.	1962	0.550-32	298	99.998 pure; Al film (0.065 to 0.11 μm thick), evaporated at 1×10^{-5} mm Hg, super-smooth fused quartz optical flats as substrate, no watermarks or other blemishes on the substrate surfaces, no shadows or streaks in the evaporated Al film; aged in air for several weeks; measured in dry nitrogen; $\theta = 5^\circ$, $\theta' = 5^\circ$, reported error $\pm 0.1\%$.
4	T28940	Dunkle, R.V. and Gier, J.T.	1953	1.00-15.00	300	Foil; data extracted from smooth curve; converted from $R(2\pi, 5^\circ)$; $\theta = 5^\circ$, $\omega' = 2\pi$, reported error $\pm 2.6\%$.
5	T28940	Dunkle, R.V. and Gier, J.T.	1953	1.00-15.00	300	Disc; polished, roughened (roughness approx. 1.27 μm); data extracted from smooth curve; converted from $R(2\pi, 5^\circ)$; $\theta = 5^\circ$, $\omega' = 2\pi$, reported error $\pm 2.6\%$.
6	T28940	Dunkle, R.V. and Gier, J.T.	1953	1.00-15.00	300	Disc; commercial finish; data extracted from smooth curve; converted from $R(2\pi, 5^\circ)$; $\theta = 5^\circ$, $\omega' = 2\pi$, reported error $\pm 4.3\%$.
7	T28940	Dunkle, R.V. and Gier, J.T.	1953	1.00-15.00	300	Disc; polished; data extracted from smooth curve; converted from $R(2\pi, 5^\circ)$; $\theta = 5^\circ$, $\omega' = 2\pi$, reported error $\pm 2.7\%$.
8	T25806	Holland, L. and Williams, B.J.	1955	0.46-0.60	298	99 pure; vacuum deposited on glass; measured immediately after removed from vacuum chamber; calculated by authors from $\rho = 1 - \alpha$ using an incandescent tungsten lamp as source; $\theta = 10^\circ$, $\omega' = 2\pi$, reported error $\pm 0.5\%$.
9	T25806	Holland, L. and Williams, B.J.	1955	0.46-0.60	298	The above specimen and conditions except exposed to the atmosphere for 8 days.
10	T25806	Holland, L. and Williams, B.J.	1955	0.46-0.60	298	99.99 pure; vacuum deposited on glass; measured immediately after removed from vacuum chamber; calculated by authors from $\rho = 1 - \alpha$ using an incandescent tungsten lamp as source; $\theta = 10^\circ$, $\omega' = 2\pi$, reported error $\pm 0.5\%$.
11	T25806	Holland, L. and Williams, B.J.	1955	0.46-0.60	298	The above specimen and conditions except exposed to atmosphere for 8 days.
12	T7159	Wulf, J.	1934	0.235-0.578	298	Disc; cold worked, annealed, etch tested, polished, stored in a solution of NaOH + NaF, washed and dried; $\theta \sim 0^\circ$, $\theta' \sim 0^\circ$, $\omega' = 2\pi$, reported error 2%.
13	T36320	Davies, J.M. and Zagieboylo, W.	1965	0.300-1.000	298	Sand blasted; $\theta \sim 0^\circ$, $\omega' = 2\pi$.
14	T33512	Leigh, C.H.	1962	2.01-25.96	298	Polished; converted from $R(2\pi, 0^\circ)$; $\theta \sim 0^\circ$, $\omega' = 2\pi$.
15	T23512	Leigh, C.H.	1962	1.57-25.94	298	The above specimen and conditions except after particle impact.
16	T29648	Geir, J.T., Possner, L., Test, A.J., Dunkle, R.V., and Bevans, J.T.	1949	1.01-15.00	~298	Foil; data extracted from smooth curve; $\theta = 0^\circ$, $\omega' = 2\pi$, reported error 5%.
17	T40413	Schocken, K. and Fountain, J.A.	1964	2.00-23.99	298	Polished; $\theta \sim 0^\circ$, $\theta' \sim 0^\circ$.

TABLE 20-5. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF ALUMINUM (Wavelength Dependence) (continued)

Cur. Ref. No.	Ref. No.	Author(s) and Fountain, J.A.	Year 1964	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
18 T40-13	Schocken, K. and Fountain, J.A.	1964	2.00-23.99	298	The above specimen and conditions except cratered with spherical particles (100 μm diameter) of Zircalloy at 1.5 km sec ⁻¹ ; average crater diameter 123 μm; average crater depth 289 μm; Knoop hardness 22 (100 g load).		
19 T40-13	Schocken, K. and Fountain, J.A.	1964	2.00-22.00	298	Different sample, the above specimen and conditions except cratered with spherical particles (100 μm diameter) of tungsten at 7 km sec ⁻¹ ; average crater diameter 54 μm; average crater depth 183 μm.		

TABLE 2j-6. EXPERIMENTAL NOMINAL SPECTRAL REFLECTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 298.$	λ	ρ	CURVE 2 (CONT.)	λ	ρ	CURVE 3 (CONT.)	λ	ρ	CURVE 4 (CONT.)	λ	ρ	CURVE 5 (CONT.)	λ	ρ	CURVE 6 $T = 300.$
0.30	0.796	40.	0.9795	2.	0.9699	4.50	0.925	1.75	0.685	13.25	0.646						
0.33	0.775	5.	0.9812	3.	0.9735	4.75	0.948	2.00	0.715	13.50	0.842						
0.40	0.796	6.	0.9823	4.	0.9758	5.00	0.940	2.50	0.740	13.75	0.848						
0.50	0.819	7.	0.9831	5.	0.9772	5.25	0.939	2.75	0.745	14.00	0.840						
0.60	0.841	8.	0.9837	6.	0.9794	5.50	0.940	3.00	0.725	14.25	0.341						
0.66	0.812	9.	0.9541	7.	0.9794	5.75	0.948	3.25	0.740	14.50	0.643						
0.70	0.830	10.	0.9845	8.	0.9801	6.00	0.950	3.50	0.772	14.75	0.655						
0.752	0.825	11.	0.9849	9.	0.9607	6.25	0.960	3.75	0.780	15.00	0.340						
0.80	0.800	12.	0.9854	10.	0.9812	6.50	0.948	4.00	0.786								
1.00	0.845	13.	0.9857	11.	0.9816	6.75	0.950	4.25	0.780								
1.20	0.836	14.	0.9861	12.	0.9821	7.25	0.950	4.50	0.793								
1.40	0.873	15.	0.9863	13.	0.9823	7.50	0.945	4.75	0.800								
1.60	0.877	16.	0.9873	14.	0.9830	7.75	0.949	5.00	0.800								
1.80	0.877	18.	0.9873	15.	0.9833	8.00	0.945	5.25	0.602								
2.00	0.896	20.	0.9673	16.	0.9833	8.25	0.942	5.50	0.803								
2.20	0.884	21.	0.9853	18.	0.9845	8.50	0.951	5.75	0.819								
2.40	0.899	24.	0.9887	20.	0.9852	8.75	0.949	6.00	0.800								
2.50	0.905	26.	0.9590	22.	0.9855	9.25	0.960	6.25	0.805								
					0.9861	10.00	0.963	7.00	0.805								
					0.9864	10.60	0.940	7.50	0.821								
					0.9867	10.75	0.955	7.75	0.775								
					0.9870	11.00	0.949	8.00	0.819								
					0.9572	11.25	0.960	8.25	0.821								
					0.9572	11.50	0.951	8.50	0.820								
					0.9867	11.75	0.955	8.75	0.819								
					0.9870	12.00	0.949	9.00	0.819								
					0.9870	12.25	0.960	9.25	0.821								
					0.9870	12.50	0.960	9.50	0.821								
					0.9870	12.75	0.960	9.75	0.821								
					0.9870	13.00	0.960	10.00	0.821								
					0.9870	13.25	0.960	10.25	0.821								
					0.9870	13.50	0.960	10.50	0.821								
					0.9870	13.75	0.960	10.75	0.821								
					0.9870	14.00	0.935	11.00	0.821								
					0.9870	14.25	0.955	11.25	0.821								
					0.9870	14.50	0.955	11.50	0.821								
					0.9870	14.75	0.955	11.75	0.821								
					0.9870	15.00	0.925	12.00	0.821								
					0.9870	15.25	0.925	12.25	0.821								
					0.9870	15.50	0.925	12.50	0.821								
					0.9870	15.75	0.925	12.75	0.821								
					0.9870	16.00	0.925	13.00	0.821								
					0.9870	16.25	0.925	13.25	0.821								
					0.9870	16.50	0.925	13.50	0.821								
					0.9870	16.75	0.925	13.75	0.821								
					0.9870	17.00	0.925	14.00	0.821								
					0.9870	17.25	0.925	14.25	0.821								
					0.9870	17.50	0.925	14.50	0.821								
					0.9870	17.75	0.925	14.75	0.821								
					0.9870	18.00	0.925	15.00	0.821								
					0.9870	18.25	0.925	15.25	0.821								
					0.9870	18.50	0.925	15.50	0.821								
					0.9870	18.75	0.925	15.75	0.821								
					0.9870	19.00	0.925	16.00	0.821								
					0.9870	19.25	0.925	16.25	0.821								
					0.9870	19.50	0.925	16.50	0.821								
					0.9870	19.75	0.925	16.75	0.821								
					0.9870	20.00	0.925	17.00	0.821								
					0.9870	20.25	0.925	17.25	0.821								
					0.9870	20.50	0.925	17.50	0.821								
					0.9870	20.75	0.925	17.75	0.821								
					0.9870	21.00	0.925	18.00	0.821								
					0.9870	21.25	0.925	18.25	0.821								
					0.9870	21.50	0.925	18.50	0.821								
					0.9870	21.75	0.925	18.75	0.821								
					0.9870	22.00	0.925	19.00	0.821								
					0.9870	22.25	0.925	19.25	0.821								
					0.9870	22.50	0.925	19.50	0.821								
					0.9870	22.75	0.925	19.75	0.821								
					0.9870	23.00	0.925	20.00	0.821								
					0.9870	23.25	0.925	20.25	0.821								
					0.9870	23.50	0.925	20.50	0.821								
					0.9870	23.75	0.925	20.75	0.821								
					0.9870	24.00	0.925	21.00	0.821								
					0.9870	24.25	0.925	21.25	0.821								
					0.9870	24.50	0.925	21.50	0.821								
					0.9870	24.75	0.925	21.75	0.821								
					0.9870	25.00	0.925	22.00	0.821								
					0.9870	25.25	0.925	22.25	0.821								
					0.9870	25.50	0.925	22.50	0.821								
					0.9870	25.75	0.925	22.75	0.821								
					0.9870	26.00	0.925	23.00	0.821								
					0.9870	26.25	0.925	23.25	0.821								
					0.9870	26.50	0.925	23.50	0.821								
					0.9870	26.75	0.925	23.75	0.821								
					0.9870	27.00	0.925	24.00	0.821								
					0.9870	27.25	0.925	24.25	0.821								
					0.9870	27.50	0.925	24.50	0.821								
					0.9870	27.75	0.925	24.75	0.821								
					0.9870	28.00	0.925	25.00	0.821								
					0.9870	28.25	0.925	25.25	0.821								
					0.9870	28.50	0.925	25.50	0.821								
					0.9870	28.75	0.925	25.75	0.821								
					0.9870	29.00	0.925	26.00	0.821								
					0.9870	29.25	0.925	26.25	0.821								
					0.9870	29.50	0.925	26.50	0.821								

TABLE 20-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE) (CONTINUED)

WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ

λ	ρ	CURVE 6 (CONT.)	λ	ρ	CURVE 7 (CONT.)	λ	ρ	CURVE 7 (CONT.)	λ	ρ	CURVE 12 $T = 298.$	λ	ρ	CURVE 15 $T = 298.$	λ	ρ	CURVE 16 (CONT.)
3.00	0.972	3.00	0.875	1.425	0.951	0.235	0.413	1.57	7.25	0.959	7.51	7.51	0.959	7.51	0.959	7.51	
3.25	0.859	3.25	0.679	1.423	0.969	0.235	0.434	4.34	7.75	0.970	7.75	7.75	0.970	7.75	0.970	7.75	
3.50	0.991	3.50	0.691	1.472	0.955	0.254	0.452	6.42	7.93	0.970	7.93	7.93	0.970	7.93	0.970	7.93	
3.75	0.888	3.75	0.895	1.500	0.972	0.265	0.523	0.523	7.17	0.945	7.93	7.93	0.945	7.93	0.945	7.93	
4.00	0.999	4.00	0.915	1.500	0.972	0.293	0.662	8.53	8.26	0.946	8.26	8.26	0.946	8.26	0.946	8.26	
4.25	0.939	4.25	0.890	1.425	0.679	0.312	0.679	11.73	0.953	8.53	8.53	0.953	8.53	0.953	8.53	0.953	
4.50	0.885	4.50	0.831	4.75	0.910	0.334	0.722	14.46	0.954	8.76	8.76	0.954	8.76	0.954	8.76	0.954	
4.75	0.828	4.75	0.960	3.46	0.889	0.366	0.749	17.38	0.961	9.32	9.32	0.961	9.32	0.961	9.32	0.961	
5.00	0.926	5.00	0.912	3.53	0.669	0.406	0.712	19.33	0.961	9.29	9.29	0.961	9.29	0.961	9.29	0.961	
5.25	0.859	5.25	0.946	3.57	0.900	0.435	0.759	22.54	0.957	9.35	9.35	0.957	9.35	0.957	9.35	0.957	
5.50	0.926	5.50	0.925	3.75	0.935	0.546	0.780	25.94	0.952	9.79	9.79	0.952	9.79	0.952	9.79	0.952	
5.75	0.828	5.75	0.942	6.00	0.936	0.578	0.781	30.61	0.973	9.73	9.73	0.973	9.73	0.973	9.73	0.973	
6.00	0.912	6.00	0.930	6.50	0.930	0.578	0.781	34.27	0.973	9.73	9.73	0.973	9.73	0.973	9.73	0.973	
6.50	0.923	6.50	0.942	7.00	0.932	0.615	0.777	39.53	0.973	9.73	9.73	0.973	9.73	0.973	9.73	0.973	
6.75	0.915	6.75	0.942	7.25	0.935	0.686	0.871	4.31	0.974	9.74	9.74	0.974	9.74	0.974	9.74	0.974	
7.00	0.922	7.00	0.960	7.25	0.953	0.686	0.871	4.26	0.974	9.74	9.74	0.974	9.74	0.974	9.74	0.974	
7.25	0.919	7.25	0.951	7.50	0.957	0.85	0.733	1.50	0.944	11.92	11.92	0.944	11.92	0.944	11.92	0.944	
7.50	0.915	7.50	0.939	7.75	0.939	0.85	0.733	1.79	0.945	12.73	12.73	0.945	12.73	0.945	12.73	0.945	
7.75	0.912	7.75	0.959	8.00	0.939	0.86	0.753	1.96	0.925	12.62	12.62	0.925	12.62	0.925	12.62	0.925	
8.00	0.912	8.00	0.960	8.25	0.959	0.86	0.753	2.25	0.957	12.27	12.27	0.957	12.27	0.957	12.27	0.957	
8.25	0.919	8.25	0.960	8.50	0.960	0.900	0.774	2.50	0.959	12.51	12.51	0.959	12.51	0.959	12.51	0.959	
8.50	0.919	8.50	0.955	8.75	0.955	0.929	0.751	2.75	0.955	12.79	12.79	0.955	12.79	0.955	12.79	0.955	
8.75	0.915	8.75	0.959	9.00	0.960	0.933	0.753	2.93	0.956	13.04	13.04	0.956	13.04	0.956	13.04	0.956	
9.00	0.919	9.00	0.960	9.25	0.960	0.933	0.753	3.27	0.964	13.26	13.26	0.964	13.26	0.964	13.26	0.964	
9.25	0.919	9.25	0.960	9.50	0.960	0.933	0.753	3.50	0.955	13.50	13.50	0.955	13.50	0.955	13.50	0.955	
9.50	0.919	9.50	0.955	9.75	0.955	0.933	0.753	3.75	0.953	13.79	13.79	0.953	13.79	0.953	13.79	0.953	
9.75	0.915	9.75	0.959	10.00	0.960	0.933	0.753	4.00	0.964	14.01	14.01	0.964	14.01	0.964	14.01	0.964	
10.00	0.912	10.00	0.959	10.25	0.959	0.933	0.753	4.24	0.974	14.28	14.28	0.974	14.28	0.974	14.28	0.974	
10.25	0.912	10.25	0.959	10.50	0.959	0.933	0.753	4.48	0.958	14.53	14.53	0.958	14.53	0.958	14.53	0.958	
10.50	0.912	10.50	0.959	10.75	0.959	0.933	0.753	4.76	0.969	14.75	14.75	0.969	14.75	0.969	14.75	0.969	
10.75	0.912	10.75	0.959	11.00	0.959	0.933	0.753	5.00	0.969	15.00	15.00	0.969	15.00	0.969	15.00	0.969	
11.00	0.912	11.00	0.959	11.25	0.959	0.933	0.753	5.24	0.972	15.27	15.27	0.972	15.27	0.972	15.27	0.972	
11.25	0.912	11.25	0.959	11.50	0.959	0.933	0.753	5.50	0.969	15.55	15.55	0.969	15.55	0.969	15.55	0.969	
11.50	0.912	11.50	0.959	11.75	0.959	0.933	0.753	5.73	0.969	15.73	15.73	0.969	15.73	0.969	15.73	0.969	
11.75	0.912	11.75	0.959	12.00	0.959	0.933	0.753	6.00	0.972	16.00	16.00	0.972	16.00	0.972	16.00	0.972	
12.00	0.912	12.00	0.959	12.25	0.959	0.933	0.753	6.24	0.974	16.27	16.27	0.974	16.27	0.974	16.27	0.974	
12.25	0.912	12.25	0.959	12.50	0.959	0.933	0.753	6.50	0.974	16.53	16.53	0.974	16.53	0.974	16.53	0.974	
12.50	0.912	12.50	0.959	12.75	0.959	0.933	0.753	6.73	0.974	16.73	16.73	0.974	16.73	0.974	16.73	0.974	
12.75	0.912	12.75	0.959	13.00	0.959	0.933	0.753	7.00	0.974	17.00	17.00	0.974	17.00	0.974	17.00	0.974	
13.00	0.912	13.00	0.959	13.25	0.959	0.933	0.753	7.27	0.974	17.27	17.27	0.974	17.27	0.974	17.27	0.974	
13.25	0.912	13.25	0.959	13.50	0.959	0.933	0.753	7.53	0.974	17.53	17.53	0.974	17.53	0.974	17.53	0.974	
13.50	0.912	13.50	0.959	13.75	0.959	0.933	0.753	7.79	0.974	17.79	17.79	0.974	17.79	0.974	17.79	0.974	
13.75	0.912	13.75	0.959	14.00	0.959	0.933	0.753	8.06	0.974	18.06	18.06	0.974	18.06	0.974	18.06	0.974	
14.00	0.912	14.00	0.959	14.25	0.959	0.933	0.753	8.32	0.974	18.32	18.32	0.974	18.32	0.974	18.32	0.974	
14.25	0.912	14.25	0.959	14.50	0.959	0.933	0.753	8.58	0.974	18.58	18.58	0.974	18.58	0.974	18.58	0.974	
14.50	0.912	14.50	0.959	14.75	0.959	0.933	0.753	8.85	0.974	18.85	18.85	0.974	18.85	0.974	18.85	0.974	
14.75	0.912	14.75	0.959	15.00	0.959	0.933	0.753	9.12	0.974	19.12	19.12	0.974	19.12	0.974	19.12	0.974	
15.00	0.912	15.00	0.959	15.25	0.959	0.933	0.753	9.38	0.974	19.38	19.38	0.974	19.38	0.974	19.38	0.974	
15.25	0.912	15.25	0.959	15.50	0.959	0.933	0.753	9.64	0.974	19.64	19.64	0.974	19.64	0.974	19.64	0.974	
15.50	0.912	15.50	0.959	15.75	0.959	0.933	0.753	9.90	0.974	19.90	19.90	0.974	19.90	0.974	19.90	0.974	
15.75	0.912	15.75	0.959	16.00	0.959	0.933	0.753	10.16	0.974	20.16	20.16	0.974	20.16	0.974	20.16	0.974	
16.00	0.912	16.00	0.959	16.25	0.959	0.933	0.753	10.42	0.974	20.42	20.42	0.974	20.42	0.974	20.42	0.974	
16.25	0.912	16.25	0.959	16.50	0.959	0.933	0.753	10.68	0.974	20.68	20.68	0.974	20.68	0.974	20.68	0.974	
16.50	0.912	16.50	0.959	16.75	0.959	0.933	0.753	10.94	0.974	20.94	20.94	0.974	20.94	0.974	20.94	0.974	
16.75	0.912	16.75	0.959	17.00	0.959	0.933	0.753	11.20	0.974	21.20	21.20	0.974	21.20	0.974	21.20	0.974	
17.00	0.912	17.00	0.959	17.25	0.959	0.933	0.753	11.46	0.974	21.46	21.46	0.974	21.46	0.974	21.46	0.974	
17.25	0.912	17.25	0.959	17.50	0.959	0.933	0.753	11.72	0.974	21.72	21.72	0.974	21.72	0.974	21.72	0.974	
17.50	0.912	17.50	0.959	17.75	0.959	0.933	0.753	12.00	0.974	22.00	22.00	0.974	22.00	0.974	22.00	0.974	
17.75	0.912	17.75	0.959	18.00	0.959	0.933	0.753	12.26	0.974	22.26	22.26	0.974	22.26	0.974	22.26	0.974	
18.00	0.912	18.00	0.959	18.25	0.959	0.933	0.753	12.52	0.974	22.52	22.52	0.974	22.52	0.974	22.52	0.974	
18.25	0.912	18.25	0.959	18.50	0.959	0.933	0.753	12.78	0.974	22.78	22.78	0.974	22.78	0.974	22.78	0.974	
18.50	0.912	18.50	0.959	18.75	0.959	0.933	0.753	13.04	0.974	23.04	23.04	0.974	23.04	0.974	23.04	0.974	
18.75	0.912	18.75	0.959	19.00	0.959	0.933	0.753	13.30	0.974	23.30	23.30	0.974	23.30	0.974	23.30	0.974	
19.00	0.912	19.00	0.959	19.25	0.959	0.933	0.753	13.56	0.974	23.56	23.56	0.974	23.56	0.974	23.56	0.974	
19.25	0.912	19.25	0.959	19.50	0.959	0.933	0.753	13.82	0.974	23.82	23.82	0.974	23.82	0.974	23.82	0.974	
19.50	0.912	19.50	0.959	19.75	0.959	0.933	0.753	14.08	0.974	24.08	24.08	0.974	24.08	0.974	24.08	0.974	
19.75	0.912	19.75	0.959	20.00	0.959	0.933	0.753	14.34	0.974	24.34	24.34	0.974	24.34	0.974	24.34	0.974	
20.00	0.912	20.00	0.959	20.25	0.959	0.933	0.753	14.60	0.974	24.60	24.60	0.974	24.60	0.974	24.60	0.974	

TABLE 20-6. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE) (CONTINUED)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ]

λ ρ
 CURVE 17 (CONT.)

16.39	0.980
17.00	0.981
17.61	0.982
18.32	0.983
18.93	0.983
19.54	0.983
20.15	0.983
20.76	0.983
21.37	0.983
21.98	0.983
22.59	0.983
23.20	0.983
23.81	0.983

CURVE 18
 $T = 296.$

2.36	0.397
4.33	0.318
5.99	0.233
6.65	0.145
10.30	0.254
12.30	0.352
17.38	0.324
18.06	0.255
18.39	0.253
25.65	0.353
22.64	0.240
23.99	0.246

CURVE 19
 $T = 293.$

2.93	0.365
4.35	0.376
5.99	0.371
6.60	0.371
15.36	0.757
12.63	0.777
17.36	0.786
16.00	0.789
18.06	0.793
20.06	0.792
22.06	0.792




FIGURE 20-4. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE).

TABLE 20-7. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 T34454	Brandenberg, W. M., 1966 Clausen, O. W., and McKeown, D.	1966	0.45-2.00	298		Evaporated film; evaporation rate 300 Å sec^{-1} at $2 \times 10^{-6} \text{ mm Hg}$; measured in vacuum; aged 8 days before measurement; $\theta \sim 10^\circ$, reported error $\pm 1.4\%$.
2 T32388	Byrne, R. F. and Mancinelli, L. N.	1954	0.204-2.600	~298		Data extracted from smooth curve; $\theta \sim 0^\circ$.
3 T32388	Byrne, R. F. and Mancinelli, L. N.	1954	0.402-2.600	~298		Polished; data extracted from smooth curve; $\theta \sim 0^\circ$.
4 A00003	Harmon, N. F. (editor)	1974	2.5-20.0	673		Bulk sample; mechanically polished.
5 A00003	Harmon, N. F. (editor)	1974	2.5-20.0	293		The above specimen except at 293 K.

TABLE 20-8. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (WAVELENGTH DEPENDENCE, λ , μm ; TEMPERATURE, T, K; ABSORPTANCE, α)

λ	α	λ	α	CURVE 1 T = 298.	CURVE 2 (CONT.)	CURVE 4 (CONT.)	CURVE 5 (CONT.)
0.45	0.3982	1.352	0.662	7.4	0.344	19.9	0.0157
0.50	0.3987	1.445	0.667	6.3	0.307		
0.55	0.4002	1.793	0.655	9.1	0.314		
0.60	0.4037	2.505	0.644	11.6	0.3235		
0.65	0.4096	2.260	0.623	11.1	0.3272		
0.70	0.4169	2.403	0.639	12.7	0.3253		
0.75	0.4131	2.630	0.659	13.3	0.3222		
0.80	0.4141	2.423	0.639	14.2	0.3239		
0.85	0.4223	2.533	0.653	15.3	0.3234		
0.90	0.4254	2.514	0.657	16.6	0.3245		
0.95	0.4344	2.424	0.641	17.3	0.3226		
1.00	0.4424	2.398	0.627	19.5	0.3221		
1.05	0.4442	2.375	0.607	19.9	0.3212		
1.10	0.4442	2.353	0.584				
1.15	0.4438	2.331	0.564				
1.20	0.4423	2.313	0.547				
1.25	0.4397	2.297	0.527				
1.30	0.4342	2.281	0.506				
1.35	0.4264	2.267	0.487				
1.40	0.4163	2.253	0.467				
1.45	0.4053	2.241	0.447				
1.50	0.3944	2.231	0.427				
1.55	0.3832	2.223	0.407				
1.60	0.3722	2.216	0.386				
1.65	0.3619	2.210	0.365				
1.70	0.3519	2.205	0.345				
1.75	0.3419	2.200	0.324				
1.80	0.3319	2.196	0.304				
1.85	0.3213	2.192	0.284				
1.90	0.3108	2.188	0.264				
1.95	0.3003	2.184	0.244				
2.00	0.2898	2.180	0.224				
2.05	0.2786	2.176	0.204				
2.10	0.2674	2.172	0.184				
2.15	0.2562	2.168	0.164				
2.20	0.2451	2.164	0.144				
2.25	0.2340	2.160	0.124				
2.30	0.2230	2.156	0.104				
2.35	0.2120	2.152	0.084				
2.40	0.2010	2.148	0.064				
2.45	0.1900	2.144	0.044				
2.50	0.1790	2.140	0.024				
2.55	0.1680	2.136	0.004				
2.60	0.1570	2.132	-0.024				
2.65	0.1460	2.128	-0.044				
2.70	0.1350	2.124	-0.064				
2.75	0.1240	2.120	-0.084				
2.80	0.1130	2.116	-0.104				
2.85	0.1020	2.112	-0.124				
2.90	0.0910	2.108	-0.144				
2.95	0.0800	2.104	-0.164				
3.00	0.0690	2.100	-0.184				
3.05	0.0580	2.096	-0.204				
3.10	0.0470	2.092	-0.224				
3.15	0.0360	2.088	-0.244				
3.20	0.0250	2.084	-0.264				
3.25	0.0140	2.080	-0.284				
3.30	0.0030	2.076	-0.304				
3.35	-0.0070	2.072	-0.324				
3.40	-0.0180	2.068	-0.344				
3.45	-0.0270	2.064	-0.364				
3.50	-0.0360	2.060	-0.384				
3.55	-0.0450	2.056	-0.404				
3.60	-0.0540	2.052	-0.424				
3.65	-0.0630	2.048	-0.444				
3.70	-0.0720	2.044	-0.464				
3.75	-0.0810	2.040	-0.484				
3.80	-0.0900	2.036	-0.504				
3.85	-0.0990	2.032	-0.524				
3.90	-0.1080	2.028	-0.544				
3.95	-0.1170	2.024	-0.564				
4.00	-0.1260	2.020	-0.584				
4.05	-0.1350	2.016	-0.604				
4.10	-0.1440	2.012	-0.624				
4.15	-0.1530	2.008	-0.644				
4.20	-0.1620	2.004	-0.664				
4.25	-0.1710	2.000	-0.684				
4.30	-0.1800	1.996	-0.704				
4.35	-0.1890	1.992	-0.724				
4.40	-0.1980	1.988	-0.744				
4.45	-0.2070	1.984	-0.764				
4.50	-0.2160	1.980	-0.784				
4.55	-0.2250	1.976	-0.804				
4.60	-0.2340	1.972	-0.824				
4.65	-0.2430	1.968	-0.844				
4.70	-0.2520	1.964	-0.864				
4.75	-0.2610	1.960	-0.884				
4.80	-0.2700	1.956	-0.904				
4.85	-0.2790	1.952	-0.924				
4.90	-0.2880	1.948	-0.944				
4.95	-0.2970	1.944	-0.964				
5.00	-0.3060	1.940	-0.984				
5.05	-0.3150	1.936	-1.004				
5.10	-0.3240	1.932	-1.024				
5.15	-0.3330	1.928	-1.044				
5.20	-0.3420	1.924	-1.064				
5.25	-0.3510	1.920	-1.084				
5.30	-0.3600	1.916	-1.104				
5.35	-0.3690	1.912	-1.124				
5.40	-0.3780	1.908	-1.144				
5.45	-0.3870	1.904	-1.164				
5.50	-0.3960	1.900	-1.184				
5.55	-0.4050	1.896	-1.204				
5.60	-0.4140	1.892	-1.224				
5.65	-0.4230	1.888	-1.244				
5.70	-0.4320	1.884	-1.264				
5.75	-0.4410	1.880	-1.284				
5.80	-0.4500	1.876	-1.304				
5.85	-0.4590	1.872	-1.324				
5.90	-0.4680	1.868	-1.344				
5.95	-0.4770	1.864	-1.364				
6.00	-0.4860	1.860	-1.384				
6.05	-0.4950	1.856	-1.404				
6.10	-0.5040	1.852	-1.424				
6.15	-0.5130	1.848	-1.444				
6.20	-0.5220	1.844	-1.464				
6.25	-0.5310	1.840	-1.484				
6.30	-0.5400	1.836	-1.504				
6.35	-0.5490	1.832	-1.524				
6.40	-0.5580	1.828	-1.544				
6.45	-0.5670	1.824	-1.564				
6.50	-0.5760	1.820	-1.584				
6.55	-0.5850	1.816	-1.604				
6.60	-0.5940	1.812	-1.624				
6.65	-0.6030	1.808	-1.644				
6.70	-0.6120	1.804	-1.664				
6.75	-0.6210	1.800	-1.684				
6.80	-0.6300	1.796	-1.704				
6.85	-0.6390	1.792	-1.724				
6.90	-0.6480	1.788	-1.744				
6.95	-0.6570	1.784	-1.764				
7.00	-0.6660	1.780	-1.784				
7.05	-0.6750	1.776	-1.804				
7.10	-0.6840	1.772	-1.824				
7.15	-0.6930	1.768	-1.844				
7.20	-0.7020	1.764	-1.864				
7.25	-0.7110	1.760	-1.884				
7.30	-0.7200	1.756	-1.904				
7.35	-0.7290	1.752	-1.924				
7.40	-0.7380	1.748	-1.944				
7.45	-0.7470	1.744	-1.964				
7.50	-0.7560	1.740	-1.984				
7.55	-0.7650	1.736	-2.004				
7.60	-0.7740	1.732	-2.024				
7.65	-0.7830	1.728	-2.044				
7.70	-0.7920	1.724	-2.064				
7.75	-0.8010	1.720	-2.084				
7.80	-0.8100	1.716	-2.104				
7.85	-0.8190	1.712	-2.124				
7.90	-0.8280	1.708	-2.144				
7.95	-0.8370	1.704	-2.164				
8.00	-0.8460	1.700	-2.184				
8.05	-0.8550	1.696	-2.204				
8.10	-0.8640	1.692	-2.224				
8.15	-0.8730	1.688	-2.244				
8.20	-0.8820	1.684	-2.264				
8.25	-0.8910	1.680	-2.284				
8.30	-0.9000	1.676	-3.000				
8.35	-0.9090	1.672	-3.020				
8.40	-0.9180	1.668	-3.040				
8.45	-0.9270	1.664	-3.060				
8.50	-0.9360	1.660	-3.080				
8.55	-0.9450	1.656	-3.100				
8.60	-0.9540	1.652	-3.120				
8.65	-0.9630	1.648	-3.140				
8.70	-0.9720	1.644	-3.160				
8.75	-0.9810	1.640	-3.180				
8.80	-0.9900	1.636	-3.200				
8.85	-0.9990	1.632	-3.220				
8.90	-0.0080	1.628	-3.240				
8.95	-0.0070	1.624	-3.260				
9.00	-0.0060	1.620	-3.280				
9.05	-0.0050	1.616	-3.300				
9.10	-0.0040	1.612	-3.320				
9.15	-0.0030	1.608	-3.340				
9.20	-0.0020	1.604	-3.360				
9.25	-0.0010	1.600	-3.380				
9.30	-0.0000	1.596	-3.400				
9.35	-0.0010	1.592	-3.420				




FIGURE 20-5. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE).

TABLE 20-9. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (Temperature Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and specimen designation	Composition (weight percent), specifications, and Remarks
1	A00003	Harmon, N.F. (editor)	1974	5.0	300-779		Film; fast-evaporated; absorptance obtained for wavelength 5.0 μm at various temperatures.
2	A00003	Harmon, N.F. (editor)	1974	10.0	298-775		The above specimen except wavelength 10.0 μm .

TABLE 20-10. EXPERIMENTAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINUM (TEMPERATURE DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α]

T	α
CURVE 1 $\lambda = 10.2$	
295.	0.0129
375.	0.0135
475.	0.0185
574.	0.0213
674.	0.0234
775.	0.0265
CURVE 2 $\lambda = 5.2$	
300.	0.0219
377.	0.0239
477.	0.0264
575.	0.0318
676.	0.0337
779.	0.0356

To isolate the individual surface characteristics is a difficult task. For most materials it is not practical to alter one characteristic without causing an influence on another. The control of the many variables required to study surface characterization in a logical manner is a complex problem. As a result only the simplest of surface profiles or compositional effects have been studied or are understood. One of the most important influences on the radiative properties of metals arises from surface roughness.

Because of the difficulties mentioned above, data analysis and evaluation is not a straight forward task; some logical but not exact means should be used in the generation of the most probable values for the properties of our interest. Although the radiative properties could be strongly dependent upon the process of applying the metallized thin films, we considered them as mechanically polished surface as a first approximation and decided to use the classical model of Hagen and Rubens with some modification in the interpretation of the selected emittance data for mechanically polished surfaces. Details of such modification are discussed in Section 2 and Eq. (2.5-5) is the resulted expression.

Reliable and accurate available data on the normal spectral emittance of mechanically polished aluminum surface were obtained by converting the data sets, curves 4 and 5 of Figure 20-4, from absorptance to emittance using Kirchhoff's law. Data for curves 4 and 5 were measured at temperatures of 573 K and 293 K respectively. By a least squares calculation the following equation was found to fit the selected data with uncertainties of less than $\pm 10\%$ for wavelength range 2.5 to 20 μm .

$$\begin{aligned}\epsilon(0, \lambda) = & 0.0007 + 0.0644 \left[\frac{1 + 0.00429(T-293)}{\lambda - 2.279} \right]^{1/2} \\ & - 0.0206 \left[\frac{1 + 0.00429(T-293)}{\lambda - 2.279} \right] \\ & + 0.00234 \left[\frac{1 + 0.00429(T-293)}{\lambda - 2.279} \right]^{3/2},\end{aligned}\quad (4.20-1)$$

$$\alpha(0, \lambda) = \epsilon(0, \lambda), \quad (4.20-2)$$

and

$$\rho(0, 2\pi, \lambda) = 1 - \alpha(0, \lambda), \quad (4.20-3)$$

where λ is in units of μm and T in K. These three equations are used to generate the most probable values on the normal spectral radiative properties for the aluminized grafoil.

a. Normal Spectral Emittance (Wavelength Dependence)

Normal spectral emittance of aluminized grafoil is calculated from Eq. (4.20-1) and listed in Table 20-11 and plotted in Figure 20-6. The values generated are considered as provisional (about $\pm 25\%$ uncertainty) since they are estimated based on the aluminum data. Provisional values are presented at five temperatures, 293, 450, 600, 750, and 850 K. Note that the provisional values are for the mechanically polished surface only. Values of true surfaces are expected to deviate from those listed. However, the tabulated values are believed to be reasonable for those surfaces of roughness less than 0.5 μm .

TABLE 20-11. PREVISIONAL NORMAL SPECTRAL EMMITTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMMITTANCE, ϵ]

λ	ϵ	MECHANICALLY POLISHED $T = 293$	λ	ϵ	MECHANICALLY POLISHED $T = 450$	λ	ϵ	MECHANICALLY POLISHED $T = 600$	λ	ϵ	MECHANICALLY POLISHED $T = 750$	λ	ϵ	MECHANICALLY POLISHED $T = 853$	
2.5	0.367	2.5	0.671	2.5	0.973	2.5	0.075	2.5	0.259	2.5	0.378	2.5	0.570	2.5	0.870
2.8	0.357	2.8	0.663	2.8	0.967	2.8	0.076	2.8	0.266	2.8	0.367	2.8	0.567	2.8	0.867
3.0	0.352	3.0	0.559	3.0	0.863	3.0	0.077	3.0	0.260	3.0	0.362	3.0	0.562	3.0	0.862
3.5	0.344	3.5	0.052	3.5	0.558	3.5	0.078	3.5	0.257	3.5	0.359	3.5	0.559	3.5	0.859
3.8	0.344	3.8	0.046	3.8	0.553	3.8	0.079	3.8	0.257	3.8	0.357	3.8	0.557	3.8	0.857
4.0	0.344	4.0	0.045	4.0	0.551	4.0	0.080	4.0	0.255	4.0	0.357	4.0	0.557	4.0	0.857
4.5	0.335	4.5	0.043	4.5	0.447	4.5	0.081	4.5	0.251	4.5	0.353	4.5	0.553	4.5	0.853
5.0	0.333	5.0	0.040	5.0	0.444	5.0	0.082	5.0	0.248	5.0	0.350	5.0	0.550	5.0	0.850
5.5	0.331	5.5	0.037	5.5	0.437	5.5	0.083	5.5	0.246	5.5	0.348	5.5	0.548	5.5	0.848
6.0	0.329	6.0	0.035	6.0	0.435	6.0	0.084	6.0	0.246	6.0	0.345	6.0	0.545	6.0	0.845
6.5	0.327	6.5	0.034	6.5	0.434	6.5	0.085	6.5	0.243	6.5	0.343	6.5	0.543	6.5	0.843
7.0	0.026	7.0	0.032	7.0	0.432	7.0	0.086	7.0	0.242	7.0	0.342	7.0	0.542	7.0	0.842
7.5	0.025	7.5	0.031	7.5	0.431	7.5	0.085	7.5	0.239	7.5	0.340	7.5	0.540	7.5	0.840
8.0	0.024	8.0	0.029	8.0	0.429	8.0	0.084	8.0	0.237	8.0	0.339	8.0	0.539	8.0	0.839
8.5	0.023	8.5	0.029	8.5	0.429	8.5	0.083	8.5	0.236	8.5	0.338	8.5	0.538	8.5	0.838
9.0	0.023	9.0	0.029	9.0	0.429	9.0	0.082	9.0	0.235	9.0	0.337	9.0	0.537	9.0	0.837
9.5	0.022	9.5	0.027	9.5	0.427	9.5	0.081	9.5	0.234	9.5	0.336	9.5	0.536	9.5	0.836
10.0	0.021	10.0	0.025	10.0	0.425	10.0	0.080	10.0	0.233	10.0	0.335	10.0	0.535	10.0	0.835
10.5	0.021	10.5	0.025	10.5	0.425	10.5	0.080	10.5	0.232	10.5	0.334	10.5	0.534	10.5	0.834
11.0	0.021	11.0	0.025	11.0	0.425	11.0	0.080	11.0	0.232	11.0	0.334	11.0	0.534	11.0	0.834
11.5	0.020	11.5	0.025	11.5	0.425	11.5	0.079	11.5	0.231	11.5	0.333	11.5	0.533	11.5	0.833
12.0	0.020	12.0	0.024	12.0	0.424	12.0	0.078	12.0	0.230	12.0	0.332	12.0	0.532	12.0	0.832
12.5	0.019	12.5	0.024	12.5	0.424	12.5	0.077	12.5	0.227	12.5	0.330	12.5	0.530	12.5	0.830
13.0	0.019	13.0	0.023	13.0	0.423	13.0	0.076	13.0	0.226	13.0	0.329	13.0	0.529	13.0	0.829
13.5	0.018	13.5	0.023	13.5	0.423	13.5	0.075	13.5	0.225	13.5	0.328	13.5	0.528	13.5	0.828
14.0	0.018	14.0	0.022	14.0	0.422	14.0	0.074	14.0	0.225	14.0	0.327	14.0	0.527	14.0	0.827
14.5	0.017	14.5	0.022	14.5	0.422	14.5	0.073	14.5	0.225	14.5	0.326	14.5	0.526	14.5	0.826
15.0	0.017	15.0	0.021	15.0	0.421	15.0	0.072	15.0	0.225	15.0	0.325	15.0	0.525	15.0	0.825




FIGURE 20-6. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE).

b. Normal Spectral Emittance (Temperature Dependence)

The normal spectral emittance as a function of temperature is given in Table 20-12 and Figure 20-7. The generated values are considered as provisional (uncertainty $\pm 25\%$). The plot clearly shows that emittance for a given wavelength does not vary appreciably for a wide temperature range. Note that the melting point of aluminum at about 930 K is not far from the ending point (about 880 K) of each curve. It seems that the curves can be extrapolated to or beyond the melting point. However, there is no definite evidence to support this attempt.

TABLE 26-12. PROVISIONAL NCKRAL SPECTRAL EMMITTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMMITTANCE, ϵ)

T MECHANICALLY POLISHED $\lambda = 2.8$	ϵ	T MECHANICALLY POLISHED $\lambda = 3.8$		T MECHANICALLY POLISHED $\lambda = 5.0$		T MECHANICALLY POLISHED $\lambda = 10.6$	
		T	ϵ	T	ϵ	T	ϵ
250.0	0.054	250.0	0.038	250.0	0.030	250.0	0.019
253.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021
300.0	0.057	350.0	0.041	350.0	0.033	350.0	0.021
350.0	0.061	350.0	0.044	350.0	0.035	350.0	0.023
400.0	0.062	402.0	0.046	400.0	0.038	400.0	0.024
450.0	0.063	450.0	0.048	450.0	0.040	450.0	0.026
500.0	0.065	502.0	0.050	500.0	0.041	500.0	0.027
550.0	0.066	550.0	0.052	550.0	0.043	550.0	0.028
600.0	0.067	601.0	0.053	600.0	0.044	600.0	0.029
650.0	0.068	650.0	0.053	650.0	0.045	650.0	0.030
700.0	0.068	700.0	0.055	700.0	0.047	700.0	0.031
750.0	0.069	750.0	0.057	750.0	0.048	750.0	0.032
800.0	0.069	800.0	0.058	800.0	0.049	800.0	0.033
850.0	0.070	850.0	0.059	850.0	0.050	850.0	0.034
900.0	0.070	900.0	0.059	900.0	0.051	900.0	0.035




FIGURE 20-7. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF ALUMINIZED GRAFOIL
(TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

As given in Table 20-13 and plotted in Figure 20-8 the normal spectral reflectance of aluminized grafoil is calculated by assuming that energy loss of the impinging radiation is entirely due to absorption. The result is remarkably good as one can see by comparing Figures 20-3 and 20-8. Since the data analysis is totally based on the available data of aluminum, allowance is given in the estimation of the predicted values. An estimated uncertainty of $\pm 20\%$ is given to the calculated values so that the estimated values can be used for most of the true surfaces.

TABLE 20-13. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFTYL (WAVELLENGTH DEPENDENCE)

WAVELENGTH, λ , μm		TEMPERATURE, T , K		REFLECTANCE, ρ	
λ	ρ	λ	ρ	λ	ρ
MECHANICALLY POLISHED $T = 233$	MECHANICALLY POLISHED $T = 456$	MECHANICALLY POLISHED $T = 693$	MECHANICALLY POLISHED $T = 750$	MECHANICALLY POLISHED $T = 850$	MECHANICALLY POLISHED $T = 850$
2.5	0.933	2.5	0.929	2.5	0.927
2.8	0.943	2.8	0.937	2.8	0.934
3.0	0.943	3.0	0.941	3.0	0.937
3.5	0.953	3.5	0.948	3.5	0.944
3.8	0.959	3.8	0.952	3.8	0.947
4.0	0.961	4.0	0.954	4.0	0.945
4.5	0.965	4.5	0.957	4.5	0.949
5.0	0.967	5.0	0.960	5.0	0.956
5.5	0.969	5.5	0.963	5.5	0.958
6.0	0.971	6.0	0.965	6.0	0.960
6.5	0.973	6.5	0.966	6.5	0.962
7.0	0.974	7.0	0.968	7.0	0.959
7.5	0.975	7.5	0.969	7.5	0.955
8.0	0.976	8.0	0.976	8.0	0.963
8.5	0.977	8.5	0.974	8.5	0.964
9.0	0.977	9.0	0.972	9.0	0.968
9.5	0.974	9.5	0.973	9.5	0.965
10.0	0.973	10.0	0.974	10.0	0.967
10.5	0.972	10.5	0.974	10.5	0.963
11.0	0.980	11.0	0.975	11.0	0.971
11.5	0.980	11.5	0.975	11.5	0.968
12.0	0.981	12.0	0.976	12.0	0.972
12.5	0.981	12.5	0.976	12.5	0.973
13.0	0.981	13.0	0.977	13.0	0.974
13.5	0.982	13.5	0.977	13.5	0.974
14.0	0.982	14.0	0.976	14.0	0.975
14.5	0.983	14.5	0.976	14.5	0.975
15.0	0.983	15.0	0.979	15.0	0.975




FIGURE 20-8. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE).

d. Normal Spectral Reflectance (Temperature Dependence)

In Table 20-14, the provisional values of the normal spectral reflectance are given with an estimated uncertainty of $\pm 20\%$. The variation of the property as a function of temperature is demonstrated in Figure 20-9. For a given wavelength, the normal spectral reflectance remains as a constant from room temperature up to near the melting point of the material. At higher temperatures our knowledge on this property is lacking. However, it seems that a linear extrapolation of the curve to and above the melting point can be used with uncertainty of no more than $\pm 35\%$.

TABLE 29-14. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

MECHANICALLY POLISHED $\lambda = 2.8$		MECHANICALLY POLISHED $\lambda = 3.6$		MECHANICALLY POLISHED $\lambda = 5.0$		MECHANICALLY POLISHED $\lambda = 10.6$	
250.0	0.946	250.0	0.952	250.0	0.970	250.0	0.981
293.0	0.943	293.0	0.953	293.0	0.967	293.0	0.979
336.0	0.942	336.0	0.959	336.0	0.967	336.0	0.973
350.0	0.943	350.0	0.956	350.0	0.964	350.0	0.977
402.0	0.938	402.0	0.954	402.0	0.962	402.0	0.976
455.0	0.937	455.0	0.952	455.0	0.960	455.0	0.974
500.0	0.935	500.0	0.950	500.0	0.959	500.0	0.973
550.0	0.934	550.0	0.948	550.0	0.957	550.0	0.972
600.0	0.933	600.0	0.947	600.0	0.956	600.0	0.971
655.0	0.932	655.0	0.945	655.0	0.954	655.0	0.970
750.0	0.932	750.0	0.944	750.0	0.953	750.0	0.969
790.0	0.931	790.0	0.943	790.0	0.952	790.0	0.968
800.0	0.931	800.0	0.942	800.0	0.951	800.0	0.967
850.0	0.930	850.0	0.941	850.0	0.950	850.0	0.966
860.0	0.930	860.0	0.941	860.0	0.949	860.0	0.965




FIGURE 20-9. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

The normal spectral absorptance is obtained from reflectance according to the Kirchhoff's law, and is numerically equal to the emittance. The absorptance varies appreciably for wavelengths lower than $4.0 \mu\text{m}$ and remains practically unchanged for longer wavelengths. The generated provisional values with $\pm 25\%$ uncertainty are given in Table 20-15 and plotted in Figure 20-10.

TABLE 23-15. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL (WAVELLENGTH DEPENDENCE)
WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α								
2.5	0.567	2.5	0.653	2.5	0.667	2.5	0.675	2.5	0.276
2.8	0.557	2.8	0.659	3.0	0.663	3.0	0.669	2.8	0.378
3.0	0.552	3.0	0.652	3.5	0.656	3.5	0.665	3.0	0.667
3.5	0.544	3.5	0.648	3.8	0.653	3.8	0.660	3.5	0.662
3.8	0.542	3.8	0.648	4.0	0.653	4.0	0.657	3.8	0.659
4.0	0.539	4.0	0.646	4.0	0.654	4.0	0.655	4.0	0.657
4.5	0.535	4.5	0.645	4.5	0.647	4.5	0.651	4.5	0.653
5.0	0.533	5.0	0.640	5.0	0.644	5.0	0.648	5.0	0.650
5.5	0.534	5.5	0.637	5.5	0.642	5.5	0.646	5.5	0.648
6.0	0.529	6.0	0.635	6.0	0.644	6.0	0.643	6.0	0.645
6.5	0.527	6.5	0.634	6.5	0.643	6.5	0.642	6.5	0.644
7.0	0.526	7.0	0.632	7.0	0.640	7.0	0.642	7.0	0.642
7.5	0.525	7.5	0.631	7.5	0.635	7.5	0.639	7.5	0.640
8.0	0.524	8.0	0.629	8.0	0.634	8.0	0.637	8.0	0.639
8.5	0.523	8.5	0.629	8.5	0.635	8.5	0.636	8.5	0.638
9.0	0.523	9.0	0.623	9.0	0.632	9.0	0.635	9.0	0.637
9.5	0.522	9.5	0.627	9.5	0.631	9.5	0.634	9.5	0.636
10.0	0.521	10.0	0.626	10.0	0.630	10.0	0.633	10.0	0.636
10.5	0.521	10.5	0.626	10.5	0.629	10.5	0.632	10.5	0.634
11.0	0.520	11.0	0.625	11.0	0.629	11.0	0.632	11.0	0.635
11.5	0.520	11.5	0.625	11.5	0.628	11.5	0.631	11.5	0.633
12.0	0.520	12.0	0.624	12.0	0.628	12.0	0.630	12.0	0.632
12.5	0.519	12.5	0.624	12.5	0.627	12.5	0.630	12.5	0.632
13.0	0.519	13.0	0.623	13.0	0.626	13.0	0.629	13.0	0.634
13.5	0.518	13.5	0.623	13.5	0.625	13.5	0.629	13.5	0.635
14.0	0.518	14.0	0.622	14.0	0.625	14.0	0.629	14.0	0.636
14.5	0.517	14.5	0.622	14.5	0.625	14.5	0.628	14.5	0.630
15.0	0.517	15.0	0.621	15.0	0.625	15.0	0.627	15.0	0.629




FIGURE 26-10. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL (WAVELENGTH DEPENDENCE).

f. Normal Spectral Absorptance (Temperature Dependence)

The provisional values of the normal spectral absorptance of aluminized grafoil is given in Table 20-16 and plotted in Figure 20-11. They are numerically equal to the normal spectral emittance. Comparing our predicted curves for $5.0 \mu\text{m}$ and $10.0 \mu\text{m}$ with the available data in Figure 20-5, it appears that our predicted values are higher than experimental values. By a careful examination of the measurement information, one sees that the experimental points in Figure 20-5 are for thin films. The absorptance of bulk material is in general higher than that of thin film. An uncertainty of 25% is incorporated to the provisional values so that they can be used for most of the real surfaces.

TABLE 20-16. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL (TEMPERATURE DEPENDENCE)
 WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

T	α	T	α	T	α	T	α
MECHANICALLY POLISHED $\lambda = 2.8$		MECHANICALLY POLISHED $\lambda = 3.8$		MECHANICALLY POLISHED $\lambda = 5.0$		MECHANICALLY POLISHED $\lambda = 10.6$	
250.0	0.054	250.0	0.033	250.0	0.030	250.0	0.019
293.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021
300.0	0.057	300.0	0.041	300.0	0.033	300.0	0.021
350.0	0.050	350.0	0.044	350.0	0.036	350.0	0.023
400.0	0.052	400.0	0.045	400.0	0.038	400.0	0.024
450.0	0.053	450.0	0.048	450.0	0.040	450.0	0.026
500.0	0.055	500.0	0.050	500.0	0.042	500.0	0.027
550.0	0.055	550.0	0.052	550.0	0.043	550.0	0.028
600.0	0.067	600.0	0.053	600.0	0.044	600.0	0.029
650.0	0.063	650.0	0.055	650.0	0.045	650.0	0.030
700.0	0.062	700.0	0.056	700.0	0.047	700.0	0.031
750.0	0.063	750.0	0.057	750.0	0.049	750.0	0.032
800.0	0.069	800.0	0.058	800.0	0.049	800.0	0.033
850.0	0.070	850.0	0.059	850.0	0.050	850.0	0.034
860.0	0.070	860.0	0.059	860.0	0.051	860.0	0.035




FIGURE 20-11. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF ALUMINIZED GRAFOIL
(TEMPERATURE DEPENDENCE).

g. Transmittance

Although it is true that metals in the form of extremely thin films may be transparent for a wide wavelength range, they are opaque if the thickness is greater than several hundred angstroms. Consequently, composites with a metal layer are opaque to visible and infrared radiation because in general applications they are not used as extremely thin films. This leads to the conclusion that as an aircraft/spacecraft structural material, this composite is opaque and its transmittance is zero.

4.21. Boron Fiber Aluminum Matrix Composite

Boron fiber aluminum matrix composite is made in the form of sheet or tape. The sheets are made by diffusion bonding boron fibers between two sheets of aluminum or aluminum alloys. The tape is made by plasma spraying the 713 braze alloys. The tape is then diffusion or braze bonded into any desired configuration.

Boron filaments are formed by the vapor deposition of boron on a fine tungsten wire substrate within a reactor. Exposure of the tungsten substrate to the high temperature boron trichloride reactor environment results in a filament consisting of a boron sheath on a tungsten boride core. Boron fibers have higher tensile strength and modulus of elasticity than the graphite fibers commonly used in composite materials. Their melting point is higher than that of aluminum generally used in conjunction with them. The boron filaments are currently produced by two principal sources, Hamilton Standard and Avco. It might be noted that composites using Borsic filaments are also available commercially. These are boron filaments coated with silicon carbide in order to adapt boron filaments to high temperature usage in composite.

In the area of metal matrix, aluminum or aluminum alloys are currently commercially available.

The advantage of the boron fiber aluminum matrix composite is that along with its light weight it has a high temperature and heat resistance. Although the fiber material stands very high temperatures, its aluminum composite is not recommended for continuous service above 590 K, but the intermittent service to 645 K is possible. The products are available commercially in a wide range of laminate thickness including monolayer sheets in finished form. Virtually all of the actual hardware items built to date have been fabricated using standard fiber volume fractions of fifty percent.

The composite materials are fabricated primarily for aircraft constructions because of their advantages. Much of their mechanical and thermal properties are extensively as well as intensively measured. As a result, numerous publications in those areas are available at users' disposal.

With regard to the thermal radiative properties of these composites, it is unfortunate to find that there is nothing available, a very discouraging fact to workers in laser research. However, in view of the facts that the fiber materials are diffusion bonded between sheets of aluminum and the thickness of aluminum sheet is far more than enough to be opaque to the radiation, the thermal radiative properties of composite materials can be fully described by considering them as aluminum alone. Although aluminum alloys

2024-T851 and 6061-T6 are also commonly used as the matrix materials, the final products of the composites are usually alclad for corrosion resistance. Therefore, the generation of the most probable values on the thermal radiative properties of boron fiber aluminum matrix composite is based on the available data of aluminum.

Literature survey for aluminum revealed an adequate amount of data on the normal spectral emittance, reflectance, and absorptance. Measurement information and experimental results obtained in this survey are given in Tables 20-1 to 20-10 and Figures 20-1 to 20-5. By careful review of the tables and figures, one will see that the magnitudes of the thermal radiative properties are very much affected by the surface conditions of the specimens. The literature abounds with examples of test surfaces shown to be very sensitive to methods of preparation, thermal history, and environmental conditions. Despite this awareness, descriptions of test surfaces are generally inadequate because of our modest understanding of the mechanisms or real surface effects and how to properly characterize a surface.

To isolate the individual surface characteristics is a difficult task. For most materials it is not practical to alter one characteristic without causing an influence on another. The control of the many variables required to study surface characterization in a logical manner is a complex problem. As a result only the simplest of surface profiles or compositional effects have been studied or are understood. One of the most important influences on the radiative properties of metals arises from surface roughness.

Because of the difficulties mentioned above, data analysis and evaluation is not a straightforward task; some logical but not exact means should be used in the generation of the most probable values for the properties of our interest. It is decided that the classical model of Hagen and Rubens with some modification is used to interpret the selected emittance data for mechanically polished surfaces, which is chosen as a good approximation to the real surfaces. Details of modifying the Hagen and Rubens equation are discussed in Section 2 and Eq. (2.5-5) is used for data analysis.

Reliable and accurate available data on the normal spectral emittance of mechanically polished aluminum surface were obtained by converting the data sets, curves 4 and 5 of Figure 20-4, from absorptance to emittance using Kirchhoff's law. Data for curves 4 and 5 were obtained at temperatures of 573 K and 293 K respectively. By a least squares calculation Eq. (4.20-1) was found to fit the selected data with uncertainties of less than $\pm 10\%$. Absorptance and reflectance can be calculated by using Eqs. (4.20-2) and (4.20-3).

By a quick scanning review of the details on the available data and information given in Tables 20-1 to 20-10 and Figures 20-1 to 20-5, it appears that the surface roughness

can be incorporated into Eq. (4.20-1). However, no attempt was made because there was not a single systematic information on the roughness dependence of the radiative properties available for data analysis. As a result, only the radiative properties of mechanically polished surface are presented here. Note that in the following tables more decimal places are reported than warranted merely for the purpose of tabular smoothness and internal comparison. Readers are advised to use the appropriate uncertainties given in each case.

a. Normal Spectral Emittance (Wavelength Dependence)

Normal spectral emittance of mechanically polished boron fiber aluminum matrix composite is calculated from Eq. (4.20-1) and listed in Table 21-1 and plotted in Figure 21-1. The values generated are considered as provisional (about $\pm 25\%$ uncertainty) since they are estimated based on the aluminum data. Provisional values are presented at five temperatures, 293, 450, 600, 750, and 850 K. Note that the emittance is usually quite low and remains practically constant for wavelengths longer than $6 \mu\text{m}$.

TABLE 21-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)

[WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ]					
λ	ϵ	λ	ϵ	λ	ϵ
MECHANICALLY POLISHED $T = 293$	MECHANICALLY POLISHED $T = 450$	MECHANICALLY POLISHED $T = 600$	MECHANICALLY POLISHED $T = 750$	MECHANICALLY POLISHED $T = 900$	MECHANICALLY POLISHED $T = 250$
2.5	0.067	2.5	0.071	2.5	0.075
2.8	0.057	2.8	0.063	2.8	0.069
3.0	0.052	3.0	0.059	3.0	0.066
3.5	0.044	3.5	0.052	3.5	0.063
3.8	0.041	3.8	0.048	3.8	0.052
4.0	0.039	4.0	0.046	4.0	0.051
4.5	0.035	4.5	0.043	4.5	0.047
5.0	0.033	5.0	0.040	5.0	0.044
5.5	0.034	5.5	0.037	5.5	0.042
6.0	0.029	6.0	0.035	6.0	0.040
6.5	0.027	6.5	0.034	6.5	0.038
7.0	0.026	7.0	0.032	7.0	0.037
7.5	0.025	7.5	0.031	7.5	0.035
8.0	0.024	8.0	0.030	8.0	0.034
8.5	0.022	8.5	0.029	8.5	0.033
9.0	0.023	9.0	0.028	9.0	0.032
9.5	0.022	9.5	0.027	9.5	0.031
10.0	0.024	10.0	0.026	10.0	0.030
10.5	0.021	10.5	0.026	10.5	0.029
11.0	0.020	11.0	0.025	11.0	0.032
11.5	0.020	11.5	0.025	11.5	0.031
12.0	0.019	12.0	0.024	12.0	0.028
12.5	0.019	12.5	0.024	12.5	0.027
13.0	0.019	13.0	0.023	13.0	0.026
13.5	0.018	13.5	0.023	13.5	0.026
14.0	0.018	14.0	0.022	14.0	0.025
14.5	0.017	14.5	0.022	14.5	0.025
15.0	0.017	15.0	0.021	15.0	0.027




FIGURE 21-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).

b. Normal Spectral Emittance (Temperature Dependence)

The normal spectral emittance as a function of temperature is given in Table 21-2 and Figure 21-2. The generated values are considered as provisional with uncertainty $\pm 25\%$. The plot clearly shows that emittance for a given wavelength does not vary appreciably for a wide temperature range. Note that the melting point of aluminum at about 930 K is not far from the ending point (about 880 K) of each curve. It seems that the curves can be extrapolated to or beyond the melting point.

TABLE 21-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

T MECHANICALLY POLISHED $\lambda = 2.8$	ϵ	T MECHANICALLY POLISHED $\lambda = 3.6$		T MECHANICALLY POLISHED $\lambda = 5.0$		T MECHANICALLY POLISHED $\lambda = 10.6$	
		T	ϵ	T	ϵ	T	ϵ
250.0	0.054	250.0	0.038	250.0	0.030	250.0	0.019
293.0	0.157	293.0	0.041	293.0	0.033	293.0	0.021
350.0	0.257	350.0	0.041	350.0	0.033	350.0	0.021
356.0	0.360	356.0	0.044	356.0	0.036	356.0	0.023
425.0	0.352	425.0	0.046	425.0	0.038	425.0	0.024
450.0	0.653	450.0	0.046	450.0	0.040	450.0	0.026
500.0	0.655	500.0	0.050	500.0	0.041	500.0	0.027
550.0	0.366	550.0	0.052	550.0	0.043	550.0	0.026
590.0	0.357	590.0	0.053	590.0	0.044	590.0	0.029
650.0	0.362	650.0	0.055	650.0	0.046	650.0	0.030
700.0	0.363	700.0	0.056	700.0	0.047	700.0	0.031
750.0	0.359	750.0	0.057	750.0	0.048	750.0	0.032
800.0	0.369	800.0	0.058	800.0	0.049	800.0	0.033
850.0	0.073	850.0	0.059	850.0	0.050	850.0	0.034
900.0	0.070	880.0	0.059	880.0	0.051	880.0	0.035




FIGURE 21-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

As given in Table 21-3 and plotted in Figure 21-3, the normal spectral reflectance of boron fiber aluminum composite is calculated by assuming that energy loss of the impinging radiation is entirely due to absorption. The result is remarkably good as one can see by comparing Figure 20-3 and Figure 21-3. Since the data analysis is totally based on the available data of aluminum, allowance is given in the estimation of the predicted values. An estimated uncertainty of $\pm 20\%$ is given to the calculated values.

TABLE 21-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ	λ	ρ	λ	ρ	λ	ρ
MECHANICALLY POLISHED $T = 293$	2.5	0.933	2.5	0.929	2.5	0.927	2.5	0.925	2.5
	2.8	0.943	2.8	0.937	2.8	0.933	2.8	0.931	2.8
	3.0	0.948	3.0	0.941	3.0	0.937	3.0	0.934	3.0
	3.5	0.956	3.5	0.946	3.5	0.944	3.5	0.940	3.5
	3.8	0.959	3.8	0.952	3.8	0.947	3.8	0.943	3.8
	4.0	0.961	4.0	0.954	4.0	0.949	4.0	0.945	4.0
	4.5	0.965	4.5	0.957	4.5	0.953	4.5	0.949	4.5
	5.0	0.967	5.0	0.960	5.0	0.956	5.0	0.952	5.0
	5.5	0.969	5.5	0.963	5.5	0.953	5.5	0.954	5.5
	6.0	0.971	6.0	0.965	6.0	0.960	6.0	0.957	6.0
	6.5	0.973	6.5	0.966	6.5	0.952	6.5	0.958	6.5
	7.0	0.974	7.0	0.968	7.0	0.953	7.0	0.960	7.0
	7.5	0.975	7.5	0.969	7.5	0.965	7.5	0.961	7.5
	8.0	0.976	8.0	0.970	8.0	0.966	8.0	0.962	8.0
	8.5	0.977	8.5	0.971	8.5	0.967	8.5	0.964	8.5
	9.0	0.977	9.0	0.972	9.0	0.968	9.0	0.965	9.0
	9.5	0.976	9.5	0.973	9.5	0.969	9.5	0.966	9.5
	10.0	0.979	10.0	0.974	10.0	0.970	10.0	0.967	10.0
	10.5	0.979	10.5	0.974	10.5	0.971	10.5	0.969	10.5
	11.0	0.969	11.0	0.975	11.0	0.974	11.0	0.969	11.0
	11.5	0.969	11.5	0.975	11.5	0.972	11.5	0.969	11.5
	12.0	0.984	12.0	0.976	12.0	0.972	12.0	0.970	12.0
	12.5	0.964	12.5	0.976	12.5	0.973	12.5	0.970	12.5
	13.0	0.961	13.0	0.977	13.0	0.974	13.0	0.971	13.0
	13.5	0.952	13.5	0.977	13.5	0.974	13.5	0.971	13.5
	14.0	0.962	14.0	0.978	14.0	0.975	14.0	0.972	14.0
	14.5	0.983	14.5	0.976	14.5	0.975	14.5	0.972	14.5
	15.0	0.993	15.0	0.979	15.0	0.975	15.0	0.973	15.0




FIGURE 21-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).

d. Normal Spectral Reflectance (Temperature Dependence)

In Table 21-4, the provisional values of the normal spectral reflectance are given with estimated uncertainties of $\pm 20\%$. The variation of the property as a function of temperature is demonstrated in Figure 21-4. For a given wavelength, the normal spectral reflectance remains as a constant from room temperature up to near the melting point of the material. At higher temperatures our knowledge on this property is lacking. However, it seems that a linear extrapolation of the curve to and above the melting point can be used with uncertainty of no more than $\pm 35\%$.

TABLE 21-4. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE [TEMPERATURE DEPENDENCE,
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

T	ρ	T	ρ	T	ρ	T	ρ
MECHANICALLY POLISHED $\lambda = 2.8$	0.979	250.0	0.952	250.0	0.979	250.0	0.981
293.3	0.945	232.0	0.959	293.0	0.967	233.0	0.979
350.0	0.942	263.0	0.959	300.0	0.967	300.0	0.979
350.0	0.945	350.0	0.956	350.0	0.964	350.0	0.977
400.0	0.939	400.0	0.957	420.0	0.962	390.0	0.976
450.0	0.937	450.0	0.952	450.0	0.950	450.0	0.974
500.0	0.935	500.0	0.950	500.0	0.959	500.0	0.973
550.0	0.934	550.0	0.948	550.0	0.957	550.0	0.972
600.0	0.933	600.0	0.947	600.0	0.956	600.0	0.971
650.0	0.932	650.0	0.946	650.0	0.954	650.0	0.970
700.0	0.932	700.0	0.944	700.0	0.953	700.0	0.969
750.0	0.931	750.0	0.943	750.0	0.952	750.0	0.968
800.0	0.931	800.0	0.942	800.0	0.951	800.0	0.967
850.0	0.930	850.0	0.941	850.0	0.950	850.0	0.966
900.0	0.930	880.0	0.940	880.0	0.949	880.0	0.965




FIGURE 21-4. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER ALUMINA MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

The normal spectral absorptance is obtained according to the Kirchhoff's law, i.e., numerically the absorptance is equal to the emittance. As a result, Table 21-5 and Figure 21-5 appear the same as Table 21-1 and Figure 21-1, as well as the uncertainties ($\pm 25\%$). The absorptance varies appreciably for wavelengths lower than $4.0 \mu\text{m}$ and remains practically unchanged for longer wavelengths as shown in Figure 21-5.

TABLE 21-5. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)
 [WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α]

λ	α	MECHANICALLY POLISHED $T = 293$	λ	α	MECHANICALLY POLISHED $T = 450$	λ	α	MECHANICALLY POLISHED $T = 600$	λ	α	MECHANICALLY POLISHED $T = 750$	λ	α	MECHANICALLY POLISHED $T = 850$	
2.5	0.067	2.5	6.071	2.5	2.073	2.5	0.075	2.5	0.078	2.5	0.079	2.5	0.079	2.5	0.079
2.8	0.057	2.8	6.063	2.8	2.067	2.8	0.069	2.8	0.069	2.8	0.069	2.8	0.069	2.8	0.069
3.0	0.052	3.0	6.059	3.0	2.063	3.0	0.066	3.0	0.066	3.0	0.066	3.0	0.067	3.0	0.067
3.5	0.044	3.5	6.052	3.5	2.056	3.5	0.055	3.5	0.055	3.5	0.055	3.5	0.056	3.5	0.062
3.8	0.041	3.8	6.048	3.8	2.053	3.8	0.053	3.8	0.053	3.8	0.053	3.8	0.053	3.8	0.059
4.0	0.039	4.0	6.046	4.0	2.051	4.0	0.051	4.0	0.051	4.0	0.051	4.0	0.051	4.0	0.057
4.5	0.035	4.5	6.043	4.5	2.047	4.5	0.047	4.5	0.047	4.5	0.047	4.5	0.053	4.5	0.053
5.0	0.033	5.0	6.043	5.0	2.043	5.0	0.044	5.0	0.044	5.0	0.044	5.0	0.045	5.0	0.050
5.5	0.031	5.5	6.037	5.5	2.042	5.5	0.042	5.5	0.042	5.5	0.042	5.5	0.048	5.5	0.048
6.0	0.029	6.0	6.032	6.0	2.040	6.0	0.040	6.0	0.040	6.0	0.040	6.0	0.045	6.0	0.045
6.5	0.027	6.5	6.034	6.5	2.035	6.5	0.035	6.5	0.035	6.5	0.035	6.5	0.044	6.5	0.044
7.0	0.026	7.0	6.032	7.0	2.037	7.0	0.037	7.0	0.037	7.0	0.037	7.0	0.042	7.0	0.042
7.5	0.025	7.5	6.031	7.5	2.035	7.5	0.035	7.5	0.035	7.5	0.035	7.5	0.040	7.5	0.040
8.0	0.024	8.0	6.030	8.0	2.034	8.0	0.034	8.0	0.034	8.0	0.034	8.0	0.039	8.0	0.039
8.5	0.023	8.5	6.029	8.5	2.033	8.5	0.033	8.5	0.033	8.5	0.033	8.5	0.039	8.5	0.039
9.0	0.023	9.0	6.028	9.0	2.032	9.0	0.032	9.0	0.032	9.0	0.032	9.0	0.037	9.0	0.037
9.5	0.022	9.5	6.027	9.5	2.031	9.5	0.031	9.5	0.031	9.5	0.031	9.5	0.036	9.5	0.036
10.0	0.021	10.0	6.026	10.0	2.030	10.0	0.030	10.0	0.030	10.0	0.030	10.0	0.035	10.0	0.035
10.5	0.021	10.5	6.026	10.5	2.029	10.5	0.029	10.5	0.029	10.5	0.029	10.5	0.034	10.5	0.034
11.0	0.020	11.0	6.025	11.0	2.029	11.0	0.029	11.0	0.029	11.0	0.029	11.0	0.033	11.0	0.033
11.5	0.020	11.5	6.025	11.5	2.028	11.5	0.028	11.5	0.028	11.5	0.028	11.5	0.033	11.5	0.033
12.0	0.019	12.0	6.024	12.0	2.028	12.0	0.028	12.0	0.028	12.0	0.028	12.0	0.032	12.0	0.032
12.5	0.019	12.5	6.024	12.5	2.027	12.5	0.027	12.5	0.027	12.5	0.027	12.5	0.031	12.5	0.031
13.0	0.019	13.0	6.023	13.0	2.026	13.0	0.026	13.0	0.026	13.0	0.026	13.0	0.029	13.0	0.031
13.5	0.019	13.5	6.023	13.5	2.025	13.5	0.025	13.5	0.025	13.5	0.025	13.5	0.029	13.5	0.031
14.0	0.018	14.0	6.022	14.0	2.024	14.0	0.024	14.0	0.024	14.0	0.024	14.0	0.028	14.0	0.030
14.5	0.017	14.5	6.022	14.5	2.024	14.5	0.024	14.5	0.024	14.5	0.024	14.5	0.028	14.5	0.030
15.0	0.017	15.0	6.021	15.0	2.023	15.0	0.023	15.0	0.023	15.0	0.023	15.0	0.027	15.0	0.029




FIGURE 21-5. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).

f. Normal Spectral Absorptance (Temperature Dependence)

The provisional values of the normal spectral absorptance of boron fiber aluminum matrix composite is given in Table 21-6 and plotted in Figure 21-6. They are numerically equal to the normal spectral emittance. In Figure 21-6, our predicted curves for 5.0 μm and 10.0 μm are higher than experimental values plotted in Figure 20-5. By a careful examination of the measurement information, one sees that the experimental points in Figure 20-5 are for thin films. The absorptance of bulk material is in general higher than that of thin film. An uncertainty of 25% is given to the provisional values so that they can be used for most of the real surfaces.

TABLE 21-E. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF 30RON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELLENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

MECHANICALLY POLISHED $\lambda = 2.8$		MECHANICALLY POLISHED $\lambda = 3.6$		MECHANICALLY POLISHED $\lambda = 5.0$		MECHANICALLY POLISHED $\lambda = 10.6$	
250.0	0.354	250.0	0.336	250.0	0.330	250.0	0.319
252.0	0.357	253.0	0.341	253.0	0.333	253.0	0.321
254.0	0.357	255.0	0.341	255.0	0.333	255.0	0.321
256.0	0.360	257.0	0.344	257.0	0.336	257.0	0.323
258.0	0.360	259.0	0.344	259.0	0.336	259.0	0.324
260.0	0.362	261.0	0.346	261.0	0.338	261.0	0.324
262.0	0.363	263.0	0.347	263.0	0.340	263.0	0.326
264.0	0.365	265.0	0.350	265.0	0.341	265.0	0.327
266.0	0.366	267.0	0.352	267.0	0.342	267.0	0.328
268.0	0.367	269.0	0.353	269.0	0.344	269.0	0.329
270.0	0.368	271.0	0.355	271.0	0.346	271.0	0.330
272.0	0.369	273.0	0.356	273.0	0.347	273.0	0.331
274.0	0.370	275.0	0.357	275.0	0.348	275.0	0.332
276.0	0.370	277.0	0.358	277.0	0.349	277.0	0.333
278.0	0.372	279.0	0.359	279.0	0.350	279.0	0.334
280.0	0.372	281.0	0.359	281.0	0.351	281.0	0.335




FIGURE 21-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).

g. Transmittance

Although it is true that metals in the form of extremely thin films may be transparent for a wide wavelength range, they are opaque if the thickness is greater than several hundred angstroms. Consequently, composites with metal matrix are opaque to visible and infrared radiation because in general applications they are not used as extremely thin films. This leads to the conclusion that as an aircraft/spacecraft structural material, this composite is opaque and its transmittance is zero.

4.22. Graphite Fiber Aluminum Matrix Composite

Graphite fiber aluminum matrix composite is made in the form of sheet or tape. The sheets are made by diffusion bonding graphite fibers between two sheets of aluminum or aluminum alloys. The tape is made by plasma spraying the 713 braze alloys. The tape is then diffusion or braze bonded into any desired configuration.

There are three types of graphite fibers currently in large-scale production. These filaments have varied tensile strengths, moduli of elasticity, and densities. Graphite fibers for use in composite materials are made by the carbonization of organic fibers. Polyacrylonitrile (PAN) is most commonly used today, but acrylic and rayon fibers have been used to some extent in the past. The mechanical properties of the fibers depend on the temperatures used in the carbonization process. Temperatures of 2800-3300 K yield fibers with high moduli of elasticity but with relatively low tensile strength while temperatures of 1800-2300 K result in fibers of the highest tensile strength but only moderate elasticity. The melting point of the graphite fibers is much higher than the aluminum matrix components generally used. The fibers are available in short lengths (about 48 inches) and continuous lengths up to 3000 feet. The mechanical properties of these two forms are somewhat different.

In the area of metal matrix, aluminum or aluminum alloys are currently commercially available.

The advantage of the graphite fiber aluminum matrix composite is that along with its light weight it has a high temperature and heat resistance. Although the fiber material stands very high temperatures, its aluminum composite is not recommended for continuous service above 590 K, but the intermittent service to 645 K is possible. The products are available commercially in a wide range of laminate thickness including monolayer sheets in finished form. Virtually all of the actual hardware items built to date have been fabricated using standard fiber volume fractions of fifty percent.

The composite materials are fabricated primarily for aircraft constructions because of their advantages. Much of their mechanical and thermal properties are extensively as well as intensively measured. As a result, numerous publications in those areas are available at users' disposal.

With regard to the thermal radiative properties of these composites, it is unfortunate to find that there is nothing available, a very discouraging fact to workers in laser research. However, in view of the facts that the fiber materials are diffusion bonded between sheets of aluminum and the thickness of aluminum sheet is far more than

enough to be opaque to the radiation, the thermal radiative properties of composite materials can be fully described by considering them as aluminum alone. Although aluminum alloys 2024-T851 and 6061-T6 are also commonly used as the matrix materials, the final products of the composites are usually alclad for corrosion resistance. Therefore, the generation of the most probable values on the thermal radiative properties of graphite fiber aluminum matrix composite is based on the available data of aluminum.

Literature survey for aluminum revealed an adequate amount of data on the normal spectral emittance, reflectance, and absorptance. Measurement information and experimental results obtained in this survey are given in Tables 20-1 to 20-10 and Figures 20-1 to 20-5. By careful review of the tables and figures, one will see that the magnitudes of the thermal radiative properties are very much affected by the surface conditions of the specimens. The literature abounds with examples of test surfaces shown to be very sensitive to methods of preparation, thermal history, and environmental conditions. Despite this awareness, descriptions of test surfaces are generally inadequate because of our modest understanding of the mechanisms or real surface effects and how to properly characterize a surface.

To isolate the individual surface characteristics is a difficult task. For most materials it is not practical to alter one characteristic without causing an influence on another. The control of the many variables required to study surface characterization in a logical manner is a complex problem. As a result only the simplest of surface profiles or compositional effects have been studied or are understood. One of the most important influences on the radiative properties of metals arises from surface roughness.

Because of the difficulties mentioned above, data analysis and evaluation is not a straightforward task; some logical but not exact means should be used in the generation of the most probable values for the properties of our interest. It is decided that the classical model of Hagen and Rubens with some modification is used to interpret the selected emittance data for mechanically polished surfaces, which is chosen as a good approximation to the real surfaces. Details of modifying the Hagen and Rubens equation are discussed in Section 2 and Eq. (2.5-5) is used for data analysis.

Reliable and accurate available data on the normal spectral emittance of mechanically polished aluminum surface were obtained by converting the data sets, curves 4 and 5 of Figure 20-4, from absorptance to emittance using Kirchhoff's law. Data for curves 4 and 5 were obtained at temperatures of 573 K and 293 K respectively. By a least squares calculation Eq. (4.20-1) was found to fit the selected data with uncertainties of less than $\pm 10\%$. Absorptance and reflectance can be calculated by using Eqs. (4.20-2) and (4.20-3).

By a quick scanning review of the details on the available data and information given in Tables 20-1 to 20-10 and Figures 20-1 to 20-5, it appears that the surface roughness can be incorporated into Eq. (4.20-1). However, no attempt was made because there was not a single systematic information on the roughness dependence of the radiative properties available for data analysis. As a result, only the radiative properties of mechanically polished surface are presented here. Note that in the following tables more decimal places are reported than warranted merely for the purpose of tabular smoothness and internal comparison. Readers are advised to use the appropriate uncertainties given in each case.

a. Normal Spectral Emittance (Wavelength Dependence)

Normal spectral emittance of mechanically polished graphite fiber aluminum matrix composite is calculated from Eq. (4.20-1) and listed in Table 22-1 and plotted in Figure 22-1. The values generated are considered as provisional (about $\pm 25\%$ uncertainty) since they are estimated based on the aluminum data. Provisional values are presented at five temperatures, 293, 450, 600, 750, and 850 K. Note that the emittance is usually quite low and remains practically constant for wavelengths longer than $6 \mu\text{m}$.

TABLE 22-1. PROVISIONAL NORMAL SPECTRAL EMISSANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)
(WAVELENGTH: λ , μm ; TEMPERATURE, T ; κ : EMISSANCE, ϵ)

λ	ϵ										
MECHANICALLY POLISHED $T = 293$	MECHANICALLY POLISHED $T = 450$	MECHANICALLY POLISHED $T = 600$	MECHANICALLY POLISHED $T = 750$	MECHANICALLY POLISHED $T = 850$							
2.5	0.057	2.5	0.071	2.5	0.073	2.5	0.075	2.5	0.076	2.5	0.076
2.8	0.057	2.8	0.063	2.8	0.067	2.8	0.069	2.8	0.070	2.8	0.070
3.0	0.052	3.0	0.059	3.0	0.063	3.0	0.065	3.0	0.067	3.0	0.067
3.5	0.044	3.5	0.052	3.5	0.056	3.5	0.058	3.5	0.062	3.5	0.062
3.8	0.041	3.8	0.046	3.8	0.052	3.8	0.057	3.8	0.059	3.8	0.059
4.0	0.039	4.0	0.046	4.0	0.051	4.0	0.055	4.0	0.057	4.0	0.057
4.5	0.035	4.5	0.043	4.5	0.047	4.5	0.051	4.5	0.053	4.5	0.053
5.0	0.033	5.0	0.040	5.0	0.044	5.0	0.048	5.0	0.050	5.0	0.050
5.5	0.031	5.5	0.037	5.5	0.042	5.5	0.045	5.5	0.048	5.5	0.048
6.0	0.029	6.0	0.035	6.0	0.040	6.0	0.043	6.0	0.045	6.0	0.045
6.5	0.027	6.5	0.034	6.5	0.039	6.5	0.042	6.5	0.044	6.5	0.044
7.0	0.026	7.0	0.032	7.0	0.037	7.0	0.040	7.0	0.042	7.0	0.042
7.5	0.025	7.5	0.031	7.5	0.035	7.5	0.039	7.5	0.040	7.5	0.040
8.0	0.024	8.0	0.030	8.0	0.034	8.0	0.037	8.0	0.039	8.0	0.039
8.5	0.023	8.5	0.029	8.5	0.033	8.5	0.036	8.5	0.038	8.5	0.038
9.0	0.023	9.0	0.028	9.0	0.032	9.0	0.035	9.0	0.037	9.0	0.037
9.5	0.022	9.5	0.027	9.5	0.031	9.5	0.034	9.5	0.036	9.5	0.036
10.0	0.021	10.0	0.026	10.0	0.030	10.0	0.033	10.0	0.035	10.0	0.035
10.5	0.021	10.5	0.025	10.5	0.029	10.5	0.032	10.5	0.034	10.5	0.034
11.0	0.020	11.0	0.025	11.0	0.029	11.0	0.032	11.0	0.033	11.0	0.033
11.5	0.020	11.5	0.025	11.5	0.028	11.5	0.031	11.5	0.033	11.5	0.033
12.0	0.019	12.0	0.024	12.0	0.028	12.0	0.030	12.0	0.032	12.0	0.032
12.5	0.019	12.5	0.024	12.5	0.027	12.5	0.030	12.5	0.031	12.5	0.031
13.0	0.019	13.0	0.023	13.0	0.026	13.0	0.029	13.0	0.031	13.0	0.031
13.5	0.019	13.5	0.023	13.5	0.026	13.5	0.029	13.5	0.030	13.5	0.030
14.0	0.019	14.0	0.022	14.0	0.025	14.0	0.029	14.0	0.030	14.0	0.030
14.5	0.017	14.5	0.022	14.5	0.025	14.5	0.029	14.5	0.029	14.5	0.029
15.0	0.017	15.0	0.021	15.0	0.025	15.0	0.027	15.0	0.029	15.0	0.029




FIGURE 22-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).

b. Normal Spectral Emittance (Temperature Dependence)

The normal spectral emittance as a function of temperature is given in Table 22-2 and Figure 22-2. The generated values are considered as provisional with $\pm 25\%$ uncertainty. The plot clearly shows that emittance for a given wavelength does not vary appreciably for a wide temperature range. Note that the melting point of aluminum at about 930 K is not far from the ending point (about 880 K) of each curve. It seems that the curves can be extrapolated to or beyond the melting point.

TABLE 22-2. PROVISIONAL NORMAL SPECTRAL EMMITTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)

[WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMMITTANCE, ϵ]

CHARCALLY LISHED $\lambda = 2.6$	T	ϵ	MECHANICALLY POLISHED $\lambda = 3.8$		MECHANICALLY POLISHED $\lambda = 5.0$		MECHANICALLY POLISHED $\lambda = 10.6$	
			T	ϵ	T	ϵ	T	ϵ
150.0	0.054	252.0	0.038	253.0	0.039	253.0	0.019	
193.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021	
226.0	0.057	352.0	0.041	353.0	0.033	353.0	0.021	
258.0	0.062	352.0	0.044	353.0	0.036	353.0	0.023	
280.0	0.062	356.0	0.046	357.0	0.038	357.0	0.024	
312.0	0.062	356.0	0.049	357.0	0.040	357.0	0.026	
344.0	0.065	356.0	0.053	357.0	0.044	357.0	0.027	
376.0	0.066	352.0	0.052	353.0	0.043	353.0	0.026	
408.0	0.067	360.0	0.053	361.0	0.044	361.0	0.029	
440.0	0.067	360.0	0.055	361.0	0.046	361.0	0.030	
472.0	0.068	359.0	0.055	360.0	0.047	360.0	0.031	
504.0	0.069	376.0	0.057	375.0	0.048	375.0	0.032	
536.0	0.069	372.0	0.059	373.0	0.049	373.0	0.033	
568.0	0.070	366.0	0.059	367.0	0.051	367.0	0.034	
600.0	0.070	360.0	0.059	361.0	0.051	361.0	0.035	




FIGURE 22-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

As given in Table 22-3 and plotted in Figure 22-3 the normal spectral reflectance of graphite fiber aluminum matrix composite is calculated by assuming that energy loss of the impinging radiation is entirely due to absorption. Since the data analysis is totally based on the available data of aluminum, allowance is given in the estimation of the predicted values. An estimated uncertainty of $\pm 20\%$ is given to the calculated values.

TABLE 22-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)

(WAVELLENGTH, λ , μm ; TEMPERATURE, T , K; REFLECTANCE, ρ)

λ	ρ										
2.5	0.933	2.5	0.929	2.5	0.927	2.5	0.925	2.5	0.922	2.5	0.922
2.6	0.943	2.5	0.937	2.6	0.933	2.6	0.931	2.6	0.930	2.6	0.930
3.0	0.948	3.0	0.941	3.0	0.937	3.0	0.934	3.0	0.933	3.0	0.933
3.5	0.956	3.5	0.946	3.5	0.944	3.5	0.940	3.5	0.938	3.5	0.938
3.8	0.959	3.8	0.952	3.8	0.947	3.8	0.943	3.8	0.941	3.8	0.941
4.0	0.961	4.0	0.957	4.0	0.952	4.0	0.945	4.0	0.943	4.0	0.943
4.5	0.965	4.5	0.962	4.5	0.957	4.5	0.949	4.5	0.947	4.5	0.947
5.0	0.967	5.0	0.960	5.0	0.956	5.0	0.952	5.0	0.950	5.0	0.950
5.5	0.969	5.5	0.963	5.5	0.953	5.5	0.954	5.5	0.952	5.5	0.952
6.0	0.971	6.0	0.966	6.0	0.960	6.0	0.957	6.0	0.955	6.0	0.955
6.5	0.973	6.5	0.966	6.5	0.955	6.5	0.953	6.5	0.951	6.5	0.951
7.0	0.974	7.0	0.963	7.0	0.953	7.0	0.950	7.0	0.948	7.0	0.948
7.5	0.975	7.5	0.963	7.5	0.953	7.5	0.950	7.5	0.948	7.5	0.948
8.0	0.976	8.0	0.963	8.0	0.953	8.0	0.950	8.0	0.948	8.0	0.948
8.5	0.977	8.5	0.963	8.5	0.953	8.5	0.950	8.5	0.948	8.5	0.948
9.0	0.977	9.0	0.962	9.0	0.952	9.0	0.949	9.0	0.947	9.0	0.947
9.5	0.973	9.5	0.963	9.5	0.953	9.5	0.950	9.5	0.948	9.5	0.948
10.0	0.973	10.0	0.974	10.0	0.963	10.0	0.957	10.0	0.954	10.0	0.954
10.5	0.979	10.5	0.970	10.5	0.963	10.5	0.957	10.5	0.954	10.5	0.954
11.0	0.979	11.0	0.971	11.0	0.963	11.0	0.957	11.0	0.954	11.0	0.954
11.5	0.979	11.5	0.971	11.5	0.963	11.5	0.957	11.5	0.954	11.5	0.954
12.0	0.971	12.0	0.971	12.0	0.963	12.0	0.957	12.0	0.954	12.0	0.954
12.5	0.971	12.5	0.971	12.5	0.963	12.5	0.957	12.5	0.954	12.5	0.954
13.0	0.971	13.0	0.971	13.0	0.963	13.0	0.957	13.0	0.954	13.0	0.954
13.5	0.971	13.5	0.971	13.5	0.963	13.5	0.957	13.5	0.954	13.5	0.954
14.0	0.972	14.0	0.972	14.0	0.963	14.0	0.957	14.0	0.954	14.0	0.954
14.5	0.973	14.5	0.973	14.5	0.963	14.5	0.957	14.5	0.954	14.5	0.954
15.0	0.973	15.0	0.973	15.0	0.963	15.0	0.957	15.0	0.954	15.0	0.954
15.5	0.973	15.5	0.973	15.5	0.963	15.5	0.957	15.5	0.954	15.5	0.954




FIGURE 22-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).

d. Normal Spectral Reflectance (Temperature Dependence)

In Table 22-4, the provisional values of the normal spectral reflectance are given with an estimated uncertainty of $\pm 20\%$. The variation of the property as a function of temperature is demonstrated in Figure 22-4. For a given wavelength, the normal spectral reflectance remains as a constant from room temperature up to near the melting point of the material. At higher temperatures our knowledge on this property is lacking. However, it seems that a linear extrapolation of the curve to and above the melting point can be used with uncertainty of no more than $\pm 35\%$.

TABLE 22-4. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)
WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ

T	ρ	T	ρ	T	ρ	T	ρ
MECHANICALLY POLISHED $\lambda = 2.8$		MECHANICALLY POLISHED $\lambda = 3.0$		MECHANICALLY POLISHED $\lambda = 5.0$		MECHANICALLY POLISHED $\lambda = 10.6$	
250.0	0.946	250.0	0.962	250.0	0.979	250.0	0.981
293.0	0.943	293.0	0.959	293.0	0.967	293.0	0.979
329.0	0.943	329.0	0.959	329.0	0.967	329.0	0.979
350.0	0.943	350.0	0.956	350.0	0.964	350.0	0.977
400.0	0.934	429.0	0.954	429.0	0.962	400.0	0.976
450.0	0.937	450.0	0.952	450.0	0.963	450.0	0.974
500.0	0.935	500.0	0.952	500.0	0.962	500.0	0.973
520.0	0.937	550.0	0.948	550.0	0.957	550.0	0.972
600.0	0.933	600.0	0.947	600.0	0.956	600.0	0.971
650.0	0.932	650.0	0.945	650.0	0.954	650.0	0.973
700.0	0.932	700.0	0.944	700.0	0.953	700.0	0.973
750.0	0.931	750.0	0.943	750.0	0.952	750.0	0.973
800.0	0.931	800.0	0.942	800.0	0.951	800.0	0.973
850.0	0.930	850.0	0.941	850.0	0.950	850.0	0.973
900.0	0.930	880.0	0.941	880.0	0.949	880.0	0.973




FIGURE 22-4. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

The normal spectral absorptance is obtained according to the Kirchhoff's law, i.e., numerically the absorptance is equal to the emittance. The absorptance varies appreciably for wavelengths lower than $4.0 \mu\text{m}$ and remains practically unchanged for longer wavelengths. The generated provisional values with $\pm 25\%$ uncertainty are given in Table 22-5 and plotted in Figure 22-5.

TABLE 22-5. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α	λ	α	λ	α	λ	α	λ	α	λ	α
MECHANICALLY POLISHED $T = 293$	0.057	2.5	0.071	2.5	0.073	2.5	0.075	2.5	0.078	2.5	0.078
	2.8	2.8	0.063	2.8	0.067	2.8	0.069	2.8	0.070	2.8	0.070
	3.0	3.0	0.059	3.0	0.063	3.0	0.066	3.0	0.067	3.0	0.067
	3.5	3.5	0.052	3.5	0.056	3.5	0.060	3.5	0.062	3.5	0.062
	3.9	3.9	0.044	3.9	0.048	3.9	0.052	3.9	0.055	3.9	0.055
	4.0	4.0	0.039	4.0	0.042	4.0	0.045	4.0	0.048	4.0	0.048
	4.5	4.5	0.035	4.5	0.043	4.5	0.047	4.5	0.051	4.5	0.053
	5.0	5.0	0.033	5.0	0.040	5.0	0.044	5.0	0.048	5.0	0.050
	5.5	5.5	0.031	5.5	0.037	5.5	0.042	5.5	0.046	5.5	0.046
	6.0	6.0	0.029	6.0	0.035	6.0	0.040	6.0	0.043	6.0	0.045
	6.5	6.5	0.027	6.5	0.034	6.5	0.038	6.5	0.042	6.5	0.044
	7.0	7.0	0.026	7.0	0.032	7.0	0.037	7.0	0.040	7.0	0.042
	7.5	7.5	0.025	7.5	0.031	7.5	0.035	7.5	0.039	7.5	0.040
	8.0	8.0	0.024	8.0	0.030	8.0	0.034	8.0	0.037	8.0	0.039
	8.5	8.5	0.023	8.5	0.029	8.5	0.035	8.5	0.036	8.5	0.036
	9.0	9.0	0.023	9.0	0.023	9.0	0.032	9.0	0.035	9.0	0.037
	9.5	9.5	0.022	9.5	0.027	9.5	0.034	9.5	0.034	9.5	0.036
	10.0	10.0	0.021	10.0	0.026	10.0	0.030	10.0	0.033	10.0	0.035
	10.5	10.5	0.021	10.5	0.026	10.5	0.029	10.5	0.032	10.5	0.034
	11.0	11.0	0.020	11.0	0.025	11.0	0.029	11.0	0.032	11.0	0.033
	11.5	11.5	0.020	11.5	0.025	11.5	0.029	11.5	0.033	11.5	0.033
	12.0	12.0	0.019	12.0	0.024	12.0	0.028	12.0	0.030	12.0	0.032
	12.5	12.5	0.019	12.5	0.024	12.5	0.027	12.5	0.030	12.5	0.031
	13.0	13.0	0.019	13.0	0.023	13.0	0.026	13.0	0.029	13.0	0.031
	13.5	13.5	0.016	13.5	0.023	13.5	0.026	13.5	0.029	13.5	0.030
	14.0	14.0	0.018	14.0	0.022	14.0	0.025	14.0	0.028	14.0	0.030
	14.5	14.5	0.017	14.5	0.022	14.5	0.025	14.5	0.028	14.5	0.029
	15.0	15.0	0.017	15.0	0.021	15.0	0.025	15.0	0.027	15.0	0.029




FIGURE 22-5. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (WAVELENGTH DEPENDENCE).

f. Normal Spectral Absorptance (Temperature Dependence)

The provisional values of the normal spectral absorptance of graphite fiber aluminum matrix composite is given in Table 22-6 and plotted in Figure 22-6. They are numerically equal to the normal spectral emittance. In Figure 22-6, our predicted curves for 5.0 μm and 10.0 μm are higher than experimental values plotted in Figure 20-5. By a careful examination of the measurement information, one sees that the experimental points in Figure 20-5 are for thin films. The absorptance of bulk material is in general higher than that of thin film. An uncertainty of 25% is incorporated to the provisional values so that they can be used for most of the real surfaces.

TABLE 22-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α :

MECHANICALLY POLISHED $\lambda = 2.8$	T	α	T	α	MECHANICALLY POLISHED $\lambda = 5.0$	T	α	MECHANICALLY POLISHED $\lambda = 10.6$
	MECHANICALLY POLISHED $\lambda = 3.8$	T	α	MECHANICALLY POLISHED $\lambda = 5.0$		T	α	
	250.0	0.054	250.0	0.038		250.0	0.030	
293.0	0.057	293.0	0.041	293.0	0.033	293.0	0.021	
300.0	0.057	300.0	0.041	300.0	0.033	300.0	0.021	
350.0	0.060	350.0	0.044	350.0	0.036	350.0	0.023	
400.0	0.062	400.0	0.046	400.0	0.038	400.0	0.024	
450.0	0.063	450.0	0.048	450.0	0.040	450.0	0.026	
500.0	0.065	500.0	0.050	500.0	0.041	500.0	0.027	
550.0	0.066	550.0	0.052	550.0	0.043	550.0	0.028	
600.0	0.067	600.0	0.053	600.0	0.044	600.0	0.029	
650.0	0.069	650.0	0.055	650.0	0.046	650.0	0.030	
700.0	0.063	700.0	0.056	700.0	0.047	700.0	0.031	
750.0	0.069	750.0	0.057	750.0	0.048	750.0	0.032	
800.0	0.069	800.0	0.053	800.0	0.049	800.0	0.033	
850.0	0.070	850.0	0.059	850.0	0.050	850.0	0.034	
880.0	0.070	880.0	0.059	880.0	0.051	880.0	0.035	




FIGURE 22-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER ALUMINUM MATRIX COMPOSITE (TEMPERATURE DEPENDENCE).

g. Transmittance

Although it is true that metals in the form of extremely thin films may be transparent for a wide wavelength range, they are opaque if the thickness is greater than several hundred angstroms. Consequently, composites with metal matrix are opaque to visible and infrared radiation because in general applications they are not used as extremely thin films. This leads to the conclusion that as an aircraft/spacecraft structural material, this composite is opaque and its transmittance is zero.

4.23. Boron Fiber Epoxy Composite

This composite material consists usually of continuous boron filaments surrounded by a matrix of epoxy resin. It is usually produced in tape form so it can be used in further fabrication of specialized materials.

The boron filaments, as currently produced, are formed by vapor deposition of boron on a fine tungsten wire substrate within a reactor. Exposure of the tungsten substrate to the high-temperature boron trichloride reactor environment results in a filament consisting of a boron sheath on a tungsten boride core. Other means of producing boron filaments are currently being investigated which would eliminate the tungsten substrate.

The organic matrix resins most commonly used with boron filaments are modified epoxy resins available as commercial formulations developed specifically for this purpose. Other organic resins used include polyamides and phenolics. However, the state of the art with these resins is less advanced than for the epoxy materials.

The normal service temperature range of the boron fiber epoxy composite is dependent on the type of epoxy resin being used as a matrix. This range is nominally 220 K, where the epoxy becomes very brittle, to 450 K. Epoxy resin decomposes around 590 K.

The boron fiber epoxy is fabricated primarily for aircraft constructions, much of its mechanical and thermal properties are studied. As a result, a large amount of experimental data are made available. However, with regard to the thermal radiative properties of the composite, it is quite discouraging. Only one set of systematic experimentally determined data on the normal spectral reflectance is all that can be uncovered by our open literature search. This leaves us no choice but to use it as the basis for the estimation of the most probable values of the radiative properties for boron fiber epoxy composite.

The fact that the composite material is made by bonding boron fibers in a matrix of epoxy resin implies that epoxy is the material which predominately contributes to the thermal radiative properties of the composite material. The other component, the boron fiber, plays minor role. Indeed, by comparing the shapes of the normal spectral reflectance curves (Figure 23-4 in this subsection and Figures 24-4 and 25-4 in subsections 4.24 and 4.25 respectively) we can see the spectral band patterns of the three epoxy composite materials (boron fiber epoxy composite, glass fiber epoxy composite and graphite fiber epoxy composite) are similar.

Reflectance of epoxy is generally fairly low, about 10%, for wavelengths longer than 2.5 μm . Also, it does not change appreciably as the material is heated up and goes decomposition phase and into the char region [A00004]. In other words, the radiative properties of epoxy are independent of temperature.

For epoxy composite materials, the following two relations are commonly used as good approximations:

$$\alpha(0, \lambda) = 1 - \rho(0, 2\pi, \lambda);$$

$$\epsilon(0, \lambda) = \alpha(0, \lambda),$$

because of opaqueness of the materials.

According to the facts discussed above, we are in a position to estimate the following six subproperties for boron fiber epoxy composite based on the single available set of reflectance data:

- Normal spectral emittance (wavelength dependence)
- Normal spectral emittance (temperature dependence)
- Normal spectral reflectance (wavelength dependence)
- Normal spectral reflectance (temperature dependence)
- Normal spectral absorptance (wavelength dependence)
- Normal spectral absorptance (temperature dependence)

a. Normal Spectral Emittance (Wavelength Dependence)

Provisional values of the normal spectral emittance of slightly grit-blasted boron fiber epoxy composite are obtained from the analyzed result of reflectance by using the relation $\alpha(0, \lambda) = 1 - \rho(0, 2\pi, \lambda)$ and Kirchhoff's law. Such conversion is frequently used for the materials whose reflectance is known [A00004]. The provisional values, listed in Table 23-1 and plotted in Figure 23-1, are in general very close to unity. For rough uses, a value of 0.95 can be safely used because the uncertainty of the provisional values is $\pm 20\%$.

TABLE 23-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF NORN FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K; EMITTANCE, ϵ)

λ	ϵ
LIGHTLY GRIT-BLASTED $T = 293$	
2.5	0.934
2.8	0.955
3.0	0.962
3.5	0.955
3.8	0.944
4.0	0.942
4.5	0.940
5.0	0.940
5.5	0.946
6.0	0.946
6.5	0.967
7.0	0.967
7.5	0.967
8.0	0.966
8.5	0.962
9.0	0.959
9.5	0.958
10.0	0.956
10.5	0.956
10.6	0.956
11.0	0.956
11.5	0.956
12.0	0.956
12.5	0.956
13.0	0.956
13.5	0.956
14.0	0.957
14.5	0.961
15.0	0.973




FIGURE 23-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER EPOXY
COMPOSITE (WAVELENGTH DEPENDENCE).

b. Normal Spectral Emittance (Temperature Dependence)

The normal spectral emittance as a function of temperature is given in Table 23-2 and plotted in Figure 23-2. The generated values are considered as provisional with 20% uncertainty. Here, we present the property values as a constant for a given wavelength because it has been observed in epoxy composites that the radiative properties do not change appreciably with temperature [A00002]. With 20% uncertainty, the provisional values can be safely used for most of the true surfaces.

TABLE 23-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIRED EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

LIGHTLY GRIT-BLASTED $\lambda = 2.6$		LIGHTLY GRIT-BLASTED $\lambda = 3.8$		LIGHTLY GRIT-BLASTED $\lambda = 5.0$		LIGHTLY GRIT-BLASTED $\lambda = 10.6$	
T	ϵ	T	ϵ	T	ϵ	T	ϵ
250.0	0.955	250.0	0.944	250.0	0.940	250.0	0.956
300.0	0.955	300.0	0.944	300.0	0.940	300.0	0.956
350.0	0.955	350.0	0.944	350.0	0.940	350.0	0.956
400.0	0.955	400.0	0.944	400.0	0.940	400.0	0.956
450.0	0.955	450.0	0.944	450.0	0.940	450.0	0.956
500.0	0.955	500.0	0.944	500.0	0.940	500.0	0.956




FIGURE 23-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

As given in Table 23-3 and plotted in Figure 23-3, the provisional values of boron fiber epoxy composite are obtained by reading off from a curve smoothed out from the only available set of data shown in Figure 23-4. It shows a quite complex spectral distribution of energy reflected from the composite material. Because of scantiness of the available data and spectral complexity, no attempt was made to carry out analytical calculations but the smoothing technique. An estimated uncertainty of 25% is given to the provisional values which are believed to be reasonable for most of the real surfaces.

TABLE 23-3. PROVISIONAL NORMAL SPECIFIC REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : REFLECTANCE, ρ)

λ	ρ
LIGHTLY GRIT-BLASTED	
$T = 293$	
2.5	0.066
2.8	0.045
3.0	0.036
3.5	0.045
3.8	0.056
4.0	0.058
4.5	0.060
5.0	0.060
5.5	0.052
6.0	0.035
6.5	0.033
7.0	0.033
7.5	0.033
8.0	0.034
8.5	0.038
9.0	0.041
9.5	0.042
10.0	0.044
10.5	0.044
10.6	0.044
11.0	0.044
11.5	0.044
12.0	0.044
12.5	0.044
13.0	0.044
13.5	0.044
14.0	0.043
14.5	0.039
15.0	0.027




FIGURE 23-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).




FIGURE 23-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).

TABLE 23-4. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent). Specifications, and Remarks
1 A00001	Grimm, T.C.	1972	2.0-14.7	293		Bare surface specimen; 2.54 cm square; lightly grit-blasted; prepared by the Organic Chemistry Laboratory in the company where the author worked; measurements made with a Dunn Associates ellipsoidal mirror reflectometer; data extracted from a figure; relative reflectance reported; multiplied by 0.95 to convert to absolute values (gold reference mirror used); $\theta = 15^\circ$; $\omega' = 2\pi$.

TABLE 23-5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF ACORDA FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T ; K : REFLECTANCE, ρ)

λ	CURVE 1 $T = 295^\circ$	λ	CURVE 1 (CONT.)	λ	CURVE 1 (CONT.)
2.66	0.066	4.93	0.057	19.31	0.043
2.67	0.044	4.93	0.059	10.56	0.042
2.79	0.047	5.00	0.053	11.60	0.043
2.80	0.050	5.62	0.057	11.90	0.039
2.84	0.039	5.05	0.057	11.32	0.041
2.89	0.031	5.12	0.055	11.65	0.039
2.90	0.026	5.31	0.055	12.60	0.039
2.93	0.031	5.51	0.055	12.15	0.040
2.96	0.039	5.63	0.043	12.44	0.043
2.98	0.032	5.73	0.033	12.76	0.042
3.02	0.028	5.81	0.035	13.33	0.041
3.03	0.047	5.89	0.030	13.50	0.040
3.07	0.040	5.97	0.031	13.63	0.044
3.13	0.040	6.05	0.030	14.00	0.042
3.15	0.045	6.18	0.031	14.26	0.049
3.21	0.042	6.25	0.031	14.51	0.033
3.26	0.045	6.38	0.034	14.63	0.030
3.29	0.041	6.53	0.029		
3.33	0.041	6.67	0.029		
3.36	0.032	6.73	0.029		
3.45	0.032	6.91	0.032		
3.55	0.043	7.02	0.031		
3.58	0.047	7.35	0.033		
3.70	0.050	7.43	0.032		
3.73	0.058	7.51	0.029		
3.80	0.060	7.61	0.028		
3.82	0.056	7.70	0.029		
3.93	0.062	7.78	0.031		
4.01	0.060	8.04	0.031		
4.11	0.064	8.18	0.035		
4.22	0.061	8.30	0.044		
4.33	0.059	8.45	0.041		
4.46	0.063	8.62	0.035		
4.51	0.058	8.76	0.036		
4.55	0.047	9.00	0.040		
4.59	0.046	9.22	0.040		
4.65	0.046	9.41	0.037		
4.71	0.054	9.65	0.036		
4.75	0.057	9.87	0.042		
		10.08	0.046		

d. Normal Spectral Reflectance (Temperature Dependence)

In Table 23-6, the provisional values of the normal spectral reflectance are given with estimated uncertainties of $\pm 25\%$. The variation of the property as a function of temperature is demonstrated in Figure 23-5. For a given wavelength, the normal spectral reflectance remains as a constant from room temperature up to the char region of epoxy. The independency of the reflectance of epoxy composite with temperature has been observed experimentally [A00002]. The reported provisional values are believed to be reasonable in most of the real situation.

TABLE 23-6. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

T	ρ	T	ρ	T	ρ	T	ρ
LIGHTLY GRIT-BLASTED						LIGHTLY GRIT-BLASTED	
$\lambda = 2.8$						$\lambda = 3.8$	
250.0	0.045	250.0	0.056	250.0	0.060	250.0	0.044
300.0	0.045	300.0	0.056	300.0	0.060	300.0	0.044
350.0	0.045	350.0	0.056	350.0	0.060	350.0	0.044
400.0	0.045	400.0	0.056	400.0	0.060	400.0	0.044
450.0	0.045	450.0	0.056	450.0	0.060	450.0	0.044
500.0	0.045	500.0	0.056	500.0	0.060	500.0	0.044

**LIGHTLY
GRIT-BLASTED**
 $\lambda = 5.0$

250.0	0.045	250.0	0.056	250.0	0.060	250.0	0.044
300.0	0.045	300.0	0.056	300.0	0.060	300.0	0.044
350.0	0.045	350.0	0.056	350.0	0.060	350.0	0.044
400.0	0.045	400.0	0.056	400.0	0.060	400.0	0.044
450.0	0.045	450.0	0.056	450.0	0.060	450.0	0.044
500.0	0.045	500.0	0.056	500.0	0.060	500.0	0.044




FIGURE 23-5. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

The normal spectral absorptance is obtained according to the Kirchhoff's law, i.e., numerically the absorptance is equal to the emittance. As a result, Table 23-7 and Figure 23-6 appear the same as Table 23-1 and Figure 23-1, as well as the estimated uncertainties ($\pm 20\%$).

TABLE 23-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF 3C₂N FILTER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α)

λ	α
LIGHTLY GRIT-BLASTED $T = 293$	
2.5	0.934
2.8	0.955
3.0	0.962
3.5	0.955
3.8	0.944
4.0	0.942
4.5	0.946
5.0	0.940
5.5	0.946
6.0	0.955
6.5	0.967
7.0	0.967
7.5	0.967
8.0	0.966
8.5	0.962
9.0	0.959
9.5	0.959
10.0	0.956
10.5	0.956
10.6	0.956
11.0	0.956
11.5	0.956
12.0	0.956
12.5	0.956
13.0	0.956
13.5	0.956
14.0	0.957
14.5	0.961
15.0	0.973




FIGURE 23-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).

f. Normal Spectral Absorptance (Temperature Dependence)

The normal spectral absorptance as a function of temperature is given in Table 23-8 and plotted in Figure 23-7. The generated values are considered as provisional with 20% uncertainty. Here, we present the property values as constant for a given wavelength because it has been observed in epoxy composites that the radiative properties do not change appreciably with temperature [A00002]. With 20% uncertainty, the provisional values can be safely used for most of the true surfaces.

TABLE 23-8. PROVISIONAL NORMAL SPECTRAL ABSORBTION OF UCPCN FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORBTANCE, α)

T	α	T	α	T	α	T	α
LIGHTLY GRIT-BLASTED							
$\lambda = 2.8$		$\lambda = 3.0$		$\lambda = 5.0$		$\lambda = 10.6$	
250.0	0.955	250.0	0.944	250.0	0.940	250.0	0.956
300.0	0.955	300.0	0.944	300.0	0.940	300.0	0.956
350.0	0.955	350.0	0.944	350.0	0.940	350.0	0.956
400.0	0.955	400.0	0.944	400.0	0.940	400.0	0.956
450.0	0.955	450.0	0.944	450.0	0.940	450.0	0.956
500.0	0.955	500.0	0.944	500.0	0.940	500.0	0.956




FIGURE 23-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF BORON FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

4.24. Glass Fiber Epoxy Composite

A small amount of the exterior area of the aircraft is composed of nonmetallics. These nonmetallics consist chiefly various glass fiber reinforced plastics, and epoxy composites, etc.

Composite materials have received great interest in the last decade because they provide unusual combinations of properties which cannot be obtained with any single, homogeneous substance. In aircraft and missile design, they have provided structural materials of very high strength and elastic modulus which also have low densities.

Among nonmetallic composites, the glass/epoxy composites are the most commonly used. The glass fiber epoxy composite consists usually of fine glass fibers surrounded by a matrix of epoxy resin. The other alternative form commonly used is the glass fabric reinforced plastics with epoxy surfacer.

Modified epoxy resins developed specifically for use in composites with glass fiber are available commercially. These are thermosetting resins used for low pressure laminating which normally cannot be used in continuous service above about 450 K although intermittent service at temperature up to 490 K is possible. Many of the various epoxy resins used as matrix constituents of composites are proprietary formulations whose exact chemical compositions are not available.

Although the mechanical and thermal properties of glass/epoxy composites are well studied, the thermal radiative properties are unattended. As a result, only one set of experimentally determined data on the normal spectral reflectance is all that can be found by our open literature search. This leaves us no choice but to use it as the basis for the estimation of the most probable values of the radiative properties for glass fiber epoxy composite.

The fact that the composite material is made by bonding the fibers in a matrix of epoxy resin implies that epoxy is the material which predominately contributes to the thermal radiative properties of the composite material. The other component, the fiber material, plays a minor role. Indeed, by comparing the shapes of the normal spectral reflectance curves (Figure 24-4 in this subsection and Figures 23-4 and 25-4 in subsections 4.23 and 4.25 respectively) we can see the spectral band patterns of the three epoxy composite materials (boron fiber epoxy composite, glass fiber epoxy composite and graphite fiber epoxy composite) are similar.

Reflectance of epoxy is generally fairly low, about 10%, for wavelengths longer than $2.5 \mu\text{m}$. Also, it does not change appreciably as the material is heated up and goes

decomposition phase and into the char region [A00004]. In other words, the radiative properties of epoxy are independent of temperature.

For epoxy composite materials, the following two relations are commonly used [A00004] as good approximations:

$$\alpha(0, \lambda) = 1 - \rho(0, 2\pi, \lambda);$$

$$\epsilon(0, \lambda) = \alpha(0, \lambda),$$

because of opaqueness of the materials.

According to the facts discussed above, we are in a position to estimate the following six subproperties for glass fiber epoxy composite based on the single available set of reflectance data:

- Normal spectral emittance (wavelength dependence)
- Normal spectral emittance (temperature dependence)
- Normal spectral reflectance (wavelength dependence)
- Normal spectral reflectance (temperature dependence)
- Normal spectral absorptance (wavelength dependence)
- Normal spectral absorptance (temperature dependence)

a. Normal Spectral Emittance (Wavelength Dependence)

Provisional values of the normal spectral emittance of slightly grit-blasted glass fiber epoxy composite are obtained from the analyzed result of reflectance by using the relation $\alpha(0, \lambda) = 1 - \rho(0, 2\pi, \lambda)$ and Kirchhoff's law. Such conversion is frequently used for the materials whose reflectance is known [A00004]. The provisional values, listed in Table 24-1 and plotted in Figure 24-1, are in general very close to unity. For rough uses, a value of 0.95 can be safely used because the uncertainty of the provisional values is $\pm 20\%$.

TABLE 24-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ
2.0	0.926
2.5	0.943
3.0	0.954
3.5	0.943
4.0	0.939
4.5	0.937
5.0	0.940
5.5	0.954
6.0	0.971
6.5	0.976
7.0	0.976
7.5	0.976
8.0	0.976
8.5	0.976
9.0	0.975
9.5	0.964
10.0	0.957
10.5	0.964
10.6	0.966
11.0	0.970
11.5	0.974
12.0	0.977
12.5	0.980
13.0	0.980
13.5	0.975
14.0	0.970
14.5	0.966
15.0	0.963

LIGHTLY
GRIT-BLASTED
 $T = 293$




FIGURE 24-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).

b. Normal Spectral Emittance (Temperature Dependence)

The normal spectral emittance as a function of temperature is given in Table 24-2 and plotted in Figure 24-2. The generated values are considered as provisional with 20% uncertainty. Here, we present the property values as a constant for a given wavelength because it has been observed in epoxy composites that the radiative properties do not change appreciably with temperature [A00002]. With 20% uncertainty, the provisional values can be safely used for most of the true surfaces.

TABLE 24-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)

(WAVELENGTH, $\lambda \cdot \mu\text{m}$: TEMPERATURE, T ; K : EMITTANCE, ϵ)					
T	ϵ	T	ϵ	T	ϵ
LIGHTLY GRIT-BLASTED $\lambda = 2.8$		LIGHTLY GRIT-BLASTED $\lambda = 3.6$		LIGHTLY GRIT-BLASTED $\lambda = 5.0$	
250.0	0.926	250.0	0.943	250.0	0.940
300.0	0.926	300.0	0.943	300.0	0.940
350.0	0.926	350.0	0.943	350.0	0.940
400.0	0.926	400.0	0.943	400.0	0.940
450.0	0.926	450.0	0.943	450.0	0.940
500.0	0.926	500.0	0.943	500.0	0.940




FIGURE 24-2. PROVISIONAL NORMAL SPECTRAL EMISSANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

As given in Table 24-3 and plotted in Figure 24-3, the provisional values of glass fiber epoxy composite are obtained by reading off from a curve smoothed out from the only available set of data shown in Figure 24-4. It shows a quite complex spectral distribution of energy reflected from the composite material. Because of scantiness of the available data and spectral complexity, no attempt was made to carry out analytical calculations but the smoothing technique. An estimated uncertainty of 25% is given to the provisional values which are believed to be reasonable for most of the real surfaces.

TABLE 24-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ
LIGHTLY GRIT-BLASTED	
2.0	0.074
3.0	0.057
3.5	0.046
3.8	0.045
4.0	0.061
4.5	0.063
5.0	0.060
5.5	0.046
6.0	0.029
6.5	0.024
7.0	0.024
7.5	0.024
8.0	0.024
8.5	0.024
9.0	0.025
9.5	0.036
10.0	0.043
10.5	0.036
10.6	0.034
11.0	0.036
11.5	0.026
12.0	0.023
12.5	0.020
13.0	0.020
13.5	0.025
14.0	0.030
14.5	0.034
15.0	0.037




FIGURE 24-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).




FIGURE 24-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).

TABLE 24-4. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (Wavelength Dependence)

Cur. Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 A00001	Grimm, T.C.	1972	2.0-14.7	293	Bare surface specimen; 2.54 cm square; lightly grit-blasted; prepared by the Organic Chemistry Laboratory in the company where the author worked; measurements made with a Durr Associates ellipsoidal mirror reflectometer; data extracted from a figure; relative reflectance reported; multiplied by 0.85 to convert to absolute values (gold reference mirror used); $\theta = 15^\circ$, $\omega' = 27$.	

TABLE 24-5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)

(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	λ	ρ
CURVE 1 $T = 293^\circ\text{K}$			CURVE 1 (CONT.)
2.58	0.262	6.93	0.027
2.66	0.196	7.17	0.026
2.70	0.138	7.27	0.026
2.74	0.103	7.48	0.025
2.78	0.080	7.65	0.022
2.80	0.080	7.79	0.020
2.81	0.065	7.98	0.020
2.83	0.081	8.24	0.026
2.94	0.047	8.45	0.026
2.96	0.049	8.90	0.018
3.08	0.050	9.12	0.018
3.14	0.055	9.57	0.037
3.20	0.049	9.81	0.048
3.28	0.049	10.01	0.041
3.35	0.037	10.10	0.039
3.47	0.042	10.28	0.035
3.50	0.051	10.47	0.035
3.55	0.055	10.60	0.040
3.63	0.050	10.66	0.031
3.72	0.057	11.00	0.028
3.80	0.060	11.31	0.028
3.85	0.053	11.49	0.027
3.97	0.054	11.76	0.021
4.24	0.066	12.10	0.020
4.36	0.063	12.48	0.017
4.50	0.065	12.94	0.017
4.58	0.063	13.19	0.021
4.66	0.066	13.47	0.025
4.83	0.055	13.96	0.028
5.00	0.160	14.13	0.028
5.01	0.055	14.23	0.022
5.15	0.049	14.64	0.033
5.55	0.044		
5.76	0.032		
5.96	0.032		
6.17	0.023		
6.33	0.029		
6.46	0.029		
6.60	0.027		

d. Normal Spectral Reflectance (Temperature Dependence)

In Table 24-6, the provisional values of the normal spectral reflectance are given with an estimated uncertainty of $\pm 25\%$. The variation of the property as a function of temperature is demonstrated in Figure 24-5. For a given wavelength, the normal spectral reflectance remains as a constant from room temperature up to the char region of epoxy. The independency of the reflectance of epoxy composite with temperature has been observed experimentally [A00002]. The reported provisional values are believed to be reasonable in most of the real situation.

TABLE 24-6. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
(WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

T	ρ	T	ρ	T	ρ	T	ρ
LIGHTLY GRIT-BLASTED							
$\lambda = 2.8$							
250.0	0.074	250.0	0.057	250.0	0.060	250.0	0.034
300.0	0.074	300.0	0.057	300.0	0.060	300.0	0.034
350.0	0.074	350.0	0.057	350.0	0.063	350.0	0.034
400.0	0.074	400.0	0.057	400.0	0.060	400.0	0.034
450.0	0.074	450.0	0.057	450.0	0.063	450.0	0.034
500.0	0.074	500.0	0.057	500.0	0.060	500.0	0.034

T	ρ	T	ρ	T	ρ	T	ρ
LIGHTLY GRIT-BLASTED							
$\lambda = 3.6$							
250.0	0.074	250.0	0.057	250.0	0.060	250.0	0.034
300.0	0.074	300.0	0.057	300.0	0.060	300.0	0.034
350.0	0.074	350.0	0.057	350.0	0.063	350.0	0.034
400.0	0.074	400.0	0.057	400.0	0.060	400.0	0.034
450.0	0.074	450.0	0.057	450.0	0.063	450.0	0.034
500.0	0.074	500.0	0.057	500.0	0.060	500.0	0.034

T	ρ	T	ρ	T	ρ	T	ρ
LIGHTLY GRIT-BLASTED							
$\lambda = 5.0$							
250.0	0.074	250.0	0.057	250.0	0.060	250.0	0.034
300.0	0.074	300.0	0.057	300.0	0.060	300.0	0.034
350.0	0.074	350.0	0.057	350.0	0.063	350.0	0.034
400.0	0.074	400.0	0.057	400.0	0.060	400.0	0.034
450.0	0.074	450.0	0.057	450.0	0.063	450.0	0.034
500.0	0.074	500.0	0.057	500.0	0.060	500.0	0.034

T	ρ	T	ρ	T	ρ	T	ρ
LIGHTLY GRIT-BLASTED							
$\lambda = 10.6$							
250.0	0.074	250.0	0.057	250.0	0.060	250.0	0.034
300.0	0.074	300.0	0.057	300.0	0.060	300.0	0.034
350.0	0.074	350.0	0.057	350.0	0.063	350.0	0.034
400.0	0.074	400.0	0.057	400.0	0.060	400.0	0.034
450.0	0.074	450.0	0.057	450.0	0.063	450.0	0.034
500.0	0.074	500.0	0.057	500.0	0.060	500.0	0.034




FIGURE 24-5. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

The normal spectral absorptance is obtained according to the Kirchhoff's law, i.e., numerically the absorptance is equal to the emittance. As a result, Table 24-7 and Figure 24-6 appear the same as Table 24-1 and Figure 24-1, as well as the estimated uncertainties ($\pm 20\%$).

TABLE 24-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α
LIGHTLY GRIT-BLASTED	
T = 293	
2.0	0.926
3.0	0.943
3.5	0.954
3.8	0.943
4.0	0.939
4.5	0.937
5.0	0.940
5.5	0.954
6.0	0.971
6.5	0.976
7.0	0.976
7.5	0.976
8.0	0.976
8.5	0.976
9.0	0.975
9.5	0.964
10.0	0.957
10.5	0.964
10.6	0.966
11.0	0.973
11.5	0.974
12.0	0.977
12.5	0.960
13.0	0.980
13.5	0.975
14.0	0.970
14.5	0.966
15.0	0.963




FIGURE 24-6. PROVISIONAL NORMAL SPECTRAL ABSORBANCE OF GLASS FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).

f. Normal Spectral Absorptance (Temperature Dependence)

The normal spectral absorptance as a function of temperature is given in Table 24-8 and plotted in Figure 24-7. The generated values are considered as provisional with 20% uncertainty. Here, we present the property values as constant for a given wavelength because it has been observed in epoxy composites that the radiative properties do not change appreciably with temperature [A00002]. With 20% uncertainty, the provisional values can be safely used for most of the true surfaces.

TABLE 24-9. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

T	α	T	α	T	α	T	α
LIGHTLY GRIT-BLASTED $\lambda = 2.8$	LIGHTLY GRIT-BLASTED $\lambda = 3.0$	LIGHTLY GRIT-BLASTED $\lambda = 5.0$	LIGHTLY GRIT-BLASTED $\lambda = 10.6$				
250.0	0.926	250.0	0.943	250.0	0.940	250.0	0.966
300.0	0.926	300.0	0.943	300.0	0.940	300.0	0.966
350.0	0.926	350.0	0.943	350.0	0.940	350.0	0.966
400.0	0.926	400.0	0.943	400.0	0.940	400.0	0.966
450.0	0.926	450.0	0.943	450.0	0.940	450.0	0.966
500.0	0.926	500.0	0.943	500.0	0.940	500.0	0.966




FIGURE 24-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GLASS FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

4.25. Graphite Fiber Epoxy Composite

Composite materials have received great interest in the last decade because they provide unusual combinations of properties which cannot be obtained with any single, homogeneous substance. In aircraft and missile design, they have provided structural materials of very high strength and elastic modulus which also have low densities.

The graphite fibers used in composites are made by the carbonization of organic filaments. The filaments most often used today are made from polyacrylonitrile (PAN) although rayon and acrylic fibers have been used to a limited extent. The mechanical properties of graphite fiber depend on the temperatures used in the carbonization process. Temperatures of 2800–3300 K result in fibers with high elastic modulus but relatively low tensile strength. Temperatures of 1800–2300 K yield fibers of the greatest tensile strength but only moderate modulus of elasticity. The density of the fibers varies from 1.74–1.94 g cm⁻³ depending on the carbonization temperatures used. The filaments are normally produced in untwisted, loose bundles, or tows, consisting of ten thousand fibers.

Modified epoxy resins developed specifically for use in composites with graphite fiber are available commercially. These are thermosetting resins used for low pressure laminating which normally cannot be used in continuous service above about 450 K although intermittent service at temperature up to 490 K is possible. Many of the various epoxy resins used as matrix constituents of composites are proprietary formulations whose exact chemical compositions are not available.

For aerospace design, graphite fiber-epoxy composites are generally supplied by the manufacturer as prepgs. These are tapes or broadgoods consisting of the graphite fibers impregnated with the epoxy resin matrix which have been only partially cured and consequently have a limited shelf life and require special storage facilities. The prepgs are used in the fabrication of laminates whose layer orientations are tailored to match individual design requirements. Consequently, large numbers of individually different crossplied laminates are likely to be encountered, each of which has distinctive properties and characteristics, and hence must be distinctly identified whenever it is to be associated with specific quantitative data.

The graphite fiber epoxy is fabricated primarily for aircraft constructions because of its advantages. Much of its mechanical and thermal properties are studied. As a result, sizable amount of data are made available at users disposal.

With regard to the thermal radiative properties of the composite, it is unfortunate to find that there is only one set of experimental data on the normal spectral reflectance

uncovered by our search. This leaves us no choice but to use it as the basis in the estimation of the most probable values of the radiative properties for graphite fiber epoxy composite.

The fact that the composite material is made by bonding graphite fibers in a matrix of epoxy resin implies that epoxy is the material which predominately contributes to the thermal radiative properties of the composite material. The other component, the graphite fiber, plays a minor role. Indeed, by comparing the shapes of the normal spectral reflectance curves (Figure 25-4 in this subsection and Figures 23-4 and 24-4 in subsections 4.23 and 4.24 respectively) we can see the spectral band patterns of the three epoxy composite materials (boron fiber epoxy composite, glass fiber epoxy composite and graphite fiber epoxy composite) are similar.

Reflectance of epoxy is generally fairly low, about 10%, for wavelengths longer than $2.5 \mu\text{m}$. Also, it does not change appreciably as the material is heated up and goes decomposition phase and into the char region [A00004]. In other words, the radiative properties of epoxy are independent of temperature.

For epoxy composite materials, the following two relations are commonly used as good approximations:

$$\alpha(0, \lambda) = 1 - \rho(0, 2\pi, \lambda);$$

$$\epsilon(0, \lambda) = \alpha(0, \lambda),$$

because of opaqueness of the materials.

According to the facts discussed above, we are in a position to make reasonable estimation of the following six subproperties for graphite fiber epoxy composite based on the single available set of reflectance data:

- Normal spectral emittance (wavelength dependence)
- Normal spectral emittance (temperature dependence)
- Normal spectral reflectance (wavelength dependence)
- Normal spectral reflectance (temperature dependence)
- Normal spectral absorptance (wavelength dependence)
- Normal spectral absorptance (temperature dependence)

a. Normal Spectral Emittance (Wavelength Dependence)

Provisional values of the thermal spectral emittance of slightly grit-blasted boron fiber epoxy composite are obtained from the analyzed result of reflectance by using

the relation $\alpha(0, \lambda) = 1 - \rho(0, 2\pi, \lambda)$ and Kirchhoff's law. Such conversion is frequently used for the materials whose reflectance is known [A00004]. The provisional values, listed in Table 25-1 and plotted in Figure 25-1, are in general very close to unity. For rough uses, a value of 0.95 can be safely used because the uncertainty of the provisional values is $\pm 20\%$.

TABLE 29-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

λ	ϵ
LIGHTLY GRIT-BLASTED	
$T = 293$	
2.5	0.903
2.8	0.921
3.0	0.927
3.5	0.928
3.8	0.900
4.0	0.994
4.5	0.986
5.0	0.888
5.5	0.993
6.0	0.914
6.5	0.938
7.0	0.945
7.5	0.947
8.0	0.947
8.5	0.946
9.0	0.944
9.5	0.939
10.0	0.931
10.5	0.925
10.6	0.925
11.0	0.925
11.5	0.939
12.0	0.937
12.5	0.935
13.0	0.926
13.5	0.914
14.0	0.904
14.5	0.896
15.0	0.894




FIGURE 25-1. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).

b. Normal Spectral Emittance (Temperature Dependence)

The normal spectral emittance as a function of temperature is given in Table 25-2 and plotted in Figure 25-2. The generated values are considered as provisional with 20% uncertainty. Here, we present the property values as a constant for a given wavelength because it has been observed in epoxy composites that the radiative properties do not change appreciably with temperature [A00002]. With 20% uncertainty, the provisional values can be safely used for most of the true surfaces.

TABLE 25-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER-EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; EMITTANCE, ϵ)

T	ϵ	T	ϵ	T	ϵ	T	ϵ
LIGHTLY GRIT-BLASTED							
$\lambda = 2.8$							
250.0	0.921	250.0	0.900	250.0	0.888	250.0	0.925
300.0	0.921	300.0	0.900	300.0	0.888	300.0	0.925
350.0	0.921	350.0	0.900	350.0	0.888	350.0	0.925
400.0	0.921	400.0	0.900	400.0	0.888	400.0	0.925
450.0	0.921	450.0	0.900	450.0	0.888	450.0	0.925
500.0	0.921	500.0	0.900	500.0	0.888	500.0	0.925

LIGHTLY GRIT-BLASTED
 $\lambda = 3.6$

T	ϵ	T	ϵ	T	ϵ	T	ϵ
LIGHTLY GRIT-BLASTED							
$\lambda = 5.0$							
250.0	0.921	250.0	0.900	250.0	0.888	250.0	0.925
300.0	0.921	300.0	0.900	300.0	0.888	300.0	0.925
350.0	0.921	350.0	0.900	350.0	0.888	350.0	0.925
400.0	0.921	400.0	0.900	400.0	0.888	400.0	0.925
450.0	0.921	450.0	0.900	450.0	0.888	450.0	0.925
500.0	0.921	500.0	0.900	500.0	0.888	500.0	0.925

LIGHTLY GRIT-BLASTED
 $\lambda = 10.6$




FIGURE 25-2. PROVISIONAL NORMAL SPECTRAL EMITTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

c. Normal Spectral Reflectance (Wavelength Dependence)

As given in Table 25-3 and plotted in Figure 25-3, the provisional values of graphite fiber epoxy composite are obtained by reading off from a curve smoothed out from the only available set of data shown in Figure 25-4. It shows a quite complex spectral distribution of energy reflected from the composite material. Because of scantiness of the available data and spectral complexity, no attempt was made to carry out analytical calculations but the smoothing technique. An estimated uncertainty of 25% is given to the provisional values which are believed to be reasonable for most of the real surfaces.

TABLE 25-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ
LIGHTLY GRIT-BLASTED .	
T = 293	
2.5	0.391
2.8	0.373
3.0	0.073
3.5	0.072
3.8	0.100
4.0	0.106
4.5	0.112
5.0	0.112
5.5	0.107
6.0	0.386
6.5	0.062
7.0	0.155
7.5	0.053
8.0	0.153
8.5	0.054
9.0	0.056
9.5	0.061
10.0	0.069
10.5	0.074
10.6	0.075
11.0	0.075
11.5	0.070
12.0	0.063
12.5	0.065
13.0	0.072
13.5	0.086
14.0	0.096
14.5	0.102
15.0	0.106




FIGURE 25-3. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).




FIGURE 26-4. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH DEPENDENCE).

TABLE 25-4. MEASUREMENT INFORMATION ON THE NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE. (Wavelength Dependence)

Cur. Ref. No.	Ref. No.	Author(s)	Year	Wavelength Range, μm	Temperature Range, K	Name and Specimen Designation	Composition (weight percent), Specifications, and Remarks
1 A00001		Grimm, T.C.	1972	2.0-14.7	293		Bare surface specimen; 2.54 cm square; lightly grit-blasted; prepared by the Organic Chemistry Laboratory in the company where the author worked; measurements made with a Dunn Associates ellipsoidal mirror reflectometer; data extracted from a figure; relative reflectance reported; multiplied by 0.95 to convert to absolute values (gold reference mirror used); $\theta = 15^\circ$, $\omega = 27^\circ$.

TABLE 2-5. EXPERIMENTAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; REFLECTANCE, ρ)

λ	ρ	CURVE 1 $T = 295^\circ\text{K}$		CURVE 1 (CONT.)		CURVE 1 (CONT.)	
		λ	ρ	λ	ρ	λ	ρ
2.16	0.064	3.80	0.100	7.97	0.044	8.17	0.052
2.19	0.124	3.93	0.092	8.29	0.045	8.53	0.055
2.25	0.122	3.94	0.098	8.53	0.053	8.72	0.053
2.29	0.115	4.01	0.098	8.72	0.052	8.84	0.052
2.30	0.093	4.11	0.104	8.84	0.052	8.97	0.053
2.33	0.065	4.15	0.106	9.07	0.053	9.11	0.056
2.35	0.065	4.26	0.103	9.16	0.054	9.16	0.054
2.42	0.093	4.38	0.105	9.57	0.054	9.57	0.054
2.43	0.073	4.54	0.108	9.64	0.056	9.64	0.056
2.51	0.096	4.62	0.109	9.71	0.067	9.71	0.067
2.55	0.094	4.72	0.108	10.00	0.069	10.21	0.069
2.56	0.070	4.84	0.104	10.60	0.070	11.64	0.063
2.62	0.074	4.94	0.104	11.04	0.070	11.79	0.059
2.63	0.089	5.00	0.100	11.99	0.069	12.00	0.059
2.70	0.392	5.01	0.104	11.23	0.071	11.44	0.068
2.71	0.102	5.09	0.106	11.44	0.068	11.64	0.063
2.75	0.105	5.17	0.104	11.64	0.066	11.79	0.059
2.76	0.087	5.31	0.104	11.79	0.059	12.00	0.059
2.79	0.087	5.38	0.106	12.00	0.059	12.40	0.063
2.80	0.076	5.49	0.107	12.40	0.063	12.73	0.063
2.81	0.055	5.64	0.103	12.73	0.063	12.99	0.066
2.89	0.053	5.69	0.103	12.99	0.066	13.34	0.079
2.96	0.164	5.84	0.082	13.34	0.083	13.42	0.083
2.97	0.059	5.93	0.084	13.42	0.083	13.84	0.091
3.01	0.059	6.02	0.091	13.84	0.091	14.16	0.091
3.02	0.067	6.06	0.089	14.16	0.091	14.44	0.095
3.05	0.072	6.23	0.051	14.44	0.095	14.69	0.100
3.10	0.079	6.27	0.056	14.69	0.100	14.86	0.100
3.13	0.084	6.32	0.050	14.86	0.100	15.03	0.100
3.16	0.082	6.40	0.079	15.03	0.100	15.20	0.100
3.23	0.104	6.48	0.071	15.20	0.100	15.37	0.100
3.33	0.066	6.63	0.049	15.37	0.100	15.54	0.100
3.44	0.048	6.70	0.047	15.54	0.100	15.71	0.100
3.49	0.053	6.78	0.049	15.71	0.100	15.88	0.100
3.55	0.073	6.93	0.049	15.88	0.100	16.05	0.100
3.56	0.083	7.20	0.056	16.05	0.100	16.22	0.100
3.65	0.086	7.51	0.047	16.22	0.100	16.39	0.100
3.69	0.697	7.76	0.047	16.39	0.100	16.56	0.100
3.76	0.095	7.88	0.044	16.56	0.100	16.73	0.100

d. Normal Spectral Reflectance (Temperature Dependence)

In Table 25-6, the provisional values of the normal spectral reflectance are given with an estimated uncertainty of $\pm 25\%$. The variation of the property as a function of temperature is demonstrated in Figure 25-5. For a given wavelength, the normal spectral reflectance remains as a constant from room temperature up to the char region of epoxy. The independency of the reflectance of epoxy composite with temperature has been observed experimentally [A00002]. The reported provisional values are believed to be reasonable in most of the real situation.

TABLE 25-6. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF 1/2-1/4 INCH FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm : TEMPERATURE, T , K : REFLECTANCE, ρ)

LIGHTLY GRIT-BLASTED $\lambda = 2.8$	LIGHTLY GRIT-BLASTED $\lambda = 3.6$	LIGHTLY GRIT-BLASTED $\lambda = 5.0$	LIGHTLY GRIT-BLASTED $\lambda = 10.6$
250.0	0.079	250.0	0.112
300.0	0.079	300.0	0.112
350.0	0.079	350.0	0.112
400.0	0.079	400.0	0.112
450.0	0.079	450.0	0.112
500.0	0.079	500.0	0.112




FIGURE 25-5. PROVISIONAL NORMAL SPECTRAL REFLECTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

e. Normal Spectral Absorptance (Wavelength Dependence)

The normal spectral absorptance is obtained according to the Kirchhoff's law, i.e., numerically the absorptance is equal to the emittance. As a result, Table 25-7 and Figure 25-6 appear the same as Table 25-1 and Figure 25-1, as well as the estimated uncertainties ($\pm 20\%$).

TABLE 2F-7. PROVISIONAL NORMAL SPHERICAL ABSORPTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (WAVELLENGTH DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K ; ABSORPTANCE, α)

λ	α
LIGHTLY GRIT-BLASTED	
2.5	0.303
2.8	0.921
3.0	0.927
3.5	0.926
3.8	0.900
4.0	0.994
4.5	0.989
5.0	0.886
5.5	0.993
6.0	0.914
6.5	0.938
7.0	0.945
7.5	0.947
8.0	0.947
8.5	0.946
9.0	0.944
9.5	0.939
10.0	0.931
10.5	0.926
10.6	0.925
11.0	0.925
11.5	0.930
12.0	0.937
12.5	0.935
13.0	0.929
13.5	0.914
14.0	0.904
14.5	0.895
15.0	0.894




FIGURE 25-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER EPOXY
COMPOSITE (WAVELENGTH DEPENDENCE).

f. Normal Spectral Absorptance (Temperature Dependence)

The normal spectral absorptance as a function of temperature is given in Table 25-8 and plotted in Figure 25-7. The generated values are considered as provisional with 20% uncertainty. Here, we present the property values as constant for a given wavelength because it has been observed in epoxy composites that the radiative properties do not change appreciably with temperature [A00002]. With 20% uncertainty, the provisional values can be safely used for most of the true surfaces.

TABLE 25-6. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE)
 (WAVELENGTH, λ , μm ; TEMPERATURE, T , K; ABSORPTANCE, α)

LIGHTLY GRIT-BLASTED $\lambda = 2.8$		LIGHTLY GRIT-BLASTED $\lambda = 3.6$		LIGHTLY GRIT-BLASTED $\lambda = 5.0$		LIGHTLY GRIT-BLASTED $\lambda = 10.6$	
T	α	T	α	T	α	T	α
250.0	0.921	250.0	0.900	250.0	0.888	250.0	0.925
300.0	0.921	300.0	0.900	300.0	0.888	300.0	0.925
350.0	0.921	350.0	0.900	350.0	0.888	350.0	0.925
400.0	0.921	400.0	0.900	400.0	0.888	400.0	0.925
450.0	0.921	450.0	0.900	450.0	0.888	450.0	0.925
500.0	0.921	500.0	0.900	500.0	0.888	500.0	0.925




FIGURE 25-7. PROVISIONAL NORMAL SPECTRAL ABSORPTANCE OF GRAPHITE FIBER EPOXY COMPOSITE (TEMPERATURE DEPENDENCE).

4.26. Silicon Nitride with Chopped Graphite Fiber

No information on the thermal radiative properties of this composite material was uncovered from the search of literature. Consequently, no tabulation or recommendation of the thermal radiative properties of this material is possible at this time.

However, it is reasonable to assume that this material in its bulk form is opaque; that is, the transmittance is zero.

4.27. Silicon Nitride with Vitreous Silica

No information on the thermal radiative properties of this composite material was uncovered from the search of literature. Consequently, no tabulation or recommendation of the thermal radiative properties of this material is possible at this time.

6. REFERENCES*

- T00758 THE EMISSIVITY OF GLOBAR
SILVERMAN SHIRLEIGH
J OPTICAL SOC AM
39 989 1948 CA 43 946
- T02147 RADIATION MEASUREMENTS ON ELECTRICALLY HEATED
SILICON CARBIDE RODS
BRUGEL W
Z PHYSIK
127 400-6 1950 CA 44 8239
- T06579 DETERMINATION OF EMISSIVITY AND REFLECTIVITY DATA ON
AIRCRAFT STRUCTURAL MATERIALS. PART II. TECHNIQUES
FOR MEASUREMENT OF TOTAL NORMAL EMISSIVITY, NORMAL
SPECTRAL EMISSIVITY, SOLAR ABSORPTIVITY AND
PRESENTATION OF RESULTS.
BETZ HOWARD T OLSON O HARRY SCHURIN BERT D
MORRIS JAMES C ARF WADC
WADC
WADC TR 56-222 PT II AD 202693
1-184 1957
- T07159 THE REFLECTIVITY OF INTERMETALLIC SYSTEMS //AL-SI,
AL-MG, AL-AG//
WULFF J
J OPT SOC AMER
26 223-226 1936 MA 1 487
- T08277 SPECTRAL EMITTANCE OF UNCOATED AND CERAMIC-COATED
INCONEL AND TYPE 321 STAINLESS STEEL.
RICHMOND JOSEPH C STEWART JAMES E NBS
NASA
NASA
NASA MEMO 4-9-59N
1-30 1959
- T08677 EMISSIVITY AT 0.65 MICRON OF SILICON AND GERMANIUM AT
HIGH TEMPERATURES.
ALLEN F G
J APPL PHYS
28 1510-11 1957 CA 52 7867
- T10060 DETERMINATION OF EMISSIVITY AND REFLECTIVITY DATA ON
AIRCRAFT STRUCTURAL MATERIALS. PT. 3 TECHNIQUES
FOR MEASUREMENT
OLSON O HARRY MORRIS JAMES C ARF WADC
ASTIA
WADC TR-56-222 /PT 3/ AD 239302
1-96 1959
- T10461 HIGH TEMPERATURE THERMAL RADIATION PROPERTIES OF
SOLID MATERIALS.
BLAU HENRY H CHAFFEE ELEANOR JASPERSE JOHN R
HARTIN WILLIAM S
ASTIA
AFCPC TN-60-165 AD 236334
1-71 1960
- T10703 SPECIAL REPORT ON DESIGN DATA FOR IR DOME MATERIALS.
KRAUSHAAR ROBERT ACF INDUSTRIES INC AVION DIV
PARAHUS N J USAF
ASTIA
AVION RPT 1070 AD 208306
1-29 1958
- T11690 OPTICAL ABSORPTION OF GERMANIUM AND SILICON BEYOND
THE MAIN ABSORPTION EDGE AT HIGH TEMPERATURES.
//ENGLISH TRANSLATION OF FIZ. TVEROOGO TELA 3 ///
2105-2110, 1961.//
UKHANOV YU I
SOVIET PHYS-SOLID STATE
3 7 1529-32 1962
- T11723 SPECTRAL EMISSIVITY OF 99.7 PERCENT ALUMINUM
BETWEEN 200 AND 540 C.
REYNOLDS P M
BRIT J APPL PHYS
12 111-6 1961
- T14404 EMISSION COEFFICIENTS OF SOME POWDERED HIGH-MELTING
COMPOUNDS.
SEREBRYAKOVA T I PADERNO YU B SAMSONOV G V
OPTICS AND SPECTROSCOPY /USSR/ ENGLISH TRANSLATION/
8 3 212-3 1960 JA 46 74
- T15906 ALCOA ALUMINUM HANDBOOK.
ALUMINUM COMPANY OF AMERICA PITTSBURGH
ALCOA
1-222 1959
- T16606 INFRARED SPECTRAL EMITTANCE PROPERTIES OF SOLID
MATERIALS.
BLAU HENRY H JR MARCH JOHN B MARTIN WILLIAM S
JASPERSE JOHN R CHAFFEE ELEANOR ARTHUR O LITTLE
INC CAMBRIDGE MASS USAF
ASTIA
AFCRL-TR-60-616
AD 248276 1-70 1960
- T16961 INFRARED SPECTRAL EMISSIVITY OF OPTICAL MATERIALS.
STIERWALT DONALD L NAVAL ORDNANCE LAB CORONA
CALIF NAVWEPS AND NOLC
ASTIA
NAVWEPS REPT 7168 NOLC RPT 537
AD 250530 1-34 1961
- T17017 OPTICAL MATERIALS FOR INFRARED INSTRUMENTATION.
SUPPLEMENT.
MICHIGAN UNIV ANN ARBOR INST OF SCIENCE AND
TECHNOLOGY UNIV MICHIGAN ONR
ASTIA
IRIA 2389-11-SSUB1
1-21 1961
- T18630 DETERMINATION OF SPECTRAL EMISSIVITY OF CERAMIC
BODIES AT Elevated TEMPERATURES.
BLAIR G RICHARD J AM CERAM SOC
43 197-203 1960 CA 54 12529
- T19294 THERMAL RADIATION PROPERTIES OF MATERIALS.
SEBAN R A ROLLING R E CALIFORNIA UNIV INST OF
ENG RESEARCH BERKELEY USAF
ASTIA
WADC TR-60-37C
1-110 1960
- T19814 EVALUATION OF THE MECHANISMS WHICH AFFECT THE
PERFORMANCE OF THERMAL RADIATION RESISTANT COATINGS.
MORE LOUISE E PRASTEIN MATTHEW
TOMPKINS EDWIN H VAN OSTENBURG DONALD O ARF
USAF
ASTIA
WADC TR 57-334 AD 151163
1-161 1958
- T19818 COATINGS FOR SOLAR CELLS. FINAL REPORT.
WITUCKI ROBERT M LEWIS ARTHUR E HOFFMAN
ELECTRONICS CORP SANTA BARBARA CALIF USAF
ASTIA
AD 258660 1-86 1961
- T19919 OPTICAL ABSORPTION OF GERMANIUM AND SILICON BEYOND
THE MAIN ABSORPTION EDGE AT HIGH TEMPERATURES.
UKHANOV YU I
FIZ TVEROOGO TELA
3 7 2125-10 1961
FOR ENGLISH TRANSLATION SEE TPRC NO. 11690
- T20117 DETERMINATION OF THE OPTICAL CONSTANTS OF METALS.
/ENGLISH TRANSLATION OF ANN. PHYSIK 33, #1-554,
1890./
DRUDE P
DOC
E-T-G-63-1 AD 430983
1-96 1963 TA U64-3 367
- T23468 THERMAL RADIATION FROM PARTIALLY TRANSPARENT
REFLECTING BODIES.
MC MAHON H O
J OPT SOC AMER
40 6 376-80 1950 AM 4 1354
- T20470 SPECTRAL EMISSIVITY OF SOLIDS IN THE INFRARED AT LOW
TEMPERATURES.
HEMER DWIGHT
J OPT SOC AMER
49 8 81E-20 1959 MA 2/ 428
- T20771 STUDY OF INFRARED SOURCES. INTERIM DEVELOPMENT
REPORT NO. 3. JUNE 20, 1959 TO SEPT. 20, 1960.
FINKELSTEIN I S SERVO CORP OF AMERICA NEW
HYDE PARK N Y USAF
ASTIA
RADCO-TN-78-32E AD 259433
1-25 1958
- T20810 TRANSMITTANCE OF OPTICAL MATERIALS AT HIGH
TEMPERATURES IN THE 1- TO 12-MICRON RANGE.
GILLESPIE D T OLSEN A L NICHOLS L M
U S NAVAL ORDNANCE TEST STATION CHINA LAKE CALIF
DOC AND CFSTI
NAVWEPS REPT 4554 NOTS-TP-3546
AD 669016 1-20 1964 PA H65-1 1332

* Reference numbers used refer to CINDAS accession numbers in the various Bibliographic Banks (T = TPRC, E = EPIC, and A = Arbitrary - not part of CINDAS coverage).

- T20946 COMMENTS ON THE MEASUREMENT OF EMITTANCE OF THE GLOBAR RADIATION SOURCE.
MORFIS J C
J OPT SOC AMER
51 7 798-9 1961 SA 64 11851 T25673 EMISSIVITY OF GLOBAR.
MITCHELL C A
J OPT SOC AM
52 3 361-2 1962 JA 65 193
- T21553 SPECTRAL AND TOTAL EMISSIVITY APPARATUS AND MEASUREMENTS OF OPAQUE SOLIDS.
SHAW C BERRY J LEE T LOCKHEED AIRCRAFT CORP MISSILES AND SPACE DIV SUNNYVALE CALIF USAF DDC
LMSD-68488 AD 202680 1-35 1959 T25806 THE EFFECT OF ALUMINUM PURITY ON THE REFLECTIVITY OF EVAPORATED FRONT SURFACE MIRRORS.
HOLLAND L WILLIAMS B J
J SCI INSTR
32 287 1955
- T21923 A METHOD FOR MEASURING THE SPECTRAL NORMAL EMITTANCE IN AIR OF A VARIETY OF MATERIALS HAVING STABLE EMITTANCE CHARACTERISTICS.
SELEMP WAYNE S WADE WILLIAM R LANGLEY RESEARCH CENTER LANGLEY STATION HAMPTON VA NASA N62-12956 1-17 1962 RR 37 33 T26088 MEASUREMENT OF TOTAL NORMAL EMITTANCE OF BORON NITRIDE FROM 1,230 TO 1,930 F WITH NORMAL SPECTRAL EMITTANCE DATA AT 1,400 F.
WALKER GILBERT H CASEY FRANCIS W JR LANGLEY RESEARCH CENTER LANGLEY STATION HAMPTON VA NASA NASA TN D-1268 1-21 1962 PA N62-2 576
- T22272 HIGH TEMPERATURE, HIGH EMITTANCE INTERMETALLIC COATINGS. PART I. EMITTANCE AND REFLECTANCE OF INTERMETALLIC COMPOUNDS.
SCHATZ ELIZU A GOLDBERG DAVID M PEARSON ERVIN G BURKS TEHAN L AERONAUTICAL SYSTEMS DIV AF MATERIALS LAB NONMETALLIC MATERIALS DIV WRIGHT-PATTERSON AFB OHIO USAF DDC ASD-TDR-63-657/PT 1/ 1-181 1963 T26638 TRANSPORT PROCESSES IN FUSED SALTS, PART I.
SUNDHEIM BENSON R NEW YORK UNIV N Y ORNL AND AEC DDC AND OTS AD 296566 1-82 + TABLES, REFS. 1962 TA U63-2 9
- T22517 RADIOMETRIC INVESTIGATIONS OF INFRA-RED ASSORPTION AND REFLECTION SPECTRA.
COBLENTZ W M NATL BUR STANDARDS BULL 2 457-70 1966 T27141 MEASUREMENT OF RADIATIVE HEAT TRANSFER WITH THIN-FILM RESISTANCE THERMOMETERS.
BOGDAN LEONARD CORNELL AERONAUTICAL LAB INC BUFFALO N Y NASA NASA AND OTS NASA-CR-27 1-39 1964
- T22613 INVESTIGATION OF HIGH EMITTANCE COATINGS TO EXTEND THE MACH NUMBER RANGE OF APPLICATION OF STRUCTURAL MATERIALS.
GRAVINA ANTHONY KATZ MILTON REPUBLIC AVIATION CORP FARMINGDALE N Y USAF ASTIA WADD TR-60-102 AD 262083 1-143 1961 T27253 STUDY OF THERMAL INSULATING MATERIALS. VOLUME I. MATERIALS RESEARCH, FINAL ENGINEERING REPT.
MALIN D R GENERAL DYNAMICS/CONVAIR SAN DIEGO CALIF NAVY BUREAU OF AERONAUTICS DDC AND OTS TG-208 AD 606107 1-203 1960 ER 39 100
- T23145 EMITTANCE STUDIES OF VARIOUS HIGH TEMPERATURE MATERIALS AND COATINGS.
SKLAREW SAMUEL RABENSTEINE A S MARQUARDT CORP VAN NUYS CALIF USAF ASTIA AND OTS PR 201-3Q-1 AD 299417 1-37 1963 TA U63-3 44 T27345 TRANSMITTANCE MEASUREMENTS OF OPTICAL MATERIALS AS Affected BY WEDGE ANGLE AND REFRACTIVE INDEX IN THE 2- TO 15-MICRON RANGE.
LABAW K B OLSEN A L NICHOLS L W NAVAL ORDNANCE TEST STATION CHINA LAKE CALIF NAVWEPS DDC AND OTS NAVWEPS 6086 NOTS TP 3116 AD 403988 1-32 1963 TA U63-3 81
- T23741 THE REFLECTING POWER OF VARIOUS METALS.
COBLENTZ W M BULL NATL BUR STANDARDS 7 2 197-225 1911 T27424 INFRARED REFLECTANCE OF EVAPORATED ALUMINUM FILMS.
BENNETT H E BENNETT JEAN M ASHLEY E J OTS NAVWEPS 6105 NOTS TP 3169 AD 404995 1-6 1963 TA U63-3 216 J OPT SOC AM 52 1245-50 1962 CA 59 6342
- T23974 SPECIAL TYPE OF DOUBLE-LAYER ANTIREFLECTION COATING FOR INFRARED OPTICAL MATERIALS WITH HIGH REFRACTIVE INDICES.
COX J T OPTICAL SOCIETY OF AMERICA JOURNAL 51 1406-8 1961 BR 11 1975 T27686 INFRARED COATING STUDIES. FINAL REPT., 15 NOV 62-- 15 FEB 63.
MARTIN T P HASSO J O TURNER A F BAUSCH AND LOMB INC ROCHESTER N Y U S ARMY DDC AND OTS AD 400346 1-9 1963 TA U63-3 61
- T24008 THE DESIGN OF ORGANIC COATINGS FOR USE IN THE SPACE ENVIRONMENT. FROM COATINGS FOR THE AEROSPACE ENVIRONMENT.
COWLING J E ALEXANDER A L NOONAN F M U S NAVAL RESEARCH LAB WASHINGTON D C USAF DDC AND OTS WADD TR 60-773 AD 267310 17-37 1961 T28664 CONCERNING THE SYSTEM CHALK-ALUMINA-SILICA.
BERL E LOBLEIN FR ARCH WARMEWIRTSCH 10 339-42 1979
- T24833 THE EFFECTS OF ULTRAVIOLET RADIATION ON ORGANIC FILMFORMING POLYMERS. FROM FIRST SYMPOSIUM ON SURFACE EFFECTS ON SPACECRAFT MATERIALS, PALO ALTO, CALIF., MAY 12-13, 1959.
COWLING J E ALEXANDER A L NOONAN F KAGARISE R STOKES S NRL USAF AND LMSD JOHN WILEY AND SONS INC 364-77 1960 T28755 STABLE WHITE COATINGS. SUMMARY REPORT, SEPT. 21, 1961-JULY 15, 1963.
ZERLAUT G A HAFADA Y IIT RESEARCH INC CHICAGO ILL NASA AND OTS IITRI-C27-25 NASA CR-52136 N63-23501 1-194 1963 PA N63-1 2062
- T24947 INFRARED FIBER OPTICS. FINAL REPORT.
ILLINOIS INST OF TECH CHICAGO ARMOUP RESEARCH FOUNDATION USAF ASTIA AND OTS ARF 1133-11 AD 209504 1-36 1961 T28823 SEMICONDUCTOR PHYSICS. FROM NAVAL ORDNANCE LABORATORY QUARTERLY REPORT, FOUNDATIONAL RESEARCH PROJECTS, OCTOBER-DECEMBER 1959.
STEHWALT O L NAVAL ORDNANCE LAB CORONA CALIF NAVOFO DDC NOLO REPT 487 NAVWEPS REPT 5981 AD 297612 1-9 1960
- T28943 PROGRESS REPORT FOR THE YEAR ENDING JUN 21, 1952.
DUNKLE R V GIER J T CALIF UNIV INST OF ENG RESEARCH BERKELEY SIPRE ASTIA AND OTS AD 16613 PI 14-463 1-73 1953 FR 33 253

- T28949 RESEARCH IN PURIFICATION OF CADMIUM SULFITE CRYSTALS AND OTHER II-IV COMPOUNDS. FINAL TECHNICAL REPORT 15 JAN 61-15 JAN 62, ON SOLAR AND NEW ENERGY CONVERSION TECHNIQUE.
BEAN K E FAHRIG R H MEDCALF W E POWDERLY J E RODERIQUE J S EAGLE-PICHER RESEARCH LABS MIAMI OKLA USAF ASTIA AND OTS ARL 62-319 AD 276616 1-86 1962
- T2902 OPTICAL PROPERTIES OF SATELLITE MATERIALS--THE THEORY OF OPTICAL AND INFRARED PROPERTIES OF METALS. RESEARCH PROJECTS DIV GEORGE C MARSHALL SPACE FLIGHT CENTER HUNTSVILLE ALABAMA NASA NASA AND OTS NASA TM 0-1523 N63-14272 1-253 1963 RR 38 32
- T29424 AN ENGINEERING HANDBOOK ON HERLON POLYCARBONATE. MOBAY CHEMICAL COMPANY PITTSBURGH PA MOBAY CHEMICAL COMPANY PITTSBURGH PA 1-32 1962
- T29563 ANGULAR DEPENDENCE OF SPECTRAL REFLECTANCE IN THE INFRARED. /M.S. THESIS/ EBERHART R C CALIFORNIA UNIV BERKELEY CALIFORNIA UNIV 1-44 1960
- T29570 THERMAL RADIATION CHARACTERISTICS OF TRANSPARENT SEMI-TRANSPARENT AND TRANSLUCENT MATERIALS UNDER NON-ISOTHERMAL CONDITIONS. FOLWEILER ROBERT C LEXINGTON LABS INC CAMBRIDGE MASS USAF ASTIA AND OTS ASO-TDR-62-719 AD 600370 1-115 1966 TA U54-14 80
- T29594 SPECTRAL AND DIRECTIONAL THERMAL RADIATION CHARACTERISTICS OF SELECTIVE SURFACES FOR SOLAR COLLECTORS. EDWARDS D K GIER J T NELSON K E RODOICK R D SOLAR ENERGY 6 1 1-8 1962
- T29599 DEVELOPMENT OF STABLE TEMPERATURE CONTROL SURFACES FOR SPACECRAFT PROGRESS REPRT NO. 1. CARROLL W F JET PROPULSION LAB CALIF INST OF TECH PASADENA NASA NASA AND OTS JPL-TR 32-340 1-17 1962
- T29605 DETERMINATION OF FREE ELECTRON EFFECTIVE MASS OF N-TYPE SILICON. HOWARTH L E GILBERT J F J APPL PHYS 36 236-7 1963 CA 33 6235
- T29648 THE ABSOLUTE SPECTRAL REFLECTIVITY OF CERTAIN PIGMENTS AND METALS IN THE WAVELENGTH RANGE BETWEEN 2 AND 16 MICRONS. GIER J T POSSNER L TEST A J DUNKLE R V BEVANS J T CALIFORNIA UNIV BERKELEY DEPT OF ENGINEERING USH DDC AND CFSTI NR-015-202 ATI-53635 1-4 1969
- T29708 THE SPECIFIC HEAT OF DYSPROSIMUM METAL BETWEEN 0.4 AND 4 K. FROM PROCEEDINGS OF THE 2ND CONFERENCE ON RARE EARTH RESEARCH, GLENWOOD SPRINGS, COLORADO SEPT. 24-7, 1961. LOUHASMAA O V GUENTHER R A GORDON AND BREACH SCIENCE PUBLISHERS NY 197-202 1962
- T30100 THE REFLECTION AND TRANSMISSION OF INFRARED MATERIALS. I. SPECTRA FROM 2 TO 50 MU. II. BIBLIOGRAPHY. MCCARTHY DONALD E APPLIED OPT 2 6 591-603 1963 CA 59 8268
- T30490 INFRARED PROPERTIES OF SILICON MONOX AND EVAPORATED SiO FILMS. HOWARTH L E SPITZER W G J AM CERAM SOC 44 1 26-8 1961
- T31344 REPORT ON THE BEHAVIOR OF CERAMIC MATERIALS IN THE NEAR INFRARED REGION AT HIGH TEMPERATURES. //ENGLISH TRANSLATION OF BER. DEUT. KERAM. FESSEL. 41, 7// 398-404 /1964// KROCKEL O OFFICE OF NAVAL INTELLIGENCE WASHINGTON D C DOC ONI-1092 AD 476706 1-19 1964 TA 63-5 A-29
- T31731 REFLECTING-POWER MEASUREMENTS IN THE SPECTRAL REGION 2000 A. TO 1300 A. JOHNSON B K PROC PHYS SOC /LONDON/ 53 258-64 1961
- T32045 SPECTRAL EMITTANCE OF REFRACTORY MATERIALS. BLAU HENRY H JR JASPERSE JOHN R APPL OPT 3 2 281-6 1964 CA 60 14022
- T32121 IMPURITY ABSORPTION IN SILICON CARBIDE CRYSTALS DOPED WITH BORON DURING CRYSTAL GROWTH. //ENGLISH TRANSLATION OF FIZ. TVERODO TELA 8 /2/ 30-7, 1966// PICHUGIN I G PIKHTIN A N SOVIET PHYSICS-SOLID STATE 8 2 465-6 1966
- T32226 RADIATION COEFFICIENTS OF HIGH MELTING COMPOUNDS. //ENGLISH TRANSLATION OF OGNEVUDRY /USSR/ 27, 1// 40-2, 1962// SAMSONOV G V FOMENKO V S PADERNO YU B SLA TT-65-13364 1-5 1965 TT 14-10 57
- T32363 REFLECTING COATINGS FOR THE EXTREME ULTRAVIOLET. HASS GEORG TOUSEY RICHARD J OPT SOC AM 49 6 593-602 1959 CA 60 6596
- T32388 REPORT OF INVESTIGATION OF OPTICAL TRANSMITTANCE, REFLECTANCE, AND ABSORPTANCE OF MATERIALS. FINAL REPORT. BYRNE R F MANCINELLI L N MATERIAL LAB NEW YORK NAVAL SHIPYARD BROOKLYN OTS PB 159155 1-39 1954
- T32537 INFRARED SPECTRAL EMITTANCE OF Si, Ge, AND CdS. STIERWALT D L POTTER R F PROC INTERN CONF PHYS SEMICOND EXETER INGL 513-26 1962 CA 60 3615
- T32821 INFRARED PROPERTIES OF HEXAGONAL SILICON CARBIDE. SPITZER W G KLEINMAN D WALSH D PHYS REV 113 1 127-32 1959 JA 47 142
- T32822 INFRARED PROPERTIES OF CUBIC SILICON CARBIDE FILMS. SPITZER W G KLEINMAN D A FROSCH C J PHYS REV 113 1 133-6 1959 JA 47 142
- T33043 FAR-INFRARED REFLECTANCE AND TRANSMITTANCE OF POTASSIUM MAGNESIUM FLUORIDE AND MAGNESIUM FLUORIDE. HUNT G R PEPRY C H FERGUSON J PHYS REV 134 3A 68E-91 1964 CA 60 14015
- T33154 FAR INFRARED TRANSMISSION OF SILICON AND GERMANIUM. LORO K C PHYS REV 85 140-1 1952
- T33156 INFRARED LATTICE ABSORPTION IN IONIC AND HOMOPOLAR CRYSTALS. LAX HELVIN OURSTEIN ELIAS PHYS REV 97 1 39-52 1955
- T33158 INFRARED LATTICE ABSORPTION BANDS IN GERMANIUM, SILICON, AND DIAMOND. COLLINS R J FAN H Y PHYS REV 93 4 674-18 1954
- T33388 REFLECTIVE COATINGS ON POLYMERIC SUBSTRATES. BELSER RICHARD B GAFITHERS HERCER D GEORGIA INST OF TECH ATLANTA USAF DOC AND OTS ASO-TDR-61-1 1/Pt 2/ AD 276486 1-121 1962

- T33450 SPECTRAL EMITTANCE OF SOLIDS. SPECTRAL EMITTANCE MEASUREMENTS ON SOME COMMERCIAL OPAQUE AND TRANSPARENT SOLIDS.
STIERMALT D L . KIRK D D DEPHSTEIN J B
NAVAL ORDNANCE LAB CORONA CALIF NORD
DDC
NOLO-TH-43-14 AD 462866 N64-32373
1-6 1965 PA N64-2 3439
- T33512 SPECTRAL EMISSIVITY OF METALS AFTER DAMAGE BY PARTICLE IMPACT. FINAL REPORT.
LEIGH CHARLES H AVCO CORP WILMINGTON MASS
NASA
NASA AND OTS
RAD-TR-62-33 NASA-CR-53235 N64-17590
1-68 1962 CA 61 15536
- T33896 OFF-SPECULAR PEAKS IN THE DIRECTIONAL DISTRIBUTION OF REFLECTED THERMAL RADIATION.
TORRANCE K E SPARROW E M
TRANS ASME J HEAT TRANSFER
88 C 2 223-30 1966
- T33965 D-XYLOSE. AN ULTRAVIOLET-TRANSMITTING CEMENT.
LAULAINEN H S MC DERMOTT M N
J OPT SOC AM
56 4 520 1966
- T33974 HIGH TEMPERATURE, HIGH EMITTANCE INTERMETALLIC COATINGS. PART II EMITTANCE AND REFLECTANCE OF INTERMETALLIC COATINGS.
SCHATZ E A ALVAREZ G H BURKS T L
COUNTS C R III DUUNDERLEY F J AMERICAN MACHINE AND FOUNDRY CO ALEXANDRIA VA USAF
DDC
ML-TDR-64-179
AD-472639 1-8 1964
- T34045 INSTRUMENTATION FOR MEASURING THERMAL CHARACTERISTICS OF SURFACES. PART 2. AN INTEGRATING SPHERE TO MEASURE THE VARIATION OF REFLECTANCE WITH ANGLE OF INCIDENCE.
PORTER J BUTLER E A M ROYAL AIRCRAFT ESTABLISHMENT FARNBOROUGH ENGLAND
DDC
RAE-TR-65155 AD 470387
1-23 1965 TA 65-21 A-139
- T34168 THE TRANSMISSION AND REFLECTION OF QUARTZ AND GERMANIUM OXIDE IN THE INFRARED.
ENGELSRATH A UNIV MICROFILMS PUBL
65-6394 1-98 1965 CA 63 15734
- T34454 HIGH-PRECISION METHOD FOR MEASURING THE ABSORPTANCE OF EVAPORATED METALS.
GRANDENBERG W H CLAUSEN O W MC KEOWN O
J OPT SOC AM
56 1 83-6 1966 CA 64 5937
- T34724 INFRARED SIGNATURE CHARACTERISTICS.
DURAND J L HOUSTON C K DIRECTORATE OF ARMAMENT DEVELOPMENT RESEARCH AND TECHNOLOGY DIVISION AIR FORCE SYSTEM COMMAND EGLIN AIR FORCE BASE FLORIDA
THE MARTIN COMPANY DIV OF MARTIN-MARIETTA CORP ORLANDO FLORIDA USAF
ATL-TR-66-8 OR-6320 302
1-174 1966
- T34753 SURVEY OF THERMAL PROPERTIES OF SELECTED MATERIALS. HERTZ J KNOWLES D GENERAL DYNAMICS/CONVAIR SAN DIEGO CALIF GENERAL DYNAMICS/CONVAIR ZZL-65-308 AR-504-1-553
N63-31775 1-172 1965 CA 67 15485
- T34814 OPTICAL REFLECTORS FOR USE IN INTERNAL SAMPLE AQUEOUS CHERENKOV COUNTERS.
STRINDEHAG O Y REV SCI INSTR
37 3 34-4-9 1966
- T34840 CONTRIBUTION TO THE INFRARED SPECTROSCOPIC STUDY OF THE ADDITION POLYMER FOLYVINYLPIRROLIDONE-POLYACRYLIC ACID.
BOYLA-KAMENOKI F COMPT RENO
263 C 6 278-81 1966
- T34908 EFFECT OF PRESSURE ON THE REFLECTANCE OF COMPACTED POWDERS.
SCHATZ E A J OPT SOC AM
56 3 359-36 1966 CA 61 12050
- T34913 EFFECT OF IONIZING RADIATION ON RUBY.
FORESTIERI A F GRIES M H LEWIS RESEARCH CENTER CLEVELAND OHIO NASA
NASA AND CFSTI
NASA-TN-D-3379
1-9 1966
- T35036 BLACKBODY REFERENCE FOR TEMPERATURES ABOVE 1200 K. STUDY FOR DESIGN EQUIPMENTS.
GRENIS A F MATKOVICH M J U S ARMY MATERIALS RESEARCH AGENCY WATERTOWN MASS CFSTI AND DDC
AMRA-TR-65-02 N65-29022 N66-34560
AD 614639 1-18 1965 TA 65-12 132
- T35117 SHEET INFRARED TRANSMISSION POLARIZERS.
HASSE M O MARA M APPL OPT
4 8 1027-31 1965
- T35131 TEMPERATURE COEFFICIENT OF THE ENERGY GAP OF BETA-SILICON CARBIDE.
DALVEN R J PHYS CHEM SOLIDS
26 2 439-41 1969
- T35223 RELATIVE PHOTOELECTRIC YIELD AND TRANSMITTANCE OF AL FILMS.
CAIRNS R B SAMSON J A R
J OPT SOC AM
57 3 433-4 1967
- T35546 UTILIZATION OF PIGMENTED COATINGS FOR THE CONTROL OF EQUILIBRIUM SKIN TEMPERATURES OF SPACE VEHICLES.
ZERLAUT GENE A ARMY MISSILE COMMAND REDSTONE ARSENAL ALA
DDC
ABMA-MISC-32 AD 463738
1-46 1960 TA 65-13 A-269
- T35800 MODULATION OF THE REFLECTIVITY OF SEMICONDUCTORS.
BIRNBBAUM M AEROSPACE CORP LOS ANGELES CALIF USAF
DDC
SSD-TDR-253 TDR-469-9230-02-1
AD-455909 1-7 1964 TA 65-6 A-235
- T35840 HIGH TEMPERATURE, HIGH EMITTANCE INTERMETALLIC COATINGS.
SCHATZ E A ALVAREZ G H COUNTS C R III HOPPKIE M A AMERICAN MACHINE AND FOUNDRY CO ALEXANDRIA VA USAF
DDC
AFML-TR-65-217 /PT III/
AD-468059 1-100 1965 TA 65-18 A-113
- T35848 INFRARED TRANSMITTANCE OF OPTICAL MATERIALS AT LOW TEMPERATURES. TECHNICAL PUBLICATION.
LINSTEADT G F NAVAL ORDNANCE TEST STATION CHINA LAKE CALIF
DDC AND CFSTI
NOTS-TP-38-9 NAVHEPS-3767 N65-36158
AD-618741 1-17 1965 PA N65-3-24 4197
- T35902 INFRARED RADIATION OF SOLIDS. REFRACTORY MATERIALS.
GRENIS A F LEVITT A P AM CERAM SOC BULL
64 11 901-3 1965
- T35934 SPECTRAL MEASUREMENT OF SOLAR ABSORPTANCE.
FAUGERE J F NASA
CNES-NT-2 N65-28516
1-20 1965 PA N65-3 3329
- T36117 EMITTANCE AND REFLECTANCE OF INTERMETALLIC COMPOUNDS. PROGRESS REPT. NO. 2, 15 SEP - 15 DEC 1962.
SCHATZ E A AMERICAN MACHINE AND FOUNDRY CO ALEXANDRIA VA USAF
DDC
AMF-PR-2 1-26 1962
- T36227 MODULATION OF THE REFLECTIVITY OF SEMICONDUCTORS.
BIRNBBAUM M J APPL PHYS
36 2 657-8 1965 CA 62 391:
- T36314 CARRIER DENSITY IN A SEMICONDUCTOR ILLUMINATED WITH A LASER. //ENGLISH TRANSLATION OF FIZ. TVUOOGO FELA 3, 854-5, 1967.//
ILINOV L N VAVILOV V S GALKIN G N SOVIET PHYSICS-SOLID STATE
9 3 663-9 1967

- T36320 AN INTEGRATING SPHERE SYSTEM FOR MEASURING AVERAGE REFLECTANCE AND TRANSMITTANCE.
DAVIES J M ZAGIEBOLO W
APPL OPT
4 2 167-76 1965 CA 62 14060
- T36324 THE REFLECTION AND TRANSMISSION OF INFRARED MATERIALS. III. SPECTRA FROM 2 TO 50 MICRONS.
MC CARTHY D E
APPL OPT
4 3 317-20 1965 CA 62 14052
- T36346 TRANSMITTANCE OF THIN METALLIC FILMS IN THE VACUUM-UNTRAVIOLET REGION BELOW 1000 ANGSTROMS.
RUSTGI OM P
J OPT SOC AM
55 6 630-4 1965 CA 62 15507
- T36371 MINIATURE OPTICALLY IMMERSED THERMISTOR BOLOMETER ARRAYS.
DE WAARD R WEINER S
APPL OPT
6 8 1327-31 1967
- T36486 FAR-INFRARED SPECTRA OF SOLIDS. FROM SYMP. ON THERMAL RADIATION OF SOLIDS, SAN FRANCISCO, CALIF., MARCH 4, 5, 6, 1964.
ARONSON J R MC LINDEN H G ARTHUR D LITTLE INC
CAMBRIDGE MASS USAF NBS NASA
NASA AND GFSTI
NASA-SP-55 HL-TDR-64-159 N65-26858
AD 629930 29-38 1965
- T36500 EFFECT OF SURFACE TEXTURE ON DIFFUSE SPECTRAL REFLECTANCE. A. DIFFUSE SPECTRAL REFLECTANCE OF METAL SURFACES. FROM SYMP. ON THERMAL RADIATION OF SOLIDS, SAN FRANCISCO, CALIF., MARCH 4, 5, 6, 1964.
KEEGAN M J SCHLETER J C WEINER V R
NATIONAL BUREAU OF STANDARDS WASHINGTON D C USAF
NBS NASA
NASA AND GFSTI
NASA-SP-55 HL-TDR-64-159 N65-26872
AD 629930 165-9 1965
- T36646 TRANSMITTANCE OF IRTRAN-1, MAGNESIUM FLUORIDE AND IRRADIATED MAGNESIUM FLUORIDE.
OLSEN A L HILLS M E MC BRIDE M R
OPT SOC AM
53 8 1003-5 1963
40 7 2053-4 1964
J CHEM PHYS
A3-515380 NAVWEPS 8716
1-6 1965 TA 65 13
- T36689 A METHOD FOR MEASURING POLARIZATION IN THE VACUUM ULTRAVIOLET.
RABINOVITCH K CANFIELD L R MADDEN R P
APPL OPT
4 8 1005-10 1965 CA 63 6486
- T37021 LASER-INDUCED INFRARED ABSORPTION IN SILICON.
GAUSTR W B BUSHNELL J C
J APPL PHYS
41 9 3950-3 1970
- T37398 IMPROVED RADIATOR COATINGS. PART I. REPT. FOR 1 APR 63-1 APR 64.
SCHATZ E A COUNTS C R III BURKS T L
AMERICAN MACHINE AND FOUNDRY CO ALEXANDRIA VA
USAF
DOC
HL-TDR-64-146
AD-442236 1-82 1964
- T37478 ACTIVITY REPORT OF HIGH TEMPERATURE COATING AND MATERIAL PROGRAMS AT AFM. FROM SUMMARY OF THE SEVENTH REFRACTORY COMPOSITES WORKING GROUP MEETING, VOLUME 2.
BROWNING M E AMERICAN MACHINE AND FOUNDRY CO
ALEXANDRIA VA USAF
DOC
RTO-TDR-63-4131/VOL II/ NEL-27020
AD-601265 401-30 1963
- T37991 DIFFUSION OF CADMIUM IN SODIUM CHLORIDE.
IKEADA T
J PHYS SOC JAPAN
13 6 650-63 1964 SA 67 20491
- T38121 INFRARED TRANSMITTANCE OF OPTICAL MATERIALS AT LOW TEMPERATURES.
LINSTEAD G U S NAVAL ORDNANCE TEST STA
APPL OPT
3 12 1453-6 1964 CA 63 1363
- T38391 RADIATION CHARACTERISTICS OF POUSH AND OXIDIZED METALS. FROM ADVANCES IN THERMOGRAPHICAL PROPERTIES AT EXTREME TEMPERATURES AND PRESSURES.
EDWARDS D K CATTON I
3RD ASME SYMP ON THERMOGRAPHICAL PROPERTIES PURDUE UNIV LAFAYETTE INO MARCH 22-25
105-99 1965 CA 63 9587
- T38423 TRANSVERSE AND LONGITUDINAL OPTIC MODE STUDY IN MAGNESIUM FLUORIDE AND ZINC FLUORIDE.
BARKER A S JR
PHYS REV /USA/
136 A 5 1290-S 1964 SA 69 4314
- T38674 TRANSMITTANCE OF OPTICAL MATERIALS AT HIGH TEMPERATURES IN THE 1-MU TO 12-MU RANGE.
GILLESPIE O T OLSEN A L NICHOLS L H
APPL OPT
4 11 1488-93 1965 CA 63 17301
- T38703 THE DISPERSION OF METALS IN THE INFRARED SPECTRUM.
INGERSOLL L R
ASTROPHYS J
32 4 265-90 1910
- T38719 INFRARED ABSORPTION SPECTRUM OF SILICON DIOXIDE.
HANNA R
J AM CERAM SOC
48 11 595-9 1965
- T38726 AVOIDING ERRORS FROM STRAY RADIATION IN MEASURING THE SPECTRAL EMITTANCE OF DIFFUSELY REFLECTING SPECIMENS.
CLARK H E
APPL OPT
4 10 1356-7 1965 CA 64 177
- T39011 EFFECTS OF A SIMULATED HIGH-ENERGY SPACE ENVIRONMENT ON THE ULTRAVIOLET TRANSMITTANCE OF OPTICAL MATERIALS BETWEEN 1000 ANGSTROMS AND 3000 ANGSTROMS.
HEATH D F SACHER P A
APPL OPT
5 6 937-43 1966
- T39074 THE DIRECTIONAL SPECTRAL REFLECTANCE OF WELL-CHARACTERIZED SYMMETRIC V-GROOVED SURFACES.
PH.D. THESIS.
ZIPIN R B PURDUE UNIVERSITY LAFAYETTE INO
UNIV MICROFILMS PUBL
66-2335 1-203 1965
- T39263 NORMAL MODES IN HEXAGONAL BORON NITRIDE.
GEICK R PERRY C H RUPPRECHT G
PHYS REV
146 2 543-7 1966
- T39365 THERMAL RADIATION CHARACTERISTICS OF TRANSPARENT, SEMI-TRANSPARENT AND TRANSLUCENT MATERIALS UNDER NON-ISOTHERMAL CONDITIONS.
HOBBES H A FULWILER R C LEXINGTON LABS INC
CAMBRIDGE MASS USAF
DOC AND OTS
ASD-TDR-62-719/PT 3/ N66-37058
AD-635621 1-112 1966 CA 67 14-17
- T39490 VERIFICATION OF THE THEORY OF THE THERMAL TRAP.
COBLE M H FANG P C LUMSDAINE E
J FRANKLIN INST
282 2 162-7 1966
- T39543 THERMAL PROPERTIES OF SILICA. PART I - EFFECT OF TEMPERATURE ON INFRARED REFLECTION SPECTRA OF QUARTZ, CRYSTOBALITE AND VITREOUS SILICA.
GASKELL P H
TRANS FARADAY SOC
62 6 1493-504 1966
- T39754 DEVELOPMENT OF MATERIAL RESISTANT TO HIGH-INTENSITY THERMAL RADIATION.
ANDERSON R B DOUGLAS AIRCRAFT CO INC LONG BEACH
CALIF USAF
DOC
AFML-TR-65-438
1-245 1965
- T39835 INFRARED TRANSMITTANCE OF SOME CALCIUM ALUMINATE AND GERMANATE GLASSES. PAPER NO. 2625.
FLORENCE J M GLAZE F W BLACK M H
J RESEARCH NAT BUREAU STANDARDS
55 6 231-50 1955

- T39967 THERMAL EXPANSION AND OTHER PHYSICAL PROPERTIES OF THE NEWER INFRARED-TRANSMITTING OPTICAL MATERIALS.
BALLARD S S BROWDER J S
APPL OPTICS
5 12 1073-6 1966 CA 66-6 23992
- T39952 INFRARED SPECTRAL EMITTANCE MEASUREMENTS OF OPTICAL MATERIALS.
STIERWALT D L
APPL OPTICS
5 12 1911-15 1966 CA 66-6 24000
- T40230 REFLECTANCE OF COMPACTED POWDER MIXTURES.
SCHATZ E A
J OPT SOC AM
57 7 941-50 1967 CA 67 58717
- T40338 LIGHTWEIGHT OPTICAL MATERIALS. FINAL TECHNICAL DOCUMENTARY REPORT, 3 APR. 64-30 APR. 65.
ACITELLI M A GUMBY W L NAUJOKAS A A
BAUSCH AND LOMB INC RESEARCH AND DEVELOPMENT DIV ROCHESTER NY DOC
DDC
AFAL-TR-65-102
AD-601291 1-189 1966 TA 66-11 A-105
- T40412 A CONFIGURATION COORDINATE MODEL FOR THE THERMAL AND ULTRAVIOLET STABILITIES OF ALPHA-AL2 O3. FROM PROC. OF CONF. ON SPACECRAFT COATINGS DEVELOP. 1964.
SCHUTT J B MACKLIN B A NASA GODDARD SPACE FLIGHT CENTER GREENBELT MARYLAND
NASA AND GSFC
N66-37819 1-24 1966
- T40413 SPECTRAL EMISSIVITY OF METALS AFTER DAMAGE BY PARTICLE IMPACT. FROM PROC. OF CONF. ON SPACECRAFT COATINGS DEVELOP. 1964.
SCHOCKEN K FOUNTAIN J A
NASA AND GSFC
NASA-TM-X-56167 N66-37820 1-20 1964 PA N66-4-23 4632
- T40420 MONOCHROMATIC REFLECTANCE TESTS.
WETMORE R A BOEING CO SEATTLE WASH USAF DDC
BSO-TR-66-140 AD 483037 1-116 1963 TA 66-14 A-107
- T40525 FOUNDATIONAL RESEARCH PROJECTS.
COOK C F BUCHANAN R A BUTLER M A MC CARTHY D E RAINWATER J E NAVAL ORDNANCE LAB CORONA CALIF
DDC
NAWEP-8852 AD 635193 1-44 1966 TA 66-16 12
- T40528 INFRARED COATING STUDIES.
SULzbACH F TURNER A F BAUSCH AND LOMB INC ROCHESTER NY RESEARCH AND DEVELOPMENT DIV
DDC
AD 635670 1-33 1966 TA 66-17 92
- T40581 THE INFRA-RED TRANSMISSION OF THIN FILMS OF VARIOUS ORGANIC MATERIALS.
HELLS A J
J APP PHYS
11 137-40 1940
- T40583 HIGH REFLECTANCE COATINGS.
DUSS C H IEEE TRANS AND NUCLEAR SCI
13 1 729-34 1956 CA 63 279
DDC
AFCRL-IP-102 AFCRL-66-414
AD 637893 1-18 1966 TA 65-20 73
- T40746 RADIATIVE PROPERTIES OF SURFACES CONSIDERED FOR USE ON THE EXPLORER SATELLITES AND PIONEER SPACE PROBES.
SHIPLEY W S THOSTESON T O JET PROPULSION LABORATORY CALIFORNIA INSTITUTE OF TECHNOLOGY PASADEMA CALIFORNIA
DDC
JPL MEMO NO. 29-194 1-26 1960
- T40798 INFRARED EMISSION SPECTRUM OF SILICON CARBIDE HEATING ELEMENTS. /RESEARCH PAPER NO. 2810//
SYLHART J E FICHMOND J C
J RESEARCH NATL BUR STANDARDS
59 6 405-9 1957
- T40808 IMPURITY-SENSITIVE INFRARED ABSORPTION IN N-TYPE ALPHA-SILICON CARBIDE.
IHAI A
J PHYS SOC JAPAN
21 12 2610-15 1966 CA 66 -499-
- T40853 INFRARED REFLECTANCE AND OPTICAL CONSTANTS OF TEKTITES.
PERRY C H WRIGLEY J D JR
APPL OPT
6 3 586-7 1967
- T40977 DISTRIBUTION OF INFRARED ABSORPTION BANDS IN THE SPECTRUM OF CRYSTALLISING GLASSES IN THE REGION OF ABSORPTION BY WATER. //ENGLISH TRANSLATION OF ZH. FIZ. KHIM. 40 /6/ 1310-, 1966.//
TROITSKII O A SHMURAK S Z
RUSS J PHYS CHEM
40 6 701-2 1966
- T41421 DEVELOPMENT OF PHASE-CHANGE COATINGS. FROM THERMAL DESIGN PRINCIPLES OF SPACECRAFT AND ENTRY BODIES. PROGRESS IN ASTRONAUTICS AND AERONAUTICS. VOL. 21.
GRIFIN R N LINDER B GENERAL ELECTRIC COMP KING OF PRUSSIA PA
ACADEMIC PRESS NEW YORK
553-74 1969
AIAA 3RD THERMOPHYSICS CONFERENCE PAPER 68-776 1969
- T41606 ROTATING CYLINDER METHOD FOR MEASURING NORMAL SPECTRAL EMITTANCE OF CERAMIC OXIDE SPECIMENS FROM 1200 TO 1600 K.
CLARK H E MOORE D G
J RES NATL BUR STD
70 A 5 393-415 1966 JA 50 51
- T41607 AN ABSOLUTE METHOD OF DETERMINING TRANSMISSION AND REFLECTION COEFFICIENTS.
FRAY S J GOODWIN A R JOHNSON F A
QUARRINGTON J E
J SCI INSTR
40 8 387-90 1963 CA 65 11493
- T41640 SPECTRAL EMISSIVITY OF SILICON.
SATO T
JAPAN J APPL PHYS
6 3 339-67 1967
- T41934 ENVIRONMENTAL STUDIES OF THERMAL CONTROL COATINGS FOR LUNAR ORBITER. FROM THERMAL DESIGN PRINCIPLES OF SPACECRAFT AND ENTRY BODIES. PROGRESS IN ASTRONAUTICS AND AERONAUTICS. VOL. 21.
SLEMP W S HANKINSON T W E NASA LANGLEY RESEARCH CENTER HAMPTON VA
ACADEMIC PRESS NEW YORK
797-817 1969
AIAA 3RD THERMOPHYSICS CONFERENCE LOS ANGELES CALIF PAPER 68-792 1968
- T41945 THERMAL CONTROL EXPERIMENTS ON THE LUNAR ORBITER SPACECRAFT. FROM THERMAL DESIGN PRINCIPLES OF SPACECRAFT AND ENTRY BODIES. PROGRESS IN ASTRONAUTICS AND AERONAUTICS. VOL. 21.
CALDWELL C R NELSON P A THE BOEING COMPANY SEATTLE WASHINGTON
ACADEMIC PRESS NEW YORK
813-52 1969
AIAA 3RD THERMOPHYSICS CONFERENCE LOS ANGELES CALIF PAPER 68-793 1968
- T42781 DEVELOPMENT OF OPTICAL COATINGS FOR COS THIN FILM SOLAR CELLS. FINAL REPORT.
SCHAFFER J C HILL S R MARSHAL CHEMICAL CO CLEVELAND OHIO
NASA AND GSFC
NASA-CR-54965
N66-2F 373 1-63 1965 CA 66 1097-6
- T42872 LATTICE INFRARED SPECTRA OF BORON NITRIDE AND BORON MONOHPSPHIDE.
GIFLISSE P J MITRA S S PLENDL J N GRIFFIS R D HANSUR L C MARSHALL R PASCOE E A PHYS REV
155 3 1039-46 1967
- T42891 OPTICAL PROPERTIES OF INSULATORS IN THE EXTREME ULTRAVIOLET.
STEPHAN G LEMOINIER J-C ROBIN S
J OPT SOC AM
57 4 485-92 1967 CA 67 379-2

T42979 INFRARED COATING STUDIES. 9TH QUARTERLY REPORT
 CHANG L BAUSCH AND LOMB INC ROCHESTER NEW YORK
 DA
 DOC
 AD 471653 1-23 1965

T43162 THE ULTRAVIOLET REFLECTIVITY OF ALPHA- AND EETA-SIC.
 WHEELER B E
 SOLID STATE COMMUN
 6 4 173-5 1966 CA 65 186

T43493 AN INVESTIGATION OF THE THERMAL RADIATION PROPERTIES
 OF CERTAIN SPACECRAFT MATERIALS. FINAL REPT.
 BEVANS J T BROWN G L LUEDKE E F MILLER W D
 NELSON K E RUSSELL D A SPACE TECH LABS INC
 REDONDO BEACH CALIF
 NASA AND CFSTI
 STL-8633-6014-SU-000 NASA-CR-74772
 N66-24938 1-106 1962 PA N66-4-13 2489

T43741 INVESTIGATION OF MECHANISMS FOR OXIDATION PROTECTION
 AND FAILURE OF INTERMETALLIC COATINGS FOR REFRactory
 METALS.
 BARTLETT R W GAGE P R PHILCO CORP RES LABS
 NEWPORT BEACH CALIF USAF
 DOC AND CFSTI
 ASD-TDR-63-753 /PT II/
 AD 603167 1-127 1964

T44164 TRANSMITTANCE OF OPTICAL MATERIALS FROM 0.17 MICRONS
 TO 3.0 MICRONS.
 MC CARTHY D E
 APPL OPT
 6 21 1966-8 1967

T44300 OBSERVATION OF ABSORPTION EDGES IN THE EXTREME
 ULTRAVIOLET BY TRANSMITTANCE MEASUREMENTS THROUGH
 THIN UNBACKED METAL FILMS. FROM OPTICAL PROPERTIES
 AND ELECTRONIC STRUCTURE OF METALS AND ALLOYS.
 HUNTER W R HULBERT E O CENTER FOR SPACE
 RESEARCH US NAVAL RESEARCH LAB WASHINGTON D C
 NORTH-HOLLAND PUB CO AMSTERDAM
 136-46 1966

T44942 DEVELOPMENT OF HIGH TEMPERATURE INSULATION MATERIALS.
 BERG D I LEWIS D W WESTINGHOUSE RESEARCH LABS
 PITTSBURGH PA
 DOC
 AD-801194 1-107 1966

T45017 TRANSPARENCY LIMITS OF INTERFERENCE FILMS OF HAFNIUM
 AND THORIUM OXIDES IN THE ULTRAVIOLET REGION OF THE
 SPECTRUM. //ENGLISH TRANSLATION OF OPTIKA I
 SPEKTROSKOPIYA 22 / 6/ 9-0-5, 1967.//
 SVIRIDOV A A SUIKOVSKAYA N V
 OPT SPECTRY
 22 6 509-12 1967

T45177 SOME PROPERTIES OF VAPOR-DEPOSITED SILICON NITRIDE
 FILMS USING THE SiH4-NH3-H2 SYSTEM.
 BEAN K E GLEIM P S YEAKLEY R L RUNYAN W R
 J ELECTROCHM SOC
 11+ 7 733-7 1967 CA 67 68288

T45212 INFRARED DIFFUSE REFLECTOR COATING. MONTHLY PROGRESS REPORT. MAY 1967.
 SCHMITT R N HONEYWELL INC SYSTEMS AND RESEARCH
 CENTER ST PAUL MINNESOTA
 DOC
 AD-815634 1-33 1967

T45481 ULTRAVIOLET WINDOWS AND FILTERS FOR THE SPECTRAL
 REGION BETWEEN 1000 Å. AND 3000 Å.
 VOLCT G MAX-PLANCK-INST PHYS ASTROPHYS MUNICH
 GER
 NASA AND CFSTI
 ESRO-SM-6 N66-21733
 1-14 1965 CA 67 16356

T45583 A TECHNIQUE FOR THE MEASUREMENT OF SPECTRAL
 REFLECTANCE AT LOW TEMPERATURES IN THE INFRARED AND
 FAR INFRARED. FROM THERMAL DESIGN PRINCIPLES OF
 SPACECRAFT AND ENTRY BODIES. PROGRESS IN
 ASTRONAUTICS AND AERONAUTICS. VOLUME 21.
 JONES M C PALMER D C
 ACADEMIC PRESS NEW YORK
 543-57 1969

AAIA 3RD THERMOPHYSICS CONFERENCE LOS ANGELES CALIF
 JUNE 24-6 1968
 PAPER 69-775 1969

T45667 THE MEASUREMENT OF ABSORPTIVITY AND REFLECTIVITY.
 DE LA PERRELLE E T HERBERT M AERONAUTICAL RES
 COUNCIL VGT BRIT/
 MM50
 RAE-TN-RAD-APC-23879 APC-CP-601 NO2-14110
 N64-28033 1-22 1962 PA N64-2 2867

T45698 MEASUREMENT OF THE INFRARED SPECTRAL ABSORPTANCE OF
 OPTICAL MATERIALS.
 STIERWALT D L BERNSTEIN J B KIRK D O
 APPL OPT
 2 2169-73 1963

T45700 PAINTS TO REFLECT ULTRAVIOLET LIGHT.
 WILCOCK D F SOLLER M
 IND ENG CHEM
 32 1446-51 1969

T45929 RELATION BETWEEN SURFACE ROUGHNESS AND SPECULAR
 REFLECTANCE AT NORMAL INCIDENCE.
 BENNETT H E PORTEUS J O
 J OPT SOC AM
 51 2 123-9 1961

T45954 VAPOR DEPOSITION OF SILICON NITRIDE ON GALLIUM
 ARSENIDE BY Si CL4-NH3-N2 SYSTEM.
 SEKI M MORIYAMA K
 JAPAN J APPL PHYS
 6 11 1345-6 1967

T46043 INFRARED FILTERS OF ANTIREFLECTED Si, Ge, INDIUM
 ARSENIDE, AND INDIUM ANTIMONIDE.
 COX J T HASS G JACOBUS G F
 J OPT SOC AM
 51 7 714-18 1961

T47062 THE SPECTRAL REFLECTANCE OF ORDNANCE MATERIALS AT
 WAVELENGTHS OF 1 TO 12 MICRONS. FINAL REPT. NO.
 3196.
 WILBURN C K RENIUS O DETROIT ARSENAL CENTER
 LIME MICHIGAN
 DOC
 AD-87246 1-51 1955

T47394 MATERIALS EVALUATION FOR SERVICEABILITY OF OPTICAL
 GLASSES UNDER PROLONGED SPACE CONDITIONS. FINAL REPT
 JULY, 1965-JUNE 1967.
 HOLLAND W R AVCO ELECTRONICS DIV AVCO CORP
 TULSA OKLA
 NASA
 TR-67-G-109-F NASA-CR-65687
 N67-34672 1-73 1967

T47262 SPECTRAL EMISSIVITY OF HIGHLY DOPED SILICON. FROM
 THERMOPHYSICS OF SPACECRAFT AND PLANETARY BODIES.
 PROGRESS IN ASTRONAUTICS AND AERONAUTICS-VOL. 23.
 LIEBERT C H
 ACADEMIC PRESS NEW YORK AND LONDON
 17-60 1967

AIAA THERMOPHYSICS SPECIALIST CONFERENCE
 PAPER 67-3C2 1967

NASA AND CFSTI
 NASA-TM-1-52254 N-67-12718

T47322 REFLECTANCE MEASUREMENTS OF GOLD AND FUSED QUARTZ
 IN THE VACUUM ULTRAVIOLET.
 PLATZEDER K STEINMANN W
 J OPT SOC AMER
 58 4 588-9 1968 CA 69 14355

T47999 INVESTIGATION OF THE EFFECT OF SURFACE CONDITIONS ON
 THE RADIENT PROPERTIES OF METALS. PART II,
 MEASUREMENTS ON ROUGHENED PLATINUM AND OXIDIZED
 STAINLESS STEEL.
 ROLLING R E FUNAI A I LOCKHEED MISSILES AND
 SPACE CO PALO ALTO CALIF
 DOC AND CFSTI
 AFRL-TR-64-3E3/PT II/ LMSC-6-77-67-27
 AD-655384 1-242 1967 CA 67 38462

T48097 DEVELOPMENT OF SILICON INFRARED OPTICAL COMPONENTS
 /TRANSMITTING WINDOWS/.
 COLE F L MITCHELL G HICKS J AERONAUTICAL
 SYSTEMS CENTER WRIGHT-PATTERSON AIR FORCE BASE OHIO
 DOC
 AFMC-7R-60-7-715
 AD-250513 1-211 1968

T48135 FORMATION OF THIN POLYACRYLONITRILE FILMS AND THEIR
 ELECTRICAL PROPERTIES.
 HIRAI T NAKADA O
 JAPAN J APPL PHYS
 7 2 11-21 1968

- T48136 VAPOR DEPOSITION OF SILICON NITRIDE FILM ON SILICON AND PROPERTIES OF MANGANESE SULFIDE DIODES. SUGANO T HIRAI K KUROIMA K HON K JAPAN J APPL PHYS 7 2 122-7 1968
- T48288 INFRA-RED ABSORPTION IN SEMICONDUCTORS. FAN H Y REPORT ON PROGRESS IN PHYS 14 107-55 1956
- T48368 EFFECT OF SURFACE ROUGHNESS ON EMITTANCE OF NONMETALS. RICHMOND J C PROGR ASTRONAUT AERONAUT 18 167-72 1966
- T48912 OPTICAL PROPERTIES OF ALUMINUM OXIDE IN THE VACUUM ULTRAVIOLET. ARAKAWA E T WILLIAMS M M J PHYS CHEM SOLIDS 29 5 735-44 1968 CA 69 14334
- T49037 TEMPERATURE DEPENDENCE OF SURFACE TENSION FOR POLY /TETRAFLUORETHYLENE/ /SUPERCOOLED LIQUID/ ESTIMATED FROM CONTACT ANGLES. SCHONHORN H POLYMER 9 2 71-4 1968 CA 68 78682
- T49418 OPTICAL CHARACTERISTICS OF SILICON PHOTOCELLS AND THE EFFICIENCY OF A THERMOPHOTOELECTRIC CONVERTER. //ENGLISH TRANSLATION OF TEPLOFIZ, VYSOKIKH TEMPERATUR 5 /6/ 1979-86, 1967-// VASILEV A M GOLOVNER T M LANDSHAN A P LIODRENKO N S HIGH TEMPERATURE 5 6 967-73 1967
- T50298 THE THERMAL RADIATION CHARACTERISTICS OF SOME HIGH-EMITTANCE COATINGS FOR SPACE APPLICATIONS. LEWIS B M WADE W R SLEMP W S PROGAR D J NASA LANGLEY RESEARCH CTR HAMPTON VA NASA AND CFSTI NASA-TM-X-59389 N68-27441 1-15 1966
- T51165 THE REFLECTION AND TRANSMISSION OF INFRARED MATERIALS. V. SPECTRA FROM 2 MICRONS TO 50 MICRONS. MC CARTHY D E APPL OPT 7 10 1997-2000 1968
- T51317 CARBOXY-ORGANSILICAS - CHEMICALLY ACTIVE FILLERS FOR POLYMERS. COMMUNICATION I. SYNTHESIS AND ABSORPTION PROPERTIES OF CARBOXY-ORGANSILICAS AND THE REINFORCEMENT OF VINYL PYRIDINE RUBBER. CHUIKO A A PAVLIK G E TERTYKH V A CHUIKO E A ARTEMOV V A NEIMARK I E TSIPENYUK E V UKRAIN KHM ZH 32 4 371-7 1966
- T51318 CARBOXY-ORGANSILICAS - CHEMICALLY ACTIVE FILLERS FOR POLYMERS. COMMUNICATION I. SYNTHESIS AND ABSORPTION PROPERTIES OF CARBOXY-ORGANSILICAS AND THE REINFORCEMENT OF VINYL PYRIDINE RUBBER. //ENGLISH TRANSLATION OF UKRAIN. KHM. ZH. 32 /4/ 371-7, 1966./ CHUIKO A A PAVLIK G E TERTYKH V A CHUIKO E A ARTEMOV V A NEIMARK I E TSIPENYUK E V SOVIET PROGR IN CHEM 32 4 283-90 1966
- T51483 THE EMITTANCE OF GERMANIUM AND SILICON AT LOW TEMPERATURE. TECH. REPT. SCHLEIGER E R WEBB L A NAVAL RADIOLOGICAL DEFENSE LABORATORY SAN FRANCISCO CALIFORNIA DOC NRDL-TRX-68-6 AFML-TR-68-242 1-31 1968
- T51594 THE EMISSIVITY AND REFLECTIVITY OF COATINGS. STORY J G OFFICIAL DIGEST 33 283-99 1961
- T51607 INFRA-RED ABSORPTION AND REFLECTION SPECTRA. COBLENTZ W W PHYS REV 23 2 125-53 1906
- T52053 THERMAL RADIATION HEAT TRANSFER. VOLUME I. THE BLACKBODY, ELECTROMAGNETIC THEORY, AND MATERIAL PROPERTIES. THERMAL RADIATION HEAT TRANSFER. VOLUME II. RADIATION EXCHANGE BETWEEN SURFACES AND IN ENCLOSURES. SIEGEL R HOWELL J R LEWIS RESEARCH CENTER CLEVELAND OHIO NASA AND CFSTI NASA-SP-164 N68-28530 1-475 1968 PA N68-E-17 2904
- T52153 THE INFLUENCE OF ULTRAVIOLET RADIATION ON THE EMITTANCE AND SOLAR ABSORPTANCE OF A WHITE PAINT COATING. BRANDENBERG W M GENERAL DYNAMICS/ASTRONAUTICS SAN DIEGO CALIFORNIA DOC GOA-AE61-1223 AD-670151 1-13 1961 RR 69-2 87
- T52784 TOTAL NORMAL SPECTRAL CHARACTERISTICS OF CENTAUR PAINT COATINGS. SHINKLE F J GENERAL DYNAMICS/ASTRONAUTICS SAN DIEGO CALIFORNIA DOC AD-843115 1-37 1961
- T52872 STUDY OF DEPOSITED INSULATING LAYERS ON SILICON. NUTTALL R ROWOTHAM C EASTWOOD E FERRANTI LIMITED HYTHENSHAWE MANCHESTER ENGLAND DOC AD-827049 1-23 1967
- T52946 ANISOTROPY IN EMISSIVITY OF SINGLE-CRYSTAL REFRACTORY MATERIALS. AUTOIO G W SCALA E ANISOTROPY SINGLE-CRYST REFRACT COMPOUNDS PROC INT SYMP DAYTON OHIO 1967 1 357-81 1968 CA 70 7813
- T53491 OPTICAL SOLAR REFLECTOR. A HIGHLY STABLE, LOW AS/E SPACECRAFT THERMAL CONTROL SURFACE. MARSHALL K N BREUCH R A J SPACECRAFT ROCKETS 5 9 1051-6 1968 DOC AD-678799 1968
- T53495 THE TOTAL NORMAL ABSORPTIVITIES AND TOTAL NORMAL EMISSIVITIES OF SHERWIN WILLIAMS FLAT BLACK ACRYLIC PAINT AT -320, 0 AND 120 F. SHINKLE F J ASTRONAUTICS DIVISION GENERAL DYNAMICS CORPORATION SAN DIEGO CALIF DOC GOA-ER-AN-056 AD-681775 1-14 1961 RR 69-7 103
- T53964 A SPECTROSCOPIC INVESTIGATION OF THE SPECTRAL NORMAL EMITTANCE OF ULTRA-HIGH PURITY ALUMINUM. PH.D. THESIS. CURCIO J V UNIVERSITY OF MASS AMHERST MASSACHUSETTS UNIV MICROFILMS PUBL 68-9173 1-15 1968 PA N69-/6 937
- T53988 INFRARED OPTICAL MATERIALS, OLD AND NEW. BALLAPO S S JAPANESE J APPL PHYS 4 SUPPL. 1 23-9 1965 DOC AFCRL-67-0487 AD-663676 APPENDIX A 1-7 1967
- T54663 SAPPHIRE AND OTHER NEW COMBUSTION-CHAMBER WINDOW MATERIALS. CALINGAERT G HERON S D STAIR R S A E JOURNAL 39 5 448-50 1936
- T55341 EXPERIMENTS CONCERNING INFRARED DIFFUSE REFLECTANCE STANDARDS IN THE RANGE 3.0 TO 20.0 MICRONS. AGNEW J T MC QUISTAN R B J OPT SOC AMER 43 11 999-1007 1953
- T56239 SPECTRAL REFLECTING POWER OF SOME PAINT AND VARNISH COATINGS IN THE 0.25-15.0 MICRON REGION. AFANASEVA G D VINOGRADOVA L M ILLYASOV S G FRIODON M B TYUKIN B F LAKOKPASOCH MATER IKH FRIMEN 4 30-41 1969 CA 72 371

- T56727 SILICON. /DATA SHEETS/
NEUBERGER M NELLES S J HUGHES AIRCRAFT CO
ELECTRONIC PROPERTIES INFORMATION CENTER CULVER CITY
CALIFORNIA
DOC
EPIC-DS-162 AD-698342
1-275 1969 RR 70-4 175
- T57246 SOME PROPERTIES OF SILICON CARBIDE THIN FILMS
PREPARED BY ELECTRON BEAM EVAPORATION.
BUNTON G V
J PHYS D /APPL PHYS/
3 2 232-5 1970
- T57891 CORRELATIONS BETWEEN DISPERSION OF REFRACTION AND
TRANSMITTANCE OF THREE POLYMERS.
CLOUD G
J OPT SOC AM
60 8 1042-5 1970
- T58018 INFRARED SPECTRA AND CHARACTERISTIC FREQUENCIES OF
INORGANIC IONS.
MILLER F A WILKINS C H
ANALYTICAL CHEMISTRY
24 8 1253-94 1952
- T58966 OPTICAL REFLECTION AT GRAZING INCIDENCE FROM A SHOCK
FRONT.
PERT G J SEEDS G M SIMPSON D SHY P R
J APPLIED PHYS
41 8 3516-20 1970
- T60470 INFRA-RED SPECTRA OF INORGANIC SOLIDS. II. OXIDES,
NITRIDES, CARBIDES, BORIDES.
SHRAME E G JR MARGRAVE J L HELOCHE V M
J INORG NUCL CHEM
5 68-52 1957
- T61238 THERMAL RADIATIVE PROPERTIES -- METALLIC ELEMENTS
AND ALLOYS. VOL. 7 OF THERMOPHYSICAL PROPERTIES
OF MATTER - THE TPRC DATA SERIES.
TOULOUKIAN, Y. S. DEWITT, D. P.
THERMOPHYSICAL PROPERTIES RESEARCH CENTER,
PURDUE UNIV., LAFAYETTE, INDIANA.
IFI/PLENUM DATA CORP., NEW YORK.
1644PP., 1970.
- T61239 THE THERMAL CONDUCTIVITY OF ZIRCONIUM
DIBORIDE-SILICON CARBIDE COMPOSITE AT Elevated
TEMPERATURES. M.S. THESIS.
KO Y-C UNIVERSITY OF CINCINNATI CINCINNATI OHIO
UNIVERSITY OF CINCINNATI
1-70 1969
- TE1411 SILICON NITRIDE AS AN ANTIREFLECTION COATING FOR
SEMICONDUCTOR OPTICS.
LAFF, R. A.
APPL. OPT.
10 (4), 968-9, 1971.
- TE1459 EFFECTS OF SPACE ENVIRONMENT FACTORS ON THE
MECHANICAL, PHYSICAL, AND OPTICAL PROPERTIES OF
SELECTED TRANSPARENT ELASTOMERS.
WILLIAMS, J. G. JUDD, J. M.
LANGLEY RESEARCH CENTER, HAMPTON, VIRGINIA
51PP., 1971.
(NASA-TN-D-6216)
- T62013 EMISSIVITY OF SEMICONDUCTING SILICON CARBIDE AT HIGH
TEMPERATURES. //ENGLISH TRANSLATION OF FIZ. TEKH.
POLUPROV. 3 / 10 / 1544-48, 1969.//
DUGROVSKII G B
SOVIET PHYSICS-SEMICONDUCTORS
3 10 1290-3 1970
- T62587 A THEORETICAL AND EXPERIMENTAL STUDY OF LIGHT
SCATTERING IN THERMAL CONTROL MATERIALS. FROM HEAT
TRANSFER AND SPACECRAFT THERMAL CONTROL. PROGRESS IN
ASTRONAUTICS AND AERONAUTICS. VOL. 24.
GILLIGAN J E JAZUSKIENICZ J IIT RESEARCH
INSTITUTE CHICAGO ILL
MIT PRESS CAMBRIDGE MASSACHUSETTS
24 69-92 1970
- T62601 CHANGES IN THE OPTICAL DENSITY OF BONE TISSUE AND IN
THE CALCIUM METABOLISM OF THE ASTRONAUTS A. G.
NIKOLAEV AND V. I. SEVASTIANOV.
BIRIUKOV, E. N. KRASHNYKH, I. G.
KOSHICHESKAIA BIOLGIIA I MEDITSINA
4, 42-6, 1970.
- T63133 SPECTRAL AND POLARIZATION CHARACTERISTICS OF
SELECTED TARGETS AND BACKGROUNDS; INSTRUMENTATION
AND MEASURED RESULTS (3.3 - 14.0 MU M).
FAULKNER, D. HORVATH, R. ULRICH, J. P.
HOPK, E.
AIR FORCE AVIONICS LABORATORY, WRIGHT-PATTERSON
AIR FORCE BASE, OHIO
107PP., 1971.
(AFAL-TR-71-199)
- T63770 LONGWAVE ABSORPTION IN POLYTYPE ON ALPHA-SILICON
CARBIDE.
ILIN, M. A. RASHEVSKAYA, E. P. BURAS, E. M.
ZH. PRIKL. SPEKTROSK.
14 (5), 935-6, 1971.
(FOR ENGLISH TRANSLATION SEE TPRC NO. 72664)
- T64206 MEASUREMENT OF SOLAR - OPTICAL PROPERTIES OF GLAZING
MATERIALS.
FENNIGTON, C. M. MOORE, G. L.
ASHRAE J.
13 (7), 55-8, 1971.
- T64336 TOTAL EMISSIVITY OF SILICON AT HIGH TEMPERATURES.
JAIN, S. C. AGARWAL, S. K. BORLE, W. N.
TATA, S.
J. PHYS.
40 (8), 1207-9, 1971.
- T64446 ANTIREFLECTION COATINGS FOR SILICON IN THE
2.5-5.5 MICROMETER REGION.
SHERMAN, G. H. COLEMAN, P. D.
APPL. OPT.
10 (12), 2675-8, 1971.
- T64949 EFFECTIVE MASSES OF FREE ELECTRONS IN SILICON
CARBIDE.
ILIN, M. A. KIKHARSKII, A. A.
RASHEVSKAYA, E. P. SUBASHIEV, V. K.
FIZ. TVERD. TELA
13 (8), 2678-80, 1971.
(FOR ENGLISH TRANSLATION SEE TPRC NO. 6490)
- T65344 KINETICS OF THE NITRIDATION OF SILICON BY AMMONIA AT
HIGH TEMPERATURES.
KAMCHATKA, M. I. ORMONT, B. F.
RUSS. J. PHYS. CHEM.
45 (9), 1246-9, 1971.
(ENGLISH TRANSLATION OF ZH. FIZ. KHIM. 45 (9),
1246-9, 1971. FOR ORIGINAL SEE TPRC NO. 6333)
- T65652 INFLUENCE OF NEUTRON AND ALPHA PARTICLE IR-RADIATION
ON THE NEAR-INFRARED TRANSMISSION SPECTRA OF
BORON-DOPED CRYSTALS OF THE GH MODIFICATION OF
ALPHA-SILICON CARBIDE.
ILIN, M. A. KOSAGANOVA, M. G.
SOLOMATIN, V. N. BARINOV, YU. V.
BUL'AKOV, YU. V.
FIZ. TEKH. POLUPROV.
5 (3), 526-9, 1971.
(FOR ENGLISH TRANSLATION SEE TPRC NO. 6563)
- T66579 THERMAL RADIATIVE PROPERTIES -- NONMETALLIC SOLIDS,
VOL. 8 OF THERMOPHYSICAL PROPERTIES OF MATTER --
THE TPRC DATA SERIES.
TOULOUKIAN, Y. S. DEWITT, D. P.
THERMOPHYSICAL PROPERTIES RESEARCH CENTER,
PURDUE UNIV., LAFAYETTE, INDIANA.
IFI/PLENUM DATA CORP., NEW YORK.
1763PP. 1972.
- T68308 DEVELOPMENT OF TECHNIQUES AND ASSOCIATED
INSTRUMENTATION FOR HIGH TEMPERATURE EMISSIVITY
MEASUREMENTS.
CUNNINGTON, G. R. FUNAI, A. I.
LOCKHEED MISSILES AND SPACE CO., PALO ALTO, CALIF.
36PP., 1972.
(N72-2447A, NASA-CR-123647, AVAIL. NTIS)
- T68743 SOME NEW WINDOW MATERIALS FOR THE NEAR INFRARED
REGION.
JANAROHANAN PILLAI, K. K. PAMAKRISHNAN, K.
RAO, H. N. V. SURAHANIAN, V.
SURYANARAYANA, C. V.
INDIAN J. PURE APPL. PHYS.
10 (2), 177-8, 1972.
- T68866 A DESCRIPTION OF THE OPTICAL BIOPRERATIONAL
CHARACTERISTICS OF STAINLESS STEEL 304.
SECKHAN, L. M.
AIR FORCE ACADEMY, COLORADO DEPT. OF AERONAUTICS
24PP., 1972.
(AF-740 121, OFAN-TP-72-3, AVAIL. NTIS)

- T68915 APPLICATION OF THE FMIR (FRUSTRATED MULTIPLE INTERNAL REFLECTION) TECHNIQUE TO THE IR-SPECTROSCOPIC IDENTIFICATION OF COATED FILMS AND PAPERS.
JAYME, G. TRASER, G.
ANGEM, HAKROMOL, CHEM.
21, 87-104, 1972.
- T70731 THERMAL CONDUCTIVITY OF INDIUM IN THE SOLID AND LIQUID STATES.
PASHAYEV, B. P. MAGOMEDOV, A. M-A.
HEAT TRANSFER-SUV. RES.
5 (2), 1-3, 1973.
- T70779 PREPARATION OF SILICON NITRIDE BY VAPOR-PHASE REACTION.
KIJIMA, K. SETAKA, N. ISHII, M.
TANAKA, M.
J. AMER. CERAM. SOC.
56 (6), 346, 1973.
- T70992 MEASUREMENT OF THE EMISSIVITY OF MATERIALS PRODUCED BY POWDER AND PLASMA METALLURGY TECHNIQUES.
SHIRNOV, E. V.
SOV. POWDER MET. METAL CERAM.
12 (11), 923-7, 1972.
(ENGLISH TRANSLATION OF POROSH. MET., 12 (11), 79-84, 1972; FOR ORIGINAL SEE TPRC NO. 70054)
- T71403 INFRARED ABSORPTION STUDY OF ION-IMPLANTED SILICON.
MORGAN, H. T.
VIRGINIA POLYTECH. INST., BLACKSBURG, VA.
PH.D. THESIS
87PP., 1972.
(UM 72-23.842, AVAIL. UNIV. MICROFILMS)
- T71498 INFRARED SPECTRA OF SILICA AND SILICON IV (NITRIDE PREPARED BY CATHODIC AND PLASMA TORCH SPRAYING.
BUCH, J.
ELEKTROTECH. CAS.
24 (3), 168-90, 1973.
- T71819 REFLECTION SPECTRA OF ORGANIC POLYMERS IN THE 5-23.1 EV QUANTUM ENERGY RANGE.
VINOKUROVA, L. N. CHERKASOV, YU. A.
KISILITSA, P. P.
OPT. SPEKTROSK.
34 (4), 805-7, 1973.
(FOR ENGLISH TRANSLATION SEE TPRC NO. 72331)
- T71893 TOTAL EMITTANCE AND MONOCHROMATIC EMITTANCE OF METALS AND NONMETALS.
KANAYAMA, K.
HEAT TRANSFER-JAP. RES.
2 (3), 78-104, 1973.
- T71959 TOTAL EMISSIVE POWER OF ALLOYS OF SILICON WITH IRON, COBALT, AND NICKEL IN THE TEMPERATURE RANGE FROM 900 TO 1750 C.
SHVAREV, K. M. BAUM, B. A. GELD, P. V.
11 (1), 66-76, 1973.
(ENGLISH TRANSLATION OF TEPLOFIZ. VVS. TEMP., 11 (1), 78-83, 1973; FOR ORIGINAL SEE TPRC NO. 71958)
- T72331 THE REFLECTANCE SPECTRA OF ORGANIC POLYMERS IN THE 5-23.1 EV ENERGY RANGE.
VINOKUROVA, L. N. CHERKASOV, YU. A.
KISILITSA, P. P.
OPT. SPECTROSK., USSR
34 (4), 644-6, 1973.
(ENGLISH TRANSLATION OF OPT. SPEKTROSK., 34 (4), 803-7, 1973; FOR ORIGINAL SEE TPRC NO. 71819)
- T72608 IMPURITY ABSORPTION IN NITROGEN-DOPED ALPHA-SILICON CARBIDE (15 R AND 27 R) CRYSTALS.
PURTSALADZE, I. M. KHAVTASI, L. G.
FIZ. TEKH. POLUPROV.
5 (10), 1871-6, 1971.
(FOR ENGLISH TRANSLATION SEE TPRC NO. 72609)
- T72777 ABSORPTION COEFFICIENT OF INFRARED LASER WINDOW MATERIALS.
DEUTSCH, T. F.
J. PHYS. CHEM. SOLIDS
34 (12), 2091-104, 1973.
- T73802 EFFECT OF CONTAMINATION ON THE OPTICAL PROPERTIES OF TRANSMITTING AND REFLECTING MATERIALS EXPOSED TO A MMH/N2O4 ROCKET EXHAUST.
ROTHMAN, R. L. SPISZ, E. W. JACK, J. R.
NASA-TM-X-69204
12PP., 1973.
(H73-20942)
- T73834 MICROWAVE PROPERTIES OF GERMANIUM AND SILICON WINDOWS.
LOTHROP, R. W.
U. S. NAVAL REPT. NNL-TR-2815
73PP., 1972.
(AD-753 466)
- T74089 INVESTIGATION OF THE EMISSIVITY OF LIQUID FERROSILICON.
BAUM, B. A. SHVAREV, K. M. GEL'D, P. V.
RUSS. MET., (METALLY)
(3), 60-3, 1971.
(ENGLISH TRANSLATION OF IZV. AKAD. NAUK SSSR, METAL., (3), 86- , 1971; FOR ORIGINAL SEE TPRC NO. 74088)
- T74177 INDUSTRIAL PRODUCTION OF PARTS FROM SELF-BONDED SILICON CARBIDE AT THE BROYARY POWDER METALLURGY FACTORY.
FRANTSovich, I. N. GNESIN, G. G.
DYBAN, YU. P. GAIUCHENKO, A. K.
OSOVITSKII, E. I. OSTROVERKHOV, V. I.
SOV. POWDER MET. METAL CERAM.
11 (12), 997-9, 1972.
(ENGLISH TRANSLATION OF POROSH. MET., 11 (12), 61-3, 1972; FOR ORIGINAL SEE TPRC NO. 74176)
- T76525 EMITTANCE MEASUREMENTS ON INFRARED WINDOWS EXHIBITING WAVELENGTH DEPENDENT DIFFUSE TRANSMITTANCE.
HATCH, S. E.
APPL. OPT.
1 (5), 595-601, 1962.
- T76795 INFRARED SPECTRA OF PLASTICS AND RESINS. PART 2.
MATERIALS DEVELOPED SINCE 1954.
STIMLER, S. S. KAGARISE, R. E.
U. S. NAVAL REPT. NRL-6392
38PP., 1966.
(AD-634 427)
- T76798 INFRARED SPECTRA OF COMPLEX ORGANIC MATERIALS USING A PYROLYtic TECHNIQUE.
LARA, M. O.
NAVAL AIR RESEARCH FACILITY, ALAMEDA, CALIF.
89PP., 1967.
(AD-822 136)
- T76806 IR REFLECTION FROM SILICON AT A HIGH NONEQUILIBRIUM-CARRIER CONCENTRATION.
BOBROVA, E. A. VAVILOV, V. S. GALKIN, G. N.
SOV. PHYS. SOLID STATE
12 (4), 959-61, 1970.
(ENGLISH TRANSLATION OF FIZ. TVERO. TELA, 12 (4), 1232-5, 1970; FOR ORIGINAL SEE TPRC NO. T75805)
- T76812 INFRARED SPECTRA OF PLASTICS AND RESINS.
KAGARISE, R. E. WEINBERGER, L. A.
NAVAL RESEARCH LAB.
38PP., 1954.
(AD-32 E35)
- T76814 DETERMINATION OF THE THERMAL EMITTANCE STABILITY OF SPACECRAFT RADIATOR COATINGS.
CONRADY, W. P.
U. S. AIR FORCE REPT. ASD-TDR-63-429
87PP., 1963.
(AD-415 299)
- T76891 HIGH TEMPERATURE OPTICAL GLASSES. LOW EXPANSION MATERIALS.
CORNING GLASS WORKS
CORNING REPORT NO. 7943
10PP., 1971.
- T76945 VITREOUS SILICA.
DUMBCHAUGH, W. H. SCHULTZ, P.
ENCYCL. CHEM. TECHNOL.
18, 73-125, 1969.
- T76946 VITREOUS SILICA FOR THE SCIENTIFIC GLASSBLOWER.
BROWELL, T. P. HETHERINGTON, G.
J. BRIT. SOC. SCI. GLASSBLOWERS
3 (1), 1-12, 1966.
- T76947 POLARIZED REFLECTANCE DATA GATHERED WITH THE GENERAL DYNAMICS CONVAIR AEROSPACE REFLECTANCE MEASURING DEVICES.
GENERAL DYNAMICS CONVAIR AEROSPACE DIVISION, SAN DIEGO, CALIFORNIA, CASD-ASC-74-061
47PP., 1976.
- T77041 FUSED SILICA.
DYNASIL CORP. OF AMERICA
DYNASIL-702
17PP.

- T77043 UTILIZATION OF INFRARED ABSORPTION SPECTROSCOPY FOR TESTING ACRYLIC FIBERS. INFRARED SPECTRUM OF THE MELANA ACRYLIC FIBER.
BAETONIU, P.
IND. TEKST.
20 (6), 385-30, 1969.
- T77096 CHANGES IN THE OPTICAL PROPERTIES AND CARRIER DENSITY IN SILICON AND GALLIUM ARSENIDE DUE TO STRONG PHOTOEXCITATION WITH A RUBB LASER.
BLINOV, L. M., VAVILOV, V. S., GALKIN, G. N.
SOV. PHYS. SEMICOND.
1 (9), 1124-3, 1967.
(ENGLISH TRANSLATION OF FIZ. TEKH. POLUPROV., 1 (9), 1351-7, 1967; FOR ORIGINAL SEE TPRC NO. 77095)
- T77102 COMPARISON OF ABSORPTIVE ENERGY AND PENETRATING ENERGY OF VARIOUS POLYMER FILMS AND THEIR RADIATION COEFFICIENTS.
FUJIKURA, Y., ISHIKAWA, K.
SEN-I GAKKAISHI
24 (11), 583-11, 1968.
- T77125 ABSORPTION COEFFICIENT OF UNPIGMENTED POLY (METHYL METACRYLATE), POLYSTYRENE, POLYCARBONATE, AND POLY (4-METHYLPENTENE-1) SHEETS.
PROGELHOF, R. C., FRANEY, J., HAAS, T. W.
J. APPL. POLYMER SCI.
15 (7), 1803-7, 1971.
- T77135 THE USE OF NMR METHODS AND INFRARED SPECTROSCOPY TO STUDY THERMOREACTIVE WATER-SOLUBLE ACRYLIC COPOLYMERS.
KVASNICKOV, YU. P., FILIPPOVICH, G. F.
J. APPL. CHEM., USSR
61 (10), 2188-90, 1968.
(ENGLISH TRANSLATION OF ZH. PRIKL. KHIM., 41 (10), 2311-3, 1968; FOR ORIGINAL SEE TPRC NO. T77134)
- T77141 THE DIELECTRIC PROPERTIES OF ORGANOSILICON FILMS AND THE EFFECT OF GAMMA-RADIATION ON THEIR STRUCTURE.
TKACHUK, B. V., PEROVA, L. V.
KOLOTYRKIN, V. N.
VYSOKOMOL. SOEDIN.
13 A (4), 828-32, 1971.
- T77362 VACUUM ULTRAVIOLET SURVEILLANCE TECHNIQUES.
MARMO, F. F., ENGLEMAN, A., SCHULTZ, E. D.
GCA CORPORATION, BEDFORD, MASS.
GCA-TR-67-2-A
58PP., 1967.
(AD-379 842)
- T77381 PRELIMINARY EVALUATION OF CAPABILITIES FOR SPACE STUDIES IN THE FIELD OF MATERIALS AND PROCESSES.
TURNER, H. C., KELLER, E. E.
FAULKENBERRY, B. H.
GENERAL DYNAMICS, CONVAIR, SAN DIEGO, CALIF.
GDA-MP-59-291
8PP., 1959.
(AD-337 722)
- T77510 INDIRECT TWO-PHOTON TRANSITIONS IN SILICON AT 1.06 MU M.
REINTJES, J. F., MC GRODDY, J. C.
PHYS. REV. LETT.
30 (19), 901-3, 1973.
- E00620 DIELECTRIC CONSTANT OF GERMANIUM AND SILICON AS A FUNCTION OF VOLUME.
CARDONA, M.
PHYS. AND CHEM. OF SOLIDS
8, 204-6, 1959.
- E02863 OPTICAL PROPERTIES OF SILICON CARBIDE.
NAMBA, M.
PHYS. AND CHEM. OF SOLIDS
2 (4), 339-340, 1957.
- E03382 THE TEMPERATURE-DEPENDENCE OF THE REFRACTIVE INDEX OF SILICON.
LUKES, F.
PHYS. AND CHEM. OF SOLIDS
11 (3-4), 342-344, 1959.
- E03590 LATTICE ABSORPTION BANDS IN SILICON.
JOHNSON, F. A.
PHYS. SOC., PROC.
73, 265-72, 1959.
- E03607 OPTICAL PROPERTIES OF PURE AND DOPED SILICON CARBIDE.
LELY, J. A., KFOEGER, F. A.
INI SEMICONDUCTORS AND PHOSPHORS
PROC., INTERNAT. COLLOQUIUM, PAPENKIRCHEN,
ED. BY SCHOEN, H. AND H. WELKE, N.Y., INTERSCI.
514-524PP., 1958.
- E03901 INFRARED REFRACTIVE INDEXES OF SILICON GERMANIUM AND MODIFIED SELENIUM GLASS.
SALBERG, C. A., VILLA, J. J.
OPTICAL SOC. OF AMERICA, J.
47 (3), 244-6, 1957.
- E04561 THE TEMPERATURE DEPENDENCE OF THE SILICON REFRACTIVE INDEX.
LUKES, F.
CZECHOSLOVAK J. OF PHYS.
10 (4), 317-326, 1960.
- E09770 NITROGEN IN SILICON.
KAISER, W., THURMOND, C. D.
JOURNAL OF APPLIED PHYSICS
30 (3), 427-431, 1959.
- E12808 THE THERMAL PROPERTIES OF TWENTY-SIX SOLID MATERIALS TO 5000 DEGREES F OR THEIR DESTRUCTION TEMPERATURES.
U. S. AIR FORCE REPT. ASO-TRD-62-765,
JAN., 1963.
(AD-298 061)
- E13314 OPTICAL EFFECTS IN BULK SILICON AND GERMANIUM.
BRIGGS, H. B.
PHYS. REV.
77 (2), 1970.
- E16981 DIAKON ACRYLIC MATERIALS FOR EXTRUSION.
IMPERIAL CHEM. INDUSTRIES LTD., PLASTICS DIV., GREAT BRITAIN
1-17 AND 60-63, 1962.
(BULL. NO. 21/14/662)
- E17415 INFRA-RED TRANSMISSION OF ALPHA SILICON CARBIDE.
LIFSON, H. G.
INI SILICON CARBIDE, A HIGH TEMPERATURE SEMICONDUCTOR,
CONF. ON SILICON CARBIDE, BOSTON, 1959.
ED. BY J. R. O'CONNOR AND J. SMILTEENS, N.Y., SYMPOSIUM PUB. DIV., PERGAMON PRESS
371-375PP., 1960.
- E17419 INTRINSIC OPTICAL ABSORPTION IN SINGLE CRYSTAL SILICON CARBIDE.
PHILIPP, H. R., TAFT, E. A.
INI SILICON CARBIDE, A HIGH TEMPERATURE SEMICONDUCTOR,
CONF. ON SILICON CARBIDE, BOSTON, 1959. ED.
BY J. R. O'CONNOR AND J. SMILTEENS, N.Y., SYMPOSIUM PUB. DIV., PERGAMON PRESS
365-371PP., 1960.
- E17420 INFRA-RED PROPERTIES OF SILICON CARBIDE.
SPITZER, W. G., ET AL.
INI SILICON CARBIDE, A HIGH TEMPERATURE SEMICONDUCTOR,
CONF. ON SILICON CARBIDE, BOSTON, 1959. ED.
BY J. R. O'CONNOR AND J. SMILTEENS, N.Y., SYMPOSIUM PUB. DIV., PERGAMON PRESS
347-365PP., 1960.
- E19326 REFRACTIVE INDICES OF LITHIUM FLUORIDE AND FUSED SILICA FROM 2000 TO 3000 ANGSTROMS.
JERRARD, H. G., TURPIN, J.
OPTICAL SOC. OF AMERICA, J.
55 (4), 453P, 1965.
- E21758 INTERSPECIMEN COMPARISON OF THE REFRACTIVE INDEX OF FUSED SILICA.
HALITSON, I. H.
OPTICAL SOC. OF AMERICA, J.
55 (10), 1206-1209, 1965.
- E26638 ORGANIC MATERIALS. I. DIELECTRIC PROPERTIES OF THIN ORGANIC POLYMER FILMS. II. CONDUCTION MECHANISM IN THE COPPER POLYMERS OF DIKETOCYCLOLUTEN:OIL.
CAFAGJAL, B. G., III.
U. S. AIR FORCE REPT. AFAL-TR-66-93,
101PP., 1966.
(AD 479 AE2)
- E27192 PREPARATION AND PROPERTIES OF PYROLYtic SILICON NITRIDE.
DOO, V. V.
ELECTROCHEM. SOC.
113 (12), 1273-1281, 1966.

- E27985 FLUOROCARBONS.
DU PONT DE NEUMOURS, E.I., AND CO., INC.
FREON PRODUCTS DIV. FREON E SERIES
1966.
- E30603 ABSOLUTE PRECISION DETERMINATION OF LATTICE CONSTANTS IN SINGLE CRYSTAL SILICON WITH ELECTRON INTERFERENCE.
KIELOL, M.
Z. FUEV NATURFORSCH
22 A (1), 79-91, 1967.
- E32764 THE PREPARATION AND PROPERTIES OF SILICON NITRIDE PRODUCED BY A RADIO FREQUENCY GLOW DISCHARGE REACTION OF SILANE AND NITROGEN. PREPARATION AND PROPERTIES OF SILICON NITRIDE.
KUHAND, Y.
JAPAN. J. OF APPL. PHYS.
7 (1), 88, 1968.
- E34318 SILICON NITRIDE.
WADCOCK, F. R.
HIRST RESEARCH CENTRE, WEMBLEY, ENG.
174 C (15), 10PP., 1967.
(C.V.D. RESEARCH PROJECT RP6-43, AD 825 410)
- E37991 ABSORPTION OF LASER RADIATION IN TRANSPARENT SUBSTANCES UNDER CONDITIONS OF APPEARANCE OF OPACITY.
PILIPETSKII, N. F.
SOVIET PHYS. JETP
27 (4), 568-9, 1968.
- E42663 SILICON NITRIDE AS A MASK IN PHOSPHORUS DIFFUSION.
FRAENZ, I. LANGHEINRICH, W.
SOLID STATE ELECTRONICS
12 (12), 955-62, 1969.
- E45777 THE OPTICAL CONSTANTS OF AMORPHOUS SILICON DIOXIDE AND GERMANIUM DIOXIDE IN THE VALENCE BAND REGION.
ZOLOTAREV, V. M.
OPT. AND SPECTRO.
23 (1), 1970.
- E46853 PRODUCTION OF SILICON NITRIDE FILMS ON SILICON BY ELECTROLYSIS IN LIQUID AMMONIA.
BARTNITSKII, I. N.
SOVIET ELECTROCHEMISTRY
5 (8), 1197-9, 1976.
- E58966 THE EFFECTS OF DEFORMATION ON THE INFRARED OPTICAL PROPERTIES OF GERMANIUM AND SILICON AND ON THE ELECTRICAL PROPERTIES.
MEYER, M. D.
UNIVERSITY OF ILLINOIS, PH.D. THESIS
111PP., 1965.
(UNIV. MICROFILMS NO. 65-11835)
- E62600 KODAK IRTRAN INFRARED OPTICAL MATERIALS. CONDENSED DATA FOR KODAK IRTRAN INFRARED OPTICAL MATERIALS.
EASTMAN KODAK COMPANY
KODAK PUBL. NO. U-71 AND U-72
57PP., 1971.
- E62601 LUCITE ACRYLIC RESINS DESIGN HANDBOOK,
E. I. DU PONT DE NEUMOURS
64PP., 1968.
- E64849 OPTICAL CHARACTERISTICS OF AMORPHOUS QUARTZ IN THE 1400-200 CM REGION.
POPOVA, S. I. TOLSTYKH, T. S.
VJROBEV, V. T.
OPT. SPECTROS., USSR
33 (4), 444-5, 1972.
(ENGLISH TRANSLATION OF OPT. SPEKTROS., 33 (4), 801-3, 1972; FOR ORIGINAL SEE E64848)
- E64850 STUDY OF SODIUM SILICATE GLASSES IN THE INFRARED BY MEANS OF THIN FILMS.
CROZIER, D. DOUGLAS, R. W.
PHYS. CHEM. GLASSES
6 (6), 240-5, 1965.
- E65870 IMPROVEMENT IN THE DETECTION OF OXYGEN IN SILICON BY IR ABSORPTION.
PAJOT, B.
SOLID STATE ELECTRON.
12 (11), 923-5, 1969.
- E66194 THE SURFACE ABSORPTION OF UNPAINTED ALLOYS AT 10.6 MICRONS.
CUNNINGHAM, S. S. LAUGHLIN, W. T.
U. S. AIR FORCE REPT. AFWL-TR-74-12
34PP., 1974.
(AD-775 763)
- A00001 INFRARED RADIATION METHODS.
FAININ, E. R. GRIMM, T. C.
MC DONNELL AIRCRAFT COMPANY
REPORT MDC A1961, 131PP., 1972.
- A00002 PRIVATE COMMUNICATION.
CUNNINGTON, G. R.
LOCKHEED PALO ALTO LABORATORY
JULY 17, 1975.
- A00003 THE PROCEEDINGS OF THE 1973 000 LASER EFFECTS HARDENING CONFERENCE.
HARMON, N. F. (EDITOR)
THE MITRE CORPORATION, HIGH ENERGY LASER SUPPORT PROGRAM, PROJECT 809A, BEDFORD, MA.
11, 1974.
- A00004 ABSORPTIVITY AND REFLECTIVITY OF SELECTED RADAR TARGET MATERIALS AT 10.6 MICRONS.
FIRSDON, R.
AIR FORCE AVIONICS LAB., AIR FORCE SYSTEMS COMMAND, WRIGHT-PATTERSON AIR FORCE BASE, OHIO
U. S. AIR FORCE REPT. AFAL-TR-68-268, 1968.
(AD 563686)
- A00005 METALS HANDBOOK.
LYMAN, T. (EDITOR)
AMERICAN SOCIETY FOR METALS, METALS PARK, OHIO
VOL. 1, 6TH EDITION, 1300PP., 1961.
- A00006 ALUMINUM STANDARDS AND DATA.
THE ALUMINUM ASSOCIATION, NEW YORK, NEW YORK
174PP., 1966.
- A00007 CRYSTAL STRUCTURES.
WYCKOFF, R. M. G.
VOLUME 1, SECOND EDITION, INTERSCI. PUB., NEW YORK
1963.
- A00008 PROPERTIES OF Ti-6Al-6V.
TIMET, TITANIUM ENGINEERING
TITANIUM METALS CORP. OF AMERICA, NEW JERSEY,
BULLETIN NO. 1, 44PP, NO DATE.
- A00009 PRIVATE COMMUNICATION.
KANDRACH, G. S.
CORNING GLASS WORKS, ADVANCED PRODUCT SALES DEPT.,
CORNING, NEW YORK
FEBRUARY 17, 1975.
- A00010 TECHNICAL LITERATURE
THERMAL AMERICAN FUSED QUARZ COMPANY
PUBLICATION FM-10-70, NO DATE.
- A00011 ANALYSIS OF HIGH-PURITY SYNTHETIC VITREOUS SILICAS.
ETHERINGTON, G. BELL, L. W.
PHYS. CHEM. GLASSES
8 (5), 208-8, 1967.
- A00012 USE OF POLISHED FUSED SILICA TO STANDARDIZE DIRECTIONAL POLARIZED EMITTANCE AND REFLECTANCE MEASUREMENTS IN THE INFRARED.
CHANPETIER, F. J. FFIESE, G. J.
U.S. AIR FORCE REPT. SAMSO-TR-74-262,
79PP., 1974.
- A00013 PRIVATE COMMUNICATION.
PLUMMER, W. A.
CORNING GLASS WORKS, RESEARCH DEPT., CORNING, N. Y.
JUNE 27, 1975.
- A00014 CUBIC BORON NITRIDE: HANDBOOK OF PROPERTIES.
DE VRIES, R. C.
GENERAL ELECTRIC CO., REPORT 72CR017A,
1-17, 1972.
- A00015 ALUMINA CERAMICS.
WESTERN GOLD AND PLATINUM CO.
CATALOG NO. C118, NO DATE.
- A00016 NRL LASER EFFECTS HANDBOOK.
NEIGHOURS, J. R.
NRL MEMO. REPT. 2737
1974.
- A00017 JANAF THERMOCHEMICAL TABLES.
STULL, D. R. PROPHET, M.
SECOND EDITION, NSPS-NBS 37,
1141PP., 1971.
- A00018 REFLECTION OF ELECTROMAGNETIC WAVES FROM ROUGH SURFACES.
DAVIES, M.
PROC. INST. FLG. ENGS.
101, 223-14, 1954.

- A60019 REFLECTION OF ELECTROMAGNETIC WAVES FROM SLIGHTLY ROUGH SURFACES.
RICE, S. O.
COMMUN. PURE APPL. MATH.
4, 351-78, 1951.
- A60020 EFFECT OF SURFACE TEXTURE ON DIFFUSE SPECTRAL REFLECTANCE, PART B: SURFACE TEXTURE MEASUREMENTS OF METAL SURFACES.
SPANGENBERG, D. B. STRANG, A. G.
CHAMBERLIN, J. L.
SYMPORIUM ON THERMAL RADIATION OF SOLIDS
IKATZOFF, S., EDITOR
NASA SP-55, 169-77, 1965.
- A60021 SURFACE ROUGHNESS, WAVINESS AND LAY.
AMERICAN STANDARDS ASSOCIATION
ASA B46-1, 1955.
- A60022 HOTT, N. F. ZENER, C.
PROC. CAMBRIDGE PHIL. SOC.
3P, 249, 1934.
- A60023 THE QUANTUM THEORY OF DISPERSION IN METALLIC CONDUCTORS.
KRONIG, R. D. L.
PROC. ROYAL SOC.
133 A, 255, 1931.
- A60024 OPTICAL PROPERTIES OF SEMICONDUCTORS.
MOSS, T. S.
BUTTERWORTH AND CO., LTD., LONDON
1961.
- A60025 A CONCISE GUIDE TO PLASTICS.
SIMONDS, M. R. CHURCH, J. M.
REINHOLD PUBLISHING CORPORATION, NEW YORK
1965.
- A60026 HIGH SILIC/ GLASS, QUARTZ, AND VITREOUS SILICA.
LAUFER, J. S.
J. OPT. SOC. AMER.
55, 458-60, 1965.
- A60027 PRIVATE COMMUNICATION.
CUNNINGTON, G. R.
LOCKHEED PALO ALTO LABORATORY, PALO ALTO, CALIFORNIA
MAY 23, 1975.
- A60028 OPTICAL LIMITING IN SEMICONDUCTORS.
RALSTON, J. H. CHANG, R. K.
APPL. PHYS. LETT.
15 (6), 164-6, 1969.
- A60029 REFLECTIVITY ENHANCEMENT OF SEMICONDUCTORS BY Q-SWITCHED RUBY LASERS.
BIRNBAUM, M. STOCKER, T. L.
J. APPL. PHYS.
39 (13), 6032-6, 1968.
- A60030 DIFFRACTION OF LIGHT BY LASER GENERATED FREE CARRIERS IN SILICON: DISPERSION OR ABSORPTION.
HOERMAN, J. P.
PHYS. LETT.
32 A (5), 305-6, 1970.
- A60031 PLASMA RESONANCE ON NON-EQUILIBRIUM CARRIERS IN SEMICONDUCTORS.
GALKIN, G. N. BLINOV, L. M. VAVILOV, V. S.
GOLOVASHKIN, A. G.
JETP LETTERS
7, 69-72, 1968.